

ATTENDANT EQUIPMENT

1- AND 2-TYPE TELEPHONE CONSOLE WITH SWITCHED LOOP TERMINATION

METHOD OF OPERATION

NO. 5 CROSSBAR CENTREX CO

ARRANGED FOR PHASE III CENTREX

1. GENERAL

1.01 This section covers the method of operating 1- and 2-type telephone consoles with switched loop termination when used as the attendant position in No. 5 crossbar offices arranged for Phase III centrex.

1.02 When initiating calls in Tables B through M, usage (PEG) registers associated with the attendant trunks, auxiliary trunks, and attendant access trunks will score. The reporting of these register operations should be made in accordance with local instructions.

2. METHOD OF OPERATION

2.01 When operational tests of the 1- and 2-type consoles are made it will be necessary to remove the customer position from service. When the console is being tested, test lines, test desk, etc, should be employed to establish the necessary conditions for test.

CAUTION: Care should be exercised when removing equipment from service during busy periods, to prevent adverse customer reactions.

2.02 The telephone console is equipped with nonlocking trunk pickup keys (TRK) and the following nonlocking common control keys: start in (STI), start out (STO), end (END), position available (PA RLS), out line (OUT LINE), supervisor (SUPV), exclude source (EXCL SRC), exclude destination (EXCL DEST), hold (HOLD), signal source (SIG SRC), conference (CON-), signal destination (SIG DEST), release destination (RLS DEST), and

release source (RLS SRC). The following are turn button keys: buzzer on (BZ ON), buzzer volume control (BZ VOL), night (NITE), and position busy (POS BSY). The position busy key makes the position busy to switched loop calls. It will not make busy the out line, auxiliary outgoing trunks, conference circuits, or the attendant access trunks. The conference circuit is made busy at the console by removing the headset or equivalent from the telephone jacks.

2.03 Index for Tables:

TABLE	TITLE	PAGE
A.	Legend	2
B.	Incoming Call — Listed Directory Number (LDN) Type	3
C.	Incoming Call — Transfer (TR) Type	16
D.	Incoming Call — Dial Zero (D0) Type	23
E.	Prearranged Conference Call Within Customer Group	30
F.	Conference Request to Attendant By Centrex Station Dialing Conference Number	32
G.	Conference Request to Attendant By Incoming Call — LDN	34
H.	Attendant Originated Call on Out Line	38
I.	Attendant Originated Call on Attendant Access Trunk	39

TABLE	TITLE	PAGE
<i>J.</i>	<i>Auxiliary Outgoing Trunk ES-26288-01 — Outgoing Call</i>	43
<i>K.</i>	<i>Auxiliary Outgoing Trunk ES-26288-01 — Incoming Call</i>	46
<i>L.</i>	<i>Auxiliary Outgoing Trunk ES-26289-01 — Outgoing Call</i>	47
<i>M.</i>	<i>Auxiliary Outgoing Trunk ES-26289-01 — Incoming Call</i>	51
<i>N.</i>	<i>Attendant Signals Supervisor</i>	54
<i>O.</i>	<i>Night Connection</i>	55

TABLE A

LEGEND	
KEY OPERATION	LAMP OPERATION
R Released	○ Steadily Lighted
O Operated	● Dark
MO Momentarily Operated	⊙(30) Flashing — 30 ipm
	⊙(60) Flashing — 60 ipm
	⊙(120) Flashing — 120 ipm

TABLE B
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																									
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																		REMARKS							
		KEYS											LAMPS														
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK										
																	TRK	SRC	DEST								
Incoming Call																											
1	Idle condition																			○	●			●	●	●	
2	Incoming LDN call																			●	●			●	60	●	Audible signal sounded
3	Atnd answers	MO																		●	●			○	○	●	2-way conversation — atnd, customer
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Release After Station Answers																											
4	Dial tone connection		MO																	●	○			○	○	●	Dial tone heard
5	Atnd dials centrex station			MO																●	●			○	○	●	Ring tone heard
6	Centrex station answers																			●	●			○	○	○	3-way conversation — atnd, customer, centrex station
7	Atnd releases											MO	○	●						○	●			●	*	*	Console idle
																											*In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Release Before Station Answers																											
8	Dial tone connection		MO																	●	○			○	○	●	Dial tone heard
9	Atnd dials centrex station			MO																●	●			○	○	●	Ring tone heard
10	Atnd releases											MO	○	●						○	●			●	○	●	Console idle
11	Centrex station answers												○	●						○	●			●	*	*	*In 2 to 4 seconds, lamps extinguished

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																				
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																	REMARKS			
		KEYS											LAMPS									
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK					
																TRK	SRC	DEST				
22	Atnd dials centrex station			MO															○	○	⊙30	Ringling tone heard
23	Centrex station answers																		○	○	○	3-way conversation — atnd, customer, centrex station
24	Atnd releases												MO	○	●				●	*	*	Console and trunk idle
																						*In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Release Before Station Answers																						
25	Dial tone connection				MO														○	○	●	Dial tone heard
26	Atnd dials centrex station			MO															○	○	⊙30	Ringling tone heard
27	Atnd releases												MO	○	●				●	○	⊙30	Console idle
28	Centrex station answers													○	●				●	*	*	Trunk idle
																						*In 2 to 4 seconds, lamps extinguished
Call Extended to Busy Station Within Customer Group (STO) Basis																						
29	Dial tone connection		MO																○	○	●	Dial tone heard
30	Atnd dials busy centrex station			MO															○	○	○	Busy tone heard
31	Atnd releases busy centrex station					MO													○	○	●	2-way conversation — atnd, customer

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS															REMARKS					
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																				
		KEYS										LAMPS										
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST		ATND TRK				
															TRK	SRC	DEST					
32	Atnd and customer release													MO	○	●			●	●	●	Console and trunk idle
Call Extended to Busy Station Within Customer Group (STI) Basis																						
33	Dial tone connection				MO									●	○			○	○	●	Dial tone heard	
34	Atnd dials busy centrex station			MO									●	●			○	○	⊙60	Busy tone heard		
35	Atnd releases busy centrex station					MO							●	●			○	○	●	2-way conversation — atnd, customer		
36	Atnd and customer release												MO	○	●			●	●	●	Console and trunk idle	
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Holds Connection — Customer and Centrex Station Release																						
37	Dial tone connection				MO								●	○			○	○	●	Dial tone heard		
38	Atnd dials centrex station			MO									●	●			○	○	⊙30	Ringling tone heard		
39	Centrex station answers												●	●			○	○	○	3-way conversation — atnd, customer, centrex station		
40	Atnd holds trunk						MO						●	●			⊙30	○	○			
41	Atnd releases												MO	○	●			⊙30	○	○	Console idle	
42	Customer and centrex station release													○	●			●	●	●	Trunk idle	

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																					
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																			REMARKS		
		KEYS											LAMPS										
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK						
																	TRK	SRC	DEST				
Attendant Holds Trunk — Attempts to Re-enter Connection — Lockout Not Provided																							
43	Dial tone connection				MO											●	○			○	○	●	Dial tone heard
44	Atnd dials centrex station			MO												●	●			○	○	(30)	Ringing tone heard
45	Centrex station answers															●	●			○	○	○	3-way conversation — atnd, incoming customer, centrex station
46	Atnd holds trunk					MO										●	●			(30)	○	○	
47	Atnd releases										MO	○	●							(30)	○	○	Console idle
48	Atnd re-enters connection	MO										●	●							○	○	○	3-way conversation — atnd, incoming customer, centrex station
49	Atnd releases										MO	○	●							●	*	*	Console and trunk idle *In 2 to 4 seconds, lamps extinguished
Attendant Holds Trunk — Attempts to Re-enter Connection — Lockout Provided																							
50	Dial tone connection				MO											●	○			○	○	●	Dial tone heard
51	Atnd dials centrex station			MO												●	●			○	○	(30)	Ringing tone heard
52	Centrex station answers															●	●			○	○	○	3-way conversation — atnd, incoming customer, centrex station
53	Atnd holds trunk					MO										●	●			(30)	○	○	

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																				
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS					
		KEYS										LAMPS										
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST				ATND TRK		
																TRK	SRC	DEST				
54	Atnd releases													MO	○	●			30	○	○	Console idle
55	Atnd attempts to re-enter connection	MO													●	●			○	○	●	Atnd cannot re-enter connection
56	Atnd holds trunk						MO								●	●			30	○	○	
57	Atnd releases													MO	○	●			30	○	○	Console idle
58	Incoming customer and centrex station release														○	●			●	*	*	Trunk idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Excludes Source and Destination																						
59	Atnd excludes customer						MO								●	●	○	●	○	○	●	Customer excluded
60	Dial tone connection		MO												●	○	○	●	○	○	●	Dial tone heard
61	Atnd dials centrex station			MO											●	●	○	●	○	○	●	Ringing tone heard
62	Centrex station answers														●	●	○	●	○	○	○	2-way conversation — atnd, centrex station
63	Atnd excludes centrex station							MO							●	●	●	○	○	○	○	2-way conversation — atnd, customer
64	Atnd removes exclusion	MO													●	●	●	●	○	○	○	3-way conversation — atnd, customer, centrex station

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION																	RESULTS			REMARKS			
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																					
		KEYS										LAMPS											
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK						
															TRK	SRC	DEST						
65	Atnd releases														MO	○	●	●	●	●	○*	○*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Intercepted Station Within Customer Group (STO) Basis																							
66	Dial tone connection		MO													●	○			○	○	●	Dial tone heard
67	Atnd dials centrex station			MO												●	●			○	○	●	Recorded announcement heard
68	Atnd releases recorded announcement					MO										●	●			○	○	●	2-way conversation — atnd, customer
69	Atnd and customer release													MO	○	●				●	●	●	Console and trunk idle
Call Extended to Intercepted Station Within Customer Group (STI) Basis																							
70	Dial tone connection				MO											●	○			○	○	●	Dial tone heard
71	Atnd dials centrex station			MO												●	●			○	○	●	Recorded announcement heard
72	Atnd releases recorded announcement					MO										●	●			○	○	●	2-way conversation — atnd, customer
73	Atnd and customer release													MO	○	●				●	●	●	Console and trunk idle
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Holds Connection — Destination Recalls Attendant																							
74	Dial tone connection		MO													●	○			○	○	●	Dial tone heard

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																		
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS			
		KEYS										LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST		ATND TRK		
																TRK	SRC	DEST		
75	Atnd dials centrex station			MO									●	●			○	○	●	Ringing tone heard
76	Centrex station answers												●	●			○	○	○	3-way conversation — atnd, customer, centrex station
77	Atnd holds trunk						MO						●	●			30	○	○	
78	Atnd releases										MO		○	●			30	○	○	Console idle
																				2-way conversation — customer, centrex station
79	Centrex station recalls atnd by flashing switch hook												●	●			30	○	120	Audible signal sounded
80	Atnd re-enters connection	MO											●	●			○	○	○	3-way conversation — atnd, customer, centrex station
81	Atnd releases										MO		○	●			●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Holds Connection — Destination Recalls Attendant																				
82	Dial tone connection				MO								●	○			○	○	●	Dial tone heard
83	Atnd dials centrex station			MO									●	●			○	○	30	Ringing tone heard
84	Station answers												●	●			○	○	○	3-way conversation — atnd, customer, centrex station

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																			
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																		REMARKS	
		KEYS											LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
																TRK	SRC	DEST			
85	Atnd holds trunk						MO							●	●			⊙30	○	○	
86	Atnd releases												MO	○	●			⊙30	○	○	Console idle
87	Centrex station recalls atnd by flashing switch hook													●	●			⊙30	○	⊙120	Audible signal sounded
88	Atnd re-enters connection	MO												●	●			○	○	○	3-way conversation — atnd, customer, centrex station
89	Atnd releases												MO	○	●			●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STO) Basis — Destination Recalls Attendant																					
90	Dial tone connection		MO											●	○			○	○	●	Dial tone heard
91	Atnd dials centrex station			MO										●	●			○	○	●	Ring tone heard
92	Centrex station answers													●	●			○	○	○	3-way conversation — atnd, customer, centrex station
93	Atnd releases												MO	○	●			●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
94	Outside customer recalls atnd by flashing switch hook													●	●			●	○	⊙120	Audible signal sounded

TABLE B (Cont)
 INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																			
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																REMARKS			
		KEYS											LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
																TRK	SRC	DEST			
95	Atnd re-enters connection	MO												●	●			○	○	○	3-way conversation — atnd, customer, centrex station
96	Atnd releases												MO	○	●			●	*	*	Console idle
																					*In 2 to 4 seconds, lamps extinguished
Incoming Central Office Operator Completed Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Recalls Operator																					
97	Dial tone connection		MO											●	○			○	○	●	Dial tone heard
98	Atnd dials centrex station			MO										●	●			○	○	●	Ringing tone heard
99	Centrex station answers													●	●			○	○	○	3-way conversation — atnd, customer, centrex station
100	Atnd recalls CO operator													●	●			○	○	○	Supervisory cord lamp at CO operator position flashes with operation and release of SIG SRC key by atnd
101	CO operator re-enters connection													●	●			○	○	○	4-way conversation — atnd, customer, CO operator, centrex station
102	Atnd releases													MO	○	●		●	*	*	Console idle
																					*In 2 to 4 seconds, lamps extinguished

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																						
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																	REMARKS					
		KEYS											LAMPS											
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK							
																	TRK	SRC		DEST				
Call Extended To Toll Operator Outside Customer Group (STO) Basis — Attendant Recalls Operator																								
103	Dial tone connection		MO													●	○	●		○	○	●	Dial tone heard	
104	Atnd dials access code															●	○	●		○	○	●	Dial tone heard	
105	Atnd dials toll operator			MO												●	●	●		○	○	○	Ringing tone heard	
106	Toll operator answers															●	●	●		○	○	○	3-way conversation — atnd, customer, toll operator	
107	Toll operator completes call and releases from connection															●	●	●		○	○	○	3-way conversation — atnd, calling customer, called customer	
108	Atnd recalls toll operator															MO	●	●	●		○	○	○	Supervisory cord lamp at toll operator position flashes with operation and release of SIG DEST key by atnd
109	Toll operator re-enters connection																●	●	●		○	○	○	4-way conversation — atnd, calling customer, toll operator, called customer
110	Atnd releases															MO	○	●	●		●	*	*	Console idle
																							*In 2 to 4 seconds, lamps extinguished	

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION		RESULTS																											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																		REMARKS									
		KEYS											LAMPS																
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND 'TRK												
																TRK	SRC	DEST											
Call Extended to Auxiliary Outgoing Trunk — Distant Office Tie Trunk Line Link Frame Terminated																													
111	Dial tone connection		MO																		●	○			○	○	●	Dial tone heard	
112	Atnd dials 1XX auxiliary outgoing trunk access code																					●	○			○	○	●	2nd dial tone heard
113	Atnd dials distant station			MO																		●	●			○	○	○	Ringing tone heard
114	Distant station answers																					●	●			○	○	○	3-way conversation — atnd, customer, distant station
115	Atnd releases													MO								○	●			●	○*	○*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Auxiliary Outgoing Trunk — Distant Office Tie Trunk Terminated at PBX Operator or Attendant Position																													
116	Dial tone connection		MO																			●	○			○	○	●	Dial tone heard
117	Atnd dials 1XX auxiliary outgoing trunk access code			MO																		●	●			○	○	○	Ringing tone heard
118	Distant operator answers and completes call																					●	●			○	○	○	3-way conversation — atnd, customer, distant office
119	Atnd releases													MO								○	●			●	○*	○*	Console idle *In 2 to 4 seconds, lamps extinguished

TABLE B (Cont)
INCOMING CALL — LISTED DIRECTORY NUMBER (LDN) TYPE

CONDITION																	RESULTS			REMARKS		
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																				
		KEYS											LAMPS									
		TRK	START OUT	END	START IN	RLS DEST	HOLD	EXCL SRC	EXCL DEST	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK					
															TRK	SRC	DEST					
Call Extended Within Customer Group (STO) Basis — All Paths Busy																						
120	Dial tone connection		MO												●	○			○	○	●	Dial tone heard
121	Atnd dials centrex station			MO											●	●			○	○	●	120-ipm overflow tone heard
122	Atnd releases overflow condition					MO									●	●			○	○	●	2-way conversation — atnd, customer
123	Atnd and customer release										MO	○	●						●	●	●	Console and trunk idle
Call Extended Within Customer Group (STI) Basis — All Paths Busy																						
124	Dial tone connection				MO										●	○			○	○	●	Dial tone heard
125	Atnd dials centrex station			MO											●	●			○	○	○ ¹²⁰	120-ipm overflow tone heard
126	Atnd releases overflow condition					MO									●	●			○	○	●	2-way conversation — atnd, customer
127	Atnd and customer release										MO	○	●						●	●	●	Console and trunk idle

TABLE C
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																										
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																REMARKS										
		KEYS								LAMPS																		
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCEL SRC	EXCL DEST	ATND TRK													
														TRK	SRC	DEST												
Incoming Call																												
1	Idle condition																	○	●					●	●	●		
2	Customer connected to centrex station and centrex station initiates transfer to atnd																		●	●					●	(120)	○	Audible signal sounded
3	Atnd answers																		●	●					○	○	○	3-way conversation — atnd, customer, originating centrex station
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Release After Station Answers																												
4	Atnd releases originating centrex station					MO													●	●					○	○	●	2-way conversation, atnd, customer
5	Dial tone connection		MO																●	○					○	○	●	Dial tone heard
6	Atnd dials 2nd centrex station			MO															●	●					○	○	●	Ringing tone heard
7	2nd centrex station answers																		●	●					○	○	○	3-way conversation — atnd, customer, 2nd centrex station
8	Atnd releases										MO								○	●					●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STO) Basis — Originating Station Not Released Before Dialing																												
9	Dial tone connection		MO																●	○					○	○	●	Dial tone heard
10	Atnd dials 2nd centrex station			MO															●	●					○	○	●	Ringing tone heard

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																		
S T E P	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE														REMARKS				
		KEYS								LAMPS										
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK					
															TRK				SRC	DEST
11	2nd centrex station answers										●	●			○	○	○	4-way conversation — atnd, customer, originating centrex station, 2nd centrex station		
12	Atnd releases								MO	○	●			●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished			
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Release Before Station Answers																				
13	Atnd releases originating centrex station					MO					●	●			○	○	●	2-way conversation — atnd, customer		
14	Dial tone connection		MO								●	○			○	○	●	Dial tone heard		
15	Atnd dials centrex station			MO							●	●			○	○	●	Ringing tone heard		
16	Atnd releases								MO	○	●			●	○	●	Console idle			
17	Centrex station answers									○	●			●	*	*	*In 2 to 4 seconds, lamps extinguished			
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Release After Station Answers																				
18	Atnd releases originating centrex station					MO					●	●			○	○	●	2-way conversation — atnd, customer		
19	Dial tone connection				MO						●	○			○	○	●	Dial tone heard		
20	Atnd dials centrex station			MO							●	●			○	○	30	Ringing tone heard		
21	Centrex station answers										●	●			○	○	○	3-way conversation — atnd, customer, centrex station		

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION											RESULTS								
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																REMARKS	
		KEYS										LAMPS							
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
														TRK	SRC	DEST			
22	Atnd releases										MO	○	●			●	*	*	Console and trunk idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Release Before Station Answers																			
23	Atnd releases originating centrex station					MO						●	●			○	○	●	2-way conversation — atnd, customer
24	Dial tone connection				MO							●	○			○	○	●	Dial tone heard
25	Atnd dials centrex station			MO								●	●			○	○	⊙ ₃₀	Ringing tone heard
26	Atnd releases									MO	○	●			●	○	⊙ ₃₀	Console idle	
27	Centrex station answers										○	●			●	*	*	Trunk idle *In 2 to 4 seconds, lamps extinguished	
Call Extended to Busy Station Within Customer Group (STO) Basis — Originating Station Released Before Dialing																			
28	Atnd releases originating centrex station					MO						●	●			○	○	●	2-way conversation — atnd, customer
29	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
30	Atnd dials busy centrex station			MO								●	●			○	○	○	Busy tone heard
31	Atnd releases busy centrex station					MO						●	●			○	○	●	2-way conversation — atnd, customer
32	Atnd and customer release									MO	○	●			●	●	●	Console and trunk idle	

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																	
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																REMARKS	
		KEYS										LAMPS							
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
															TRK	SRC	DEST		
Call Extended to Busy Station Within Customer Group (STI) Basis																			
33	Atnd releases originating centrex station					MO						●	●			○	○	●	2-way conversation — atnd, customer
34	Dial tone connection				MO							●	○			○	○	●	Dial tone heard
35	Atnd dials busy centrex station			MO								●	●			○	○	⊙ ⁶⁰	Busy tone heard
36	Atnd releases busy centrex station					MO						●	●			○	○	●	2-way conversation — atnd, customer
37	Atnd and customer release									MO	○	●			●	●	●	Console and trunk idle	
Call Extended to Busy Station Within Customer Group (STO) Basis — Originating Station Not Released Before Dialing																			
38	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
39	Atnd dials busy centrex station			MO								●	●			○	○	○	Busy tone heard
40	Atnd releases busy centrex station					MO						●	●			○	○	○	3-way conversation — atnd, customer, originating station
41	Atnd, originating centrex station, and customer release									MO	○	●			●	●	●	Console and trunk idle	
Call Extended to Intercepted Station Within Customer Group (STO) Basis — Originating Station Not Released																			
42	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
43	Atnd dials centrex station			MO								●	●			○	○	●	Recorded announcement heard

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																	
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS		
		KEYS									LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
														TRK	SRC	DEST			
44	Atnd releases recorded announcement					MO						●	●			○	○	○	3-way conversation — atnd, customer, originating station
45	Atnd, customer, and originating centrex station release									MO	○	●				●	●	●	Console and trunk idle
Call Extended to Intercepted Station Within Customer Group (STI) Basis — Originating Station Released																			
46	Atnd releases originating centrex station					MO					●	●			○	○	●	2-way conversation — atnd, customer	
47	Dial tone connection				MO						●	○			○	○	●	Dial tone heard	
48	Atnd dials 2nd centrex station			MO							●	●			○	○	●	Recorded announcement heard	
49	Atnd releases recorded announcement					MO					●	●			○	○	●	2-way conversation — atnd, customer	
50	Atnd and customer release									MO	○	●				●	●	●	Console and trunk idle
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Excludes Source and Destination																			
51	Atnd excludes customer and originating centrex station						MO				●	●	○	●	○	○	○	Customer and originating centrex station excluded	
52	Dial tone connection		MO								●	○	○	●	○	○	●	Dial tone heard	
53	Atnd dials 2nd centrex station			MO							●	●	○	●	○	○	●	Ring tone heard	
54	2nd centrex station answers										●	●	○	●	○	○	○	2-way conversation — atnd, 2nd centrex station	

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																REMARKS
		KEYS								LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK			
															TRK	SRC	DEST	
55	Atnd excludes 2nd centrex station							MO			●	●	●	○	○	○	○	3-way conversation — atnd, customer, originating centrex station
56	Atnd removes exclusion	MO									●	●	●	●	○	○	○	4-way conversation — atnd, customer, originating centrex station, 2nd centrex station
57	Atnd releases							MO	○	●	●	●	●	●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished	
Call Extended to Idle Station Within Customer Group (STO) Basis — Destination Recalls Attendant																		
58	Atnd releases originating centrex station					MO					●	●			○	○	●	2-way conversation — atnd, customer
59	Dial tone connection		MO								●	○			○	○	●	Dial tone heard
60	Atnd dials 2nd centrex station			MO							●	●			○	○	●	Ringing tone heard
61	Station answers										●	●			○	○	○	3-way conversation — atnd, customer, 2nd centrex station
62	Atnd releases							MO	○	●					●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
63	2nd centrex station recalls atnd by flashing switch hook										●	●			●	○	(120)	Audible signal sounded
64	Atnd re-enters connection	MO									●	●			○	○	○	3-way conversation — atnd, customer, 2nd centrex station

TABLE C (Cont)
INCOMING CALL — TRANSFER (TR) TYPE

CONDITION		RESULTS																
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE														REMARKS		
		KEYS								LAMPS								
		TRK	START OUT	END	START IN	RLS DEST	EXCL SRC	EXCL DEST	HOLD	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK			
														TRK	SRC	DEST		
65	Atnd releases									MO	○	●			●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
Call Extended to Idle Station Within Customer Group (STI) Basis — Attendant Holds Connection — Destination Recalls Attendant																		
66	Atnd releases originating centrex station					MO					●	●			○	○	●	2-way conversation — atnd, customer
67	Dial tone connection				MO						●	○			○	○	●	Dial tone heard
68	Atnd dials centrex station			MO							●	●			○	○	(30)	Ringing tone heard
69	Centrex station answers										●	●			○	○	○	3-way conversation — atnd, customer, centrex station
70	Atnd holds trunk								MO		●	●			(30)	†	†	2-way conversation — customer, centrex station †Lamps remain same condition as before operation of HOLD key.
71	Atnd releases									MO	○	●			(30)	†	†	Console idle †Lamps remain same condition as before operation of HOLD key.
72	Centrex station recalls atnd by flashing switch hook										●	●			(30)	○	(120)	Audible signal sounded
73	Atnd re-enters connection	MO									●	●			○	○	○	3-way conversation — atnd, customer, centrex station
74	Atnd releases									MO	○	●			●	*	*	Console and trunk idle *In 2 to 4 seconds, lamps extinguished

TABLE D
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																										
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS											
		KEYS										LAMPS																
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK												
																TRK				SRC	DEST							
Incoming Call																												
1	Idle condition																	○	●					●	●	●		
2	Centrex station dials 0																		●	●					●	(120)	●	Audible signal sounded
3	Atnd answers	MO																	●	●					○	○	●	2-way conversation — atnd, originating centrex station
Call Extended to Idle Station Within Customer Group (STO) Basis — Attendant Recalled																												
4	Dial tone connection		MO																●	○					○	○	●	Dial tone heard
5	Atnd dials 2nd centrex station			MO															●	●					○	○	●	Ring tone heard
6	2nd centrex station answers																		●	●					○	○	○	3-way conversation — atnd, originating centrex station, 2nd centrex station
7	Atnd releases														MO				○	●					●	*	*	Console idle
																												*In 2 to 4 seconds, lamps extinguished
8	Destination flashes switch hook to recall atnd																		●	●					●	○	(120)	Audible signal sounded
9	Atnd answers	MO																	●	●					○	○	○	3-way conversation — atnd, originating centrex station, 2nd centrex station

TABLE D (Cont)
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																	
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS		
		KEYS										LAMPS							
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK			
															TRK	SRC	DEST		
20	Dial tone connection		MO									●	○			○	●	●	Dial tone heard
21	Atnd dials access code											●	○			○	●	●	Dial tone heard
22	Atnd dials outside customer station			MO								●	●			○	●	○	Ringing tone heard
23	Outside customer answers											●	●			○	●	○	2-way conversation — atnd, outside customer
24	Atnd recalls originating station						MO					●	●			○	●	○	Ringing voltage applied to originating station line
25	Originating station answers											●	●			○	○	○	3-way conversation — atnd, outside customer, centrex station
26	Atnd releases										MO	○	●			●	*	*	Console idle
																			*In 2 to 4 seconds, lamps extinguished
Ringback From Toll Operator																			
27	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
28	Atnd dials access code											●	○			○	○	●	Dial tone heard
29	Atnd dials toll operator			MO								●	●			○	○	†	Ringing tone heard †Lights only when toll diversion not provided
30	Toll operator answers											●	●			○	○	○	3-way conversation — atnd, centrex station, toll operator

TABLE D (Cont)
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																		
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																	REMARKS	
		KEYS									LAMPS									
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK				
																TRK	SRC	DEST		
31	Atnd releases										MO	○	●				●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
32	Toll operator rings back											●	●				●	○	(120)	Audible signal sounded
33	Atnd re-enters connection	MO										●	●				○	○	○	3-way conversation — atnd, centrex station, toll operator
34	Atnd, toll operator, centrex station release										MO	○	●				●	●	●	Console and trunk idle
Call Extended to Busy Station Outside Customer Group (STO) Basis																				
35	Dial tone connection		MO									●	○				○	○	●	Dial tone heard
36	Atnd dials access code											●	○				○	○	●	Dial tone heard
37	Atnd dials outside customer			MO								●	●				○	○	○	Busy tone heard
38	Atnd releases outside customer							MO				●	●				○	○	●	2-way conversation — atnd, centrex station
39	Atnd and station release										MO	○	●				●	●	●	Console and trunk idle
Call Extended to Intercepted Station Outside Customer Group (STO) Basis																				
40	Dial tone connection		MO									●	○				○	○	●	Dial tone heard
41	Atnd dials access code											●	○				○	○	●	Dial tone heard

TABLE D (Cont)
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																	
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS		
		KEYS										LAMPS							
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK			
															TRK	SRC	DEST		
42	Atnnd dials outside customer			MO								●	●			○	○	●	Recorded announcement heard or intercept operator reached
43	Atnnd releases recorded announcement or intercept operator							MO				●	●			○	○	●	2-way conversation — atnd, centrex station
44	Atnnd and station release									MO	○	●			●	●	●	Console and trunk idle	
Call Extended to Toll Operator Outside Customer Group (STO) Basis — Attendant Recalls Toll Operator																			
45	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
46	Atnnd dials access code											●	○			○	○	●	Dial tone heard
47	Atnnd dials toll operator			MO								●	●			○	○	○	Ringing tone heard
48	Toll operator completes call and releases from connection											●	●			○	○	○	3-way conversation — atnd, called customer, centrex station
49	Atnnd recalls toll operator								MO			●	●			○	○	○	Supervisory cord lamp at toll operator position flashes with operation and release of SIG DEST key by atnd
50	Toll operator re-enters connection											●	●			○	○	○	4-way conversation — atnd, centrex station, toll operator, called customer

TABLE D (Cont)
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																			
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																	REMARKS		
		KEYS										LAMPS									
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK					
															TRK	SRC	DEST				
51	Toll operator and atnd release											MO	○	●				●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished
Atnd Holds Trunk — Attempts to Re-enter Connection — Lockout Not Provided																					
52	Dial tone connection		MO										●	○				○	○	●	Dial tone heard
53	Atnd dials access code												●	○				○	○	●	Dial tone heard
54	Atnd dials outside customer			MO									●	●				○	○	○	Ringing tone heard
55	Outside customer answers												●	●				○	○	○	3-way conversation — atnd, outside customer, centrex station
56	Atnd holds trunk								MO				●	●				30	○	○	
57	Atnd releases										MO		○	●				30	○	○	Console idle
58	Centrex station switch hook flashes atnd												○	●				30	**	○	**Source lamp follows switch hook flashes
59	Atnd re-enters connection	MO											●	●				○	○	○	3-way conversation — atnd, outside customer, centrex station
60	Atnd releases										MO		○	●				●	*	*	Console idle *In 2 to 4 seconds, lamps extinguished

TABLE D (Cont)
INCOMING CALL — DIAL ZERO (D0) TYPE

CONDITION		RESULTS																	
S T E P	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS		
		KEYS										LAMPS							
		TRK	START OUT	END	EXCL SRC	EXCL DEST	SIG SRC	RLS DEST	HOLD	SIG DEST	PA RLS	PA RLS	RDY	EXCL SRC	EXCL DEST	ATND TRK			
																TRK		SRC	DEST
Attendant Holds Trunk — Attempts to Re-enter Connection — Lockout Provided																			
61	Dial tone connection		MO									●	○			○	○	●	Dial tone heard
62	Atnd dials access code											●	○			○	○	●	Dial tone heard
63	Atnd dials outside customer			MO								●	●			○	○	○	Ringing tone heard
64	Outside customer answers											●	●			○	○	○	3-way conversation — atnd, outside customer, centrex station
65	Atnd holds trunk							MO				●	●			30	○	○	
66	Atnd releases									MO		○	●			30	○	○	Console idle
67	Atnd attempts to re-enter connection	MO										●	●			○	○	●	Atnd cannot re-enter connection
68	Atnd holds trunk							MO				●	●			30	○	○	
69	Atnd releases									MO		○	●			30	○	○	Console idle
70	Outside customer and centrex station release											○	●			●	*	*	Trunk idle *In 2 to 4 seconds, lamps extinguished

TABLE E
PREARRANGED CONFERENCE CALL WITHIN CUSTOMER GROUP

CONDITION		RESULTS													
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS		
		KEYS					LAMPS								
		RLS SRC	START OUT	END	CONF 2	PA RLS	PA RLS	RDY	CONF 1	CONF 2	CONF TRK				
											TRK	SRC		DEST	
1	Idle condition						○	●	●	●	●	●	●	●	Console idle
2	Atnd connects to conference circuit				MO		●	●	●	Ⓣ	●	●	●		
3	Dial tone connection		MO				●	○	●	Ⓣ	●	●	●		Dial tone heard
4	Atnd dials 1st conferee			MO			●	●	●	Ⓣ	●	●	●		Ringing tone heard
5	1st conferee answers						●	●	●	Ⓣ	●	●	●		2-way conversation — atnd, 1st conferee
6	Atnd connects 1st conferee to conference bridge				MO		●	●	●	Ⓣ	●	●	●		2-way conversation — atnd, 1st conferee
7	Dial tone connection		MO				●	○	●	Ⓣ	●	●	●		Dial tone heard
8	Atnd dials 2nd conferee			MO			●	●	●	Ⓣ	●	●	●		Ringing tone heard
9	2nd conferee answers						●	●	●	Ⓣ	●	●	●		2-way conversation — atnd, 2nd conferee
10	Atnd connects 2nd conferee to conference bridge				MO		●	●	●	Ⓣ	●	●	●		3-way conversation — atnd, 1st conferee, 2nd conferee
11	Repeat Steps 3 - 6 to add additional conferees														
12	Atnd releases					MO	○	●	●	Ⓣ	●	●	●		Conference continues
13	1st or 2nd conferee flashes switch hook to recall atnd						●	●	●	Ⓣ	●	●	●		Audible signal sounded
14	Atnd re-enters conference circuit				MO		●	●	●	Ⓣ	●	●	●		Conversation with all conferees

TABLE E (Cont)

PREARRANGED CONFERENCE CALL WITHIN CUSTOMER GROUP

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS					LAMPS							
		RLS SRC	START OUT	END	CONF 2	PA RLS	PA RLS	RDY	CONF 1	CONF 2	CONF TRK			
										TRK	SRC	DEST		
15	Atnnd releases all conferees	MO					●	●	●	⊙30	●	●	●	All conferees released
16	Atnnd releases					MO	○	●	●	●	●	●	●	Console and conference circuit idle

TABLE F
CONFERENCE REQUEST TO ATTENDANT BY CENTREX STATION DIALING CONFERENCE NUMBER

CONDITION		RESULTS													
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE													REMARKS
		KEYS						LAMPS							
		RLS SRC	START OUT	CONF 1	RLS DEST	END	PA RLS	PA RLS	RDY	CONF 1	CONF 2	ATND TRK			
											TRK	SRC	DEST		
1	Idle condition							○	●	●	●	●	●	●	Console idle
2	Centrex station dials conference number							●	●	Ⓣ20	●	●	●	●	Audible signal sounded
3	Atnd answers			MO				●	●	Ⓣ30	●	●	●	●	2-way conversation — atnd, originating station
4	Atnd connects centrex station to conference bridge			MO				●	●	Ⓣ30	●	●	●	●	2-way conversation — atnd, originating station
5	Dial tone connection		MO					●	○	Ⓣ30	●	●	●	●	Dial tone heard
6	Atnd dials 2nd conferee					MO		●	●	Ⓣ30	●	●	●	●	Ringing tone heard
7	2nd conferee answers							●	●	Ⓣ30	●	●	●	●	2-way conversation — atnd, 2nd conferee
8	Atnd connects 2nd conferee to conference bridge			MO				●	●	Ⓣ30	●	●	●	●	3-way conversation — atnd, originating station, 2nd conferee
9	Dial tone connection		MO					●	○	Ⓣ30	●	●	●	●	Dial tone heard
10	Atnd dials 3rd conferee					MO		●	●	Ⓣ30	●	●	●	●	Ringing tone heard
11	3rd conferee answers							●	●	Ⓣ30	●	●	●	●	2-way conversation — atnd, 3rd conferee
12	Atnd connects 3rd conferee to conference bridge			MO				●	●	Ⓣ30	●	●	●	●	4-way conversation — atnd, originating station, 2nd conferee, 3rd conferee
13	Repeat Steps 5 - 8 to add additional conferees — maximum 5 on 1 conference circuit														
14	Atnd attempts to add 6th conferee		MO					●	○	Ⓣ20	●	●	●	●	All conference lines busy

TABLE F (Cont)

CONFERENCE REQUEST TO ATTENDANT BY CENTREX STATION DIALING CONFERENCE NUMBER

CONDITION		RESULTS													
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE													REMARKS
		KEYS						LAMPS							
		RLS SRC	START OUT	CONF 1	RLS DEST	END	PA RLS	PA RLS	RDY	CONF 1	CONF 2	ATND TRK			
											TRK	SRC	DEST		
15	Atnd operates END key					MO		●	●	Ⓣ120	●	●	●	●	
16	Atnd abandons attempt				MO			●	●	Ⓣ30	●	●	●	●	
17	Atnd connects to conference circuit			MO				●	●	Ⓣ30	●	●	●	●	Conversation with all conferees
18	Atnd releases					MO		○	●	Ⓣ30	●	●	●	●	Console idle
19	Originating station or 2nd conferee flashes switch hook to recall atnd							●	●	Ⓣ120	●	●	●	●	Audible signal sounded
20	Atnd re-enters conference circuit			MO				●	●	Ⓣ30	●	●	●	●	Conversation with all conferees
21	Atnd releases all conferees	MO						●	●	Ⓣ30	●	●	●	●	All conferees released
22	Atnd releases					MO		○	●	●	●	●	●	●	Console and conference circuit idle

TABLE G
CONFERENCE REQUEST TO ATTENDANT BY INCOMING CALL — LDN

CONDITION											RESULTS							REMARKS	
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE																	
		KEYS										LAMPS				ATND TRK			
		TRK	END	START OUT	RLS SRC	CONF 1	CONF 2	RLS DEST	START IN	PA RLS	PA RLS	RDY	CONF 1	CONF 2	TRK	SRC	DEST		
(STO) Basis																			
1	Idle condition										○	●	●	●	●	●	●		
2	Incoming LDN call										●	●	●	●	●	60	●	Audible signal sounded	
3	Atnd answers	MO									●	●	●	●	○	○	●	2-way conversation — atnd, customer	
4	Incoming customer requests conference										●	●	●	●	○	○	●		
5	Dial tone connection			MO							●	○	●	●	○	○	●	Dial tone heard	
6	Atnd dials conference number		MO								●	●	120	●	○	○	●	Ringling tone heard	
7	Atnd releases position								MO		●	●	120	●	●	○	●	Audible signal sounded	
8	Atnd connects to conference circuit					MO					●	●	30	●	●	*	*	2-way conversation — atnd, customer *In 2 to 4 seconds, lamps extinguished	
9	Atnd connects customer to conference bridge					MO					●	●	30	●	●	●	●		
10	Dial tone connection			MO							●	○	30	●	●	●	●	Dial tone heard	
11	Atnd dials 2nd conferee		MO								●	●	30	●	●	●	●	Ringling tone heard	
12	2nd conferee answers										●	●	30	●	●	●	●	2-way conversation — atnd, 2nd conferee	

TABLE G (Cont)
CONFERENCE REQUEST TO ATTENDANT BY INCOMING CALL — LDN

CONDITION											RESULTS								
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE															REMARKS		
		KEYS										LAMPS							
		TRK	END	START OUT	RLS SRC	CONF 1	CONF 2	RLS DEST	START IN	PA RLS	PA RLS	RDY	CONF 1	CONF 2	ATND TRK				
														TRK	SRC	DEST			
13	Atnd connects 2nd conferee to conference bridge					MO						●	●	30	●	●	●	●	3-way conversation — atnd, customer, 2nd conferee
14	Dial tone connection			MO								●	○	30	●	●	●	●	Dial tone heard
15	Atnd dials 3rd conferee		MO									●	●	30	●	●	●	●	Ring tone heard
16	3rd conferee answers											●	●	30	●	●	●	●	2-way conversation — atnd, 3rd conferee
17	Atnd connects 3rd conferee to conference bridge					MO						●	●	30	●	●	●	●	4-way conversation — atnd, customer, 2nd conferee, 3rd conferee
18	Repeat Steps 10 - 13 to add additional conferees																		
19	Atnd releases									MO	○	●	30	●	●	●	●	●	Console idle
20	2nd conferee flashes switch hook to recall atnd											●	●	120	●	●	●	●	Audible signal sounded
21	Atnd re-enters conference circuit					MO						●	●	30	●	●	●	●	Conversation with all conferees
22	Atnd releases all conferees				MO							●	●	30	●	●	●	●	All conferees released
23	Atnd releases									MO	○	●	●	●	●	●	●	●	Console and conference circuit idle
(STI) Basis																			
24	Idle condition										○	●	●	●	●	●	●	●	

TABLE G (Cont)
CONFERENCE REQUEST TO ATTENDANT BY INCOMING CALL — LDN

CONDITION		RESULTS																
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE														REMARKS		
		KEYS								LAMPS								
		TRK	END	START OUT	RLS SRC	CONF 1	CONF 2	RLS DEST	START IN	PA RLS	PA RLS	RDY	CONF 1	CONF 2	ATND TRK			
														TRK	SRC	DEST		
25	Incoming LDN call										●	●	●	●	●	⊙	●	Audible signal sounded
26	Atnd answers	MO									●	●	●	●	○	○	●	2-way conversation — atnd, customer
27	Incoming customer requests conference										●	●	●	●	○	○	●	
28	Dial tone connection							MO			●	○	●	●	○	○	●	Dial tone heard
29	Atnd dials conference number		MO								●	●	●	⊙	○	○	⊙	Ringling tone heard
30	Atnd releases								MO		●	●	●	⊙	○	○	⊙	Audible signal sounded
31	Atnd connects to conference circuit						MO				●	●	●	⊙	●	*	*	*In 2 to 4 seconds, lamps extinguished
32	Atnd connects incoming customer to conference bridge						MO				●	●	●	⊙	●	●	●	2-way conversation — atnd, incoming customer
33	Dial tone connection			MO							●	○	●	⊙	●	●	●	Dial tone heard
34	Atnd dials 2nd conferee		MO								●	●	●	⊙	●	●	●	Ringling tone heard
35	2nd conferee answers										●	●	●	⊙	●	●	●	2-way conversation — atnd, 2nd conferee
36	Atnd connects 2nd conferee to conference bridge						MO				●	●	●	⊙	●	●	●	3-way conversation — atnd, incoming customer, 2nd conferee
37	Dial tone connection			MO							●	○	●	⊙	●	●	●	Dial tone heard
38	Atnd dials 3rd conferee		MO								●	●	●	⊙	●	●	●	No answer, line-busy, or overflow

TABLE G (Cont)
CONFERENCE REQUEST TO ATTENDANT BY INCOMING CALL — LDN

CONDITION		RESULTS																
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE														REMARKS		
		KEYS								LAMPS								
		TRK	END	START OUT	RLS SRC	CONF 1	CONF 2	RLS DEST	START IN	PA RLS	PA RLS	RDY	CONF 1	CONF 2	ATND TRK			
														TRK	SRC	DEST		
39	Atnd releases 3rd conferee							MO			●	●	●	⊙30	●	●	●	
40	Repeat Steps 33-36 to add additional conferees																	
41	Atnd releases								MO	○	●	●	⊙30	●	●	●	Console idle	
42	All conferees release									○	●	●	●	●	●	●	Conference circuit idle	

**TABLE H
ATTENDANT ORIGINATED CALL ON OUT LINE**

CONDITION					RESULTS								
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS				LAMPS							
		END	START OUT	OUT LINE	PARLS	PARLS	RDY	OUT LINE	EXCL DEST	ATND TRK			
									TRK	SRC	DEST		
1	Idle condition					○	●	●	●	●	●	●	Console idle
2	Atnd seizes out line			MO		●	●	○	●	●	●	●	
3	Dial tone connection		MO			●	○	○	●	●	●	●	Dial tone heard
4	Atnd dials access code					●	○	○	●	●	●	●	Dial tone heard
5	Atnd dials 7-digit number	MO				●	●	○	●	●	●	●	Ring tone heard
6	Customer answers					●	●	○	●	●	●	●	2-way conversation — atnd, customer
7	Atnd and customer release				MO	○	●	●	●	●	●	●	Console and out line idle

**TABLE I
ATTENDANT ORIGINATED CALL ON ATTENDANT ACCESS TRUNK**

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	SIG DEST	RLS SRC	PA RLS	PA RLS	RDY	ATND ACCESS			
										TRK	SRC	DEST		
Attendant Connect to Centrex Station														
1	Idle condition								○	●	●	●	●	
2	Trunk seized	MO							●	●	○	●	●	
3	Dial tone connection		MO						●	○	○	●	●	Dial tone heard
4	Atnd dials 4- or 5-digit centrex station number			MO					●	●	○	●	●	Ringling tone heard
5	Centrex station answers								●	●	○	○	●	2-way conversation — atnd, centrex station
Call Extended to Idle Outside Station														
6	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
7	Atnd dials access code								●	○	○	○	●	Dial tone heard
8	Atnd dials 7-digit number for outside customer			MO					●	●	○	○	○	Ringling tone heard
9	Outside customer answers								●	●	○	○	○	3-way conversation — atnd, centrex station, outside customer
10	Atnd releases							MO	○	●	●	○	○	Console idle
11	Atnd re-enters connection	MO							●	●	○	○	○	3-way conversation — atnd, centrex station, outside customer
12	Atnd releases							MO	○	●	●	○	○	Console idle
13	Centrex station and outside customer release								○	●	●	●	●	Trunk idle

TABLE I (Cont)
ATTENDANT ORIGINATED CALL ON ATTENDANT ACCESS TRUNK

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	SIG DEST	RLS SRC	PA RLS	PA RLS	RDY	ATND ACCESS			
											TRK	SRC		DEST
Call Extended to Busy Outside Station														
14	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
15	Atnd dials access code								●	○	○	○	●	Dial tone heard
16	Atnd dials busy station			MO					●	●	○	○	○	60-ipm busy tone heard
17	Atnd releases outside station				MO				●	●	○	○	●	2-way conversation — atnd, centrex station
18	Atnd and centrex station release						MO		○	●	●	●	●	Console and trunk idle
Call Extended to Toll Operator — Toll Operator Re-rings Attendant														
19	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
20	Atnd dials access code								●	○	○	○	●	Dial tone heard
21	Atnd dials toll operator			MO					●	●	○	○	○	Ring tone heard
22	Toll operator answers								●	●	○	○	○	3-way conversation — atnd, centrex station, toll operator
23	Toll operator extends call								●	●	○	○	○	Ring tone heard
24	Called customer answers								●	●	○	○	○	4-way conversation — atnd, toll operator, centrex station, outside customer
25	Atnd releases						MO		○	●	●	○	○	Console idle
26	Toll operator re-rings atnd								●	●	●	○	①20	Audible signal sounded

TABLE I (Cont)
ATTENDANT ORIGINATED CALL ON ATTENDANT ACCESS TRUNK

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	SIG DEST	RLS SRC	PA RLS	PA RLS	RDY	ATND ACCESS			
											TRK	SRC		DEST
27	Atnd re-enters connection	MO							●	●	○	○	○	4-way conversation — atnd, toll operator, centrex station, outside customer
28	Atnd and toll operator release						MO	○	●	●	○	○	Console idle	
29	Centrex station and outside customer release							○	●	●	●	●	Trunk idle	
Call Extended to Toll Operator — Attendant Recalls Toll Operator														
30	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
31	Atnd dials access code								●	○	○	○	●	Dial tone heard
32	Atnd dials toll operator			MO					●	●	○	○	○	Ringing tone heard
33	Toll operator answers								●	●	○	○	○	3-way conversation — atnd, centrex station, toll operator
34	Toll operator extends call and releases								●	●	○	○	○	Ringing tone heard
35	Called customer answers								●	●	○	○	○	3-way conversation — atnd, centrex station, called customer
36	Atnd recalls toll operator					MO			●	●	○	○	○	Supervisory cord lamp at toll operator position flashes with operation and release of SIG DEST key by atnd
37	Toll operator answers								●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, called customer
38	Toll operator releases								●	●	○	○	○	3-way conversation — atnd, centrex station, called customer

TABLE I (Cont)
ATTENDANT ORIGINATED CALL ON ATTENDANT ACCESS TRUNK

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	SIG DEST	RLS SRC	PA RLS	PA RLS	RDY	ATND ACCESS			
											TRK	SRC		DEST
39	Atnd releases							MO	○	●	●	○	○	Console idle
40	Centrex station and outside customer release								○	●	●	●	●	Trunk idle
Attendant Releases Originating Station — Initiates Outside Call														
41	Atnd releases originating centrex station						MO		●	●	○	●	●	
42	Dial tone connection		MO						●	○	○	●	●	Dial tone heard
43	Atnd dials 4- or 5-digit centrex station number			MO					●	●	○	●	●	Ring tone heard
44	Centrex station answers								●	●	○	○	●	2-way conversation — atnd, centrex station
45	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
46	Atnd dials access code								●	○	○	○	●	Dial tone heard
47	Atnd dials outside customer			MO					●	●	○	○	○	Ring tone heard
48	Outside customer answers								●	●	○	○	○	3-way conversation — atnd, centrex station, outside customer
49	Atnd releases						MO		○	●	●	○	○	Console idle
50	Centrex station and outside customer release								○	●	●	●	●	Trunk idle

TABLE J
AUXILIARY OUTGOING TRUNK ES-26288-01 — OUTGOING CALL

CONDITION		RESULTS											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS						LAMPS					
		TRK	START OUT	END	RLS DEST	RLS SRC	PA RLS	PA RLS	RDY	AUX OG TRK			
										TRK	SRC	DEST	
Centrex Station Connection													
1	Idle condition							○	●	●	●	●	
2	Trunk seized	MO						●	●	○	●	●	
3	Dial tone connection		MO					●	○	○	●	●	Dial tone heard
4	Atnd dials centrex station			MO				●	●	○	●	●	Ring tone heard
5	Centrex station answers							●	●	○	○	●	2-way conversation — atnd, centrex station
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated													
6	Dial tone connection		MO					●	○	○	○	●	Dial tone heard
7	Atnd dials station in distant office			MO				●	●	○	○	●	Ring tone heard
8	Distant office station answers							●	●	○	○	○	3-way conversation — atnd, centrex station, distant office station
9	Atnd releases						MO	○	●	●	○	○	Console idle
10	Centrex station and distant office release							○	●	●	●	●	Trunk idle
Call Extended to Distant Office — Tie Trunks Terminated to PBX Operator or Attendant Position													
11	Atnd signals distant office		MO					●	●	○	○	●	Distant office receives signal
12	Atnd momentarily operates END key			MO				●	●	○	○	●	

TABLE J (Cont)
AUXILIARY OUTGOING TRUNK ES-26288-01 — OUTGOING CALL

CONDITION		RESULTS											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS						LAMPS					
		TRK	START OUT	END	RLS DEST	RLS SRC	PA RLS	PA RLS	RDY	AUX TRK	OG SRC	TRK DEST	
13	Distant office operator answers							●	●	○	○	○	3-way conversation — atnd, distant office operator, centrex station
14	Distant office operator completes call							●	●	○	○	○	4-way conversation — atnd, distant office operator, distant office station, centrex station
15	Atnd and distant office operator release						MO	○	●	●	○	○	Console idle
16	Centrex station and distant office release							○	●	●	●	●	Trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Release Destination													
17	Dial tone connection		MO					●	●	○	○	●	Dial tone heard
18	Atnd dials station in distant office			MO				●	●	○	○	●	Ring tone heard
19	Distant office station busy							●	●	○	○	○	60-ipm busy tone heard
20	Atnd releases distant office station				MO			●	●	○	○	●	2-way conversation — atnd, centrex station
21	Atnd and centrex station release						MO	○	●	●	●	●	Console and trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Release Source													
22	Atnd releases originating centrex station					MO		●	●	○	●	●	
23	Dial tone connection		MO					●	○	○	●	●	Dial tone heard
24	Atnd dials centrex station			MO				●	●	○	●	●	Ring tone heard

TABLE J (Cont)
AUXILIARY OUTGOING TRUNK ES-26288-01 — OUTGOING CALL

CONDITION		RESULTS											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS						LAMPS					
		TRK	START OUT	END	RLS DEST	RLS SRC	PA RLS	PA RLS	RDY	AUX OG TRK			
										TRK	SRC	DEST	
25	Centrex station answers							●	●	○	○	●	2-way conversation — atnd, centrex station
26	Dial tone connection		MO					●	○	○	○	●	Dial tone heard
27	Atnd dials distant office station			MO				●	●	○	○	●	Ring tone heard
28	Distant office station answers							●	●	○	○	○	3-way conversation — atnd, centrex station, distant office station
29	Atnd releases						MO	○	●	●	○	○	Console idle
30	Centrex station and distant office station release							○	●	●	●	●	Trunk idle

**TABLE K
AUXILIARY OUTGOING TRUNK ES-26288-01 — INCOMING CALL**

CONDITION		RESULTS									
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE									REMARKS
		KEYS				LAMPS					
		TRK	START OUT	END	PA RLS	PA RLS	RDY	AUX OG TRK			
								TRK	SRC	DEST	
Incoming Call from Distant Office — Console Terminated Call Extended to Idle Centrex Station											
1	Console and trunk idle					○	●	●	●	●	
2	Signal from distant office					●	●	●	⊙120	●	Audible signal sounded
3	Atnd answers	MO				●	●	○	○	●	2-way conversation — atnd, distant office
4	Dial tone connection		MO			●	○	○	○	●	Dial tone heard
5	Atnd dials centrex station			MO		●	●	○	○	●	Ringing tone heard
6	Centrex station answers					●	●	○	○	○	3-way conversation — atnd, distant office, centrex station
7	Atnd releases				MO	○	●	●	○	○	Console idle
8	Centrex station and distant office release					○	●	●	●	●	Trunk idle

TABLE I
AUXILIARY OUTGOING TRUNK ES-26289-01 — OUTGOING CALL

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	RLS SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
											TRK	SRC		DEST
Centrex Station Connection														
1	Idle condition								<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	
2	Trunk seized	MO							<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	
3	Dial tone connection		MO						<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Dial tone heard
4	Atnd dials centrex station			MO					<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Ringling tone heard
5	Centrex station answers								<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	2-way conversation — atnd, centrex station
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated														
6	Dial tone connection		MO						<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Dial tone heard
7	Atnd dials station in distant office			MO					<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Ringling tone heard
8	Distant office station answers								<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	3-way conversation — atnd, centrex station, distant office station
9	Atnd releases							MO	<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	Console idle
10	Centrex station and distant office station release								<input type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input checked="" type="radio"/>	Trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Release Destination														
11	Dial tone connection		MO						<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Dial tone heard
12	Atnd dials station in distant office			MO					<input checked="" type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	Ringling tone heard

TABLE L (Cont)
AUXILIARY OUTGOING TRUNK ES-26289-01 — OUTGOING CALL

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS							LAMPS					
		TRK	START OUT	END	RLS DEST	RLS SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
											TRK	SRC		DEST
13	Distant office station busy								●	●	○	○	○	60-ipm busy tone heard
14	Atnd releases distant office station				MO				●	●	○	○	●	2-way conversation — atnd, centrex station
15	Atnd and centrex station release						MO		○	●	●	●	●	Trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Release Source														
16	Atnd releases originating centrex station					MO			●	●	○	●	●	
17	Dial tone connection		MO						●	○	○	●	●	Dial tone heard
18	Atnd dial centrex station			MO					●	●	○	●	●	Ring tone heard
19	Centrex station answers								●	●	○	○	●	2-way conversation — atnd, centrex station
20	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
21	Atnd dials distant office station			MO					●	●	○	○	●	Ring tone heard
22	Distant office station answers								●	●	○	○	○	3-way conversation — atnd, centrex station, distant office station
23	Atnd releases						MO		○	●	●	○	○	Console idle
24	Centrex station and distant office station release								○	●	●	●	●	Trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Hold — Flash Recall														
25	Dial tone connection		MO						●	○	○	○	●	Dial tone heard

TABLE I (Cont)

AUXILIARY OUTGOING TRUNK ES-26289-01 — OUTGOING CALL

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	RLS SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
											TRK	SRC		DEST
26	Atnd dials station in distant office			MO					●	●	○	○	●	Ringing tone heard
27	Distant office station answers								●	●	○	○	○	3-way conversation — atnd, centrex station, distant office station
28	Atnd holds connection								●	●	(30)	○	○	2-way conversation — centrex station, distant office station
29	Atnd releases						MO	○	●	(30)	○	○	Console idle	
30	Centrex station recalls atnd by flashing switch hook							●	●	(30)	*	○	*Source lamp follows switch hook flashes	
31	Atnd re-enters connection	MO						●	●	○	○	○	3-way conversation — atnd, centrex station, distant office station	
32	Atnd releases						MO	●	●	●	○	○	Console idle	
33	Centrex station and distant office station release							○	●	●	●	●	Trunk idle	
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Toll Operator Rings Back														
34	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
35	Atnd dials toll operator through distant office			MO					●	●	○	○	●	Ringing tone heard
36	Toll operator answers and completes call								●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, called customer
37	Atnd releases						MO	○	●	●	○	○	Console idle	
38	Toll operator rings back								●	●	●	○	(120)	Audible signal sounded
39	Atnd re-enters connection	MO							●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, called customer

TABLE L (Cont)
AUXILIARY OUTGOING TRUNK ES-26289-01 — OUTGOING CALL

CONDITION		RESULTS												
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS	
		KEYS						LAMPS						
		TRK	START OUT	END	RLS DEST	RLS SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX TRK	OG SRC		TRK DEST
40	Atnd and toll operator release							MO	○	●	●	○	○	Console idle
41	Centrex station and called customer release								○	●	●	●	●	Trunk idle
Call Extended to Distant Office — Tie Trunk Line Link Frame Terminated — Signal Destination														
42	Dial tone connection		MO						●	○	○	○	●	Dial tone heard
43	Atnd dials toll operator through distant office			MO					●	●	○	○	●	Ringing tone heard
44	Toll operator answers and completes call								●	●	○	○	○	4-conversation — atnd, centrex station, toll operator, called customer
45	Toll operator releases								●	●	○	○	○	3-way conversation — atnd, centrex station, called customer
46	Atnd recalls toll operator						MO		●	●	○	○	○	Toll operator supervisory lamp flashes with operation and release of SIG DEST key
47	Toll operator re-enters connection								●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, called customer
48	Atnd and toll operator release							MO	○	●	●	○	○	Console idle
49	Centrex station and called customer release								○	●	●	●	●	Trunk idle

TABLE M
AUXILIARY OUTGOING TRUNK ES-26289-01 — INCOMING CALL

CONDITION		RESULTS											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS					LAMPS						
		TRK	START OUT	END	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
										TRK	SRC	DEST	
1	Idle condition							○	●	●	●	●	
2	Trunk seized by toll operator							●	●	●	⊙60	●	Audible signal sounded
3	Atnd answers	MO						●	●	○	○	●	3-way conversation — atnd, calling customer, toll operator
Call Extended to Idle Station — Attendant Release — Centrex Station Flash Recall													
4	Dial tone connection		MO					●	○	○	○	●	Dial tone heard
5	Atnd dials centrex station			MO				●	●	○	○	●	Ring tone heard
6	Centrex station answers							●	●	○	○	○	4-way conversation — atnd, centrex station, calling customer, toll operator
7	Atnd and toll operator release						MO	○	●	●	○	○	Console idle
8	Centrex station recalls atnd by flashing switch hook							●	●	●	○	⊙120	Audible signal sounded
9	Atnd re-enters connection	MO						●	●	○	○	○	3-way conversation — atnd, centrex station, calling customer
10	Atnd releases						MO	○	●	●	○	○	Console idle
11	Centrex station and calling customer release							○	●	●	●	●	Trunk idle
Call Extended to Idle Station — Attendant Recalls Toll Operator — Signal Source													
12	Dial tone connection		MO					●	○	○	○	●	Dial tone heard
13	Atnd dials centrex station			MO				●	●	○	○	●	Ring tone heard

TABLE M (Cont)
AUXILIARY OUTGOING TRUNK ES-26289-01 — INCOMING CALL

CONDITION		RESULTS											
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS						LAMPS					
		TRK	START OUT	END	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
									TRK	SRC	DEST		
14	Centrex station answers							●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, calling customer
15	Toll operator releases							●	●	○	○	○	3-way conversation — atnd, centrex station, calling customer
16	Atnd recalls toll operator				MO			●	●	○	○	○	Toll operator supervisory lamp flashes with operation and release of SIG SRC key
17	Toll operator re-enters connection							●	●	○	○	○	4-way conversation — atnd, centrex station, toll operator, calling customer
18	Atnd and toll operator release					MO		○	●	●	○	○	Console idle
19	Centrex station and calling customer release							○	●	●	●	●	Trunk idle
Call Extended to Toll Operator — Attendant Recalls Toll Operator — Signal Destination													
20	Dial tone connection		MO					●	○	○	○	●	Dial tone heard
21	Atnd dials access code							●	○	○	○	●	Dial tone heard
22	Atnd dials toll operator			MO				●	●	○	○	●	Ring tone heard
23	Toll operator answers and completes call							●	●	○	○	○	4-way conversation — atnd, calling customer, toll operator, called customer
24	Toll operator releases							●	●	○	○	○	3-way conversation — atnd, calling customer, called customer
25	Atnd recalls toll operator				MO			●	●	○	○	○	Toll operator supervisory lamp flashes with operation and release of SIG DEST key
26	Toll operator re-enters connection							●	●	○	○	○	4-way conversation — atnd, calling customer, toll operator, called customer

TABLE M (Cont)
AUXILIARY OUTGOING TRUNK ES-26289-01 — INCOMING CALL

CONDITION		RESULTS											
S T E P	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE											REMARKS
		KEYS						LAMPS					
		TRK	START OUT	END	SIG SRC	SIG DEST	PA RLS	PA RLS	RDY	AUX OG TRK			
								TRK	SRC	DEST			
27	Atnd and toll operator release						MO	○	●	●	○	○	Console idle
28	Calling and called customers release							○	●	●	●	●	Trunk idle

**TABLE N
ATTENDANT SIGNALS SUPERVISOR**

CONDITION		RESULTS							
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE							REMARKS
		KEYS		LAMPS					
		SUPV	PARLS	RDY	SUPV	TRK	SRC	DEST	
1	Idle condition		○	●	●	●	●	●	
2	Atnd requests supervisor assistance	MO	○	●	○	●	●	●	Supervisor turret receives signal
3	Supervisor connects to supervisor jacks on console		○	●	●	●	●	●	2-way conversation — atnd, supervisor
4	Supervisor disconnects from console		○	●	●	●	●	●	Console idle

TABLE O
NIGHT CONNECTION

CONDITION		RESULTS						
STEP	ACTION	1- AND 2-TYPE TELEPHONE CONSOLE						REMARKS
		KEYS		LAMPS				
		NITE	PA RLS	NITE	TRK	SRC	DEST	
1	Idle condition		○	●	●	●	●	Console idle
2	Atnd transfers to night connection	MO	○	○	●	●	●	Calls transferred to night answer station
3	Atnd removes headset		●	○	●	●	●	