
SL-1

2-Mb/s Digital Trunk Interface

Fault clearing procedures

Publication number: 553-2911-510

Product release: Group F

Document status: Standard

Date: 91 03 08

© 1988 Northern Telecom

All right reserved

NT, Meridian 1, Meridian and SL-1 are trademarks of Northern Telecom.

Title to and ownership of SL-1 software shall at all times remain with Northern Telecom. SL-1 software shall not be sold outright and the use thereof by the customer shall be subject to the parties entering into agreement as specified by Northern Telecom.

Information contained in this document is subject to change. Northern Telecom reserves the right, without notice, to make changes in equipment or program components as progress in engineering, manufacturing, or technology may warrant.

Reason for revision

91 03 08

This procedure was reissued to include information on the Japan Digital Multiplex Interface (JDMI) for GenericX11 including supplementary features.

It has been reformatted for CD-ROM application

Contents

General	1-1
Flowchart symbols	1-1
<hr/>	
Trouble analyzing procedures	2-1
Alarm Lamps (LEDS)	2-1
Out of Service (OOS) Alarm LED Lit	2-1
Far-end Alarm (FEA) LED Lit	2-3
Near-end Alarm (NEA) LED Lit	2-6
Loopback Alarm LED Lit	2-9
Disable (DIS) Alarm LED Lit	2-11
Violation Error Messages	2-12
Slip Error Message	2-15
Frame Alignment Error Message	2-17
<hr/>	
DTI2/DMI Pack Replacement	3-1
Clock Controller pack replacement	3-2
2.048 Megabit PCM line monitor	3-4
Verification tests for DTI2/DMI and CC packs	3-5

General

This manual describes the maintenance procedures for the Meridian SL-1 2 Mb/s Digital Trunk Interface (DTI) and Japan Digital Multiplex Interface (JDMI) for GenericX11 including supplementary features.

This manual is divided into two chapters. The first chapter contains step-by-step instructions on how to analyze a trouble. The second chapter contains information and instructions on how to perform a specific task. References are made in chapter one to the detailed procedures in chapter two when required.

Flowchart symbols

Figure 1-1 illustrates the flowchart symbols contained in this manual.

Figure 1-1

Flowchart symbols

Instruction block - contains an instruction






Figure 1-1 (continued)

Flowchart symbols

Decision block - contains a question. The answer indicates the path to follow.



Continuation symbol - contains the location of the next step




Stop symbol - identifies the end of a procedure




Figure 1-1 (continued)

Flowchart symbols

AND symbol - groups a sequence of steps, ALL of which must be performed to achieve a result.



OR symbol - groups a sequence of steps, only ONE of which must be performed to achieve a result.




Trouble analyzing procedures

Alarm Lamps (LEDS)


This section contains detailed step-by-step instructions on how to analyse a trouble (with reference to Detailed Procedures, where required)

Out of Service (OOS) Alarm LED Lit


If either the Near-end alarm (NEA) or Far-end alarm (FEA) LED is also lit, then perform that procedure (i.e., NEA or FEA) before attempting this procedure.




2-2 Trouble analyzing procedures




Far-end Alarm (FEA) LED Lit





2-4 Trouble analyzing procedures






Near-end Alarm (NEA) LED Lit







2-8 Trouble analyzing procedures




Loopback Alarm LED Lit




2-10 Trouble analyzing procedures



Disable (DIS) Alarm LED Lit







Violation Error Messages


Note: Error Message Formats:

- Bipolar Violation Error: DTAXXX L BV
- Coded Mark Inversion Violation Error: DTAXXX L CV







2-14 Trouble analyzing procedures




Slip Error Message




2-16 Trouble analyzing procedures



Frame Alignment Error Message





DTI2/DMI Pack Replacement

Chart 3-1
Replacement of Digital Interface circuit pack

CAUTION

Firmly touch the metal frame of the cabinet to discharge static electricity from your body before handling circuit packs

Step	Procedure
-------------	------------------

Pack Removal:

- 1 Disable the Network Loop, using Overlay 60. The command is *DISL 'loop number'*.
- 2 Disconnect cables on the Interface pack faceplate.
- 3 Remove circuit pack.

Installation

- 4 Install the pack in the appropriate slot. LEDs will flash:
 4 LEDS on, 1 LED off.
 4 LEDS off, 1 LED on.

– continued –

3-2 Replacement, Monitor and Test procedures

Chart 3-1 (continued)

Replacement of Digital Interface circuit pack

Step	Procedure
5	Connect the carrier interface cable, then the network loop cable. If the Interface pack is defined as a Primary or Secondary clock source, connect the Clock Controller cable(s). When the network cable is installed, the LEDs will flash all LEDs on/ all LEDs off as the hardware reset/test is done.
6	Test the Interface pack using Overlay 60. The command is SLFT 'loop number'. If trouble is indicated by the response, refer to NTP 553-2301-511 for message interpretation. Otherwise, continue with the next step.
7	Enable the Network Loop using Overlay 60. Command is ENLL 'loop number'.

Clock Controller pack replacement

Chart 3-2

Replacement of Clock Controller circuit pack

Note: Do not deviate from this procedure. This procedure will not cause the system to SYSLOAD or initialize, but deviation could cause major service disruption for the complete system.,

CAUTION

Firmly touch the metal frame of the cabinet to discharge static electricity from your body before handling circuit packs

Chart 3-2 (continued)
Replacement of Clock Controller circuit pack

Step	Procedure
1	Ensure that the Clock Controller card being replaced is associated with the inactive CPU. Switch CPUs, if necessary, using Overlay 35. The command is SCPU.
2	Use Overlay 60 to disable the Clock Controller card being replaced. The command is DIS CC 'n'.
3	On the Clock Controller card being replaced, set the ENB/DIS switch to DIS.
4	Disconnect cables from Clock Controller card being replaced.
5	Remove card from shelf.
6	Set the ENB/DIS switch to DIS on the Clock Controller card being added.
7	Ensure that the option switch setting is correct. Depending on the Clock Controller, perform either (a) or (b): a) For the QPC471, set to OFF if the Clock Controller card is to be located in a CPU shelf (XN machine) or ON if it is to be located in a Network shelf., b) For the QPC775, refer to 553-2201-211 for option switch settings.
8	Install new Clock Controller card in same slot as the defective card.
9	Reconnect cable(s) to Clock Controller faceplate.
10	Set ENB/DIS switch on new Clock Controller to ENB.
11	Enable new Clock Controller card, using Overlay 60. The command is ENL CC 'n'.

- 12 Use Overlay 60 to verify normal service level. First; switch the active clock to standby. The command is SWCK 'n'.
Next; check the status of the new Clock Controller. The command is SSCK 'n'.
If a trouble is indicated by the response, refer to NTP 553-2301-511 for an interpretation of the message.
-

2.048 Megabit PCM line monitor

Chart 3-3

2.048 Megabit PCM line monitor

Step	Procedure
1	<p>To monitor the DTI 2.048 Mb/s pcm data stream, use: SIGNAL MONITOR,</p> <ul style="list-style-type: none">• model: EPMII,• ELMI, of Copenhagen Denmark• or equivalent.. <p>This SIGNAL MONITOR allows the user to monitor the framing patterns, alarm bit, or any of the thirty channels.</p> <p>Loopback plug (shorts pins 2 to 6 and 3 to 7 of a 9-pin D connector).</p>
2	<p>To monitor the DMI 2.048 Mb/s pcm data stream, use: SIGNAL MONITOR,</p> <ul style="list-style-type: none">• model: ANDO Multimedia MUX analyserAP-9205• or equivalent.. <p>This SIGNAL MONITOR allows the user to monitor the framing patterns, alarm bit, or any of the thirty channels.</p> <p>Loopback plug (shorts pins 2 to 7 and 3 to 6 of a 9-pin D connector).</p>

Verification tests for DTI2/DMI and CC packs

Chart 3-4

Verification tests for DTI2/DMI and CC packs

1. Verification test for DTI circuit pack

Step	Procedure
1	Disable the Network Loop, using Overlay 60. The command is DISL ' <i>loop number</i> '.
2	Test the DTI2 or DMI pack using Overlay 60. The command is SLFT ' <i>loop number</i> '. If a trouble is indicated by the response, check that the Network cable, Network card and carrier cable are installed properly. Run the Interface file test a second time. If a problem still exists, refer to NTP 553-2301-511 for message interpretation. Otherwise continue with the next step.
3	Enable Network Loop, using Overlay 60. Command is ENLL ' <i>loop number</i> '.

2. Verification test for the clock controller circuit pack

Step	Procedure
1	Switch the active clock to standby. The command is SWCK ' <i>n</i> '.
2	Check the Clock Controller status. The command is SSCK ' <i>n</i> '. If a trouble is indicated by the response, refer to NTP 553-2301-511 for message interpretation.

SL-1

2-Mb/s Digital Trunk Interface

Fault clearing procedures

© 1988Northern Telecom
All rights reserved.
Information subject to change without notice.
Product release: Group F
Document status: Standard
91 03 08
Printed in Canada

