

---

Meridian 1 and Succession Communication Server for Enterprise 1000

# DECT

## Installation Guide

---

Publication Number: 553-3601-203

Document Release: Standard 6.00

Date: September 2002

---

Copyright © 1997 - 2002 Nortel Networks,

All Rights Reserved

Printed in Canada

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. Hereby Nortel Networks declares the Meridian/Succession Companion DECT is in compliance with the essential requirements and other provisions of Directive 1999/5/EC. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manuals, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

Meridian 1, Succession, and Companion are trademarks of Nortel Networks. Windows, Windows NT, Windows 98, Windows 2000, and Internet Explorer are trademarks of the Microsoft Corporation. Netscape is a trademark of the Netscape Communications Corporation. Amphenol is a trademark of Amphenol Corporation. Southco is a trademark of Southco, Inc. DECT is a registered trademark of the European Telecommunications Standards Institute.



---

# Revision history

---

## September 2002

Standard, Release 6.00. This document has been updated to reflect support for Succession Communication Server for Enterprise (CSE) 1000, and for changes in technical content.

## June 2001

Standard, Release 5.00. This version introduces information about: DMC8, and OTM DECT Manager. This version excludes retired DMC equipment, associated parts, and DECT Manager (for Windows) in compliance with Product Bulletin PBME484, and Product Bulletin PBCE71. This version introduces a new document title *Meridian/Succession Companion DECT* and the NTP number 553-3601-203.

This version replaces all previous versions.

## March 2000

Standard, Release 4.00. This version introduces information about: DECT C4010 handset, C4010 Ex handset, C4020 handset, DECT Manager fill down for MSMN concentrated DCMs, MSMN implementation and operation.

## July 1999

Standard, Release 3.00. This version introduces information about: DECT Manager enhancements to the DECT Manager Connections, User Administration, Login Module, System Parameter files, and DMC addressing; the C4610 base station, and the C4010 handset. This version also introduces changes that improve the on-line and printed document. This version arranges the handset subscription chapter in a more logical order.

## July 1998

Standard, Release 2.00. This version introduces information about the C4040 handset.

**June 1998**

Standard, Release 1.00. The first release of the *Meridian Companion DECT Installation Guide*.

---

# Contents

---

|  |           |
|--|-----------|
| <b>About this document</b> .....                     | <b>11</b> |
| How to use this guide .....                          | 11        |
| Target audience .....                                | 11        |
| Identifying Nortel Networks PBX systems .....        | 11        |
| <br>   |           |
| <b>Hardware installation introduction</b> .....      | <b>13</b> |
| Introduction .....                                   | 13        |
| Reference list .....                                 | 13        |
| Before you begin .....                               | 13        |
| Unpack and examine the equipment .....               | 14        |
| <br>   |           |
| <b>Install base station</b> .....                    | <b>15</b> |
| Contents .....                                       | 15        |
| Reference list .....                                 | 15        |
| DECT base station rules .....                        | 15        |
| Compatibility .....                                  | 16        |
| C4610E base station .....                            | 16        |
| Install C4600, C4610, and C4610E base stations ..... | 18        |
| Install Base Station wiring to the MDF .....         | 20        |
| Install the base station external power supply ..... | 24        |
| Install base station in the external housing .....   | 27        |
| Attach the external housing to a wall .....          | 30        |

|   |           |
|---|-----------|
| <b>Install additional IPE shelves or small system cabinets</b> .....          | <b>35</b> |
| Contents .....  | 35        |
| Reference list .....  | 35        |
| Install additional IPE modules .....  | 36        |
| Install additional small system cabinets .....                                | 38        |
| Install IPE module wiring to the MDF .....                                    | 41        |
| Install small system cabinet wiring to the MDF .....                          | 45        |
| Install Option 11C Mini expander chassis .....                                | 46        |
| Install Succession CSE 1000 Media Gateway Expansion .....                     | 46        |
| <br>  |           |
| <b>Install DMC8 and faceplate cables</b> .....                                | <b>47</b> |
| Contents .....  | 47        |
| Reference list .....  | 47        |
| Compatibility .....   | 47        |
| Cross-connect base stations to the DMC8 positions .....                       | 48        |
| Cross-connect base stations to the DMC8 Relay card .....                      | 51        |
| Install DMC8 and DMC8-E in an IPE shelf (Option 51C to 81C) .....             | 53        |
| Install DMC8-E in Option 11C, Option 11 Mini, or Succession CSE 1000 .....    | 56        |
| Option 11C Mini .....   | 66        |
| Install faceplate cables and inter-shelf/cabinet cable .....                  | 67        |
| <br>  |           |
| <b>Install OTM DECT application</b> .....                                     | <b>71</b> |
| Contents .....  | 71        |
| Reference list .....  | 71        |
| Ensure the DECT application is on the OTM server .....                        | 72        |
| Ensure a Communications Profile is associated with the DECT application ..... | 73        |
| Add a Communications Profile for the DECT application .....                   | 75        |
| Add an Ethernet profile .....   | 77        |

---

|   |            |
|---|------------|
| <b>Configure the DECT system<br/>on the OTM server</b>                | <b>79</b>  |
| Contents  | 79         |
| Install the DME on the DMC8 Relay card                                | 80         |
| Change the DMC8 Relay card default IP address                         | 81         |
| Connect the DMC8 Relay card to a configuring PC                       | 81         |
| Reset the DMC8 Relay card default IP address to<br>the LAN IP address | 84         |
| Connect the DMC8 Relay card to the OTM server                         | 86         |
| Launch the DECT application   | 88         |
| Add the DECT system   | 89         |
| Add General System Properties   | 89         |
| Set the DECT system IP address to match<br>the DMC8 Relay card        | 91         |
| Add the upstream manager IP address, if required                      | 93         |
| Synchronize data with the DECT system                                 | 94         |
| Synchronize DECT PARI and SARI  | 97         |
| Synchronize DECT parameters   | 98         |
| Synchronize DECT Upstream Manager IP address                          | 99         |
| <br>  |            |
| <b>Un-installing DECT Manager – Caution</b>                           | <b>101</b> |
| <br>  |            |
| <b>Configure handsets and retrieve<br/>subscription data</b>          | <b>103</b> |
| Contents  | 103        |
| Reference list  | 104        |
| Configure non-concentrated handsets on a Meridian 1 PBX               | 105        |
| Open Station Administration window                                    | 105        |
| Access Add Station dialog   | 106        |
| Add 500 analog standard   | 107        |
| Access features   | 108        |
| Access wireless type  | 109        |
| Select wireless type  | 110        |
| Select DECT wireless set  | 111        |

|   |     |
|---|-----|
| Accept changes                                      | 112 |
| Configure concentrated handsets on a Meridian 1 PBX | 113 |
| Open Station Administration window                  | 113 |
| Access Add Station dialog                           | 114 |
| Select Digital Cordless Set                         | 115 |
| Select Features                                     | 116 |
| Select wireless type                                | 117 |
| Select Visiting DECT SET or local calling only      | 118 |
| Select an index                                     | 120 |
| Provision hardware                                  | 121 |
| Accept changes                                      | 122 |
| Select Single Line Features                         | 123 |
| Retrieve subscription data for handsets             | 124 |
| Enable subscription                                 | 126 |
| Activate the PIN on the handsets                    | 127 |
| Handset subscription                                | 128 |

## **Base Station Power and Muting . . . . . 129**

|   |     |
|---|-----|
| Contents  | 129 |
| Open RFP window   | 130 |
| Set alarm muting, line power, and comments<br>for base stations | 132 |

## **Add a V.24 serial connection . . . . . 135**

|   |     |
|---|-----|
| Contents  | 135 |
| Reference list  | 136 |
| DMC8 to OTM server serial connections                           | 136 |
| Serial connection for Windows 2000                              | 137 |
| Connect the Relay card to a local OTM server<br>without a modem | 137 |
| Connect the relay card to a remote OTM server with modems       | 139 |
| Install a virtual modem on the PC                               | 142 |
| Configure modem properties                                      | 144 |
| Set modem speed   | 146 |
| Set connection preferences                                      | 147 |

---

|   |            |
|---|------------|
| Disable flow control . . . . .                          | 149        |
| Configure Remote Access Service (RAS) . . . . .         | 150        |
| Set RAS modem and port usage . . . . .                  | 152        |
| Configure RAS setup and network . . . . .               | 153        |
| Configure NetBIOS services . . . . .                    | 155        |
| Set up and configure a RAS Phone book entry . . . . .   | 157        |
| Open the Dial-up Networking dialog . . . . .            | 157        |
| Set up the phone book entry name . . . . .              | 158        |
| Set up the server dialog . . . . .                      | 160        |
| Go to the next dialog . . . . .                         | 161        |
| Set up complete . . . . .                               | 162        |
| Configure the networking dial-up . . . . .              | 163        |
| Configure the Dial using an entry . . . . .             | 164        |
| Configure the Dial-up server type . . . . .             | 165        |
| Configure IP address . . . . .                          | 166        |
| Accept the configuration changes . . . . .              | 167        |
| Establish the RAS connection . . . . .                  | 168        |
| Establish a connection to the DECT system . . . . .     | 169        |
| Establish connection complete . . . . .                 | 170        |
| Set the IP address through Telnet . . . . .             | 171        |
| Configure the IP address . . . . .                      | 173        |
| Hang-up the RAS connection . . . . .                    | 174        |
| V.24 connection using Windows 2000 . . . . .            | 175        |
| Dial-up configuration . . . . .                         | 175        |
| Modem configuration . . . . .                           | 175        |
| Network and dial-up connections configuration . . . . . | 178        |
| DECT Access System configuration . . . . .              | 189        |
| Error messages . . . . .                                | 190        |
| Launch OTM-DECT back-end . . . . .                      | 191        |
| <br>  |            |
| <b>Multi-Site Mobility Networking . . . . .</b>         | <b>195</b> |
| Contents . . . . .                                      | 195        |
| Reference list . . . . .                                | 195        |
| Feature implementation . . . . .                        | 195        |
| Feature operation . . . . .                             | 199        |

|  |     |
|--|-----|
| Contents .....   | 201 |
| Introduction .....   | 202 |
| Backup the DMC4 data with Windows Manager .....                      | 203 |
| Upload OTM supporting firmware to the<br>DMC4 Relay card .....       | 205 |
| Close the Windows Manager .....                                      | 207 |
| Change the DMC4 Relay card default<br>IP address .....               | 208 |
| Connect the DMC4 Relay card to a configuring PC .....                | 208 |
| Reset the DMC4 Relay card to the server IP address .....             | 209 |
| Connect the DMC4 Relay to the OTM server .....                       | 210 |
| Add the DECT system .....  | 213 |
| Add General System Properties .....                                  | 213 |
| Set the DECT system IP address to match<br>the DMC4 Relay card ..... | 215 |
| Synchronize data with the DECT system .....                          | 217 |
| Confirm the active software package on the<br>DMC4 Relay card .....  | 219 |
| Activate the firmware on all DMC4s .....                             | 220 |
| Monitor the firmware activation .....                                | 221 |

---

## About this document

---

This document is a global document. Please contact your system supplier or your Nortel Networks representative to verify that the hardware and software described are supported in your area.

### How to use this guide

Complete the installation tasks in sequence. Start at the first page and proceed through the procedures until the end of this guide is reached.

### Target audience

The DECT Installation Guide provides information for installers, site maintenance personnel, and administrators.

### Identifying Nortel Networks PBX systems

The following systems are referred to in this guide as large systems:

- Option 51
- Option 61
- Option 71
- Option 81
- Option 51C
- Option 61C
- Option 81C

The following systems are referred to as small systems:

- Option 11
- Option 11E

- Option 11C
- Option 11C Mini
- Succession Communication Server for Enterprise 1000



**CAUTION: Data loss**

This symbol alerts you to a procedure that can result in a loss of data.



**CAUTION: Electrostatic sensitive device**

This symbol alerts you to a procedure that can result in equipment damage due to ElectroStatic Discharge (ESD).



**DANGER: Electric shock**

This symbol alerts you to the risk of serious injury, or death, caused by an electric shock.



**DANGER: Serious injury**

This symbol alerts you to the risk of serious injury, or death, caused by an immediate hazard.

---

# Hardware installation introduction

---

## Introduction

This chapter contains information on the following topics:

|  |    |
|--|----|
| <a href="#">Before you begin. ....</a>                 | 13 |
| <a href="#">Unpack and examine the equipment. ....</a> | 14 |

## Reference list

The following are the references in this section:

- *DECT Provisioning Records (553-3601-102)*

## Before you begin

Before the DECT system is installed, the following tasks must be completed:

- the site survey
- the deployment
- the installation of the house wiring for base stations

Before the DECT system is installed, the following information and materials are required:

- site work order
- list of equipment to be installed, showing quantities
- *DECT Provisioning Records (553-3601-102)*
- a marked-up floor plan
- a volt/ohm meter

- hand tools and hardware, such as
  - screwdrivers and pliers
  - spanners and socket wrenches
  - drill and drill bits
  - screws and screw anchors
  - punch-down tools for MDF and RJ-45 surface mount jacks
  - cable continuity checking equipment

## Unpack and examine the equipment

Complete the following steps:

**Table 1**  
**Unpack and examine the equipment**

| Step | Action   |
|------|--|
| 1    | Check the items shipped for discrepancies against the list of equipment required for the installation. |
|      | If any items are missing, take the action that is appropriate for this situation.                      |
| 2    | Carefully unpack and examine the equipment for damage.   |
|      | If any items are missing, take the action that is appropriate for this situation.                      |



*Note:* Store the equipment containers away from the installation area. Use the containers to return damaged equipment.

---

# Install base station

---

## Contents

This chapter contains information on the following topics:

|   |    |
|---|----|
| DECT base station rules. . . . .                        | 15 |
| Compatibility. . . . .                                  | 16 |
| Install C4600, C4610, and C4610E base stations. . . . . | 18 |
| Install Base Station wiring to the MDF. . . . .         | 20 |
| Install the base station external power supply. . . . . | 24 |
| Install base station in the external housing. . . . .   | 27 |
| Attach the external housing to a wall. . . . .          | 30 |
| Connect the external housing wiring to the MDF. . . . . | 32 |

## Reference list

The following are the references in this section:

- *System Installation Procedures* (553-3001-210)

## DECT base station rules

Be aware of the following rules:

- DC powered Meridian systems input voltage of at least –48 volts is required for maximum base station line length.
- One hundred ohms is the maximum line length for a C4610 high traffic base station. If the line measurement approaches 100 ohms, use an external power supply.
- If the exact location is not accessible, mount the base station as close as possible to the location in the site survey.

- Mount the base station in a vertical position, not horizontally, on a ceiling.
- Lead the base station cable directly away from the base station. Surplus cable can cause base station malfunctions.
- Place the base station where it is unlikely to be damaged. For example, a base station in a warehouse must be placed where it cannot be damaged by a forklift truck.
- Surrounding objects must not affect the base station. For example, a base station in a car park needs to be placed higher than any vehicle parked next to it.
- The minimum distance between two base stations must be greater than two meters.
- Do not mount base stations on large concrete or stone columns, air ducts or large metal objects.
- The external base station is powered from the line connection and does not require a mains connection.
- Use the external housing kit to mount any base station out-of-doors.
- Use the external housing kit for any base station subject to conductive pollution or dust that could become conductive due to condensation.

## Compatibility

The C4600, C4610, and C4610E base stations are compatible with all DECT, Meridian 1, and Succession CSE 1000 software releases. The base stations are backward compatible.

## C4610E base station

The C4610E 12-channel base station has an adaptor to support an external antenna. The external antenna increases the operating distance between the base station and the DECT handset. Nortel Networks recommends the use of a Huber & Suhner dual-planar directional antenna. Directional antennas are suitable for use in places such as large halls, outside parking lots, and between buildings. See [Figure 1 on page 17](#).

*Note:* The Huber & Suhner 8.0dBi and 10.5dBi antenna packages were tested with the C4610E base station. Other third-party directional antenna are available, but have not been tested with this base station.


**Figure 1**  
**A Huber & Suhner dual-planar directional antenna**



## Install C4600, C4610, and C4610E base stations

Consult the work order and marked-up floor plan to determine the position of the base station, then perform the steps in Table 2 on page 19:

**Figure 2**  
**Base station mounting details**



- a.** screw mounting slot
- b.** screw and cable tie retaining washer hole
- c.** cable tie grooves

**Table 2**  
**Install C4600, C4610, and C4610E base station**

| <b>Step</b>   | <b>Action</b>  |
|---|--|
|   |  |
| <b>1</b>  | Locate the base station mounting position.   |
|   |  |
| <b>2</b>  | Install the base station mounting screw.   |
|   | If required, drill the holes for a screw anchor and install the anchor.  |
| <b>3</b>  | Fasten the base station on the wall or a building protrusion.  |
|   | Hang the base station on the screw or use cable ties to mount the base station. Insert the cable ties in the vertical or horizontal grooves on the back of the base station. Secure the cable ties to the base station with the retaining washers and screws provided. Fasten the cable ties to the building protrusion. |
| <b>4</b>  | If installing the C4610E base station, install the external antenna according to the manufacturer's instructions.  |
|   |  |
|  |  |

## Install Base Station wiring to the MDF

Consult the work order and marked-up floor plan to determine the base station to MDF connections, then follow the steps in Table 3 on page 21.




### CAUTION: Service interruption

For maximum line length before signal degradation occurs, use UTP Cat 5 cabling between the base station and the shelf or cabinet. If the line length exceeds 100 ohms for the 4610 base station, an external power supply must be used.

The maximum distance when using external power with UTP Cat 5 cabling is approximately 1.7 km.

**Figure 3**  
Base station, MDF, and I/O panel details




- a. RJ-45 single surface mount jack
- b. MDF
- c. recommended UTP Cat 5 cable
- d. IPE shelf I/O connector panel

**Table 3**  
**Install Base Station wiring to the MDF**

| Step   | Action  |
|--|---|
| 1  | Connect one end of the NTCW10 cable into the base station RJ-45 jack.   |
|  | Use the supplied cable.   |
| 2  | Install the RJ-45 single surface mount jack.  |
|  | Use the NTCW10 cable length to measure the location of the RJ-45 surface mount jack.  |
| 3  | Connect a UTP3/UTP5 cable from the MDF house side to the RJ-45 surface mount jack.  |
|  | <p><a href="#">Table 4 on page 22</a> shows the RJ-45 plug/socket to MDF connections. For DMC8s type NTCW00AB and NTCW01AB connect from base station 1 to base station 8.</p> <p><b>Note:</b> To support base stations 5, 6, 7, and 8 on NT8D37 (AA and DC) IPE modules requires 24 tip and ring pair backplane to I/O panel connections. To re-cable NT8D37 from 16 pair to 24 pair, see <i>System Installation Procedures</i> (553-3001-210), Appendix C.</p> |
| 4  | Connect the free end of the NTCW10 cable into the RJ-45 surface mount jack.   |
|  |   |
|  |   |

**Note:** The BIX tip and ring connections shown in [Table 4 on page 22](#) correspond to standard BIX designation. The first pair are labeled T0 and R0. See *System Installation Procedures* (553-3001-210), section *Planning and Designating the MDF*.

**Figure 4**  
**RJ-45 plug/socket connections to base station 1 MDF**



**Table 4**  
**Base station RJ-45 to BIX MDF connections (Part 1 of 2)**

| Base station number | RJ-45 pin out of the plug and socket | MDF connection |
|---------------------|--------------------------------------|----------------|
| Base station 1      | 4                                    | T8             |
| Base station 1      | 5                                    | R8             |
| Base station 1      | 6                                    | T9             |
| Base station 1      | 3                                    | R9             |
| Base station 2      | 4                                    | T10            |
| Base station 2      | 5                                    | R10            |
| Base station 2      | 6                                    | T11            |
| Base station 2      | 3                                    | R11            |
| Base station 3      | 4                                    | T12            |
| Base station 3      | 5                                    | R12            |
| Base station 3      | 6                                    | T13            |

**Table 4**  
**Base station RJ-45 to BIX MDF connections (Part 2 of 2)**

| Base station number | RJ-45 pin out of the plug and socket | MDF connection |
|---------------------|--------------------------------------|----------------|
| Base station 3      | 3                                    | R13            |
| Base station 4      | 4                                    | T14            |
| Base station 4      | 5                                    | R14            |
| Base station 4      | 6                                    | T15            |
| Base station 4      | 3                                    | R15            |
| Base station 5      | 4                                    | T16            |
| Base station 5      | 5                                    | R16            |
| Base station 5      | 6                                    | T17            |
| Base station 5      | 3                                    | R17            |
| Base station 6      | 4                                    | T18            |
| Base station 6      | 5                                    | R18            |
| Base station 6      | 6                                    | T19            |
| Base station 6      | 3                                    | R19            |
| Base station 7      | 4                                    | T20            |
| Base station 7      | 5                                    | R20            |
| Base station 7      | 6                                    | T21            |
| Base station 7      | 3                                    | R21            |
| Base station 8      | 4                                    | T22            |
| Base station 8      | 5                                    | R22            |
| Base station 8      | 6                                    | T23            |
| Base station 8      | 3                                    | R23            |

## Install the base station external power supply

For the C4600, C4610, and C4610E base stations, an external power supply must be installed if the UTP Cat 5 line resistance exceeds 100 ohms.

**Figure 5**  
**C4610 base station external power**





Figure 6  
C4610E external power and external antenna connectors



**Table 5**  
**Install the C4610 base station external power supply**


| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             |   |
| <b>1</b>    | Remove the plastic stopper from the C4610 base station power socket.<br>The power socket is located next to the yellow LED. |
| <b>2</b>    | Plug the external power supply jack into the C4610 base station power socket.   |
|             |   |
| <b>3</b>    | Connect the external power supply to the ac mains outlet.   |
|             |   |



## Install base station in the external housing


Consult the work order, then perform the steps in Table 7 on page 31:

**Figure 7**  
**External housing details**



- a. component mounting plate
- b. power transformer (not used)
- c. cable connecting box
- d. base station
- e. plate retaining nuts
- f. cable outlet
- g. external housing cabinet

**Figure 8**  
**Base station mounting details**



**CAUTION: Equipment damage**

The following procedure requires the removal of the base station cover. The circuit board is attached to the base station cover. Do not damage the circuit board or bend the two antennas on the bottom of the circuit board.

**Table 6**  
**Install the base station in the external housing**


| Step | Action  |
|------|---|
| 1    | Open the external housing cover.  |
|      | Insert the external housing key and turn clockwise.   |
| 2    | Remove the base station mounting plate.   |
|      | Unscrew the four nuts securing the plate and pull the plate from the cabinet.   |
| 3    | Remove the base station cover. See the preceding caution note on page 28.   |
|      | Carefully pry one corner of the cover from the base station, then the other corner.   |
| 4    | Remove the base station lower screw hole cover.   |
|      | Push the screw hole cover out of the base station.  |
| 5    | Mount the base station to the housing plate.  |
|      | Affix with the screws as shown in <a href="#">Figure 8</a> .  |
| 6    | Replace the base station cover.   |
|      | Snap the cover in place.  |
| 7    | Connect the connecting box cable to the base station.   |
|      | Snap the connecting box cable into the base station RJ-45 connector. Lead the cable away from the base station for optimal performance of the antennas. |
| 8    | Replace the base station mounting plate.  |
|      | Secure the plate with the four nuts.  |




## Attach the external housing to a wall

Consult the work order and marked-up floor plan to determine the position of the base station external housing, then perform the following steps:

**Figure 9**  
**External housing mounting lugs**



**Figure 10**  
**External housing wall mounting**



**DANGER: Electric shock**

Do not drill into electrical wires that are embedded in the wall.

**Table 7**  
**Attach the external housing to a wall**


| Step | Action   |
|------|--|
| 1    | Choose the vertical or horizontal mounting position.<br>See <a href="#">Figure 9 on page 30</a> for details. Reposition mounting lugs if necessary.                          |
| 2    | Drill mounting holes in the wall.<br>Use the drilling jig to align the holes.  |
| 3    | Mount the external housing to the wall.<br>See <a href="#">Figure 10 on page 30</a> for details. Use the screws, and appropriate inserts, to fasten the housing to the wall. |



## Connect the external housing wiring to the MDF

Consult the work order, then perform the steps in Table 8:

**Figure 11**  
External housing MDF connection details



*Note:* The BIX tip and ring connections shown in [Table 9 on page 33](#) correspond to standard BIX designation. The first pair are labelled T0 and R0. See *System Installation Procedures (553-3001-210)*, section *Planning and Designating the MDF*.

**Table 8**  
Connect the external housing wiring to the MDF (Part 1 of 2)

| Step | Action  |
|------|---|
| 1    | Lead the building cable into the external housing.                |
|      | Route the cable through the cable outlet in the external housing. |

**Table 8**  
**Connect the external housing wiring to the MDF (Part 2 of 2)**

| Step  | Action   |
|---|--|
| 2   | Secure the cable in the connecting box.  |
|   | Use a cable tie-wrap.  |
| 3   | Connect the external housing wiring from the connecting box to the MDF.  |
|   | <p><b>Note:</b> See <a href="#">Figure 11 on page 32</a> and <a href="#">Table 9 on page 33</a> for wiring connections. For DMC8 types NTCW00AB and NTCW01AB, connect from base station 1 to base station 8.</p> <p><b>Note:</b> To support base stations 5, 6, 7, and 8 on NT8D37 (AA and DC) IPE modules requires 24 tip and ring pair backplane to I/O panel connections. To re-cable NT8D37 from 16 pair to 24 pair, see <i>System Installation Procedures</i> (553-3001-210), Appendix C.</p> |
|  |  |

**Table 9**  
**External housing base station to BIX MDF connections (Part 1 of 2)**

| External housing base station number | External housing connector box pin number | MDF connection |
|--------------------------------------|---|----------------|
| Base station 1                       | 3   | T8             |
| Base station 1                       | 4   | R8             |
| Base station 1                       | 2   | T9             |
| Base station 1                       | 5   | R9             |
| Base station 2                       | 3   | T10            |
| Base station 2                       | 4   | R10            |
| Base station 2                       | 2   | T11            |
| Base station 2                       | 5   | R11            |
| Base station 3                       | 3   | T12            |

**Table 9**  
**External housing base station to BIX MDF connections (Part 2 of 2)**

| External housing base station number | External housing connector box pin number | MDF connection |
|--------------------------------------|---|----------------|
| Base station 3                       | 4   | R12            |
| Base station 3                       | 2   | T13            |
| Base station 3                       | 5   | R13            |
| Base station 4                       | 3   | T14            |
| Base station 4                       | 4   | R14            |
| Base station 4                       | 2   | T15            |
| Base station 5                       | 4   | T16            |
| Base station 5                       | 5   | R16            |
| Base station 5                       | 6   | T17            |
| Base station 5                       | 3   | R17            |
| Base station 6                       | 4   | T18            |
| Base station 6                       | 5   | R18            |
| Base station 6                       | 6   | T19            |
| Base station 6                       | 3   | R19            |
| Base station 7                       | 4   | T20            |
| Base station 7                       | 5   | R20            |
| Base station 7                       | 6   | T21            |
| Base station 7                       | 3   | R21            |
| Base station 8                       | 4   | T22            |
| Base station 8                       | 5   | R22            |
| Base station 8                       | 6   | T23            |
| Base station 8                       | 3   | R23            |

---

# Install additional IPE shelves or small system cabinets

---

## Contents

This chapter contains information on the following topics:

|  |    |
|--|----|
| Install additional IPE modules. ....                 | 36 |
| Install additional small system cabinets. ....       | 38 |
| Install IPE module wiring to the MDF. ....           | 41 |
| Install small system cabinet wiring to the MDF. .... | 45 |

## Reference list

The following are the references in this section:

- *Option 11C Planning and Installation (553-3021-210)*
- *System Installation Procedures (553-3001-210)*
- *Option 11C Mini Planning and Installation (553-3021-209)*
- *Succession CSE 1000 – Installation and Configuration Guide (553-3023-210)*

## Install additional IPE modules

Consult the work order and marked-up floor plan to determine if additional IPE modules are required, then perform the steps in Table 10:

*Note:* If unfamiliar with this process, refer to *System Installation Procedures* (553-3001-210).

**Table 10**  
Install additional IPE modules (Part 1 of 2)

| Step | Action   |
|------|--|
| 1    | Remove the IPE module front and rear covers.<br>Remove the covers from the module on which the DECT module will sit.   |
| 2    | Remove the air grills.<br>Release the air grill tabs or Southco® fasteners and lift the air grill off.   |
| 3    | Remove the top cap.<br>Loosen and remove the three front and rear top cap bolts. Lift off top cap.   |
| 4    | Unfasten the column LED.<br>Remove the LED bracket bolts.  |
| 5    | Remove the I/O back panel cover.<br>Unlock the four Southco fasteners.   |
| 6    | Disconnect the column LED.<br>Unlock LED wiring connector latches on the module backplane. Detach the LED wiring connector.  |
| 7    | Disconnect the thermal sensor connector.<br>Unlock the sensor connector latches on the 36 pin orange/brown colored connector, located to the left of the LED connector. Unplug the sensor connector. |
| 8    | Remove the EMI perf panel.<br>Lift directly up.  |

**Table 10**  
**Install additional IPE modules (Part 2 of 2)**

| <b>Step</b> | <b>Action</b>   |
|-------------|---|
| <b>9</b>    | Place the new module on top of the column.  |
|             | Keep hands and fingers out from under the module when placing the module on top of the equipment column.            |
| <b>10</b>   | Connect the new module wiring.  |
|             | Install the sensor connector of the new module into the vertical connector housing of the module below.             |
| <b>11</b>   | Secure the new module.  |
|             | Insert the five bolts and lock washers into the base of the new module. Tighten the bolts into the original module. |
| <b>12</b>   | Attach the power cable.   |
|             | Connect the ribbon cable of the new module to J2 of the module below.   |
| <b>13</b>   | Re-install the EMI perf panel and the LED.  |
|             | Install the LED connector and the sensor connector on the new module.   |
| <b>14</b>   | Replace the air grills and covers.  |
|             | Reverse the procedure for steps 1 to 4.   |



## Install additional small system cabinets

Consult the work order and marked-up floor plan to determine if additional small system cabinets are required, then perform the following steps:

**Note:** If not familiar with this process, refer to *Option 11C Planning and Installation* (553-3021-210).



### CAUTION: Electrostatic sensitive device

Wear a properly connected antistatic wrist strap to handle circuit cards. Only touch the edges. Do not touch the contacts or components. Set the cards on a protective antistatic bag. If an antistatic bag is not available, hand-hold the card, or set it in a card cage unseated from the connectors.

**Table 11**  
Install additional small system cabinets (Part 1 of 3)

| Step | Action  |
|------|---|
| 1    | Mount the expansion cabinet.  |
|      | For a wall mount, draw a level line, rest the bottom of mounting bracket on the line, screw the mounting bracket to the wall. Hang the cabinet on the mounting bracket. Fasten the bottom of the cabinet to the wall.<br>For a floor mount, install the cabinet on the pedestal. Position the cabinet according to the equipment layout plan. |
| 2    | Remove the drip tray.   |
|      | Slide drip tray outward.  |
| 3    | Install ground wire.  |
|      | As a minimum, use #6AWG ground wire. Tag the main ground connection at the ground source to ensure it is not accidentally discontinued. Test the ground.  |
| 4    | Install the power supply.   |
|      | Wear the anti-static wrist strap. Turn power supply circuit breaker to OFF. Check the option switches on the power supply.  |

**Table 11**  
**Install additional small system cabinets (Part 2 of 3)**

| <b>Step</b> | <b>Action</b>   |
|-------------|---|
| <b>5</b>    | Install the fiber routing guide.  |
|             | Mount the guide in the area below the circuit cards and secure with the existing screws.  |
| <b>6</b>    | Connect the fiber optic cable or copper cable as applicable.  |
|             | For the A0618443 cable, remove the two plugs on the Fiber Receiver card. Connect the cable to the card so the “V” shaped groove is facing inward. For the glass fiber optic cable, remove the plug on one connector on the card, and the cap on the cable. Insert the connector and secure with a half turn clockwise. Wind the excess cable on the storage device. |
| <b>7</b>    | Insert the circuit cards in the expansion cabinet.  |
|             | Refer to “Install DMC8-Es” Table 22 on page 58 and the work order for card placement.   |
| <b>8</b>    | Install or expand the MDF cross-connect terminal.   |
|             | Consult the marked-up floor plan for the MDF addition location.   |
| <b>9</b>    | Install cables from the cabinet to the MDF cross-connect.   |
|             | Consult the marked-up floor plan for the cable location.  |
| <b>10</b>   | Install PFTU and SDI cable if required.   |
|             | Consult the marked-up floor plan for the cable location.  |
| <b>11</b>   | Replace the expansion cabinet drip tray.  |
|             | Slide the drip tray inward.   |
| <b>12</b>   | Remove the main cabinet cover and drip tray.  |
|             | Undo the catches on the main cabinet and slide the drip tray outward.   |
| <b>13</b>   | Install a Fiber Routing guide in the main cabinet, if required.   |
|             | The Fiber Routing guide is secured to the under side of the bottom card rail and uses the screws to the left of the CPU card label and under the card 2 label.  |
| <b>14</b>   | Turn the power supply circuit breaker to OFF.   |
|             |   |

**Table 11**  
**Install additional small system cabinets (Part 3 of 3)**

| Step | Action   |
|------|--|
| 15   | Unseat the NTDK20 SSC card and install a Fiber Expansion daughterboard.  |
|      | Connect the Fiber Expansion daughterboard to the connector “Fiber 1” if this is the first expansion cabinet, or to “Fiber 2” if this is the second expansion cabinet.  |
| 16   | Connect the fiber optic cable to the Fiber Expansion daughterboard.  |
|      | For the A0618443 cable, remove the two plugs on the Fiber Receiver card. Connect the cable to the card so the “V” shaped groove is facing inward. For the glass fiber optic cable, remove the plug on one connector on the card and the cap on the cable. Insert the connector and secure with a half turn clockwise. Wind the excess cable on the storage device. |
| 17   | Re-seat the NTDK20 SCC card.   |
|      |  |
| 18   | Route the fiber optic cable through the Fiber Routing Guide.   |
|      |  |
| 19   | Set the circuit breaker in the main cabinet to ON.   |
|      | The system reloads. Check time and date using LD 2.  |
| 20   | Re-install the drip tray in the main cabinet.  |
|      |  |
| 21   | Re-install the main cabinet cover.   |
|      |  |



## Install IPE module wiring to the MDF


Consult the work order to determine the layout of the module I/O panel to MDF cabling route, then perform the steps in Table 12 on page 43.



### CAUTION: Service interruption

The existing MDF cabling can be used; however, UTP Cat 5 – NTCW15, NTCW16, or NTCW17 MDF to PBX cabling is recommended, as it provides a greater line length before signal degradation occurs.


**Figure 12**  
IPE I/O cable to BIX MDF termination



553-8145.EPS

**Note:** In NT8D11AC or NT8D11DC CE/PE and NT8D37AC or NT8D37DC IPE modules, these BIX connectors are not used. However, they are used in the NT8D11BC or NT8D11EC CE/PE and NT8D37BA or NT8D37 EC IPE modules.

**Figure 13**  
IPE I/O cable to Krone MDF termination



**Table 12**  
**Install IPE module wiring to the MDF**

| Step | Action   |
|------|--|
| 1    | Identify the UTP Cat 5 twenty-five pair MDF cable.   |
|      | Label both ends of the cable with the IPE module number and the I/O panel letter designation.  |
| 2    | Connect the IPE or cabinet end of the cable.   |
|      | Insert the cable's Amphenol® connector into the appropriate I/O panel connector. See <a href="#">Table 13 on page 43</a> .   |
| 3    | Run the cable to the MDF.  |
|      |  |
| 4    | Terminate the cable on the MDF.  |
|      | For BIX MDF, refer to <a href="#">Figure 12 on page 41</a> to locate the BIX connectors and <a href="#">Table 13 on page 43</a> to locate the cable color code. For Krone MDF, refer to <a href="#">Figure 13 on page 42</a> to locate the Krone connectors and <a href="#">Table 13</a> to locate the cable color code. |



**Table 13**  
**Color code for 25 pair cable (Part 1 of 2)**

| Amphenol pin number | Tip          | Ring         |
|---------------------|--------------|--------------|
|                     | Body/Band    | Body/Band    |
| 26/1                | White/Blue   | Blue/White   |
| 27/2                | White/Orange | Orange/White |
| 28/3                | White/Green  | Green/White  |
| 29/4                | White/Brown  | Brown/White  |
| 30/5                | White/Slate  | Slate/White  |
| 31/6                | Red/Blue     | Blue/Red     |


**Table 13**  
**Color code for 25 pair cable (Part 2 of 2)**

| Amphenol pin number | Tip           | Ring          |
|---------------------|---------------|---------------|
|                     | Body/Band     | Body/Band     |
| 32/7                | Red/Orange    | Orange/Red    |
| 33/8                | Red/Green     | Green/Red     |
| 34/9                | Red/Brown     | Brown/Red     |
| 35/10               | Red/Slate     | Slate/Red     |
| 36/11               | Black/Blue    | Blue/Black    |
| 37/12               | Black/Orange  | Orange/Black  |
| 38/13               | Black/Green   | Green/Black   |
| 39/14               | Black/Brown   | Brown/Black   |
| 40/15               | Black/Slate   | Slate/Black   |
| 41/16               | Yellow/Blue   | Blue/Yellow   |
| 42/17               | Yellow/Orange | Orange/Yellow |
| 43/18               | Yellow/Green  | Green/Yellow  |
| 44/19               | Yellow/Brown  | Brown/Yellow  |
| 45/20               | Yellow/Slate  | Slate/Yellow  |
| 46/21               | Violet/Blue   | Blue/Violet   |
| 47/22               | Violet/Orange | Orange/Violet |
| 48/23               | Violet/Green  | Green/Violet  |
| 49/24               | Violet/Brown  | Brown/Violet  |
| 50/25               | Violet/Slate  | Slate/Violet  |

## Install small system cabinet wiring to the MDF

Consult the work order to determine the small system cabinet-to-MDF cabling route, then perform the steps in Table 14 on page 46:

**Figure 14**  
**Option 11 MDF details**



**Table 14**  
**Install small system cabinet wiring to the MDF**

| Step | Action  |
|------|---|
| 1    | Identify the UTP Cat 5 twenty five pair MDF cable.  |
|      | Label both ends of the cable with the cabinet jack number.  |
| 2    | Connect the cabinet end of the cable.   |
|      | Insert the cable's Amphenol connector into the appropriate cabinet connector jack.  |
| 3    | Run the cable to the MDF.   |
|      |   |
| 4    | Terminate the cable on the MDF.   |
|      | For BIX MDF, refer to <a href="#">Figure 14 on page 45</a> to locate the BIX connectors and <a href="#">Table 13 on page 43</a> to locate the cable color code. |



## Install Option 11C Mini expander chassis

For information on installing an Option 11C Mini expander chassis, refer to [Option 11C Mini Planning and Installation](#) (553-3021-209).

## Install Succession CSE 1000 Media Gateway Expansion

For information on installing a Succession CSE 1000 Media Gateway Expansion, refer to Succession CSE 1000 – [Installation and Configuration Guide](#) (553-3023-210).

---

# Install DMC8 and faceplate cables

---

## Contents

This chapter contains information on the following topics:

|   |    |
|---|----|
| Compatibility .....   | 49 |
| Cross-connect base stations to the DMC8 positions. ....                       | 50 |
| Cross-connect base stations to the DMC8 Relay card. ....                      | 53 |
| Install DMC8 and DMC8-E in an IPE shelf (Option 51C to 81C). ....             | 55 |
| Install DMC8-E in Option 11C, Option 11 Mini, or<br>Succession CSE 1000 ..... | 58 |
| Install faceplate cables and inter-shelf/cabinet cable. ....                  | 69 |

## Reference list

The following are the references in this section:

- *System Installation Procedures* (553-3001-210)
- *Option 11C Planning and Installation* (553-3021-210)
- *DECT Overview* (553-3601-103)

## Compatibility

The NTCW00AB DMC8 and NTCW01AB DMC8-E cards are compatible with the following Meridian 1 software releases:

- Release 23 and later supports basic configuration, CLID and CPND, DECT card addressing within OA&M, 16 users per card.

- Release 24B and later supports 32 users per card.
- Release 25 and later supports MSMN and Concentration.

## Cross-connect base stations to the DMC8 positions

Consult the work order to determine the cross-connect details and perform the following steps:



### CAUTION: Service interruption

The jumper wire on the MDF must be at least UTP Cat 3. UTP Cat 5 is recommended as it provides a greater line length before signal degradation occurs.

**Table 15**  
Cross-connect base stations to the DMC8 positions

| Step | Action   |
|------|--|
| 1    | Cross-connect from the base station house side connector to the DMC8 equipment side connector.   |
|      | Connect a jumper wire from the tip and ring of the house side connector to the tip and ring of the equipment side connector. Refer to Table 16 on page 49 for the tip and ring designators. For DMC8s type NTCW00AB and NTCW01AB, connect from base station 1 to base station 8.<br><br><b>Note:</b> To support base stations 5, 6, 7, and 8 on NT8D37 (AA and DC) IPE modules, use 24 tip and ring pair backplane to I/O panel connections. To re-cable NT8D37 from 16 pair to 24 pair, see <i>System Installation Procedures</i> (553-3001-210), Appendix C. |
| 2    | Cross-connect the remaining base stations.   |
|      | Repeat step one until all base stations are cross-connected.   |



**Note:** The BIX tip and ring connections shown in [Table 2](#) correspond to standard BIX designation. The first pair are labeled T0 and R0. See *System Installation Procedures (553-3001-210)*, section *Planning and Designating the MDF*.

**Table 16**  
Base station tip and ring connections (Part 1 of 2)

| Base station number | Base station MDF connection | DMC8 MDF connection |
|---------------------|-----------------------------|---------------------|
| Base station 1      | T8                          | T8                  |
| Base station 1      | R8                          | R8                  |
| Base station 1      | T9                          | T9                  |
| Base station 1      | R9                          | R9                  |
| Base station 2      | T10                         | T10                 |
| Base station 2      | R10                         | R10                 |
| Base station 2      | T11                         | T11                 |
| Base station 2      | R11                         | R11                 |
| Base station 3      | T12                         | T12                 |
| Base station 3      | R12                         | R12                 |
| Base station 3      | T13                         | T13                 |
| Base station 3      | R13                         | R13                 |
| Base station 4      | T14                         | T14                 |
| Base station 4      | R14                         | R14                 |
| Base station 4      | T15                         | T15                 |
| Base station 4      | R15                         | R15                 |
| Base station 5      | T16                         | T16                 |
| Base station 5      | R16                         | R16                 |
| Base station 5      | T17                         | T17                 |
| Base station 5      | R17                         | R17                 |
| Base station 6      | T18                         | T18                 |


**Table 16**  
**Base station tip and ring connections (Part 2 of 2)**

| Base station number | Base station MDF connection | DMC8 MDF connection |
|---------------------|-----------------------------|---------------------|
| Base station 6      | R18                         | R18                 |
| Base station 6      | T19                         | T19                 |
| Base station 6      | R19                         | R19                 |
| Base station 7      | T20                         | T20                 |
| Base station 7      | R20                         | R20                 |
| Base station 7      | T21                         | T21                 |
| Base station 7      | R2                          | R21                 |
| Base station 8      | T22                         | T22                 |
| Base station 8      | R22                         | R22                 |
| Base station 8      | T23                         | T23                 |
| Base station 8      | R23                         | R23                 |

## Cross-connect base stations to the DMC8 Relay card

Consult the work order to determine the cross-connect details, then perform the steps in Table 18 on page 52.

Figure 17  
DMC8 Relay card to base station connections



**Table 18**  
**Cross-connect base stations to the DMC8 positions**

| Step | Action   |
|------|--|
| 1    | Connect the NTCW12DA cable to the DMC8 Relay card.   |
|      | Insert P1 into the DMC8 Relay card backplane connector located on the Meridian 1 PBX shelf/module or the Option 11C cabinet.   |
| 2    | Connect the MDF cable to the NTCW12DA cable.   |
|      | Insert the MDF cable connector into P2.  |
| 3    | Connect the MDF cable to the equipment side MDF cross-connect terminal block.  |
|      | See <i>System Installation Procedures</i> (553-3001-210) section “Cabling lines and trunks”, or <i>Option 11C Planning and Installation</i> (553-3021-210), section “Installing and connecting cross-connect terminal to cabinets”.  |
| 4    | Cross-connect from the base station house-side connector to the DMC8 Relay card equipment side connector.  |
|      | Connect a jumper wire from the tip and ring of the house-side connector to the tip and ring of the equipment-side connector. Refer to Table 16 on page 49 for the tip and ring designators. For DMC8s, type NTCW00AB and NTCW01AB connect from base station 1 to base station 8. |
|      | To support base stations 5, 6, 7, and 8 on NT8D37 (AA and DC) IPE modules requires 24 tip and ring pair backplane to I/O panel connections. To re-cable NT8D37 from 16 pair to 24 pair, see <i>System Installation Procedures</i> (553-3001-210), Appendix C.                    |



## Install DMC8 and DMC8-E in an IPE shelf (Option 51C to 81C)

Refer to the work order and marked-up floor plan to determine the position of the DMC8 and DMC8-E, then perform the steps in Table 20 on page 55.



### **CAUTION: Electrostatic sensitive device**

Wear a properly connected antistatic wrist strap to handle circuit cards. Only touch the edges. Do not touch the contacts or components. Set the cards on a protective antistatic bag, whenever possible. If an antistatic bag is not available, hand-hold the card, or set it in a card cage removed from the connectors.




### **CAUTION: Service interruption**

Only install DMC8-Es in slot 8.

**Note 1:** Install the DMC8s next to each other so the faceplate cables connect to the ports.

**Note 2:** See *DECT Overview* (553-3601-103), section “System software parameters” for DMC8 and DMC8-E software package compatibility.

**Figure 19**  
**DMC8/DMC8-E jumper details**



See [page 59](#) for Option 11C card jumper settings.



**CAUTION: Service interruption**

Ensure that the DMC8/DMC8-E Relay card jumpers J6 to J9 are in the ETH position for operation on a dedicated LAN.

Ensure that the DMC8/DMC8-E Relay card jumpers J6 to J9 are in the V.24 position for operation on a serial connection to the OTM server.

**Table 20**  
**Install DMC8 and DMC8-E in an IPE shelf (Option 51C to 81C)**

| Step | Action   |
|------|--|
| 1    | Install J1 jumper straps on the DMC8 and the DMC8-Es for Card ID.  |
|      | For pre-Release 23 software, strap A B. For post-Release 23 software, and Multi-Site Mobility Networking, strap B C.   |
| 2    | Install J2 jumper straps on the DMC8 and the DMC8-Es for the system type.  |
|      | Strap A B for IPE shelf. (See Table 22 on page 58 for Option 11C settings.)  |
| 3    | Install J3 jumper straps on the DMC8 and the DMC8-Es for cabinet or IPE shelf number.  |
|      | For shelf 0, the lower TN IPE shelf, strap B C. For shelf 1, the higher TN IPE shelf, strap A B.   |
| 4    | Install J6 to J9 jumper straps on the DMC8 and the DMC8-Es used as the Relay card for either V.24 connection or Ethernet connection.   |
|      | For the V.24 connection strap jumpers J6 to J9 to the V24 position. For the Ethernet connection strap jumpers J6 to J9 to the ETH position.  |
| 5    | Insert DMC8-E(s), if required.   |
|      | Place DMC8-E(s) in slot 8. See examples in <a href="#">Figure 18</a> , <a href="#">Figure 19</a> , <a href="#">Figure 20</a> , and <a href="#">Figure 21</a> .   |
| 6    | Insert DMC(s).   |
|      | Place DMC8s in the slots as indicated on the work order. Do not place DMC8s in slot 8. See examples in <a href="#">Figure 18</a> , <a href="#">Figure 19</a> , <a href="#">Figure 20</a> , and <a href="#">Figure 21</a> . |



## Install DMC8-E in Option 11C, Option 11 Mini, or Succession CSE 1000

Consult the work order and marked-up floor plan to determine the position of the DMC8 and DMC8-Es, then perform the steps in Table 22 on page 58.



### **CAUTION: Electrostatic sensitive device**

Wear a properly connected antistatic wrist strap when handling circuit cards. Handle cards by the edges only. Do not touch the contacts or components. Set the cards on a protective antistatic bag, whenever possible. If an antistatic bag is not available, hand-hold the card, or set it in a card cage unseated from the connectors.




### **CAUTION: Service interruption**

Do not install DMC8-Es into any slot except slots 9, 19, or 29.

**Note 1:** The DMC8s must be adjacent to each other so the faceplate cables can be connected to the ports.

**Note 2:** See *DECT Overview* (553-3601-103) section “System software parameters” for DMC8 and DMC8-E software package compatibility.

**Figure 21**  
**DMC8/DMC8-E jumper details**



See [page 56](#) for Option 51C to 81C card jumper settings.



**CAUTION: Service interruption**

Ensure that the DMC8/DMC8-E Relay card jumpers J6 to J9 are in the ETH position for operation on a dedicated LAN.

Ensure that the DMC8/DMC8-E Relay card jumpers J6 to J9 are in the V.24 position for operation on a serial connection to the OTM server.

**Table 22**  
**Install DMC8-E in an Option 11C cabinet, Option 11C Mini cabinet, Succession CSE 1000 Media Gateway, or Succession CSE 1000 Media Gateway Expansion**

| Step | Action  |
|------|---|
|      |   |
| 1    | Install J1 jumper straps on the DMC8 and the DMC8-Es for Card ID.<br><br>For pre Release 23 software strap A B. For post Release 23 software, and Multi-Site Mobility Networking, strap B C.  |
| 2    | Install J2 jumper straps on the DMC8 and the DMC8-Es for system type.<br><br>Strap B C for Option 11C, 11C Mini, Media Gateway, or Media Gateway Expansion. (See <a href="#">page 56</a> for Option 51C to 81C settings.)   |
| 3    | Install J3 jumper straps on the DMC8 and the DMC8-Es for shelf number.<br><br>For the lower TN cabinet, strap B C. For the higher TN cabinet, strap A B.  |
| 4    | Insert DMC8-E(s), if required.<br><br>Place DMC8-E(s) in slot 9, slot 19 or slot 29. See examples in <a href="#">Figure 22</a> , <a href="#">Figure 23</a> , <a href="#">Figure 24</a> , and <a href="#">Figure 25</a> .  |
| 5    | Install J6 to J9 jumper straps on the DMC8 and the DMC8-Es used as the Relay card for either V.24 connection or Ethernet connection.<br><br>For the V.24 connection strap jumpers J6 to J9 to the V24 position. For the Ethernet connection strap jumpers J6 to J9 to the ETH position. |
| 6    | Insert DMC8(s).<br><br>Place DMC8s in the slots as indicated on the work order. Do not place DMC8s in slot 9, slot 19 or slot 29. See examples in <a href="#">Figure 22</a> , <a href="#">Figure 23</a> , <a href="#">Figure 24</a> , and <a href="#">Figure 25</a> .                   |



Figure 23  
Example of a full system housed in two IPE shelves






Figure 24  
Example of a 16 card system housed in two IPE shelves




553-8150.EPS


**Figure 25**  
**Example of a 17 card system housed in two IPE shelves**




**Figure 26**  
**Example of an eight card system housed in one IPE shelf**




**Figure 27**  
**Example of a full Option 11C system not using a CPU cabinet**




**Figure 28**  
**Example of a full Option 11C system using a CPU cabinet**



**Figure 29**  
Example of an eight card system in two Option 11C cabinets



**Figure 30**  
Example of an eight card system in one Option 11C cabinet



## Option 11C Mini

For information on installing circuit cards in an Option 11C Mini, refer to *Option 11C Planning and Installation (553-3021-210)*.

Figure 31

Option 11C Mini main and expander chassis connected with the two NTDK95 and CE-MUX/DS-30SX bus cables





Figure 32


Succession CSE 1000 Media Gateway and Media Gateway Expansion cabling



## Install faceplate cables and inter-shelf/cabinet cable

Consult the work order to determine the position of the faceplate cable layout and NTCW11EA DMC8-E to DMC8-E inter-shelf cables, then perform the steps in [Table 6 on page 71](#).

**Figure 33**  
**NTCW11EA DMC8-E to DMC8-E faceplate cable**



**CAUTION**  
**Service Interruption**

The NTCW11EA DMC8-E to DMC8-E faceplate cable has four sets of movable ferrites. The position of the ferrites on the cable is important. See [Figure 28](#).

Each end of the cable must have a group of 20 ferrites. One quarter of the distance from each end of the cable must have a group of 10 ferrites. The maximum length of the cable is 1.5 meters, limiting the position of DECT shelves 0 and 1 to adjacent IPE modules or small system cabinets.

Consult the work order to determine the position of the terminator plugs, then perform the following steps:

**Table 34**  
**Install faceplate cables and inter-shelf/cabinet cable**

| Step  | Action   |
|---|--|
|   |  |
| 1   | Connect the DMC8 to DMC8 faceplate cables.   |
|   | Arrange the NTCW11AA DMC8 to DMC8 cables so that the DMC8 to DMC8-E cable is connected into the ports shown in <a href="#">Figures 18 to 20</a> .  |
| 2   | If required, connect the NTCW11BA DMC8 to DMC8-E cable on the IPE shelf. Not required on Option 11C.   |
|   | Plug the cable into the lower port of the DMC8 in slot 7. Plug the other end of the cable into the arrow pointing left port of the DMC8-E in slot 8. See <a href="#">Figure 18</a> , <a href="#">Figure 19</a> , and <a href="#">Figure 20</a> . |
| 3   | Connect the NTCW11EA DMC8-E to DMC8-E inter-IPE shelf or inter-cabinet cable, if required.   |
|   | Plug the DMC8-E to DMC8-E cable into each DMC8-E lower port.   |
|  |  |



---

# Install OTM DECT application

---

## Contents

This chapter contains information on the following topics:

|  |    |
|--|----|
| Ensure the DECT application is on the OTM server. . . . .                        | 72 |
| Ensure a Communications Profile is associated with the DECT application. . . . . | 73 |
| Add a Communications Profile for the DECT application. . . . .                   | 75 |
| Add an Ethernet profile. . . . .   | 77 |

## Reference list

The following are the references in this section:


- *Installing and Configuring Optivity Telephony Manager (553-3001-230)*

This Installation Guide assumes that an Optivity Telephony Manager (OTM) server is installed on the PBX.

If the OTM is not installed, follow the instructions in *Installing and Configuring Optivity Telephony Manager (553-3001-230)* to install it.

## Ensure the DECT application is on the OTM server

Figure 35  
Applications to Re-install



Complete the following steps:

Table 1  
Ensure the DECT application is on the OTM server


| Step | Action   |
|------|--|
| 1    | If there is a check in the DECT box in the Applications to Re-install dialog.<br>Go to "Configure the DECT system on the OTM server" on page 79. |
| 2    | If there is no check in the DECT box in the Applications to Re-install dialog.<br><b>Note:</b> Installation is like any other application.       |
|      | Select the check-box and click on the <b>Next</b> button.  |



## Ensure a Communications Profile is associated with the DECT application

The DECT application must be associated with a Communications Profile.

**Figure 36**  
**Systems Properties – Applications**



The following describes the **OK**, **Cancel**, and **Apply** button actions:

- **OK** adds the changes that were made, then returns to the previous screen.
- **Apply** adds the changes and leaves the properties open so that other information can be added to this properties dialog.
- **Cancel** closes the dialog box without adding the changes.

Complete the following steps:

**Table 2**


**Ensure a Communications Profile is associated with the DECT application**

| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             |   |
| <b>1</b>    | Open the Systems Properties sheet.  |
|             | Choose <b>Properties</b> from the OTM Navigator window <b>File</b> menu.  |
| <b>2</b>    | Select the Applications tab.  |
|             | Click on the <b>Applications</b> tab.   |
| <b>3</b>    | If there is a check in the Enabled column next to DECT in the Name column.  |
|             | Go to “Configure the DECT system on the OTM server” on page 79.   |
| <b>4</b>    | If there is no check in the Enabled column next to DECT in the Name column.   |
|             | Highlight <b>DECT</b> in the name column.   |
| <b>5</b>    | Select a Communication Profile.   |
|             | Choose any entry from the <b>Communication Profile</b> drop-down list.<br><b>Note:</b> If there are no entries in the Communication Profile drop-down list, go to “Add a Communications Profile for the DECT application” on page 75. |
| <b>6</b>    | Accept the changes.   |
|             | Click the <b>OK</b> button.   |



## Add a Communications Profile for the DECT application

Figure 37  
Add Communications Profile



Complete the following steps:


**Table 3**  
**Add new Meridian 1 PBX Communications Profile**

| Step | Action  |
|------|---|
|      |   |
| 1    | In the Navigator window, select the Sample Site.  |
|      | Double click on <b>Sample Site</b> .  |
| 2    | Choose the Properties dialog.   |
|      | Click on <b>Properties</b> from the <b>File</b> menu.   |
| 3    | Open the <b>Add Communications Profile</b> dialog.  |
|      | Click on the <b>Communications</b> tap and click <b>Add</b> .   |
| 4    | Select a communications type.   |
|      | Highlight <b>Ethernet</b> in the <b>Type</b> box.<br><b>Note:</b> The DECT application does not use the Communications Profile. Unless there is another application that requires a specific Communications Profile, choosing Ethernet is the least complicated profile to implement. |
| 5    | Program the Profile Name.   |
|      | Enter a <b>Profile Name</b> .   |
| 6    | Accept the changes.   |
|      | Click <b>OK</b> .   |



## Add an Ethernet profile

Figure 38  
System Properties – Communications



Complete the following steps:

**Table 4**  
**Add the Meridian 1 PBX Ethernet profile**

| <b>Step</b> | <b>Action</b>  |
|-------------|--|
|             |  |
| <b>1</b>    | Fill in the communications information for the <b>Ethernet</b> profile.  |
|             | Enter any IP address.<br><b>Note:</b> Unless there is another application that requires a specific IP address, enter a non-existing address. |
| <b>2</b>    | Accept changes.  |
|             | Click <b>Apply</b> .   |
| <b>3</b>    | Return to configuring a communications profile.  |
|             | Go to “Ensure a Communications Profile is associated with the DECT application” on page 73.  |



---

# Configure the DECT system on the OTM server

---


## Contents

This chapter contains information on the following topics:

|   |    |
|---|----|
| Install the DME on the DMC8 Relay card. . . . .                             | 80 |
| Change the DMC8 Relay card default IP address. . . . .                      | 81 |
| Connect the DMC8 Relay card to a configuring PC. . . . .                    | 81 |
| Reset the DMC8 Relay card default IP address to the LAN IP address. . . . . | 84 |
| Connect the DMC8 Relay card to the OTM server. . . . .                      | 86 |
| Launch the DECT application. . . . .  | 88 |
| Add the DECT system. . . . .  | 89 |
| Add General System Properties. . . . .                                      | 89 |
| Set the DECT system IP address to match the DMC8 Relay card. . . . .        | 91 |
| Add the upstream manager IP address, if required. . . . .                   | 93 |
| Synchronize data with the DECT system. . . . .                              | 94 |
| Synchronize DECT PARI and SARI. . . . .                                     | 97 |
| Synchronize DECT parameters. . . . .  | 98 |
| Synchronize DECT Upstream Manager IP address. . . . .                       | 99 |

## Install the DME on the DMC8 Relay card

Figure 39  
NTCW25AA DECT Manager Ethernet (DME) daughterboard location



The NTFZ38AA Ethernet Management Connection package is available, containing the following:

- one NTCW25AA DECT Mobility Ethernet (DME) card
- one NTCW12DA DMC8 I/O cable

**Table 5**  
**Install the DME on the DMC8 Relay card**

| Step | Action  |
|------|---|
|      |   |
| 1    | Unpack the NTCW25AA DECT Manager Ethernet (DME) daughterboard.  |
|      | Remove the packing material.  |
| 2    | Install the DME.  |
|      | Carefully position the daughterboard over the four standoff posts and press onto the DMC8 relay card. |



## Change the DMC8 Relay card default IP address


### Connect the DMC8 Relay card to a configuring PC



**CAUTION: Service interruption**

The DMC8 is shipped with a default IP address 192.168.1.1. The default address must be changed to conform to the network IP address plan.

Figure 40  
NTCW12DA Ethernet cable to configuring PC connections



For information on connecting OTM through a V.24 serial connection, see “Add a V.24 serial connection” on page 135.

**Note:** The configuring PC can be the OTM server or another PC. If the configuring PC is the OTM server, the Captive LAN shown in Figure 40 will be the OTM Server Dedicated LAN shown in [Figure 42 on page 86](#).

Consult the work order to determine the DMC8 Relay card location, then perform the steps in Table 6 on page 83.

*Note:* The Relay card can be any of the DMC 8 or DMC8-E cards. Usually, the lowest-numbered card is used.

**Table 6**  
**Connect the DMC8 Relay card to a configuring PC**


| Step | Action   |
|------|--|
|      |  |
| 1    | Connect the NTCW12DA cable to the connector on the backplane of the DMC8 Relay card.   |
|      | Insert P1 into the DMC8 Relay card backplane connector located on the Meridian 1 PBX shelf/module or the Option 11C cabinet. |
| 2    | If the Configuring PC is on a captive LAN, link the DMC8 Relay card to the Configuring PC.                                   |
|      | Insert P3 into the captive LAN RJ-45 connector.  |
| 3    | If the Configuring PC is on the OTM server dedicated LAN,  |
|      | Insert P3 into the OTM server dedicated LAN RJ-45 connector. See “Connect the DMC8 Relay card to the OTM server” on page 86. |



## Reset the DMC8 Relay card default IP address to the LAN IP address

The DMC8 Relay card default IP address 192.168.1.1 must be changed to conform to the server network IP address plan.

**Figure 41**  
**Telnet 192.168.1.1**



Complete the following steps:


**Table 7**  
**Reset the DMC8 Relay card default IP address to the LAN IP address**

| Step  | Action   |
|---|--|
|   |  |
| 1   | Open the Telnet dialog.  |
|   | Click on Start>Accessories>Telnet.   |
| 2   | Enter user name and password.  |
|   | Type user name <b>dasuser</b> and password <b>dasuser</b> .  |
| 3   | When the connection prompt <b>local</b> appears, change the DMC8 Relay card address.   |
|   | <p>Enter the following command:<br/> <b>ipconfig xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz</b><br/> <b>xxx.xxx.xxx.xxx</b> = new IP address of the DMC8 Relay card.<br/> <b>yyy.yyy.yyy.yyy</b> = subnet mask, usually <b>255.255.255.0</b><br/> <b>zzz.zzz.zzz.zzz</b> = IP address if this is the gateway for the network.</p> <p><b>Note:</b> <b>zzz.zzz.zzz.zzz</b> should be set to the IP address of the OTM server Ethernet interface. If there are two Ethernet interfaces on the OTM server, <b>zzz.zzz.zzz.zzz</b> should be set to the IP address of the interface which is on the same network as the DMC8 Relay card.</p> |
|  |  |

I

## Connect the DMC8 Relay card to the OTM server

Figure 42  
NTCW12DA Ethernet cable to OTM Server LAN connections



Complete the following steps:

**Table 8**  
**Connect the DMC8 Relay card to a Captive LAN**


| Step | Action   |
|------|--|
|      |  |
| 1    | If the DMC8 Relay card was configured on a captive LAN, remove the NTCW12DA Ethernet cable from the captive LAN. |
|      | Disconnect P3 from the captive LAN RJ-45 connector.  |
| 2    | Connect the NTCW12DA cable to the OTM Server Dedicated LAN.  |
|      | Insert P3 into the Dedicated LAN RJ-45 connector.  |



I

## Launch the DECT application

Figure 43  
M1 System Window



Complete the following steps:


Table 9  
Launch the DECT application

| Step | Action   |
|------|--|
| 1    | Launch the DECT application.<br>Double click on the DECT icon. |

## Add the DECT system

### Add General System Properties

Figure 44  
DECT Systems and DECT System Properties



Complete the following steps:


**Table 10**  
**Add the DECT system**

| <b>Step</b> | <b>Action</b>  |
|-------------|--|
|             |  |
| <b>1</b>    | Open the DECT System Properties dialog.                  |
|             | Pull down <b>File&gt;Properties</b> .                    |
| <b>2</b>    | Enter the DECT system name.                              |
|             | Type the system name in the <b>DECT System Name</b> box. |
| <b>3</b>    | Accept the changes.                                      |
|             | Click on the <b>Apply</b> button.                        |



## Set the DECT system IP address to match the DMC8 Relay card

Figure 45  
System Properties – Communication




Complete the following steps:

**Table 11**  
**Set the IP address of the DMC8 Relay card in the manager**

| Step  | Action  |
|---|---|
| 1   | Open the Communications dialog.   |
|   | Click on the <b>Communications</b> tab.   |
| 2   | Enter the IP address.   |
|   | Type the IP address that was entered in <a href="#">Table 7 on page 85</a> .  |
| 3   | If the communication link is Ethernet, select <b>Ethernet</b> .   |
|   | Click on the <b>Ethernet</b> radio button.  |
| 4   | If the communication link is Serial, select <b>Serial</b> .   |
|   | Click on <b>Serial</b> radio button, and go to “Add a V.24 serial connection” on page 135.  |
| 5   | Accept the changes.   |
|   | Click on the <b>OK</b> button.<br><b>Note:</b> When the OK button or Apply button is clicked at this point, the manager attempts to connect to the DECT system to write the MIB2 system name. |
| 6   | If required, program an Upstream Manager.   |
|   | Go to <a href="#">page 93</a> .   |
| 7   | If an Upstream Manager is not required.   |
|   | Go to “Synchronize data with the DECT system” on page 94.   |
|  |   |

## Add the upstream manager IP address, if required

Figure 46  
System Properties – Alarm



Complete the following steps:


**Table 12**  
**Add the upstream IP address, if required**

| <b>Step</b> | <b>Action</b>                           |
|-------------|---|
|             |   |
| <b>1</b>    | Open the DECT System Properties dialog. |
|             | Pull down <b>File&gt;Add</b> .          |
| <b>2</b>    | Open the Alarm dialog.                  |
|             | Click on the <b>Alarm</b> tab.          |
| <b>3</b>    | Enter the IP address.                   |
|             | Type the Upstream manager IP address.   |
| <b>4</b>    | Accept the changes.                     |
|             | Click on the <b>OK</b> button.          |



## Synchronize data with the DECT system

When the DECT manager connects to the DECT system, synchronization occurs. Synchronization compares the database on the manager to the database of the DECT system. Database mismatches are flagged by dialogs. The opportunity to change either the DECT system data or the manager data is given.

**Figure 47**  
**DECT Systems**

Complete the following steps:


**Table 13**  
**Synchronize data with the DECT system**

| <b>Step</b> | <b>Action</b>  |
|-------------|--|
| 1           | If the toolbar icon is <b>red</b> , the connection to the DECT system is enabled. Disconnect from the DECT system. |
|             | Double click on the icon, or use <b>File&gt;Disconnect</b> . Go to “Synchronize DECT PARI and SARI” on page 97.    |
| 2           | If the toolbar icon is <b>green</b> , re-connect to the DECT system  |
|             | Double click on the red icon, or use <b>File&gt;Connect</b> .  |



## Synchronize DECT PARI and SARI

**Figure 48**  
Synchronize DECT PARI and SARI Mismatch dialog



Complete the following step:


**Table 14**  
Synchronize DECT PARI and SARI

| Step | Action  |
|------|---|
| 1    | Store the DECT system PARI SARI parameters in the OTM Manager database. |
|      | Click on the <b>Update DECT Manager</b> button.                         |



## Synchronize DECT parameters

Figure 49  
Synchronize DECT Parameters Mismatch dialog



Complete the following step:

Table 15  
Synchronize DECT Parameters


| Step | Action  |
|------|---|
| 1    | Store the DECT system DECT Parameters in the OTM Manager database.<br>Click on the <b>Update DECT Manager</b> button. |



## Synchronize DECT Upstream Manager IP address

Figure 50

### Synchronize DECT Upstream Manager IP address mismatch dialog



Complete the following step:

Table 16

### Synchronize DECT Upstream Manager IP address

| Step | Action   |
|------|--|
| 1    | Store the DECT system Upstream Manager IP address in the OTM Manager database. |
|      | Click on the <b>Update DECT Manager</b> button.                                |





---

## Un-installing DECT Manager – Caution

---

Before un-installing DECT Manager, read the following information.



**CAUTION: Service interruption**

When the OTM DECT Manager is un-installed, the Sentinel driver is also un-installed, even if other applications require the driver. Any attempt to launch other OTM systems or applications generates the message

**“No dongle attached to the PC.”**

It is necessary to re-install the Sentinel driver. Download the driver from the internet.

Go to **[www.rainbow.com.tech/downloads.html](http://www.rainbow.com.tech/downloads.html)**

In the product drop-down menu, scroll down and select **System Drivers**.

On the System Drivers page, select the **Sentinel System Driver – Driver Only** file and download the zipped file. After download is complete, unzip the file and install the driver.



---

# Configure handsets and retrieve subscription data

---

## Contents

This chapter contains information on the following topics:

|  |     |
|--|-----|
| Configure non-concentrated handsets on a Meridian 1 PBX. . . . . | 105 |
| Open Station Administration window. . . . .                      | 105 |
| Access Add Station dialog. . . . .                               | 106 |
| Add 500 analog standard. . . . .                                 | 107 |
| Access features. . . . .   | 108 |
| Access wireless type. . . . .                                    | 109 |
| Select wireless type. . . . .                                    | 110 |
| Select DECT wireless set. . . . .                                | 111 |
| Accept changes. . . . .  | 112 |
| Configure concentrated handsets on a Meridian 1 PBX. . . . .     | 113 |
| Open Station Administration window. . . . .                      | 113 |
| Access Add Station dialog. . . . .                               | 114 |
| Select Digital Cordless Set. . . . .                             | 115 |
| Select Features. . . . .   | 116 |
| Select wireless type. . . . .                                    | 117 |
| Select Visiting DECT SET or local calling only. . . . .          | 118 |
| Select an index. . . . .   | 120 |
| Provision hardware. . . . .                                      | 121 |
| Accept changes. . . . .  | 122 |
| Select Single Line Features. . . . .                             | 123 |
| Retrieve subscription data for handsets. . . . .                 | 124 |
| Enable subscription. . . . .                                     | 126 |
| Activate the PIN on the handsets. . . . .                        | 127 |

[Handset subscription. . . . .](#) 128

## Reference list

The following are the references in this section:

- *Using Optivity Telephony Manager (553-3001-330)*
- *DECT Programming and Provisioning Record (553-3601-250)*
- *DECT Operation Administration and Maintenance (553-3601-301)*

# Configure non-concentrated handsets on a Meridian 1 PBX

For information about System Administration, see *Using Optivity Telephony Manager* (553-3001-330).

## Open Station Administration window

Figure 51  
M1 System Window





Table 17  
Station Administration window

| Step | Action  |
|------|---|
| 1    | Open the Station Administration window.                         |
|      | Click on <b>Station Administration</b> in the M1 System Window. |



## Access Add Station dialog

Figure 52  
Station Administration window



Complete the following step:


Table 18  
Access Add Station dialog

| Step | Action   |
|------|--|
| 1    | Access Add Station dialog.                                 |
|      | From the <b>Edit</b> pull-down menu, click on <b>Add</b> . |



## Add 500 analog standard

Figure 53  
Add Station dialog



Complete the following step:

Table 19  
Add 500 analog standard

| Step | Action   |
|------|--|
| 1    | Add 500 analog standard.                                     |
|      | Highlight <b>500 Analog Standard</b> , and click <b>OK</b> . |



## Access features

Figure 54  
500 dialog

Complete the following step:


Table 20  
Access features

| Step | Action   |
|------|--|
| 1    | Access the features.<br>Click on the <b>Features</b> button. |



## Access wireless type

Figure 55  
Features dialog



Complete the following step:

Table 21  
Access wireless type

| Step | Action  |
|------|---|
| 1    | Access wireless type.   |
|      | Highlight <b>Wireless Type</b> , and click on the <b>Select</b> button. |



## Select wireless type

Figure 56  
Wireless dialog

The screenshot shows a dialog box titled "Wireless". It contains three dropdown menus:

- Call Party Name Display (CNDA): Denied
- Wireless (WRLS): Yes
- Wireless Type (WTYP): Yes (highlighted)

At the bottom of the dialog are three buttons: OK, Cancel, and Help.

Complete the following step:


Table 22  
Select wireless type

| Step | Action   |
|------|--|
| 1    | Select wireless type.<br>From the <b>Wireless Type (WTYP)</b> pull-down menu select <b>YES</b> . |



## Select DECT wireless set

Figure 57  
Wireless dialog



Complete the following step:


Table 23  
Select DECT wireless set

| Step | Action   |
|------|--|
| 1    | Select DECT handset.   |
|      | From the <b>Wireless Type (WTYP)</b> pull-down menu, click on <b>DECT Wireless Set</b> . Click <b>OK</b> . |



## Accept changes

Figure 58  
Features dialog



Complete the following step:

Table 24  
Accept changes


| Step | Action                           |
|------|----------------------------------|
|      |                                  |
| 1    | Accept changes.                  |
|      | Click on the <b>Done</b> button. |



## Configure concentrated handsets on a Meridian 1 PBX

### Open Station Administration window

Figure 59  
M1 System Window



Complete the following step:


Table 25  
Station Administration window

| Step | Action  |
|------|---|
| 1    | Open the Station Administration window.                                 |
|      | Click on <b>Station Administration</b> in the Meridian 1 System Window. |



## Access Add Station dialog

Figure 60  
Station Administration window



Complete the following step:

Table 26  
Access Add Station dialog

| Step | Action   |
|------|--|
| 1    | Access Add Station dialog.                                 |
|      | From the <b>Edit</b> pull-down menu, click on <b>Add</b> . |



## Select Digital Cordless Set

Figure 61  
Add Station dialog

Table 27  
Select Digital Cordless Set

| Step | Action  |
|------|---|
| 1    | Select Digital Cordless Set.                          |
|      | Highlight <b>DCS</b> . Click on the <b>OK</b> button. |



## Select Features

Figure 62  
DCS dialog

**DCS**

First Name  **Directory**

Last Name  **Clear**

**Single Line Features**

|            |                     |
|------------|---------------------|
| CFW        | Forward             |
| SCU        | SpdCall User        |
| <b>SCC</b> | <b>SpdCall Cntl</b> |
| SSU        | Sys Speed           |
| PHD        | PermanentHld        |

**Set** **Clear**

Speed Call List No.

**Customer** 0

**Location**

**Department**

**Virtual Terminal Number**

**Directory Number**

**CLID Entry**

**Hunt to**

**OK**  
**Cancel**  
**Features**  
**Admin..**  
**Validate**  
**Help**

|   |   |   |
|---|---|---|
| ■ | ■ | ■ |
| ■ | ■ | ■ |
| ■ | ■ | ■ |
| ■ | ■ | ■ |


Table 28  
Select Features

| Step | Action                               |
|------|--------------------------------------|
| 1    | Select the features.                 |
|      | Click on the <b>Features</b> button. |



### Select wireless type

Figure 63  
Features dialog




**Table 29**  
**Select wireless type**

| Step | Action   |
|------|--|
| 1    | Select wireless type.  |
|      | Highlight <b>WTYP</b> , and click on the <b>Select</b> button. |



### Select Visiting DECT SET or local calling only

**Figure 64**  
**Wireless dialog**



**Table 30**  
**Select Visiting DECT Set or local calling only**

| Step | Action   |
|------|--|
|      |  |
| 1    | Select <b>Visiting DECT Set</b> as <b>Yes</b> if the handset is to visit this Meridian 1 PBX. Select <b>No</b> if this handset is to be used for local calling only. |
|      | If <b>Visiting DECT Set</b> is <b>Yes</b> , go to step 2. If this handset is to be used for local calling only, go to step 3.  |
| 2    | Select a Home DN.  |
|      | Enter a DN in the <b>Home Directory Number (HMDN)</b> box.   |
| 3    | If the handset is to be used for local calling only, from the <b>Visiting DECT Set (VSIT)</b> list, select <b>No</b> .   |
|      |  |
| 4    | Accept changes.  |
|      | Click on the <b>OK</b> button.   |



## Select an index

Figure 65  
Features dialog




Table 31  
Select an index

| Step | Action  |
|------|---|
| 1    | Select an index.  |
|      | Highlight <b>INDEX</b> , and click on the <b>Select</b> button. |



## Provision hardware

**Figure 66**  
Hardware Provisioning dialog

**Table 32**  
Provision hardware

| Step | Action  |
|------|---|
| 1    | Select a DMC TN.<br>Enter a TN in the <b>DECT Mobility Controller (DMC)</b> box.  |
| 2    | Select an index.<br>Enter an index in the <b>Index on DMC (INDX)</b> box. (Index range is 0 to 509.)<br><b>Note:</b> The Terminal Number (TN) is a virtual TN and is selected by the Meridian 1 PBX system. |
| 3    | Accept changes.<br>Click the <b>OK</b> button.  |



## Accept changes

Figure 67  
Features dialog




Table 33  
Accept changes

| Step | Action                           |
|------|----------------------------------|
|      |                                  |
| 1    | Accept changes.                  |
|      | Click on the <b>Done</b> button. |



## Select Single Line Features

Figure 68  
500 dialog

Table 34  
Single Line Features


| Step | Action   |
|------|--|
| 1    | For information on other Single Line Features.   |
|      | Refer to the OTM Station Administration in <i>Using Optivity Telephony Manager</i> (553-3001-330). |



**Note:** Complete the *DECT Programming and Provisioning Record* (553-3601-250).

## Retrieve subscription data for handsets

**Figure 69**  
DECT Systems window and Subscriptions window




Complete the following steps:

**Table 35**  
**Subscribe handsets**

| Step  | Action   |
|---|--|
|   |  |
| 1   | Launch the Subscriptions window from the DECT Systems window.  |
|   | Click on the <b>Applications</b> pull-down menu, click on <b>Subscriptions</b> .   |
| 2   | Retrieve the subscription configuration data from the OTM Station Administration database.<br><b>Note:</b> At this point, no handset data appears in the Subscriptions window. |
|   | In the Subscriptions window, click on the <b>Operations</b> pull-down menu, click on <b>Retrieve OTM Configuration</b> .   |
| 3   | Open the Configure DECT Subscription dialog.<br><b>Note:</b> At this point, all handsets configured on OTM Station Administration are shown in the Subscriptions window        |
|   | Click on the <b>File</b> pull-down menu, click on <b>Add</b> or click on  .                   |
|  |  |

## Enable subscription

Figure 70  
Subscriptions window



Complete the following steps for each handset:


Table 36  
Configure handsets

| Step | Action   |
|------|--|
| 1    | <b>Note:</b> At this point, there are no PINs shown in the Subscriptions window. Select a handset from the list.   |
|      | Click on one handset in the list to highlight a row.   |
| 2    | Enable handsets.   |
|      | Click on the <b>Operations</b> pull-down menu, click on <b>Enable</b> or click on  . |



## Activate the PIN on the handsets

**Figure 71**  
Subscriptions window



Complete the following steps:

**Table 37**  
Obtain the PIN

| Step | Action  |
|------|---|
| 1    | <p><b>Note:</b> At this point, in the Subscriptions window, the PINs are shown and the Status is Enabled.</p> <p>Subscribe the DECT handsets.</p> |
|      | See "Handset subscription" on page 128.   |



**Note:** When a handset is subscribed, the Subscription window shows the Status column as Subscribed and does not show a PIN.

## Handset subscription

For detailed information on subscribing a handset, refer to “DECT system administration” in *DECT Operation Administration and Maintenance* (553-3601-301), or the individual handset’s User Guide.

---

# Base Station Power and Muting

---


## Contents

This chapter contains information on the following topics:

|   |     |
|---|-----|
| Open RFP window. . . . .  | 130 |
| Set alarm muting, line power, and comments for base stations. . . . . | 132 |

## Open RFP window

Figure 72  
DECT Systems main window and RFP window




Complete the following steps:

**Table 38**  
**Open RFP window**

| <b>Step</b>   | <b>Action</b>   |
|---|---|
|   |   |
| <b>1</b>  | Launch the DECT Systems window.   |
|   |   |
| <b>2</b>  | Launch the Boards window.   |
|   | On the DECT Systems window, click on the <b>Applications</b> pull-down menu, click on <b>Boards</b> . |
| <b>3</b>  | Select a base station from the list.  |
|   | Click on one RFP in the list to highlight a row.  |
| <b>4</b>  | Open the Radio Fixed Part properties dialog.  |
|   | Click on the <b>File</b> pull-down menu, click on <b>Properties</b> .                                 |
|  |   |

## Set alarm muting, line power, and comments for base stations

Figure 73  
DECT Radio Fixed Parts



Complete the following steps:

**Table 39**

**Set alarm muting, line power, and comments for base stations**

| <b>Step</b> | <b>Action</b>  |
|-------------|--|
|             |  |
| <b>1</b>    | Set alarm muting. Select <b>No</b> to deny alarm muting or <b>Yes</b> to allow alarm muting. |
|             | Click on <b>No</b> or <b>Yes</b> .   |
| <b>2</b>    | Enter up to 80 characters for comments.  |
|             | Type comments.   |
| <b>3</b>    | Select local powered or line powered for the selected base station.                          |
|             | Click the <b>Line Powered</b> or <b>Local Powered</b> radio button.                          |
| <b>4</b>    | Apply the selections.  |
|             | Click the <b>OK</b> button.  |





---

# Add a V.24 serial connection

---

## Contents

This chapter contains information on the following topics:

|  |     |
|--|-----|
| DMC8 to OTM server serial connections .....                        | 136 |
| Serial connection for Windows 2000. ....                           | 137 |
| Connect the Relay card to a local OTM server without a modem. .... | 137 |
| Connect the relay card to a remote OTM server with modems. ....    | 139 |
| Install a virtual modem on the PC. ....                            | 142 |
| Configure modem properties. ....                                   | 144 |
| Set modem speed. ....  | 146 |
| Set connection preferences. ....                                   | 147 |
| Disable flow control. ....   | 149 |
| Configure Remote Access Service (RAS). ....                        | 150 |
| Set RAS modem and port usage. ....                                 | 152 |
| Configure RAS setup and network. ....                              | 153 |
| Configure NetBIOS services. ....                                   | 155 |
| Set up and configure a RAS Phone book entry. ....                  | 157 |
| Open the Dial-up Networking dialog. ....                           | 157 |
| Set up the phone book entry name. ....                             | 158 |
| Set up the server dialog. ....                                     | 160 |
| Go to the next dialog. ....  | 161 |
| Set up complete. ....  | 162 |
| Configure the networking dial-up. ....                             | 163 |
| Configure the Dial using an entry. ....                            | 164 |
| Configure the Dial-up server type. ....                            | 165 |
| Configure IP address. ....   | 166 |
| Accept the configuration changes. ....                             | 167 |

|  |     |
|--|-----|
| Establish the RAS connection. . . . .                  | 168 |
| Establish a connection to the DECT system. . . . .     | 169 |
| Establish connection complete. . . . .                 | 170 |
| Set the IP address through Telnet. . . . .             | 171 |
| Configure the IP address. . . . .                      | 173 |
| Hang-up the RAS connection. . . . .                    | 174 |
| V.24 connection using Windows 2000. . . . .            | 175 |
| Dial-up configuration. . . . .                         | 175 |
| Modem configuration. . . . .                           | 175 |
| Network and dial-up connections configuration. . . . . | 178 |
| DECT Access System configuration. . . . .              | 189 |
| Error messages. . . . .                                | 190 |
| Launch OTM-DECT back-end. . . . .                      | 191 |

## Reference list

The following are the references in this section:

- *System Installation Procedures (553-3001-210)*

## DMC8 to OTM server serial connections

A DMC8 Relay card-to-OTM server serial connection is required if a DME daughterboard is not present on the relay card. There are two types of serial connections:

- when the relay card and OTM server are *local*, and connected *without* a modem
- when the relay card and OTM server are *remote*, and connected *with* a modem



### **CAUTION: Service interruption**

Ensure that the DMC8/DMC8-E Relay card jumpers J6 to J9 are in the V.24 position for operation on a serial connection to the OTM server.


## Serial connection for Windows 2000

For information on how to configure a serial connection using Windows 2000, see “V.24 connection using Windows 2000” on page 175.

### Connect the Relay card to a local OTM server without a modem

Figure 74

DMC8 Relay card connection to a local OTM server without a modem



**Table 40**  
**Connect the Relay card to a local OTM server**

| Step | Action   |
|------|--|
| 1    | Connect the NTCW12AA cable to the DMC8 Relay card MDF connector.                                 |
|      | Refer to <a href="#">Table 41 on page 138</a> for the NTCW12AA cable tip and ring connections.   |
| 2    | Choose the OTM server COM port from the work order.  |
|      | Connect the DB-9 cable connector into the OTM COM port.  |
| 3    | Install the null modem plug.   |
|      | Connect the DB-25 connector end and the NTCW12AA cable end into the AO773252 null modem adapter. |



*Note:* The BIX tip and ring connections shown in [Table 41 on page 138](#) correspond to standard BIX designation. The first pair are labeled T0 and R0. See *System Installation Procedures (553-3001-210)*, section *Planning and Designating the MDF*.

**Table 41**  
**NTCW12AA cable to MDF connections**

| DMC8 Relay card MDF connection | Cable color | DB25 connector pin number | Signal designator |
|--------------------------------|-------------|---------------------------|-------------------|
| T1                             | Grey        | 8                         | V.24DCD           |
| R2                             | Yellow      | 4                         | V.24RTS           |
| T3                             | Blue        | 2                         | V.24TXD           |
| R3                             | Red         | 3                         | V.24RXD           |
| T4                             | Pink        | 7                         | V.24GND           |

## Connect the relay card to a remote OTM server with modems

Figure 75  
DMC8 relay card connection to a remote OTM server




Table 42  
Connect the remote OTM server to a modem (Part 1 of 2)

| Step | Action  |
|------|---|
| 1    | Connect the OTM COM port to the modem.<br>Connect the DB-9 end of the V.24 cable to the OTM COM port. Connect the DB-25 end of the V.24 cable to the modem. |

**Table 42**  
**Connect the remote OTM server to a modem (Part 2 of 2)**

| Step | Action   |
|------|--|
| 2    | Set up the OTM modem.  |
|      | Follow the manufacturers set-up procedures. Set modem as follows: <ul style="list-style-type: none"> <li>• Line speed = 38400b/s</li> <li>• No parity</li> <li>• 1 stop bit</li> <li>• 8 bit words</li> <li>• No output control</li> <li>• No timer</li> </ul> |
| 3    | Connect the modem to the Public Switched Telephone Network.  |
|      | Plug a teledapt cable into the modem RJ-11 jack. Connect the other end of the teledapt cable to the PSTN.  |



**Table 43**  
**Connect the DMC8 Relay card to a modem (Part 1 of 2)**

| Step | Action   |
|------|--|
|      |  |
| 1    | Connect the NTCW12AA cable to the DMC8 Relay card MDF connector.                               |
|      | Refer to <a href="#">Table 41 on page 138</a> for the NTCW12AA cable tip and ring connections. |
| 2    | Set up the OTM modem.  |

**Table 43**  
**Connect the DMC8 Relay card to a modem (Part 2 of 2)**


| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             | Follow the manufacturers set-up procedures. Set modem as follows: <ul style="list-style-type: none"><li>• Line speed = 38400b/s</li><li>• No parity</li><li>• 1 stop bit</li><li>• 8 bit words</li><li>• No output control</li><li>• No timer</li></ul> |
| <b>3</b>    | Connect the NTCW12AA cable to the modem.  |
|             |   |
| <b>4</b>    | Connect the OTM modem to the Public Switched Telephone Network (PSTN).  |
|             | Plug a teledapt cable into the modem RJ11 jack. Connect the other end of the teledapt cable to the PSTN.  |



## Install a virtual modem on the PC

A virtual modem is required for a local serial connection.

Figure 76  
Install New Modem



Complete the following steps:

**Table 44**  
**Install a modem on the PC**


| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             |   |
| <b>1</b>    | Go to Control Panel.  |
|             | Click on <b>Modem</b> .                                       |
| <b>2</b>    | In the Manufacturers field.                                   |
|             | Select [ <b>Standard Modem Types</b> ].                       |
| <b>3</b>    | In the Models field.  |
|             | Select <b>Dial-Up Networking Serial Cable between 2 PCs</b> . |
| <b>4</b>    | Continue.   |
|             | Click on <b>Next</b> .  |



## Configure modem properties

The properties must be configured to interface serially to the DECT system.

**Figure 77**  
**Modem Properties**



Complete the following steps:


**Table 45**  
**Configure modem properties**

| <b>Step</b> | <b>Action</b>                       |
|-------------|-------------------------------------|
|             |                                     |
| <b>1</b>    | Go to Control Panel.                |
|             | Click on <b>Modem</b> .             |
| <b>2</b>    | Select the modem installed.         |
|             | Click on the modem in the list.     |
| <b>3</b>    | Open the properties dialog.         |
|             | Click the <b>Properties</b> button. |



## Set modem speed

**Figure 78**  
Dial-Up Networking Serial Cable between 2 PCs #... General tab



Complete the following steps:


**Table 46**  
Set modem speed

| Step | Action   |
|------|--|
| 1    | Select maximum modem speed.<br>Choose <b>38400</b> . |
| 2    | Apply selection.<br>Click <b>OK</b> .                |



## Set connection preferences

Figure 79  
Dial-Up Networking Serial Cable between 2 PCs #... Connection tab



Complete the following steps:


**Table 47**  
**Set connection preferences**

| <b>Step</b> | <b>Action</b>                        |
|-------------|--------------------------------------|
|             |                                      |
| <b>1</b>    | Set Data bits.                       |
|             | Select <b>8</b> .                    |
| <b>2</b>    | Set Parity.                          |
|             | Select <b>None</b> .                 |
| <b>3</b>    | Set Stop bits                        |
|             | Select <b>1</b> .                    |
| <b>4</b>    | Open Advanced dialog.                |
|             | Click on the <b>Advanced</b> button. |



## Disable flow control

Figure 80  
Advanced Connection Settings



Complete the following step:


Table 48  
Disable flow control

| Step | Action   |
|------|--|
| 1    | Ensure that flow control is disabled.              |
|      | Remove check from the <b>Use flow control</b> box. |



## Configure Remote Access Service (RAS)

Figure 81  
Network – Services



Complete the following steps:


**Table 49**  
**Configure Remote Access Service**

| <b>Step</b> | <b>Action</b>                                    |
|-------------|--|
|             |  |
| <b>1</b>    | Open the Network property dialog.                |
|             | Start> Control Panel> click on the network icon. |
| <b>2</b>    | Select Services.                                 |
|             | Click on Services tab.                           |
| <b>3</b>    | Select the Remote Access Service.                |
|             | Click on <b>Remote Access Service</b> .          |



## Set RAS modem and port usage

**Figure 82**  
Remote Access Setup and Configure Port Usage



Complete the following steps:

**Table 50**  
Set modem and port usage (Part 1 of 2)

| Step | Action   |
|------|--|
| 1    | Select a modem.<br>Highlight a device.                 |
| 2    | Configure.<br>Click on the <b>Configure...</b> button. |


**Table 50**  
**Set modem and port usage (Part 2 of 2)**

| Step | Action  |
|------|---|
| 3    | Select Port Usage.                              |
|      | Click on the <b>Dial out only</b> radio button. |



## Configure RAS setup and network

**Figure 83**  
**Remote Access Setup and Network Configuration**



Complete the following steps:

**Table 51**  
**Configure Remote Access Service**


| <b>Step</b> | <b>Action</b>                           |
|-------------|---|
|             |   |
| <b>1</b>    | Select a modem.                         |
|             | Highlight a device.                     |
| <b>2</b>    | Select Network.                         |
|             | Click on the <b>Network</b> button.     |
| <b>3</b>    | Select TCP/IP protocol for this port.   |
|             | Click a check in the <b>TCP/IP</b> box. |



## Configure NetBIOS services

The NetBIOS Interface Service must be installed. If this is not done, there will be no PPP protocols configured on the RAS ports.

**Figure 84**  
**Network – Services**



Complete the following steps:


**Table 52**  
**Configure Remote Access Service**

| <b>Step</b>   | <b>Action</b>   |
|---|---|
|   |   |
| <b>1</b>  | Ensure that the NetBIOS Interface Service is installed.   |
|   | Double-click on the Control Panel's Network and Dial-up Connections icon. Right-click on the appropriate connection. Click <b>Properties</b> . Click the <b>Services</b> tab.   |
| <b>2</b>  | Observe if the NetBIOS Interface is on the list of Network Services.  |
|   | If the NetBIOS Interface is on the list of Network Services, click <b>Close</b> . Go to "Set up and configure a RAS Phone book entry" on page 157.<br>If the NetBIOS Interface is not on the list of Network Services, click <b>Add</b> .<br>See Figure 84. |
| <b>3</b>  | The Select Network Component appears. Select the required network component.  |
|   | Select <b>Protocol</b> . Click <b>Add</b>   |
| <b>4</b>  | The Select Network Protocol window opens. Select the desired protocol.  |
|   | Select <b>NetBIOS Interface</b> . Click <b>Install</b> . Click <b>Close</b> .   |
|  |   |

## Set up and configure a RAS Phone book entry

### Open the Dial-up Networking dialog

Figure 85  
Dial-up Networking dialog



Complete the following steps:

Table 53  
Open the Dial-up Networking dialog (Part 1 of 2)

| Step | Action   |
|------|--|
| 1    | Open the Dial-up Networking property dialog on Windows NT.       |
|      | <b>Start&gt; Program&gt; Accessories&gt; Dial-up Networking.</b> |


**Table 53**  
**Open the Dial-up Networking dialog (Part 2 of 2)**

| Step | Action                       |
|------|------------------------------|
| 2    | Continue.                    |
|      | Press the <b>New</b> button. |



## Set up the phone book entry name

**Figure 86**  
**New Phonebook Entry Wizard**



Complete the following steps:


**Table 54**  
**Set up the phone book entry name**

| <b>Step</b> | <b>Action</b>                 |
|-------------|-------------------------------|
|             |                               |
| <b>1</b>    | Name the phone book entry.    |
|             | Enter the system name.        |
| <b>2</b>    | Accept the changes.           |
|             | Press the <b>Next</b> button. |



## Set up the server dialog

Figure 87  
Server



Complete the following steps:

Table 55  
Configure Remote Access Service

| Step | Action  |
|------|---|
| 1    | Set up the server dialog.<br>Check the <b>Send my plain text password...</b> box. |
| 2    | Accept the changes.<br>Press the <b>Next</b> button.                              |



## Go to the next dialog

**Figure 88**  
**Phone Number**



Complete the following step:


**Table 56**  
**Go to the next dialog**

| Step | Action                        |
|------|-------------------------------|
| 1    | Omit this dialog.             |
|      | Press the <b>Next</b> button. |



## Set up complete

Figure 89  
New Phonebook Entry Wizard



Complete the following step:


Table 57  
Set up complete

| Step | Action                          |
|------|---------------------------------|
| 1    | Complete the set up.            |
|      | Press the <b>Finish</b> button. |



## Configure the networking dial-up

Figure 90  
Dial-Up Networking



Complete the following steps:


Table 58  
Configure the networking dial-up

| Step | Action  |
|------|---|
| 1    | Open the Dial-up Network property dialog on Windows NT.<br><b>Start&gt; Program&gt; Accessories&gt; Dial-up Networking.</b> |
| 2    | Select edit phone book.<br>Under the <b>More</b> drop-down list, select <b>Edit entry and modem properties.</b>             |



## Configure the Dial using an entry

Figure 91  
Edit Phonebook Entry – Basic



Complete the following step:


Table 59  
Configure the Dial using an entry

| Step | Action  |
|------|---|
| 1    | Configure an entry from the Dial using drop-down list.<br><b>Note:</b> The list shows modems that were previously configured. |
|      | Select an appropriate entry from the Dial using drop-down list.   |
| 2    | Accept the changes.   |
|      | Press the <b>OK</b> button.   |



## Configure the Dial-up server type

**Figure 92**  
**Edit Phonebook Entry – Server**



Complete the following steps:


**Table 60**  
**Configure the Dial-up server type**

| Step | Action   |
|------|--|
| 1    | Configure the Dial-up server type.<br>Select <b>PPP: Windows NT...</b> and check the boxes shown in Figure 92 on page 165. |
| 2    | Open the PPP TCP/IP Settings dialog.<br>Press the <b>TCP/IP</b> settings button.   |



## Configure IP address

Figure 93  
PPP TCP/IP Settings



Complete the following steps:

Table 61  
Configure IP address (Part 1 of 2)

| Step | Action   |
|------|--|
| 1    | Select the settings.<br>Click the <b>Specify an IP address</b> and the <b>Server assigned name server address</b> radio buttons.<br>Click on both check boxes. |


**Table 61**  
**Configure IP address (Part 2 of 2)**

| Step | Action                 |
|------|------------------------|
| 2    | Specify an IP address. |
|      | Enter the IP address.  |



## Accept the configuration changes

**Figure 94**  
**Services**



Complete the following step:


Table 62  
Accept the configuration changes

| Step | Action                            |
|------|-----------------------------------|
| 1    | Accept the configuration changes. |
|      | Press the <b>OK</b> button.       |



## Establish the RAS connection

Figure 95  
Dial-Up Networking



Complete the following steps:


**Table 63**  
**Establish the RAS connection**

| Step | Action  |
|------|---|
| 1    | Open the Dial-up Network property dialog on Windows NT.<br><b>Start&gt; Program&gt; Accessories&gt; Dial-up Networking.</b> |
| 2    | Select the Phonebook entry to dial.<br>Highlight the entry.   |
| 3    | Dial.<br>Press the <b>Dial</b> button.  |



## Establish a connection to the DECT system

**Figure 96**  
**Connect to my DECT system**



Complete the following step:

**Table 64**  
**Establish a connection to the DECT system**

| Step | Action  |
|------|---|
| 1    | Establish access.<br><b>Note:</b> No input to this dialog needed. |
|      | Press the <b>OK</b> button.                                       |



## Establish connection complete

**Figure 97**  
**Connection Complete**



Complete the following step:


**Table 65**  
**Establish connection complete**

| Step | Action                      |
|------|-----------------------------|
| 1    | Finish.                     |
|      | Press the <b>OK</b> button. |



## Set the IP address through Telnet

**Figure 98**  
**Connect**



Complete the following steps:

**Table 66**  
**Set the IP address through Telnet**


| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             |   |
| <b>1</b>    | Open the Dial-up Network property dialog on Windows NT.<br><b>Start&gt; Program&gt; Accessories&gt; Telnet.</b>     |
| <b>2</b>    | Address the DMC8 Relay card using the card's default IP address.<br>Enter 192.168.1.1 in the <b>Host Name:</b> box. |
| <b>3</b>    | Connect to the DMC8 Relay card.<br>Press the <b>Connect</b> button.   |



## Configure the IP address

Figure 99

Telnet 192.168.1.1



```

Telnet - 192.168.1.1
Connect Edit Terminal Help

login: dasuser
password:
local> ipconfig
wrong format..
ipconfig <ipaddress> <subnet>[ <gateway>]

local> ipconfig 192.168.1.25 255.255.255.0 192.168.1.200

```

Complete the following steps:

Table 67


Configure the IP address

| Step | Action   |
|------|--|
| 1    | Login.<br>Enter <b>dasuser</b> .   |
| 2    | Password.<br>Enter <b>dasuser</b> .  |
| 3    | Configure the IP address.<br>Use <b>ipconfig</b> as shown on the bottom line in <a href="#">Figure 99</a> on page 173. |
| 4    | Disconnect the Telnet connection.<br>Click on the close box in the upper right corner.                                 |



## Hang-up the RAS connection

Figure 100  
Dial-Up networking



Complete the following steps:

Table 68  
Hang up the RAS connection

| Step | Action                           |
|------|----------------------------------|
| 1    | Hang up the RAS connection.      |
|      | Click the <b>Hang Up</b> button. |



## V.24 connection using Windows 2000

For the OTM-DECT Manager to communicate with the DECT system remotely over Point-to-Point Protocol (PPP), RAS must be configured for dial-out using the appropriate modem. See “Configure Remote Access Service (RAS)” on page 150.

*Note 1:* The DECT system can also directly communicate over a modem to a remote OTM-DECT Manager.

*Note 2:* The back-end process must be visible to make a connection. See “Launch OTM-DECT back-end” on page 191 for more information. If the back-end is closed in error, OTM-DECT will not operate.

### Dial-up configuration

Configure dial-up on the OTM server using Windows 2000. Perform the following steps:

- 1 Select the **Control Panel > Phone and Modem Options > Modems** tab.
- 2 Click **Add**.
- 3 Click check box **Don't detect my modem....** Click **NEXT**.
- 4 From Manufacturer's List Type list, select **Standard Modem**.
- 5 From Model's list, select **Communications cable between two computers**. Click **Next**.

*Note:* Step 5 is required only if there is no Ethernet connection to the DMC8 card.


- 6 Select a COM port supported by the PC. Click **Next**.
- 7 Click **Finish**.

### Modem configuration

Configure the modem properties for serial interface. To configure the modem, perform the following steps:


- 1 Select **Control Panel > Phone and Modem Options > Modems** tab.
- 2 Select the modem **Communications cable between two computers**. Click **Properties**. See [Figure 101 on page 176](#).

**Figure 101**  
Control Panel > Phone and Modem Options > Modems tab



- 3 In the **Maximum Port Speed** drop-down menu, select **38400**.  
See [Figure 102 on page 177](#).

**Figure 102**  
**Modem tab – Properties button**



- 4 Click the **Advanced** tab.
- 5 Set the **Data** bits to **8**.  
Set the **Parity** bits to **None**.  
Set the **Stop** bits to **1**.
- 6 Click **OK**.

## Network and dial-up connections configuration

*Note:* Ensure that the NetBIOS Interface Service is installed; otherwise PPP is not configured on the RAS ports.

To configure network and dial-up connections, perform the following steps:

- 1 Select **Control Panel > Network and Dial-up Connections**.
- 2 Click the **Make new connection** icon. The Connection Wizard starts. See Figure 103.


Figure 103  
Network Connection Wizard



- 3 Click **Next**.
- 4 Click the **Connect directly to another computer** radio button. Click **Next**. See [Figure 104 on page 179](#).


*Note:* If using a modem connection to the DMC8 card, click the **Dial up to private network** radio button.

**Figure 104**  
**Network Connection Type radio buttons**




- 5 Click the **Guest** radio button. Click **Next**. See [Figure 105 on page 180](#).

Figure 105  
Host or Guest




- 6 From the **Select a Device** drop-down list, select **Communications cable between two computers**. Click **Next**. See [Figure 106 on page 181](#).

**Figure 106**  
**Select a Device**




- 7 Click the **For all users** radio button. Click **Next**. See [Figure 107](#) on page 182.

**Figure 107**  
**Connection Availability**



- 8 Type a name for the connection. Click **Finish**.  
See [Figure 108 on page 183](#).


**Figure 108**  
**Completing the Network Connection Wizard**



A new window appears automatically. The window is titled with the connection name entered earlier. See [Figure 109 on page 184](#).


It is not necessary to enter a user name or password.

**Figure 109**  
**New connection window**




- 9 Click **Properties**. A new window opens.
- 10 Select the **General** tab. Select **Communications cable between two computers (COM2)** from the **Select a device** drop-down menu. See [Figure 110 on page 185](#).

**Figure 110**  
**General tab**




- 11** Click **Configure**. The Modem Configuration window opens. Ensure that the **Maximum speed (bps)** is 38400 bauds. See Figure 111 on page 186. Click **OK**.

**Figure 111**  
**Modem Configuration window**




- 12 Select the **Security** tab. Click the **Security Options – Typical** radio button. Select **Allow unsecured password** from the drop-down menu. Click **OK**. See [Figure 112 on page 187](#).

**Figure 112**  
**Security tab**



- 13** Click the **Networking** tab. Select **Internet Protocol (TCP/IP)**. Click **Properties**.
- 14** Click the radio button for **Use the following IP address**. Enter the IP address of the OTM server.
- 15** Click **Advanced**. Check all three boxes in the PPP Settings window. Click **OK**.
- 16** On the **Networking** tab, click **OK**.
- 17** Click **Connect** in the named dial-up connection window. See [Figure 113 on page 188](#). No password is required.

**Figure 113**  
**Connect to the DMC8**



The screen shown in [Figure 114 on page 188](#) appears.

**Figure 114**  
**Registering on the network**



The screen shown in [Figure 115 on page 189](#) appears when a successful connection has been made.

**Figure 115**  
**Connection complete screen**



- 18 Disconnect the connection by following the on-screen instructions. Close the screen.
- 19 Restart the OTM PC.

## DECT Access System configuration

It is necessary to configure the DECT Access System (DAS). Perform the following steps:

- 1 In OTM-DECT, add a new DAS.
- 2 Select the **Communications** tab.
- 3 Enter the IP address of the DMC8 card.
- 4 Select **Serial** and click **Details**.
- 5 Select the COM port that DAS uses to connect to the PC.
- 6 Enter the IP address of the OTM Server in the **OTM Server IP Interface** field.

*Note:* The IP address of both the DMC8 card and the OTM Server must have the same subnet mask. See Table 69 for an example.


**Table 69**  
**Sample IP addresses with the same subnet mask**

|                       |                 |
|-----------------------|-----------------|
| DMC8 IP address       | 192.168.100.35  |
| OTM Server IP address | 192.168.100.179 |

## Error messages

If the error message (Connection event) shown in [Figure 116 on page 190](#) appears, verify the device manager for COM2 in **Control Panel > System > Hardware > Device Manager > Ports > COM2**.

**Figure 116**  
**Connection event**



## Launch OTM-DECT back-end



### **CAUTION**


Always ensure the Windows Registry is backed up before opening the Registry and its keys.

To launch the OTM-DECT back-end, perform the following steps:

- 1 Open the Windows Registry.  
**Start > Run> regedit**

See Figure 117 on page 192.


**Figure 117**  
**Windows Registry**



- 2 Copy the value of the key  
**HKEY\_LOCAL\_MACHINE\SOFTWARE\NorMat\SMP\OTMServices\DECT\Args**


See Figure 118 on page 193.

**Figure 118**  
**Registry key HKEY-LOCAL\_MACHINE**




- 3 Open a command prompt window. At the command prompt, type **java** *paste copied text here*  
 (At the command prompt, type **java**, press the space bar once, and paste the contents of the clipboard.)  
 See Figure 119 on page 194.

Figure 119  
Command prompt with pasted text



- 4 Press the **Enter** key.  
The OTM-DECT back-end is launched. See Figure 120.

Figure 120  
OTM-DECT back-end is launched



---

# Multi-Site Mobility Networking

---

## Contents

This chapter contains information on the following topics:

|  |     |
|--|-----|
| <a href="#">Feature implementation. ....</a> | 195 |
| <a href="#">Feature operation. ....</a>      | 199 |

## Reference list

The following are the references in this section:

- *DECT Installation Guide (553-3601-203)*

## Feature implementation

The sequence of actions required to configure this feature are as follows:

- 1 Configure a phantom superloop using LD 97, if required.
- 2 Create the new DCS sets in LD 10.
- 3 Configure the RCFW data in LD 57 and LD 15 for handsets assigned as a visitor.
- 4 Use the DECT manager to configure sets on the DMC8.
- 5 Pre-subscribe the visiting handset one time at the MCDN node.

**Note:** Subscription includes both overlay configuration and DECT Manager configuration. For DECT Manager configuration, see *DECT Installation Guide (553-3601-203)*.

LD 10 – Add/Change DCS data block or data blocks. (Part 1 of 2)

| Prompt | Response                     | Description   |
|--------|------------------------------|---|
| REQ:   | NEW, NEW 1-255,<br>CHG, ECHG | <p>NEW = Add a Digital Cordless Set</p> <p>NEW X = The generation of new DCS units stop when the maximum Index of 509 is reached on a single DMC8 or VTNs on the system run out or WRLS ISM limits reached. All new DCS must be on the same DMC8.</p> <p>CHG = Allows the DCS configuration to change to another DMC8. All new DCS must be on the same DMC8.</p> <p>ECHG = This command can change either the VSIT response or the HMDN response.</p> |
| TYPE:  | DCS                          | <p>Digital Cordless Set.</p> <p>Differentiates between analog sets and non-concentrated digital Companion DECT handsets.</p> <p>If TYPE=DCS, the system allocates the next available VTN, and WRLS defaults to YES and WTYP defaults to DECT. If package #350 is included, MWUN defaults to 32.</p> <p>CLS defaults to ERCA, allowing the Enhanced RCFW feature.</p>  |
| TN     | l s c u<br>l u               | TN on an IPE shelf or Option 11C cabinet. The system provides the Virtual TN for the handset.   |
| CDEN   | (4D)                         | Card Density. Only valid value for IPE is 4D. Normal input is <CR>.   |
| WRLS   | YES                          | WiReLess analog Set - entry defaults to YES with no user input - value cannot be CHG'ed.  |
| WTYP   | DECT                         | Wireless TYPE - entry defaults to DECT with no user input - value cannot be CHG'ed.   |
| MWUN   | 32                           | <p>Maximum number of Wireless UNits – entry defaults to 32 with no user input – value cannot be CHG'ed.</p> <p>Note: If MWUN = 32, CDEN automatically changes to 8D, and prints as an 8D unit.</p>  |
| DMC8   | l s c<br>c (Opt.11C)         | <p>Location of the actual DMC8.</p> <p>Assigns a TN to a DECT Mobility Card located on an IPE shelf or Option 11C cabinet.</p>  |

**LD 10** – Add/Change DCS data block or data blocks. (Part 2 of 2)

|      |          |  |
|------|----------|--|
| INDX | 0..509   | DMC8 index to map the Virtual TN to a DMC8 TN.<br>Starting index on DMC8, each unit increments to the next available unit.   |
| VSIT | (NO)/YES | ViSITing DECT set. Determines the difference between a local handset and a visiting handset.<br>VSIT available if the MSMN Package is unrestricted.<br>YES=visiting DECT set. NO=local DECT set. |
| HMDN | X...X    | HoMe Directory Number. Sets the DN as a valid MCDN network DN.<br>NMDN available if VSIT=YES.  |

**LD 10** – Copy DCS data block or data blocks.

| Prompt | Response             | Description   |
|--------|----------------------|---|
| REQ:   | CPY 1 – 32           | CPY n = The generation of new units stop when the following occurs:<br><br>maximum index of 509 is reached on a single DMC8 or VTNs on the system run out or<br><br>WRLS ISM limits reached.<br><br>All DCS must be on the same DMC8. |
| DMC8   | l s c<br>l (Opt 11C) | Location of the actual DMC8 to copy on an IPE shelf or Option 11C cabinet.  |

**LD 10** – Remove DCS data block or data blocks.

| Prompt | Response             | Description   |
|--------|----------------------|---|
| REQ:   | OUT 1-255            | OUT X = Removing units stops when the maximum index of 509 is reached on a single DMC8. All new DCS must be on the same DMC8. |
| DMC8   | l s c<br>l (Opt 11C) | Location of the actual DMC8 to out on an IPE shelf or Option 11C cabinet.   |

**LD 10** – Convert handset type 500 to DCS

| Prompt | Response | Description   |
|--------|----------|---|
| REQ    | CDCS     | Convert Digital Cordless Set – convert from a non-concentrated to a concentrated system after software upgrade. The conversion routine converts the 500 units to DCS units and moves them from the actual TN to a virtual TN. |

*Note:* To convert from concentrated to non-concentrated, OUT all DCS units and re-subscribe the handsets.

The CDCS conversion routine prints each TN as it is moved, in the following format:

**500 TN l s c 00 = DCS TN L' S' C' Index#.**

where: L' S' C' = virtual TN

Index# = default of the unit number of the 500 type set.

**LD 20** – Print actual DMC8 TN and virtual DMC8 TN list.

| Prompt | Response   | Description   |
|--------|--|---|
| REQ    | PRT  | Request.  |
| TYPE   | DCS  | Digital Cordless Set.   |
| TN     | l s c<br>l (Opt 11C)<br>l' s' c' u'<br>l' u' (Opt 11C) | Terminal Number for actual DMC8 card on an IPE shelf or Option 11C cabinet.<br>Virtual Terminal Number on an IPE shelf or Option 11C cabinet. |

The print routine outputs the following format:

**INDEX    Index #    VTN lll s cc uu**

where: Index # = Index number of virtual TN.

lll s cc uu = Virtual TN of unit.

**LD 81** – Print DCS features.

| Prompt | Response  | Description   |
|--------|-----------|---|
| REQ    | LST       | Request.  |
| FEAT   | VSIT      | Feature Request - DECT visitors.  |
| HMDN   | Xx / <cr> | HoMe Directory Number. Specify a single HMDN or print all HMDN on system. |

The LD 81 output format is as follows:

```
DCS  Cust#  Local DN  TN 111 s cc uu  HMDN  Home
DN   Last Activity Date.
```

where:

- Cust# = Customer Number
- Local DN = Local Directory Number of user
- 111 s cc uu = TN of unit
- Home DN = Home directory number of user
- Last Activity Date = Last date of service change activity for user

**LD 83** – Prints DCS terminal numbers with a unit type of DCS instead of 500.

## Feature operation

To activate the MSMN feature, perform the following steps:

- 1 Turn the handset on within the coverage range of a visited Companion DECT system.
- 2 Enter the coverage range of a visited Companion DECT system from another Companion DECT system with the handset turned on.

To deactivate the MSMN feature, perform the following steps:

- 1 turn the handset off within coverage range of the visited Companion DECT system. (The handset must have the DECT Detach feature.)
- 2 turn the handset on at the home Companion DECT system. (Any CFW related to the handset is cancelled.)
- 3 enter the coverage range of the home Companion DECT system with the handset on (Any CFW related to the handset is cancelled.)

---

# Appendix A: Upgrade a DECT system to a SNMP managed system

---

## Contents

This section contains information on the following topics:

|   |     |
|---|-----|
| Backup the DMC4 data with Windows Manager. . . . .                  | 203 |
| Upload OTM supporting firmware to the DMC4 Relay card. . . . .      | 205 |
| Close the Windows Manager. . . . .                                  | 207 |
| Change the DMC4 Relay card default IP address. . . . .              | 208 |
| Connect the DMC4 Relay card to a configuring PC. . . . .            | 208 |
| Reset the DMC4 Relay card to the server IP address. . . . .         | 209 |
| Connect the DMC4 Relay to the OTM server. . . . .                   | 210 |
| Add the DECT system. . . . .  | 213 |
| Add General System Properties. . . . .                              | 213 |
| Set the DECT system IP address to match the DMC4 Relay card. ..     | 215 |
| Synchronize data with the DECT system. . . . .                      | 217 |
| Confirm the active software package on the DMC4 Relay card. . . . . | 219 |
| Activate the firmware on all DMC4s. . . . .                         | 220 |
| Monitor the firmware activation. . . . .                            | 221 |

## Introduction

There are two types of managers for DECT systems:

- Windows Manager
- OTM with DECT application

The Windows Manager, a non-SNMP device, is used to manage the first generation of DECT systems. An OTM with a DECT application manages the present generation of DECT systems.

**Note:** The following terms are used in this appendix:

- The DMC (NTCW00AA) and DMC-E (NTCW01AA) are referred to as DMC4 and DMC4-E
- A DECT system equipped with both DMC4/DMC4-E and DMC8/DMC8-E is referred to as a Mixed DECT system.

An OTM can manage a DMC4/DMC4-E DECT system or a Mixed DECT system.

In a DMC4/DMC4-E DECT system, or a Mixed DECT system managed by an OTM, the DMC's must run SNMP software.


A Mixed DECT system must be managed by an OTM. In a Mixed DECT system, a DMC8/DMC8-E must be the relay card.

In a DMC4/DMC4-E DECT system or a Mixed DECT system managed by an OTM, the DMCs must run 451001xx.dwl software, and the DMC8s/DMC8-Es must run 470001xx.dwl software. If DECT Messaging is used, the DMCs must run 451002xx.dwl software, and the DMC8s/DMC8-Es must run 470002xx.dwl software

Connecting an OTM to a DMC4 Relay card using an Ethernet connection is not supported. Only a V.24 connection can be used.

## Backup the DMC4 data with Windows Manager

Figure 121  
DECT Manager window



Complete the following steps:


**Table 70**  
**Backup the DMC data with Windows Manager**

| <b>Step</b> | <b>Action</b>   |
|-------------|---|
|             |   |
| <b>1</b>    | Launch the Windows Manager program.                     |
|             | Double click on the <b>DECT-Manager</b> icon.           |
| <b>2</b>    | Select the Companion system.                            |
|             | Highlight the system and click on the <b>OK</b> button. |
| <b>3</b>    | Select the Boards tab.                                  |
|             | Place the cursor on the tab and click.                  |
| <b>4</b>    | Select all DMC4s.                                       |
|             | Highlight all addresses.                                |
| <b>5</b>    | Backup the DMC4 data.                                   |
|             | Click on the <b>Backup</b> button.                      |
| <b>6</b>    | Close the connection to the relay card.                 |
|             | From the toolbar, click on the <b>Connect</b> icon.     |



## Upload OTM supporting firmware to the DMC4 Relay card

Figure 122  
DECT Manager window



Complete the following steps:

Table 71


## Upload OTM supporting firmware to the DMC4 Relay card

| Step | Action  |
|------|---|
| 1    | Load the OTM supporting 451001xx.dwl firmware file on the Windows Manager PC.   |
| 2    | Select the Companion system.<br>Highlight the system and click on the <b>OK</b> button.   |
| 3    | Select the Boards tab.<br>Place the cursor on the tab and click.  |
| 4    | Select the Relay DMC4.<br>Highlight the address.  |
| 5    | Upload the 451001xx.dwl firmware file to the Relay DMC.<br>From the <b>Boards</b> pull-down menu, click on <b>Upload firmware</b> . |



## Close the Windows Manager

Figure 123  
Close Program dialog



Complete the following steps:

Table 72  
Close the Windows Manager

| Step | Action   |
|------|--|
| 1    | Open the Close Program dialog.<br>Press the <b>Ctrl + Alt + Delete</b> keys.                     |
| 2    | Disable the Windows Manager.<br>Select <b>DECT Manager</b> and press the <b>End Task</b> button. |



## Change the DMC4 Relay card default IP address


### Connect the DMC4 Relay card to a configuring PC



**CAUTION: Service interruption**

The DMC4 address must be changed to conform to the network IP address plan.

Figure 124  
NTCW12AA cable to configuring PC connections



*Note:* The configuring PC can be the OTM server or another PC. If the configuring PC is the OTM server, the Configuring PC shown in [Figure 124](#) will be the OTM Server shown in [Figure 126](#) on page 211.

**Table 73**  
**Connect the DMC4 relay card to a configuring PC**

| Step | Action  |
|------|---|
| 1    | Connect the NTCW12AA cable to the Configuring PC.   |
|      | Insert the NTCW12AA cable into the A0773252 Null Modem Adaptor and connect to the Configuring PC. |



## Reset the DMC4 Relay card to the server IP address

Change the Relay DMC4 IP address to conform to the server network IP address plan.

**Figure 125**  
**Telnet 192.168.1.**

```

Telnet - 192.168.1.1
Connect Edit Terminal Help

login: dasuser

password:
local> ipconfig
wrong format..
ipconfig <ipaddress> <subnet>[ <gateway>]

local> ipconfig 192.168.1.25 255.255.255.0 192.168.1.200

```

Complete the following steps:

**Table 74**  
**Reset the Relay DMC4 IP address to the LAN IP address**


| Step | Action   |
|------|--|
|      |  |
| 1    | Open the Telnet dialog.  |
|      | Click on Start>Accessories>Telnet.   |
| 2    | Enter user name and password.  |
|      | Type user name <b>dasuser</b> and password <b>dasuser</b> .  |
| 3    | When the connection prompt <b>local</b> appears, change the Relay DMC4 card address.   |
|      | <p>Enter the following command:<br/> <b>ipconfig xxx.xxx.xxx.xxx yyy.yyy.yyy.yyy zzz.zzz.zzz.zzz</b><br/> <b>xxx.xxx.xxx.xxx</b> = new IP address of the Relay DMC4 card.<br/> <b>yyy.yyy.yyy.yyy</b> = subnet mask, usually <b>255.255.255.0</b><br/> <b>zzz.zzz.zzz.zzz</b> = IP address if this is the gateway for the network.</p> <p><b>Note:</b> <b>zzz.zzz.zzz.zzz</b> should be set to the IP address of the OTM server Ethernet interface. If there are two Ethernet interfaces on the OT server, <b>zzz.zzz.zzz.zzz</b> should be set to the IP address of the interface, which is on the same network as the DMC4 Relay card.</p> |



## Connect the DMC4 Relay to the OTM server

Connect the OTM server to a DMC4 Relay card using a V.24 connection. Connecting an OTM to a DMC4 Relay card using an Ethernet connection is not supported.

Figure 126  
OTM Server to DMC4 relay connections (local and remote)



Complete the following step:

**Table 75**  
**Connect the DMC4 Relay to the OTM server**


| <b>Step</b> | <b>Action</b>  |
|-------------|--|
|             |  |
| 1           | Connect the OTM server to the DMC4 Relay card.                       |
|             | Refer to <a href="#">"Add a V.24 serial connection"</a> on page 135. |



## Add the DECT system

### Add General System Properties

Figure 127  
DECT Systems and DECT System Properties



Complete the following steps:


**Table 76**  
**Add the DECT system**

| <b>Step</b> | <b>Action</b>  |
|-------------|--|
|             |  |
| <b>1</b>    | Open the DECT System Properties dialog.                  |
|             | Pull down <b>File&gt;Add</b> .                           |
| <b>2</b>    | Enter the DECT system name.                              |
|             | Type the system name in the <b>DECT System Name</b> box. |
| <b>3</b>    | Accept the changes.                                      |
|             | Click on the <b>Apply</b> button.                        |



## Set the DECT system IP address to match the DMC4 Relay card

Figure 128  
System Properties – Communication



Complete the following steps:

Table 77

Set the IP address of the DMC4 Relay card in the manager


| Step | Action  |
|------|---|
|      |   |
| 1    | Open the Communications dialog.   |
|      | Click on the <b>Communications</b> tab.   |
| 2    | Enter the IP address.   |
|      | Type the IP address that was entered in <a href="#">Table 74 on page 210</a> .  |
| 3    | Select <b>Serial</b> .  |
|      | Click on <b>Serial</b> radio button, and go to “Add a V.24 serial connection” on page 135.  |
| 4    | Accept the changes.   |
|      | Click on the <b>OK</b> button.<br><b>Note:</b> When the OK button or Apply button is clicked at this point, the manager attempts to connect to the DECT system to write the MIB2 system name. |



## Synchronize data with the DECT system

When the DECT manager connects to the DECT system, synchronization occurs. The OTM database can be updated with the DECT system data.

**Figure 129**  
**DECT Systems, and a synchronize dialog**




Complete the following steps:

**Table 78**  
**Synchronize data with the DECT system**

| Step  | Action   |
|---|--|
|   |  |
| 1   | If the toolbar icon is <b>red</b> , indicating the DECT system connection is enabled, disconnect from the DECT system. |
|   | Double click on the icon, or use <b>File&gt;Disconnect</b> . Go to step 3.   |
| 2   | If the toolbar icon is <b>green</b> .  |
|   | Go to step 3.  |
| 3   | Re-connect to the DECT system.   |
|   | Double click on the red icon, or use <b>File&gt;Connect</b> .  |
| 4   | Store the DECT system data in the OTM Manager database.  |
|   | Click on the <b>Update DECT Manager</b> button on all synchronization dialogs.   |
|  |  |

## Confirm the active software package on the DMC4 Relay card

Figure 130  
DMC window and DECT Board properties dialog



Complete the following steps:


Table 79  
Confirm the active software package on the DMC4 Relay card

| Step | Action   |
|------|--|
| 1    | Examine the Active Software Package on the DMC4 relay in the DMC window list.<br>Active Software Package must be 451001xx.dwl firmware, the same one that was loaded on <a href="#">page 205</a> . |
| 2    | Close the DMC window.<br>Click on the close box.   |



## Activate the firmware on all DMC4s

Figure 131  
DECT Systems window



Complete the following step:


**Table 80**  
**Activate the firmware on all DMC4s**

| Step | Action  |
|------|---|
| 1    | Activate the 451001xx.dwl firmware the same as was loaded on <a href="#">page 205</a> to all DMC4s. |
|      | From the <b>Firmware</b> pull-down menu, click on <b>Activate</b> .                                 |



## Monitor the firmware activation

**Figure 132**  
**DMC window**



The screenshot shows a software window titled "DTM - DMC - Sample Site - Sample System - test". It has a menu bar with "File", "View", "Synchronization", and "Help". Below the menu bar are two checked checkboxes: "Show Operational" and "Show Non Operational". A table is displayed with the following columns: "DMC TN", "Type", "Active Software Package", "Relay", "State", "Number of Users", and "Comment". The table contains two rows of data. A red circle highlights the "Active Software Package" column.

| DMC TN  | Type | Active Software Package | Relay | State       | Number of Users | Comment                 |
|---------|------|-------------------------|-------|-------------|-----------------|-------------------------|
| 48 2 06 | DMC  | 45100105                | No    | Operational | 0               | Automatic creation o... |
| 48 2 07 | DMC  | 45100105                | Yes   | Operational | 1               | Automatic creation o... |

Connected

Complete the following step:

**Table 81**  
**Monitor the firmware activation**

| Step | Action  |
|------|---|
|      |   |
| 1    | Examine the Active Software Package on the DMC4 relay card in the DMC window list.                |
|      | Active Software Package must be 451001xx.dwl firmware on all DMCs. See <a href="#">page 205</a> . |





# DECT

## Installation Guide

Copyright © 1997 - 2002 Nortel Networks,  
All Rights Reserved

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. Hereby Nortel Networks declares the Meridian/Succession Companion DECT is in compliance with the essential requirements and other provisions of Directive 1999/5/EC. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manuals, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

Meridian 1, Succession, and Companion are trademarks of Nortel Networks. Windows, Windows NT, Windows 98, Windows 2000, and Internet Explorer are trademarks of Microsoft Corporation. Netscape is a trademark of the Netscape Communications Corporation. Amphenol is a trademark of Amphenol Corporation. Southco is a trademark of Southco, Inc. DECT is a registered trademark of the European Telecommunications Standards Institute.

553-3601-203

Document Release: Standard 6.00

Date: September 2002



Printed in Canada

**NORTEL**  
NETWORKS™