



**GuestWorks<sup>®</sup> and DEFINITY<sup>®</sup> Systems**  
Technician Handbook for Hospitality Installations

555-231-743  
Issue 2  
December 2001  
Compas ID 88500

## Notice

Every effort was made to ensure that the information in this document was complete and accurate at the time of printing. However, information is subject to change.

## Preventing Toll Fraud

“Toll fraud” is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there may be a risk of toll fraud associated with your system and that, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

## Avaya Fraud Intervention

If you suspect that you are being victimized by toll fraud and you need technical assistance or support, in the United States and Canada, call the Technical Service Center's Toll Fraud Intervention Hotline at 1-800-643-2353. For additional support telephone numbers, see the Avaya web site:

<http://www.avaya.com>

Click on Support, click on Escalation Lists US and International. This web site includes phone numbers for escalation within the United States. For escalation phone numbers outside the United States, click on Global Escalation List.

## Providing Telecommunications Security

Telecommunications security (of voice, data, and/or video communications) is the prevention of any type of intrusion to (that is, either unauthorized or malicious access to or use of) your company's telecommunications equipment by some party.

Your company's “telecommunications equipment” includes both this Avaya product and any other voice/data/video equipment that could be accessed via this Avaya product (that is, “networked equipment”).

An “outside party” is anyone who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf. Whereas, a “malicious party” is anyone (including someone who may be otherwise authorized) who accesses your telecommunications equipment with either malicious or mischievous intent.

Such intrusions may be either to/through synchronous (time-multiplexed and/or circuit-based) or asynchronous (character-, message-, or packet-based) equipment or interfaces for reasons of:

- Utilization (of capabilities special to the accessed equipment)
- Theft (such as, of intellectual property, financial assets, or toll-facility access)
- Eavesdropping (privacy invasions to humans)
- Mischief (troubling, but apparently innocuous, tampering)
- Harm (such as harmful tampering, data loss or alteration, regardless of motive or intent)

Be aware that there may be a risk of unauthorized intrusions associated with your system and/or its networked equipment. Also realize that, if such an intrusion should occur, it could result in a variety of losses to your company (including but not limited to, human/data privacy, intellectual property, material assets, financial resources, labor costs, and/or legal costs).

## Your Responsibility for Your Company's Telecommunications Security

The final responsibility for securing both this system and its networked equipment rests with you - an Avaya customer's system administrator, your telecommunications peers, and your managers. Base the fulfillment of your responsibility on acquired knowledge and resources from a variety of sources including but not limited to:

- Installation documents
- System administration documents
- Security documents
- Hardware-/software-based security tools
- Shared information between you and your peers
- Telecommunications security experts

To prevent intrusions to your telecommunications equipment, you and your peers should carefully program and configure:

- your Avaya-provided telecommunications systems and their interfaces
- your Avaya-provided software applications, as well as their underlying hardware/software platforms and interfaces
- any other equipment networked to your Avaya products.

## How to get help

For support phone numbers, see the Avaya web site:

<http://www.avaya.com>

Click on Support, click on Escalation Lists US and International. This web site includes phone numbers for escalation within the United States. For escalation phone numbers outside the United States, click on Global Escalation List.

## Standards Compliance

Avaya Inc. is not responsible for any radio or television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Avaya Inc. The correction of interference caused by such unauthorized modifications, substitution or attachment will be the responsibility of the user. Pursuant to Part 15 of the Federal Communications Commission (FCC) Rules, the user is cautioned that changes or modifications not expressly approved by Avaya Inc. could void the user's authority to operate this equipment.

The equipment described in this manual complies with standards of the following organizations and laws, as applicable:

- Australian Communications Agency (ACA)
- American National Standards Institute (ANSI)
- Canadian Standards Association (CSA)
- Committee for European Electrotechnical Standardization (CENELEC) – European Norms (EN's)
- Digital Private Network Signaling System (DPNSS)
- European Computer Manufacturers Association (ECMA)
- European Telecommunications Standards Institute (ETSI)
- FCC Rules Parts 15 and 68
- International Electrotechnical Commission (IEC)
- International Special Committee on Radio Interference (CISPR)
- International Telecommunications Union - Telephony (ITU-T)
- ISDN PBX Network Specification (IPNS)
- National ISDN-1
- National ISDN-2
- Underwriters Laboratories (UL)

## Product Safety Standards

This product complies with and conforms to the following international Product Safety standards as applicable:

Safety of Information Technology Equipment, IEC 60950, 3rd Edition including all relevant national deviations as listed in Compliance with IEC for Electrical Equipment (IECEE) CB-96A.

Safety of Laser products, equipment classification and requirements:

- IEC 60825-1, 1.1 Edition
- Safety of Information Technology Equipment, CAN/CSA-C22.2 No. 60950-00 / UL 60950, 3rd Edition
- Safety Requirements for Customer Equipment, ACA Technical Standard (TS) 001 - 1997
- One or more of the following Mexican national standards, as applicable: NOM 001 SCFI 1993, NOM SCFI 016 1993, NOM 019 SCFI 1998

## Electromagnetic Compatibility (EMC) Standards

This product complies with and conforms to the following international EMC standards and all relevant national deviations:

Limits and Methods of Measurement of Radio Interference of Information Technology Equipment, CISPR 22:1997 and EN55022:1998.

Information Technology Equipment – Immunity Characteristics – Limits and Methods of Measurement, CISPR 24:1997 and EN55024:1998, including:

- Electrostatic Discharge (ESD) IEC 61000-4-2
- Radiated Immunity IEC 61000-4-3
- Electrical Fast Transient IEC 61000-4-4
- Lightning Effects IEC 61000-4-5
- Conducted Immunity IEC 61000-4-6
- Mains Frequency Magnetic Field IEC 61000-4-8
- Voltage Dips and Variations IEC 61000-4-11
- Powerline Harmonics IEC 61000-3-2
- Voltage Fluctuations and Flicker IEC 61000-3-3

## Federal Communications Commission Statement

### Part 15:

**Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.**

**Part 68: Answer-Supervision Signaling.** Allowing this equipment to be operated in a manner that does not provide proper answer-supervision signaling is in violation of Part 68 rules. This equipment returns answer-supervision signals to the public switched network when:

- answered by the called station,
- answered by the attendant, or
- routed to a recorded announcement that can be administered by the customer premises equipment (CPE) user.

This equipment returns answer-supervision signals on all direct inward dialed (DID) calls forwarded back to the public switched telephone network. Permissible exceptions are:

- A call is unanswered.
- A busy tone is received.
- A reorder tone is received.

Avaya attests that this registered equipment is capable of providing users access to interstate providers of operator services through the use of access codes. Modification of this equipment by call aggregators to block access dialing codes is a violation of the Telephone Operator Consumers Act of 1990.

This equipment complies with Part 68 of the FCC Rules. On the rear of this equipment is a label that contains, among other information, the FCC registration number and ringer equivalence number (REN) for this equipment. If requested, this information must be provided to the telephone company.

The REN is used to determine the quantity of devices which may be connected to the telephone line. Excessive RENs on the telephone line may result in devices not ringing in response to an incoming call. In most, but not all areas, the sum of RENs should not exceed 5.0. To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company.

REN is not required for some types of analog or digital facilities.

## Means of Connection

Connection of this equipment to the telephone network is shown in the following table.

Manufacturer's Port Identifier	FIC Code	SOC/REN/A.S. Code	Network Jacks
Off/On premises station	OL13C	9.0F	RJ2GX, RJ21X, RJ11C
DID trunk	02RV2-T	0.0B	RJ2GX, RJ21X
CO trunk	02GS2	0.3A	RJ21X
CO trunk	02LS2	0.3A	RJ21X
Tie trunk	TL31M	9.0F	RJ2GX
Basic Rate Interface	02IS5	6.0F, 6.0Y	RJ49C
1.544 digital interface	04DU9-BN, 1KN, 1SN	6.0F	RJ48C, RJ48M
120A2 channel service unit	04DU9-DN	6.0Y	RJ48C

If the terminal equipment (for example, the DEFINITY® System equipment) causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this equipment, for repair or warranty information, please contact the Technical Service Center at 1-800-242-2121 or contact your local Avaya representative. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

It is recommended that repairs be performed by Avaya certified technicians.

The equipment cannot be used on public coin phone service provided by the telephone company. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

This equipment, if it uses a telephone receiver, is hearing aid compatible.

### Canadian Department of Communications (DOC) Interference Information

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

### DECLARATIONS OF CONFORMITY

#### United States FCC Part 68 Supplier's Declaration of Conformity (SDoC)

Avaya, Inc. in the United States of America hereby certifies that the equipment described in this document and bearing a TIA TSB-168 label identification number complies with the FCC's Rules and Regulations 47 CFR Part 68, and the Administrative Council on Terminal Attachments (ACTA) adopted technical criteria.

Avaya further asserts that Avaya handset equipped terminal equipment described in this document complies with Paragraph 68.316 of the FCC Rules and Regulations defining Hearing Aid Compatibility and is deemed compatible with hearing aids.

Copies of SDoCs signed by the Responsible Party in the U. S. can be obtained by contacting your local sales representative and are available on the following Web site:

<http://support.avaya.com/elmodocs2/DoC/SDoC/index.jhtml/>

All DEFINITY® system products are compliant with FCC Part 68, but many have been registered with the FCC before the SDoC process was available. A list of all Avaya registered products may be found at:

<http://www.part68.org/>

by conducting a search using "Avaya" as manufacturer.

#### European Union Declarations of Conformity



Avaya Inc. declares that the equipment specified in this document bearing the "CE" (*Conformité Européenne*) mark conforms to the European Union Radio and Telecommunications Terminal Equipment Directive (1999/5/EC), including the Electromagnetic Compatibility Directive (89/336/EEC) and Low Voltage Directive (73/23/EEC). This equipment has been certified to meet CTR3 Basic Rate Interface (BRI) and CTR4 Primary Rate Interface (PRI) and subsets thereof in CTR12 and CTR13, as applicable.

Copies of these Declarations of Conformity (DoCs) signed by the Vice President of DEFINITY® systems research and development, Avaya Inc., can be obtained by contacting your local sales representative and are available on the following Web site:

<http://support.avaya.com/elmodocs2/DoC/IDoC/index.jhtml/>

#### Japan

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective actions.

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

### Network Connections

Digital Connections - The equipment described in this document can be connected to the network digital interfaces throughout the European Union.

Analogue Connections - The equipment described in this document can be connected to the network analogue interfaces throughout the following member states:

Belgium	Germany	Greece	Italy	Luxemburg
Netherlands	Spain	United Kingdom		

### LASER Product

The equipment described in this document may contain Class 1 LASER Device(s) if single-mode fiber-optic cable is connected to a remote expansion port network (EPN). The LASER devices operate within the following parameters:

- Maximum power output -5 dBm to -8 dBm
- Center Wavelength 1310 nm to 1360 nm
- CLASS 1 LASER PRODUCT IEC 60825-1: 1998

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure. Contact your Avaya representative for more laser product information.

### Trademarks

AUDIX, DEFINITY, and GuestWorks are registered trademarks of Avaya.

Comsphere is a registered trademark of Paradyne Corp.

GuideBuilder and INTUITY are trademarks of Avaya.

InnLine 2020 is a trademark of ComTelco (North America), Inc.

Okidata is a registered trademark of OKI Electric Co., LTD.

UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.

Xiox is a trademark of @Comm Corporation.

### To order copies of this and other documents:

Call: Avaya Publications Center  
Voice 1.800.457.1235 or +1.410.568.3680  
FAX 1.800.457.1764 or +1.410.891.0207

Write: Globalware Solutions  
200 Ward Hill Avenue  
Haverhill, MA 01835 USA  
Attention: Avaya Account Management

Email: [totalware@gwsmail.com](mailto:totalware@gwsmail.com)

Order: Document No. 555-231-743  
Issue 2, December 2001

---

# Contents

---

---

<b>About this handbook</b>	<b>xv</b>
■ Suggested training	xv
■ Reasons for reissue	xvi
■ Conventions	xvi
■ Related Documents	xvii
■ Technical support contacts	xx

---

---

<b>Hospitality features</b>	<b>1</b>
-----------------------------	----------

---

---

<b>Installing the system</b>	<b>3</b>
■ Overview	3
■ Installation checklist	4
■ Additional parts and test equipment	5
■ Planning and preparing the site	6
■ Unpacking the equipment	9
■ Installing and connecting the equipment	10
■ Installing telecommunications cabling	10
■ Installing the management terminal	11
Connecting a PC to the switch	11
Parts list	11
Cabling diagram	12
■ Activating the systems	12
■ Setting up the initial options	13

---

---

# Contents

■ Connecting the hospitality adjuncts	18
Overall connectivity not using asynchronous links	20
Overall connectivity using asynchronous links	22
Switch-to-voice messaging admin link (TCP/IP)	25
Parts list	25
Distance limits	26
Cabling diagram	26
Crossover wiring	28
Switch-to-INTUITY admin link (X.25)	29
Parts list	29
Distance limits	30
Cabling diagram	30
Switch-to-INTUITY admin link (Mode Code integration)	31
Switch-to-voice messaging system voice port connections	32
Switch-to-INTUITY voice port connections	32
Parts list	32
Distance limits	33
Cabling diagram	36
Switch-to-InnLine 2020 voice port connections	37
Parts list	37
Distance limits	37
Cabling diagram	38
INTUITY Lodging-to-PMS link	39
Parts list	39
Distance limits	39
Cabling diagram	40
Test procedure	42

---

# Contents

Switch-to-call accounting links	43
Co-resident INTUITY Lodging Call Accounting link using a terminal server	44
Parts list	44
Distance limits	44
Cabling diagram	45
Test procedure	46
Xiox call accounting system link using a terminal server	48
Parts list	48
Distance limits	48
Cabling diagram	49
Test procedure	50
Stand-alone call accounting system link using a terminal server	52
Parts list	52
Distance limits	52
Cabling diagram	53
Test procedure	54
Co-resident INTUITY Lodging Call Accounting link using the DCE port	56
Parts list	56
Distance limits	56
Cabling diagram	57
Test procedure	58
Xiox call accounting system link using the DCE port	60
Parts list	60
Distance limits	60
Cabling diagram	61
Test procedure	62

---

# Contents

Stand-alone call accounting system link using the DCE port	64
Parts list	64
Distance limits	64
Cabling diagram	64
Test procedure	65
Switch-to-call accounting link using DCP data modules	67
Parts list	67
Distance limits	68
Cabling diagram	68
8400B options	69
7400A options	70
7400B options	71
INTUITY Lodging Call Accounting-to-PMS link	72
Parts list	72
Distance limits	72
Cabling diagram	73
Xiox call accounting-to-PMS link	74
Parts list	74
Distance limits	74
Cabling diagram	74
Switch-to-PMS link	75
PMS link using a terminal server	75
Parts list	75
Distance limits	75
Cabling diagram	76
PMS link using a data module	77
Parts list	77
Distance limits	77
Cabling diagram	78
8400B options	79
7400A options	80

---

# Contents

7400B options	81
Test procedure	82
Journal/PMS log or system printer connections	84
Printer connections using a terminal server	85
Parts list	85
Distance limits	86
Cabling diagram	86
Printer connections using a data module	87
Parts list	87
Distance limits	87
Cabling diagram	88
8400B options	89
7400A options	90
7400B options	91
Okidata model ML321T journal/PMS log printer options	92
Okidata model ML321T system printer options	93
Test procedure	95
Printer connection on the INTUITY	97
Parts list	97
Cabling diagram	97
Switch-to-INADS connections	98
Parts list	98
SCC and MCC	98
CMC	98
Cabling diagram	99
INADS registration	100
MAP remote access connections	102
Parts list	102
Cabling diagram	103
INADS alarm origination download	104

---

# Contents

---

<b>Translations and testing</b>	<b>105</b>
■ Translation checklist	106
■ Miscellaneous translations	107
Time of day and date (INTUITY)	108
Dial by Name special application (switch)	109
Dial plan (switch)	110
Dial plan (INTUITY)	111
Feature access codes (switch)	112
Class of service (switch)	115
Class of restriction (switch)	117
Class of service (INTUITY)	124
System parameters (INTUITY)	125
Fax parameters (switch and INTUITY)	127
Billing considerations when forwarding faxes	128
Abbreviated Dialing lists (switch)	129
Listed Directory Numbers (switch)	130
Attendant console (switch)	131
Attendant console button layouts (switch)	132
Attendant Backup (switch)	136
Office staff, front desk, and guest services telephones (switch)	139
Backup telephone button layouts (switch)	142
Mailboxes for AUDIX subscribers (INTUITY)	146
Guest room telephones (switch)	147
Administering analog Caller ID (switch)	150
Administering Caller ID	150
Administering Caller ID station options	151
Suite telephones (switch)	152
Enabling Suite Check-In	153
Administering station hunting	153
Administering Station Hunt Before Coverage	154
Considerations	155

---

# Contents

Mailboxes for guest rooms (INTUITY)	158
Recorded announcements (switch)	159
Emergency Access to Attendant (switch)	163
Crisis Alert (switch)	164
Routing calls	164
Setting system parameters	166
Trunk groups (switch)	168
Assigning DID numbers to guest rooms (switch)	169
Enabling Automatic and Custom Selection of DID Numbers	170
Assigning the DID numbers	171
Assigning DID number feature buttons	172
Considerations	172
Automatic Wakeup options (switch)	174
Call Vectoring (switch)	176
Attendant Vectoring (switch)	178
Dial by Name (switch)	179
Trunk-to-Trunk Transfer (switch)	182
Terminal server for asynchronous links	183
Connecting a PC for administration	183
Administering the terminal server	184
Setting up HyperTerminal on the computer	184
Navigating the terminal server	184
Administering the terminal server the first time	185
Rebooting the terminal server	187
Administering the gateway	188
■ Switch-to-PMS link translations and testing	189
Hospitality parameters	189
Link connectivity administration	193
TCP/IP link administration	193
Administering node names and IP addresses	193
Administering IP services	194
Administering a port on the terminal server	195

---

# Contents

DCP link administration	197
Network Control (Netcon) data module	197
Link data modules	198
Housekeeping status	198
Controlled Restrictions	200
Testing the switch-to-PMS link	201
Switch-to-PMS link testing with the RS232 Mini-Tester	202
Netcon and link data module testing	204
PMS testing and status	205
Database swap testing	207
Check-in and check-out testing	208
Message waiting testing	209
Controlled Restrictions testing	212
Housekeeping status testing	213
■ Switch-to-voice messaging translations and testing	214
Switch-to-voice messaging link	214
TCP/IP signaling	215
TCP/IP link (switch)	215
TCP/IP link (INTUITY)	222
Testing the TCP/IP link	226
X.25 signaling	231
X.25 link (switch)	231
X.25 link (INTUITY)	234
Testing the X.25 link	236
Mode Code Integration	238
Mode Code Integration link (switch)	238
Mode Code Integration (INTUITY)	239
Voice ports (switch)	240
Hunt groups for voice ports (switch)	243
Extensions for guest message retrieval (switch)	245

---

# Contents

Call Coverage path (switch)	246
INTUITY AUDIX voice ports (INTUITY)	247
Services to phone number mapping (INTUITY)	249
Attendant and administrator passwords (INTUITY)	250
Testing the switch-to-INTUITY voice ports	251
■ Voice messaging-to-PMS translations and testing	252
PMS Interface for GuestWorks	253
Stand-alone interface link	255
Testing the INTUITY Lodging-to-PMS link	258
■ Switch-to-call accounting translations and testing	262
Link parameters (INTUITY)	262
CDR parameters (switch)	262
Administering a port on the terminal server	264
Testing the switch-to-call accounting link	266
■ INTUITY Lodging Call Accounting-to-PMS translations and testing	267
■ Printer translations (switch)	268
Administering the printer endpoints	268
Administering a TCP/IP printer connection	271
Administering node names and IP addresses	271
Administering IP services	271
Administering a port on the terminal server	272
Administering the printer connection using data modules	274
Testing the Journal/PMS log or system printer	275
■ Parallel printer translations (INTUITY)	278
■ Customer logins (switch)	278
■ Customer logins (INTUITY)	278
■ Security notification (switch)	279
■ Saving translations (switch)	280
■ Creating a backup (INTUITY)	280

---

# Contents

---

---

<b>Finishing the switch installation</b>	<b>281</b>
■ Testing the switch	281
■ Installing and wiring telephones and other equipment	281
■ Testing telephones and other equipment	282
■ Turning the system over to the customer	282
■ Maintenance	283

---

---

<b>Appendixes</b>	<b>285</b>
■ Appendix A — Parts list	286
■ Appendix B — Connector pinouts	288
■ Appendix C — List PMS down events	289
■ Appendix D — Homisco call record format	292
■ Appendix E — Xiox call accounting format	293

---

---

<b>Index</b>	<b>295</b>
--------------	------------

---

---

## About this handbook

---

This handbook provides instructions for installing Avaya Call Processing switches in a hospitality solution. The procedures in this handbook describe how to connect the switch and adjuncts used in a hospitality solution, and how to administer the switch so it operates with the adjuncts in a hospitality solution. The information provided in this handbook includes information about preparing the site, unpacking and installing the cabinets, connecting cabling and adjuncts, translating the switch and adjuncts, and activating and testing the switch.

The information in this handbook can be used with any of the following switches when the switches are optioned for hospitality services:

- GuestWorks®
- DEFINITY® Enterprise Communications Server (ECS)
- DEFINITY Business Communications System (BCS)

## Suggested training

---

It is suggested that technicians installing this equipment receive training on GuestWorks, DEFINITY, and INTUITY™ systems before installing this equipment. Except for connectivity of hospitality adjuncts and translations of those adjuncts, this handbook contains high-level reminders of the tasks required to install the switch, and is not intended to replace normal switch training or standard switch installation documents.

## Reasons for reissue

---

This document updates the *GuestWorks and DEFINITY ECS Release 9 Technician Handbook for Hospitality Installations* (555-231-741, Issue 1). This document is reissued for the following reasons:

- To update all information related to latest release of Avaya Call Processing software.
- To add information about the new asynchronous links connectivity to adjuncts such as the Property Management System (PMS), call accounting systems, system printers, and administration terminals.

## Conventions

---

The following conventions are used in this handbook:

- In this handbook:
  - the term “switch” refers to the telephone switching equipment (GuestWorks, DEFINITY ECS, or DEFINITY BCS).
  - the term “INTUITY” refers to the voice messaging and call accounting platform.
  - the term “PMS” refers to the Property Management System provided by the customer.
- All screens shown in this handbook are approximations of how the actual screens appear. Depending on the system options, the screens may vary.
- The terms “attendant console” and “backup telephone” are used in this document. The attendant console is the model 302 that is usually found at the front desk. The preferred backup telephone is the model 6424 or 8434 telephone with attendant-type feature buttons. The model 6408 or 8410 can be used as a secondary backup to the model 6424 or 8434.
- For most hospitality installations, the MAP/5P is the voice messaging platform of choice. For very large installations that require more voice ports or message storage, the MAP/40P or MAP/100 may be used. Unless otherwise noted, the term “MAP” refers to any of the different platforms. Any differences between the platforms (other than capacities) will be noted in this handbook.

The Avaya Call Processing switches also work with the InnOvation™ InnLine™ 2020 voice messaging system. Where appropriate, connectivity and translation information to integrate with the InnLine 2020 is provided.

- This handbook documents two versions of the INTUITY system — Release 4.4 (R4.4) and Release 5 (R5) and later. Unless otherwise specified, all connectivity and administration applies to either release.

- Administration command paths and options you enter in the administration fields are shown as follows:

**change system-parameters hospitality**

Some administration command paths have additional actions available (such as **change**, **list**, **add**, and **display**). In this document, only the suggested action is shown in the administration sections.

- Field names referring to the administration screens are shown as follows:

Queue Length

- On the cabling diagrams, the << and >> symbols are used to show the plug-receptacle relationship. If this relationship is not known, the diagrams show a rectangular box.
- Switch hardware is offered on the compact modular cabinet (CMC), the single-carrier cabinet (SCC), or the multi-carrier cabinet (MCC) platforms. Specific cabinet models will not be mentioned except when necessary. Refer to the installation document for the cabinet type you are installing.
- Switch software is packaged for *csi*, *si*, or *r* systems. The *csi* system uses CMC hardware, the *si* system uses SCC or MCC hardware, and the *r* system uses MCC hardware.

## Related Documents

---

The following documents will be useful when installing a hospitality solution. Most of these documents are included on the Documentation Library CDs shipped with the system.

- 555-015-201 — *DEFINITY Terminals and Adjuncts Reference*
- 555-020-706 — *7400A Data Module User Guide*
- 555-020-707 — *7400B Data Module User Guide*
- 555-020-709 — *8400B Plus Data Module User's Guide*
- 555-025-600 — *BCS Products Security Handbook*
- 555-230-700 — *DEFINITY ECS Console Operations*
- 555-230-755 — *GuideBuilder Software for DEFINITY Telephones*
- 555-230-890 — *DEFINITY ECS Console Operations Quick Reference*
- 555-231-205 — *GuestWorks INTUITY Lodging Call Accounting User's Guide*
- 555-231-601 — *GuestWorks and DEFINITY ECS Property Management System Interface Specifications*

- 555-231-744 — *DEFINITY Business Communications System and GuestWorks Call Vectoring Guide*
- 555-233-116 — *DEFINITY ECS Installation for Adjuncts and Peripherals*
- 555-233-117 — *DEFINITY ECS Maintenance for r*
- 555-233-118 — *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*
- 555-233-119 — *DEFINITY ECS Maintenance for csi*
- 555-233-123 — *DEFINITY ECS Maintenance for si*
- 555-233-200 — *DEFINITY ECS System Description*
- 555-233-004 — *DEFINITY ECS What's New for Release 10*
- 555-233-505 — *DEFINITY ECS Reports*
- 555-233-506 — *DEFINITY ECS Administrator's Guide*
- 555-233-705 — *Using the New Abbreviated Dialing Program Feature*
- 555-233-742 — *GuestWorks and DEFINITY ECS Hospitality Operations*
- 555-233-756 — *DEFINITY System's Little Instruction Book for Basic Administration*
- 555-233-757 — *DEFINITY System's Little Instruction Book for Advanced Administration*
- 555-233-758 — *DEFINITY System's Little Instruction Book for Basic Diagnostics*
- 555-233-767 — *DEFINITY Products Overview*
- 555-233-822 — *DEFINITY ECS Release 10 Documentation Library (CD)*
- *DEFINITY Made-Easy Tools* for installation of MCC and SCC, and upgrades for csi, si, and r  
The Made-Easy Tools are found on the documentation CD-ROM.
- 585-310-564 — *INTUITY Messaging Solutions Release 4 Administration*
- 585-310-577 — *INTUITY Lodging Release 4 Administration*
- 585-310-739 — *INTUITY Lodging Artwork Package*
- 585-310-745 — *GuideBuilder Software for AUDIX System*
- 585-313-401 — *INTUITY Messaging Solutions Release 4 Supplement for Technicians*
- 585-313-701 — *INTUITY AUDIX Release 5 Basic Administration Guide*

- 585-313-703 — *INTUITY Messaging Solutions Release 5 Getting Connected*
- 585-313-803 or 585-313-807 — *INTUITY Messaging Solutions Release 5 Documentation (CD)*

This CD includes all Release 5 documents, including hardware installation and maintenance, *INTUITY Lodging Administration and Feature Operations*, *INTUITY Lodging Property Management Specifications*, and *INTUITY Messaging Solutions Release 5 LAN Integration with DEFINITY Systems*.

## Technical support contacts

Use the following telephone numbers and Web sites for technical support. Write in the support numbers for other application vendors.

<p>Avaya Fraud Intervention                  United States and Canada                  Outside of the United States and Canada</p>	<p>1.800.643.2453                  For additional support telephone numbers, see the Avaya web site:  <a href="http://www.avaya.com">http://www.avaya.com</a>                  Click on Support, then click on Escalation Lists US and International. This web site includes telephone numbers for escalation within the United States. For escalation telephone numbers outside the United States, click on Global Escalation List.</p>
<p>Avaya Technical Support                  United States and Canada                  Outside of the United States and Canada</p>	<p>1.800.242.2121                  For additional support telephone numbers, see the Avaya web site:  <a href="http://www.avaya.com">http://www.avaya.com</a>                  Click on Support, then click on Escalation Lists US and International. This web site includes telephone numbers for escalation within the United States. For escalation telephone numbers outside the United States, click on Global Escalation List.</p>
<p>Homisco</p>	<p>+1.781.665.1997  <a href="http://www.homisco.com">http://www.homisco.com</a></p>
<p>Xiox™ (@comm)</p>	<p>+1.603.628.3000                  +1.480.614.3574  <a href="http://www.atcomm.com">http://www.atcomm.com</a>                  support@atcomm.com</p>
<p>InnOvation InnLine 2020</p>	<p>+1.608.798.3555  <a href="http://www.innovationvt.com">http://www.innovationvt.com</a></p>
<p>PMS Vendor</p>	
<p>Call Accounting Vendor</p>	

---

# Hospitality features

---

DEFINITY now has different offer categories for customers. Offer Category A contains all possible DEFINITY features. Offer Category B contains a subset of Offer Category A features used by the GuestWorks and DEFINITY BCS products. The following is an abbreviated list of the hospitality features most likely to be used in your installation:

- Analog Station Caller ID
- Answer Detection
- ASCII Data Over the Switch-to-Property Management System (PMS) Link
- Asynchronous Data Links (R9.5 and later)
- Attendant Backup
- Attendant Split Swap
- Authorization Codes
- Automated Attendant
- Automatic Alternate Routing (AAR)
- Automatic Route Selection (ARS)
- Automatic Selection of DID Numbers
- Attendant-activated Automatic Wakeup Service
- Attendant-activated Do Not Disturb
- Basic Call Management System (BCMS)
- Busy Verification
- Call Vectoring (requires a recorded announcement circuit pack when using Call Vectoring for the Automated Attendant feature)
- Check-in/Check-out
- Controlled Restrictions
- Crisis Alert to attendant console, display station, or digital pager
- Custom Selection of VIP DID Numbers
- Daily Wakeup
- Dial by Name

- Dual Wakeup
- Emergency Access to the Attendant
- Guest-activated Automatic Wakeup (requires a speech synthesizer circuit pack)
- Guest-activated Do Not Disturb (requires a speech synthesizer circuit pack)
- Integrated Services Digital Network (ISDN) access using Primary Rate Interface (PRI) and Basic Rate Interface (BRI) telephones and adjuncts
- Maid Status
- Message Waiting Lamps, either light-emitting diode (LED) or neon, on guest room telephones
- Names Registration
- PMS Interface
- Recorded Announcements
- Room Status
- Station Self-Display
- Suite Check-In
- Switch/INTUITY/PMS Link Integration



**NOTE:**

If your installation is using the Mode Code Integration feature, the Switch/INTUITY/PMS Link Integration feature is not an option.

- Terminal Translation Initialization
- Trunk Identification
- VIP Wakeup
- Wakeup Activation via Tones



**NOTE:**

If Wakeup Activation via Tones is enabled, the wakeup feature provided by a speech synthesizer circuit pack is disabled from service.

- World Class Routing (WCR)

---

# Installing the system

---

This section describes the procedures you must use to install the components of a hospitality solution.

## Overview

---

Before you connect the switch to the hospitality adjuncts (see [“Connecting the hospitality adjuncts” on page 18](#)), you must first install the basic switch equipment and, if purchased, install the voice messaging system. Use the following documents when installing the switch and voice messaging equipment:

- *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*
- *DEFINITY ECS Installation and Test for Single-Carrier Cabinets*
- *DEFINITY ECS Installation and Test for Multi-Carrier Cabinets*
- *DEFINITY ECS Change Description*
- *DEFINITY ECS Installation for Adjuncts and Peripherals*
- *INTUITY Messaging Solutions Release 5 Documentation (CD)*

## Installation checklist

The following is a brief checklist of the information you should read and the tasks you should do to install a hospitality solution. Translation of the switch features and adjuncts begins on [page 105](#). After translations, final testing and customer turnover begins on [page 281](#).

**Table 1. Installation checklist**

✓	Information or procedure
	<a href="#">“Additional parts and test equipment” on page 5</a>
	<a href="#">“Planning and preparing the site” on page 6</a>
	<a href="#">“Unpacking the equipment” on page 9</a>
	<a href="#">“Installing and connecting the equipment” on page 10</a>
	<a href="#">“Installing telecommunications cabling” on page 10</a>
	<a href="#">“Installing the management terminal” on page 11</a>
	<a href="#">“Activating the systems” on page 12</a>
	<a href="#">“Setting up the initial options” on page 13</a>
	<a href="#">“Connecting the hospitality adjuncts” on page 18</a>

## **Additional parts and test equipment**

---

Other than the tools and test equipment noted in the installation manuals, you should also have the following items available on site:

- RS232 mini-tester (comcode 407515139)



**NOTE:**

The mini-tester shows positive voltage with a green LED and negative voltage with a red LED. This can be verified by connecting the mini-tester to a printer's EIA port, adding power to the printer, and then putting the printer on-line. The Data Terminal Ready (DTR) lamp should then light with a positive (green) voltage. You may already have your own mini-tester that shows positive voltage as red and negative voltage as green. If this is true at your installation, the mini-tester result diagrams shown in this handbook must be read from an "opposite" perspective; that is, if the book shows that DTR should be green, and you have a mini-tester that operates in an "opposite" mode, your mini-tester will show DTR being red. This change in perspective should be true for all data leads.



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

- RS232 gender changers and M25A or M25B RS232 cables
- Analog line used to place test calls.

See "[Appendix A — Parts list](#)" on page 286 for a list of the parts used for this installation. Part numbers are provided in case replacements must be ordered.

## Planning and preparing the site

---

See Chapter 1 in the DEFINITY ECS and INTUITY installation documents for more information about the tasks in this section.

1. Inventory the equipment delivered to the customer site and verify that it matches the customer's order. If the equipment does not match the customer's order, follow the appropriate claims process or report the discrepancies to your Avaya representative. If this is a dealer-installed site, report the discrepancies to the dealer.

The equipment may include the following:

- Switch cabinets and circuit packs
- Default translation card for R9.5 and earlier systems (Category B systems only)

Unless instructed otherwise, always use the default translation card for R9.5 and earlier systems.

For R10 and later systems, a license file is provided that defines the customer's purchased options. For more information about License Files, see the *DEFINITY ECS Administrator's Guide*.

- Avaya Site Administration software (provided for the customer's PC), or a 715 management terminal
- Multi-Application Platform (MAP) for INTUITY Lodging Voice Messaging, INTUITY AUDIX Voice Messaging, and INTUITY Lodging Call Accounting

When using the INTUITY Lodging Call Accounting from Homisco, share "[Appendix D — Homisco call record format](#)" on page 292 with the PMS vendor before or during the switch integration.

- InnOvation InnLine 2020 voice messaging systems

Contact your InnOvation representative for installation and setup support.

- Xiox call accounting equipment, which will be software, a buffer box, and a PC

Call Xiox technical support if any issues arise about their call accounting equipment or installation support. See "[Technical support contacts](#)" on page xx.

- Attendant console
- Multiappearance telephones (usually the 6400-series or 8400-series; a 6424 or 8434 is recommended as the primary attendant backup telephone)

- Guest room telephones

If custom room telephones and faceplates are being ordered, coordinate the translations on the switch with any special feature access buttons being programmed by the vendor. If programming is done ahead of time, this could save time at installation.

- Modems

- Printers

The Okidata<sup>®</sup> Models 320, 321, and 184T are often used for hospitality installations, but be aware that other printers may be delivered on site.

- Miscellaneous equipment.

- If the INTUITY Lodging Call Accounting co-resident application from Homisco has been ordered, part of the miscellaneous equipment is a set of adapters, cables, and user documentation used with the INTUITY system. This equipment is packaged in a separate box with the INTUITY equipment and is labeled "Hold for Homisco Technicians - Do Not Discard!" Save this equipment for the Homisco technicians.

2. Locate the equipment room and lay out the equipment room floor plan. If possible, use standard floor plans as described in *DEFINITY ECS System Description*. When laying out the equipment locations, consider the following:

- The switch-to-voice messaging link distance limitations depend on whether you are using Transmission Control Protocol/Internet Protocol (TCP/IP), X.25, or Mode Code:

- The TCP/IP link using the crossover cord is 328 feet (100 meters). This is the default configuration. This is one connectivity method allowed with using the InnLine 2020 system.

- The TCP/IP link using a 10/100base-T auto-sensing hub or router is 656 feet (200 meters). This can be 328 feet (100 meters) on either side of the hub or router. This is one connectivity method allowed with using the InnLine 2020 system.

- The Isolating Data Interface (IDI) X.25 link must be 200 feet (61 meters) or less. This link is used only on an upgraded system if TCP/IP is not used. Duplicated *si* systems must use data modules instead of IDI, so the distance limit is not an issue.
- The Mode Code link is done over the same analog voice ports connected between the switch and the voice messaging adjunct. The analog ports have a distance limit of 20000 feet (6100 meters). This connection is limited to upgraded systems; the default configuration is TCP/IP.
- The link between the switch and the INTUITY Lodging Call Accounting on the MAP is limited to 50 feet (15.2 meters) unless you use DCP data modules to extend the distance. When using a stand-alone call accounting system, there is still the 50 foot (15.2 meter) limit that can be extended with DCP data modules.
- For the call accounting link, the MAP hardware must be within 50 feet (15.2 meters) of the PMS. This distance can be extended using a pair of Digital Communications Protocol (DCP) data modules connected through the switch.

[Figure 2 on page 20](#) and [Figure 3 on page 22](#) illustrate an overall view of connectivity for hospitality solutions.

Additional equipment that you must consider when laying out the floor plan includes the following:

- A customer-provided PC equipped with Avaya Site Administration, or a 715 management terminal
  - Cross-connect fields
  - Space requirements and room layout
  - Cable slack manager.
3. Lay out and ensure appropriate power for the switch and the management terminal in the equipment room, and arrange for an electrician to install.
  4. Lay out and ensure appropriate grounding in the equipment room, including provisions for a coupled bonding conductor (CBC).
  5. Determine the location of equipment closets where feeder cables can be terminated.
  6. Determine where external trunk lines come into the building and where external trunk converters and adapters will be installed.
  7. Determine an appropriate available port circuit on the switch for each telephone, trunk, and peripheral connection needed, and create a provisioning plan based on standard procedures.

8. Have the customer contact the PMS vendor and, if not using the INTUITY Lodging Call Accounting, the call accounting system vendor to find out if there are any special connections required to interface with their equipment. It is highly recommended that the customer schedule the vendors to be on-site when the connections are made and the testing is done for the PMS and the call accounting. If the vendors cannot be on-site, they should at least be available by telephone.
9. If this is an upgrade from an existing system, remind the customer that during the cutover, all Automatic Wakeup requests and Do Not Disturb requests must be noted manually. After the cutover is complete, the customer must manually input these requests.

## Unpacking the equipment

---



### **CAUTION:**

*Lifting and moving the switch cabinets may require two people. The average weight of a CMC is 50 pounds (23 kilograms); an SCC is 125 pounds (60 kilograms); and the MCC is 800 pounds (268 kilograms). Use caution to avoid injury.*

See the appropriate installation document for information about unpacking the equipment:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.
- For installations with an INTUITY system, see Chapter 2 in the INTUITY installation documents.

## **Installing and connecting the equipment**

---

See the appropriate installation document for information about installing and connecting the equipment:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.
- For installations with an INTUITY system, see Chapters 2 through 4 in the INTUITY installation documents.

## **Installing telecommunications cabling**

---

See the appropriate installation document for information about installing telecommunications cabling:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.

## **Installing the management terminal**

---

The management terminal for administration on either the switch or the INTUITY system can be either a customer-provided PC loaded with the Avaya Site Administration software, or a dedicated management terminal, which must be purchased separately. It is the customer's responsibility to set up his or her PC with Avaya Site Administration, but the technicians are responsible for connecting and setting up the 715 management terminal if it was purchased for the system. Use the customer's PC, your own laptop PC, or the management terminal to access the switch for administration during the installation.

See the appropriate installation document for information about installing the management terminal:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.
- For installations with an INTUITY system, see Chapter 4 in the INTUITY installation documents.

The following section shows how to connect a PC to the switch.

### **Connecting a PC to the switch**

---

Use the on-line help for Avaya Site Administration to set the communication options on the PC.

#### **Parts list**

- PC with keyboard and monitor
- One M25A or M25B RS232 cable (or equivalent 25-pin straight-through cable); see ["Appendix A — Parts list" on page 286](#).
- One 9-pin to 25-pin transition cable (if using a 9-pin COM port) (comcode 847106945)
- Gender changers, as needed.

## Cabling diagram




Figure 1. Direct PC connection to the switch

## Activating the systems

See the appropriate installation document for information about activating the switch and the INTUITY system:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.
- For installations with an INTUITY system, see Chapter 4 in the INTUITY installation documents.

Unless instructed otherwise, *always* activate your system using the default translation card for R9.5 and earlier systems. For R10 and later systems, a license file is provided that defines the customer's purchased options. For more information about License Files, see the *DEFINITY ECS Administrator's Guide*.

## Setting up the initial options

---

After activating the systems, there are some initial administration options you must set up. In addition to the procedures given in this section, see the appropriate installation document for information about setting up the initial options:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.
- For installations with an INTUITY system, see Chapter 5 in the INTUITY installation documents.



**NOTE:**

Before setting any options, ensure that the default translation card is being used on a Category B switch for R9.5 and earlier. For R10 and later systems, a license file is provided that defines the customer's purchased options. For more information about License Files, see the *DEFINITY ECS Administrator's Guide*.

To set up the initial options:

1. After the switch powers up, log on to the switch using the `craft` login ID and the `crftpw` password. Distributors should use the `dadmin` login ID.
2. Before you do any administration, verify that you are using the correct translation card for R9.5 and earlier systems. For GuestWorks and DEFINITY BCS, there is a default translation card that is already administered for Offer Category B with certain default options. For all other systems, you will start with a blank card, and all options must be set on site. Check this by using the **display system-parameters offer-options** command.

```
display system-parameters offer-options
```

```
OFFER OPTIONS
```

```
Offer Category: B
```

```
Activate Offer? y
```

```
WARNING: Need to save translations and reboot to make the change permanent
```



**NOTE:**

If the Offer Category is not set correctly and activated, contact the technical support group or your regional Center of Excellence (COE). The switch must be set to the correct Offer Category; the translations must be saved; and the switch must be reset before you can do any translations.

For R10 and later systems, a license file is provided that defines the customer's purchased options. For more information about License Files, see the *DEFINITY ECS Administrator's Guide*.

3. Set the required country options using the **change system-parameters country-options** command.

4. Set the daylight savings time rules using the **change daylight-savings-rules** command.

```
change daylight-savings-rules                                     Page 1 of 2
                        DAYLIGHT SAVINGS RULES

Rule          Change Day          Month Date  Time      Increment

0: No Daylight Savings

1: Start: first Sunday          on or after April    1  at 02:00  01:00
   Stop: first Sunday          on or after October  25 at 02:00

2: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :

3: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :

4: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :

5: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :

6: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :

7: Start: first                 on or after          at  :      :
   Stop: first                 on or after          at  :      :
```

5. Set the date and the time using the **set time** command. This includes applying the daylight savings time rules set up in [Step 4](#).

```
set time                                                         Page 1 of 1
                        DATE AND TIME

DATE

Day of the Week: Saturday          Month: September
Day of the Month: 15              Year: 2001

TIME

Hour: 10 Minute: 32 Second: 33 Type: Daylight Savings

Daylight Savings Rule: 1

WARNING: Changing the date or time will impact BCMS, CDR and MEASUREMENTS
```

- If the switch has EPNs in different time zone locations, use the **change location** command to set the time zone offset, daylight savings rules, and numbering plan area code.

```
change locations                                     Page 1 of 1
                                     LOCATIONS
                                     ARS Prefix 1 Required For 10-Digit NANP Calls? n
Number  Name                Timezone  Daylight-Savings  Number Plan
      Offset  Rule
  1    Main                + 00:00  1                  303
```

- Set the switch maintenance parameters using the **change system-parameters maintenance** command. For csi systems that have a C-LAN (TN799) circuit pack, use Page 2 of this screen to verify that the Bus Bridge Packet Interface 2 has been enabled for the C-LAN circuit pack. If it is not already assigned, enter the C-LAN circuit pack equipment location, and use the defaults for the Timeslot Port fields as shown below.

```
change system-parameters maintenance             Page 2 of 3
                                     MAINTENANCE-RELATED SYSTEM PARAMETERS
MINIMUM MAINTENANCE THRESHOLDS ( Before Notification )
  TTRs: 16      CPTRs: 16      Call Classifier Ports: 16
  MMIs: 0       VCs: 0
TERMINATING TRUNK TRANSMISSION TEST ( Extension )
  Test Type 100:      Test Type 102:      Test Type 105:
ISDN MAINTENANCE
  ISDN-PRI Test Call Extension:      ISDN-BRI Service SPID:
DSL MAINTENANCE
  DS0 Loop-Around Test Call Extension:
SPE OPTIONAL BOARDS
                                     Packet Intf1? y      Packet Intf2? y
  Bus Bridge: 01B07  Inter-Board Link Timeslots  Pt0: 6  Pt1: 1  Pt2: 1
```

8. Verify that the hospitality customer options have been enabled by checking the **display system-parameters customer-options** screen. On Page 3, the following options must be enabled:

- Hospitality (Basic)
- Hospitality (G3V3 Enhancements)

These options can be enabled only with a superuser login ID. Contact technical support or your COE if you do not have permission to make this change.

9. Change the craft password using the **change password craft** command.



**CAUTION:**

*After the craft password is changed, the new password must be safeguarded to prevent unauthorized administration changes. This password **MUST NOT BE REVEALED** to the customer.*

10. Save these initial translations. Use the **save translation** command. Label the translation card with the current date and switch name.



**CAUTION:**

*It is recommended that you save your translations regularly during the installation process. If a power failure occurs, all translations since the last save are lost and must be readministered.*

## Connecting the hospitality adjuncts

---

The hospitality adjuncts include the following:

- INTUITY Lodging Voice Messaging

INTUITY Lodging Voice Messaging is an optional adjunct that resides on the MAP. INTUITY Lodging is used for the guest access to voice messages; and INTUITY AUDIX is used for the office staff to access voice messaging.

- INTUITY Lodging Call Accounting

INTUITY Lodging Call Accounting is a co-resident application from Homisco that resides on the MAP. It is based on a product from the Homisco Corporation. At most installations, you can expect a technician from Homisco to be on site to install the software and hardware for the call accounting portion of the product. The Homisco technician will assist you in making the call accounting system interface to the switch.

For installations that include INTUITY Lodging Voice Messaging and INTUITY Lodging Call Accounting, all connections are shown in complete detail.

- InnOvation InnLine 2020 voice messaging

The InnLine 2020 is a hospitality-industry voice messaging system that integrates with the switch using TCP/IP over a LAN to the C-LAN circuit pack. Installation support is provided by InnOvation.

- Stand-Alone call accounting

Stand-alone call accounting systems (such as Xiox) can be installed if the call record format is compatible with the switch. Two typical formats are *printer* and *Teleser*.

For installations that include voice mail or call accounting from another vendor, the connections are shown up to a definable demarcation point. Connections beyond that demarcation point must be coordinated with the vendor.

- Property Management System (PMS)

The PMS is a vendor-provided product that interfaces to the switch according to the *GuestWorks and DEFINITY ECS Property Management System Interface Specifications*. If the PMS follows those specifications, the PMS will interface to the switch when properly connected to the switch. The PMS connections are shown up to a definable demarcation point. Connections beyond that demarcation point must be coordinated with the vendor.

- Printers

Two serial printers can be installed to print hospitality reports and to keep a log of events as they occur on the switch. Each printer connects to the switch using a terminal server or a DCP data module. The printers are designated as either a “journal/schedule” printer or a “log” printer. The journal/schedule printer records Emergency Access to Attendant calls and Automatic Wakeup calls. The log printer records housekeeping updates when the PMS link is down, in addition to recording any other PMS-related events. These PMS events are shown in [“Appendix C — List PMS down events” on page 289](#).




**NOTE:**

In most cases, only one printer is provided to perform both the journal/schedule and log printer functions.

A parallel printer may be connected to the INTUITY system to run call accounting reports or reports from the INTUITY messaging system.

## Overall connectivity not using asynchronous links

Figure 2 shows the overall connectivity for a hospitality installation when using the MAP for INTUITY Lodging Voice Messaging, INTUITY Lodging Call Accounting, plus connections to a PMS. This diagram does not show any connections using asynchronous links. References to the detailed connectivity drawings are shown in this figure and in Table 2.



\* This link is not used with the Switch/Intuity/PMS Link Integration feature. This link is required when using Mode Code Integration.

gws\_sol2.cdr

**Figure 2. Overall connectivity not using asynchronous links**

**Table 2. Cabling diagrams for connections not using asynchronous links**

From...	To...						
	Switch	Voice Messaging	Voice Ports	INTUITY Lodging Call Accounting	Xiox Call Accounting	Stand-alone Call Accounting	PMS
Switch		Figure 4, Figure 5, Figure 7*, or Figure 10	Figure 10 or Figure 11	Figure 17 or Figure 20	Figure 18 or Figure 20	Figure 19 or Figure 20	Figure 24
Voice Messaging	Figure 4, Figure 5, Figure 7*, or Figure 10						Figure 12 <sup>†</sup> or Figure 13*
INTUITY Lodging Call Accounting	Figure 17 or Figure 20						Figure 21
Xiox Call Accounting	Figure 18 or Figure 20						Figure 22
Stand-alone Call Accounting	Figure 19 or Figure 20						Designed Locally

\* Only the INTUITY Lodging Voice Messaging system can use X.25 connectivity.

† This connection is not required when using the Switch/INTUITY/Link Integration feature.

## Overall connectivity using asynchronous links

Figure 3 shows the overall connectivity for a hospitality installation when using the MAP for INTUITY Lodging Voice Messaging, INTUITY Lodging Call Accounting, plus connections to a PMS. This diagram shows connections using asynchronous links. References to the detailed connectivity drawings are shown in this figure and in Table 3.




Figure 3. Overall connectivity using asynchronous links

**Table 3. Cabling diagrams for connections using asynchronous links**

From...	To...						
	Switch	Voice Messaging	Voice Ports	INTUITY Lodging Call Accounting	Xiox Call Accounting	Stand-alone Call Accounting	PMS
Switch		Figure 4, Figure 5, Figure 7*, or Figure 10	Figure 10 or Figure 11	Figure 14	Figure 15	Figure 16	Figure 23
Voice Messaging	Figure 4, Figure 5, Figure 7*, or Figure 10						Figure 12 <sup>†</sup> or Figure 13*
INTUITY Lodging Call Accounting	Figure 14						Figure 21
Xiox Call Accounting	Figure 15						Figure 22
Stand-alone Call Accounting	Figure 16						Designed Locally

\* Only the INTUITY Lodging Voice Messaging system can use X.25 connectivity.

† This connection is not required when using the Switch/INTUITY/Link Integration feature.

In [Figure 2](#) and in [Figure 3](#), there are a variety of digital line circuit packs and telephones/data modules that can be used. [Table 4](#) shows which circuit packs should be used to support the different digital telephones and data modules.

**Table 4. Digital Line Circuit Packs and Telephone Equipment Compatibility**

Equipment	Circuit Packs			
	TN754 (4-wire)	TN2181 (2-wire)	TN2214 (2-wire)	TN2224 (2-wire)
302D Console (2-wire)	No	Yes	Yes	Yes
302B/C Console (2-wire/4-wire)	Yes	Yes	Yes	Yes
6400-Series telephones (2-wire)	No	Yes	Yes	Yes
8400-Series telephones/data modules (2-wire/4-wire)	Yes	Yes	Yes	Yes
7400-Series telephones/data modules (4-wire)	Yes	No	No	No

## **Switch-to-voice messaging admin link (TCP/IP)**

This data link transfers information to the voice messaging system for office staff voice messaging. For all new installations, this is the recommended way to connect the switch to the voice messaging system for administrative messages. If the system is an upgrade, you may reuse the X.25 hardware for this connection; see [“Switch-to-INTUITY admin link \(X.25\)” on page 29](#). For installations using Mode Code integration, see [“Switch-to-INTUITY admin link \(Mode Code integration\)” on page 31](#).

The TCP/IP link can be used for connections to the INTUITY and InnOvation voice messaging systems.

### **Parts list**

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
UTP Category 5 cross-connect hardware and connecting blocks, or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router (required when using asynchronous links), or  
One 6-inch RJ45 crossover cord (comcode 846943306 or 104154414) for a single 10 Mbps link
- One or two RJ45 UTP Category 5 modular cords (see [“Appendix A — Parts list” on page 286](#))
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- One LAN card on the MAP (for INTUITY R4.4, model 8412; for INTUITY R5 and later, model 8416), or  
One network card on the InnLine 2020 system

## Distance limits

Using the standard crossover cord (or alternate crossover wiring arrangement in [Figure 6](#)), the distance limit between the switch and the voice messaging system is 328 feet (100 meters).

Using a hub or customer router, the distance limit between the switch and a voice messaging system is 656 feet (200 meters) total [328 feet (100 meters) from the switch to the hub or router, and 328 feet (100 meters) from the hub or router to the voice messaging system]. If the distance between the switch and the voice messaging system is more than 656 feet (200 meters), you can daisy-chain up to four separate hubs.




### NOTE:

If you do locate the switch more than 50 feet (15.2 meters) from the MAP and are using the coresident INTUITY Lodging Call Accounting system on the MAP, the call accounting link limit of 50 feet (15.2 meters) must be taken into account. [Figure 20](#) shows how the call accounting link can be extended beyond that limit.

## Cabling diagram

[Figure 4](#) shows a detailed connection between the C-LAN circuit pack and the LAN card on a voice messaging system when using the default crossover cord. Do not use this configuration when you have to install a terminal server for the asynchronous links feature.



lan\_xover.cdr

**Figure 4. Switch-to-voice messaging admin link (TCP/IP) with crossover cord**

Figure 5 shows a detailed connection between the C-LAN circuit pack and the LAN card on a voice messaging system when using a hub or customer router. Use this connection when you have to install a terminal server for the asynchronous links feature.




Figure 5. Switch-to-voice messaging admin link (TCP/IP) with hub or router

The C-LAN circuit pack ethernet lead designations are as follows:


Lead name	25-pair cable wire color	25-pair cable connector pin-out	RJ45 jack pin-out	Terminal block pin-out on connecting block
TD+	white/orange	27	1	3
TD-	orange/white	2	2	4
RD+	white/green	28	3	5
RD-	green/white	3	6	6

Use this information when making connections from the using an IP Media Processor adapter, a 259A adapter, or standard cross-connect wiring.

## Crossover wiring

If the standard crossover cord or the hub/router are not available, you can build your own crossover wiring arrangement to flip the transmit and receive leads for the LAN connection. [Figure 6](#) shows how this can be done with a 104A connecting block (comcode 105164859). When using this device, the distance limit from the switch to the voice messaging system is 328 feet (100 meters) at 10 Mbps. Using this device, you would connect one Category 5 modular cord to the switch C-LAN circuit pack, and another Category 5 modular cord to the voice messaging LAN card.

---



---

**Figure 6. Alternate crossover wiring**

## Switch-to-INTUITY admin link (X.25)

---

This data link transfers information to support the INTUITY AUDIX service for office staff voice messaging. This connection will be used only if:

- Your system has been upgraded from an earlier system, and
- The customer chooses to retain their X.25 hardware (a PI circuit pack is needed on the *si* system, or a Packet Gateway circuit pack is needed on an *r* system) instead of the TCP/IP C-LAN hardware.

See “[Switch-to-voice messaging admin link \(TCP/IP\)](#)” on page 25. For installations using Mode Code integration, see “[Switch-to-INTUITY admin link \(Mode Code integration\)](#)” on page 31.



### NOTE:

The connectivity shown in this section will not work on an *si* system with duplication. For a duplicated system, the connection between the switch and the INTUITY is done with DCP data modules. See your project manager for more information.

## Parts list

- A PI port (TN765) on an *si* system, or a Packet Gateway port (TN577) on an *r* system
- One H600-347 cable (*r* system only)
- One H600-210 Group 3 cable (50 feet; 15.2 meters)
- One 105C IDI (comcode 107422735) or 105D IDI (comcode 108367376)  
An IDI provides electrical isolation and protection between the switch and the INTUITY hardware. The dip switch settings on the IDI must be set for “Direct Connect.”
- One ED1E434-11 Group 175 cable (4.5 feet; 1.5 meters)
- One DCIU card (comcode 406801647, J1P260AA, L31) installed in the MAP, usually located in slot 1.

## Distance limits

The distance limit between the switch and the IDI is 200 feet (61 meters). If you need a cable longer than the default 50 foot (15.2 meter) cable provided, order a Group 4 cable (100 feet; 30.5 meters) or a Group 5 cable (200 feet; 61 meters). See [“Appendix A — Parts list” on page 286](#) for a list of cables.




### NOTE:

If you locate the switch more than 50 feet (15.2 meters) from the MAP and are using the coresident INTUITY Lodging Call Accounting system on the MAP, the call accounting link limit of 50 feet (15.2 meters) must be taken into account. [Figure 20](#) shows how the call accounting link can be extended beyond this limit.

## Cabling diagram

[Figure 7](#) shows a detailed connection between a Processor Interface (PI) switch port (*si* system) or Packet Gateway (PGATE) switch port (*r* system) and the DCIU card on the MAP.



**Figure 7. Switch-to-INTUITY admin link (X.25)**

## Switch-to-INTUITY admin link (Mode Code integration)

---

When using Mode Code Integration, the administrative link between the switch and the voice messaging system (the link that transfers information to support the service for office staff voice messaging) connects by way of an analog port on the switch and a voice port on the voice messaging system. This connection is the same as the voice port connections shown in [“Switch-to-INTUITY voice port connections” on page 32](#) and in [Figure 10](#).

In other words, the voice ports used for leaving and retrieving messages on the voice messaging system are the same voice ports used for Mode Code Integration. This means that the ports will be in use for the amount of time it takes to leave a message, plus the amount of time it takes for the Mode Codes to exchange messages between the switch and voice messaging system. This will affect the traffic-handling of the voice messaging system.

The Mode Code Integration link can be used for connections to the INTUITY and InnOvation voice messaging systems.

Mode Code Integration should not be used if TCP/IP or X.25 link integration is available. See [“Switch-to-voice messaging admin link \(TCP/IP\)” on page 25](#) or [“Switch-to-INTUITY admin link \(X.25\)” on page 29](#) for more information.



### NOTE:

When using Mode Code Integration, you cannot take advantage of the Switch/INTUITY/PMS Link Integration feature. This means that you must install the link shown in [“INTUITY Lodging-to-PMS link” on page 39](#).

Mode Code Integration between the switch and the MAP is described in more detail in the following documents:

- *DEFINITY ECS Administrator's Guide*
- *INTUITY Messaging Solutions Release 4 MAP/5P System Installation*
- *INTUITY Messaging Solutions Integration with System 75, DEFINITY Generics 1 & 3, and R5/6*
- *INTUITY Messaging Solutions Release 5 Documentation (CD)*.

## Switch-to-voice messaging system voice port connections

---

The voice port connections from the switch to the voice messaging system depends on the system you are installing:

- [“Switch-to-INTUITY voice port connections”](#)
- [“Switch-to-InnLine 2020 voice port connections” on page 37](#)

### Switch-to-INTUITY voice port connections

This connection is used for the following:

- For callers leaving messages for guests and office staff
- For guests and office staff to call the INTUITY system to retrieve their voice messages
- For the administrative link between the switch and the MAP when using Mode Code Integration (see [page 31](#)).



**NOTE:**

For voice port connections to the InnLine 2020, consult with the InnLine installation support personnel.

### Parts list

- One or more Tip/Ring cards in the MAP (different cards are required within different regions of the world)
  - IVC6 (AYC-10) Analog Voice Card (comcode 106406580)
  - IVC6A (AYC-29) Tip/Ring Card (comcode 107213944)
  - NGTR (AYC-30) Next Generation Tip/Ring Card (comcode 107224586)

Each Tip/Ring card supports six voice ports. For R5 and later, you can have up to three Tip/Ring cards to support 18 ports for voice messaging. For R4.4, when using the Multi-Port Serial Card, you can have up to two Tip/Ring cards to support 12 ports for voice messaging; when not using the Multi-Port Serial Card, you can have up to three Tip/Ring cards to support 18 ports for voice messaging.

If your system came from the factory configured with more than one tip/ring card, the option settings on the cards should be set correctly. However, if you are adding a card on-site, or if you want to check the card configuration, [Figure 8](#) shows the switch settings for the IVC6 (AYC-10) and IVC6A (AYC-29) cards, and [Figure 9](#) shows the switch settings for the NGTR (AYC-30) card.

For each voice port card, you must install an 885A connector kit. [Figure 10](#) shows connections for one kit using all six voice ports. Depending on the customer's order, you will install voice ports in pairs up to 18 ports.

- Two or more ED5P208-30 Group 16 modular cords  
You need two cords for each Tip/Ring card.
- One 885A connector kit for each Tip/Ring card installed in the MAP (ED-5P907-70, Group 1, comcode 601419666)

These kits come with one 885A connecting block, six RJ11C 4-wire modular cords (comcode 103732582), and two RJ25 6-wire modular cords.



**CAUTION:**

*The two RJ25 6-wire modular cords that come with the 885A connector kits are not used in this application. Do not use the RJ25 cords for any connections; the wiring in the RJ25 cords will not work in this application.*


Use the 885A connecting block label to record the extension numbers of the voice ports connected to the MAP.

- Ferrites (one for each voice line) (comcode 407616846)  
Ferrites are required for installation in some countries. See *INTUITY Messaging Solution Release 4 Supplement for Technicians* for more information.
- 103A modular connecting blocks (one for each voice port) (comcode 105164818)
- Standard cross-connect hardware
- Ports on an analog circuit pack.


Each analog circuit pack supports 8, 16, or 24 analog voice connections. Depending on the circuit pack and the required number of voice ports, you may need to spread out the voice port assignments over more than one circuit pack. For example, if you are using a 16-port circuit pack, use no more than four ports of circuits 1-8 and four ports of circuits 9-16 on that circuit pack. If you still need more INTUITY voice ports, select a circuit pack that is at least one-quarter carrier distance away from the first circuit pack. For example, if your system has 12 voice ports, and you assign the first eight ports to the circuit pack in slot 3, assign the other four voice ports to a circuit pack in slot 7 or higher. See more about circuit pack characteristics in the *DEFINITY ECS System Description*.

### Distance limits

The distance limit from an analog port to the MAP is 20000 feet (6100 meters) using 24 AWG wire.




**Figure 8. IVC6 and IVC6A tip/ring card switch settings**




ngtr KLC 070296

Base I/O address =  
100 Hex.




NGTR T/R 0  
First card installed

Base I/O address =  
200 Hex.




NGTR T/R 1  
Second card installed

Base I/O address =  
300 Hex.




NGTR T/R 2  
Third card installed

Base I/O address =  
500 Hex.




NGTR T/R 3  
Fourth card installed

Base I/O address =  
600 Hex.



NGTR T/R 4  
Fifth card installed

Base I/O address =  
700 Hex.




NGTR T/R 5  
Sixth card installed

Base I/O address =  
900 Hex.



NGTR T/R 6  
Seventh card installed




NGTR T/R 7  
Eighth card installed

swcng4 KLC 110596

**Figure 9. NGTR tip/ring card switch settings**

### Cabling diagram

Figure 10 shows the connections between analog circuit pack ports on the switch and a Tip/Ring card on the MAP.



m5\_791.cdr

Figure 10. Switch-to-INTUITY voice port connections

## Switch-to-InnLine 2020 voice port connections

This connection is used for the following:

- For callers leaving messages for guests and office staff
- For guests and office staff to call the voice messaging system to retrieve their voice messages
- For the administrative link between the switch and the voice messaging system when using Mode Code Integration (see [page 31](#)).

For detailed voice port connections to the InnLine 2020, see the InnLine 2020 Installation guide that is shipped with the system.

### Parts list

- One or more Tip/Ring cards in the InnLine 2020. Each card supports four voice ports. For each voice port, you must use a locally-provided 2-line adapter.
- 103A modular connecting blocks (one for each voice port) (comcode 105164818)
- Standard cross-connect hardware
- Ports on an analog circuit pack.

Each analog circuit pack supports 8, 16, or 24 analog voice connections. Depending on the circuit pack and the required number of voice ports, you may need to spread out the voice port assignments over more than one circuit pack. For example, if you are using a 16-port circuit pack, use no more than four ports of circuits 1-8 and four ports of circuits 9-16 on that circuit pack. If you still need more voice ports, select a circuit pack that is at least one-quarter carrier distance away from the first circuit pack. For example, if your system has 12 voice ports, and you assign the first eight ports to the circuit pack in slot 3, assign the other four voice ports to a circuit pack in slot 7 or higher. See more about circuit pack characteristics in the *DEFINITY ECS System Description*.

### Distance limits

The distance limit from an analog port to the voice messaging system is 20000 feet (6100 meters) using 24 AWG wire.

### Cabling diagram

Figure 11 shows the connections between analog circuit pack ports on the switch and the voice ports on the InnLine 2020.




Figure 11. Switch-to-InnLine 2020 voice port connections

## INTUITY Lodging-to-PMS link

---

This connection is used to activate and deactivate guest voice messaging mailboxes when guests check-in and check-out.



**NOTE:**

If the Switch/INTUITY/PMS Link Integration feature is used, this connection is not required. See [“Voice messaging-to-PMS translations and testing” on page 252](#) for more information about this feature. If Mode Code Integration is used, this link is required and cannot be removed.

### Parts list

- One Multi-Port Serial card on the MAP (comcode 407009406; J1P260AA1, List 12)

For this connection, use the third port on the card. This port is not marked on the card, but is administered in software as port TTYsac.

- One D6AP modular cord (comcode 102937604)
- One Equinox P/N:210068 DTE 10/10 adapter (DB25 DTE, comcode 406983155); see [“Appendix B — Connector pinouts”](#)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)
- One RS232 cable (use gender changers as needed).

### Distance limits

The distance limit from the MAP to the PMS is 50 feet (15.2 meters).

### Cabling diagram

Figure 12 shows the connection used for controlling guest mailboxes between the MAP and the PMS. Use this connection when the MAP has a Multi-Port Serial Card.





Figure 12. INTUITY Lodging-to-PMS link (multi-port serial card)

For some installations, the connection used for controlling guest mailboxes between the MAP and the PMS uses COM1 instead of the Multi-Port Serial Card. [Figure 13](#) shows this connection.



**Figure 13. INTUITY Lodging-to-PMS link (COM1)**

## Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link where the Equinox adapter connects to the null modem as shown in [Figure 12](#). The leads marked with an asterisk are controlled by the INTUITY system, and the PMS controls the other leads. Translations for this connection begin on [page 252](#).



### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the Equinox adapter coming from the MAP, the mini-tester should show the following:

TD* <input checked="" type="radio"/> red	dark <input type="radio"/> RD
RTS* <input type="radio"/> dark	dark <input type="radio"/> CTS
DSR <input type="radio"/> dark	green <input checked="" type="radio"/> DTR*
CD <input type="radio"/> dark	

With the mini-tester connected to only the PMS at the null modem, the mini-tester should show the following:

TD* <input type="radio"/> dark	green <input checked="" type="radio"/> RD
RTS* <input type="radio"/> dark	green <input checked="" type="radio"/> CTS
DSR <input checked="" type="radio"/> green	dark <input type="radio"/> DTR*
CD <input checked="" type="radio"/> green	

With the mini-tester connected to the MAP and the PMS, but in an idle state, the mini-tester should show the following:

TD* <input checked="" type="radio"/> red	green <input checked="" type="radio"/> RD
RTS* <input type="radio"/> dark	green <input checked="" type="radio"/> CTS
DSR <input checked="" type="radio"/> green	green <input checked="" type="radio"/> DTR*
CD <input checked="" type="radio"/> green	

## **Switch-to-call accounting links**

---

The switch-to-call accounting link can be configured several different ways depending on the ports used at the switch and the type of call accounting system. This section describes the following call accounting configurations:

- [“Co-resident INTUITY Lodging Call Accounting link using a terminal server” on page 44](#)
- [“Xiox call accounting system link using a terminal server” on page 48](#)
- [“Stand-alone call accounting system link using a terminal server” on page 52](#)
- [“Co-resident INTUITY Lodging Call Accounting link using the DCE port” on page 56](#)
- [“Xiox call accounting system link using the DCE port” on page 60](#)
- [“Stand-alone call accounting system link using the DCE port” on page 64](#)
- [“Switch-to-call accounting link using DCP data modules” on page 67](#)

## Co-resident INTUITY Lodging Call Accounting link using a terminal server

This connection is used to transfer Call Detail Recording (CDR) information to the co-resident INTUITY Lodging Call Accounting software (Homisco), and is valid for any system.

### Parts list

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router
- One or two RJ45 UTP Category 5 modular cords (see [“Appendix A — Parts list” on page 286](#))
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- Terminal server (comcode 700015084)
- RJ45-to-DB25 cable (part of comcode 700015084)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)
- One Equinox P/N:210068 DTE 10/10 adapter (DB25 DTE, comcode 406983155); see [“Appendix B — Connector pinouts”](#)
- One D6AP modular cord (comcode 102937604)
- One Multi-Port Serial card on the MAP (comcode 407009406; J1P260AA1, List 12).

For this connection, use the first port on the card. This port is not marked on the card, but is administered in software as port TTYsaa.

### Distance limits

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). The distance from the terminal server to the MAP is 50 feet (15.2 meters).

### Cabling diagram

Figure 14 shows the connection used to transfer CDR information between the switch and the MAP using a terminal server.




Figure 14. Co-resident INTUITY Lodging Call Accounting link using a terminal server

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link where the Equinox adapter connects to the null modem as shown in [Figure 14](#). The leads marked with an asterisk are controlled by the switch, and the INTUITY Lodging Call Accounting system controls the other leads. Translations for this connection begin on [page 262](#).



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the null modem on the terminal server port, the mini-tester should show the following:

TD	<input type="radio"/>	dark			
			red	<input checked="" type="radio"/>	RD*
RTS	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	CTS*
DSR*	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	DTR
CD*	<input checked="" type="radio"/>	green			

With the mini-tester connected to only the Equinox adapter, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red			
			dark	<input type="radio"/>	RD*
RTS	<input type="radio"/>	dark			
			dark	<input type="radio"/>	CTS*
DSR*	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	DTR
CD*	<input checked="" type="radio"/>	red			

With the mini-tester connected to the terminal server port and the Equinox adapter, the mini-tester should show the following (if any of the switch leads are dark on an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	red ● RD*
RTS ○ dark	green ● CTS*
DSR* ● green	green ● DTR
CD* ● green	

Another way to test this connection is to connect a dumb terminal to the terminal server port, make some test calls, and look for call records being displayed on the terminal.

## **Xiox call accounting system link using a terminal server**

This connection is used to transfer CDR information to the Xiox call accounting system. This connection is valid for any system.

### **Parts list**

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router
- One or two RJ45 UTP Category 5 modular cords (see [“Appendix A — Parts list” on page 286](#))
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- Terminal server (comcode 700015084)
- RJ45-to-DB25 cable (part of comcode 700015084)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)
- Xiox Intelligent Buffer unit (includes AC power adapter and cable for connecting to the Xiox call accounting PC)
- Xiox call accounting PC

### **Distance limits**

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). The distance from the terminal server to the Xiox call accounting PC is 50 feet (15.2 meters).

### Cabling diagram

Figure 15 shows the connection between a terminal server port and a Xiox call accounting system.




Figure 15. Xiox call accounting system link using a terminal server

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link at the point where the null modem connects to the Xiox Intelligent Buffer as shown in [Figure 15](#). The leads marked with an asterisk are controlled by the switch, and the call accounting system controls the other leads. Translations for this connection begin on [page 262](#).



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the null modem from the terminal server port, the mini-tester should show the following:

TD	<input type="radio"/>	dark			
			red	<input checked="" type="radio"/>	RD*
RTS	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	CTS*
DSR*	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	DTR
CD*	<input checked="" type="radio"/>	green			

With the mini-tester connected to only the PBX port on the Xiox Intelligent Buffer, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red			
			dark	<input type="radio"/>	RD*
RTS	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	CTS*
DSR*	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	DTR
CD*	<input type="radio"/>	dark			

With the mini-tester connected to the switch and the PBX port on the Xiox Intelligent Buffer, the mini-tester should show the following (if any of the switch leads are dark in an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	
RTS ● green	red ● RD*
DSR* ● green	green ● CTS*
CD* ● green	green ● DTR

Another way to test this connection is to connect a dumb terminal to the terminal server port on the switch, make some test calls, and look for call records being displayed on the terminal.

## **Stand-alone call accounting system link using a terminal server**

This connection is used to transfer CDR information to a stand-alone call accounting system. This connection is valid for any system.

### **Parts list**

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router
- One or two RJ45 UTP Category 5 modular cords (see [“Appendix A — Parts list” on page 286](#))
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- Terminal server (comcode 700015084)
- RJ45-to-DB25 cable (part of comcode 700015084)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)

### **Distance limits**

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). The distance from the hub to the stand-alone call accounting system is 50 feet (15.2 meters).

### Cabling diagram

Figure 16 shows the connection between the terminal server port and a stand-alone call accounting system.




Figure 16. Stand-alone call accounting system link using a terminal server

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link at the demarcation point as shown in [Figure 16](#). The leads marked with an asterisk are controlled by the switch, and the call accounting system controls the other leads. Translations for this connection begin on [page 262](#).



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the null modem on the terminal server port from the switch, the mini-tester should show the following:

TD	<input type="radio"/>	dark			
			red	<input checked="" type="radio"/>	RD*
RTS	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	CTS*
DSR*	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	DTR
CD*	<input checked="" type="radio"/>	green			

With the mini-tester connected to only the interface port on the stand-alone call accounting system, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red			
			dark	<input type="radio"/>	RD*
RTS	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	CTS*
DSR*	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	DTR
CD*	<input type="radio"/>	dark			

With the mini-tester connected to the switch and the stand-alone call accounting system, the mini-tester should show the following (if any of the switch leads are dark in an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	
RTS ● green	red ● RD*
DSR* ● green	green ● CTS*
CD* ● green	green ● DTR

Another way to test this connection is to connect a dumb terminal to the terminal server port on the switch, make some test calls, and look for call records being displayed on the terminal.

## Co-resident INTUITY Lodging Call Accounting link using the DCE port

This connection is used to transfer Call Detail Recording (CDR) information to the co-resident INTUITY Lodging Call Accounting software (Homisco). This connection is valid for a *csi* or *si* system.

### Parts list

- The DCE port on the switch (this port is found on the Processor Interface Cable of a *csi* system labeled as J2)
- One M25A RS232 cable (or equivalent straight-through cable) (comcode 105193668)
- One Equinox P/N:210068 DTE 10/10 adapter (DB25 DTE, comcode 406983155); see [“Appendix B — Connector pinouts”](#)
- One D6AP modular cord (comcode 102937604)
- One Multi-Port Serial card on the MAP (comcode 407009406; J1P260AA1, List 12).


For this connection, use the first port on the card. This port is not marked on the card, but is administered in software as port TTYsaa.

### Distance limits

The distance limit from the switch to the MAP is 50 feet (15.2 meters). If the distance from the switch and the MAP is more than 50 feet (15.2 meters), or if the switch is an *r* system, see [“Switch-to-call accounting link using DCP data modules”](#) on page 67.

### Cabling diagram

Figure 17 shows the connection used to transfer CDR information between the DCE port on a *csi* or *si* system and the MAP.



**Figure 17. Co-resident INTUITY Lodging Call Accounting link using the DCE port**

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link where the Equinox adapter connects to the M25A cable as shown in [Figure 17](#). The leads marked with an asterisk are controlled by the switch, and the INTUITY Lodging Call Accounting system controls the other leads. Translations for this begin on [page 262](#).



#### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the M25A cable, the mini-tester should show the following:

TD	<input type="radio"/>	dark		
			red	<input checked="" type="radio"/> RD*
RTS	<input type="radio"/>	dark		
			green	<input checked="" type="radio"/> CTS*
DSR*	<input checked="" type="radio"/>	green		
			dark	<input type="radio"/> DTR
CD*	<input checked="" type="radio"/>	green		

With the mini-tester connected to only the Equinox adapter, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red		
			dark	<input type="radio"/> RD*
RTS	<input type="radio"/>	dark		
			dark	<input type="radio"/> CTS*
DSR*	<input type="radio"/>	dark		
			green	<input checked="" type="radio"/> DTR
CD*	<input checked="" type="radio"/>	red		

With the mini-tester connected to the M25A cable and the Equinox adapter, the mini-tester should show the following (if any of the switch leads are dark on an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	
	red ● RD*
RTS ○ dark	
	green ● CTS*
DSR* ● green	
	green ● DTR
CD* ● green	

Another way to test this connection is to connect a dumb terminal to the DCE port on the switch, make some test calls, and look for call records being displayed on the terminal.

## **Xiox call accounting system link using the DCE port**

This connection is used to transfer CDR information to the Xiox call accounting system. This connection is valid for a *csi* or *si* system.

### **Parts list**

- The DCE port on the switch (this port is found on the Processor Interface Cable of a *csi* system labeled as J2)
- One M25A or M25B cable plus gender changers as needed (or equivalent 25-pin straight-through cable) to connect from the DCE port to the PBX port on the Xiox Intelligent Buffer unit
- Xiox Intelligent Buffer unit (includes AC power adapter and cable for connection to the Xiox call accounting PC)
- Xiox call accounting PC.

### **Distance limits**

The distance limit from the switch to the Xiox call accounting PC is 50 feet (15.2 meters). If the distance from the switch and the PC is more than 50 feet (15.2 meters), or if the switch is an *r* system, see [“Switch-to-call accounting link using DCP data modules” on page 67](#).

### Cabling diagram

Figure 18 shows the connection between the DCE port on a *csi* or *si* system and a Xiox call accounting system.




Figure 18. Xiox call accounting system link using the DCE port

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link at the point where the M25 cable connects to the Xiox Intelligent Buffer as shown in [Figure 18](#). The leads marked with an asterisk are controlled by the switch, and the call accounting system controls the other leads. Translations for this connection begin on [page 262](#).



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the M25 cable from the switch, the mini-tester should show the following:

TD	○	dark			
			red	●	RD*
RTS	○	dark			
			green	●	CTS*
DSR*	●	green			
			dark	○	DTR
CD*	●	green			

With the mini-tester connected to only the PBX port on the Xiox Intelligent Buffer, the mini-tester should show the following:

TD	●	red			
			dark	○	RD*
RTS	●	green			
			dark	○	CTS*
DSR*	○	dark			
			green	●	DTR
CD*	○	dark			

With the mini-tester connected to the switch and the PBX port on the Xiox Intelligent Buffer, the mini-tester should show the following (if any of the switch leads are dark in an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	
RTS ● green	red ● RD*
DSR* ● green	green ● CTS*
CD* ● green	green ● DTR

Another way to test this connection is to connect a dumb terminal to the DCE port on the switch, make some test calls, and look for call records being displayed on the terminal.

## Stand-alone call accounting system link using the DCE port

This connection is used to transfer CDR information to a stand-alone call accounting system. This connection is valid for a *csi* or *si* system.

### Parts list


- The DCE port on the switch (this port is found on the Processor Interface Cable of a *csi* system labeled as J2)
- One M25A or M25B cable plus gender changers as needed (or equivalent 25-pin straight-through cable) to connect from the DCE port to the interface port on the call accounting system.

### Distance limits

The distance limit from the switch to the stand-alone call accounting system is 50 feet (15.2 meters). If the distance from the switch and the call accounting system is more than 50 feet (15.2 meters), or if the switch is an *r* system, see [“Switch-to-call accounting link using DCP data modules” on page 67](#).

### Cabling diagram

Figure 19 shows the connection between the DCE port on a *csi* or *si* system and a stand-alone call accounting system.



**Figure 19. Switch-to-call accounting link (stand-alone call accounting system)**

### Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link at the demarcation point as shown in [Figure 19](#). The leads marked with an asterisk are controlled by the switch, and the call accounting system controls the other leads. Translations for this connection begin on [page 262](#).



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the M25 cable from the switch, the mini-tester should show the following:

TD	○	dark			
			red	●	RD*
RTS	○	dark			
			green	●	CTS*
DSR*	●	green			
			dark	○	DTR
CD*	●	green			

With the mini-tester connected to only the interface port on the stand-alone call accounting system, the mini-tester should show the following:

TD	●	red			
			dark	○	RD*
RTS	●	green			
			dark	○	CTS*
DSR*	○	dark			
			green	●	DTR
CD*	○	dark			

With the mini-tester connected to the switch and the stand-alone call accounting system, the mini-tester should show the following (if any of the switch leads are dark in an end-to-end connection, the processor circuit pack should be replaced):

TD	●	red			
			red	●	RD*
RTS	●	green			
			green	●	CTS*
DSR*	●	green			
			green	●	DTR
CD*	●	green			

Another way to test this connection is to connect a dumb terminal to the DCE port on the switch, make some test calls, and look for call records being displayed on the terminal.

## Switch-to-call accounting link using DCP data modules

This connection is used when the distance between the switch and the call accounting system is greater than 50 feet (15.2 meters), or when using an *r* system.

### Parts list

#### Co-Resident INTUITY Lodging Call Accounting (Homisco)

- One digital communications protocol (DCP) port on the switch; the 8400B data module uses a TN2214 or TN2224 2-wire digital port, and the 7400A and 7400B data modules use a TN754C 4-wire digital port
- Standard cross-connect hardware
- One D8W modular cord
- One 8400B data module optioned as shown on [page 69](#), a 7400A data module optioned as shown in [Table 5](#), or a 7400B data module optioned as shown on [page 71](#)
- One DB9-to-DB25 transition cable when using the 8400B data module
- One Equinox P/N:210068 DTE 10/10 adapter (DB25 DTE, comcode 406983155); see [“Appendix B — Connector pinouts”](#)
- One D6AP modular cord (comcode 102937604).

#### Xiox or other stand-alone call accounting system

- One digital communications protocol (DCP) port on the switch; the 8400B data module uses a TN2214 or TN2224 2-wire digital port, and the 7400A and 7400B data modules use a TN754C 4-wire digital port
- Standard cross-connect hardware
- One D8W modular cord
- One 8400B data module optioned as shown on [page 69](#), a 7400A data module optioned as shown in [Table 5 on Page 70](#), or a 7400B data module optioned as shown on [page 71](#)
- One DB9-to-DB25 transition cable when using the 8400B data module
- One M25A or M25B cable (or equivalent 25-pin straight-through cable); see [“Appendix A — Parts list” on page 286](#).

### Distance limits

The distance limit when connecting a data module to a TN2214 or TN2224 with 24 AWG wire is 3500 feet (1067 meters). The distance limit when connecting a data module to a TN754C is 5000 feet (1524 meters) with 24 AWG wire, and 4000 feet (1219 meters) with 26 AWG wire.

### Cabling diagram

Figure 20 shows the connection between the switch and the call accounting system (INTUITY Lodging Call Accounting or stand-alone call accounting) when using a DCP data module. Use these connections for *r* systems.




Figure 20. Call accounting link using DCP data modules

## 8400B options

The options on the 8400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 8400B. For the switch-to-call accounting link, a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 8400B:

1. Set the speed on the data terminal or terminal emulation package to match the speed of the call accounting system. By doing this, the speed on the 8400B will autobaud to match the correct speed.
2. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The OK prompt should display.
3. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the OK prompt is not displayed.

**at&f**  (the OK prompt displays)

**ats24=1**  (the OK prompt displays)

**at&c1&d2&s1s0=1**  (the OK prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:ACH S16:00H S18:000 S21:70H
S22:76H S23:1BH S24:01H S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:ACH S18:000 S21:70H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

TELEPHONE NUMBERS:
```

4. Disconnect the data terminal or PC from the 8400B.
5. Reconnect the unit as shown in [Figure 20](#).
6. Cycle power on the 8400B (disconnect the line cord momentarily).

If your call accounting system requires a different set of options, consult the *8400B Plus Data Module User's Guide*.

## 7400A options

The options for the 7400A used for the switch-to-call accounting connection are given in [Table 5](#). These options must match the call accounting system communication parameters, which are usually 9600 bps, 8 data bits, 1 stop bit, and no parity.

The data module interface board must be positioned at the DCE location, and the interface option must be set for Answer-Only mode.

**Table 5. 7400A options for switch-to-call accounting link**

<b>Set Interface</b>	<b>Set Values</b>
Option	Answer-only mode
<b>Set Option Displays</b>	<b>Set Values</b>
*Set 300 speed	OFF
*Set 1200 speed	OFF
*Set 2400 speed	OFF
*Set 4800 speed	OFF
*Set 9600 speed	ON
*Set 19200 speed	OFF
Set Answer	AUTO
Set Break DISC	LONG
Set CI Lead	OFF
Set CH Lead	OFF
Set CTS Lead	NORMAL
Set DCD Lead	NORMAL
Set DSR Lead	NORMAL
Set DTR Detect	50
Set DTR Lead	FOLLOW
Set LL Lead	OFF
Set Remote Loop	GRANT
Set RI Lead	ON
Set RL Lead	OFF
Set SIGLS DISC	ON
Set TM Lead	OFF

\* Verify the speed setting with the call accounting vendor. Enable other speeds as needed.

## 7400B options

The options on the 7400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 7400B. For the switch-to-call accounting link, only a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 7400B:

1. Set the option dip switches SW1-1 to **ON** (without phone), SW1-5 to **OFF**, and SW1-8 to **OFF**.
2. Set the speed on the data terminal or terminal emulation package to match the speed of the call accounting system. By doing this, the speed on the 7400B will autobaud to match the correct speed.
3. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The **OK** prompt should display.
4. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the **OK** prompt is not displayed.

**at&f**  (the **OK** prompt displays)

**at&c1&d2&s1s0=1**  (the **OK** prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:AAH S16:00H S18:000 S21:00H
S22:76H S23:0BH S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X1 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:AAH S18:000 S21:00H S22:76H S23:0BH S25:005 S26:001
S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S25:005 S26:001
S27:40H

TELEPHONE NUMBERS:
```

5. Disconnect the data terminal or PC from the 7400B.
6. Reconnect the unit as shown in [Figure 20](#).

If your call accounting system requires a different set of options, consult the *7400B Data Module User's Guide*.

## **INTUITY Lodging Call Accounting-to-PMS link**

This connection is used to transmit the call accounting information from the MAP to the PMS. This call detail information has been reformatted from its format on the switch for use by the PMS.



### **NOTE:**

This link between the co-resident INTUITY Lodging Call Accounting package and the PMS is required to transmit call detail records between the call accounting system and the PMS. This link is separate and distinct from the INTUITY Lodging-to-PMS link described on [page 39](#).

### **Parts list**

- One Multi-Port Serial card on the MAP (comcode 407009406; J1P260AA1, List 12)

For this connection, use the second port on the card. This port is not marked on the card, but is administered in software as port TTYsab.


- One D6AP modular cord (comcode 102937604)
- One Equinox P/N:210068 DTE 10/10 adapter (DB25 DTE, comcode 406983155); see “[Appendix B — Connector pinouts](#)”
- Gender changers, as needed.

### **Distance limits**

The distance limit from the MAP to the PMS is 50 feet (15.2 meters).

### Cabling diagram

Figure 21 shows the INTUITY Lodging Call Accounting connection between the MAP and a PMS.



---

**Figure 21. INTUITY Lodging Call Accounting-to-PMS link**

## Xiox call accounting-to-PMS link

---

This connection is used to transmit the call accounting information from the Xiox call accounting system to the PMS. This call detail information has been reformatted from its format on the switch for use by the PMS.

### Parts list


- One standard null modem serial cable to connect from COM2 on the Xiox call accounting PC to the call accounting port on the PMS
- Gender changers, as needed.

### Distance limits

The distance limit from the Xiox call accounting PC to the PMS is 50 feet (15.2 meters).

### Cabling diagram

Figure 22 shows the connection between the Xiox call accounting PC and a PMS.



**Figure 22. Xiox call accounting-to-PMS link**

## Switch-to-PMS link

---

This connection is used to transfer the normal hospitality information, such as names registration, check-in, check-out, and so on, between the switch and the PMS.

This connection is used to transfer the normal hospitality information, such as names registration, check-in, check-out, and so on, between the switch and the PMS. This connection can be done in either of two different ways:

- [“PMS link using a terminal server”](#)
- [“PMS link using a data module” on page 77](#)

### PMS link using a terminal server

This section describes how to connect the switch to a PMS using a terminal server.

#### Parts list

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router
- One or two RJ45 UTP Category 5 modular cords (see [“Appendix A — Parts list” on page 286](#))
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- Terminal server (comcode 700015084)
- RJ45-to-DB25 cable (part of comcode 700015084)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)

#### Distance limits

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). The distance from the hub to the PMS is 50 feet (15.2 meters).

### Cabling diagram

Figure 23 shows the connection between the switch and the PMS using a terminal server.




Figure 23. PMS link using a terminal server

## **PMS link using a data module**

This section describes how to connect the switch to a PMS using a data module.

### **Parts list**

- One digital communications protocol (DCP) port on the switch; the 8400B data module uses a TN2214 or TN2224 2-wire digital port, and the 7400A and 7400B data modules use a TN754C 4-wire digital port.
- Standard cross-connect hardware
- One D8W modular cord
- One 8400B data module optioned as shown on [page 79](#), a 7400A DCP data module optioned as shown in [Table 6 on Page 80](#), or a 7400B DCP data module optioned as shown on [page 81](#)
- One DB9-to-DB25 transition cable when using the 8400B data module
- One M25A or M25B cable (or equivalent 25-pin straight-through cable); see [“Appendix A — Parts list” on page 286](#).

### **Distance limits**

The distance limit when connecting a data module to a TN2214 or TN2224 with 24 AWG wire is 3500 feet (1067 meters). The distance limit when connecting a data module to a TN754C is 5000 feet (1524 meters) with 24 AWG wire, and 4000 feet (1219 meters) with 26 AWG wire.

### Cabling diagram

Figure 24 shows the connection between the switch and the PMS.




Figure 24. PMS link using a data module

## 8400B options

The options on the 8400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 8400B. For the switch-to-PMS link, a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 8400B:

1. Set the speed on the data terminal or terminal emulation package to match the speed of the PMS link. By doing this, the speed on the 8400B will autobaud to match the correct speed.
2. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The OK prompt should display.
3. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the OK prompt is not displayed.

**at&f**  (the OK prompt displays)

**ats24=1**  (the OK prompt displays)

**at&c1&d2&s1s0=1**  (the OK prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:ACH S16:00H S18:000 S21:70H
S22:76H S23:1BH S24:01H S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:ACH S18:000 S21:70H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

TELEPHONE NUMBERS:
```

4. Disconnect the data terminal or PC from the 8400B.
5. Reconnect the unit as shown in [Figure 24](#).
6. Cycle power on the 8400B (disconnect the line cord momentarily).

If your PMS requires a different set of options, consult the *8400B Plus Data Module User's Guide*.

## 7400A options

The options for the 7400A used for the switch-to-PMS connection are given in [Table 6](#). These options must match the PMS communication parameters, which are usually 9600 bps, 8 data bits, 1 stop bit, and no parity.

The data module interface board must be positioned at the DCE location, and the interface option must be set for Answer-Only mode.

**Table 6. 7400A options for switch-to-PMS link**

<b>Set Interface</b>	<b>Set Values</b>
Option	Answer-only mode
<b>Set Option Displays</b>	<b>Set Values</b>
*Set 300 speed	OFF
*Set 1200 speed	OFF
*Set 2400 speed	OFF
*Set 4800 speed	OFF
*Set 9600 speed	ON
*Set 19200 speed	OFF
Set Answer	AUTO
Set Break DISC	LONG
Set CI Lead	OFF
Set CH Lead	OFF
Set CTS Lead	NORMAL
Set DCD Lead	NORMAL
Set DSR Lead	NORMAL
Set DTR Detect	50
Set DTR Lead	FOLLOW
Set LL Lead	OFF
Set Remote Loop	GRANT
Set RI Lead	ON
Set RL Lead	OFF
Set SIGLS DISC	ON
Set TM Lead	OFF

\* The speed is typically set to 9600 for Transparent mode and 1200 for Normal mode. Verify the speed setting with the PMS vendor. Enable other speeds as needed.

## 7400B options

The options on the 7400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 7400B. For the switch-to-PMS link, only a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 7400B:

1. Set the option dip switches SW1-1 to **ON** (without phone), SW1-5 to **OFF**, and SW1-8 to **OFF**.
2. Set the speed on the data terminal or terminal emulation package to match the speed of the PMS. By doing this, the speed on the 7400B will autobaud to match the correct speed.
3. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The **OK** prompt should display.
4. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the **OK** prompt is not displayed.

**at&f**  (the **OK** prompt displays)

**at&c1&d2&s1s0=1**  (the **OK** prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:AAH S16:00H S18:000 S21:00H
S22:76H S23:0BH S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X1 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:AAH S18:000 S21:00H S22:76H S23:0BH S25:005 S26:001
S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S25:005 S26:001
S27:40H

TELEPHONE NUMBERS:
```

5. Disconnect the data terminal or PC from the 7400B.
6. Reconnect the unit as shown in [Figure 24](#).

If your PMS requires a different set of options, consult the *7400B Data Module User's Guide*.

## Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the link at the null modem or data module before you connect to the PMS. The leads marked with an asterisk are controlled by the switch, and the PMS controls the other leads. Translations for this connection begin on [page 189](#).



### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the null modem of the terminal server ([Figure 23 on page 76](#)) or to only the data module ([Figure 24 on page 78](#)), the mini-tester should show the following:

TD	<input type="radio"/>	dark			
			red	<input checked="" type="radio"/>	RD*
RTS	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	CTS*
DSR*	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	DTR
CD*	<input checked="" type="radio"/>	green			



### NOTE:

The CTS lead shows green when used with an 8400B. RTS will be lit on the front panel of the 7400A or 7400B.

With the mini-tester connected to only the PMS, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red			
			dark	<input type="radio"/>	RD*
RTS	<input checked="" type="radio"/>	green			
			dark	<input type="radio"/>	CTS*
DSR*	<input type="radio"/>	dark			
			green	<input checked="" type="radio"/>	DTR
CD*	<input type="radio"/>	dark			

With the mini-tester connected to the null modem or data module and the PMS, the link will be idle, but the mini-tester should show the following (if any of the switch leads are dark in an end-to-end connection, the processor circuit pack should be replaced):

TD ● red	
	red ● RD*
RTS ● green	
	green ● CTS*
DSR* ● green	
	green ● DTR
CD* ● green	



**NOTE:**

The CTS lead shows green when used with an 8400B. RTS will be lit on the front panel of the 7400A or 7400B.

## **Journal/PMS log or system printer connections**

---

These serial printers are used to run hospitality service reports, to report failed Automatic Wakeup calls and Do Not Disturb requests, or to run Basic Call Management System (BCMS) reports.



**NOTE:**

In most cases, only one printer is provided to perform both the journal/schedule and PMS log printer functions. The system printer is usually a separate printer.

Connecting serial printers can be done in either of two different ways:

- [“Printer connections using a terminal server” on page 85](#)
- [“Printer connections using a data module” on page 87](#)

## Printer connections using a terminal server

This section describes how you connect a serial printer to the switch using a terminal server.



### CAUTION:

*Using a terminal server to connect a printer does not provide guaranteed delivery of print jobs. If your installation requires guaranteed delivery of print jobs, use a data module to connect your printer. See “Printer connections using a data module” on page 87.*

This connection may also be used to send printer output to a PC, where the printer records are saved in a file on the PC. To do this, you must install a reliable session protocol to the PC. To download this protocol, see the Avaya support web site:

<http://www.avaya.com/support>

Select Online Services/AVXTRA, then select Software/Firmware Downloads. A table displays the software available for downloading. Select the Reliable Session Layer Protocol and download it to your PC. The file is a self-extracting program and contains on-line instructions for using the protocol.

## Parts list

Each printer connection requires the following parts:

- An ethernet port on the C-LAN circuit pack
- One IP Media Processor adapter (comcode 848525887) for a 100 Mbps link (TN799DP or later), or  
One 259A adapter (comcode 102631413) for a 10 Mbps link (TN799C or earlier)
- One 10/100Base-T auto-sensing LAN hub or customer router
- One or two RJ45 UTP Category 5 modular cords (see “Appendix A — Parts list” on page 286)
- One or more 451A in-line RJ45 adapters, as needed (used to connect modular cords together)
- Terminal server (comcode 700015084)
- RJ45-to-DB25 cable (part of comcode 700015084)
- One null modem with transmit/receive swapped (all other leads are straight-through) (comcode 407122043)
- One Okidata Model ML321T printer (or equivalent serial printer).

### Distance limits

The distance limit from the switch to the LAN hub is 328 feet (100 meters). The distance limit from the LAN hub to the terminal server is 328 feet (100 meters). The distance from the hub to the serial printer is 50 feet (15.2 meters).

### Cabling diagram

Figure 25 shows how to connect a journal/schedule printer, a PMS log printer, or a system printer to the switch using a terminal server.




Figure 25. Printer connections using a terminal server

## Printer connections using a data module

This section describes how you connect a serial printer to the switch using a data module.

### Parts list

Each printer connection requires the following parts:

- One digital communications protocol (DCP) port on the switch; the 8400B data module uses a TN2214 or TN2224 2-wire digital port, and the 7400A and 7400B data modules use a TN754C 4-wire digital port.
- Standard cross-connect hardware
- One D8W modular cord
- One 8400B DCP data module optioned as shown on [page 89](#), one 7400A DCP data module optioned as shown in [Table 7 on Page 90](#), or one 7400B DCP data module optioned as shown on [page 91](#)
- One DB9-to-DB25 transition cable when using the 8400B data module
- One M25B cable (or equivalent 25-pin straight-through cable); see [“Appendix A — Parts list” on page 286](#).
- One Okidata Model ML321T printer (or equivalent).

### Distance limits

The distance limit when connecting a data module to a TN2214 or TN2224 with 24 AWG wire is 3500 feet (1067 meters). The distance limit when connecting a data module to a TN754C is 5000 feet (1524 meters) with 24 AWG wire, and 4000 feet (1219 meters) with 26 AWG wire.

### Cabling diagram

Figure 26 shows how to connect a journal/schedule printer, a PMS log printer, or a system printer to the switch using a data module.




Figure 26. Printer connections using a data module

## 8400B options

The options on the 8400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 8400B. For the journal/log printers, a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 8400B:

1. Set the speed on the data terminal or terminal emulation package to match the speed of the printer. By doing this, the speed on the 8400B will autobaud to match the correct speed.
2. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The OK prompt should display.
3. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the OK prompt is not displayed.

**at&f**  (the OK prompt displays)

**ats24=1**  (the OK prompt displays)

**at&c1&d2&s1s0=1**  (the OK prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:ACH S16:00H S18:000 S21:70H
S22:76H S23:1BH S24:01H S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:ACH S18:000 S21:70H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S24:01H S25:005
S26:001 S27:40H

TELEPHONE NUMBERS:
```

4. Disconnect the data terminal or PC from the 8400B.
5. Reconnect the unit as shown in [Figure 26](#).
6. Cycle power on the 8400B (disconnect the line cord momentarily).

If your printer requires a different set of options, consult the *8400B Plus Data Module User's Guide*.

## 7400A options

The options for the 7400A used for printers are given in [Table 7](#). These options must match the printer communication parameters, which are usually 9600 bps, 8 data bits, 1 stop bit, and no parity.

The data module interface board must be positioned at the DCE location, and the interface option must be set for Answer-Only mode.

**Table 7. 7400A options for printers**

<b>Set Interface</b>	<b>Set Values</b>
Option	Answer-only mode
<b>Set Option Displays</b>	<b>Set Values</b>
* Set 300 speed	OFF
* Set 1200 speed	OFF
* Set 2400 speed	OFF
* Set 4800 speed	OFF
* Set 9600 speed	ON
* Set 19200 speed	OFF
Set Answer	AUTO
Set Break DISC	LONG
Set CI Lead	OFF
Set CH Lead	OFF
Set CTS Lead	NORMAL
Set DCD Lead	NORMAL
Set DSR Lead	NORMAL
Set DTR Detect	50
Set DTR Lead	FOLLOW
Set LL Lead	OFF
Set Remote Loop	GRANT
Set RI Lead	ON
Set RL Lead	OFF
Set SIGLS DISC	ON
Set TM Lead	OFF
* Match the speed based on the printer settings.	

## 7400B options

The options on the 7400B must be set using an ASCII data terminal or a PC using a terminal emulation package. You must connect the data terminal or PC to the EIA interface connector on the back of the 7400B. For the journal/log printers, only a subset of options must be changed. These options are changed using the AT command set. Use the following steps to set the options on the 7400B:

1. Set the option dip switches SW1-1 to **ON** (without phone), SW1-5 to **OFF**, and SW1-8 to **OFF**.
2. Set the speed on the data terminal or terminal emulation package to match the speed of the printer. By doing this, the speed on the 7400B will autobaud to match the correct speed.
3. From the data terminal or PC, type **at** . This automatically sets the speed and parity for the connection. The **OK** prompt should display.
4. Type the following commands as shown. (The character **0** is the number zero.) Before you press  for each command, make sure that the command has been entered correctly. The **e0** option on the last command turns off keyboard echo, which means that after you enter this command, any future keyboard entries will not be displayed, and the **OK** prompt is not displayed.

**at&f**  (the **OK** prompt displays)

**at&c1&d2&s1s0=1**  (the **OK** prompt displays)

**ate0q1&w0&y0&v**

The **&v** portion of the last command displays the current set of options. Your screen should look something like this:

```
ACTIVE PROFILE:
B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0 &Y0
S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:060
S08:002 S09:006 S10:014 S12:050 S14:AAH S16:00H S18:000 S21:00H
S22:76H S23:0BH S25:005 S26:001 S27:40H

STORED PROFILE 0:
B1 E0 L2 M1 Q1 V1 X1 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q0 &R0 &S1 &X0
S00:001 S14:AAH S18:000 S21:00H S22:76H S23:0BH S25:005 S26:001
S27:40H

STORED PROFILE 1:
B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0
S00:000 S14:AAH S18:000 S21:00H S22:76H S23:1BH S25:005 S26:001
S27:40H

TELEPHONE NUMBERS:
```

5. Disconnect the data terminal or PC from the 7400B.
6. Reconnect the unit as shown in [Figure 26](#).

If your printer requires a different set of options, consult the *7400B Data Module User's Guide*.

## Okidata model ML321T journal/PMS log printer options

Using the serial interface card (comcode 406940577), option the printer as follows for a journal or PMS log printer:

1. Press SHIFT + SEL to enter the Menu Mode.
2. Press Print (Park) to print out the Groups and Items. The first Group/Item to come up will be Printer Control/Emulation Control.
3. Press SET to option the emulation to ML.
4. Press GROUP (LF) repeatedly until you come to Serial I/F.
5. Press ITEM to advance to the next item in this group (Serial I/F) or SET to change it.
6. After changing defaults of an item, press ITEM to advance to the next one. Set the Serial I/F options for the printer as shown in [Table 8](#).

**Table 8. Okidata model ML321T journal/PMS log printer options**

Item	Setting
Parity	None
Serial Data 7/8 Bits	8 (if data module) 7 (if DCE port)
Protocol	X-ON/X-OFF
Diagnostic Test	No
Busy Line	DTR
Baud Rate	9600 (match speed of data module or DCE port)
DSR Signal	Invalid
DTR Signal	Ready on Power UP
Busy Time	200 ms

7. After setting the options, press SHIFT + SEL to save the settings.

### Okidata model ML321T system printer options

Using the serial interface card (comcode 406940577), option the printer as follows for a system printer:

1. Press SHIFT + SEL to enter the Menu Mode.
2. Use the GROUP, ITEM, and SET keys to make changes:
  - Press GROUP until the group you wish to change appears in the first column.
  - Press ITEM until the item you wish to change appears in the second column.
  - Press SET until the setting you want appears in the third column.
3. Set the options for the printer as shown in [Table 9](#).

**Table 9. Okidata model ML321T system printer options**

Group	Item	Setting
Printer Control	Emulation Mode	ML
Font	Print Mode	Utility
	DRAFT Mode	HSD
	Pitch	12 CPI
	Proportional	No
	Style	Normal
	Size	Single
Symbol Sets	Character Set	Standard
	Language Set	American
	Zero Character	Slashed
	Code Page	USA
Clear Feed	Line Spacing	8 LPI
	Form Tear-Off	Off
	Skip Over Perforation	No
	Page Width	13.6"
	Page Length	11"
Bottom Feed	Line Spacing	6 LPI
	Form Tear-Off	Off
	Skip Over Perforation	No
	Page Width	13.6"
	Page Length	11"

**Table 9. Okidata model ML321T system printer options (Continued)**

<b>Group</b>	<b>Item</b>	<b>Setting</b>
Top Feed	Line Spacing	6 LPI
	Bottom Margin	Valid
	Page Width	13.6"
	Page Length	11"
	Wait Time	1 sec
	Page Length Control	by Actual Page Length
Set-Up	Graphics	Uni-directional
	7 or 8 Bits Graphics	7
	Receive Buffer Size	16K
	Paper Out Override	No
	Print Registration	0
	7 or 8 Bits Data Word	7
	Operator Panel Function	Full Operation
	Reset Inhibit	No
	Print Suppress Effective	Yes
	Auto LF	Yes
	Print DEL Code	No
	Time Out Print	Valid
	Auto Select	No
	Centering Position	DEFAULT
CSF Type	Wide	
Parallel I/F	I-Prime	Buffer Print
	Pin 18	+5v
Serial I/F	Parity	None
	Serial Data 7/8 Bits	8 Bits
	Protocol	X-ON/X-OFF
	Diagnostic Test	No
	Busy Line	DTR
	Baud Rate	9600 BPS
	DSR Signal	Invalid
	DTR Signal	Ready on Power UP
Busy Time	200 ms	

4. After setting the options, press SHIFT + SEL to save the settings.

## Test procedure

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the connection at the terminal server port or data module. The leads marked with an asterisk are controlled by the switch, and the printer controls the other leads. Translations for this connection begin on [page 268](#).



### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

With the mini-tester connected to only the terminal server port or data module, the mini-tester should show the following:

TD	<input type="radio"/>	dark		
			red	<input checked="" type="radio"/> RD*
RTS	<input type="radio"/>	dark		
			green	<input checked="" type="radio"/> CTS*
DSR*	<input checked="" type="radio"/>	green		
			dark	<input type="radio"/> DTR
CD*	<input checked="" type="radio"/>	green		



### NOTE:

RTS will be lit on the front panel of the 7400A or 7400B. The CTS lead shows green when used with an 8400B.

With the mini-tester connected to only the printer, the mini-tester should show the following:

TD	<input checked="" type="radio"/>	red		
			dark	<input type="radio"/> RD*
RTS	<input checked="" type="radio"/>	green		
			dark	<input type="radio"/> CTS*
DSR*	<input type="radio"/>	dark		
			green	<input checked="" type="radio"/> DTR
CD*	<input type="radio"/>	dark		

With the mini-tester connected to the terminal server port or data module and the printer, the link is idle and no software is running, but the mini-tester should show the following:

TD ● red	
RTS ● green	red ● RD*
DSR* ● green	green ● CTS*
CD* ● green	green ● DTR



**NOTE:**

RTS will be lit on the front panel of the 7400A or 7400B. The CTS lead shows green when used with an 8400B.

## Printer connection on the INTUITY

---


This is an optional printer that the customer may purchase to print INTUITY Lodging Call Accounting reports.

### Parts list

- One Centronics parallel printer cable (customer-provided)
- One parallel printer (customer-provided; the Okidata Model 320 or 184T are often used).

### Cabling diagram

Figure 27 shows how to connect a printer to the MAP.



**Figure 27. Printer connection on the INTUITY**

## Switch-to-INADS connections

---

This connection is used for remote maintenance access to the switch from the Initialization and Administration System (INADS). The connectivity is different for the CMC switch than for the SCC or MCC switch.



**NOTE:**

This INADS connection is typically installed only for installations in the United States. Contact your local support organization to see if INADS is required in your service area.

## Parts list

### SCC and MCC


- The AUX connector on the SCC or MCC switch
- One B25A 25-pair cable for cross-connections [connect the central office (CO) trunk to the last wire pair on this cable]
- Standard cross-connect hardware
- One CO trunk for dedicated access.

### CMC

- The Modem connector on the switch (this port is found on the Processor Interface Cable of the CMC hardware labeled as P2)
- One M25A cable (or equivalent 25-pin straight-through cable)
- One U.S. Robotics® Sportster® 33.6K modem
- One RJ11 modular cord
- One 103A connecting block
- Standard cross-connect hardware
- One CO trunk for dedicated access.

### Cabling diagram


Figure 28 shows how the INADS port is connected to an SCC or MCC switch.



---

**Figure 28. INADS connection for remote access to SCC or MCC switch**

Figure 29 shows how the INADS port is connected to a CMC switch.



---

**Figure 29. INADS connection for remote access to CMC switch**

## INADS registration

After connecting the CO trunk for INADS access, call the INADS hotline to register the switch. For Avaya technicians in the United States, use 1-800-248-1234. For dealers and distributors in the United States, use 1-877-295-0099. If the installation is outside of the United States, contact your Center of Excellence (COE) or your Avaya representative for information about registering the switch.

You will be instructed to give them the dial-up number, the customer identification number, serial number, and other information. If there is a working fax machine at the site, request that the INADS group send you a fax that confirms all of the registration information.

You will also be instructed to add some information to the maintenance-related system parameters screen. If the customer needs a login assigned, have the INADS personnel create a customer login ID when they connect to the switch.

```
change system-parameters maintenance                               Page 1 of 3
      MAINTENANCE-RELATED SYSTEM PARAMETERS

OPERATIONS SUPPORT PARAMETERS
  Product Identification: 1828482848
    First OSS Endpoint: 918005353573      Abbrev Alarm Report? y
    Second OSS Endpoint: 93034509174     Abbrev Alarm Report? n
  Alarm Origination to OSS Numbers: neither
  Cleared Alarm Notification? n          Suspension Threshold: 5
  Restart Notification? y
  Test Remote Access Port? y
  CPE Alarm Activation Level: none

  Customer Access to INADS Port? n
  Repeat Dial Interval (mins): 7

SCHEDULED MAINTENANCE
  Start Time: 10 : 00                      Stop Time: 15 : 00
  Daily Maintenance: daily                 Save Translation: daily
                                          Command Time-out (hours): 2
  Control Channel Interchange: no         System Clocks Interchange: no
  SPE Interchange: no                    EXP-LINK Interchange: no
```

For a CMC switch, you must also set up the modem options on Page 3 before a connection can be made. See Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets* for more information on modem setup.

```
change system-parameters maintenance                               Page 3 of 3
      MAINTENANCE-RELATED SYSTEM PARAMETERS

      Modem Connection: external
        Data Bits: 8
        Parity: none

      Modem Name: u.s. robotics

      RTS/CTS Enabled: &F1&H1           Auto Answer Ring Count (rings): S0=10
Asynchronous Data Mode:                               Dial Type: T
      DTE Auto-Data Speed:           Adjustable Make/Break Ratio:
Disable Data Compression: &K0           Dial Command: D
      Enable Error Control:           No Answer Time-out: S7=255
      Misc. Init. Param: S12=24&W0

MAINTENANCE SAVE TRANSLATION CORRUPTION AUDIT
      Enable Translation Audit? y
      Display Warning When Detected? n
        Alarm When Detected? n
      Block Save Translation When Detected? n
```

## MAP remote access connections

---

The INADS access is required, but the remote administration is optional. See the INTUITY documentation for more information about this remote access connection.



**NOTE:**

If the INTUITY Remote Maintenance Board (RMB) is used, an external modem is not needed. See the INTUITY documentation for more information about using the Remote Maintenance Board.

### Parts list

- One or two Comsphere<sup>®</sup> 3820 modems (comcode 107560534) or locally-provided modems
- One or two straight-through 9-pin to 25-pin transition cables (comcode 847106945)
- One or two D25F cables (or equivalent straight-through cables) (comcode 105193668)
- One or two D8W modular cords
- Standard cross-connect hardware
- One or two CO or DID trunks.

### Cabling diagram

Figure 30 shows how to connect the Paradyne Comsphere 3820 modems to the MAP for remote access. This diagram also shows how the RMB is connected. If the RMB is used, the COM2 port cannot be used for any other application.




Figure 30. MAP remote access connections

## INADS alarm origination download

You can have the Comsphere 3820 or the RMB automatically configured by doing an alarm origination download. To start this download:

1. Use the **Customer/Services Administration > Alarm Management** command to display the following screen:

```

+-----+
+           Alarm Management           +
+-----+
|Product ID           2200000000      |
|Alarm Destination    18005353573     |
|Alarm Origination    ACTIVE          |
|Alarm Level          MAJOR            |
|Alarm Suppression    INACTIVE        |
|Clear Alarm Notification ACTIVE       |
+-----+

```

2. Enter the information as shown in the screen, using your actual Product ID and Alarm Destination phone number (the INADS number).
3. Once the options are correct, press **F3** to save the options. Press  to continue.
4. Press **F8** to select the Chg Keys function.
5. Press **F1** to select the Test Alrm function.
6. Select the **Execute Alarm Origination Test** menu item.
7. Press **y** to start the test. The alarm origination download takes 2 to 5 minutes to complete.
8. After the download is complete, select the **Review Latest Test Results** menu item. The result message should say Alarm origination test successful.

For more details on this procedure, see the appropriate MAP installation document.

---

# Translations and testing

---

The following sections contain translations and testing required to successfully administer the switch, the INTUITY Lodging Voice Messaging, and the INTUITY Lodging Call Accounting. Only the most important fields are highlighted with either required or suggested translations. Unless specified otherwise, the defaults provided are acceptable.

Most INTUITY Lodging installations will involve the MAP/5P hardware platform. In some cases, though, customers will have the MAP/40P or MAP/100P. The screens shown in this section apply for all of these platforms.

For installations with the InnOvation InnLine 2020, consult with the InnLine support personnel for administration.



## NOTE:

The screens shown in this section are examples only. Do not use the example equipment locations, extension numbers, access codes, and so on in your system. Use the translations provided by your software specialist or design specialist.



## CAUTION:

*While you are doing these translations on the switch, you should save your translations regularly using the **save translation** command. This could save you time retranslating if you lose power during installation. It takes about 10 minutes to process each translation save.*

## Translation checklist

Table 10 is a high-level checklist of the tasks required to translate a hospitality solution including the switch and the INTUITY system.

**Table 10. Translation checklist**

✓	Procedure
	"Setting up the initial options" on page 13
	"Miscellaneous translations" on page 107
	"Switch-to-PMS link translations and testing" on page 189
	"Switch-to-voice messaging translations and testing" on page 214
	"Voice messaging-to-PMS translations and testing" on page 252
	"Switch-to-call accounting translations and testing" on page 262
	"INTUITY Lodging Call Accounting-to-PMS translations and testing" on page 267
	"Printer translations (switch)" on page 268
	"Parallel printer translations (INTUITY)" on page 278
	"Customer logins (switch)" on page 278
	"Customer logins (INTUITY)" on page 278
	"Security notification (switch)" on page 279
	"Saving translations (switch)" on page 280
	"Creating a backup (INTUITY)" on page 280

## Miscellaneous translations

Table 11 is a checklist of the miscellaneous translations that must be done before you administer the links to the adjuncts.

**Table 11. Checklist for miscellaneous translations**

✓	Procedure
	"Time of day and date (INTUITY)" on page 108
	"Dial by Name special application (switch)" on page 109
	"Dial plan (switch)" on page 110
	"Dial plan (INTUITY)" on page 111
	"Feature access codes (switch)" on page 112
	"Class of service (switch)" on page 115
	"Class of restriction (switch)" on page 117
	"Class of service (INTUITY)" on page 124
	"System parameters (INTUITY)" on page 125
	"Fax parameters (switch and INTUITY)" on page 127
	"Abbreviated Dialing lists (switch)" on page 129
	"Listed Directory Numbers (switch)" on page 130
	"Attendant console (switch)" on page 131
	"Attendant console button layouts (switch)" on page 132
	"Attendant Backup (switch)" on page 136
	"Office staff, front desk, and guest services telephones (switch)" on page 139
	"Backup telephone button layouts (switch)" on page 142
	"Mailboxes for AUDIX subscribers (INTUITY)" on page 146
	"Guest room telephones (switch)" on page 147
	"Administering analog Caller ID (switch)" on page 150
	"Suite telephones (switch)" on page 152
	"Mailboxes for guest rooms (INTUITY)" on page 158
	"Recorded announcements (switch)" on page 159
	"Emergency Access to Attendant (switch)" on page 163
	"Crisis Alert (switch)" on page 164
	"Trunk groups (switch)" on page 168
	"Assigning DID numbers to guest rooms (switch)" on page 169
	"Automatic Wakeup options (switch)" on page 174

**Table 11. Checklist for miscellaneous translations (Continued)**

✓	Procedure
	"Call Vectoring (switch)" on page 176
	"Attendant Vectoring (switch)" on page 178
	"Dial by Name (switch)" on page 179
	"Trunk-to-Trunk Transfer (switch)" on page 182
	"Terminal server for asynchronous links" on page 183

### **Time of day and date (INTUITY)**

For R4.4, use the **Customer/Services Administration > System Management > UNIX<sup>®</sup> Management > UNIX Date and Time** command to set the time and date on the INTUITY system. For R5 and later, use the **UNIX Management > UNIX Date and Time** command.

```

+-----+
+                UNIX Date and Time                +
+-----+
| Date:                April 22, 1999                |
| Time:                3:39                          |
| AM/PM:              PM                            |
| Timezone:           US/Mountain                    |
| Is Daylight Savings Time used: YES                 |
+-----+
    
```

The switch time of day and date should already be set. See [page 15](#) for information about setting the time of day and date on the switch if it is not correct. It is important that the switch and INTUITY system are set to the same time.

## Dial by Name special application (switch)

Use the **display system-parameters special-applications** command to verify that the Dial by Name feature has been enabled. Dial by Name is a standard feature with Category B systems. It can be purchased and enabled as a special application for Category A systems. If the feature has not been enabled, call the technical support organization or your COE and have them dial in and enable the feature or apply a new license file.

```
display system-parameters special-applications                               Page 2 of 4
                                SPECIAL APPLICATIONS

      (SA7666) - COS Conference Tone Check? n
      (SA7880) - ASAI Internally Measured Data? n
                (SA7779) - Enhanced DID Routing? n
      (SA7777) - Night Service on DID Trunk Groups? n
                (SA7778) - Display UUI Information? n
      (SA7776) - Display Incoming Digits for ISDN Trunk Groups? n
                (SA7852) - # and * in Vector Collect Step? none
      (SA7933) - Busy Tone with SAC and No Available Cvg Points? n

                                (SA7963) - Dial by Name? y
      (SA7990) - Service Observe Physical Set? n
      (SA7991) - Variable Length Account Code? n

                (SA8052) - ISDN Redirecting Number? n
      (SA8077) - Russian Power Industry Feature? n

      (SA7161) - NORTEL SL1 PRI and DMS Names Display? n
      (SA7578) - Integrated Directory Service over DCS? n
```

## Dial plan (switch)

Use the **change dialplan** command to administer the switch dial plan based on the customer's requirements. Unless otherwise instructed, set the `Local Node Number` to **1**. For more information about the Dial Plan feature, see the *DEFINITY ECS Administrator's Guide*.



**NOTE:**

The PMS interface supports 3-, 4-, or 5-digit extensions, but be aware that prefixed extensions do not send the entire number across the interface. Only the assigned extension number is sent. Therefore, you should not use prefixed extensions for numbers that are also going to use the Insert/Delete Digit function (see "[Hospitality parameters](#)" on page 189).

```
change dialplan                                     Page 1 of 1
                                         DIAL PLAN RECORD
                                         Local Node Number: 1
                                         ETA Node Number:
Uniform Dialing Plan: none                    ETA Routing Pattern:

FIRST DIGIT TABLE
First                                         Length
Digit  - 1 -      - 2 -      - 3 -      - 4 -      - 5 -      - 6 -
1:                                           extension
2:                                           extension
3:                                           extension
4:                                           extension
5:                                           extension
6:                                           extension
7: misc
8: fac
9: fac
0: attd
*:                                           fac
#:                                           fac
```

The **add second-digit** command is used when a first digit is defined as **misc** in the Dial Plan. In this example, first digit 7 is used in several ways (70, 72x, 73x, and 74x are feature access codes, and 71x, 78xx, and 79xx are extensions).

```
add second-digit 7                                Page 1 of 1
                                         SECOND DIGIT TABLE FOR DIGIT 7

SECOND DIGIT TABLE
Digit Identification  Number of      Digit Identification  Number of
                    Digits                          Digits
0: fac                2                          5:                    0
1: extension          3                          6:                    0
2: fac                3                          7:                    0
3: fac                3                          8: extension         4
4: fac                3                          9: extension         4
```

## Dial plan (INTUITY)

Use the **AUDIX Administration > change machine** command to identify the range of mailboxes that can be activated by the INTUITY system. This must be administered to match the switch's dial plan.

```
change machine                                     Page 1 of 1
                                         MACHINE PROFILE
Machine Name: local                               Type: local                               Location: local
Voiced Name? n                                   Extension Length: 4
Voice ID: 0                                       Default Community: 1
ADDRESS RANGES
Prefix      Start Ext.  End Ext.    Warnings
1:          1000      7999
2:
3:
4:
5:
6:
7:
8:
9:
10:
```

If you change the `Extension Length` field, you must stop and restart the voice system. To stop the voice system, use the path **Customer/Services Administration > System Management > System Control > Stop Voice System**. To start the voice system, use the path **Customer/Services Administration > System Management > System Control > Start Voice System**.

## Feature access codes (switch)

The **change feature-access-codes** command is used to assign the switch feature access codes. Unless the customer requests a feature, or a feature is needed for maintenance personnel, do not assign a feature access code for features not being used. There are no default feature access codes.

```
change feature-access-codes                               Page 1 of 5
                FEATURE ACCESS CODE (FAC)
Abbreviated Dialing List1 Access Code:
Abbreviated Dialing List2 Access Code:
Abbreviated Dialing List3 Access Code:
Abbreviated Dial - Prgm Group List Access Code:
Announcement Access Code:
Answer Back Access Code:
Auto Alternate Routing (AAR) Access Code:
Auto Route Selection (ARS) - Access Code 1:           Access Code 2:
Automatic Callback Activation:                       Deactivation:
Call Forwarding Activation Busy/DA:                 All:           Deactivation:
Call Park Access Code:
Call Pickup Access Code:
CAS Remote Hold/Answer Hold-Unhold Access Code:
CDR Account Code Access Code:
Change COR Access Code:
Change Coverage Access Code:

Data Origination Access Code:
Data Privacy Access Code:
Directed Call Pickup Access Code:
```

```
change feature-access-codes                               Page 2 of 5
                FEATURE ACCESS CODE (FAC)
Emergency Access to Attendant Access Code:
Enhanced EC500 Activation:                           Deactivation
Extended Call Fwd Activate Busy D/A                 All:           Deactivation
Extended Group Call Pickup Access Code:
Facility Test Calls Access Code:
Flash Access Code:
Group Control Restrict Activation:                   Deactivation:
Hunt Group Busy Activation:                         Deactivation:
ISDN Access Code:
Last Number Dialed Access Code:
Leave Word Calling Message Retrieval Lock:
Leave Word Calling Message Retrieval Unlock:
Leave Word Calling Send A Message:
Leave Word Calling Cancel A Message:
Malicious Call Trace Activation:                   Deactivation:
PASTE (Display PBX data on Phone) Access Code:
Personal Station Access (PSA) Associate Code:       Dissociate Code:
Per Call CPN Blocking Code Access Code:
Per Call CPN Unblocking Code Access Code:
Print Messages Access Code:
```

change feature-access-codes

Page 3 of 5

FEATURE ACCESS CODE (FAC)

Priority Calling Access Code:  
Program Access Code:  
Refresh Terminal Parameters Access Code:  
Remote Send All Calls Activation:           Deactivation:  
Self Station Display Activation:  
Send All Calls Activation:                   Deactivation:  
Station Security Code Change Access Code:  
Station User Admin of FBI Assign:                   Remove:  
Terminal Dial-Up Test Access Code:  
Terminal Translation Initialization Merge Code:           Separation Code:  
Transfer to Voice Mail Access Code:  
Trunk Answer Any Station Access Code:  
User Control Restrict Activation:           Deactivation:  
Voice Coverage Message Retrieval Access Code:  
Voice Principal Message Retrieval Access Code:  
Whisper Page Activation Access Code:

change feature-access-codes

Page 4 of 5

FEATURE ACCESS CODE (FAC)

Automatic Call Distribution Features

After Call Work Access Code:  
Assist Access Code:  
Auto-In Access Code:  
Aux Work Access Code:  
Login Access Code:  
Logout Access Code:  
Manual-in Access Code:  
Service Observing Listen Only Access Code:  
Service Observing Listen/Talk Access Code:

Remote Logout of Agent Access Code:

Call Vectoring/Prompting Features  
Converse Data Return Code:

change feature-access-codes

Page 5 of 5

FEATURE ACCESS CODE (FAC)  
Hospitality Features

Automatic Wakeup Call Access Code:  
Housekeeping Status (Client Room) Access Code:  
Housekeeping Status (Station) Access Code:  
Verify Wakeup Announcement Access Code:  
Voice Do Not Disturb Access Code:

## Class of service (switch)

---

You must make assignments to the Class of Service (COS) on the switch. A unique COS must be assigned to each of the following groups of users and equipment types on the switch:

- Front desk, attendant console, and housekeeping (COS 0)  
Telephones and attendant consoles used for check-in/check-out and Message Waiting Notification must have Console Permissions enabled in the COS. Designated stations used for housekeeping updates must have Console Permissions enabled in the COS.
- Guest rooms (COS 1)  
Guest rooms where Message Waiting Notification is used to light message lamps must have Client Room enabled in the COS.
- Office staff (COS 2)
- Guest services (COS 3)
- AUDIX voice ports (4)
- Data modules (COS 15)



### **CAUTION:**

*Do not assign Client Room COS of any of the following:*

- *Front desk telephones*
- *Housekeeping telephones*
- *Office staff telephones*
- *Guest services telephones*
- *DID telephone numbers (XDID and XDIDVIP station types)*

*If any of these are assigned to a Client Room COS, the name field on the station screen will not be saved in translations.*

*In addition, do not assign Console Permissions to any Class of Service except for the attendant consoles, backup telephones, and guest services telephones.*

Use the **change cos** command to administer the COS. The following screen shows an example COS using the COS numbers given in the previous list. Features assigned with the COS must be approved by the customer.

```

change cos
                                     Page 1 of 1
                                     CLASS OF SERVICE
0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
Auto Callback                       y n y y n n n n n n n n n n n n
Call Fwd-All Calls                   y n y y n y n n n n n n n n n n
Data Privacy                          n y n n y n n n n n n n n n n y
Priority Calling                       y n y y n n n n n n n n n n n n
Console Permissions                   y n y y n n n n n n n n n n n n
Off-hook Alert                        n y n n n n n n n n n n n n n n
Client Room                           n y n n n n n n n n n n n n n n
Restrict Call Fwd-Off Net             y y y y y y y y y y y y y y n
Call Forwarding Busy/DA              y n y y n n n n n n n n n n n n
Personal Station Access (PSA)        n n n n n n n n n n n n n n n n
Extended Forwarding All              n n n n n n n n n n n n n n n n
Extended Forwarding B/DA             n n n n n n n n n n n n n n n n
Trk-to-Trk Transfer Override         n n n n n n n n n n n n n n n n
QSIG Call Offer Originations         n n n n n n n n n n n n n n n n
Automatic Exclusion                   n n n n n n n n n n n n n n n n
    
```

## **Class of restriction (switch)**

---

You must create several Classes of Restriction (COR) to separate features and services among the different groups of users and equipment. The COR also controls calling permissions between CORs. That is, you can restrict one group of users from calling another group through the COR. The following is a list of these general COR groups (and the COR number used in the screen examples):

- Guest rooms (COR 1)
- Front desk, attendant console, and housekeeping (COR 2; similar setup as COR 1)
- Office staff (COR 3; similar setup as COR 1)
- Guest services (room service, kitchen, and so on) (COR 4)
- Trunk groups (COR 20 and COR 21)
- Vectors (COR 30)
- INTUITY AUDIX voice ports and hunt groups (COR 35; similar setup as COR 30)
- Netcon, processor interface, and data modules (COR 50).

The following screens show typical COR assignments for each of the groupings. Use the **change cor** command to administer the CORs. All levels of restriction must be agreed to by the customer.

This is an example COR for the guest rooms, front desk, housekeeping, and the office staff.

change cor 1 Page 1 of 4

CLASS OF RESTRICTION

COR Number: 1  
 COR Description: GUEST ROOMS

FRL: 7 APLT? y  
 Can Be Service Observed? n Calling Party Restriction: none  
 Can Be A Service Observer? n Called Party Restriction: none  
 Time of Day Chart: 1 Forced Entry of Account Codes? n  
 Priority Queuing? n Direct Agent Calling? n  
 Restriction Override: all Facility Access Trunk Test? n  
 Restricted Call List? n Can Change Coverage? n

Access to MCT? y Fully Restricted Service? n  
 Group II Category For MFC: 7  
 Send ANI for MFE? n  
 MF ANI Prefix: Automatic Charge Display? n  
 Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n  
Can Be Picked Up By Directed Call Pickup? n  
Can Use Directed Call Pickup? n  
 Omit Extension/Room Display: n Group Controlled Restriction: inactive

change cor 1 Page 2 of 4

CLASS OF RESTRICTION

MF Incoming Call Trace? n  
 Brazil Collect Call Blocking? n  
 Block Transfer Display? n  
 Remote Logout of Agent? n

change cor 1 Page 3 of 4

CLASS OF RESTRICTION

CALLING PERMISSION (Enter "y" to grant permission to call specified COR)

0? y	12? y	24? y	36? y	48? y	60? y	72? y	84? y
1? y	13? y	25? y	37? y	49? y	61? y	73? y	85? y
2? y	14? y	26? y	38? y	50? n	62? y	74? y	86? y
3? y	15? y	27? y	39? y	51? y	63? y	75? y	87? y
4? y	16? y	28? y	40? y	52? y	64? y	76? y	88? y
5? y	17? y	29? y	41? y	53? y	65? y	77? y	89? y
6? y	18? y	30? y	42? y	54? y	66? y	78? y	90? y
7? y	19? y	31? y	43? y	55? y	67? y	79? y	91? y
8? y	20? y	32? y	44? y	56? y	68? y	80? y	92? y
9? y	21? y	33? y	45? y	57? y	69? y	81? y	93? y
10? y	22? y	34? y	46? y	58? y	70? y	82? y	94? y
11? y	23? y	35? y	47? y	59? y	71? y	83? y	95? y

This is an example COR for the guest services.

change cor 4 Page 1 of 4

CLASS OF RESTRICTION

COR Number: 4  
COR Description: GUEST SERVICES

FRL: 3 APLT? y  
Can Be Service Observed? n Calling Party Restriction: none  
Can Be A Service Observer? n Called Party Restriction: none  
Time of Day Chart: 1 Forced Entry of Account Codes? n  
Priority Queuing? n Direct Agent Calling? n  
Restriction Override: all Facility Access Trunk Test? n  
Restricted Call List? n Can Change Coverage? n

Access to MCT? y Fully Restricted Service? n  
Group II Category For MFC: 7  
Send ANI for MFE? n  
MF ANI Prefix: Automatic Charge Display? n  
Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n  
Can Be Picked Up By Directed Call Pickup? n  
Can Use Directed Call Pickup? n  
Omit Extension/Room Display: n Group Controlled Restriction: inactive

change cor 4 Page 2 of 4

CLASS OF RESTRICTION

MF Incoming Call Trace? n  
Brazil Collect Call Blocking? n  
Block Transfer Display? n  
Remote Logout of Agent? n

change cor 4 Page 3 of 4

CLASS OF RESTRICTION

CALLING PERMISSION (Enter "y" to grant permission to call specified COR)

0? y	12? y	24? y	36? y	48? y	60? y	72? y	84? y
1? y	13? y	25? y	37? y	49? y	61? y	73? y	85? y
2? y	14? y	26? y	38? y	50? n	62? y	74? y	86? y
3? y	15? y	27? y	39? y	51? y	63? y	75? y	87? y
4? y	16? y	28? y	40? y	52? y	64? y	76? y	88? y
5? y	17? y	29? y	41? y	53? y	65? y	77? y	89? y
6? y	18? y	30? y	42? y	54? y	66? y	78? y	90? y
7? y	19? y	31? y	43? y	55? y	67? y	79? y	91? y
8? y	20? y	32? y	44? y	56? y	68? y	80? y	92? y
9? y	21? y	33? y	45? y	57? y	69? y	81? y	93? y
10? y	22? y	34? y	46? y	58? y	70? y	82? y	94? y
11? y	23? y	35? y	47? y	59? y	71? y	83? y	95? y

This is an example COR for an outgoing trunk group.

```

change cor 20                                     Page 1 of 4
                                CLASS OF RESTRICTION

COR Number: 20
COR Description: OUTGOING TRUNK GROUP

FRL: 0                                           APLT? y
Can Be Service Observed? n                       Calling Party Restriction: none
Can Be A Service Observer? n                     Called Party Restriction: none
Time of Day Chart: 1                             Forced Entry of Account Codes? n
Priority Queuing? n                               Direct Agent Calling? n
Restriction Override: all                         Facility Access Trunk Test? n
Restricted Call List? n                           Can Change Coverage? n

Access to MCT? y                                 Fully Restricted Service? n
Group II Category For MFC: 7
Send ANI for MFE? n
MF ANI Prefix:                                  Automatic Charge Display? n
Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n
Can Be Picked Up By Directed Call Pickup? n
Can Use Directed Call Pickup? n
Omit Extension/Room Display: n                   Group Controlled Restriction: inactive
    
```

```

change cor 20                                     Page 2 of 4
                                CLASS OF RESTRICTION

MF Incoming Call Trace? n
Brazil Collect Call Blocking? n
Block Transfer Display? n
Remote Logout of Agent? n
    
```

```

change cor 20                                     Page 3 of 4
                                CLASS OF RESTRICTION

CALLING PERMISSION (Enter "y" to grant permission to call specified COR)

0? y   12? y   24? y   36? y   48? y   60? y   72? y   84? y
1? y   13? y   25? y   37? y   49? y   61? y   73? y   85? y
2? y   14? y   26? y   38? y   50? n   62? y   74? y   86? y
3? y   15? y   27? y   39? y   51? y   63? y   75? y   87? y
4? y   16? y   28? y   40? y   52? y   64? y   76? y   88? y
5? y   17? y   29? y   41? y   53? y   65? y   77? y   89? y
6? y   18? y   30? y   42? y   54? y   66? y   78? y   90? y
7? y   19? y   31? y   43? y   55? y   67? y   79? y   91? y
8? y   20? y   32? y   44? y   56? y   68? y   80? y   92? y
9? y   21? y   33? y   45? y   57? y   69? y   81? y   93? y
10? y  22? y   34? y   46? y   58? y   70? y   82? y   94? y
11? y  23? y   35? y   47? y   59? y   71? y   83? y   95? y
    
```

This is an example COR for an incoming trunk group.

```
change cor 21                                     Page 1 of 4
                                     CLASS OF RESTRICTION
COR Number: 21
COR Description: INCOMING TRUNK GROUP
FRL: 0                                           APLT? y
Can Be Service Observed? n                       Calling Party Restriction: outward
Can Be A Service Observer? n                     Called Party Restriction: none
Time of Day Chart: 1                             Forced Entry of Account Codes? n
Priority Queuing? n                               Direct Agent Calling? n
Restriction Override: all                         Facility Access Trunk Test? n
Restricted Call List? n                           Can Change Coverage? n
Access to MCT? y                                 Fully Restricted Service? n
Group II Category For MFC: 7
Send ANI for MFE? n
MF ANI Prefix:                                  Automatic Charge Display? n
Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n
Can Be Picked Up By Directed Call Pickup? n
Can Use Directed Call Pickup? n
Omit Extension/Room Display: n                   Group Controlled Restriction: inactive
```

```
change cor 21                                     Page 2 of 4
                                     CLASS OF RESTRICTION
MF Incoming Call Trace? n
Brazil Collect Call Blocking? n
Block Transfer Display? n
Remote Logout of Agent? n
```

```
change cor 21                                     Page 3 of 4
                                     CLASS OF RESTRICTION
CALLING PERMISSION (Enter "y" to grant permission to call specified COR)
0? y  12? y  24? y  36? y  48? y  60? y  72? y  84? y
1? y  13? y  25? y  37? y  49? y  61? y  73? y  85? y
2? y  14? y  26? y  38? y  50? n  62? y  74? y  86? y
3? y  15? y  27? y  39? y  51? y  63? y  75? y  87? y
4? y  16? y  28? y  40? y  52? y  64? y  76? y  88? y
5? y  17? y  29? y  41? y  53? y  65? y  77? y  89? y
6? y  18? y  30? y  42? y  54? y  66? y  78? y  90? y
7? y  19? y  31? y  43? y  55? y  67? y  79? y  91? y
8? y  20? y  32? y  44? y  56? y  68? y  80? y  92? y
9? y  21? y  33? y  45? y  57? y  69? y  81? y  93? y
10? y 22? y  34? y  46? y  58? y  70? y  82? y  94? y
11? y 23? y  35? y  47? y  59? y  71? y  83? y  95? y
```

This is an example COR for the Call Vectoring procedures, INTUITY AUDIX voice ports, and INTUITY AUDIX hunt groups. For the Calling Party Restriction field, use **outward** if outcalling and faxes are not being used.

change cor 30 Page 1 of 4

CLASS OF RESTRICTION

COR Number: 30  
 COR Description: CALL VECTORING

FRL: 1 APLT? y  
 Can Be Service Observed? n **Calling Party Restriction: none**  
 Can Be A Service Observer? n Called Party Restriction: none  
 Time of Day Chart: 1 Forced Entry of Account Codes? n  
 Priority Queuing? n Direct Agent Calling? n  
 Restriction Override: all Facility Access Trunk Test? n  
 Restricted Call List? n Can Change Coverage? n

Access to MCT? y Fully Restricted Service? n  
 Group II Category For MFC: 7  
 Send ANI for MFE? n  
 MF ANI Prefix: Automatic Charge Display? n  
 Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n  
Can Be Picked Up By Directed Call Pickup? n  
Can Use Directed Call Pickup? n  
 Omit Extension/Room Display: n Group Controlled Restriction: inactive

change cor 30 Page 2 of 4

CLASS OF RESTRICTION

MF Incoming Call Trace? n  
 Brazil Collect Call Blocking? n  
 Block Transfer Display? n  
 Remote Logout of Agent? n

change cor 30 Page 3 of 4

CLASS OF RESTRICTION

CALLING PERMISSION (Enter "y" to grant permission to call specified COR)

0? y	12? y	24? y	36? y	48? y	60? y	72? y	84? y
1? y	13? y	25? y	37? y	49? y	61? y	73? y	85? y
2? y	14? y	26? y	38? y	50? n	62? y	74? y	86? y
3? y	15? y	27? y	39? y	51? y	63? y	75? y	87? y
4? y	16? y	28? y	40? y	52? y	64? y	76? y	88? y
5? y	17? y	29? y	41? y	53? y	65? y	77? y	89? y
6? y	18? y	30? y	42? y	54? y	66? y	78? y	90? y
7? y	19? y	31? y	43? y	55? y	67? y	79? y	91? y
8? y	20? n	32? y	44? y	56? y	68? y	80? y	92? y
9? y	21? n	33? y	45? y	57? y	69? y	81? y	93? y
10? y	22? y	34? y	46? y	58? y	70? y	82? y	94? y
11? y	23? y	35? y	47? y	59? y	71? y	83? y	95? y

This is an example COR for the netcon, processor interface link, and data modules.

```
change cor 50 Page 1 of 4
                CLASS OF RESTRICTION
                COR Number: 50
                COR Description: NETCON/PROC LINK/DATA MODULES
                FRL: 7 APLT? y
                Can Be Service Observed? n Calling Party Restriction: none
                Can Be A Service Observer? n Called Party Restriction: none
                Time of Day Chart: 1 Forced Entry of Account Codes? n
                Priority Queuing? n Direct Agent Calling? n
                Restriction Override: all Facility Access Trunk Test? n
                Restricted Call List? n Can Change Coverage? n
                Access to MCT? y Fully Restricted Service? n
                Group II Category For MFC: 7
                Send ANI for MFE? n
                MF ANI Prefix: Automatic Charge Display? n
                Hear System Music on Hold? y PASTE (Display PBX Data on Phone)? n
                Can Be Picked Up By Directed Call Pickup? n
                Can Use Directed Call Pickup? n
                Omit Extension/Room Display: n Group Controlled Restriction: inactive
```

```
change cor 50 Page 2 of 4
                CLASS OF RESTRICTION
                MF Incoming Call Trace? n
                Brazil Collect Call Blocking? n
                Block Transfer Display? n
                Remote Logout of Agent? n
```

```
change cor 50 Page 3 of 4
                CLASS OF RESTRICTION
                CALLING PERMISSION (Enter "y" to grant permission to call specified COR)
                0? y 12? y 24? y 36? y 48? y 60? y 72? y 84? y
                1? y 13? y 25? y 37? y 49? y 61? y 73? y 85? y
                2? y 14? y 26? y 38? y 50? y 62? y 74? y 86? y
                3? y 15? y 27? y 39? y 51? y 63? y 75? y 87? y
                4? y 16? y 28? y 40? y 52? y 64? y 76? y 88? y
                5? y 17? y 29? y 41? y 53? y 65? y 77? y 89? y
                6? y 18? y 30? y 42? y 54? y 66? y 78? y 90? y
                7? y 19? y 31? y 43? y 55? y 67? y 79? y 91? y
                8? y 20? y 32? y 44? y 56? y 68? y 80? y 92? y
                9? y 21? y 33? y 45? y 57? y 69? y 81? y 93? y
                10? y 22? y 34? y 46? y 58? y 70? y 82? y 94? y
                11? y 23? y 35? y 47? y 59? y 71? y 83? y 95? y
```

## Class of service (INTUITY)

Use the following screens to administer the INTUITY COS for the guest rooms and the office staff INTUITY AUDIX subscribers. To access the INTUITY COS screens, use the **AUDIX Administration > change cos** command. On Page 1, the Type field must be set to **call-answer**. See *INTUITY Messaging Solutions Administration* for more information about the other options on these screens.

```

change cos 0                                     Page 1 of 2
                                     CLASS OF SERVICE

Name: class00          COS Number: 0          Modified? y
Addressing Format: extension

System Multilingual is ON          Login Announcement Set: System
Call Answer Language Choice? n    Call Answer Primary Annc. Set: System
Call Answer Secondary Annc. Set: System

PERMISSIONS
Type: call-answer          Announcement Control? y          Outcalling? n
Priority Messages? n      Broadcast: none          IMAPI Access? y
IMAPI Message Transfer? n    Fax Creation? n          Trusted Server Access? y
    
```

If Fax Creation was **y** on Page 1, change the following on Page 2:

- Voice Mail Message, Maximum Length — Enter **1200**.
- Call Answer Message, Maximum Length — Enter **1200**.
- Mailbox Size, Maximum — Enter **4800**.

```

change cos 0                                     Page 2 of 2
                                     CLASS OF SERVICE

INCOMING MAILBOX          Order: fifo          Category Order: nuo
Retention Times (days),  New: 10          Old: 10          Unopened: 10

OUTGOING MAILBOX          Order: fifo          Category Order: unfda
Retention Times(days),File Cab: 10          Delivered/Nondeliverable: 5

Voice Mail Message (seconds), Maximum Length: 300 Minimum Needed: 32
Call Answer Message (seconds), Maximum Length: 120 Minimum Needed: 8

End of Message Warning Time (seconds):

Maximum Mailing Lists: 25          Total Entries in all Lists: 250
Mailbox Size (seconds), Maximum: 1200          Minimum Guarantee: 0
    
```

## System parameters (INTUITY)

Use the **AUDIX Administration > change system-parameters features** command to assign the INTUITY system parameters. The parameters will vary according to the customer's needs. See *INTUITY Messaging Solutions Administration* for more information about other options on these screens.

```
change system-parameters features                               Page 1 of 4
                        SYSTEM-PARAMETERS FEATURES

LOG-IN PARAMETERS
  Login Retries: 3                      Consecutive Invalid Attempts: 18
  System Guest Password:                Minimum Password Length: 6

SUBSCRIBER PASSWORD AGING LIMITS (DAYS)
  Password Expiration Interval: 0      (0 for no password aging)
  Minimum Age Before Changes: 0
  Expiration Warning: 0                (0 for no warning)

INPUT TIME LIMITS (SECONDS)
  Normal: 60      Full Mailbox Timeout: 5      Wait (*W): 180
  Between Digits at Auto-attendant or Standalone Menu: 3 (3-12)

DISCONNECT OPTIONS
  Quick Silence Disconnect? n          Silence Limit? 30 (5-30 seconds)
```

```
change system-parameters features                               Page 2 of 4
                        SYSTEM-PARAMETERS FEATURES

MISCELLANEOUS PARAMETETERS
  Broadcast Mailbox Extension:
  System Prime Time, Start: 08:00      End: 17:00d Length: 6
  Increment(l/s), Rewind: s           Advance: s

FEATURE ACTIVATION
  Traffic Collection? y
  Name Record by Subscriber? y
  Multiple Personal Greetings? y
  End of Message Warning? y           Warning Time (seconds): 15
  Priority on Call Answer? n
  Call Answer Disable? n
  Address Before Record? n

MULTIMEDIA PARAMETERS
  Fax Print Destination Prefix:
  Text to Speech Conversion: none
```

On Page 3 of the INTUITY system parameters, administer the following:

- **Transfer Type** — Enter **enhanced\_cover\_0**. This will restrict the voice ports from calling trunk access codes assigned to the trunk groups.
- **Transfer Restriction** — It is recommended that you enter **subscribers** to allow call transfers out of INTUITY AUDIX for calls to office staff subscribers only, and not calls to guest room telephones. Only technical support personnel can change this field to **digits**, and only when the customer has signed a letter to that effect.
- **Covering Extension** — Enter the Listed Directory Number extension used for attendant-seeking calls (See [page 130](#)). If the **Covering Extension** is not administered, callers that “zero out” from the voice messaging system will hear “Operator not assigned,” and the caller cannot receive assistance.

```
change system-parameters features                                     Page 3 of 4
                                SYSTEM-PARAMETERS FEATURES
CALL TRANSFER OUT OF AUDIX
  Transfer Type: enhanced_cover_0          Transfer Restriction: subscribers
  Covering Extension: 2000

ANNOUNCEMENT SETS
  System: us-eng                          Administrative:

RESCHEDULING INCREMENTS FOR UNSUCCESSFUL MESSAGE DELIVERY
Incr 1: 0 days 0 hrs 5 mins      Incr 2: 0 days 0 hrs 15 mins
Incr 3: 0 days 0 hrs 30 mins     Incr 4: 0 days 1 hrs 0 mins
Incr 5: 0 days 2 hrs 0 mins      Incr 6: 0 days 6 hrs 0 mins
Incr 7: 1 days 0 hrs 0 mins      Incr 8: 2 days 0 hrs 0 mins
Incr 9: 7 days 0 hrs 0 mins      Incr10: 14 days 0 hrs 0 mins
```

```
change system-parameters features                                     Page 4 of 4
                                SYSTEM-PARAMETERS FEATURES

NETWORKING PARAMETETERS

  Automatic Deletion of Non-administered Remote Subscribers
  Days without Activity: 0          Even If on a Mailing List? n
```

## Fax parameters (switch and INTUITY)

Integrating fax machines with the INTUITY system requires special setup on the switch. Many properties have their fax machines connected to a dedicated central office (CO) trunk. To integrate the fax machine with the functionality of the INTUITY fax services, you should do the following to help set up the best solution possible:

- Connect the dedicated CO fax line to a CO trunk circuit on the switch.
- Translate the CO trunk to have an Incoming Destination of some previously-unassigned extension. See [“Trunk groups \(switch\)” on page 168](#) for more information.
- Route calls intended for the CO trunk and the extension to the INTUITY hunt group. See [“Hunt groups for voice ports \(switch\)” on page 243](#) for more information.
- On the INTUITY system, the incoming destination extension must be set up as DNIS service LGfax. See [“Services to phone number mapping \(INTUITY\)” on page 249](#) for more information.
- The fax machine must be connected to an analog port on the switch.
- To send a fax from the fax machine, hotel staff and guests must remember to dial a prefix (typically 9) to gain access to a CO line. All preprogrammed numbers must be updated with this new dialing plan.

On the INTUITY, the fax machine extension must be administered as the Guest Services Fax Machine number. If fax messaging is installed on the INTUITY system, use the following screens to enable fax messaging options. See *INTUITY Lodging Administration* and *INTUITY Messaging Solutions Administration* for more information about using the options on these screens.

- Use the **Lodging Administration > FAX Add-on Administration > FAX System Parameters Administration** command to administer the fax system parameters.

```
+-----+
+       FAX System Parameter Administration       +
+-----+
          Allow delivery of FAX to any number?: Yes
Maximum number of digits allowed in the FAX number:15
          Maximum number of tries to deliver a FAX:5
Maximum number of channels to use for FAX delivery:2
          First retry interval (min):5
          Second retry interval (min):10
          Subsequent retries interval (min):30
          String of digits to prefix to the FAX number:*99
Use prefix only if entered number is greater than:6 digits
          Guest services FAX machine:810
+-----+
```



## Abbreviated Dialing lists (switch)

For access to a common set of telephone numbers, it is good to set up an Abbreviated Dialing system list. You can then program several telephones to use the system list, and if the extensions ever change for those services, you only have to change the extension in the system list. The following example shows a five-member system list with entries for the AUDIX extension and the Guest Voice Mail extension.

```
add abbreviated-dialing system                               Page 1 of 1
      ABBREVIATED DIALING LIST

      System List
      Size (multiple of 5): 5                               Privileged? n
DIAL CODE
01: 699
02: 710
03:
04:
05:
```

You can also set up a group list to use with fixed access buttons on the guest room telephones. When you want to change the same button for all telephones, you change the assignment in the group list.

```
add abbreviated-dialing group 1                             Page 1 of 1
      ABBREVIATED DIALING LIST

      Group List: 1
      Size (multiple of 5): 10                             Program Ext: 195   Privileged? n
DIAL CODE
01: 710
02: 195
03: 196
04: 204
05:
06:
07:
08:
09:
10:
```

## Listed Directory Numbers (switch)

---

Use the **change listed-directory-number** command to assign Listed Directory Numbers (LDNs) to the switch. These LDNs are usually the published numbers for the property and terminate at the attendant console.

```
change listed-directory-number                               Page 1 of 2
LISTED DIRECTORY NUMBERS
Night Destination: 195

  Ext   Name      TN
1: 2000
2:
3:
4:
5:
6:
7:
8:
```

## Attendant console (switch)

Use the **add attendant** command to administer an attendant console. For most installations, there will only be one attendant console.

On Page 1:

- Type — Enter **console**.
- Extension — Enter a valid extension in the dial plan.
- Console Type — Enter **principal**.
- Port — Enter the equipment location of the digital port connected to the console.
- Name — Enter **Attendant**.
- COR — Use an appropriate COR.
- COS — Use a COS that has Console Permissions.
- Select Buttons — Administer trunk group and hundreds group select buttons as needed.

```
add attendant 1                                     Page 1 of 3
                                         ATTENDANT CONSOLE 1

      Type: console           Name: Attendant
      Extension: 3000         Group: 1           Auto Answer: none
      Console Type: principal  TN: 1             Data Module? n
      Port: 01A0301          COR: 2           Disp Client Redir? y
                                         Display Language: english
                                         H.320 Conversion? n

DIRECT TRUNK GROUP SELECT BUTTON ASSIGNMENTS (Trunk Access Codes)
Local Remote Local Remote Local Remote
1:           5:           9:
2:           6:           10:
3:           7:           11:
4:           8:           12:

HUNDREDS SELECT BUTTON ASSIGNMENTS
1:           5:           9:           13:           17:
2:           6:           10:          14:           18:
3:           7:           11:          15:           19:
4:           8:           12:          16:           20:
```

See the following sections for assigning feature buttons on Pages 2 and 3.

## Attendant console button layouts (switch)

The attendant console feature buttons are assigned using the **change attendant 1** command. The recommended button layout differs depending on whether or not the property has voice messaging, a PMS, or call accounting.




**NOTE:**

The examples in this section are based on punch-out button labels used with older consoles that are no longer being sold as new. The button labels for the newer consoles must be typed or hand-written on the button label sheets.


For information on installing the attendant console, see the switch installation documents.

Figure 31 shows the recommended button layout if you have voice messaging. The shaded buttons are different from the ones suggested in Figure 32. Do not translate the PMS Alarm or Call Accounting System (CAS) Alarm buttons if there is no PMS or call accounting system.



**Figure 31. Console buttons with voice messaging**

Figure 32 shows the recommended button layout if you do not have voice messaging. The shaded buttons are different from the ones suggested in Figure 31. Do not translate the PMS Alarm or CAS Alarm buttons if there is no PMS or call accounting system.



**Figure 32. Console buttons without voice messaging**

The buttons shown in Figure 31 and Figure 32 are administered on Page 2 of the Attendant Console screen using the following button types (button labels shown in parentheses):

- **split** (Split; this button assignment cannot be changed)
- **split-swap** (Split Swap)
- **busy-ind** or **abrvt-dial** (Voice Mail; with the voice mail extension programmed)
- **busy-ind** or **abrvt-dial** (VM Passwd; with the master voice mail password programmed)
- **mwn-act** (MW Act; if the system does not have voice mail)
- **mwn-deact** (MW Deact; if the system does not have voice mail)
- **did-view** (DID View) (the Automatic Selection of DID Numbers feature must be enabled; see [page 169](#))

- **hold** (Hold)
- **check-in** (Check In)
- **check-out** (Check Out)
- **occ-rooms** (Occupd Rooms)
- **maid-stat** (Maid Status)
- **directory** (Integ Dirctry)
- **trk-id** (Trunk ID)
- **auto-wkup** (Auto Wakeup)
- **vip-wakeup** (VIP Wakeup)
- **vip-retry** (VIP Retry)
- **ext-dn-dst** (DND Ext)
- **crss-alert** (Crisis Alert)
- **atd-qtime** (Queue Time)
- **forced-rel** (Forced Release; this button assignment cannot be changed)
- **pms-alarm** (PMS Alarm)
- **cdr1-alm** (CAS Alarm)
- **aut-msg-wt** (Failed Wakeup; administer the extension where failed Automatic Wakeup Calls are reported)
- **night-serv** (Night)
- **pos-busy** (Pos Busy)

There are other buttons you may want to add to the attendant console. If preprinted labels are not available for these features, you must create them on-site. These other buttons include the following:


- **abrv-dial** (Controlled Restrictions assigned as an Abbreviated Dialing button). The Abbreviated Dialing button emulates dialing the feature access code followed by the desired restriction code, such as Outward Restriction.

For example, if the User Controlled Restriction Activate feature access code is \*27, assign an Abbreviated Dialing button that dials \*271. This automatically dials the feature access code and the code (1) for Outward Restriction. All the customer has to do now is enter the room number where the restriction is to be applied. Another button can be assigned for the deactivate code.

- **pr-awu-alm** (Automatic Wakeup printer alarm)
- **pr-pms-alm** (PMS printer alarm)

- **pr-sys-alm** (System printer alarm)
- **vip-chkin** (VIP Check In) (the Custom Selection of DID Numbers feature must be enabled; see [page 169](#))
- **did-remove** (DID Remove) (the Automatic Selection of DID Numbers feature must be enabled; see [page 169](#))

[Figure 33](#) shows the recommended button layout for the eight display buttons. These buttons are assigned on Page 3 of the Attendant Console screen.



**Figure 33. Console buttons for display features**

The display buttons are administered with the following button types (button labels shown in parentheses):

- **normal** (Normal Mode)
- **inspect** (Inspect Mode)
- **cov-msg-rt** (Cover Msg Rt)
- **next** (Next)
- **delete-msg** (Delete)
- **call-disp** (Call)
- **date-time** (Date Time)
- **timer** (Timer)

## Attendant Backup (switch)

Use the **change console-parameters** command to administer the Attendant Backup parameters. In addition, you must assign a  button to the backup telephones. See [page 142](#) for more information.

On Page 1, administer the following:

- **Calls in Queue Warning** — This level should be set to **1** if the customer uses the backup telephones for most call handling. If the customer uses the attendant console for most call handling, you can set this level to a higher threshold. The customer may have to experiment with this setting to find a good working queue level.
- **Ext Alert Port (TAAS)** — This field must have an analog circuit equipment location administered even if you do not have external ringing equipment connected to the circuit. This is required to allow the Attendant Backup feature to work properly.
- **Backup Alerting** — Enter **y**. If Tenant Partitioning is enabled on the switch, the Backup Alerting option cannot be used.

```
change console-parameters                               Page 1 of 4
                CONSOLE PARAMETERS

Attendant Group Name: OPERATOR
                  COS: 1                                COR: 1
Calls in Queue Warning: 1                            Attendant Lockout? y
Ext Alert Port (TAAS): 01A1216
                  CAS: none

IAS (Branch)? n          Night Service Act. Ext.:
IAS Att. access Code:   IAS Tie Trunk Group No.:
Backup Alerting? y    Alternate FRL Station:
Attendant Vectoring VDN: DID-LDN Only to LDN Night Ext? n
```

On Page 2, administer the following:

- **No Answer Timeout** — This controls when ringing at the console will stop after a call is waiting in queue. When the timeout occurs, the console stops ringing, but the call can still be answered. A good value to begin with is **10**.
- **Alerting** — This controls the timeout limit before the console automatically goes into Night mode and Position Busy when calls are not answered. This is a good feature to administer in the situation in which the attendant takes a break or leaves at the end of the day and forgets to put the console into Night service. For example, if the **No Answer Timeout** field is set to **10** seconds, and the **Alerting** field is set to **10** seconds, the following occurs: a call rings at the console; after 10 seconds the console ringing shuts off; the call continues to queue for 10 seconds; then the console goes into Night mode and Position Busy. The call can now be answered from a backup telephone.

```
change console-parameters                               Page 2 of 4
                CONSOLE PARAMETERS

TIMING
Time Reminder on Hold (sec): 30           Return Call Timeout (sec): 60
Time in Queue Warning (sec): 15

INCOMING CALL REMINDERS
  No Answer Timeout (sec): 10           Alerting (sec): 10
                Secondary Alert on Held Reminder Calls? y

ABBREVIATED DIALING
List1:                               List2:           List3: system
                SAC Notification? n

                COMMON SHARED EXTENSIONS
Starting Extension: 670           Count: 3
```

On Page 3, set the console incoming call queue priority. This defines which types of calls receive priority over other calls. It is recommended that you set Emergency Access to the highest priority (**1** is the highest priority, to a low of **13**). After that, it is up to the customer to define how calls are prioritized. The following screen shows the default settings.

```
change console-parameters                               Page 3 of 4
                                           CONSOLE PARAMETERS

QUEUE PRIORITIES

    Emergency Access: 1
    Assistance Call: 2
    CO Call: 2
    DID to Attendant: 2
    Tie Call: 2
    Redirected DID Call: 2
    Redirected Call: 2
    Return Call: 2
    Serial Call: 2
    Individual Attendant Access: 2
    Interpositional: 2
    VIP Wakeup Reminder Call: 2
    Miscellaneous Call: 2

Call-Type Ordering Within Priority Levels? n
```

On page 4, set the tenant partitions for multiple consoles.

```
change console-parameters                               Page 4 of 4
                                           CONSOLE PARAMETERS

ASSIGNED MEMBERS ( Installed attendant consoles )
    Type      Grp  TN      Type      Grp  TN
1: principal  1   1       9:
2:
3:
4:
5:
6:
7:
8:
9:
10:
11:
12:
13:
14:
15:
16:
```

## Office staff, front desk, and guest services telephones (switch)

You must assign the telephones for the office staff, the front desk, guest room services, and other telephones located on the property. Use the **add station** command to administer these telephones. Depending on the model of the telephone, the screens show different fields. This example shows the model 6424 used as an attendant backup telephone.

**⇒ NOTE:** When the INTUITY Lodging Call Accounting package is first installed, the set of extensions and trunks administered on the switch is coordinated with Homisco. If extensions and trunks are added at a later date, Homisco must be notified so changes can be added to the call accounting package.

```
add station 195                                     Page 1 of 5
                                                    STATION
Extension: 195                                     Lock Messages? n      BCC: 0
Type: 6424D+                                       Security Code:         TN: 1
Port: 01A0201                                    Coverage Path 1: 1    COR: 2
Name: FRONT DESK                                Coverage Path 2:      COS: 0
                                                    Hunt-to Station:

STATION OPTIONS
  Loss Group: 2                                     Personalized Ringing Pattern: 1
  Data Option: none                               Message Lamp Ext: 195
  Speakerphone: 2-way                             Mute Button Enabled? y
  Display Language: english                       Expansion Module? n

                                                    Media Complex Ext:
                                                    IP SoftPhone? n
```

```
add station 195                                     Page 2 of 5
                                                    STATION
FEATURE OPTIONS
  LWC Reception: audix                            Auto Select Any Idle Appearance? n
  LWC Activation? n                               Coverage Msg Retrieval? y
  LWC Log External Calls? n                       Auto Answer: none
  CDR Privacy? n                                 Data Restriction? n
  Redirect Notification? y                       Idle Appearance Preference? n
  Per Button Ring Control? n                     Restrict Last Appearance? y
  Bridged Call Alerting? n
  Active Station Ringing: single

  H.320 Conversion? n                            Per Station CPN - Send Calling Number?

  MWI Served User Type? n                       Audible Message Waiting? n
                                                    Display Client Redirection? n
                                                    Select Last Used Appearance? n
                                                    Coverage After Forwarding? n

Emergency Location Ext:
```

add station 195

Page 3 of 5

STATION

SITE DATA

Room:	Headset? n
Jack:	Speaker? n
Cable:	Mounting: d
Floor:	Cord Length: 0
Building:	Set Color:

ABBREVIATED DIALING

List1: personal 1	List2:	List3: system
-------------------	--------	---------------

BUTTON ASSIGNMENTS

1: call-appr	5: autodial	Number:
2: call-appr	6: autodial	Number:
3: call-appr	7: autodial	Number:
4: call-appr	8: autodial	Number:

add station 195

Page 4 of 5

STATION

FEATURE BUTTON ASSIGNMENTS

9: atd-qcalls  
10: vip-chkin  
11: did-remove  
12: aut-msg-wt Ext: 699  
13: auto-wkup  
14: ext-dn-dst  
15: check-in  
16: check-out  
17: did-view  
18: mwn-act  
19: mwn-deact  
20:  
21: pms-alarm  
22: cdrl-alm  
23: aut-msg-wt Ext: 399  
24: autodial Number: \*271

add station 195

STATION

Page 5 of 5

SOFTKEY BUTTON ASSIGNMENTS

- 1: directory
- 2: drop
- 3: int-aut-an
- 4: timer
- 5: priority
- 6: auto-cback
- 7: abr-prog
- 8: abr-spchar Char: ~p
- 9: lwc-store
- 10: ringer-off
- 11: btn-view
- 12: admin

## **Backup telephone button layouts (switch)**

---

The telephones used for the Attendant Backup feature should have several of the same buttons you would assign to the attendant console. These are assigned using the **change station XXXX** command, where the **XXXX** is the extension number. The following is a list of the recommended feature buttons:

- Attendant Queue Calls (**atd-qcalls**) (this button is required for the Attendant Backup feature)
- Attendant Call Pickup (this is an **autodial** button that is programmed with the TAAS feature access code; the TAAS code is used to answer the Attendant Backup calls)
- Attendant time in queue (**atd-qtime**)
- Do Not Disturb - Extension (**ext-dn-dst**)
- Automatic Wakeup (**auto-wkup**)
- **aut-msg-wt** (administer the extension where failed Automatic Wakeup Calls are reported)
- Night Service (**night-serv**) (only one backup telephone can have a Night Service button)
- Ringer Cutoff (**ringer-off**)
- Check-In (**check-in**)
- Check-Out (**check-out**)
- VIP Check-In (**vip-chkin**)
- DID View (**did-view**) (the Automatic or Custom Selection of DID Numbers features must be enabled; see [page 169](#))
- DID Remove (**did-remove**) (the Automatic or Custom Selection of DID Numbers features must be enabled; see [page 169](#))
- Message Waiting Activation (**mwn-act**; if the system does not have voice mail)
- Message Waiting Deactivation (**mwn-deact**; if the system does not have voice mail)
- Busy Indication for the attendant console extension and any other backup telephones (**busy-ind**)
- PMS Alarm (**pms-alarm**)
- CAS Alarm (**cdr1-alarm**)

In addition, make sure that the backup telephone's class of service has console permissions assigned (**change cos**).

[Figure 34](#), [Figure 35](#), and [Figure 36](#) show a typical setup if you had three telephones used as backups to the attendant console. The recommended primary backup telephone is the model 6424. The second and third backup telephones could be a model 6408. In this example, actual extension numbers are not given. Extension 1 represents the published front desk telephone number. Extensions 2 and 3 are nonpublished numbers known only to the hotel office staff. In this example, there are call appearances or bridged appearances of Extension 1 on all telephones, plus each telephone has at least one other extension that can be accessed as needed. With this arrangement, it makes it easy for front desk staff to answer a call at one telephone, put the call on hold, and pick up the call from another telephone.

When using the 8434 and 8410 telephones, adjust these recommended layouts to fit the button layouts available with those telephones.

		Extension 3 (bridged app 1)	9
		Extension 3 (bridged app 2)	
		Do Not Disturb	
		PMS Alarm	
		CAS Alarm	
		Failed Wakeup	
		Delete	
1	Extension 2 (call app 1)	Check-In	
	Extension 2 (call app 2)	VIP Check-In	
	Extension 2 (call app 3)	Check-Out	
	Extension 1 (bridged app 1)	DID View	
	Extension 1 (bridged app 2)	DID Remove	
	Auto Wakeup	MW Act	
	Attendant Queue Calls	MW Deact	
8	Attendant Call Pickup	Attendant Busy	24

6424\_buttons.cdr

**Figure 34. First backup telephone button layout (Model 6424)**

---

Extension 1 (call app 1)	1
Extension 1 (call app 2)	
Extension 1 (call app 3)	
Extension 2 (bridged app 1)	
Extension 2 (bridged app 2)	
Auto Wakeup	
Attendant Queue Calls	
Attendant Call Pickup	

8

---

**Figure 35. Second backup telephone button layout (Model 6408)**

---

Extension 3 (call app 1)	1
Extension 3 (call app 2)	
Extension 1 (bridged app 1)	
Extension 1 (bridged app 2)	
Extension 1 (bridged app 3)	
Auto Wakeup	
Attendant Queue Calls	
Attendant Call Pickup	

8

---

**Figure 36. Third backup telephone button layout (Model 6408)**

---

## Mailboxes for AUDIX subscribers (INTUITY)

The following screens show an example of how to administer mailboxes for office staff subscribers on the INTUITY system. Use the **AUDIX Administration > add subscriber** command to access these screens. The default class of service, **class00**, is a good option to use. See *INTUITY Messaging Solutions Administration* for more information about other options on these screens. These screens are different between INTUITY R4.4 and R5. This example shows INTUITY R5 and later.

```

add subscriber 150                                     Page 1 of 2
                                                    SUBSCRIBER

      Name: Jean Collins                               Locked? n
      Extension: 150                                  Password:
      COS: class00                                    Miscellaneous 1:
      Switch Number: 1                                Miscellaneous 2:
      Community ID: 1                                 Miscellaneous 3:
      Secondary Ext:                                  Miscellaneous 4:
      Account Code:                                  Covering Extension: 161
                                                    Broadcast Mailbox? n

      Email Address:
    
```

On Page 2:

- Type — Enter **call-answer**.
- If Fax Creation is **y**, then change the following fields:
  - Voice Mail Message, Maximum Length — Enter **1200**.
  - Call Answer Message, Maximum Length — Enter **1200**.
  - Mailbox Size, Maximum — Enter **4800**.

```

add subscriber 150                                     Page 2 of 2
                                                    SUBSCRIBER CLASS OF SERVICE PARAMETERS
      Addressing Format: extension                     Login Announcement Set: System
      System Multilingual is ON                       Call Answer Primary Annc. Set: System
      Call Answer Language Choice? n                  Call Answer Secondary Annc. Set: System

      PERMISSIONS
      Type: call-answer                               Announcement Control? y           Outcalling? n
      Priority Messages? n                            Broadcast: none                   IMAPI Access? y
      IMAPI Message Transfer? n                      Fax Creation? n                   Trusted Server Access? y

      INCOMING MAILBOX                               Order: fifo                       Category Order: nuo
      Retention Times (days), New: 10               Old: 10                           Unopened: 10
      OUTGOING MAILBOX                               Order: fifo                       Category Order: unfda
      Retention Times(days), File Cab: 10            Delivered/Nondeliverable: 5

      Voice Mail Message (seconds), Maximum Length: 1200 Minimum Needed: 32
      Call Answer Message (seconds), Maximum Length: 1200 Minimum Needed: 8
      End of Message Warning Time (seconds):
      Maximum Mailing Lists: 25                      Total Entries in all Lists: 250
      Mailbox Size (seconds), Maximum: 4800         Minimum Guarantee: 0
    
```

## Guest room telephones (switch)

Use the **add station** command to add guest room telephones. Once you have created one telephone, use the **duplicate** command to create the rest of the guest rooms since all rooms usually have the same features, coverage path, COS, and COR. The `Message Waiting Indicator` is hardware-dependent and must match the type of message waiting lamps on the guest telephones. This can vary from room to room. The `Message Lamp Extension` field must match the extension of the guest room.



**NOTE:**

There are two features that affect the administration of guest rooms: Caller ID Telephones and Suite Telephones. If administering a room phone that has a caller ID, see also [“Administering analog Caller ID \(switch\)” on page 150](#). If administering a guest room that is part of a suite, see also [“Suite telephones \(switch\)” on page 152](#).

```

add station 107                                     Page 1 of 3
                                                STATION
Extension: 107                                     Lock Messages? n      BCC: 0
Type: 2500                                         Security Code:        TN: 1
Port: 01A0201                                     Coverage Path 1: 1    COR: 1
Name:                                              Coverage Path 2:      COS: 1
                                                Hunt-to Station:      Tests? y

STATION OPTIONS
Loss Group: 1                                     Message Waiting Indicator: led
Off Premise Station? n                          Message Lamp Ext: 107
    
```

```

add station 107                                     Page 2 of 3
                                                STATION
FEATURE OPTIONS
LWC Reception: audix
LWC Activation? n                                Coverage Msg Retrieval? n
LWC Log External Calls? n                       Auto Answer: none
CDR Privacy? n                                  Data Restriction? y
Redirect Notification? y                        Call Waiting Indication? n
Per Button Ring Control? n                     Att. Call Waiting Indication? n
Bridged Call Alerting? n                      Distinctive Audible Alerting? n
Switchhook Flash? y                           Adjunct Supervision? n
Ignore Rotary Digits? n
H.320 Conversion? n                            Per Station CPN - Send Calling Number?

                                                Audible Message Waiting? n
MWI Served User Type? n                       Coverage After Forwarding? s

Emergency Location Ext:
    
```

On Page 3:

- **Room** — Enter the room number. When the hospitality parameter Display Room Information in Call Display is enabled, this room number and guest name are displayed. Do not put the word “room” in front of the room number.
- **List1** — You may want to populate an Abbreviated Dialing system list to be used for one-button access to guest services.
- **Line Appearance** — Enter **call-appr**.

```
add station 107                                     Page 3 of 3
                                                    STATION
SITE DATA
  Room: 107                                         Headset? n
  Jack:                                             Speaker? n
  Cable:                                           Mounting: d
  Floor:                                           Cord Length: 0
  Building:                                        Set Color:

ABBREVIATED DIALING
  List1: System 1      List2:                    List3:

HOT LINE DESTINATION
  Abbreviated Dialing List Number (From above 1, 2 or 3):
  Dial Code:

  Line Appearance: call-appr
```

After you have administered the guest rooms, you can use the **list station** command to verify that all guest rooms have been translated.

Use the **change system-parameters hospitality** command to determine whether guest room information will be shown on digital display telephones typically used by front desk or office personnel. This may be a security issue for the customer. Use the Display Room Information in Call Display field to enable or disable this feature.

```
change system-parameters hospitality                               Page 2 of 3
                        HOSPITALITY

Dual Wakeups? y      Daily Wakeup? y      VIP Wakeup? y
                    VIP Wakeups Per 5 Minutes: 5
                    Room Activated Wakeup With Tones? y
                    Time of Scheduled Wakeup Activity Report:
                    Time of Scheduled Wakeup Summary Report:
Time of Scheduled Emergency Access Summary Report:
                    Announcement Type: mult-integ
                    Default Announcement Extension: 380

Length of Time to Remain Connected to Announcement: 30
Extension to Receive Failed Wakeup LWC Messages: 399
Routing Extension on Unavailable Voice Synthesis: attd
Display Room Information in Call Display? n
    Automatic Selection of DID Numbers? y
    Custom Selection of VIP DID Numbers? y
        Number of Digits from PMS:
            PMS Sends Prefix? n
    Number of Digits in PMS Coverage Path: 3
        Digit to Insert/Delete:
```

## Administering analog Caller ID (switch)

The TN2793B and TN793B analog line circuit packs can be administered to deliver Incoming Calling Line Identification (ICLID) data to stand-alone analog Caller ID display units or analog telephones with built-in Caller ID display units. For this feature to work, the serving central office (CO) must support delivery of Caller ID information over the trunks that are serving the switch. To administer this feature:

- Administer the Caller ID system options.
- Administer stations with Caller ID options.

## Administering Caller ID

Use the **change system-parameters features** command to select the Caller ID protocol that matches the protocol used by the Caller ID units or telephones, and to enable display of Caller ID information for room-to-room calls. These options are set on a system-wide basis. Administer the following options:

- Protocol for Caller ID Analog Terminals — The available protocols include:
  - **Bellcore** (default) — US protocol (Bellcore transmission protocol with 212 modem protocol)
  - **V23-Bell** — Bahrain protocol (Bellcore transmission protocol with V.23 modem protocol).
- Display Calling Number for Room to Room Caller ID Calls — Enter **y** to display both name and number, or **n** to display name only. The information displayed on the telephone may be a security issue for the customer.

```
change system-parameters features                               Page 1 of 11
      FEATURE-RELATED SYSTEM PARAMETERS
      Self Station Display Enabled? y
      Trunk-to-Trunk Transfer: none
Automatic Callback - No Answer Timeout Interval (rings): 3
      Call Park Timeout Interval (minutes): 10
      Off-Premises Tone Detect Timeout Interval (seconds): 20
      AAR/ARS Dial Tone Required? y
      Music/Tone on Hold: music Port: 01B1101
      Music (or Silence) on Transferred Trunk Calls? no
      DID/Tie/ISDN Intercept Treatment: attd
      Messaging Service Adjunct (MSA) Connected? n
      Internal Automatic Answer for Attendant Extended Calls? n
      Automatic Circuit Assurance (ACA) Enabled? y
      ACA Referral Calls: local
      ACA Referral Destination: attd
      ACA Short Holding Time Originating Extension: 3070
      ACA Long Holding Time Originating Extension: 3070
      Abbreviated Dial Programming by Assigned Lists? n
      Auto Abbreviated/Delayed Transition Interval (rings): 2
      Protocol for Caller ID Analog Terminals: Bellcore
      Display Calling Number for Room to Room Caller ID Calls? n
```

## Administering Caller ID station options

Use the **add station** or **change station** commands to administer the Caller ID options for each Caller ID telephone. Administer the following options:

- Type — Enter **CallrID**.
- Display Caller ID — Enter **y** to enable Caller ID for this telephone.
- Caller ID Message Waiting Indication — Enter **y** to enable Bellcore-defined FSK message waiting indication for this telephone. When this option is enabled, the circuit pack will refresh the Message Waiting Indication status for this telephone on a regular basis.

This administration is independent of the Message Waiting Indicator field.

```
add station 107                                     Page 1 of 3
                                                    STATION
Extension: 107                                     Lock Messages? n      BCC: 0
Type: CallrID                                     Security Code:        TN: 1
Port: 01A0201                                     Coverage Path 1: 1   COR: 1
Name:                                             Coverage Path 2:    COS: 1
                                                    Hunt-to Station:    Tests? y

STATION OPTIONS
    Loss Group: 1                                     Message Waiting Indicator: led
Off Premise Station? n                             Message Lamp Ext: 107
                                                    Display Caller ID: y
                                                    Caller ID Message Waiting Indication? n
```

## Suite telephones (switch)

---

There are two features that better enable the setup of suite telephones: Suite Check-In and Station Hunt Before Coverage.

Suite Check-In allows the switch to check-in more than one telephone with one check-in command, whether the command is done from the switch or from the PMS. This is done by setting up a “hunt-to chain” between a primary telephone and up to 29 secondary telephones that are installed at different locations of a suite, or between telephones in separate rooms that have been linked as a suite of rooms. This feature does not apply to telephones that have bridged extensions of the primary extension; the secondary phones must have their own extension numbers.

For example, room 207 has three telephones, each with different extensions: 7207 (the primary extension), 7887, and 7897 (secondary extensions). You would administer station hunting from 7207 to 7887, and from 7887 to 7897. When you check in room 207 (extension 7207), the check-in process looks at the `Hunt-To Station` field, and if there is an extension in that field (in this case, 7887), that extension is also checked in. The system then checks the second extension’s `Hunt-To Station` field, and if there is an extension in that field (in this case, 7897), that extension is also checked in. You can link up to 30 stations as one suite of telephones. There is no limit to the number of suites you can create.

When two or more telephones are administered in this suite arrangement, you must also administer how incoming calls will be handled. There is a coverage option called Station Hunt Before Coverage. If Station Hunt Before Coverage is not enabled, calls to the primary extension (in this example, 7207) will go to coverage as specified in the coverage path criteria. If Station Hunt Before Coverage is enabled and there is a call to room 207 (extension 7207), if extension 7207 is busy, the call hunts to 7887. If extension 7887 is busy, the call hunts to extension 7897. If extension 7897 is busy, the call goes to coverage for extension 7207 (usually voice mail or the front desk). If any of the telephones in the station hunting group are idle, the call rings at that telephone and, when not answered, goes to coverage for extension 7207 (the primary extension). It is important to remember that hunting occurs only when an extension is busy, not when a call goes unanswered.

## Enabling Suite Check-In

Use the **change system-parameters hospitality** command, Page 3, to enable the Suite Check-In feature.

```
change system-parameters hospitality                               Page 3 of 3
ROOM STATES                HOSPITALITY

Definition for Rooms in State 1: occupied/dirty
Definition for Rooms in State 2: occupied/maid in room
Definition for Rooms in State 3: occupied/clean
Definition for Rooms in State 4: vacant/clean
Definition for Rooms in State 5:
Definition for Rooms in State 6:

HOSPITALITY FEATURES
Suite Check-in? y
```

## Administering station hunting

Use the **add station XXXX** or **change station XXXX** command to administer Hunt-To Stations. Based on the previous suite example, the following screen shows how you would administer station hunting from primary extension 7207 to secondary extension 7887.

```
change station 7207                                           Page 1 of 3
STATION

Extension: 7207                Lock Messages? n          BCC: 0
Type: CallrID                 Security Code:             TN: 1
Port: 01A0201                Coverage Path 1: 1        COR: 1
Name:                         Coverage Path 2:          COS: 1
                               Hunt-to Station: 7887     Tests? y

STATION OPTIONS
Loss Group: 1                Message Waiting Indicator: led
Off Premise Station? n      Message Lamp Ext: 7207
                               Display Caller ID: y
Caller ID Message Waiting Indication? n
```

The following screen shows how you would then administer station hunting from secondary extension 7887 to secondary extension 7897.

```

change station 7887                                     Page 1 of 3
                                     STATION
Extension: 7887                                         Lock Messages? n      BCC: 0
Type: CallrID                                         Security Code:        TN: 1
Port: 01A0201                                         Coverage Path 1: 1    COR: 1
Name:                                                  Coverage Path 2:      COS: 1
                                     Hunt-to Station: 7897  Tests? y

STATION OPTIONS
  Loss Group: 1                                         Message Waiting Indicator: led
Off Premise Station? n                                Message Lamp Ext: 7887
                                                         Display Caller ID: y
Caller ID Message Waiting Indication? n
    
```

You would repeat this administration for each telephone in the hunting group.

### Administering Station Hunt Before Coverage

Use the **change system-parameters coverage-forwarding** command, Page 1, to enable or disable Station Hunt Before Coverage.

```

change system-parameters coverage-forwarding           Page 1 of 2
SYSTEM PARAMETERS - CALL COVERAGE/CALL FORWARDING

CALL COVERAGE/FORWARDING PARAMETERS

  Local Cvg Subsequent Redirection/CFWD No Ans Interval (rings): 2
  Off-Net Cvg Subsequent Redirection/CFWD No Ans Interval (rings): 2
  Coverage - Caller Response Interval (seconds): 4
  Threshold For Blocking Off-Net Redirection of Incoming Trunk Calls: 1

COVERAGE
  Keep Held SBA At Coverage Point? y
External Cvg Treatment For G3 Transferred Calls to G2 Supporting AUDIX? n
  Immediate Redirection on Receipt of PROGRESS Inband Information? n
  Maintain SBA At Principal? y

  Station Hunt Before Coverage? y

FORWARDING
  Call Forward Override? n
  Coverage after Forwarding? y
    
```

## Considerations

There are some considerations when setting up suite telephones.

- Automatic Selection of DID Numbers and Custom Selection of VIP DID Numbers for Guest Rooms

If Automatic Selection of DID Numbers or Custom Selection of VIP DID Numbers is active, a DID number is assigned only to the primary extension (the one that appears in the check-in message), not to all of the secondary hunt-to extensions.

- Automatic Wakeup

An Automatic Wakeup will be set and delivered only for the extension dialed, not the hunt-to extensions. If the wakeup call is placed and the telephone is busy, the wakeup call is retried two more times at 5-minute intervals.

- Call Coverage

If Station Hunt Before Coverage is active, a call to a busy telephone tries to terminate to the hunt-to telephone before going to coverage. If the call goes to coverage, it goes to the coverage of the originally-dialed number. This is true unless the dialed number is an XDID number, and then the call goes to the coverage of the non-XDID telephone found in the XDID's hunt-to field.

- Call Detail Recording

Calls made from any of the secondary suite telephones will record the extension that placed the call, not the primary suite extension. Billing for calls from secondary extensions must be coordinated with the call accounting system vendor.

- Check-In

If the primary extension or any of the secondary extensions are already in the checked-in state, the room will not be checked in, and the message "Room Already Occupied" will display.

- Check-Out

If the primary extension is not in the occupied state, the message "Room Already Vacant" is displayed, and no rooms are checked out. If any secondary extensions are in the vacant state, all extensions will be checked out, and "Check Out Complete" is displayed.

- **Controlled Restrictions**

When a controlled restriction is applied to the primary extension, the restriction is applied to all secondary extensions. This applies to restrictions done from the PMS, the attendant console, or from an authorized telephone.

- **Dial by Name**

Secondary extensions that are checked in as part of a suite have an asterisk (\*) inserted before the name that is stored in the names database. This prevents someone from using Dial by Name to access a secondary extension; only the primary extension can be accessed. However, when a guest calls the attendant or a display telephone from one of the secondary extensions, the guest name (with the asterisk in front of it) displays.

- **Do Not Disturb**

When one of the telephones in a suite of telephones has Do Not Disturb activated, calls to that telephone go to intercept treatment, not to the next hunt-to telephone in the suite.

- **Housekeeping Status Updates**

When room status is updated by housekeeping, it should be done from the primary extension for that room in order to be properly recorded. If housekeeping updates the status from the secondary extensions in the suite, the status for the suite (the primary extension) will not be updated.

- **Mailboxes**

Mailboxes on the INTUITY system must be created manually for suites of rooms.

- **Message Waiting Lamps**

Messages left for the primary extension do not light the message waiting lamps of the secondary extensions unless the `Message Lamp Ext` field for the secondary extensions contains the primary extension. In some cases, the customer will want each telephone to have its own message waiting lamp. In other cases, the customer will want a single message waiting lamp for all telephones in a suite.

- PMS Synchronization

In some cases, the PMS database and the switch database may get out-of-sync, and the telephones in a suite may not have the same status. If this happens, front desk personnel may have to check out the room (saving any messages for that room) and then retry the check-in.

During a database swap, if the PMS sends an extension that should be checked in but that is not currently checked in, all extensions in the hunt-to chain are updated along with the primary extension, regardless of their current state.

During a Room Change, the information for the old primary extension and secondary hunt-to extensions is cleared. All of the old information is inserted for the new room number.

During a Room Swap, the system will change the guest name and coverage path between the two rooms for the primary extension and the secondary extensions.

- Send All Calls

When a telephone has Send All Calls active, and the telephone is called, the call goes directly to coverage, and no station hunting is done. If a hunt-to telephone has Send All Calls active, it is skipped in the hunt-to chain.

## Mailboxes for guest rooms (INTUITY)

---

Guest room mailboxes are handled differently depending on which type of messaging link is used between the switch and the INTUITY.

When using TCP/IP or X.25 signaling, messages are sent between the PMS and the INTUITY system to automatically create guest room mailboxes when the PMS checks in a guest. No manual intervention is required.

When using Mode Code, you must manually create a mailbox for each guest room and leave the mailbox open at all times. This procedure is described in the *INTUITY Lodging Release 4 Administration* document or on the *INTUITY Messaging Solutions Release 5 Documentation (CD)*. You must also use the **Lodging Administration > System Parameter Administration** command and set the `Lamps ON For New Messages Only` field to **No**. This means that the customer must clear messages manually every time a guest checks out. Instructions for this are also found in these documents.

When mailboxes are created, an \* (asterisk) or 0 (zero) in the Guest Password field allows access to anyone checking that mailbox for messages. The system will not prompt the user for a password. If a # (pound or hash) is in the Guest Password field, guests can access their voice mailboxes only from their rooms until the guest assigns a valid password to the account. After assigning a password, guests can then get their messages from any location.



### NOTE:

The asterisk is the default password for a PMS-initiated check-in when the PMS does not send a password to the switch in stand-alone mode. The pound (or hash) symbol is the default password for a PMS-initiated check-in when the PMS does not send a password to the switch in the integrated switch link mode. See [“Voice messaging-to-PMS translations and testing” on page 252](#) for more information.

If the guest mailbox has the `Allow Personal Greeting` field enabled, a guest can create a personal greeting, and also change his or her password when accessing his or her mailbox. A password must be four digits, non-sequential, non-repetitive, and not the same number as the room number.

## Recorded announcements (switch)

Use the **change announcements** command to assign extension numbers to be used for recorded announcements. There are two circuit packs that can be used to record announcements:

- TN2501AP

The TN2501AP can record from 128 to 256 announcements. The maximum recording time per circuit pack is 1 hour. Each circuit pack has one dedicated port for recording announcements, one ethernet port for downloading wave (.wav) files, and 31 ports for playback. The TN2501AP is compatible with R9.5 and later.



**NOTE:**

The TN2501AP circuit pack requires extensive administration which is described in the *DEFINITY ECS Administrator's Guide*.

- TN750

The TN750 supports up to 16 announcements. The maximum recording time per circuit pack is 256 seconds (TN750) or 512 seconds (TN750B or TN750C).

The extensions used for recorded announcements must already be administered in the dialing plan but cannot be used for any other purpose (such as stations or directory numbers).

change announcements		ANNOUNCEMENTS/AUDIO SOURCES										Page 1 of 8
Ann. No.	Ext.	Type	COR	TN	Name	Q	QLen	Pro	Rate	Port		
1:	380	integrated	1	1	Wakeup	n	N/A	n	32	01A14		
2:	381	integrated	1	1	1st Auto Atnd	n	N/A	n	32	01A14		
3:	382	integrated	1	1	Dial Extension	n	N/A	n	32	01A14		
4:	383	integrated	1	1	Directory	n	N/A	n	32	01A14		
5:			1	1		n						
6:			1	1		n						
7:			1	1		n						
8:			1	1		n						
9:			1	1		n						
10:			1	1		n						
11:			1	1		n						
12:			1	1		n						
13:			1	1		n						
14:			1	1		n						
15:			1	1		n						
16:			1	1		n						

Once you have designated which extensions will be used for recorded announcements, use the following procedures to record and test the announcements. You must record the announcements from the attendant console or from a station that has console permissions. It is recommended that you have a hotel employee record the announcements so the same person can be used for later changes or additions.

To record each of the announcements:

1. Go off-hook, and dial the Announcement FAC \_\_\_\_\_.
2. Dial the extension number of the announcement you want to record.  
If an announcement session is already in progress, or if announcements are being saved or restored, you will hear reorder tone. Try again later.
3. Press **1**, and record after the tone.  
If the announcement already exists and is marked "protected" in the announcements screen, you will hear intercept tone.
4. Hang up when finished recording the message.



**NOTE:**

The system records the sound of the receiver returning to the station. Press the switchhook with your finger, press **Drop**, or hang up gently.

5. After waiting 15 seconds, dial the extension number of the announcement you just recorded.
6. Listen to the recording. If you need to record the message again, repeat this procedure. If the message is satisfactory, hang up, and repeat this procedure to record the other announcements.

To delete a recorded announcement:

1. Go off-hook at a station, and dial the Announcement FAC \_\_\_\_\_.
2. Dial the extension number of the announcement you want to delete.
3. Press **3**.  
Confirmation tone is heard, and the announcement is deleted.
4. Hang up.
5. Use the **change announcements** command to delete the announcement extension.

If your system uses the TN750 or TN750B circuit packs, you must manually save the announcements recorded on those circuit packs. Use the **save announcements** command. If you do not save the announcements, all announcements recorded since the last save will be lost if the system loses power, or if the TN750 or TN750B circuit packs are removed from the system.

If your system uses only the TN750C or TN2501AP circuit packs, saving the announcements is not required. The TN750C and TN2501AP have on-board memory for all announcements.

Use the **change system-parameters hospitality** command to administer options associated with recorded announcements. On Page 2, administer the following:

- Use the `Announcement Type` field to indicate the type of automatic wakeup announcement the hotel guest will receive. Allowable entries are as follows:

Valid entries	Usage
<b>external</b>	Applicable when using an announcement adjunct. If <b>external</b> is used, complete the <code>Auxiliary Board for Announcement</code> field.
<b>integrated</b>	Applicable when using the TN2501AP, TN750B, or TN750C announcement circuit packs. If <b>integrated</b> is used, complete the <code>Integrated Announcement Extension</code> field. The extension you enter must be a valid integrated announcement extension (administered on the Recorded Announcements screen) or a VDN. If you enter an invalid extension, the switch displays an error message.
<b>mult-integ</b>	Applicable when using the TN2501AP, TN750B, or TN750C announcement circuit packs. If <b>mult-integ</b> is used, complete the <code>Default Announcement Extension</code> field. The extension you enter must be a valid integrated announcement extension (administered on the Recorded Announcements screen) or a VDN. If you enter an invalid extension, the switch displays an error message.
<b>voice-synthesis</b>	If <b>voice-synthesis</b> is used, complete the <code>Announcement Ports</code> field.
<b>music-on-hold</b>	If <b>music-on-hold</b> is used, no other field appears.
<b>silence</b>	If <b>silence</b> is used, no other field appears.



**NOTE:**

One of the following four fields appears depending on what data is entered in the `Announcement Type` field.

- The `Auxiliary Board for Announcement` field appears only when the **external** announcement type is used. This indicates the equipment location of an auxiliary trunk circuit that connects to the external announcement equipment.
  - The `Integrated Announcement Extension` field appears only when the **integrated** announcement type is used. This indicates the wakeup announcement extension when using the integrated announcement circuit pack.
  - The `Default Announcement Extension` field appears only when the **mult-integ** announcement type is used. This indicates the default wakeup announcement extension when using the integrated announcement circuit pack.
  - The `Announcement Ports` field appears only when the **voice-synthesis** announcement type is used. For the **voice-synthesis** announcement type, this indicates the equipment location of two ports on a voice synthesizer circuit pack.
- The `Length of Time to Remain Connected to Announcement` field indicates the length of time, in seconds, that a hotel guest will be connected to an announcement. This applies only after the guest has heard the announcement completely one time, and then continues to listen.

```
change system-parameters hospitality                               Page 2 of 3
                        HOSPITALITY

Dual Wakeups? y      Daily Wakeup? y      VIP Wakeup? y
                    VIP Wakeups Per 5 Minutes: 5
                    Room Activated Wakeup With Tones? y
                    Time of Scheduled Wakeup Activity Report:
                    Time of Scheduled Wakeup Summary Report:
                    Time of Scheduled Emergency Access Summary Report:
                    Announcement Type: mult-integ
                    Default Announcement Extension: 380

Length of Time to Remain Connected to Announcement: 30
                    Extension to Receive Failed Wakeup LWC Messages: 399
                    Routing Extension on Unavailable Voice Synthesis:
                    Display Room Information in Call Display? n
                    Automatic Selection of DID Numbers? y
                    Custom Selection of VIP DID Numbers? y
                    Number of Digits from PMS:
                    PMS Sends Prefix? n
                    Number of Digits in PMS Coverage Path: 3
                    Digit to Insert/Delete:
```

For more information about recorded announcements, see *Managing Announcements* in the *DEFINITY ECS Administrator's Guide*. For information about multiple music-on-hold sources, see the *Tenant Partitioning* section of the *DEFINITY ECS Administrator's Guide*.

## Emergency Access to Attendant (switch)

Use the **display system-parameters customer-options** command, Page 3, to verify that the Emergency Access to Attendant feature is enabled. This feature can only be enabled with the *init* login ID. Contact technical support or your COE if you do not have permission to make this change.

Use the **change system-parameters features** command to administer parameters for the Emergency Access to Attendant feature.

- `Time before Off-hook Alert` — This is the system delay after a user goes off-hook before the attendant is notified of the condition.
- `Emergency Access Redirection Extension` — Enter a backup extension that can receive off-hook alert calls.
- `Number of Emergency Calls Allowed in Attendant Queue` — Enter the number of off-hook alert calls that you wish to allow at any one time in the attendant queue.
- You must also administer the feature access code (see [page 112](#)) and the Off-Hook Alert option for the appropriate COS (see [page 115](#)).

```
change system-parameters features                               Page 3 of 11
      FEATURE-RELATED SYSTEM PARAMETERS
Reserved Slots for Attendant Priority Queue: 5
      Time before Off-hook Alert: 10
      Emergency Access Redirection Extension: 195
Number of Emergency Calls Allowed in Attendant Queue: 5
      Call Pickup Alerting? n
Temporary Bridged Appearance on Call Pickup? y
      Call Pickup on Intercom Calls? y
      Directed Call Pickup? n
      Extended Group Call Pickup: none
Deluxe Paging and Call Park Timeout to Originator? y
Controlled Outward Restriction Intercept Treatment: attendant
Controlled Termination Restriction (Do Not Disturb): attendant
Controlled Station to Station Restriction: attendant
AUTHORIZATION CODE PARAMETERS      Authorization Codes Enabled? y
      Authorization Code Length: 7
      Authorization Code Cancellation Symbol: #
      Attendant Time Out Flag? n
      Display Authorization Code? y
Controlled Toll Restriction Replaces: none
```

## Crisis Alert (switch)

Crisis Alert is a feature that sends a message to one or more attendant consoles, one or more digital display telephones, and to as many as three digital, numeric pagers when a guest or employee places a call to an emergency service agency (for example, 911). The message will help personnel identify where the emergency has occurred at the property.

## Routing calls

To ensure that the Crisis Alert feature operates properly, you must administer ARS patterns to accept any combination of digits that guests could possibly dial while trying to dial the emergency service agency, and route the call to the correct location. For example, some guests might dial 9 (for an outside line) and then 911. Other guests may only dial 911. Without the correct routing patterns, the call will not go through. These screens show two examples of how this routing can be administered.

Assign a routing pattern and the **alrt** Call Type to the desired emergency service access code. For example, if your emergency service access code is 911, assign the 911 digit string to a routing pattern, and assign it the **alrt** Call Type. This takes care of the condition when the guest dials 9 (for local access) and then 911. If a guest only dials 911, you also want the call to route to the emergency service agency. You must assign a dialed string of 11 with a different routing pattern that removes the dialed digits 11 and inserts the dialed digit string 911. The following screens show these two examples administered as part of the ARS Digit Analysis Table.

```

change ars analysis 9
ARS DIGIT ANALYSIS TABLE
Location: all
Page 1 of 2
Percent Full: 6
Dialed      Total   Route  Call   Node  ANI
String      Min  Max   Pattern Type  Num  Reqd
911         3    3     5      alrt  n
           n
           n
           n
           n
           n
           n
           n
           n
           n
           n

```

```

change ars analysis 1
ARS DIGIT ANALYSIS TABLE
Location: all
Page 1 of 1
Percent Full: 6

Dialed      Total      Route      Call      Node      ANI
String      Min  Max    Pattern   Type      Num      Reqd
11          2    2     6         alrt      n
           n
           n
           n
           n
           n
           n
           n
           n
           n
           n

```

Use the **change route-pattern** command to assign a routing pattern for the emergency service access code. In this first example, Preference 1 of Pattern 5 is used when guests dial 9911 (9 for the ARS access code, and 911 for the emergency service agency).

```

change route-pattern 5
Pattern Number: 5
Page 1 of 1

Grp. FRL NPA Pfx Hop Toll No.  Inserted      DCS/ IXC
No.      Mrk Lmt List Del  Digits      QSIG
          Dgts      Intw
1: 5    0
2:
3:
4:
5:
6:

          BCC VALUE  TSC CA-TSC      ITC BCIE Service/Feature BAND  No. Numbering LAR
          0 1 2 3 4 W      Request      Dgts Format
          Subaddress
1: y y y y y n n      rest      none
2: y y y y y n n      rest      none
3: y y y y y n n      rest      none
4: y y y y y n n      rest      none
5: y y y y y n n      rest      none
6: y y y y y n n      rest      none

```

In this second example, Preference 1 of Pattern 6 is used when guests dial 911. Pattern 6 deletes the two digits dialed (11) after the ARS access code (9) and inserts the caller's intended digit string (911).

```
change route-pattern 6                                     Page 1 of 1
                                     Pattern Number: 6

  Grp. FRL NPA Pfx Hop Toll No.  Inserted          DCS/ IXC
  No.          Mrk Lmt List Del  Digits          QSIG
                                     Dgts          Intw
1: 5    0                2  911                n  user
2:                                     n  user
3:                                     n  user
4:                                     n  user
5:                                     n  user
6:                                     n  user

  BCC VALUE  TSC CA-TSC  ITC BCIE Service/Feature BAND  No. Numbering LAR
  0 1 2 3 4 W      Request          Dgts Format
                                     Subaddress
1: y y y y y n n          rest          none
2: y y y y y n n          rest          none
3: y y y y y n n          rest          none
4: y y y y y n n          rest          none
5: y y y y y n n          rest          none
6: y y y y y n n          rest          none
```

**Setting system parameters**

Crisis Alert can notify attendant consoles, digital display telephones, and digital, numeric pagers. Use the **change system-parameters crisis-alert** command to set the Crisis Alert system parameters.



**NOTE:**

You should never set up Crisis Alert to Pager as your only option. When using the Crisis Alert to Pager option, always set up at least one attendant console or telephone to receive the same crisis alert messages.

If you are setting up Crisis Alert to notify one or more display telephones, use this screen to indicate whether every designated display telephone user must respond to the crisis notification, or whether only one user must respond.

The options for Crisis Alert to Pager include the following:

- Alert Pager — Enter **y** to enable Crisis Alert to Pager. When this field is enabled, the other fields display. If you want to temporarily disable this feature, enter **n**. This will cause the fields to disappear, but any data in the fields will be displayed the next time you enable the feature.
- Originating Extension — Enter a valid extension from the dial plan.

- Crisis Alert Code — Enter a distinctive code that identifies this page as an emergency call from the property. For example, you might use **911** in the United States.
- Retries — Enter the number of times (**0** to **10**) the system will attempt to send the alert message if the call was unsuccessful.
- Retry Interval — Enter the amount of time between retries. You may enter a value from **30** to **60** seconds.
- Main Number — Enter the LDN for the property, or a number that the user would call to respond to the crisis alert page. This is an optional field, and can be up to 15 digits, including one or more # digits at the end of the number.
- Pager Numbers and PIN — Enter at least one, and up to three different pager numbers. Each pager number can be up to 15 digits long. If needed, enter personal ID numbers (PIN) for each pager number. PINs can also be up to 15 characters long. For the PIN, the letter **p** adds a pause interval before sending the PIN. The characters **\*** and **#** may also be part of the PIN.
- DTMF Duration — Enter a value (from **20** to **2550** msec) for the duration of the DTMF tones, and the amount of pause between the tones. The default for each is 100 msec. This value may need to be adjusted depending on trunking requirements.

```
change system-parameters crisis-alert                               Page 1 of 1
                        CRISIS ALERT SYSTEM PARAMETERS

ALERT STATION
  Every User Responds? y

ALERT PAGER
  Alert Pager? y
  Originating Extension: 3000
  Crisis Alert Code: 999
    Retries: 3
    Retry Interval: 60
    Main Number: 555-3000

                        Pager Number      Pin Number
1: 623-577-1353      1:
2:                   2:
3:                   3:

DTMF Duration - Tone (msec): 100  Pause (msec): 100
```

Based on the above example, the person with pager number 623-577-1353 will receive crisis alerts that will display “999 3000 555-3000.”

## Trunk groups (switch)

Use the **add trunk-group** command to assign each trunk group. For more information on administering trunk groups, including CAMA 911 emergency trunks, see the *DEFINITY ECS Administrator's Guide*.

- **COR** — Each trunk group must have a COR.
- **CDR Reports** — Enter **y** for every trunk group that the customer wishes to record. Usually, only outgoing trunk groups are recorded.
- **Dial Access** — Enter **n**.

```

add trunk-group 1                                     Page 1 of 11
                                     TRUNK GROUP
Group Number: 1           Group Type: co           CDR Reports: y
Group Name: Outside Call           COR: 20           TN: 1           TAC: 710
Direction: two-way           Outgoing Display? n
Dial Access? n           Busy Threshold: 10           Night Service:
Queue Length: 0           Country: 1           Incoming Destination: attd
Comm Type: voice           Auth Code? n           Digit Absorption List:
Prefix-1? y           Trunk Flash? n           Toll Restricted? y

TRUNK PARAMETERS
Trunk Type: ground-start
Outgoing Dial Type: tone           Cut-Through? n
Trunk Termination: rc           Disconnect Timing(msec): 500

Auto Guard? n           Call Still Held? n           Sig Bit Inversion: none
Analog Loss Group: 6           Digital Loss Group: 11
Trunk Gain: high

Disconnect Supervision - In? y Out? n
Answer Supervision Timeout: 10           Receive Answer Supervision? n

```



### NOTE:

When a call accounting package is first installed, the set of extensions and trunks administered on the switch is coordinated with the call accounting vendor. If extensions and trunks are added at a later date, the call accounting vendor must be notified so changes can be added to the call accounting package.

## **Assigning DID numbers to guest rooms (switch)**

Front desk personnel can assign a DID number to a guest room when the guest checks in, or at any time during the guest's stay. A DID number gives the guest a direct phone number to his or her room that can be shared with family or business associates. A DID number also enhances guest security by allowing people to contact guests without giving out the guest room number. The DID number can be dialed as an extension from within the property, or as a 7- or 10-digit number by callers outside of the property. These numbers are selected from a block of DID numbers purchased by the customer from the customer's local telephone company.

DID numbers can be assigned to guest rooms using two different features:

- Automatic Selection of DID Numbers, or
- Custom Selection of VIP DID numbers.

Automatic Selection of DID Numbers allows the switch to automatically assign a DID number to a guest room when the guest checks in. The switch selects the DID numbers from an administered set of DID numbers that have been designated for automatic assignment. The numbers are selected on a rotating basis, with the oldest DID number assigned with each new check-in. After the switch assigns a DID number, the number can be viewed and changed manually from an attendant console or backup telephone. The pool of DID numbers used for this feature is separate from the pool of numbers used for the Custom Selection of VIP DID Numbers feature.

Custom Selection of VIP DID Numbers allows the switch to assign a special DID number to a guest room when a guest checks in. The front desk personnel select the DID numbers from an administered set of DID numbers that have been designated for custom, or repeat, assignment. This feature is used for VIP guests that wish to have the same DID number every time they check in to the property. After a DID number is assigned, the number can be viewed and changed manually from an attendant console or backup telephone. The pool of DID numbers used for this feature is separate from the pool of numbers used for the Automatic Selection of DID Numbers feature.

These features work when checking in either from the attendant console or backup telephone, or when checking in using a PMS, as long as the PMS software has been updated to use this feature. The switch PMS messages have been changed to allow the PMS to request a DID number, which the switch sends as part of the check-in response (automatic selection) or as a separate message (custom selection). See the *GuestWorks and DEFINITY ECS Property Management System Interface Specifications* (555-231-601, Issue 3 or later) for more details.

To administer this feature:

- Enable the Automatic Selection of DID Numbers and the Custom Selection of VIP DID Numbers features.
- Assign one block of extensions to be used as automatic DID numbers and a different block of extensions to be used as custom DID numbers.
- Assign VIP Check-In, DID View, and DID Remove buttons on the attendant console and backup telephones.

## Enabling Automatic and Custom Selection of DID Numbers

Use the **change system-parameters hospitality** command, Page 2, to enable these features. You can have Automatic Selection of DID Numbers enabled without using Custom Selection of VIP DID Numbers, but you cannot have Custom Selection of VIP DID Numbers without enabling Automatic Selection of DID numbers.

```

change system-parameters hospitality                               Page 2 of 3
                        HOSPITALITY

Dual Wakeups? y      Daily Wakeup? y      VIP Wakeup? y
                        VIP Wakeups Per 5 Minutes: 5
                        Room Activated Wakeup With Tones? y
Time of Scheduled Wakeup Activity Report: 12:00AM
Time of Scheduled Wakeup Summary Report: 12:30AM
Time of Scheduled Emergency Access Summary Report: 12:45AM
                        Announcement Type: silence

Length of Time to Remain Connected to Announcement: 30
Extension to Receive Failed Wakeup LWC Messages: 399
Routing Extension on Unavailable Voice Synthesis:
Display Room Information in Call Display? n
Automatic Selection of DID Numbers? y
Custom Selection of VIP DID Numbers? y
                        Number of Digits from PMS:
                        PMS Sends Prefix? n
                        Number of Digits in PMS Coverage Path: 3
                        Digit to Insert/Delete:
    
```

## Assigning the DID numbers

Use the **add station XXXX** command to assign the DID numbers. Use a block of unassigned extensions from the switch numbering plan. The DID numbers must match the DID numbers assigned by the customer's telephone company. To maintain consistency, the extension length on the switch must match the extension length of the DID numbers assigned by the telephone company.

The quantity and management of DID numbers assigned is up to the customer. The customer may want to limit the quantity of DID numbers assigned, or have the ability to give out a DID number to every guest. If the customer wants to use both automatic and custom selection of DID numbers, they must have one set of automatic DID numbers and another set of custom DID numbers. When assigning the DID numbers, do not use a COS that has the Client Room feature enabled. This prevents someone from accidentally checking in or checking out a DID telephone number.

The following examples show and XDID and XDIDVIP station assignment.

```

add station 6000                                     Page 1 of 1
                                                    STATION
Extension: 6000                                     BCC: 0
Type: xdidd                                         TN: 1
                                                    Coverage Path 1: 5    COR: 1
Name:                                               Coverage Path 2:     COS: 10
                                                    Hunt-to Station:
    
```

```

add station 6224                                     Page 1 of 1
                                                    STATION
Extension: 6224                                     BCC: 0
Type: xdiddvip                                     TN: 1
                                                    Coverage Path 1: 5    COR: 1
Name:                                               Coverage Path 2:     COS: 10
                                                    Hunt-to Station:
    
```

When you first assign the DID numbers, the `Hunt-to Station` field does not have an assignment (it is a display-only field). When a DID number is assigned to a guest room extension when the guest checks in, that guest room extension is then displayed in the `Hunt-to Station` field of the assigned DID number. Use the **list station type xdidd** or **list station type xdiddvip** commands to list the DID number assignments.

After you assign one DID number, use the **duplicate station XXXX** command to create the rest of your DID numbers. Duplication can be used for only one station type at a time (XDID or XDIDVIP, but not both at the same time).

## Assigning DID number feature buttons

Assign the following feature buttons to use the DID number features:

- did-view
- did-remove
- vip-chkin

These buttons can be assigned to attendant consoles and backup telephones with console permissions. See [“Attendant console button layouts \(switch\)” on page 132](#) and [“Backup telephone button layouts \(switch\)” on page 142](#) for more information.

## Considerations

- Call Coverage

Calls using a DID number will cover to the guest’s coverage path as if the guest’s extension was dialed.
- Call Coverage for Unassigned DID Numbers

Assign a special Call Coverage path for all DID numbers. This coverage should terminate to the attendant or to a recording stating that the number dialed is no longer in use. When the DID number is assigned to a guest room, the coverage follows the path for that guest. When the DID number is not being used, the call will go to the attendant or to a recording.

If the coverage goes to a special mailbox on the voice mail system, you can administer the system so the caller can dial 0 to get the front desk. For example, the recording could say “Thank you for calling the ABC Hotel. The guest you have called is no longer available at this number. Please press 0 for assistance.”
- Call Detail Recording

Incoming calls are recorded for the DID number, not the room extension number. Billing for incoming calls to DID numbers must be coordinated with the call accounting system vendor.
- Call Vectoring

You cannot route a vector step to an **xdid** or **xdidvip** station type.

- **Collect Calls**

In general, collect calls to DID guest room numbers should not be allowed. Check with your local telephone company to see if the incoming trunks can be administered to deny collect calls to the guest rooms.

- **Number Rotation for Automatic Selection of DID Numbers**

Initially, the DID numbers are assigned during check-in in the order in which they were administered on the switch. Over time, that order will become more random, depending on the length of each guest's stay.

This rotation of numbers is not used for Custom Selection of VIP DID Numbers since those numbers are manually assigned.

- **Save Translations**

The DID number assignments are saved in translations (either when done manually or during the automatic save every night). Any system resets of level 3 or higher will lose DID number check-in assignments since the last save.

## Automatic Wakeup options (switch)

---

Automatic Wakeup is a standard feature when hospitality is enabled on the Customer Options form. In addition to the standard single wakeup option set up by front desk personnel, the following options are available for the Automatic Wakeup feature:

- Dual Wakeup

Dual wakeup calls can be set up by front desk personnel, or by the guest when using the Wakeup Activation via Tones feature.

- Daily Wakeup

Daily wakeup calls can only be set up by front desk personnel.

- VIP Wakeup, including the maximum number of VIP Wakeup requests allowed during a 5-minute interval

VIP wakeup calls can only be set up by front desk personnel.

- Wakeup Activation via Tones

This feature allows a guest to set up wakeup calls without having to use the Speech Synthesizer circuit pack.



**NOTE:**

If Wakeup Activation via Tones is enabled, the wakeup feature provided by a Speech Synthesizer circuit pack is disabled from service.

- If a wakeup call is not acknowledged by the guest answering the call, the switch keeps track of these failed wakeups. Use the `Extension to Receive Failed Wakeup LWC Messages` field to assign a message waiting lamp to notify front desk personnel when this happens. See more about this in [“Attendant console button layouts \(switch\)” on page 132](#) and [“Backup telephone button layouts \(switch\)” on page 142](#).

- The speech synthesizer circuit pack allows a guest to set up a wakeup call. If the speech synthesizer is unavailable (busy or out of service), you can administer a backup extension that will receive those wakeup call requests so that they can still be entered into the system. Use the `Routing Extension on Unavailable Voice Synthesis` field to administer a front desk extension that can take those wakeup requests.

```
change system-parameters hospitality                               Page 2 of 3
                                HOSPITALITY

Dual Wakeups? y   Daily Wakeup? y   VIP Wakeup? y
                VIP Wakeups Per 5 Minutes: 5
                Room Activated Wakeup With Tones? y
                Time of Scheduled Wakeup Activity Report:
                Time of Scheduled Wakeup Summary Report:
Time of Scheduled Emergency Access Summary Report:
                Announcement Type: mult-integ
                Default Announcement Extension: 380

Length of Time to Remain Connected to Announcement: 30
Extension to Receive Failed Wakeup LWC Messages: 399
Routing Extension on Unavailable Voice Synthesis: 300
                Display Room Information in Call Display? n
                Automatic Selection of DID Numbers? y
                Custom Selection of VIP DID Numbers? y
                Number of Digits from PMS:
                PMS Sends Prefix? n
                Number of Digits in PMS Coverage Path: 3
                Digit to Insert/Delete:
```

## Call Vectoring (switch)



**NOTE:**

If you use a vector to route calls to a location outside of your hotel, the COR of the vector must route using its own ARS restricted partition to prevent toll fraud, and the Facility Restriction Level (FRL) should be set to 0.

The Call Vectoring feature is used to set up the Automated Attendant feature for incoming calls to the hotel. Coordinate this administration with your customer. To set up an automated attendant, you will need a recorded announcement circuit pack (TN750C), and you will need to record announcements (see [page 159](#)).

You must first assign a vector directory number (VDN) using the **add vdn XXXX** command. The extension number **XXXX** is an unused extension on the switch. You can have up to 40 VDNs depending on the capacity of the system (csi/si is 30; r is 40). One of the VDNs is usually the published telephone number for the hotel. A second VDN could be used by hotel guests to provide a menu of information about hotel services and events. After you add a VDN, you can later change the VDN if needed. For more information about vectors, see the *DEFINITY BCS and GuestWorks Call Vectoring Guide*.

The next step is to create the vector used by callers to access different numbers at the hotel. The following example shows an auto-attendant vector.

```

change vector 1                                     Page 1 of 3
                                     CALL VECTOR
Number: 1                                           Name auto-attd-1
      Basic? y   EAS? n   G3V4 Enhanced? n   ANI/II-Digits? n   ASAI Routing? n
Prompting? y   LAI? n   G3V4 Adv Route? n   CINFO? n   BSR? n   Holidays? y
01 wait-time   2   secs hearing ringback
02 collect     1   digits after announcement 381
03
04 route-to   number 0                               with cov n if digit   = 0
05 route-to   number 105                             with cov n if digit   = 1
06 goto       step 12 if digits                       = 2
07 route-to   number 699                             with cov n if digit   = 3
08 goto       step 20 if digits                       = 4
09 goto       step 16 if digits                       = 5
10 route-to   number 0                               with cov n if unconditionally
11
    
```

change vector 1

CALL VECTOR

Page 2 of 3

```
12 collect      3 digits after announcement 382
13 route-to    digits with coverage y
14 route-to    number 0          with cov n if unconditionally
15
16 goto        step 2    if unconditionally
17
18
19
20 collect      3 digits after announcement 383
21 goto        step 13  if unconditionally
22
```

This vector does the following:

1. The caller hears ringback for 2 seconds.
2. Announcement 381 plays. This announcement asks callers to do one of the following:
  - Press **0** or wait if they want the front desk; if they press **0** or wait for the timeout, they are routed to the front desk.
  - Press **1** if they want the reservation desk; if they press **1**, they are routed to extension 105, which is the reservations desk.
  - Press **2** if they know the guest room extension; if they press **2**, they are routed to announcement 382, which tells them to dial the guest room extension.
  - Press **3** if they want to retrieve their voice messages; if they press **3**, the call is routed to the voice messaging system.
  - Press **4** if they know the department they wish to access (such as catering); if they press **4**, they are routed to announcement 383, which gives them a listing of several extensions at the hotel that they can dial directly.
  - Press **5** to start over again; if they press **5**, the caller hears announcement 381, which repeats all of the options.
  - If the caller dials anything else, the call is routed to the front desk.

## Attendant Vectoring (switch)

Attendant Vectoring enables a set of commands used to write vectors for calls routed to attendant consoles. When Attendant Vectoring is enabled, all attendant-seeking calls using a VDN are processed using the call vectors, not the normal attendant console “dial 0” call routing.

The main reason to use Attendant Vectoring is to allow flexible routing of attendant-seeking calls. If users are instructed to dial an attendant VDN, the call could be answered by an attendant, but it may also be covered to the voice mailbox of a night station. Training users to understand these different call routing options is something you should consider before using Attendant Vectoring.

If you use Attendant Vectoring and night service to route calls to a voice mail system, you can also use the Automatic Message Waiting feature to notify after-hours personnel that there are messages in the night service station mailbox by assigning an AMW lamp on one or more backup telephones. When personnel see that there are new messages, they can check those messages after hours and act upon them as needed.

Attendant vectors are set up no differently than regular vectors, except that you designate the vector as an attendant vector. The following screen shows an attendant vector.

```
change vector 5                                     Page 1 of 3
                                           CALL VECTOR
Number: 5                                           Name attd-vector
           Attendant Vectoring? y                Lock? n
  Basic? y  EAS? n  G3V4 Enhanced? n  ANI/II-Digits? n  ASAI Routing? n
  Prompting? y  LAI? n  G3V4 Adv Route? n  CINFO? n  BSR? n  Holidays? y

01 wait 0 secs hearing
02 goto step 8 if time-of-day is all 12:00 to 13:00
03 queue-to attd-group
04 goto step 8 if queue-fail
05 announcement 9000
06 wait 15 seconds hearing music
07 goto step 5 if unconditionally
08 queue-to attendant 6000
09 goto step 11 if queue-fail
10 wait 999 secs hearing ringback
11 route-to number 93035381000 with cov y if unconditionally
```

## Dial by Name (switch)

The Dial by Name feature allows you to “dial” someone by entering the person’s name from your touch-tone keypad. This feature is accessible by using the Call Vectoring feature and recorded announcements (see [page 159](#)) to create an auto-attendant procedure where one option allows callers to enter a person’s name instead of the person’s extension number. The system processes the name characters received, and, when a single match is found, the number is dialed automatically. For more information about Dial by Name and vectoring, see the *DEFINITY BCS and GuestWorks Call Vectoring Guide*. The Dial by Name feature is available only on GuestWorks and DEFINITY BCS.

You must first assign a VDN using the **add vdn XXXX** command. The extension number **XXXX** is an unused extension on the switch. You can have up to 40 VDNs depending on the capacity of the system (csi/si is 30; r is 40). The VDN used for Dial by Name would be the published telephone number for the hotel.

The next step is to create the vector that enables the Dial by Name feature. The following example shows a vector that includes steps for Dial by Name.

```

change vector 2                                     Page 1 of 3
                                     CALL VECTOR
Number: 2                                     Name: Dial by Name
      Attendant Vectoring? y                   Lock? n
      Basic? y      EAS? n      G3V4 Enhanced? n      ANI/II-Digits? n      ASAI Routing? n
      Prompting? y  LAI? n      G3V4 Adv Route? n      CINFO? n      BSR? n      Holidays? y

01 wait-time      2      secs hearing ringback
02 collect        1      digits after announcement 381
03
04 route-to      number 0                       with cov n if digit      = 0
05 route-to      number 105                     with cov n if digit      = 1
06 goto          step 12 if digits                = 2
07 goto          step 21 if digits                = 3
08 goto          step 19 if digits                = 4
09 goto          step 16 if digits                = 5
10 route-to      number 0                       with cov n if unconditionally
11

```

change vector 2

CALL VECTOR

Page 2 of 3

```
12 collect      3 digits after announcement 382
13 route-to    digits with coverage y
14 route-to    number 0          with cov n if unconditionally
15
16 goto        step 2    if unconditionally
17
18
19 collect      3 digits after announcement 383
20 goto        step 13  if unconditionally
21 collect      4 digits after announcement 661
22 route-to    name1 with coverage y
```

change vector 2

CALL VECTOR

Page 3 of 3

```
23 goto        step 30 if nomatch
24 collect      11 digits after announcement 662
25 route-to    name2 with coverage y
26 goto        step 30 if nomatch
27 collect      2 digits after announcement 663
28 route-to    name3 with coverage y
29 goto        step 30 if nomatch
30 collect      1 digits after announcement 660
31 goto        step 21 if digits = 1
32 route-to    number 0          with cov n if unconditionally
```

This Dial by Name vector does the following:

1. The caller hears ringback for 2 seconds.
2. Announcement 381 plays. This announcement instructs the caller to do one of the following:
  - Press **0** or wait if the caller wants the operator; if the caller presses **0** or waits for the timeout, the caller is routed to the operator.
  - Press **1** if the caller wants the front desk; if the caller presses **1**, the caller is routed to extension 105, which is the front desk.
  - Press **2** if the caller knows the person's extension; if the caller presses **2**, the caller is routed to announcement 382, which tells the caller to dial the person's extension.
  - Press **3** if the caller knows the person's name; if the caller presses **3**, the following sub-procedure occurs:
    - a. Announcement 661 plays requesting that the caller enter the first four letters of the person's last name.  
If there is a single match, the call is redirected.  
If there are multiple matches, continue with [Step b](#).  
If there is no match, go to [Step d](#).
    - b. Announcement 662 plays requesting that the caller enter the rest of the person's last name, followed by the **#** key.  
If there is a single match, the call is redirected.  
If there are multiple matches, continue with [Step c](#).  
If there is no match, go to [Step d](#).
    - c. Announcement 663 plays requesting that the caller enter the first two letters of the person's first name.  
If there is a single match, the call is redirected.  
If there is no match, continue with [Step d](#).
    - d. Since there are no matches, announcement 660 plays telling the caller that they can press **1** to try again, or press **0** to get an operator.
  - Press **4** if the caller knows the department (such as housekeeping) the caller wishes to access. If the caller presses **4**, the caller is routed to announcement 383, which gives the caller a listing of several departments that the caller can dial directly.
  - Press **5** to start over again; if the caller presses **5**, the caller hears announcement 381, which repeats all of the options.
  - If the caller dials anything else, the call is routed to the operator.

## Trunk-to-Trunk Transfer (switch)

Use the **change system-parameters features** command to enable Trunk-to-Trunk Transfer only if it is requested by the customer. This feature is normally disabled because of the possibility of toll fraud.



### CAUTION:

*If Trunk-to-Trunk Transfer is enabled, calls made to guest rooms can be transferred outside of the hotel, and toll charges may be lost for some calls.*

```

change system-parameters features                               Page 1 of 10
      FEATURE-RELATED SYSTEM PARAMETERS
      Self Station Display Enabled? y
      Trunk-to-Trunk Transfer: none
Automatic Callback - No Answer Timeout Interval (rings): 3
      Call Park Timeout Interval (minutes): 10
      Off-Premises Tone Detect Timeout Interval (seconds): 20
      AAR/ARS Dial Tone Required? y
      Music/Tone on Hold: music Port: 01B1101
      Music (or Silence) on Transferred Trunk Calls? no
      DID/Tie/ISDN Intercept Treatment: attd
      Messaging Service Adjunct (MSA) Connected? n
      Internal Automatic Answer for Attendant Extended Calls? n
      Automatic Circuit Assurance (ACA) Enabled? y
      ACA Referral Calls: local
      ACA Referral Destination: attd
      ACA Short Holding Time Originating Extension: 3070
      ACA Long Holding Time Originating Extension: 3070
      Abbreviated Dial Programming by Assigned Lists? n
      Auto Abbreviated/Delayed Transition Interval (rings): 2
      Protocol for Caller ID Analog Terminals: Bellcore
      Display Calling Number for Room to Room Caller ID Calls? n
  
```

## Terminal server for asynchronous links


---

An IOLAN+ four-port terminal server is used to connect adjuncts to the ethernet port of the TN799 C-LAN circuit pack. Options on the terminal server must be administered before you administer each port for a specific adjunct. Administration for those adjuncts are given later in this chapter.

### Connecting a PC for administration

Connect the PC to Port 1 on the terminal server using the RJ45-to-DB25 cable, null modem, and a DB25-to-DB9 adapter/cable. See [Figure 37](#).

---



#### Figure Notes

- |                                 |  |
|---------------------------------|--|
| 1. C-LAN circuit pack in switch | 5. Null modem (provided locally)                             |
| 2. Local area network (LAN)     | 6. PC or laptop (for initial administration)                 |
| 3. Terminal server              | 7. RJ45-to-DB25 cable (4 provided with each terminal server) |
| 4. Adjunct (PMS, for example)   | 8. DB25-to-DB9 adapter/cable                                 |

---

**Figure 37. Connecting a PC to administer the IOLAN+**

## Administering the terminal server

Before beginning the initial administration, make sure you have the following information:

- IP address and subnet mask for terminal server
- Host name for terminal server
- IP address of C-LAN Ethernet interface
- Port number of C-LAN Ethernet interface where adjunct connects.

### Setting up HyperTerminal on the computer

Use the HyperTerminal software program that comes with Windows to administer the terminal server.

To set up HyperTerminal:

1. Open HyperTerminal.
2. Click on **File > Properties > Connect** tab. In the Connect using: field, select **COM *n***, where *n* is the communication port your computer is using.
3. Click on **CONFIGURE** and set the bits per second field to **9600** and the Flow control field to **Hardware**.
4. Click **OK, OK**.
5. Press **ENTER** to get the login prompt.

### Navigating the terminal server

Refer to the terminal server user and administration guide for details. In general,

- Use the arrow keys to move to a menu item.
- Use the **TAB** key to move from field to field horizontally.
- Use the **ENTER** key to choose an item.

## Administering the terminal server the first time

To initially administer the terminal server

1. At the login prompt type any text and press ENTER.
2. At the second prompt type **set term ansi** and press ENTER to view the Connections menu.

```
Name: port 2                CONNECTIONS MENU                Terminal: 2

      Connection      Host
      1                *** FREE ** === Commands ===
      2                *** FREE ** | Telnet      ^T|
      3                *** FREE ** | Rlogin     ^R|
      4                *** FREE ** | Port       ^P|
                               | Admin mode ^A|
                               | CLI        |
                               | Lock        |
                               | Logout     ^D|
                               |=====|

-----

IOLAN PLUS v4.02.00 a CDi                iolan
```

3. Under Connection select Port 1 and press ENTER to access the Commands menu.
4. Select **Admin mode > Password** and press ENTER.

```

Name: port 2                ADMINISTRATION MENU                Terminal: 2

gateway    Examine/modify gateway table.
host       Examine/modify host table.
line       Terminal configuration organised by line.
password   Specify password to allow modification of menu items.
port       Terminal configuration organised by port.
quit       Return to connections menu.
server     Examine/modify Server parameters.
stats      Examine Server statistics.

Password   [          ]

-----

IOLAN PLUS v4.02.00 a CDi                iolan-st

```

5. Type **iolan**, the default password, and press ENTER.  
The Administration Menu changes, offering more options.
6. Select **server** and press ENTER to view the Server Configuration menu.

```

** Administrator **                SERVER CONFIGURATION                Terminal: 2

Name       [iolan      ]                Debug mode   [0      ]
IP address [168.92.1.99 ]
Subnet mask [222.222.0.0   ]
Ethernet address [00:80:d4:03:11:cd]    Ethernet interface [AUTO  ]
Language    [English  ]
Identification [          ]
Lock        [Disabled]
Password limit [5      ]
CR to initiate [No   ]
SNAP encoding [Disabled]
Boot host    [          ]    Boot diagnostics [Enabled ]
Boot file    [          ]
Init file    [          ]
MOTD file    [          ]
Domain name  [          ]
Name server  [          ]    NS Port   [53   ]
WINS server  [          ]

-----

Name used for prompts and message on bottom right of screen.

IOLAN PLUS v4.02.00 a CDi                iolan

```

7. Fill in the following fields with information appropriate to your network. Leave the default settings for all other fields.
  - Name: *the name of the terminal server*
  - IP address: *the IP address of the terminal server as defined on the switch IP Node Names form*
  - Subnet mask: *optional*
8. Press ENTER and select **Save & Exit** to effect the changes.

### Rebooting the terminal server

You must reboot the terminal server any time you change an IP address or Local Port value.

To reboot the terminal server:

1. Press ENTER to view the Administration Menu.

```
** Administrator **                ADMINISTRATION MENU                Terminal: 2

access      Remote System Access (PPP).
change      Change login and/or admin password.
gateway     Examine/modify gateway table.
host        Examine/modify host table.
kill        Kill TCP connections on serial line.
line        Terminal configuration organised by line.
port        Terminal configuration organised by port.
quit        Return to connections menu.
reboot      Reboot Server.
server      Examine/modify Server parameters.
stats       Examine Server statistics.
trap        Examine/modify SNMP Trap parameters.

Port                [ 2 ]

-----

IOLAN PLUS v4.02.00 a CDi                iolan
```



**NOTE:**

The following steps re-initialize the IOLAN+ so it knows it's connected to the LAN through its IP address.

2. Select **reboot** and press ENTER.
3. Press the space bar to restart the terminal server.

## Administering the gateway



**NOTE:**

If the C-LAN circuit pack and terminal server are in the same subnet, skip this procedure.

To administer the gateway:

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **gateway** to access the Gateway menu
4. Fill in the following fields for Entry 1:
  - Destination: *C-LAN IP address on the switch IP Node Names form*
  - Gateway: *Gateway address*
  - Netmask: *Subnet mask*



**NOTE:**

The following steps reinitialize the terminal server so it knows it is connected to the LAN through your gateway.

5. Select **reboot** and press ENTER.
6. Press the space bar to restart the terminal server.

## Switch-to-PMS link translations and testing

---

Administration of the switch-to-PMS link includes the following:

- Hospitality parameters ([page 189](#))
- Link connectivity, which is administered one of two ways:
  - TCP/IP link using the C-LAN circuit pack ([page 193](#))
  - DCP link using the network control (netcon) data module for *si* system ([page 197](#)) and a processor data module on all systems ([page 198](#))
- Housekeeping status feature access codes and definitions ([page 198](#))
- Controlled restrictions ([page 200](#)).

### Hospitality parameters

---

Use the **change system-parameters hospitality** command to administer the hospitality parameters for the PMS. These assignments must be coordinated with the PMS vendor and the customer. On Page 1, administer the following:

- For the `Message Waiting Configuration` field, enter **act-nopms** if the INTUITY is controlling the message waiting lamps, and enter **act-pms** if the PMS is controlling the message waiting lamps. If the PMS supports text messaging, enter **act-pms**. If all messaging is handled on the INTUITY system, enter **act-nopms**.
- The `Controlled Restrictions Configuration`, `Housekeeper Information Configuration`, and `Client Room Coverage Path Configuration` fields control features offered by some PMS vendors. If the PMS vendor supports the feature, enter **act-pms** in the corresponding field. If the PMS vendor does not support the feature, enter **act-nopms** in the corresponding field. Note that if the `Client Room Coverage Path Configuration` field is administered incorrectly, administered coverage paths for rooms will be deleted.
- In the `PMS Endpoint` field, enter **PMS** for a TCP/IP link using a terminal server, or enter the extension number of the PMS data module for a DCP link.

- If the PMS Protocol Mode is **transparent** (also known as *Names* protocol), set the Seconds before PMS Link Idle Timeout to **20** and the Milliseconds before PMS Link Acknowledgement Timeout to **500**.

If the PMS Protocol Mode is **normal**, set the Seconds before PMS Link Idle Timeout to **20** and the Milliseconds before PMS Link Acknowledgement Timeout to **300**.

If the PMS supports the ASCII data mode, enter a **y** in the ASCII mode field, set the Seconds before PMS Link Idle Timeout to **20**, and the Milliseconds before PMS Link Acknowledgement Timeout to **500**.

- The PMS Link Maximum Retransmissions field indicates the number of times that the switch will retransmit a message to the PMS in response to a negative acknowledgment or send an inquiry for acknowledgment from the PMS before giving up on the message. Valid entries are **1** to **5**.
- The PMS Link Maximum Retransmission Requests field indicates the number of times that the switch will allow the PMS to request acknowledgment for a message that it sent. Valid entries are **1** to **5**.
- The Take Down Link for Lost Messages field indicates whether the link will be taken down if messages are being lost. If set to **n**, you should monitor the PMS error log to see if the link is operating correctly.

```
change system-parameters hospitality                               Page 1 of 3
                                HOSPITALITY

                                Message Waiting Configuration: act-nopms
                                Controlled Restrictions Configuration: act-pms
                                Housekeeper Information Configuration: act-pms
                                Number of Housekeeper ID Digits: 0
                                PMS Log Endpoint:
                                Journal/Schedule Endpoint:
                                Client Room Coverage Path Configuration: act-nopms
                                Default Coverage Path for Client Rooms: 1
                                Forward PMS Messages to Intuity Lodging? y

                                PMS LINK PARAMETERS
                                PMS Endpoint: 7899
                                PMS Protocol Mode: transparent ASCII mode? y
                                Seconds before PMS Link Idle Timeout: 20
                                Milliseconds before PMS Link Acknowledgement Timeout: 500
                                PMS Link Maximum Retransmissions: 5
                                PMS Link Maximum Retransmission Requests: 5
                                Take Down Link for Lost Messages? y
```



**NOTE:**

Use the commands **busyout pms-link** followed by **release pms-link** whenever you change the link timer values.

On Page 2, administer the following:

- The `Number of Digits From PMS` field should be left blank, and the `Digit to Insert/Delete` field may need to be administered. If the room numbers use a combination of 3- and 4-digit or 4- and 5-digit extension numbers, you must enter the leading digit that must be inserted when sent from the PMS to the switch and that must be deleted when sent from the switch to the PMS.



**NOTE:**

The PMS interface supports 3-, 4-, or 5-digit extensions, but be aware that prefixed extensions do not send the entire number across the interface. Only the assigned extension number is sent. Therefore, you should not use prefixed extensions for numbers that are also going to use the Insert/Delete Digit function.

This works as shown in the following example:

- **Digit Insertion** — If the digits received by the switch are 123, and the insertion digit is 7, extension 7123 is checked to see if it is a valid extension. If 7123 is valid, the message is processed for extension 7123; if extension 7123 is not valid, the switch assumes that the message is for extension 123 and processes it accordingly. If both 7123 and 123 are valid, the message will only be processed for extension 7123. Numbering conflicts such as this should be avoided when possible.
- **Digit Deletion** — The switch checks the extension number before the number is sent to the PMS. If the extension number contains the maximum number of digits translated for a leading digit, and the leading digit matches the administered Insert/Delete digit, the digit is deleted before sending the extension to the PMS.

For example, if the Insert/Delete digit is 7, and extensions 712 and 7123 are valid on the switch, 712 will be sent as 712; however, 7123 is sent as 123. This example presumes that there are no 5-digit extensions starting with 7 on the switch.

- The `PMS Sends Prefix` field indicates whether the PMS sends a prefix digit to the switch as part of the room numbering plan.



**NOTE:**

If the `PMS Sends Prefix` field is set to **n**, and the `Number of Digits from PMS` field is blank, the switch will not support an extension that starts with **0**.

- The Number of Digits in PMS Coverage Path field indicates whether the coverage paths are **3** or **4** digits long.

```
change system-parameters hospitality                               Page 2 of 3
                        HOSPITALITY

Dual Wakeups? y      Daily Wakeup? y      VIP Wakeup? y
                    VIP Wakeups Per 5 Minutes: 5
                    Room Activated Wakeup With Tones? y
                    Time of Scheduled Wakeup Activity Report:
                    Time of Scheduled Wakeup Summary Report:
Time of Scheduled Emergency Access Summary Report:
                    Announcement Type: mult-integ
                    Default Announcement Extension: 380

Length of Time to Remain Connected to Announcement: 30
Extension to Receive Failed Wakeup LWC Messages: 399
Routing Extension on Unavailable Voice Synthesis:
Display Room Information in Call Display? n
Automatic Selection of DID Numbers? y
Custom Selection of VIP DID Numbers? y
                    Number of Digits from PMS:
                    PMS Sends Prefix? n
                    Number of Digits in PMS Coverage Path: 3
                    Digit to Insert/Delete:
```

## Link connectivity administration

---

The switch-to-PMS link is administered in one of two ways:

- TCP/IP using the C-LAN circuit pack (R9 or later)
- DCP using a data module.

### TCP/IP link administration

To administer the switch-to-PMS link using the C-LAN circuit pack:

- Administer node names and IP addresses for the switch and the terminal server on the IP Node Names form.
- Administer service types, local nodes, and remote nodes on the IP Services form.
- Administer a TCP “listen” port on the terminal server.

### Administering node names and IP addresses

Using the **change node-names ip** command, assign node names and IP addresses for both the switch and the terminal server. In this example, the switch is named **guestworks** and the IP address is **192.168.1.10**. The terminal server is named **terminalserver** and the IP address is **192.168.1.99**. The IP addresses in this example are non-public addresses. Use this IP address if you are installing a dedicated direct link between the switch and the INTUITY system. The **default** node name entry is display-only and is not used for this application. You can add the node names in any order on this screen; the next time you display the node names, they will be in alphabetical order.

```
change node-names ip
```

```
Page 1 of 1
```

```
IP NODE NAMES
```

Name	IP Address	Name	IP Address
default	0 .0 .0 .0		. . .
guestworks	192.168.1 .10		. . .
terminalserver	192.168.1 .99		. . .
	. . .		. . .

## Administering IP services

Using the **change ip-services** command, assign the following:

- Service Type — Enter **PMS**.
- Local Node — Enter the node name for the switch. In this example, **guestworks** is the local node.
- Local Port — Enter **0**. This is the recommended default for the PMS service type.
- Remote Node — Enter node name for the terminal server. In this example, **terminalserver** is the remote node.
- Remote Port — Enter the TCP listen port assigned to the terminal server port that is physically connected to the PMS. The recommended value for PMS is **5103**. The TCP listen port is administered on the terminal server.
- Protocol Enabled — Not used for PMS.

```
change ip-services                                     Page 1 of 3

                IP SERVICES
Service  Enabled  Local   Local  Remote  Remote
Type     Enabled  Node    Port   Node    Port
-----  -
PMS      yes    guestworks  0    terminalserver 5103
```

## Administering a port on the terminal server

The initial options on the terminal server must be administered before you administer a port (see [“Terminal server for asynchronous links” on page 183](#)). Use this procedure when connecting the PMS to the terminal server (see [Figure 37 on page 183](#)).

To administer a port on the terminal server:

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **port** and press ENTER.
4. Type **port number**, where **port number** is the port that the adjunct connects to, and press ENTER to view the Port Setup Menu.

```

** Administrator **                PORT SETUP MENU                Terminal: 2
Hardware                            Flow ctrl                    Keys
Speed      [9600 ]                 Flow ctrl [None ]           Hot   [^]   Intr  [^C]
Parity     [None]                 Input Flow [Enabled ]       Quit  [^@]  Kill  [^U]
Bit        [8]                   Output Flow [Enabled ]      Del   [^@]  Sess  [^@]
Stop       [1 ]
Break      [Disabled]             IP Addresses
Monitor DSR [Yes ]               Src   [
Monitor DCD [No ]                Dst   [

User
Name [pms ]                     Keepalive [No ]             Access [Remote ]
Terminal type [undef ]          Rlogin/Telnet [Telnet]     Authentication [None ]
TERM [ ]                         Debug options [No ]        Mode [Raw ]
Video pages [0]                 Map CR to CR LF [No ]     Connection [None ]
CLI/Menu [Menu]                 Hex data [No ]             Host [
Reset Term [No ]                Secure [No ]                Remote Port [0 ]
MOTD [No ]                      Local Port [5103 ]

```

---

5. Fill in the following fields. Leave the default settings for all other fields.
  - Speed: *must match the PMS port speed* (default is 9600)
  - Monitor DSR: Yes
  - Name: pms
  - Flow ctrl: None
  - Access: Remote
  - Mode: Raw
  - Remote Port: 0 (*C-LAN Ethernet port where IP adjunct service is offered*)
  - Local Port: 5103 (*must match the value of Remote Port on the DEFINTY IP Services screen*)
6. Press ENTER and select **Save & Exit** to effect the changes.
7. Press ENTER again to view the Administration Menu.
8. Select **kill** to disable the port connection.
9. When administration is complete, from the Connections Menu, select **logout** (or press **Ctrl D**).
10. Close HyperTerminal.
11. Continue with ["Housekeeping status" on page 198](#).

### DCP link administration

To administer the switch-to-PMS link using a DCP data module:

- Administer the netcon internal data module (si systems only).
- Administer a link processor external data module (all systems).

### Network Control (Netcon) data module

Use the **add data-module** command to administer the internal netcon data module on an *si* system.

```

add data-module 7891
                                DATA MODULE

Data Extension: 7891             Name: NETCON 01                 BCC: 2
                                Type: netcon                   COS: 15           Maintenance Extension: 7995
Physical Channel: 01             COR: 50
                                ITC: restricted                TN: 1

ABBREVIATED DIALING
List1:

SPECIAL DIALING OPTION:

ASSIGNED MEMBER ( Station with a data extension button for this data module )

Ext      Name
1:
    
```

You should assign all four netcon channels. The following table is an example of how you can administer the netcon channels:

<b>Data Extension</b>	<b>Physical Channel</b>	<b>Maintenance Extension</b>
7891	01	7895
7892	02	7896
7893	03	7897
7894	04	7898

## Link data modules

Use the **add data-module** command to administer the external data module connected between the switch and the PMS.

```

add data-module 7899
                                DATA MODULE

Data Extension: 7899           Name: PMS LINK                BCC: 2
Type: pdm                     COS: 1                Remote Loop-Around Test? n
Port: 01B0102                 COR: 50             Secondary data module? n
ITC: restricted                TN: 1                Connected to: dte

ABBREVIATED DIALING
List1:

SPECIAL DIALING OPTION:

ASSIGNED MEMBER ( Station with a data extension button for this data module )

Ext      Name
1:
    
```

## Housekeeping status

Use the **change feature-access-codes** command to assign the housekeeping status feature access codes. Administer only the feature access codes that the vendor supports and that match the status definitions.

```

change feature-access-codes
                                FEATURE ACCESS CODE (FAC)
                                Hospitality Features

Automatic Wakeup Call Access Code: *98
Housekeeping Status (Client Room) Access Code: *81
Housekeeping Status (Client Room) Access Code: *82
Housekeeping Status (Client Room) Access Code: *83
Housekeeping Status (Client Room) Access Code: *84
Housekeeping Status (Client Room) Access Code:
Housekeeping Status (Client Room) Access Code:
Housekeeping Status (Station) Access Code:
Verify Wakeup Announcement Access Code: *89
Voice Do Not Disturb Access Code: *33
    
```

Use the **change system-parameters hospitality** command to define whether the housekeeping staff will use IDs, and to administer the housekeeping status definitions.

On Page 1, the **Number of Housekeeper ID Digits** field determines the length of the housekeeping staff ID numbers. Valid entries are **0** to **6**. If set to **0**, housekeeping IDs are not used.

```
change system-parameters hospitality                               Page 1 of 3
                        HOSPITALITY

                        Message Waiting Configuration: act-nopms
                        Controlled Restrictions Configuration: act-pms
                        Housekeeper Information Configuration: act-pms
                        Number of Housekeeper ID Digits: 0
                        PMS Log Endpoint:
                        Journal/Schedule Endpoint:
                        Client Room Coverage Path Configuration: act-nopms
                        Default Coverage Path for Client Rooms: 1
                        Forward PMS Messages to Intuity Lodging? y

                        PMS LINK PARAMETERS
                        PMS Endpoint: 7899
                        PMS Protocol Mode: transparent ASCII mode? y
                        Seconds before PMS Link Idle Timeout: 20
                        Milliseconds before PMS Link Acknowledgement Timeout: 500
                        PMS Link Maximum Retransmissions: 5
                        PMS Link Maximum Retransmission Requests: 5
                        Take Down Link for Lost Messages? y
```

On Page 2, enter the definitions for each room state. The status for each of these must be coordinated with what is administered in the PMS.

```
change system-parameters hospitality                               Page 3 of 3
                        HOSPITALITY

ROOM STATES
  Definition for Rooms in State 1: Occupied/dirty
  Definition for Rooms in State 2: Occupied/maid In Room
  Definition for Rooms in State 3: Occupied/clean
  Definition for Rooms in State 4: Vacant/clean
  Definition for Rooms in State 5:
  Definition for Rooms in State 6:

HOSPITALITY FEATURES
  Suite Check-in? y
```

## Controlled Restrictions

When Controlled Restrictions are applied to guest rooms, calls made to those rooms or from those rooms are routed to intercept treatment. The recommended intercept treatment is shown in the following example. Use the **change system-parameters features** command to set the controlled restriction intercept treatment.

```
change system-parameters features                               Page 3 of 10
                    FEATURE-RELATED SYSTEM PARAMETERS

                    Reserved Slots for Attendant Priority Queue: 5
                                Time before Off-hook Alert: 10
                    Emergency Access Redirection Extension:
Number of Emergency Calls Allowed in Attendant Queue: 5
                                Call Pickup Alerting? n
                    Temporary Bridged Appearance on Call Pickup? y
                                Call Pickup on Intercom Calls? y
                                Directed Call Pickup? n
                                Extended Group Call Pickup: none
                    Deluxe Paging and Call Park Timeout to Originator? y
Controlled Outward Restriction Intercept Treatment: attendant
Controlled Termination Restriction (Do Not Disturb): coverage
Controlled Station to Station Restriction: attendant
AUTHORIZATION CODE PARAMETERS      Authorization Codes Enabled? y
                                Authorization Code Length: 7
                                Authorization Code Cancellation Symbol: #
                                Attendant Time Out Flag? n
                                Display Authorization Code? y
Controlled Toll Restriction Replaces: station-station
```

The PMS automatically applies controlled restrictions to guest rooms as guests check in and check out. If the PMS link is down, you will have to apply and remove controlled restrictions manually. Administer the controlled restriction feature access codes using the screens beginning on [page 112](#). You can also assign feature buttons on the attendant console for the Controlled Restrictions feature. See [“Attendant console button layouts \(switch\)” on page 132](#) for more information.

Optionally, customers can substitute Toll Restriction for the standard Outward or Station-to-Station restrictions. Using the `Controlled Toll Restriction replaces` field, you can enter **none**, **outward**, or **station-station**. If you enter **none**, the customer has access to Outward, Total, Termination, and Station-to-Station restrictions. If you enter **outward**, the customer has access to Toll, Total, Termination, and Station-to-Station restrictions. If you enter **station-station**, the customer has access to Outward, Total, Termination, and Toll restrictions. In this example, Toll Restriction is substituted for Station-Station Restriction.

Instruct customers to use the *GuestWorks and DEFINITY ECS Hospitality Operations* document to learn more about Controlled Restrictions and how to use them.

## Testing the switch-to-PMS link

---

To test the switch-to-PMS link, have the hotel designate a room for testing. Testing the switch-to-PMS link includes the following:

- Link testing with the RS232 mini-tester ([page 202](#))
- Netcon and data module testing ([page 204](#))
- PMS testing and status ([page 205](#))
- Database swap testing ([page 207](#))
- Check-in and check-out testing ([page 208](#))
- Message waiting testing (both manual messages and voice messages) ([page 209](#))
- Controlled restrictions testing ([page 212](#))
- Housekeeping status testing ([page 213](#)).

During the switch-to-PMS testing, you will use the **list pms-down** command often to view events that may indicate problems with the link. These events are found in "[Appendix C — List PMS down events](#)" on [page 289](#).

## Switch-to-PMS link testing with the RS232 Mini-Tester

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the PMS link. The leads marked with an asterisk are controlled by the switch, and the PMS controls the other leads. If any switch leads are dark, there is no connection.



### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

If the link to a PMS is active, the mini-tester should show the following. The Physical Link State should be up, and the Protocol State should be up. If this is the status of the link, proceed to [“Netcon and link data module testing” on page 204](#). Otherwise, look at the other results in this section.

TD ● red	
	red ● RD*
RTS ● green	
	green ● CTS*
DSR* ● green	
	green ● DTR
CD* ● green	

If the link is idle, the mini-tester may show the following. The Physical Link State will be down, and the Protocol State will be down. Possible causes may be that the switch or PMS are not administered correctly, or the PMS software is not running.

TD ● red	
	red ● RD*
RTS ● red	
	red ● CTS*
DSR* ● red	
	red ● DTR
CD* ● red	



### NOTE:

The CTS lead shows green when used with an 8400B. RTS will be lit on the front panel of the 7400A and 7400B.

If the link to a PMS is idle, the mini-tester may also show the following. The Physical Link State will be down, and the Protocol State will be down. Possible causes may be that the PMS hardware is powered-up, but the switch is not administered correctly, or the PMS link is busied out at the switch.

TD ● red	
RTS ● green	red ● RD*
DSR* ● red	red ● CTS*
CD* ● red	green ● DTR



**NOTE:**

The CTS lead shows green when used with an 8400B. RTS will be lit on the front panel of the 7400A or 7400B.

## Netcon and link data module testing

If the switch-to-PMS link uses TCP/IP, skip this test. To test the netcon and the data modules for a DCP link:

1. Use the **status data-module XXXX** command (where **XXXX** is the extension of the netcon data module).

```
status data-module 7891
                                DATA-MODULE STATUS
Data Ext/Stn Ext for Stn DM: 7891      Service State: in-service/active
Port/Channel Number: 01A0502          Maintenance Busy? no
                                      CF Destination Ext:

Connected Ports: 01AXX01
```

If the status message shows that the netcon data module is in the in-service/active state and shows the connected port of the actual data module, this indicates that there was an available netcon data channel and that the data module extension has been added to the hospitality parameters screen.

If the status message shows that the netcon data module is in the in-service/idle state, the PMS link may have been busied out. Release the PMS link.

2. Use the **status data-module XXXX** command (where **XXXX** is the extension of the PMS link data module).

```
status data-module 7899
                                DATA-MODULE STATUS
Data Ext/Stn Ext for Stn DM: 7899      Service State: in-service/active
Port/Channel Number: 01AXX01          Maintenance Busy? no
                                      CF Destination Ext:

Connected Ports: 01A0502
```

If the status message shows that the PMS link data module is in the in-service/active state and shows the connected port of the netcon, this indicates that the PMS link data module extension has been added to the hospitality parameters screen.

If the status message shows that the netcon data module is in the in-service/idle state, the PMS link may not be providing DTR. Contact the PMS vendor for assistance.

3. Dial the netcon extension and the PMS link data module extension. If these facilities are operational, you will hear a high-pitched data tone.

## PMS testing and status

Use the **test pms** command to test the PMS link. If the link is not active, this command sometimes causes the link to be established. The PMS test (Test 215) must pass before you proceed with further testing.

Use the **status pms-link** command to display the current status of the PMS link. The following is an example of that screen:

```
status pms-link
                PMS LINK STATUS

Physical Link State: Down
  Protocol State: Down

Maintenance Busy? No
Database Swapping? No
```

The fields are defined as follows:

- **Physical Link State** — If the link state is `Up`, the transmit/receive lamps will be flashing, and all lamps except for the ringing indicator lamp will be lit. This indicates that the link is active, and the call has been placed from the netcon to the data module.
- **Protocol State** — If the protocol state is `Up`, the data module carrier detect lamp is lit, and at least one status inquiry message has been received and understood from the PMS. The data module transmit/receive lamps will be flashing if the switch is talking with the PMS. If the lamps stay on longer than the link idle timeout setting (usually 20 seconds), the switch and the PMS are communicating. If the TD lamp flashes every 15 to 20 seconds, this indicates that the PMS is sending data to the switch.
- **Number of Retries** — This count increments every 5 minutes for the first 12 retries, and then every 15 minutes until the link is established. A high number of retries could indicate that the netcon data channel is not available because too many resources are assigned, or the data module could be busy. If there are no retries to report, this field is not displayed.
- **Maintenance Busy?** — This field shows whether the link is currently maintenance busied-out. If the link is not maintenance busied-out, this field is not displayed.
- **Database Swapping?** — If the field displays `yes`, the room images are being transmitted between the switch and the PMS. If the field displays `pending`, the database swap has been requested by the switch. If the field displays `no`, the PMS link is up.

Use the **status link X** command to display the active TCP/IP applications. **X** is the TCP/IP link number. In this example of Page 4, the system shows the current activity of the different IP services. The PMS service should show one active session.

```
status link 1                                     Page 4 of 4
TCP/IP Applications Currently Active

Service Type      Sessions
ALARM1            1
ALARM2            1
CDR1              1
CDR2              0
DOLAN             0
PMS               1
PMS_JOURNAL       1
PMS_LOG           0
SAT               3
SYS_PRNT          1
```

## Database swap testing

To test database swapping:

1. Busy-out the PMS link using the **busyout pms-link** command.
2. Do a check-in or check-out on the test room from the attendant console or backup telephone. This sets the flag for the switch to request a database swap from the PMS.
3. Release the PMS link using the **release pms-link** command.
4. Use the **status pms-link** command to verify the database swap between the switch and the PMS. A database swap can take from 20 minutes to 1 hour. If the database swap completes immediately, the PMS may only be set up for an “empty swap” as opposed to a full swap. Contact the PMS vendor and request that the vendor change the system setup to do a full swap when one is requested by the switch.

```
status pms-link
                PMS LINK STATUS

Physical Link State: Up
  Protocol State: Up

Database Swapping? Yes
```



**NOTE:**

Before the database swapping begins, the Database Swapping field may show Pending.

5. When the database swapping is complete, the Database Swapping field displays No. Use the **status station XXXX** command (where **XXXX** is a guest room number) on a few guest rooms to confirm that the check-in and check-out status agrees between the switch and the PMS.
6. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

## Check-in and check-out testing

To test check-in and check-out:

1. Do a check-in for the test room from the PMS terminal.
2. Use the **status station XXXX** command (where **XXXX** is the test room number). The status should appear as follows:

```

status station 1005                                     Page 1 of 1
                                           GENERAL STATUS

                Type: 2500                               Service State: in-srv/on-hook or disc
                Extension: 1005                         Download Status: not-applicable
                Port: 01B0601                           SAC Activated? no
                Call Parked? no                          User Cntrl Restr: none
                Ring Cut Off Act? No                    Group Cntrl Restr: none
                Active Coverage Option: 1                 CF Destination Ext:

                Message Waiting:
                Connected Ports:

                ACD STATUS                                HOSPITALITY STATUS
                Grp/Mod Grp/Mod Grp/Mod Grp/Mod Grp/Mod  AWU Call At:
                / / / / /                               User DND: not activated
                / / / / /                               Group DND: not activated
                / / / / /                               Room Status: occupied
                On ACD Call? no
    
```

At check-in, the `Room Status` field displays `occupied`, and the `User Cntrl Restr` field displays `none`. If an occupied room's restriction is set to `outward`, this indicates that the guest is a cash-paying customer and is restricted from placing calls external to the switch.

3. Use the **list station** command to list the guest room stations. The test room guest name, as well as other guest names received on a database swap, should display on that listing.
4. Use the **list maintenance pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
5. Do a check-out on the test room.
6. Run the **status station XXXX** command again.

The `Room Status` field should be `vacant`, and the restrictions should be set to `outward`.

7. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

## Message waiting testing

You must test manual message waiting and voice messaging (if installed). To test manual message waiting:

1. From the PMS terminal, activate manual message waiting for the test room.
2. Use the **status station XXXX** command (where **XXXX** is the test room number). The status should appear as follows:

```
status station 1005

                                GENERAL STATUS

                                Type: 2500                Service State: in-srv/on-hook or disc
                                Extension: 1005            Download Status: not-applicable
                                Port: 01B0601             SAC Activated? no
                                Call Parked? no           User Cntrl Restr: none
                                Ring Cut Off Act? No      Group Cntrl Restr: none
                                Active Coverage Option: 1  CF Destination Ext:

Message Waiting: pms
Connected Ports:

                                ACD STATUS                HOSPITALITY STATUS
                                Grp/Mod Grp/Mod Grp/Mod Grp/Mod Grp/Mod  AWU Call At:
                                / / / / /                    User DND: not activated
                                / / / / /                    Group DND: not activated
                                / / / / /                    Room Status: occupied
                                / / / / /
                                On ACD Call? no
```

3. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
4. Deliver the message from the PMS terminal.
5. Run the **status station XXXX** command again.  
The Message Waiting field should be blank.
6. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

To test voice messaging by retrieving the message from the test room:

1. Call the test room.
2. Leave a message after the greeting and tone.
3. Use the **status station XXXX** command (where **XXXX** is the test room number). The status should appear as follows:

```

status station 1005

                                GENERAL STATUS

                Type: 2500                Service State: in-srv/on-hook or disc
            Extension: 1005                Download Status: not-applicable
                Port: 01B0601            SAC Activated? no
            Call Parked? no                User Cntrl Restr: none
            Ring Cut Off Act? No          Group Cntrl Restr: none
            Active Coverage Option: 1      CF Destination Ext:

Message Waiting: audix
Connected Ports:

                                ACD STATUS                HOSPITALITY STATUS
            Grp/Mod Grp/Mod Grp/Mod Grp/Mod Grp/Mod      AWU Call At:
            / / / / /                                     User DND: not activated
            / / / / /                                     Group DND: not activated
            / / / / /                                     Room Status: occupied
            / / / / /
            On ACD Call? no
    
```

4. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
5. From the test room, call the voice messaging system. You will hear “Welcome to the guest voice mail system. You have one new message.” Listen to the message, and then delete the message.
6. Run the **status station XXXX** command again.  
The Message Waiting field should be blank.
7. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

To test voice messaging by retrieving the message from the attendant console:

1. Call the test room.
2. Leave another message after the greeting and tone.
3. Use the **status station XXXX** command (where **XXXX** is the test room number). The status should appear as follows:

```

status station 1005
                                GENERAL STATUS

                                Type: 2500                Service State: in-srv/on-hook or disc
                                Extension: 1005            Download Status: not-applicable
                                Port: 01B0601             SAC Activated? no
                                Call Parked? no           User Cntrl Restr: none
                                Ring Cut Off Act? No      Group Cntrl Restr: none
                                Active Coverage Option: 1  CF Destination Ext:

Message Waiting: audix
Connected Ports:

                                ACD STATUS                HOSPITALITY STATUS
                                Grp/Mod Grp/Mod Grp/Mod Grp/Mod Grp/Mod  AWU Call At:
                                / / / / /                    User DND: not activated
                                / / / / /                    Group DND: not activated
                                / / / / /                    Room Status: occupied
                                / / / / /
                                On ACD Call? no
    
```

4. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
5. From the attendant console or backup telephone, call the voice messaging system. You will hear “Please enter your room extension.” Enter the test room extension. You will hear “You have one new voice mail message.” Listen to the message, and then delete the message.
6. Run the **status station XXXX** command again.  
The Message Waiting field should be blank.
7. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

## Controlled Restrictions testing

To test Controlled Restrictions:

1. From the PMS terminal, activate Outward Restriction on the test room.
2. Use the **status station XXXX** command (where **XXXX** is the test room number). The status should appear as follows:

```

status station 1005

                                GENERAL STATUS

                Type: 2500                Service State: in-srv/on-hook or disc
                Extension: 1005            Download Status: not-applicable
                Port: 01B0601              SAC Activated? no
                Call Parked? no            User Cntrl Restr: outward
                Ring Cut Off Act? No       Group Cntrl Restr: none
                Active Coverage Option: 1    CF Destination Ext:

                Message Waiting:
                Connected Ports:

                                ACD STATUS                HOSPITALITY STATUS
                Grp/Mod Grp/Mod Grp/Mod Grp/Mod Grp/Mod  AWU Call At:
                / / / / /                               User DND: not activated
                / / / / /                               Group DND: not activated
                / / / / /                               Room Status: occupied
                / / / / /
                On ACD Call? no
    
```

3. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
4. From the PMS terminal, deactivate Outward Restriction on the test room.
5. Run the **status station XXXX** command again.  
The `User Cntrl Restr` field should be none.
6. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).

## Housekeeping status testing

To verify that the housekeeping status is updated:

1. Using a telephone in the test room, update the housekeeping status. If the PMS confirms the status change within 4 seconds, you will hear confirmation tone. If the status was not accepted, you will hear reorder tone. If you dialed an invalid code, you will hear intercept tone.
2. Verify that the status changed at the PMS terminal. You can also check the housekeeping status from the attendant console.
3. Use the **list pms-down** command to display any PMS messages that may help you troubleshoot link problems. The meanings of the PMS messages are found in [“Appendix C — List PMS down events” on page 289](#).
4. At a telephone designated for housekeeping updates, update the housekeeping status for the test room. If the PMS confirms the status change within 4 seconds, you will hear confirmation tone. If the status was not accepted, you will hear reorder tone. If you dialed an invalid code, you will hear intercept tone.
5. Verify that the status changed at the PMS terminal. You can also check the housekeeping status from the attendant console.

Provide a list of feature access codes and housekeeping status codes to the customer and the PMS vendor.

## Switch-to-voice messaging translations and testing

Table 12 is a checklist of the translations and tests that must be done to administer the switch-to-voice messaging link.

**Table 12. Checklist for Switch-to-voice messaging translations**

✓	Description
	Switch-to-voice messaging link — Depending on the hardware, use only one of these three configurations: - <a href="#">“TCP/IP signaling” on page 215</a> - <a href="#">“X.25 signaling” on page 231</a> - <a href="#">“Mode Code Integration” on page 238</a>
	<a href="#">“Voice ports (switch)” on page 240</a>
	<a href="#">“Hunt groups for voice ports (switch)” on page 243</a>
	<a href="#">“Extensions for guest message retrieval (switch)” on page 245</a>
	<a href="#">“Call Coverage path (switch)” on page 246</a>
	<a href="#">“INTUITY AUDIX voice ports (INTUITY)” on page 247</a>
	<a href="#">“Services to phone number mapping (INTUITY)” on page 249</a>
	<a href="#">“Attendant and administrator passwords (INTUITY)” on page 250</a>
	<a href="#">“Testing the switch-to-INTUITY voice ports” on page 251</a>

### Switch-to-voice messaging link

There are three ways you can set up the messaging link between the switch and the voice messaging system:

- [“TCP/IP signaling” on page 215](#) (this is the only method used with the InnLine 2020 system)
- [“X.25 signaling” on page 231](#)
- [“Mode Code Integration” on page 238](#)

This link requires administration on the switch and the voice messaging system.

## TCP/IP signaling

The TCP/IP signaling link requires administration on both the switch and the voice messaging system. Any switch type (csi, si or r) can use a TCP/IP link. The TCP/IP link supports the PMS Interface for GuestWorks (see [page 253](#)). This section includes procedures for testing the link.

### TCP/IP link (switch)

On the switch, you must do the following to administer the TCP/IP link:

1. Assign the bus bridge (*csi* systems only)
2. Assign node names
3. Assign IP interfaces
4. Assign an ethernet data module
5. Assign a processor interface channel
6. Assign IP routes (if needed).

*Assign the bus bridge (csi systems only)*

Using the **change system-parameters maintenance** command, Page 2, verify that the Bus Bridge Packet Interface 2 has been enabled for the C-LAN circuit pack. If it is not already assigned, enter the C-LAN circuit pack equipment location, and use the defaults for the Timeslot Port fields as shown below.

```
change system-parameter maintenance                               Page 2 of 4
                                MAINTENANCE-RELATED SYSTEM PARAMETERS

MINIMUM MAINTENANCE THRESHOLDS ( Before Notification )
    TTRs: 4          CPTRs: 1          Call Classifier Ports:
    MMIs: 0          VCs:

TERMINATING TRUNK TRANSMISSION TEST (Extension)
    Test Type 100:          Test Type 102:          Test Type 105:

ISDN MAINTENANCE
    ISDN-PRI TEST CALL Extension:          ISDN BRI Service SPID:

DS1 MAINTENANCE
    DSO Loop-Around Test Call Extension:

LOSS PLAN (Leave Blank if no Extra Loss is Required)
    Minimum Number of Parties in a Conference Before Adding Extra Loss:

SPE OPTIONAL BOARDS
    Packet Intf1? y          Packet Intf2? y
    Bus Bridge: 03C05      Inter-Board Link Timeslots Pt0: 6 Pt1: 1 Pt2: 1
```



*Assign IP interfaces*

Use the **change ip-interfaces** command to administer a C-LAN circuit pack as an IP interface.

- `Enable Eth Pt` — Enter **y** to enable the C-LAN IP interface. After initial administration, you must disable the interface before you make any changes.
- `Type` — Enter **C-LAN**.
- `Slot` — Enter the equipment location of the C-LAN circuit pack.
- `Code/Sfx` — This is a display-only field that shows the designation number of the circuit pack installed in the specified slot.
- `Node Name` — Enter the switch node name assigned on Page 2 of the Node Names screen. In this example, enter **guestworks**. The same node name cannot be assigned to two different IP interfaces.
- `Subnet Mask` — Identifies which portion of an IP address is a network address and which is a host identifier. Use the default entry of 255.255.255.0, or check with the LAN administrator on site if connecting through the customer’s LAN.
- `Gateway Address` — Enter the address of a network node that will serve as the default gateway for the IP interface. If the application goes to points off the subnet, a gateway address of the router is required. If the switch and the INTUITY are on the same subnet, a gateway address is not required. If using ethernet only, and a gateway address is administered, no IP routes are required.
- `Network Region` — For a C-LAN IP interface, enter **1**.

```

change ip-interfaces                                     Page 1 of 4

                                IP INTERFACES

Enable
Eth Pt  Type  Slot  Code Sfx Node Name      Subnet Mask  Gateway Address Rgn
   y    C-LAN 01A02 TN799  D guestworks  255.255.255.0  192.168.1.255 1
   n
   n
   n
   n
   n
   n

```

*Assign an ethernet data module*

Use the **add data-module** command to administer an ethernet data module. If you are changing options on an existing data module, you must disable the link before you make any changes.

- `Data Extension` — Use an unassigned extension number.
- `Type` — Enter **ethernet**.
- `Port` — Enter the equipment location of the C-LAN circuit pack. For the ethernet link, you will always use circuit number **17**.
- `Link` — Select a TCP/IP link number (1-25 for *csi/si*, 1-33 for *r*). For most systems, use link **1**. This entry is also used on the Processor Channel screen.
- `Name` — Enter a name for the data module. This name will display when you list the assigned data modules.
- `BCC` — A display-only field.
- `Network uses 1's for Broadcast Address` — This sets the host portion of the IP address to 0's or 1's. The default is yes (all 1's). Use the default for this installation.

```
add data-module 2000                                     Page 1 of 1
                                                    DATA MODULE
Data Extension: 2000                                     Name: ethernet data module
Type: ethernet
Port: 01A0217
Link: 1
Network uses 1's for Broadcast Addresses? y
```

*Assign a processor interface channel*

Use the **change communication-interface processor-channels** command to assign a processor interface channel.

- Proc Chan — Select a processor channel for this link. Use the first channel available.
- Enable — Enter **y**.
- Appl — Enter **audix**.
- Gtwy To — Not used for the voice messaging application.
- Mode — Enter **s** (for server).
- Interface Link — Enter the TCP/IP link number used on the ethernet data module screen. For this series of examples, link **1** was used.
- Interface Chan — Enter the TCP channel number (5002 or 6001-6999). This must match the TCP Port field of the INTUITY Switch Interface Administration screen. The recommended entry for a voice messaging system is **5002**.
- Destination Node — Enter the node name for the voice messaging system as assigned on the Node Names screen. In these examples, **audix** is used.
- Destination Port — Use the default of **0**.
- Session Local — Enter **1**. This field must match the Local Node Number field on the switch dial plan.
- Session Remote — Enter **1**. This field must match the AUDIX Number field on the INTUITY Switch Interface Administration screen.
- Mach ID — Enter **1**. This field must match the AUDIX Number field on the INTUITY Switch Interface Administration screen.

```

change communication-interface processor-channels                               Page 1 of 8
                                PROCESSOR CHANNEL ASSIGNMENT

Proc                               Gtwy      Interface      Destination      Session      Mach
Chan Enable   Appl.   To   Mode Link/Chan   Node   Port   Local/Remote   ID
1:   y       audix      s    1 5002   audix  0     1    1           1
2:   n
3:   n
    
```

*Assign IP routes (if needed)*

Use the **add ip-route** command to set up the IP route(s) from the switch to the voice messaging system. This is required only when:

- The switch and the voice messaging system are on different subnets, or
- When a Gateway address is not administered for the C-LAN IP interface.

Administer the following fields for each IP route:

- **Route Number** — If you are going through a router, you must set up IP route 1 from the switch to the router, and then set up IP route 2 from the switch to the voice messaging system.
- **Destination Node** — This field represents the node name of the destination for this route. You would typically enter the node name for the voice messaging system or a router, depending on your configuration.
- **Gateway** — Enter the node name of the gateway by which the destination node is reached for this route. This is either the local C-LAN port or the first intermediate node between the C-LAN port and the final destination. For example, if there were one or more routers between the C-LAN port and the final destination node (the voice messaging system), the gateway would be the node name of the first router.
- **C-LAN Board** — Enter the equipment location of the C-LAN circuit pack that provides this route. It is possible to have more than one C-LAN circuit pack, but hospitality configurations will only use one C-LAN circuit pack.
- **Metric** — This field specifies the complexity of this IP route. Enter **0** if there are no intermediate nodes between the switch C-LAN port and the LAN circuit card on the voice messaging system. A metric value of **1** is used only on a switch that has more than one C-LAN circuit pack installed.

This example shows a simple IP route without any intermediate nodes.

```
add ip-route 1                               page 1 of 1
                                           IP ROUTING
Route Number: 1
Destination Node: audix
Gateway: guestworks
C-LAN Board: 01A02
Metric: 0
```

These next two examples show how you might set up a pair of IP routes when there is one intermediate router in the link.

```
add ip-route 1                                page 1 of 1
                                             IP ROUTING
Route Number: 1
Destination Node: router
Gateway: guestworks
C-LAN Board: 01A02
Metric: 0
```

```
add ip-route 2                                page 1 of 1
                                             IP ROUTING
Route Number: 2
Destination Node: audix
Gateway: guestworks
C-LAN Board: 01A02
Metric: 0
```

## TCP/IP link (INTUITY)

On the INTUITY, you must do the following for the TCP/IP link:

- Administer the link mode
- Administer the TCP/IP networking



### NOTE:

Before you can administer the TCP/IP networking, the TCP/IP feature must be enabled on the customer features window. Technical support must dial in and enable TCP/IP if it is not enabled.

- Configure the LAN circuit card
- Select a switch type (R4.4 only)
- Administer the switch interface
- Reboot the INTUITY system (R4.4 only).

### *Administer the link mode*

Use the **Customer/Services Administration > System Management > System Control > PMS Interface Administration** command to administer the link mode (GuestWorks or standalone).

### *Administer the TCP/IP networking (R4.4)*

Use the **Networking Administration > TCP/IP Administration** command to access the TCP/IP administration.



### NOTE:

If this administration is already complete, verify that the settings are accurate for your installation.

- `UNIX Machine Name` — Enter the UNIX name for the INTUITY system. This name is case-sensitive.
- `IP Address` — Enter the IP address for the INTUITY system. From the previous examples, use **192.168.1.70** if using a dedicated private link.
- `Subnet Mask` — Use the default of **255.255.255.0**.

- **Default Gateway IP Address** — This is an optional field. Leave it blank.

```
+-----+
+           TCP/IP Administration           +
+-----+
          UNIX Machine Name: map5p
                IP Address: 192.168.1.70
                Subnet Mask: 255.255.255.0
          Default Gateway IP Address:
```

*Administer the TCP/IP networking (R5 and later)*

Use the **TCP/IP Administration > Network Addressing** command to access the TCP/IP administration.



**NOTE:**

If this administration is already complete, verify that the settings are accurate for your installation.

- **TCP/IP Interface** — Use the default **eeE\_0**.
- **Host Name** — Enter the UNIX name for the INTUITY system. This name is case-sensitive.
- **IP Address** — Enter the IP address for the INTUITY system. From the previous examples, use **192.168.1.70** if using a dedicated private link.
- **Subnet Mask** — Use the default of **255.255.255.0**.
- **Default Gateway Address** — This is an optional field. Leave it blank.

```
+-----+
+           Network Addressing             +
+-----+
          TCP/IP Interface: eeE_0
                Host Name: map5p
                IP Address: 192.168.1.70
                Subnet Mask: 255.255.255.0
          Default Gateway Address:
```

*Configure the LAN Circuit Card (R4.4)*

After adding the TCP/IP administration, press **F8** to change the function key display, then press **F2** to select the LAN circuit card configuration. This should be set to **10BASE-T**. After selecting this option, press **F3** to save the change. The circuit card configuration is displayed. Press **F6** to exit the display.



- IP Address/Host Name — Enter the IP address of the switch. In this example, use **192.168.1.10**. This must match the IP address from the switch Node Names screen.
- TCP Port — Enter the TCP port number (5002 or 6001-6999). This must match the Interface Channel field of the switch Processor Channel screen. The default for an INTUITY system is **5002**.

```
+-----+
+               Switch Link Administration               +
+-----+
Switch Link Type: LAN                               Country: UNITED STATES
Extension Length: 3                               Switch: DEFINITY OVERLAN
Host Switch Number: 1
AUDIX Number: 1

Switch      IP Address/      TCP      Switch      IP Address/      TCP
Number     Host Name         Port    Number     Host Name         Port
  1         192.168.1.10       5002
```

*Reboot the INTUITY system (R4.4 Only)*

You must now reboot the INTUITY system. This is not required on an R5 and later system.

1. Use the **Customer/Services Administration > System Management > System Control > Shutdown System** command to shut down the INTUITY system.
2. When the system asks for a number of seconds to wait before shutdown, enter **0**. Follow the shutdown instructions to bring the system back up.
3. After bringing the system up, start up the voice system and then continue with link testing.



**NOTE:**

If you change any INTUITY system IP addresses on an R4.4 system after doing this administration, you must reboot the system before the link will come up.

## Testing the TCP/IP link

The following tests can be run from the switch to test the link to the voice messaging system:

- ping node-name *name* board *CCs* [packet-length *YYYY* repeat *ZZZ*]**, where *name* is the voice messaging system node name; *CCs* is the equipment location of the C-LAN circuit pack; *YYYY* is the size of the test packet; and *ZZZ* is the number of times that the test will be repeated. The packet length defaults to 64 bytes, with a maximum of 1500 bytes.

```
ping node-name audix board 01B10
```

PING RESULTS

End-pt	Node-name	Port	Port Type	Result	Time(ms)	Error Code
audix		01B1017	ETH-PT	PASS	8	

- ping ip-address *address* board *CCs* [packet-length *YYYY* repeat *ZZZ*]**, where *address* is the voice messaging system IP address; *CCs* is the equipment location of the C-LAN circuit pack; *YYYY* is the size of the test packet; and *ZZZ* is the number of times that the test will be repeated. The packet length defaults to 64 bytes, with a maximum of 1500 bytes.

```
ping ip-address 192.168.1.70 board 01B10
```

PING RESULTS

End-pt	ip	Port	Port Type	Result	Time(ms)	Error Code
192.168.1.70		01B1017	ETH-PT	PASS	8	

- status processor-channels *X***, where *X* is the ethernet link number.

```
status processor-channels 1
```

PROCESSOR-CHANNEL STATUS

```

Channel Number: 1
Session Layer Status: In Service
Socket Status: Established TCP
Link Number: 1
Link Type: ethernet
Message Buffer Number: 0

```

```

Last Failure: Far end sent disconnect message
At: 05/10/99 20:24

```

- **status link X**, where **X** is the TCP/IP link number. In this example of Page 1, the system shows that the link is connected and that the link is in service.

```
status link 1                               Page 1 of 4
                                     LINK/PORT STATUS
Link Number: 1
Link Status: connected
Link Type: ethernet
Link Name: ethernet data module
Service Port Location: 01B1017
Service Port Data Extension: 2000
Service Stats: in-service/active
Node Name: guestworks
Source IP Address: 192.168.1.10
Subnet Mask: 255.255.255.0
Broadcast Address: 192.168.1 .255
Physical Address: ff:ff:ff:ff:ff:ff
Enabled? yes
Maintenance Busy? no
Active Channels: 1
```

Page 2 shows the error counts.

Page 3 shows whether the link is up or down. If the link is not up, there is a problem somewhere in translations or connectivity.

```
status link 1                               Page 3 of 4
                                     PROCESSOR CHANNEL STATUS
UP: 001
```

Page 4 shows which IP services are currently active.

- **status data-module XXXX**, where **XXXX** is the extension number of the ethernet data module. This shows which port is connected and if the port is in service.

```
status data-module 3100
                                     DATA-MODULE STATUS
Data Ext/Stn Ext for Stn DM: 3100      Service State: in-service/active
Port/Channel Number: 01B1017          Maintenance Busy? no
CF Destination Ext:

Connected Ports:
```

- trace-route ip-address address board CCs**, where **address** is the voice messaging system IP address, and **CCs** is the equipment location of the C-LAN circuit pack. The command displays the hops traversed from source to destination, along with the IP addresses of the hop points and final destination, and the observed round-trip delay from the source to each hop point. If no reply is received from a hop point, the IP address is blank.

```

trace-route ip-address 192.168.1.70 board lb10

                                TRACE ROUTE RESULTS

Hop           Time(ms)      IP Address
0             Start Addr:  192.168.1.10
1             15, 15, 12   192.168.1.15
2             23, 26, 26  192.168.1.12
3             23, 25, 25  192.168.1.70
    
```

- list measurements clan ethernet CCs**, where **CCs** is the cabinet, carrier, and slot number of the C-LAN circuit pack. This command displays Cyclic Redundancy Check and collision counts for the past 24 hours in 15-minute intervals. N/A is displayed if the data cannot be retrieved for any interval.

```

list measurements clan ethernet lb10                                Page 1 of 3

Switch Name: guestworks                                           Date: 3:50 pm TUE AUG 17, 1999

                                C-LAN ETHERNET PERMORMANCE MEASUREMENT DETAILED REPORT

Date      Time      CRC CHECK      Collision Count
          total    delta          total    delta
02/01    03:08      650           50        650     250
02/01    02:53      600           600       400     400
02/01    02:38      N/A           N/A       N/A     N/A
02/01    02:23    10000000570    20       10000000570    20
02/01    02:08    10000000550    10000000550  10000000550  10000000550
    
```



■ **Customer/Services Administration > Diagnostics > TCP/IP  
Diagnostics > Send & Receive Test Packets**

After entering the switch IP address, press **F3** to start the test. This sends test packets between the INTUITY and the switch. The system tests to see whether all the packets are transmitted and whether they are transmitted in the correct sequence. If there is high (greater than 10%) packet loss, or if the packets are out of order, there may be network problems. While this test is running, the yellow T/R lamp on the LAN circuit card should be flashing.

```

+-----+
+                               Test Packet Results                               +
+-----+
|72 bytes from 192.168.X.X: icmp_seq=0, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=1, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=2, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=3, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=4, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=5, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=6, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=7, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=8, time=0, ms
|72 bytes from 192.168.X.X: icmp_seq=9, time=0, ms
|
|10 packets transmitted, 10 packets recieved, 0% packet loss
|round-trip (ms) min/avg/max=0/0/0
|
|Note: Hight packet loss, long round-trip time, or
|packets received out of order (icmp-swq) may
|indicate a network problem.
|
|Press Enter to continue.
+-----+

```

■ **Customer/Services Administration > Diagnostics > TCP/IP  
Diagnostics > View Packet Statistics**

When using this command, you can select from a detailed report, an interfaces report (shown below), and a routing report.

```

+-----+
+                               Packet Statistics                               +
+-----+
| Name  Mtu   Network   Address   Ipkts  Ierrs  Opkts  Oerrs  Collis
| sme0  1500  192.168.1 192.168.1.10 65827  0      48865  0      0
|
|Note: Abnormally high values in the Ierrs, Oerrs,
|or Collis column may indicate a network problem.
|
|Press Enter to continue
+-----+

```

Continue with ["Voice ports \(switch\)"](#) on page 240.

## X.25 signaling

The X.25 PI link requires administration on both the switch and the INTUITY. This section includes procedures for testing the link. Only the *si* and *r* systems can use an X.25 link. A *csi* system must use TCP/IP (page 215) or Mode Code Integration (page 238).



### NOTE:

An X.25 link cannot be used with the InnLine 2020 voice messaging system.

If the link is already administered, continue with “Voice ports (switch)” on page 240.

## X.25 link (switch)

Use the following procedures to administer the link between the switch and the INTUITY for administrative voice messaging. This administration is applicable for *si* or *r* systems using a direct IDI connection.

### *Data modules on an si system*

Use the **add data-module** command on an *si* system to administer the data module parameters for a processor interface (PI) link. For this connection, the data modules are integrated into the TN765 PI circuit pack. Set the options as shown, except use the correct extension, COS, and COR as set up for your installation.

```

add data-module 7991                                     Page 1 of 1
                                                    DATA MODULE

Data Extension: 7991                                     Name: intuition
Type: procr-infc                                       COS: 15      Maintenance Extension: 7995
Physical Channel: 01                                   COR: 50      Destination Number: eia
ITC: restricted                                       TN:          Establish Connection? y
Link: 1                                               DTE/DCE: DTE Connected To:
                                                    Enable Link? n      Clocking: internal

ABBREVIATED DIALING
List1:

SPECIAL DIALING OPTION:

ASSIGNED MEMBERS (Station with a data extension button for this data module)

Ext      Name
1:

```

You must set the `Enable Link` field to `n` at this time. After you have set up the processor interface channel, you must go back and enable the link.

The following table is an example of how you can administer the processor interface channels (your extensions will differ). Only channel 01 will be enabled later to handle the messaging traffic. The other channels are used for maintenance and testing.

Data Extension	Physical Channel	Maintenance Extension
7991	01	7995
7992	02	7996
7993	03	7997
7994	04	7998

*Data module on an r system*

Use the **add data-module** command on an *r* system to administer the data module parameters for a packet gateway link. For this connection, the data modules are integrated into the TN577 circuit pack. Set the options as shown, except use the correct extension, COS, and COR as set up for your installation.

```

add data-module 2005                                     Page 1 of 2
                                                    DATA MODULE
Data Extension: 2005                                     Name: intuition link
  Type: x.25                                             Remote Loop-Around Test? n
  Port: 01C0301                                         COR: 50                 Destination Number: external
  Baud Rate: 9600                                       TN: 1                  Establish Connection?
Endpoint Type: adjunct                                   DTE/DCE: dte          Connected Data Module:
  Link: 1                                               Enable Link? n         Error Logging? y

Permanent Virtual Circuit? y                             Highest PVC Logical Channel: 64
Switched Virtual Circuit? n
    
```

You must set the `Enable Link` field to `n` at this time. After you have set up the processor interface channel, you must go back and enable the link.

*Processor channels*

Use the **change communication-interface processor-channels** command to administer the processor channels.

- Proc Chan — Use channel **59**. It is recommended that this should match the `Session Local` field used for this link.
- Enable — Enter **y**.
- Appl — Enter **audix**.
- Gtwy To — Not used.
- Mode — Not used.
- Interface Link — Enter the link number used on the data module screen.
- Interface Chan — Enter the `Local Node Number` as administered on the dial plan screen.
- Destination Node — Not used.
- Destination Port — Enter **0**.
- Session Local — It is recommended that this should match the processor channel number used for this link. However, this value must match the `Switch Port` field on the INTUITY Switch/DCIU Interface Administration screen.
- Session Remote — This must match the `AUDIX Number` field on the INTUITY Switch/DCIU Interface Administration screen.
- Machine-ID — This must match the `AUDIX Number` field on the INTUITY Switch/DCIU Interface Administration screen.

```
change communication-interface processor-channels          Page 4 of 8
                PROCESSOR CHANNEL ASSIGNMENT

Proc
Chan  Enable   Appl.   Gtwy   Interface   Destination   Session   Mach
      49:      50:      51:      52:      53:      54:      55:      56:      57:      58:      59:      60:
      y          audix          1   1          0          59   1          1
```

*Enabling the Data Module Link*

You must now go back to the data module screen and enable the link. You should only enable the link for channel 01, the link that handles the messaging traffic.



*Administer the switch interface (R4.4)*

Use the **Switch Interface Administration > DCIU Interface Administration** command on the INTUITY to administer the link to the switch.

- Extension Length — Enter the extension length from the switch dial plan.
- Host Switch Number — Enter **1**.
- AUDIX Number — Enter **1**. This must match the Machine ID field on the switch Processor Channel screen.
- Logical Channel — Enter **1**.
- Switch Port — Enter **59**. This must match the Session Local field value on the switch Processor Channel screen.

```

+-----+
+                   DCIU Interface Administration                   +
+-----+
Switch Link Type: DCIU                               Switch:   Definity
Extension Length: 3
Host Switch Number: 1
AUDIX Number: 1
          HOST SWITCH LINK ASSIGNMENTS
          AUDIX Port                               AUDIX Port
Switch   Logical Switch                           Switch Logical Switch
Number  Channel Port                               Number Channel Port
  1         1      59                               2
  3                                         4
  5                                         6
  7                                         8
  9                                         10
 11                                         12
 13                                         14
 15                                         16
 17                                         18
 19                                         20
    
```

*Administer the switch interface (R5 and later)*

Use the **Switch Interface Administration** command on the INTUITY to administer the link to the switch.

- Extension Length — Enter the extension length from the switch dial plan.
- Host Switch Number — Enter **1**.
- AUDIX Number — Enter **1**. This must match the Machine ID field on the switch Processor Channel screen.
- Logical Channel — Enter **1**.
- Switch Port — Enter **59**. This must match the Session Local field value on the switch Processor Channel screen

```

+-----+
+               Switch Interface Administration               +
+-----+
|Switch Link Type: DCIU                               Country:   UNITED STATES|
|Extension Length: 3                                Switch:    Definity   |
|Host Switch Number: 1                               |
|AUDIX Number: 1                                     |
|               HOST SWITCH LINK ASSIGNMENTS           |
|               AUDIX Port                             AUDIX Port   |
|Switch Logical Switch                               Switch Logical Switch |
|Number Channel Port                                 Number Channel Port  |
| 1         1     59                                 2                 |
| 3                                     4                 |
| 5                                     6                 |
| 7                                     8                 |
| 9                                     10                |
| 11                                    12                |
| 13                                    14                |
| 15                                    16                |
| 17                                    18                |
| 19                                    20                |
+-----+
    
```

**Testing the X.25 link**

The following tests can be run from the switch to test the link to the INTUITY:

- **status processor-channels X**, where **X** is the X.25 link number.

```

status processor-channels 1
                          PROCESSOR-CHANNEL STATUS

Channel Number: 59
Channel Status: In Service
Link Number: 10
Link Type: BX.25
Message Buffer Number: 0
Reset Count: 0
Retransmission Count: 0
Failure Reason:
    
```

- **status link X**, where **X** is the X.25 link number.

```

status link 1                                     Page 1 of 3
                                LINK/PORT STATUS

Link Number: 1
Link Status: connected
Link Type: x.25
Link Name: intuition link
Service Port Location: 01C0301
Service Port Data Extension: 2005
Service Stats: in-service/active
Enabled? y
Maintenance Busy? n
Active Channels: 0

CONNECTED TO:

Destination: TDMODULE                               Destination Port: 1C0303
Destination Status: in-service/active                Destination Extension: external
AC: 1 Connected/Orig
    
```

The following tests can be run from the INTUITY to test the link to the switch:

- Use the command **Lodging Administration**, press **F7** to bring up the command menu, and select **LDG/PMS Link Restart** to restart the switch-to-INTUITY link.
- **Customer/Services Administration > Diagnostics > Switch Link Diagnostics > Link Diagnostics**

This screen is an example of an X.25 link. It shows the link being in service and the link level as up.

```

+-----+
+                               Diagnose Switch Link                               +
+-----+
| STATUS SWITCH-LINK |
|                               |
| Type  Baud   State          |
| DCIU  9600   In Service     |
|                               |
| Link Level 2 is Up         |
|                               |
| DCIU switches (In/Out of data transfer) |
|   1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20 |
|   I                                     |
+-----+
    
```

After pressing **F8** to change the function key labels, the following function keys control the status of the link:

- **F2** busies-out the link
- **F3** releases the link from busy-out
- **F4** performs diagnostics on the link.

Continue with [“Voice ports \(switch\)” on page 240](#).

## Mode Code Integration

The Mode Code Integration link requires administration on both the switch and the voice messaging system. Any switch types can use Mode Code Integration, but TCP/IP or X.25 are the recommended methods for messaging links.



### NOTE:

The Mode Code Integration link does not support the integrated link between the switch and the voice messaging system.

### Mode Code Integration link (switch)

Translating the Mode Code Integration link involves the following:

- Enabling the Mode Code feature
- Verifying that the default mode codes are accurate.

Mode Code Integration on the switch is described in the *DEFINITY ECS Administrator's Guide*.

Use the **display system-parameters features** command, Page 5, to verify that there is a **y** in the Mode Code Interface field.

```
change system-parameters features                               Page 5 of 10
                        FEATURE-RELATED SYSTEM PARAMETERS

    Public Network Trunks on Conference Call: 5                Auto Start? n
    Conference Parties with Public Network Trunks: 6           Auto Hold? n
    Conference Parties without Public Network Trunks: 6        Attendant Tone? y
    Night Service Disconnect Timer (seconds): 180             Bridging Tone? n
    Short Interdigit Timer (seconds): 3                       Conference Tone? n
    Unanswered DID Call Timer (seconds):                      Intrusion Tone? n
    Line Intercept Tone Timer (seconds): 30                   Special Dial Tone? n
    Long Hold Recall Timer (seconds): 0                       Mode Code Interface? y
    Reset Shift Timer (seconds): 0
    Station Call Transfer Recall Timer (seconds): 0
    DID Busy Treatment: tone
    Allow AAR/ARS Access from DID/DIOD? n
    Allow ANI Restriction on AAR/ARS? n
    Abort Conference Upon Hang-Up? n
    7405ND Numeric Terminal Display? n                       7434ND? n
DISTINCTIVE AUDIBLE ALERTING
    Internal: 1 External: 2 Priority: 3
    Attendant Originated Calls: external
```

Use the **change system-parameters mode-code** command to verify that the default mode code parameters are correct for this installation.

```
change system-parameters mode-code                               Page 1 of 1
      MODE CODE RELATED SYSTEM PARAMETERS

      MODE CODES (FROM SWITCH TO VMS)
      Direct Inside Access: #00
Direct Dial Access - Trunk: #01
      Internal Coverage: #02
      External Coverage: #03

      Refresh MW Lamp: #06

      System In Day Service: #11
      System In Night Service: #12

      OTHER RELATED PARAMETERS
DTMF Duration - On (msec): 100  Off (msec): 100  Sending Delay (msec):100

      VMS Hunt Group Extension:
Remote VMS Extensions - First:      Second:
```

### Mode Code Integration (INTUITY)

Mode Code Integration on the INTUITY is described in the following documents:

- *INTUITY Messaging Solutions Release 4 MAP/5P System Installation*
- *INTUITY Messaging Solutions Integration with System 75, DEFINITY Generics 1 & 3, and R5/6*
- *INTUITY Messaging Solutions Release 5 Documentation (CD)*.

Continue with [“Voice ports \(switch\)” on page 240](#).

## Voice ports (switch)

Use the **add station** command to administer the voice ports that are linked to the voice messaging system. On Page 1, assign the following fields as shown:

- **Extension** — The extension must be in the dial plan but not assigned for any other purpose.
- **Type** — Enter **2500** for the station type when using the TCP/IP or X.25 link. Enter **VMI** for the station type when using Mode Code integration.
- **Port** — Each analog circuit pack supports 8, 16, or 24 analog voice connections. Depending on the circuit pack and the required number of voice ports, you may need to spread out the voice port assignments over more than one circuit pack. For example, if you are using a 16-port circuit pack, use no more than four ports of circuits 1-8 and four ports of circuits 9-16 on that circuit pack. If you still need more voice ports, select a circuit pack that is at least one-quarter carrier distance away from the first circuit pack. For example, if your system has 12 voice ports and you assign the first eight ports to the circuit pack in slot 3, assign the other four voice ports to a circuit pack in slot 7 or higher. See more about circuit pack characteristics in the *DEFINITY ECS System Description*.
- **Name** — Assign the first port as **VM1**, and then increment the number for each subsequent port (**VM2**, **VM3**, and so on).
- **COR** — Use the same COR for the voice ports that you use for the hunt groups. This COR should have the FRL set to 1 and should not allow access to trunk group CORs.
- **COS** — Use a COS that allows data privacy.

```

add station 720                                     Page 1 of 3
                                                    STATION
Extension: 720                                     Lock Messages? n      BCC: 0
Type: 2500                                         Security Code:        TN: 1
Port: 01A0201                                     Coverage Path 1:      COR: 35
Name: AUDIX1                                       Coverage Path 2:      COS: 4
                                                    Hunt-to Station:      Tests? n

STATION OPTIONS
Loss Group: 1                                     Message Waiting Indicator: none
Off Premise Station? n

```

The following is an example of Page 1 when Mode Code Integration is installed.

```

add station 720                                     Page 1 of 3
                                                    STATION

Extension: 720                                     Lock Messages? n          BCC: 0
Type: VMI                                         Security Code:           TN: 1
Port: 01A0201                                     COR: 35
Name: AUDIX1                                     COS: 4
                                                    Tests? n

STATION OPTIONS
    Loss Group: 1
    Off Premise Station? n
    
```

On Page 2:

- LWC Reception — Enter **audix** when using TCP/IP or X.25 signaling. Enter **none** when using Mode Code integration.
- LWC Activation — Enter **n** when using TCP/IP or X.25 signaling. Enter **y** when using Mode Code integration.
- Switchhook Flash — Enter **y**.
- Distinctive Audible Alerting — Enter **n** when using Mode Code integration.
- Adjunct Supervision — Enter **y** if Message Manager is not being used; enter **n** if Message Manager is being used. Enter **y** when using Mode Code integration whether or not Message Manager is being used.

```

add station 720                                     Page 2 of 3
                                                    STATION

FEATURE OPTIONS
    LWC Reception: audix
    LWC Activation? n                               Coverage Msg Retrieval? n
    CDR Privacy? n                                   Auto Answer: none
    Redirect Notification? n                          Data Restriction? n
    Per Button Ring Control? n                       Call Waiting Indication? n
    Bridged Call Alerting? n                         Att. Call Waiting Indication? n
    Switchhook Flash? y                             Distinctive Audible Alerting? n
    Ignore Rotary Digits? n                          Adjunct Supervision? y
    H.320 Conversion? n

    Per Station CPN - Send Calling Number?

    MWI Served User Type? n                          Audible Message Waiting? n

                                                    Coverage After Forwarding? s

Emergency Location Ext:
    
```

On Page 3, set the Line Appearance field to **call-appr**.

```
add station 720                                     Page 3 of 3
                                                    STATION
SITE DATA
  Room:                                             Headset? n
  Jack:                                             Speaker? n
  Cable:                                           Mounting: d
  Floor:                                           Cord Length: 0
  Building:                                        Set Color:

ABBREVIATED DIALING
  List1: System 1      List2:                    List3:

HOT LINE DESTINATION
  Abbreviated Dialing List Number (From above 1, 2 or 3):
  Dial Code:

Line Appearance: call-appr
```

After you assign the first port, use the **duplicate station** command to assign the rest of the ports.

## Hunt groups for voice ports (switch)

Use the **add hunt-group** command to administer the voice port hunt groups. This hunt group is used by both the office staff and the hotel guests when they call to retrieve their messages.

On Page 1:

- Group Name — Enter a name for this group.
- Group Extension — Enter an unassigned extension. This extension will be used by office staff for message retrieval. The guests will use a different extension that is forwarded into this hunt group. See [page 245](#).
- Group Type — Enter **ucd-mia**.
- COR — Use the same COR as the voice messaging system voice ports.
- Queue — Enter **y**.
- Queue Length — This must equal the number of installed voice ports.

```

add hunt-group 1                                     Page 1 of 10
                                                    HUNT GROUP
Group Number: 1                                     ACD? n
  Group Name: AUDIX                                 Queue? y
Group Extension: 699                               Vector? n
  Group Type: ucd-mia                             Coverage Path:
      TN: 1                                       Night Service Destination:
      COR: 35                                    MM Early Answer? n
Security Code:
ISDN Caller Display:

  Queue Length: 6
Calls Warning Threshold:      Port:
Time Warning Threshold:      Port:

```

On Page 2:

- Message Center — Enter **audix** if using TCP/IP or X.25 signaling. Enter **none** if using Mode Code integration.
- Calling Party Number to INTUITY AUDIX — Enter **n** except when this feature is active on the INTUITY system.
- LWC Reception — Enter **none**.

```

add hunt-group 1                                     Page 2 of 10
                                     HUNT GROUP
                                     Message Center: audix

                                     Calling Party Number to INTUITY AUDIX? n
                                     LWC Reception: none

                                     First Announcement Extension:      Delay (sec):
    
```

On Page 3, assign each extension in the same order as assigned in the voice ports on the voice messaging system ([page 247](#)). The name field is populated after you add the list of extensions and redisplay the hunt group. The Administered Members fields should match the number of voice ports once all the voice ports have been assigned.

```

add hunt-group 1                                     Page 3 of 10
                                     HUNT GROUP
                                     Group Number: 1      Group Extension: 699      Group Type: ucd-mia
                                     Member Range Allowed: 1 - 200      Administered Members (min/max): 1 /6
                                     Total Administered Members: 6

GROUP MEMBER ASSIGNMENTS
  Ext  Name                               Ext  Name
  1: 720  VM1                                14:
  2: 721  VM2                                15:
  3: 722  VM3                                16:
  4: 723  VM4                                17:
  5: 724  VM5                                18:
  6: 725  VM6                                19:
  7:
  8:
  9:
  10:
  11:
  12:
  13:
  14:
  15:
  16:
  17:
  18:
  19:
  20:
  21:
  22:
  23:
  24:
  25:
  26:

At End of Member List
    
```

## Extensions for guest message retrieval (switch)

The way guests retrieve their messages is to call an extension that is call forwarded to the voice messaging system hunt group extension. This is done using a standard station line that covers to the hunt group (defined on [page 243](#)). You can also assign an extension that allows guests to retrieve their messages when they are not in their room, and an extension that allows guests to leave messages for other guests without ringing the other guest's room. See "[Services to phone number mapping \(INTUITY\)](#)" on [page 249](#) for more information.

Use the **add station** command to add a station extension that is used only for accessing the voice messaging system voice messages:

- Type — Enter **2500**.
- Port — Enter **X** (administration without hardware).
- Name — Enter a name to identify this station.
- COS — Enter a COS designated for voice messaging use.

```

add station 710                                     Page 1 of 3
                                     STATION
Extension: 710                                     Lock Messages? n      BCC: 0
Type: 2500                                         Security Code:        TN: 1
Port: X                                             Coverage Path 1:     COR: 35
Name: GUEST VOICE MAIL                            Coverage Path 2:     COS: 4
                                                    Hunt-to Station:     Tests? y

STATION OPTIONS
Loss Group: 1                                     Message Waiting Indicator:
Off Premise Station? n
    
```

```

add station 710                                     Page 2 of 3
                                     STATION
FEATURE OPTIONS
LWC Reception: audix
LWC Activation? n                                Coverage Msg Retrieval? y
LWC Log External Calls? n                        Auto Answer: none
CDR Privacy? n                                  Data Restriction? n
Redirect Notification? y                          Call Waiting Indication? n
Per Button Ring Control? n                       Att. Call Waiting Indication? n
Bridged Call Alerting? n                        Distinctive Audible Alerting? n
Switchhook Flash? y                             Adjunct Supervision? y
Ignore Rotary Digits? n
H.320 Conversion? n

Per Station CPN - Send Calling Number?

Audible Message Waiting? n

MWI Served User Type? n

Coverage After Forwarding? s
    
```

On Page 3, set the Line Appearance field to **call-appr**.

```

add station 710
                                     STATION
SITE DATA
  Room: 710                          Headset? n
  Jack:                               Speaker? n
  Cable:                             Mounting: d
  Floor:                             Cord Length: 0
  Building:                           Set Color:

ABBREVIATED DIALING
  List1: System 1                    List2:
                                     List3:

HOT LINE DESTINATION
  Abbreviated Dialing List Number (From above 1, 2 or 3):
  Dial Code:

Line Appearance: call-appr
    
```

After you assign the guest message retrieval extension, you must manually assign Call Forwarding to this extension so that calls will forward to the main voice messaging system hunt group extension. To use Call Forwarding, the Class of Service for this station (the guest message retrieval extension) must have Call Forwarding enabled (see [page 115](#)). In this example, you would forward calls intended for extension 710 to extension 699. You can set up Call Forwarding from any telephone that has console permissions.

### Call Coverage path (switch)

Use the **add coverage path** command to define the coverage path that redirects unanswered calls to the voice messaging system (as defined on [page 243](#)). After three rings, calls go to hunt group 1 (**h1**). If the voice messaging system is down or the voice ports are all busy, then the calls forward to the attendant (**attd**).

```

add coverage path 1
                                     COVERAGE PATH
                                     Coverage Path Number: 1
                                     Hunt after Coverage? n
                                     Next Path Number:         Linkage

COVERAGE CRITERIA
  Station/Group Status  Inside Call  Outside Call
  Active?               Y           Y
  Busy?                 Y           Y
  Don't Answer?        Y           y           Number of Rings: 3
  All?                  n           n
  DND/SAC/Goto Cover? Y           Y

COVERAGE POINTS
  Terminate to Coverage Pts. with Bridged Appearances? n

  Point1: h1             Point2: attd           Point3:
  Point4:                Point5:                Point6:
    
```

## INTUITY AUDIX voice ports (INTUITY)

To assign the voice port extension numbers to each activated voice channel on the INTUITY system:



**NOTE:**

Port numbers and channel numbers start with 0 (zero).

1. Enter the **Voice System Administration > Voice Equipment** command.
2. Press **F8** to display the actions menu.
3. Select the **Assign/Change** option.
4. Select the **PBX Extension to Channel** option.

```
+-----+
+ Assign PBX Extension to a Channel +
+-----+
| PBX Extension: |
| Channel Number: |
+-----+
```

5. Enter a voice port extension number and a channel number (0-5). Use the same order here as was used when the hunt group extensions were assigned ([page 243](#)).
6. Press **F3** to save the assignment. A message displays confirming that the extension was mapped to a channel.
7. Press Enter to acknowledge the message.
8. Repeat this procedure for each voice port extension.
9. When finished, press **F6** to exit. You must now map services to channels for normal operation.
10. Select the **Services to Channels** option.

```
+-----+
+ Assign Services to Channels +
+-----+
| Channel Numbers: |
| Service Name: |
+-----+
```

11. Enter the numbers of the channels the customer has purchased in the `Channel Numbers` field. For example, if the customer purchased 12 channels, enter **0-11**.
12. Enter **\*DNIS\_SVC** for all channels in the `Service Name` field.

13. Press **F3** to save the assignment.  
An acknowledgement message is displayed. Press **F1** to continue.
14. Press **F6** repeatedly to return to the INTUITY Main Menu.
15. Enter the **Voice System Administration > Voice Equipment** command to display the voice channel setup.

```

+-----+
+               Display Voice Equipment               +
+-----+-----+-----+-----+-----+-----+-----+
| CD.PT | CHN | STATE | STATE-CHNG-TIME | SERVICE-NAME | PHONE | GROUP | OPTS | TYPE |
+-----+-----+-----+-----+-----+-----+-----+-----+
| CARD  | 0   | STATE: | Inserv          | CLASS: Analog(TR) |      | O.S. INDEX: 0 |
|       |     | NAME:  | AYC10           | OPTIONS: master 1,no tdm,tt |
|       |     | FUNCTION: | TipRing        |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.0   | 0   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 720  | 2   | talk | IVC6 |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.1   | 1   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 721  | 2   | talk | IVC6 |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.2   | 2   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 722  | 2   | talk | IVC6 |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.3   | 3   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 723  | 2   | talk | IVC6 |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.4   | 4   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 724  | 2   | talk | IVC6 |
|-----+-----+-----+-----+-----+-----+-----+-----+
| 0.5   | 5   | Inserv | Mar 20 18:49:25 | *DNIS_SVC   | 725  | 2   | talk | IVC6 |
+-----+-----+-----+-----+-----+-----+-----+

```

The channel state should normally be **Inserv** (in-service), but it could be **foos** (facility out-of-service) or **manoos** (manually out-of-service). The **SERVICE NAME** should be **\*DNIS\_SVC**, and the **GROUP** should be set to **2**.

## Services to phone number mapping (INTUITY)

You must map the extension numbers used to retrieve and leave voice mail messages to the services the extensions provide. These assignments control how the call is processed by the INTUITY system. In the examples as shown in this section, extension 699 is used by the office staff; extension 710 is used by the guests from their guest rooms; and extension 770 is used for printing fax messages.



### CAUTION:

*If the AUDIX service is not assigned, calls placed to the office staff extensions will hear an “Extension not valid” message when the call is transferred to INTUITY AUDIX, and the caller cannot leave a message.*

Use the **Voice System Administration > Number Services > Assign Service** command to access the number service screen.

```

+-----+
+               Assign Number Service               +
+-----+-----+
+  Called Numbers:699                to 699         +
+  Calling Numbers:any                to any         +
+  Service Name:AUDIX                +
+-----+-----+

```

Assign `Called Numbers` and `Calling Numbers` to the following services:

- **AUDIX** — Enter the extension that the office staff call to retrieve their AUDIX messages. In the example for this book, that would be extension 699.
- **AUDIX+ldg** — Enter **any**.
- **ldging** — Enter the extension that guests call to retrieve their lodging messages. In the example for this book, that would be extension 710.
- **ldg\_ni\_vm** — Enter an extension that guests can call to retrieve their messages when away from their room. This extension should be assigned to a DID number so guests can retrieve their messages when outside of the hotel. This option is not available on all systems.
- **ldg\_ni\_ca** — Enter an extension that guests can call to leave a message for another guest without ringing the other guest’s room. This extension must have a coverage path that redirects to the voice mail extension and should be call forwarded to the voice mail extension (in this example, extension 699). This option is not available on all systems.
- **LGfax** — Enter the extension callers would use to transmit a fax. In the example for this book, that would be extension 770.

The `Calling Numbers` fields will always be **any**. The example shown here matches the extension used elsewhere in this book.

## Attendant and administrator passwords (INTUITY)

---

Use the **Lodging Administration > Lodging Administrator Registration** command to access the administrator registration screen. Using this screen, you must assign an administrator extension (an unused extension on the switch), an administrator password, and an attendant password. These passwords can be used to retrieve voice messages for the guests. Your administration should look similar to this screen.



### CAUTION:

*When creating passwords, do not use a sequential string of digits (such as 1234) or a repeated digit (such as 5555).*

```
+-----+
+Lodging Administrator Registration+
+-----+
|Administrator Extension: 475      |
| Administrator Password: 3872    |
|      Attendant Password: 6391   |
+-----+
```

## Testing the switch-to-INTUITY voice ports

Use the **Voice System Administration > Voice Equipment** command to check the status of the voice ports.

```

+-----+
+                               Display Voice Equipment                               +
+-----+
CD.PT CHN STATE   STATE-CHNG-TIME  SERVICE-NAME  PHONE  GROUP  OPTS TYPE
-----
CARD 0  STATE: Inserv   CLASS: Analog(TR)           O.S. INDEX: 0
      NAME: AYC10     OPTIONS: master 1,no tdm,tt
      FUNCTION: TipRing
0.0 0  Inserv   Mar 20 18:49:25  *DNIS_SVC   720   2      talk IVC6
0.1 1  Inserv   Mar 20 18:49:25  *DNIS_SVC   721   2      talk IVC6
0.2 2  Inserv   Mar 20 18:49:25  *DNIS_SVC   722   2      talk IVC6
0.3 3  Inserv   Mar 20 18:49:25  *DNIS_SVC   723   2      talk IVC6
0.4 4  Inserv   Mar 20 18:49:25  *DNIS_SVC   724   2      talk IVC6
0.5 5  Foos     Mar 20 18:49:25  *DNIS_SVC   725   2      talk IVC6
+-----+

```

This command shows you the extension numbers directly assigned to each INTUITY AUDIX voice port. You can call each extension to test the ports. There are four possible port states:

- In-Service (Inserv) — The channel is ready to accept telephone calls.
- Facility-out-of-service (Foos) — The channel is not in service. This occurs when a channel has been released through the **Voice Board Diagnostics** screen to Inserv, and it does not detect loop current. A channel in the Foos state should automatically convert to the Inserv state when it detects loop current, but it may need to be reset. If you connected the ports to the switch and the ports remain in the Foos state, there is a problem with the switch, the connection, or the INTUITY hardware.
- Manually-out-of-service (Manoos) — The channel has been busied-out under the **Voice Board Diagnostics** screen, or the channel is on a new tip/ring circuit card. A channel in the Manoos state will remain until it is released under the **Voice Board Diagnostics** screen.
- Non-Existent (NONEX or no entry on any screen) — The system does not see the channel. The system will not see a channel that has not been properly activated even if the tip/ring circuit card is present. To change a channel from non-existent to recognized, the remote maintenance center must activate it.

In this example, extension 725 is possibly out of service. It can be verified by calling the port extension to see if the call is answered by INTUITY AUDIX. Refer to the appropriate MAP installation document for more information about testing.

## Voice messaging-to-PMS translations and testing

---

There are two ways that the voice messaging system lodging software and the PMS software can exchange messages for database updates:

- Use the Switch/INTUITY/PMS Link Integration feature. This feature uses the switch to exchange the voice mail database update messages between the voice messaging system and the PMS. This option is known as the “PMS Interface for GuestWorks.” The INTUITY system currently defaults to this option. This option can be used with TCP/IP or X.25 links, but cannot be used for Mode Code Integration.

Use this integration method whenever connecting over C-LAN to a voice messaging system that supports lodging software, such as INTUITY Lodging or the InnLine 2020.

- Use a hard-wired link between the MAP and the PMS voice messaging port. This link is illustrated in [Figure 12 on page 40](#). This option is known as the “Stand-alone Mode.” This option can be used with TCP/IP or X.25 links, and must be used for Mode Code Integration. This link should also be used if the PMS must keep track of the number of voice mail messages for each guest.

## PMS Interface for GuestWorks

To administer the PMS Interface for GuestWorks, you must do the following:

- Enable the feature on the switch
- Install the software on the INTUITY
- Set up the system parameters on the INTUITY.

To enable the Switch/INTUITY/PMS Link Integration feature (the “PMS Interface for GuestWorks” link), enter a **y** in the Forward PMS Messages to Intuity Lodging field.

```
change system-parameters hospitality                               Page 1 of 3
                                HOSPITALITY

                                Message Waiting Configuration: act-nopms
                                Controlled Restrictions Configuration: act-pms
                                Housekeeper Information Configuration: act-pms
                                Number of Housekeeper ID Digits: 0
                                PMS Log Endpoint:
                                Journal/Schedule Endpoint:
                                Client Room Coverage Path Configuration: act-nopms
                                Default Coverage Path for Client Rooms: 1
                                Forward PMS Messages to Intuity Lodging? y

                                PMS LINK PARAMETERS
                                PMS Endpoint: 7899
                                PMS Protocol Mode: transparent ASCII mode? y
                                Seconds before PMS Link Idle Timeout: 20
                                Milliseconds before PMS Link Acknowledgement Timeout: 500
                                PMS Link Maximum Retransmissions: 5
                                PMS Link Maximum Retransmission Requests: 5
                                Take Down Link for Lost Messages? y
```

You must then verify whether the INTUITY system has the PMS Interface for GuestWorks link software installed and active. Use the **Software Management** screen to display or change the available options.

- If the “PMS Interface for GuestWorks” is currently installed, no changes are needed.
- If the “Stand-Alone PMS Interface” is currently active or no interface has been installed, install the “PMS Interface for GuestWorks” option. Follow the instructions to install the software.

Once the software is installed, use the **Lodging Administration > System Parameter Administration** command to administer the system parameters for INTUITY Lodging.

- **Attendant Extensions** — Enter **0** for the attendant console, the backup telephone extensions, and any extensions that will be used to retrieve messages for guests.
- **Primary Attendant** — Enter the attendant console dial-up number (usually 0) or extension.
- **Default Language** — Select a default language option.

```

+-----+
+               System Parameter Administration               +
+-----+
+               Attendant Extensions:                       +
+   2000   195   0   _____   _____   _____   +
+           Hunt Group Or                                     +
+           Primary Attendant: 0                             +
+
+           Voice Mail Parameters                            +
+           Mailbox Size: 6 min                               +
+           Pause For TT Input: 4 sec                       +
+           Maximum Extension Length: 4                     +
+           Maximum Message Length: 120 sec                 +
+ Allow Guests To Save Messages?: Yes                       +
+ Lamp ON For New Messages Only?: Yes                      +
+           Automatic Transfer to                            +
+           Operator At End Of Call?: No                    +
+           Default Language: American English              +
+-----+

```

## Stand-alone interface link

To administer the stand-alone interface link:

- Disable the integrated link feature on the switch
- Install the software on the INTUITY
- Set up the link on the INTUITY
- Set up the system parameters on the INTUITY.

To use the hard-wired link between the INTUITY and the PMS (Figure 12), you must first disable the Switch/INTUITY/PMS Link Integration feature. Enter an **n** in the Forward PMS Messages to Intuity Lodging field.

```

change system-parameters hospitality                               Page 1 of 3
                                HOSPITALITY

                                Message Waiting Configuration: act-nopms
                                Controlled Restrictions Configuration: act-pms
                                Housekeeper Information Configuration: act-pms
                                Number of Housekeeper ID Digits: 0
                                    PMS Log Endpoint:
                                Journal/Schedule Endpoint:
                                Client Room Coverage Path Configuration: act-nopms
                                Default Coverage Path for Client Rooms: 1
                                Forward PMS Messages to Intuity Lodging? n

                                PMS LINK PARAMETERS
                                    PMS Endpoint: 7899
                                    PMS Protocol Mode: transparent ASCII mode? y
                                Seconds before PMS Link Idle Timeout: 20
                                Milliseconds before PMS Link Acknowledgement Timeout: 500
                                    PMS Link Maximum Retransmissions: 5
                                PMS Link Maximum Retransmission Requests: 5
                                    Take Down Link for Lost Messages? y
  
```

Then, verify whether the INTUITY system has the Stand-Alone Mode link software installed and active. Use the **Software Management** screen to display or change the available options.

- If the “Stand-Alone PMS Interface” is currently installed, no changes are needed.
- If the “PMS Interface for GuestWorks” is currently active or no interface has been installed, install the “Stand-alone PMS Interface” option. Follow the instructions to install the software.

Once the software is installed, use this screen on the INTUITY to administer the standard hard-wired link between the INTUITY Lodging and the PMS. Use the **Lodging Administration > PMS Parameter Administration** command to access this screen.

- **Device for Link** — This must match the physical port connected to the Equinox card. Use **/dev/ttysac** if the connection is on the Multi-Port Serial Card, and use **/dev/ttys00** if the connection is on the COM1 port.
- **Baud Rate** — Set the speed to match the vendor equipment. If the vendor does not have a recommended speed, use 4800 bps. You must enter the letter **B** in front of the baud rate you select.
- All other options must match the vendor requirements.

```

+-----+
+       PMS Parameter Administration       +
+-----+
|           Device for Link: /dev/ttysac   |
|           Maximum Link Error: 50        |
| Link Acknowledgement Timeout: 20 sec    |
|           Link Idle Timeout: 20 sec     |
|           Maximum Retransmission: 5     |
| Maximum Retransmission Request: 5      |
|           Baud Rate: B4800              |
+-----+

```

Use the **Lodging Administration > System Parameter Administration** command to administer the system parameters for INTUITY Lodging.

- **Attendant Extensions** — Enter **0** for the attendant console, the backup telephone extensions, and any extensions that will be used to retrieve messages for guests.
- **Primary Attendant** — Enter the attendant console dial-up number (usually 0) or extension.
- **Lamp ON For New Messages Only** — Enter **Yes** if using TCP/IP or X.25 signaling between the switch and the INTUITY system. Enter **No** if using Mode Code integration between the switch and the INTUITY system.
- **Default Language** — Select the default language option.

- PMS Integration Parameters — Must match the vendor requirements.
- Message Lamp Controlled By — This should be set to **LDG** if you want INTUITY Lodging to control the guest room message lamps. If the lamp control is enabled for the PMS, the front desk personnel should take messages for guests when the PMS link is down because the message lamps will not be turned on even when the INTUITY has taken a message.

```
+-----+
+               System Parameter Administration               +
+-----+
+
+               Attendant Extensions:
+
+   2000   195   0
+   Hunt Group Or
+   Primary Attendant: 0
+
+               Voice Mail Parameters
+
+   Mailbox Size: 6 min           Mailbox Type: Separate
+   Pause For TT Input: 4 sec     Play Back Format: FIFO
+   Maximum Extension Length: 4
+   Maximum Message Length: 120 sec
+
+ Allow Guests To Save Messages?: Yes   PMS Integration Parameters
+ Lamp ON For New Messages Only?: Yes   Message Lamp Controlled By: LDG
+   Automatic Transfer to             When PMS link is down, calls
+ Operator At End Of Call?: No        For Guests Handled By: LDG
+
+   Default Language: American English
+-----+
```

## Testing the INTUITY Lodging-to-PMS link

After the connection is complete, and the link is active, the mini-tester should show the following results (see the Note on [page 5](#)). The leads marked with an asterisk are controlled by the INTUITY system, and the PMS controls the other leads.



**CAUTION:**

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

TD* ● red	red ● RD
RTS* ○ dark	green ● CTS
DSR ● green	green ● DTR*
CD ● green	

After the connection is complete and the INTUITY link is active, the following may indicate that the PMS is not active. Check with the vendor to verify whether the link is active.

TD* ● red	red ● RD
RTS* ○ dark	red ● CTS
DSR ● red	green ● DTR*
CD ● red	

Table 13 gives a list of PMS alarm codes, the event IDs, a description of the problem, and a method to clear the problem. Use the **Customer/Services Administration > Log Administration > Maintenance Log** command to set up which maintenance events will display.

**Table 13. PMS Event IDs generated on the INTUITY**

<b>Alarm Code</b>	<b>Event IDs</b>	<b>Description</b>	<b>Clearing</b>
11	PMS01, PMS02, PMS04, PMS05, PMS06, PMS07	The PMS communication link is down.	Restart PMS through the command menu.
12	PMS08	An unknown PMS communication link problem.	Stop and restart the voice system.
13	PMS10, PMS11, PMS38	Unable to manage allocated memory.	Stop and restart the voice system.
14	PMS14	PMS received a message of an invalid size.	Stop and restart the voice system.
15	PMS03, PMS09, PMS12, PMS13, PMS15, PMS16, PMS27, PMS29, PMS30, PMS31, PMS33, PMS34, PMS35, PMS39, PMS43	The PMS communication interface is having problems.	Restart PMS through the command menu.
16	PMS20, PMS22, PMS24, PMS25	Unable to use the assigned serial port.	Stop and restart the voice system.

Use the following procedure to test the voice mailboxes for the guest rooms:



**NOTE:**

When using TCP/IP or X.25 signaling, mailboxes are created automatically for the guest rooms and do not require administration. When using Mode Code integration, guest mailboxes must be created manually. See [“Mailboxes for guest rooms \(INTUITY\)” on page 158](#) for more information.

1. Do a test check-in from the PMS terminal to create a valid entry. Access the following screen using the **Lodging Administration > Guests Mailbox Administration > Mailbox** command.

```

+-----+
+                Mailbox                +
+-----+
|
| Guest Extension: 112
| Guest Room Number: 112
|   Guest Name: ERWIN
|   Guest Password: *
|   Guest Language: Canadian French
|   Switch number: 1
| Allow personal greeting: Yes
|
| Messages Waiting:
|   Voice:
|   Fax:
|   Text:
| Mailbox Capacity Usage: 0%
| Suite Mailbox Extension:
|   Comments:
|
+-----+
    
```

2. Press **F8** to change the function key labels.
3. Enter the extension number, and press the DISPLAY function key.

4. Display the following screen using the **Lodging Administration > Traffic and Space Usage Reports > Mailbox Usage** command to verify that the test mailbox was created.

```
+-----+
+                               Mailbox Usage Report                               +
+-----+
+                               Mailbox Usage Report                               +
+                               Mailbox size: 360 seconds                          +
+                               Mon Apr 1 07:40:20 1996                            +
+-----+
Current Messages:
Mailbox      Voice Msgs  Time(secs)  Text Msgs  Fax Msgs
112          0           0           0           0
115          0           0           0           0
119          0           0           0           0
123          0           0           0           0

Deleted Messages:
Mailbox      Voice Msgs  Time(secs)
115          4           230

Old Messages:
Mailbox      Voice Msgs  Time(secs)
112          0           0
```

5. After you verify that the guest mailbox was created, remove the test entry by doing a check-out at the PMS terminal.

## Switch-to-call accounting translations and testing

---

You must assign the link between the switch and the INTUITY, administer the CDR parameters, and enable CDR for each incoming and outgoing trunk group that the customer wishes to record. If a stand-alone call accounting system (such as Xiox) is used, the vendor must assist in setting up the call accounting system.

### Link parameters (INTUITY)

---

The data link between the switch and the INTUITY Lodging Call Accounting must be administered by the Homisco technician when he or she installs the software on the INTUITY platform.

### CDR parameters (switch)

---

Use the **change system-parameters cdr** command to assign the CDR parameters on the switch.

- `Primary Output Format` — Enter **printer** (or the format required by the call accounting vendor).
- `Primary Output Endpoint` — Do one of the following:
  - Enter **CDR1** if the call accounting system is connecting to the switch over a terminal server. You must also administer the IP Services form for the CDR interface.
  - Enter **eia** if the call accounting system is directly connected to the switch using the DCE port.
  - Enter the data module extension if using a switched connection. A data module must be administered first before making this assignment.
- `Secondary Output Format` — Enter **printer** (or the format required by the call accounting vendor). The secondary output port is not always used.
- `Secondary Output Endpoint` — Do one of the following (if the secondary output port is used):
  - Enter **CDR2** if the call accounting system is connecting to the switch over a terminal server. You must also administer the IP Services form for the CDR interface.
  - Enter **eia** if the call accounting system is directly connected to the switch using the DCE port.
  - Enter the data module extension if using a switched connection. A data module must be administered first before making this assignment.

- EIA Device Bit Rate — If the output endpoint is set to **eia**, use the default of 9600 for the INTUITY Lodging Call Accounting system, and 1200 for the Xiox call accounting system. For other stand-alone call accounting systems, use the speed specified by the vendor.
- Record Outgoing Calls Only — Unless the customer wishes to record incoming calls, enter **y**.
- CDR Account Code Length — When setting up billing for forwarding faxes (see “Billing considerations when forwarding faxes” on page 128), set this field to the number of digits used for extensions in the dial plan.

```

change system-parameters cdr                               Page 1 of 1
                                CDR SYSTEM PARAMETERS

Node Number (Local PBX ID):                               CDR Date Format: month/day
  Primary Output Format: printer                          Primary Output Endpoint: eia
  Secondary Output Format:
    Use ISDN Layouts? n                                  EIA Device Bit Rate: 9600
    Use Enhanced Formats? n                             Condition Code 'T' for Redirected Calls? n
  Modified Circuit ID Display? n                         Remove # From Called Number? n
    Record Outgoing Calls Only? y                       Intra-switch CDR? n
  Suppress CDR for Ineffective Call Attempts? y         CDR Call Splitting? y
  Disconnect Information in Place of FRL? n             Attendant Call Recording? y
    Interworking Feat-flag? n
  Force Entry of Acct Code for Calls Marked on Toll Analysis Form? n
    Calls to Hunt Group - Record: member-ext
  Record Called Vector Directory Number Instead of Group or Member? n

  Inc Trk Call Splitting? n
  Record Non-Call-Assoc TSC? n
  Record Call-Assoc TSC? n                             Digits to Record for Outgoing Calls: dialed
  Privacy - Digits to Hide: 0                          CDR Account Code Length: 4
  
```

As shown on [page 168](#), enable CDR Reports for each trunk group.

If you assigned **CDR1** or **CDR2** as the CDR endpoint, use the **change ip-services** command to assign the CDR endpoint.

- Service Type — Enter **CDR1** (primary) or **CDR2** (secondary).
- Local Node — Enter the node name for the switch. In this example, **guestworks** is the local node.
- Local Port — Enter **0**. This is the recommended default for the CDR service type.
- Remote Node — Enter node name for the terminal server. In this example, **terminalserver** is the remote node.

- **Remote Port** — Enter the TCP listen port assigned to the terminal server port that is physically connected to the call accounting system. The recommended value for CDR1 is **5101**, and the recommended value for CDR2 is **5102**. The TCP listen port is administered on the terminal server.
- **Protocol Enabled** — Enter **y** to enable the CDR session layer protocol.

```
change ip-services Page 1 of 3

                IP SERVICES
Service  Enabled  Local      Local  Remote      Remote
Type    Type          Node       Port   Node         Port
-----
PMS                    guestworks  0      terminalserver 5103
CDR1                    guestworks  0      terminalserver 5101
CDR2                    guestworks  0      terminalserver 5102
```

On Page 3, you enable the reliable protocol and can adjust the timers and counters used for the reliable protocol. For most applications, you should use the system defaults.

```
change ip-services Page 3 of 3

                SESSION LAYER TIMERS
Service  Reliable Packet Resp  Session Connect  SPDU  Connectivity
Type    Type          Protocol  Timer           Message Cntr     Cntr     Timer
-----
CDR1                    n          3                1                1        1
```

## Administering a port on the terminal server

The initial options on the terminal server must be administered before you administer a port (see [“Terminal server for asynchronous links” on page 183](#)). Use this procedure when connecting a call accounting adjunct to the terminal server.

To administer a port on the terminal server:

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **port** and press ENTER.
4. Type **port number**, where **port number** is the port that the adjunct connects to, and press ENTER to view the Port Setup Menu.

```

** Administrator **
PORT SETUP MENU
Terminal: 2
Hardware
Speed [9600 ] Flow ctrl [Hardware] Keys
Parity [None] Input Flow [Enabled ] Hot [^] Intr [^C]
Bit [8] Output Flow [Enabled ] Quit [^@] Kill [^U]
Stop [1 ] Echo [^@]
Break [Disabled] IP Addresses
Monitor DSR [Yes ] Src [ ] Mask [ ]
Monitor DCD [No ] Dst [ ]

User
Name [cdr ] Keepalive [No ] Access
Terminal type [undef ] Rlogin/Telnet [Telnet] Authentication [None ]
TERM [ ] Debug options [No ] Mode [Raw ]
Video pages [0] Map CR to CR LF [No ] Connection [None ]
CLI/Menu [Yes ] Hex data [No ] Host [ ]
Reset Term [No ] Secure [No ] Remote Port [0 ]
MOTD [No ] Local Port [5101 ]

```

5. Fill in the following fields. Leave the default settings for all other fields.
  - Speed: *must match the call accounting adjunct port speed (default is 9600)*
  - Monitor DSR: Yes
  - Name: cdr
  - Flow ctrl: Hardware or vendor setting
  - Access: Remote
  - Mode: Raw
  - Remote Port: 0 (*C-LAN Ethernet port where IP adjunct service is offered*)
  - Local Port: 5101 or 5102 (*must match the value of Remote Port on the DEFINTY IP Services screen*)
6. Press ENTER and select **Save & Exit** to effect the changes.
7. Press ENTER again to view the Administration Menu.
8. Select **kill** to disable the port connection.
9. When administration is complete, from the Connections Menu, select **logout** (or press **Ctrl D**).
10. Close HyperTerminal.

At this point, you have established a connection path from the adjunct through the IOLAN+ to the C-LAN circuit pack.

## Testing the switch-to-call accounting link

---

To test the CDR link, use the **status cdr-link** command on the switch.

```
status cdr-link
                Primary          CDR LINK STATUS          Secondary
                Link State: up    extension not administered
                Maintenance Busy? no
```

You should also work with the vendor to test the link from the call accounting end. If you are installing the INTUITY Lodging Call Accounting, work with the Homisco technician to test the link.

## **INTUITY Lodging Call Accounting-to-PMS translations and testing**

---

The data link between the INTUITY Lodging Call Accounting and the PMS must be administered by the Homisco technician when he or she installs the software on the INTUITY platform.

If a stand-alone call accounting system (such as Xiox) is used, the vendor must assist in setting up the call accounting system.

To test the call accounting link, make a test call from a test guest room to verify that the call is posted on the call accounting system and the PMS.

## Printer translations (switch)

To translate a printer:

- Administer the printer endpoints (either an IP endpoint or a data module extension number).
- Administer the time when scheduled reports will print.
- Administer the node name and IP services, or administer a data module.

## Administering the printer endpoints

Enter a printer endpoint definition (**PMS\_JOURNAL** or **PMS\_LOG**), or the data module extensions of the printers in the PMS Log Endpoint and Journal/Schedule Endpoint field.

```
change system-parameters hospitality                               Page 1 of 3
                        HOSPITALITY

                        Message Waiting Configuration: act-nopms
                        Controlled Restrictions Configuration: act-pms
                        Housekeeper Information Configuration: act-pms
                        Number of Housekeeper ID Digits: 0
                        PMS Log Endpoint: 7850
                        Journal/Schedule Endpoint: 7850
                        Client Room Coverage Path Configuration: act-nopms
                        Default Coverage Path for Client Rooms: 1
                        Forward PMS Messages to Intuity Lodging? y

                        PMS LINK PARAMETERS
                        PMS Endpoint: 7899
                        PMS Protocol Mode: transparent ASCII mode? y
                        Seconds before PMS Link Idle Timeout: 20
                        Milliseconds before PMS Link Acknowledgement Timeout: 500
                        PMS Link Maximum Retransmissions: 5
                        PMS Link Maximum Retransmission Requests: 5
                        Take Down Link for Lost Messages? y
```

For a system printer, enter a printer endpoint definition (**SYS\_PRNT**), or enter the data module extension in the System Printer Endpoint field. If you are connecting the system printer to the DCE EIA port (instead of using that port for call accounting), enter **eia** in this field.

```
change system-parameters features                               Page 4 of 10
                        FEATURE-RELATED SYSTEM PARAMETERS

SYSTEM PRINTER PARAMETERS
      System Printer Endpoint: 7860                            Lines Per Page: 60
      EIA Device Bit Rate: 9600

SYSTEM-WIDE PARAMETERS
      Switch Name:
      Emergency Numbers - Internal:                            External:
      No-License Incoming Call Number:

MALICIOUS CALL TRACE PARAMETERS
      Apply MCT Warning Tone? n    MCT Voice Recorder Trunk Group:

SEND ALL CALLS OPTIONS
      Send All Calls Applies to: station
      Auto Inspect on Send All Calls? n

UNIVERSAL CALL ID
      Create Universal Call ID (UCID)? n
                                          UCID Network Node ID:
```

Use the **change system-parameters maintenance** command to enter the time of day when you want the scheduled reports to print.



**CAUTION:**

*Do not set the time for these reports to the same time when the switch starts its scheduled maintenance tests (usually at 1 a.m.). See the **change system-parameters maintenance** screen to verify the time and to coordinate this administration so the times do not overlap.*

```

change system-parameters hospitality                               Page 2 of 3
                        HOSPITALITY

Dual Wakeups? y      Daily Wakeup? y      VIP Wakeup? y
                        VIP Wakeups Per 5 Minutes: 5
                        Room Activated Wakeup With Tones? y
                        Time of Scheduled Wakeup Activity Report: 12:00AM
                        Time of Scheduled Wakeup Summary Report: 12:30AM
Time of Scheduled Emergency Access Summary Report: 12:45AM
                        Announcement Type: silence

Length of Time to Remain Connected to Announcement: 30
Extension to Receive Failed Wakeup LWC Messages: 399
Routing Extension on Unavailable Voice Synthesis:
Display Room Information in Call Display? n
Automatic Selection of DID Numbers? y
Custom Selection of VIP DID Numbers? y
Number of Digits from PMS:
PMS Sends Prefix? n
Number of Digits in PMS Coverage Path: 3
Digit to Insert/Delete:
    
```

## Administering a TCP/IP printer connection

To administer the switch-to-printer link using the C-LAN circuit pack:

- Administer node names and IP addresses for the switch and the terminal server on the IP Node Names form (if not already done).
- Administer service types, local nodes, and remote nodes on the IP Services form.
- Administer a TCP “listen” port on the terminal server.

## Administering node names and IP addresses

Using the **change node-names ip** command, assign node names and IP addresses for both the switch and the terminal server. In this example, the switch is named **guestworks**, and the IP address is **192.168.1.10**. The terminal server is named **terminalserver**, and the IP address is **192.168.1.99**. The IP addresses in this example are non-public addresses. Use this IP address if you are installing a dedicated direct link between the switch and the INTUITY system. The **default** node name entry is display-only and is not used for this application. You can add the node names in any order on this screen; the next time you display the node names, they will be in alphabetical order.

```
change node-names ip                                     Page 1 of 1

                                IP NODE NAMES

Name          IP Address      Name          IP Address
default       0 .0 .0 .0         . . .
guestworks    192.168.1 .10     . . .
terminalserver 192.168.1 .99     . . .
. . .         . . .         . . .
```

## Administering IP services

Using the **change ip-services** command, assign the following:

- Service Type — Enter **PMS\_JOURNAL** for a journal printer, **PMS\_LOG** for a PMS log printer, or **SYS\_PRNT** for a system printer.
- Local Node — Enter the node name for the switch. In this example, **guestworks** is the local node.
- Local Port — Enter **0**. This is the recommended default for the printer service types.
- Remote Node — Enter node name for the terminal server. In this example, **terminalserver** is the remote node.

- **Remote Port** — Enter the TCP listen port assigned to the terminal server port that is physically connected to the printer. The recommended value for PMS\_JOURNAL is **5104**; the recommended value for PMS\_LOG is **5105**; and the recommended value for SYS\_PRNT is **5106**. The TCP listen port is administered on the terminal server.
- **Protocol Enabled** — This field is used only for PMS\_JOURNAL and PMS\_LOG printers.

```
change ip-services Page 1 of 3

      IP SERVICES
Service  Enabled  Local  Local  Remote  Remote
Type    Node     Port  Node   Node    Port
-----
PMS      0         guestworks 0 terminalserver 5103
CDR1     0         guestworks 0 terminalserver 5101
PMS_JOURNAL 0         guestworks 0 terminalserver 5104
PMS_LOG  0         guestworks 0 terminalserver 5105
SYS_PRNT 0         guestworks 0 terminalserver 5106
```

On Page 3, you enable the reliable protocol and can adjust the timers and counters used for the reliable protocol. For most applications, you should use the system defaults.

### Administering a port on the terminal server

The initial options on the terminal server must be administered before you administer a port (see [“Terminal server for asynchronous links” on page 183](#)). Use this procedure when connecting printers to the terminal server.

To administer a port on the terminal server:

1. Select **Admin mode > Password** and press ENTER.
2. Type **iolan** and press ENTER.
3. Select **port** and press ENTER.
4. Type **port number**, where **port number** is the port that the adjunct connects to, and press ENTER to view the Port Setup Menu.

```

** Administrator **
PORT SETUP MENU
Terminal: 2
Hardware
Speed [9600 ] Flow ctrl [Hardware] Keys
Parity [None] Input Flow [Enabled ] Hot [^] Intr [^C]
Bit [8] Output Flow [Enabled ] Quit [^@] Kill [^U]
Stop [1 ] Echo [^@] Sess [^@]
Break [Disabled] IP Addresses
Monitor DSR [Yes ] Src [ ] Mask [ ]
Monitor DCD [No ] Dst [ ]

User
Name [sysprinter ] Keepalive [No ] Access [Remote ]
Terminal type [undef ] Rlogin/Telnet [Telnet] Authentication [None ]
TERM [ ] Debug options [No ] Mode [Raw ]
Video pages [0] Map CR to CR LF [No ] Connection [None ]
CLI/Menu [Menu] Hex data [No ] Host [ ]
Reset Term [No ] Secure [No ] Remote Port [0 ]
MOTD [No ] Local Port [5104 ]

```

5. Fill in the following fields. Leave the default settings for all other fields.
  - Speed: *must match the printer speed* (default is 9600)
  - Monitor DSR: Yes
  - Name: *printer name*
  - Flow ctrl: Hardware
  - Access: Remote
  - Mode: Raw
  - Remote Port: 0 (*C-LAN Ethernet port where IP adjunct service is offered*)
  - Local Port: 5104, 5105, or 5106 (*must match the value of Remote Port on the DEFINTY IP Services screen*)
6. Press ENTER and select **Save & Exit** to effect the changes.
7. Press ENTER again to view the Administration Menu.
8. Select **kill** to disable the port connection.
9. When administration is complete, from the Connections Menu, select **logout** (or press **Ctrl D**).
10. Close HyperTerminal.

At this point, you have established a connection path from the printer through the terminal server to the C-LAN circuit pack.

## Administering the printer connection using data modules

---

In the example below, the same printer is used for journal/schedule printing and log printing. If you have two different printers, you must administer two different data modules, and you will assign a different extension for each printer.



**NOTE:**

A log printer must be administered if the “list PMS down” feature is to log errors. If an actual log printer is not being installed, you should administer an **X** in the `Port` field (administration without hardware) to represent the log printer assignment.

```
add data-module 7850
                                DATA MODULE

Data Extension: 7850           Name: JOURNAL PRT           BCC: 2
Type: pdm                     COS: 15   Remote Loop-Around Test? n
Port: 01B0101                 COR: 50   Secondary data module? n
ITC: restricted               TN: 1           Connected to: dte

ABBREVIATED DIALING
List1:

SPECIAL DIALING OPTION:

ASSIGNED MEMBER ( Station with a data extension button for this data module )

    Ext   Name
1:

```

## Testing the Journal/PMS log or system printer

---

Using the RS232 Mini-Tester (see the Note on [page 5](#)), check the status of the printer connection. The leads marked with an asterisk are controlled by the switch, and the printer controls the other leads. If any of the switch leads are dark, there is no connection.



### CAUTION:

*After using a mini-tester to check data leads, you MUST remove the mini-tester from the connection. DO NOT leave the mini-tester in-line during actual operation.*

If the link is active, the mini-tester should show the following:

TD ● red	
	red ● RD*
RTS ● green	
	green ● CTS*
DSR* ● green	
	green ● DTR
CD* ● green	

The following three test results occur if the link is idle, but the reason for each result is different.

The following will display if the link is not up; try the **test journal pms** command to start the link. The printer could also be busied out; try the **release journal pms** command to release the printer.

TD ● red	
	red ● RD*
RTS ● green	
	red ● CTS*
DSR* ● red	
	green ● DTR
CD* ● red	

The following will display if the printer is turned off; turn on the printer power.

TD	<input type="radio"/>	dark		
			red	<input checked="" type="radio"/> RD*
RTS	<input type="radio"/>	dark		
			red	<input checked="" type="radio"/> CTS*
DSR*	<input checked="" type="radio"/>	red		
			dark	<input type="radio"/> DTR
CD*	<input checked="" type="radio"/>	red		



**NOTE:**

RTS will be lit on the front panel of the 7400A or 7400B. The CTS lead shows green when used with an 8400B.

The following will display if the printer is off-line; press the on-line button on the printer.

TD	<input checked="" type="radio"/>	red		
			red	<input checked="" type="radio"/> RD*
RTS	<input checked="" type="radio"/>	red		
			green	<input checked="" type="radio"/> CTS*
DSR*	<input checked="" type="radio"/>	green		
			green	<input checked="" type="radio"/> DTR
CD*	<input checked="" type="radio"/>	green		

Another way to test the log printer connection is to create an Automatic Wakeup call for the test room. If the printer is working, an Automatic Wakeup call request message prints on the log printer.

Use the **status link X** command to display the active TCP/IP applications. **X** is the TCP/IP link number. In this example of Page 4, the system shows the current activity of the different IP services. Each assigned printer service should show one active session.

```
status link 1                                     Page 4 of 4
TCP/IP Applications Currently Active

Service Type      Sessions
ALARM1            1
ALARM2            1
CDR1              1
CDR2              0
DOLAN             0
PMS               1
PMS_JOURNAL       1
PMS_LOG           0
SAT               3
SYS_PRNT          1
```

## Parallel printer translations (INTUITY)

For R4.4, use the **Customer/Services Administration > System Management > UNIX Management > Printer Administration > Install Printer Software** command to set up the parallel printer on the INTUITY system. This command enables the printer port (lp1) for parallel printer operation.

For R5 and later, use the **UNIX Management > Printer Administration** command to set up the parallel printer on the INTUITY system. This command enables the printer port (lp1) for parallel printer operation. You can select from **Install Okidata 320 Printer Software** or **Install Okidata Laser Printer Software**. Use the option that best matches your printer model.

## Customer logins (switch)

Customer logins cannot be added using the craft login, but you can change passwords for existing customer logins (use **list login** to display the logins). If customer logins exist, use the following screen to change the passwords to the switch. The passwords must be three to six characters long using any combination of 0-9, a-z, and A-Z. You should change only the logins that the customer requests. Instruct the customer that the logins and passwords must be kept secure to avoid security issues.

```
change password staff1                                Page 1 of 1
                PASSWORD ADMINISTRATION

Password of Login Making Change:

LOGIN BEING CHANGED                                Login Name: staff1

LOGIN'S PASSWORD INFORMATION
                Login's Password:
                Reenter Login's Password:
```

## Customer logins (INTUITY)

Use the **Customer/Services Administration > System Management > Password Administration > Assign/Change Password** command to create a password for the customer. The customer will use the "sa" login. Remind the customer to change the password as soon as the system is turned over, and to change it frequently. You can also set the password aging option using the **Customer/Services Administration > System Management > Password Administration > Assign/Change Password Aging** command.

## Security notification (switch)

Use the **change system security-parameters** command to add security notification to the switch for login, remote access, authorization code, or station security code violations. You must enter **y** in the highlighted fields before the other entry fields will display.

```
change system-parameters security                               Page 1 of 2
      SECURITY-RELATED SYSTEM PARAMETERS

SECURITY VIOLATION NOTIFICATION PARAMETERS

SVN Login Violation Notification Enabled? y
  Originating Extension:                                     Referral Destination:
  Login Threshold:                                           Time Interval:
  Announcement Extension:

SVN Remote Access Violation Notification Enabled? y
  Originating Extension:                                     Referral Destination:
  Barrier Code Threshold:                                    Time Interval:
  Announcement Extension:

SVN Authorization Code Violation Notification Enabled? y
  Originating Extension:                                     Referral Destination:
  Authorization Code Threshold:                             Time Interval:
  Announcement Extension:
```

```
change system-parameters security                               Page 2 of 2
      SECURITY-RELATED SYSTEM PARAMETERS

SECURITY VIOLATION NOTIFICATION PARAMETERS

SVN Station Security Code Violation Notification Enabled? y
  Originating Extension:                                     Referral Destination:
  Station Security Code Threshold:                          Time Interval:
  Announcement Extension:

STATION SECURITY CODE VERIFICATION PARAMETERS

      Minimum Station Security Code Length: 4
Station Security Code for Terminal Self-Administration Required? y

ACCESS SECURITY GATEWAY PARAMETERS
  MGRI? n          INADS? n          IP? n
  EPN? n          NET? n

IP SAT Timeout (mins):          Translation-ID Mismatch Interval (days): 5
```

## **Saving translations (switch)**

---

After you have finished all translations, tested the translations, and verified them with the customer, save the announcements using the **save announcements** command. When that is finished, save translations using the **save translation** command. After saving translations, log off using the **logoff** command.

## **Creating a backup (INTUITY)**

---

Use the **Customer/Services Administration > Backup/Restore > Backup** command to create a backup tape for the INTUITY. Follow the instructions displayed on the screen.

---

## Finishing the switch installation

---

This section contains procedures that you must complete after you have connected and tested the hospitality adjuncts. The procedures in this section are fully detailed in the appropriate switch installation documents.

### Testing the switch

---

See the appropriate installation document for information about testing the switch:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.

### Installing and wiring telephones and other equipment

---

See the appropriate installation document for information about installing and wiring telephones and other equipment:

- For CMC installations, see Chapters 1 and 2 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.

When installing the attendant consoles, see [“Attendant console button layouts \(switch\)” on page 132](#) for more information. When installing backup telephones, see [“Backup telephone button layouts \(switch\)” on page 142](#) for more information.

## Testing telephones and other equipment

---

See the appropriate installation document for information about testing telephones and other equipment:

- For CMC installations, see Chapter 1 of *DEFINITY ECS Installation, Upgrades and Additions for Compact Modular Cabinets*.
- For SCC installations, see the *DEFINITY Made Easy Tools*.
- For MCC installations, see the *DEFINITY Made Easy Tools*.

A feature now available is Station Self-Display. This feature allows you to dial a feature access code or press the Inspect button at a display telephone to display the extension number for that telephone. The feature is enabled using the **change system-parameters features** command. The feature access code is assigned using the **change feature-access-codes** command.

## Turning the system over to the customer

---

After you have installed and tested the switch and installed adjuncts, and have determined that the system is operating correctly, you will turn control of the system over to the customer. Follow your local customer turnover procedures as determined by your distributor or as determined by the customer's contract. This turnover should include the following:

- Do a final save of the translations.
- Give the customer the following documentation:
  - *GuestWorks and DEFINITY ECS Hospitality Operations*
  - *DEFINITY ECS Documentation Library* (CD)
  - INTUITY voice messaging instructions/artwork
  - A copy of the dialing plan, a list of the feature access codes, and a list of the trunk access codes
  - Customer logins and passwords for the switch and the INTUITY system.
- Show the customer how to record announcements for Automatic Wakeup calls or the Automatic Attendant feature.
- Explain any Call Vectoring procedures that have been administered for the Automated Attendant or Dial by Name features.

- Remind the customer to provide information about any new telephone numbers and services to the guests, such as instructions that show guests how to do their own Automatic Wakeup calls and Do Not Disturb requests. The information about those features is in *GuestWorks and DEFINITY ECS Hospitality Operations*.
- If the customer has a maintenance contract with Avaya, tell the customer that all trouble calls, whether they involve the switch, the INTUITY AUDIX or INTUITY Lodging, or the INTUITY Lodging Call Accounting, should go to 1-800-242-2121. Outside of the United States and Canada, the customer should call their local Avaya representative.

## Maintenance

---

See the appropriate maintenance document for more information:

- *DEFINITY ECS Maintenance for r*
- *DEFINITY ECS Maintenance for csi*
- *DEFINITY ECS Maintenance for si*



---

# Appendixes

---

Additional information for technicians is provided in the following appendixes:

- [“Appendix A — Parts list” on page 286](#)
- [“Appendix B — Connector pinouts” on page 288](#)
- [“Appendix C — List PMS down events” on page 289](#)
- [“Appendix D — Homisco call record format” on page 292](#)
- [“Appendix E — Xiox call accounting format” on page 293](#)

## Appendix A — Parts list

Table 14 shows many of the parts used with the switch. Use this list as a reference if you need to order additional or replacement parts.

**Table 14. Parts list**

Part	Number
MAP LAN cards	Model 8412 Model 8416
MAP DCIU card (GPSync)	406801647; J1P260AA, List 31
MAP Multiport Serial card (Equinox)	J1P260AA1, List 39
MAP Equinox DTE 10/10 adapter, P/N:210068	406983155
MAP IVC6 (AYC10) analog voice interface	106406580
MAP IVC6A (AYC29) tip/ring interface	107213944
MAP NGTR (AYC30) next generation tip/ring interface	107224586
MAP Ferrites (required for some voice port installations)	407616846
MAP 6-pin modular cords, 3 ft.	ED5P208-30, Group 16
MAP 885A connector kit 885A connecting block RJ11C 4-wire modular cords, 25 ft.	601419666; ED5P907-70, Group 1 103732582
103A connecting block	105164818
104A connecting block	105164859
Isolating Data Interface (IDI) Unit 105C 105D	107422735 108367376
PI-to-IDI cable 10 ft. 25 ft. 50 ft. 100 ft. 200 ft.	H600-210, Group 1 H600-210, Group 2 H600-210, Group 3 H600-210, Group 4 H600-210, Group 5
IDI-to-DCIU card cable, 4.5 ft.	ED1E434-11, Group 175
D6AP RJ25 6-pin modular cord 7 ft. 14 ft. 25 ft.	102937620 102937604 102937588
D8W RJ45 8-pin modular cord 7 ft. 14 ft. 25 ft. 50 ft. 75 ft. 100 ft.	103786786 or 103786778 103786802 103786828 103866109 103866125 103866141
451A in-line adapter (for linking RJ45 cables)	103786240

**Table 14. Parts list (Continued)**

<b>Part</b>	<b>Number</b>
Category 5 RJ45 modular cords	
5 ft.	107748063
10 ft.	107748105
15 ft.	107748188
25 ft.	107742322
50 ft.	107742330
100 ft.	107748238
200 ft.	107748246
300 ft.	107748253
Modular Adapters (50-pin to 8-pin)	
259A	102631413
IP Media Processor	848525887
D8AM-87 crossover cord	846943306 or 104154414
D25F 5 ft. cable, plug-to-receptacle	105193668
M25A cable, plug-to-receptacle	
5 ft.	102269602
9 ft.	102269610
25 ft.	102269628
50 ft.	102269636
M25B cable, plug-to-plug	
4 ft.	102269669
10 ft.	102269677
25 ft.	102986643
50 ft.	846823730
B25A distribution cable	
10 ft.	846300994
15 ft.	846301000
25 ft.	846301026
50 ft.	846301075
100 ft.	846301174
Null modem	407122043
7400A data module	105558050
7400B data module	106545841
7400A/7400B power supply; WP90110, L7	405509852
7400B power supply; WP91508, L5	405967696
8400B data module	407444835
Comsphere 3820 modem	107560534
9-pin to 25-pin EIA transition cable, 1 ft.	847106945; ED3G1115
RS232 Mini-Tester	407515139

## **Appendix B — Connector pinouts**

---

Connections from the Equinox card on the MAP to the hospitality adjuncts (PMS or call accounting) can often cause problems. The following list gives you the pinouts and EIA leads provided when using a D6AP modular cord from the Equinox card to the Equinox 10/10 adapter (P/N:210068, comcode 406983155). These pinouts are on the 25-pin end of the adapter.

- Pin 2 - TD (transmit data)
- Pin 3 - RD (receive data)
- Pin 7 - GND (ground)
- Pin 8 - DCD (data carrier detect)
- Pin 20 - DTR (data terminal ready).

This arrangement of EIA is standard in the industry, but these pinouts may become valuable if the adjunct vendor needs to provide a special adapter to interface to this arrangement.

## Appendix C — List PMS down events

Whenever an error occurs between the switch and the PMS, a log of the event is kept on the switch. The following is an example of some PMS down events and reasons.

```
list pms-down                                Page 1
PROPERTY MANAGEMENT SYSTEM ACTIVITY

Extension  Event                Reason                Date/Time
2900      from room, code 1    active - nopms       18/20:10 PM
3100      from sta., code 2    active - nopms       18/21:00 PM
3344      checkout, MWL off    PMS Link Out         18/21:25 PM
3302      room check in        PMS Link Out         18/21:34 PM
3320      PBX chng stn rstr   active - nopms       18/22:00 PM
```

You can use these events to troubleshoot link problems or verify link events. If there is a log printer installed and administered on the switch, these events are logged to that printer as they occur. If there is not a log printer, the **list pms-down** command displays the events that occurred on the switch for the last 24 hours. The **list pms-down long** command displays the last 100 events that occurred on the switch, regardless of time frame. [Table 15](#) is a listing of the events and their meanings, and [Table 16](#) is a listing of the reasons and their meanings.

**Table 15. PMS down events**

Event	Meaning
checkin, occupied	Check in confirmed; room already occupied
checkout, message	Check out confirmed; messages exist
checkout, MWL off	Check out confirmed; MWL off
checkout, MWL on	Check out confirmed; MWL on
checkout, vacant	Check out confirmed; room already vacant
cnf data link rel	Confirm data link release
end data swap	End of database exchange
from room, code 1	Housekeeping from room; process code 1
from room, code 2	Housekeeping from room; process code 2
from room, code 3	Housekeeping from room; process code 3
from room, code 4	Housekeeping from room; process code 4
from room, code 5	Housekeeping from room; process code 5
from room, code 6	Housekeeping from room; process code 6
from room, PMS acc	PMS accepts housekeeping status change from room
from room, PMS rej	PMS rejects housekeeping status change from room
from stn, code 1	Housekeeping from station; process code 1
from stn, code 2	Housekeeping from station; process code 2

**Table 15. PMS down events (Continued)**

<b>Event</b>	<b>Meaning</b>
from stn, code 3	Housekeeping from station; process code 3
from stn, code 4	Housekeeping from station; process code 4
from stn, PMS acc	PMS accepts housekeeping status change from station
from stn, PMS rej	PMS rejects housekeeping status change from station
gst info: complt	Guest info completed
gst info: no chg	Guest info no change
gst info: request	Guest info request
gst info: vacant	Guest info vacant
invalid PMS msg	Switch received a message with either a bad feature code or process code
MWL, another type	PMS attempted clearing MWL
PBX chng stn rstr	Switch changed the station's restriction value
PBX cleared MWL	Switch cleared a station's MWL
PBX enabled MWL	Switch enabled a station's MWL
PBX room image	Switch's room data image for synchronization
PMS chng stn rstr	PMS changes station's restriction value
PMS cleared MWL	PMS wants station's MWL cleared
PMS enabled MWL	PMS wants station's MWL enabled
PMS room change	Room change message from PMS
PMS room image	PMS's room data image for synchronization
PMS room swap	Room swap message from PMS
req data link rel	Request data link release
room ch/sw error	Room change/swap data error
room checkin	Room check-in
room checkout	Switch is to check-out room
room data request	Room data request
room data resp	Room data response
start data swap	Start of database exchange
status inquiry	Status inquiry from PMS
status : OK	Status response: OK
status : PBX init	Status response: switch-initiated
status : UC	Status response: uncommunicated changes

**Table 16. PMS Down Reasons**

<b>Reason</b>	<b>Meaning</b>
active-nopms	Feature is active, no PMS
ADX link out	AUDIX link is out of service
ADX rej msg	AUDIX rejected message
PBX bfr ovfl	Switch buffer overflow
PBX rej msg	Switch rejected message
PMS link out	PMS link is out of service
PMS prot vio	PMS protocol violation
PMS rej msg	PMS rejected the message
rcv viol msg	Received violation message
viol:bad cp	Coverage path not within allowed range or equal to a special code representing the "Default Coverage Path for Client Rooms"
viol:bad ext	Extension does not exist or does not have a client room COS
viol:bad fea	Invalid feature code
viol:bad fmt	Message format not correct (for example, 0xff characters or 0xf bytes not present where required)
viol:bad mw	Invalid Message Waiting message
viol:bad nm	At least one name character is invalid
viol:bad occ	Invalid occurrence
viol:bad pro	Invalid process code for the associated feature code
viol:bad res	Invalid restriction level
xmt viol msg	Transmitted violation message

## Appendix D — Homisco call record format

This appendix provides a copy of the Homisco call record format for call accounting. If possible, share this information with the PMS vendor before the installation.

### Call Record Format

```

01-- <STX>Start Of Text
02--05 Call ID
06-- Space
07--09 Hotel Identifier (3 char.)
10-- Space
11--15 Date Field
16-- Space
17--22 Extension Field (left-justified)
23--27 Time of Day (24-hour clock)
28-- Space
29--32 Duration Field
33-- Space
34--40 Price Field (including "$" and ".")
41-- Space
42--57 Number Dialed Field (left-justified)
58-- Call Type Identifier (L=Local, F=Foreign)
59-- <ETX> End of Text
60-- Check Sum (may be disregarded)

```

### Examples of Call Record Format

```

<STX>0001 PPH 08/12 1102 10:02 0004 $003.34 617-234-9876 <ETX>a
<STX>0002 PPH 08/12 303 10:16 0011 $012.56 3438754923 F<ETX>P
<STX>0003 PPH 08/12 72101 11:01 0001 $000.60 555-1212 <ETX>M
<STX>0004 PPH 08/12 1309 11:15 0006 $000.75 399-1000 L<ETX>+
<STX>0005 PPH 08/12 723 13:27 0018 $000.50 610-375-3876 <ETX>!
<STX>0006 PPH 08/12 505 13:45 0001 $000.60 411 L<ETX>8
<STX>0007 PPH 08/12 72100713:59 0003 $002.18 332-7845 <ETX>*

```

### Message Exchange

```

Homisco                               PMS
ENQ ----->
      <-----ACK
TEXT----->
      <-----ACK/NAK

```

## Appendix E — Xiox call accounting format

---

This appendix provides information about the Xiox call accounting posting interface and format. If possible, share this information with the PMS vendor before the installation.

Posting from the Xiox call accounting is done over an RS232 connection from COM2 of the PC running the Xiox call accounting software to a serial port on the PMS. The cable configuration is a standard serial cable with a null modem. When the PC serial port connector is a standard 9-pin connector, Xiox sends on pin 3 and receives on pin 2. Xiox requires a connection on pin 5 (signal ground) and holds pin 4 (DTR) and pin 7 (RTS) high while in the Call Processing mode. DTR and RTS will drop when exiting Call Processing.

The following information is needed from the Property Management System vendor:

1. What are the speed, parity, data bits, and stop bit parameters expected by the PMS?
2. What data format is expected by the PMS? The choices are:
  - 0 - Hobic record with a 4-digit sequence number
  - 1 - Micros PMS format
  - 2 - Hobic record with 3-digit sequence number followed by one letter
  - 3 - Hobic fixed length record with 4-digit sequence number.
3. What is the initiator (start of text) character expected by the PMS? (For example, 02 for a black happy face indicating STX.)
4. What is the terminator (end of text) character expected by the PMS? (For example, 03 for a black heart indicating ETX.)
5. Is the PMS capable of handshaking? If so, what character is expected by the PMS for Acknowledge and Negative Acknowledge? (For example, 06 for ACK, and 21 for NAK.)
6. Is a Block Check Character (BCC) or check sum expected by the PMS?

The following is a sample of Format 0 (Hobic with 4-digit sequence number):

**0001 HTL 02/29 501 13:32 0009 \$002.50 650-555-1212**

The following table describes this format:

<b>Position</b>	<b>Length</b>	<b>Description</b>
1	4	Message Sequence Number - right justified, 0 filled
6	3	Property Name Acronym - up to 3 alpha characters specified by the user
10	5	Date - MM/DD
16	5	Extension Number - left justified, space filled
22	5	Call Start Time - HH:MM
28	4	Duration in Minutes - right justified, 0 filled
33	7	Price - fixed format, 0 filled
41	14	Dialed Digits - variable length field consisting of a dialed digit string of up to 12 characters

---

# Index

---

## Numerics

103A modular connecting blocks, [33](#), [37](#)  
105C IDI, [29](#)  
105D IDI, [29](#)  
3820 modem, [102](#)  
7400A data module options, [70](#), [80](#), [90](#)  
7400B data module options, [71](#), [81](#), [91](#)  
8400B data module options, [69](#), [79](#), [89](#)  
885A connector kit, [33](#)

---

## A

Abbreviated Dialing, [129](#), [134](#)  
about this handbook, [xv](#)  
activate the switch, [12](#)  
adjunct supervision, [241](#)  
alarm management, [104](#)  
alerting, [137](#)  
analog caller ID, [150](#)  
announcements, [159](#)  
ASCII mode, [190](#)  
Attendant Backup, [136](#), [139](#), [142](#)  
Attendant Call Pickup, [142](#)  
attendant console, [131](#), [132](#)  
    permissions, [115](#)  
    queue priority, [138](#)  
Attendant Split Swap, [133](#)  
Attendant Vectoring, [178](#)  
AUDIX subscribers, [146](#)  
Automated Attendant, [1](#), [176](#)  
Automatic Selection of DID Numbers, [169](#)  
Automatic Wakeup options, [174](#)  
Avaya Site Administration, [8](#), [11](#)

---

## B

backup on INTUITY, [280](#)  
backup telephone, [142](#)  
billing considerations for faxes, [128](#)  
bus bridge, [16](#), [215](#)  
button layout  
    attendant console, [132](#)  
    telephones, [142](#)

## buttons

Attendant Call Pickup, [142](#)  
Automatic Wakeup, [134](#)  
Automatic Wakeup printer alarm, [134](#)  
CDR alarm, [134](#)  
check-in, [134](#)  
check-out, [134](#)  
Controlled Restrictions, [134](#)  
Coverage Message Retrieval, [135](#)  
Crisis Alert, [134](#)  
date/time, [135](#)  
delete message, [135](#)  
DID view, [133](#)  
directory, [134](#)  
display, [135](#)  
Do Not Disturb, [134](#)  
failed wakeups, [134](#), [142](#)  
forced release, [134](#)  
Hold, [134](#)  
inspect, [135](#)  
maid status, [134](#)  
Message Waiting activation, [133](#), [142](#)  
Message Waiting deactivation, [133](#), [142](#)  
next, [135](#)  
Night Service, [134](#)  
normal, [135](#)  
occupied rooms, [134](#)  
PMS alarm, [134](#)  
PMS printer alarm, [134](#)  
position busy, [134](#)  
split, [133](#)  
Split Swap, [133](#)  
system printer alarm, [135](#)  
timer, [135](#)  
translations, [132](#)  
trunk ID, [134](#)  
VIP retry, [134](#)  
VIP wakeup, [134](#)

---

## C

### cabling

hospitality adjuncts, [18](#)  
INTUITY Lodging Call Accounting-to-PMS, [72](#)  
INTUITY Lodging-to-PMS, [39](#)  
MAP remote access, [102](#)  
Mode Code Integration, [32](#)  
overall connectivity, [20](#)  
parallel printers, [97](#)  
serial printers, [84](#)  
switch-to-call accounting, [44](#), [48](#), [52](#), [56](#), [60](#), [64](#)  
    data modules, [67](#)  
switch-to-INADS, [98](#)  
switch-to-INTUITY (Mode Code Signaling), [31](#)

- cabling, (continued)
  - switch-to-INTUITY (X.25), 29
  - switch-to-INTUITY voice ports, 32
  - switch-to-PMS, 75
  - switch-to-voice messaging (TCP/IP), 25
  - voice ports, 32
  - Xiox call accounting-to-PMS, 74
- call accounting, 267
  - link parameters, 262
- Call Forwarding, 116
  - guest message retrieval, 246
- call record format
  - Homisco, 292
  - Xiox, 293
- Call Vectoring, 176, 179, 282
- caller ID, 150
  - message waiting indication, 151
- calls in queue warning, 136
- CDR, 44, 48, 52, 56, 60, 64, 168, 262, 266
  - reports, 168, 263
  - translations, 262
- CE marks, 4
- Center of Excellence, 14, 100, 109
- check-in/check-out, 208
- checklist
  - installation, 4
  - miscellaneous translations, 107
  - switch-to-voice messaging translations, 214
  - translations, 106
- C-LAN, 27, 28
- class of restriction, 117
- class of service, 115, 124
- client room, 115, 116
  - coverage path configuration, 189
- Comsphere 3820, 102
- connector pinouts, 288
- console, 131
  - permissions, 116
- Controlled Restrictions, 134, 200, 212
  - configuration, 189
  - testing, 212
  - translations, 200
- conventions, xvi
- country options, 14
- coverage path configuration, 189
- coverage paths, 246
- Crisis Alert, 134, 164
  - ARS pattern, 164, 165
  - button assignment, 134
  - display telephone, 166
  - every user responds, 166
  - pager, 166
  - translations, 164
- crossover cable, 26

- crossover wiring, 28
- Custom Selection of DID Numbers, 169
- customer
  - documentation, 282
  - logins, 278
  - turnover, 282

---

## D

- daily wakeup, 174
- Data Modules, 198
- data modules, 69, 70, 71, 79, 80, 81, 89, 90, 91, 198
- data privacy, 116
- database swap, 207
- date and time, 15, 108
- daylight savings time rules, 15
- default language, 254, 256
- default translation card, 12
- delete digit, 191
- Dial by Name, 109, 179
- dial plan, 110, 111
  - first digit, 110
  - second digit, 110
- DID numbers, 169
- digit deletion, 191
- digit insertion, 191
- digit to insert/delete, 110, 191
- digital line circuit packs, 24
- display calling number for room to room caller ID calls, 150
- display room information in call display, 149
- displaying a telephone's extension, 282
- distinctive audible alerting, 241
- dual wakeup, 174
- duplicate command, 147, 242

---

## E

- electromagnetic compatibility standards, 3
- emergency access redirection extension, 163
- Emergency Access to Attendant, 163
- Equinox pinouts, 288
- equipment layout, 7
- equipment room, 7
- ethernet data module, 218
- extension to receive failed wakeup LWC messages, 174
- external alert port, 136

---

## F

- failed wakeup button, [134](#), [142](#)
- failed wakeup messages, [174](#)
- fax billing considerations, [128](#)
- fax extension, [249](#)
- fax parameters, [127](#)
- faxes forwarded from guest mailbox, [128](#)
- feature access codes, [112](#)
- feature overview, [1](#)
- ferrites, [33](#)
- floor plan, [7](#)
- forward PMS messages to INTUITY Lodging, [253](#), [255](#)
- forwarding faxes, [128](#)

---

## G

- guest
  - information display, [149](#)
  - mailboxes, [158](#), [260](#)
  - message retrieval, [245](#)
  - rooms, [147](#)
- GuestWorks interface link, [253](#)

---

## H

- hardware options, [xvii](#)
- Homisco, [6](#), [18](#), [44](#), [56](#), [67](#), [139](#), [262](#), [292](#)
- hospitality
  - customer options, [17](#)
  - parameters, [189](#)
- housekeeper
  - ID digits, [199](#)
  - information configuration, [189](#)
- housekeeping status, [198](#)
  - testing, [213](#)
  - translations, [198](#)
- hunt groups, [243](#)
- hunt-to stations, [153](#)

---

## I

- ICLID, [150](#)
- IDI, [30](#)
- INADS, [99](#), [100](#), [102](#)
  - alarm origination, [104](#)

- insert digit, [191](#)
- insert/delete digit, [110](#), [191](#)
- installation
  - cabinet, [10](#)
  - checklist, [4](#)
  - management interface, [11](#)
  - overview, [3](#)
  - telecommunications cabling, [10](#)
  - telephones and other equipment, [281](#)
- integrated link, [253](#)
- INTUITY Lodging Call Accounting, [18](#), [44](#), [56](#), [72](#), [97](#), [139](#), [262](#)
- INTUITY Lodging Call Accounting-to-PMS link
  - testing, [267](#)
  - translations, [267](#)
- INTUITY Lodging voice messaging, [18](#)
- INTUITY Lodging-to-PMS link
  - testing, [258](#)
  - translations, [252](#)
- INTUITY system parameters, [125](#)
- IP addresses, [193](#), [216](#), [222](#), [271](#)
- IP interfaces, [217](#)
- IP routes, [220](#)
- IP services, [194](#), [271](#)
- Isolating Data Interface, [30](#)

---

## J

- journal/log printers
  - testing, [95](#), [275](#)
  - translations, [268](#)
- journal/schedule printer, [19](#), [86](#), [88](#)
- journal/schedule printer endpoint, [268](#)

---

## L

- lamps on for new messages, [158](#), [256](#)
- LAN circuit card, [223](#)
- languages, [254](#), [256](#)
- layout, [7](#)
- LDG, [257](#)
- LEDs, [147](#)
- link integration, [253](#)
- list PMS down events, [289](#)
- Listed Directory Numbers, [126](#), [130](#)
- log printer, [19](#), [86](#), [88](#)
- logical channel, [235](#), [236](#)
- logins, [278](#)
- lost PMS messages, [190](#)
- LWC activation, [241](#)
- LWC reception, [241](#)

---

## M

- maid status
  - testing, [213](#)
  - translations, [198](#)
- mailboxes
  - guest room, [158](#)
  - office staff subscribers, [146](#)
- maintenance, [283](#)
- management interface, [11](#)
- mapping phone numbers to services, [249](#)
- message center, [244](#)
- message lamp control, [257](#)
- message retrieval, [245](#)
- Message Waiting
  - configuration, [189](#)
  - indicator, [147](#)
  - testing, [209](#)
- mini-tester, [5](#)
  - INTUITY Lodging-to-PMS link, [42](#), [258](#)
  - journal/log printers, [95](#)
  - printers, [275](#)
  - switch-to-call accounting link, [46](#), [50](#), [54](#), [58](#), [62](#), [65](#)
  - switch-to-PMS link, [82](#), [202](#)
- Mode Code Integration, [2](#), [31](#), [32](#), [39](#), [238](#), [252](#)
- modems, [102](#)
- multiple locations, [16](#)

---

## N

- neon lamps, [147](#)
- Netcon, [197](#)
  - testing, [204](#)
  - translations, [197](#)
- no answer timeout, [137](#)
- node names, [193](#), [216](#), [271](#)
- number of digits from PMS, [191](#)
- number of emergency calls allowed in attendant queue, [163](#)
- number of housekeeper ID digits, [199](#)

---

## O

- offer categories, [1](#)
- off-hook alert, [116](#), [163](#)
- Okidata model ML321T printer options, [92](#), [93](#)

- Okidata printers, [7](#), [85](#), [87](#)
- options
  - 572 printer, [92](#), [93](#)
  - 7400A for call accounting, [70](#)
  - 7400A for PMS, [80](#)
  - 7400A for printers, [90](#)
  - 7400B for call accounting, [71](#)
  - 7400B for PMS, [81](#)
  - 7400B for printers, [91](#)
  - 8400B for call accounting, [69](#)
  - 8400B for PMS, [79](#)
  - 8400B for printers, [89](#)
  - Okidata printers, [92](#), [93](#)

---

## P

- packet gateway, [30](#)
- Paradyne, [103](#)
- parallel printers, [97](#)
  - translations, [278](#)
- parts, [5](#), [286](#)
- passwords, [17](#), [250](#), [278](#)
  - administrator, [250](#)
  - attendant, [250](#)
  - craft, [14](#)
- PBX extension to channel, [247](#)
- phone number mapping, [249](#)
- ping, [226](#)
- pinouts, [288](#)
- PMS
  - ASCII mode, [190](#)
  - communication parameters, [80](#)
  - down, [289](#)
  - endpoint, [189](#)
  - event IDs on the INTUITY, [259](#)
  - integration parameters, [257](#)
  - Link Acknowledgement Timeout, [190](#)
  - link acknowledgement timeout, [190](#)
  - link maximum retransmission requests, [190](#)
  - link maximum retransmissions, [190](#)
  - link parameters, [190](#)
  - log printer endpoint, [268](#)
  - status, [205](#)
  - take down link for lost messages, [190](#)
  - testing, [205](#)
- prefixed extensions, [191](#)
- printer
  - communication parameters, [90](#)
  - options, [92](#), [93](#)
  - parallel, [97](#)
  - system, [19](#)
  - translations, [268](#)

processor  
  channels, 219, 233  
  interface, 231  
  interface link, 30, 231, 234  
protocol for caller ID analog terminals, 150  
protocol mode, 190

---

## Q

queue length, 243  
queue priority, 138

---

## R

reasons for reissue, *xvi*  
reboot INTUITY, 225  
Recorded Announcements, 159  
recorded announcements, 159  
related documents, *xvii*  
remote maintenance board, 102  
reports, 270  
room status definitions, 199  
routing extension on unavailable voice  
  synthesis, 175

---

## S

saving translations, 105, 280  
scheduling reports, 270  
security notification, 279  
services to channels, 247  
site planning, 6  
software packages, *xvii*  
special applications, 109  
speech synthesizer circuit packs, 162  
Split Swap, 133  
stand-alone interface link, 255  
standards  
  electromagnetic compatibility, 3  
station hunt before coverage, 152, 154  
station hunting, 153  
station self-display, 282  
stations  
  guest rooms, 147  
  office staff, 139  
subscribers, 146  
Suite Check-In, 152  
support helpline, 283  
switch interface on INTUITY, 224  
switch port, 225, 235, 236

switch tests, 281  
switch type, 224  
switch/INTUITY/PMS link integration, 39, 253, 255  
switchhook flash, 240, 241  
switch-to-call accounting link  
  testing, 46, 50, 54, 58, 62, 65, 266  
  translations, 262  
switch-to-PMS link  
  testing, 82, 201  
  translations, 189  
switch-to-voice messaging link  
  testing, 251  
  translations, 214  
system parameters, 125  
system printer  
  testing, 275  
  translations, 268

---

## T

TAAS, 136  
tape backup, 280  
TCP/IP on INTUITY, 222  
TCP/IP signaling, 25, 215  
technical support, *xx*, 283  
  Xiox, 6  
telephones, 282  
terminal server, 183  
test equipment, 5  
testing, 105  
  7400A, 204  
  8400B, 204  
  check-in/check-out, 208  
  Controlled Restrictions, 212  
  database swap, 207  
  housekeeping status, 213  
  INTUITY Lodging Call Accounting-to-PMS  
    link, 267  
  INTUITY Lodging-to-PMS link, 258  
  journal/log printers, 95, 275  
  Message Waiting, 209  
  Netcon, 204  
  ping, 226  
  PMS, 205  
  switch-to-call accounting link, 42, 46, 50, 54, 58,  
    62, 65, 266  
  switch-to-INTUITY link, 251  
  switch-to-PMS link, 82, 201  
  system printer, 275  
  TCP/IP link, 226  
  telephones and other equipment, 282  
  voice mailboxes, 260  
  voice ports, 251  
  X.25 link, 236

- time and date, 15, 108
- tip/ring card, 32, 37
- TN799B, 27
- Toll Restriction, 200
- training, xv
- translation card, 12
- translations, 105, 193
  - Abbreviated Dialing, 129
  - alarm management, 104
  - announcements, 159
  - Attendant Backup, 136
  - attendant console, 131
  - Attendant Vectoring, 178
  - automated attendant, 176
  - billing for forwarded faxes, 128
  - bus bridge, 16, 215
  - buttons, 132
    - attendant console, 132
    - backup telephone, 142
  - call accounting link parameters, 262
  - Call Forwarding for guest message retrieval, 246
  - Call Vectoring, 176
  - caller ID, 150
  - CDR, 262
  - checklist, 106
  - class of restriction, 117
  - class of service, 115, 124
  - console, 131
  - console queue priority, 138
  - Controlled Restrictions, 200
  - country options, 14
  - coverage paths, 246
  - Crisis Alert, 164
  - customer logins, 278
  - date and time, 15, 108
  - daylight savings time rules, 15
  - default language, 256
  - Dial by Name, 109, 179
  - dial plan, 110, 111
  - DID numbers for guest rooms, 169
  - Emergency Access to Attendant, 163
  - ethernet data module, 218
  - fax extension, 249
  - fax parameters, 127
  - feature access codes, 112
  - guest message retrieval, 245
  - guest room mailboxes, 158
  - hospitality
    - customer options, 17
    - parameters, 189
  - housekeeping status, 198
  - hunt groups, 243
  - INADS, 100
  - INTUITY Lodging Call Accounting-to-PMS, 267
  - INTUITY Lodging-to-PMS, 252
  - INTUITY system parameters, 125
  - translations, (continued)
    - IP addresses, 216, 222, 271
    - IP interfaces, 217
    - IP routes, 220
    - IP services, 194, 271
    - LAN circuit card, 223
    - languages, 254, 256
    - link data modules, 198
    - Listed Directory Numbers, 126, 130
    - logins, 278
    - mailboxes, 146, 158
    - miscellaneous, 107
    - Mode Code signaling, 238
    - multiple locations, 16
    - Netcon, 197
    - node names, 193, 216, 271
    - parallel printers, 278
    - passwords, 17, 250, 278
    - PBX extension to channel, 247
    - phone number mapping, 249
    - printer, 268
    - printer endpoints, 268
    - processor channels, 219, 233
    - processor interface link, 231
    - reboot INTUITY, 225
    - recorded announcements, 159
    - remote maintenance, 100
    - saving translations, 17, 280
    - security notification, 279
    - serial printer, 268
    - services to channels, 247
    - services to phone number mapping, 249
    - station hunt before coverage, 154
    - station hunting, 153
    - stations, 139
    - subscribers, 146
    - Suite Check-In, 152
    - switch interface on INTUITY, 224, 235, 236
    - switch type, 224, 234
    - switch/INTUITY/PMS link integration, 253, 255
    - switch-to-call accounting, 262
    - switch-to-INTUITY, 214
    - switch-to-PMS, 189
    - system printer endpoint, 269
    - TCP/IP link, 193
    - TCP/IP on INTUITY, 222
    - TCP/IP signaling, 215
    - terminal server, 183, 195, 264, 272
    - time and date, 108
    - trunk groups, 168
    - Trunk-to-Trunk Transfer, 182
    - voice ports on INTUITY, 247
    - voice ports to INTUITY AUDIX, 240
    - wakeup options, 174
    - X.25 data module, 231
    - X.25 signaling, 231

Trunk Groups, [168](#)  
trunk groups, [168](#)  
Trunk-to-Trunk Transfer, [182](#)

---

## V

VIP wakeup, [174](#)  
voice mailboxes, [260](#)  
voice ports, [32](#), [240](#), [247](#)  
    hunt groups, [243](#)  
    status, [251](#)  
    testing, [251](#)  
    translations, [240](#), [247](#)

---

## W

Wakeup Activation via Tones, [174](#)  
wakeup options, [174](#)

---

## X

X.25 data module, [231](#)  
X.25 signaling, [29](#), [231](#)  
Xiox, [6](#), [18](#), [48](#), [60](#), [67](#)  
    posting interface and format, [293](#)  
    technical support, [6](#)

