

Lucent Technologies
Bell Labs Innovations



DEFINITY[®]

Enterprise Communications Server

Release 8.3

What's New: Network Call Redirection

555-233-759
Comcode 108725649
Issue 1
July 2000

Notice

Every effort was made to ensure that the information in this book was complete and accurate at the time of printing. However, information is subject to change.

Lucent Technologies Web Page

The world wide web home page for Lucent Technologies is:
<http://www.lucent.com>

Preventing Toll Fraud

“Toll fraud” is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or working on your company’s behalf). Be aware that there may be a risk of toll fraud associated with your system and that, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

Lucent Technologies Fraud Intervention

If you suspect you are being victimized by toll fraud and you need technical support or assistance, call the appropriate BCS National Customer Care Center telephone number. Users of the MERLIN®, PARTNER®, and System 25 products should call 1 800 628-2888. Users of the System 75, System 85, DEFINITY® Generic 1, 2 and 3, and DEFINITY® ECS products should call 1 800 643-2353.

Providing Telecommunications Security

Telecommunications security (of voice, data, and/or video communications) is the prevention of any type of intrusion to (that is, either unauthorized or malicious access to or use of your company’s telecommunications equipment) by some party.

Your company’s “telecommunications equipment” includes both this Lucent product and any other voice/data/video equipment that could be accessed via this Lucent product (that is, “networked equipment”).

An “outside party” is anyone who is not a corporate employee, agent, subcontractor, or working on your company’s behalf. Whereas, a “malicious party” is anyone (including someone who may be otherwise authorized) who accesses your telecommunications equipment with either malicious or mischievous intent. Such intrusions may be either to/through synchronous (time-multiplexed and/or circuit-based) or asynchronous (character-, message-, or packet-based) equipment or interfaces for reasons of:

- Utilization (of capabilities special to the accessed equipment)
- Theft (such as, of intellectual property, financial assets, or toll-facility access)
- Eavesdropping (privacy invasions to humans)
- Mischief (troubling, but apparently innocuous, tampering)
- Harm (such as harmful tampering, data loss or alteration, regardless of motive or intent)

Be aware that there may be a risk of unauthorized intrusions associated with your system and/or its networked equipment. Also realize that, if such an intrusion should occur, it could result in a variety of losses to your company (including, but not limited to, human/data privacy, intellectual property, material assets, financial resources, labor costs, and/or legal costs).

Your Responsibility for Your Company’s Telecommunications Security

The final responsibility for securing both this system and its networked equipment rests with you – a Lucent customer’s system administrator, your telecommunications peers, and your managers. Base the fulfillment of your responsibility on acquired knowledge and resources from a variety of sources including but not limited to:

- Installation documents
- System administration documents
- Security documents
- Hardware-/software-based security tools
- Shared information between you and your peers
- Telecommunications security experts

To prevent intrusions to your telecommunications equipment, you and your peers should carefully program and configure your:

- Lucent-provided telecommunications systems and their interfaces
- Lucent-provided software applications, as well as their underlying hardware/software platforms and interfaces
- Any other equipment networked to your Lucent products

Lucent Technologies does not warrant that this product or any of its networked equipment is either immune from or will prevent either unauthorized or malicious intrusions. Lucent Technologies will not be responsible for any charges, losses, or damages that result from such intrusions.

Federal Communications Commission Statement

Part 15: Class A Statement. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Trademarks

- DEFINITY is a registered trademark of Lucent Technologies.
- CentreVu is a registered trademark of Lucent Technologies.
- CONVERSANT is a registered trademark of Lucent Technologies.
- Informix is a registered trademark of Informix Software, Inc.
- Intel is a registered trademark of Intel.
- Microsoft, MS, MS-DOS, Windows, Windows 95, Windows NT, and Access are registered trademarks of Microsoft Corporation.
- MCI is a registered trademark of MCI WorldCom.
- OpenLink is a trademark of OpenLink Software.
- Crystal Reports is a trademark of SeaGate Software.
- Solaris is a trademark of Sun Microsystems, Inc.
- SPARC trademarks, including the SCD compliant logo, are trademarks or registered trademarks of SPARC International, Inc. SPARCstation, SPARCserver, SPARCengine, SPARCworks, and SPARCcompiler are licensed exclusively to Sun Microsystems, Inc. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.
- Sun and Sun Microsystems are trademarks or registered trademarks of Sun Microsystems, Inc.
- Ultra Enterprise 3000 and Ultra 5 are trademarks of Sun Microsystems, Inc.
- UNIX is a registered trademark in the United States and other countries, licensed exclusively through X/Open Company Limited.
- All other products mentioned herein are the trademarks of their respective owners.

Ordering Information

Call: Lucent Technologies BCS Publications Center
Voice 1 800 457-1235 or
International Voice +1 317 322-6791
Fax 1 800 457-1764 International Fax +1 317 322-6699

Write: Lucent Technologies BCS Publications Center
2855 N. Franklin Road
Indianapolis, IN 46219 USA

You can be placed on a standing order list for this and other documents you may need. For more information on standing orders, or to be put on a list to receive future issues of this document, contact the Lucent Technologies Publications Center.

Obtaining Products

To learn more about Lucent Technologies products and to order products, contact Lucent Direct, the direct-market organization of Lucent Technologies Business Communications Systems. Access their web site at www.lucentdirect.com. Or call the following numbers: customers 1 800 451 2100, account executives 1 888 778 1880 (voice) or 1 888 778 1881 (fax).

European Union Declaration of Conformity

The “CE” mark affixed to the equipment means that it conforms to the above directives. Lucent Technologies Business Communications Systems declares that equipment specified in this document conforms to the referenced European Union (EU) Directives and Harmonized Standards listed below:

 EMC Directive 89/336/EEC
Low-Voltage Directive 73/23/EEC

Comments

To comment on this document, return the comment card at the front of the document.

Acknowledgment

This document was prepared by the Product Documentation Development, Lucent Technologies, Denver, CO.

How Are We Doing?

Document Title: DEFINITY® Enterprise Communications System (ECS) Release 8.3
 What's New: Network Call Redirection

Document No.: 555-233-759 Issue 1 Date: July 2000

Lucent Technologies welcomes your feedback on this document. Your comments are of great value in helping us to improve our documentation.

1. Please rate the effectiveness of this document in the following areas:

	Excellent	Good	Fair	Poor	Not Applicable
Ease of Use					////////////////////
Clarity					////////////////////
Completeness					////////////////////
Accuracy					////////////////////
Organization					////////////////////
Appearance					////////////////////
Examples					////////////////////
Illustration					
Overall Satisfaction					////////////////////

2. Please check the ways you feel we could improve this document:

- Improve the overview/introduction
- Improve the table of contents
- Improve the organization
- Include more figures
- Add more examples
- Add more detail
- Make it more concise/brief
- Add more step-by-step procedures/tutorials
- Add more troubleshooting information
- Make it less technical
- Add more/better quick reference aids
- Improve the index

Please provide details for the suggested improvement. _____

3. What did you like most about this document?

4. Feel free to write any comments below or on an attached sheet.

If we may contact you concerning your comments, please complete the following:

Name: _____ Telephone Number: (____) _____

Company/Organization: _____ Date: _____

When you have completed this form, please fax it to 303-538-1741.

DEFINITY® Enterprise Communications Server Release 8.3

What's New: Network Call Redirection

Table of Contents

General Information	1
Overview	1
Audience	1
Before you start: Platform	2
Compliance	3
Trunking considerations	3
Interactions with other call center features	4
CMS database changes	5
What is Network Call Redirection?	6
Overview	6
Network Call Transfer	6
Network Call Deflection	6
Important	7
Implementation	8
Before you start: Platform	8
NCR activation using DEFINITY ECS Call Vectoring	9
NCR and ASAI.	11
Station Call Transfer/ Conference	11
Administration	12
Overview	12
NCR activation by BSR vector call processing	12
Network Call Transfer	13
Sample Vectors	14
DEFINITY administration overview	15
Trunk Group form	16
Signaling Group form	19
Best Service Routing Application form	20
Call Vector form	21
Troubleshooting and Things to Know	22
Overview	22
Troubleshooting	22
NCR troubleshooting	23
Things to know	24
Feature Interactions	25
Best Service Routing	25
Attendant Vectoring.	25
ASAI Drop Event	25
ASAI Third-Party Merge/Call Transfer.	25

What's New: Network Call Redirection

General Information

Overview

Today, call center customers are looking for many ways to reduce their costs. One of these ways is to employ Virtual Private Networks (VPNs) to eliminate as much private network cost as possible. These cost reductions are particularly valuable in enterprises or multi-site call-center environments and especially to Enterprise call centers where network costs are typically high. Network Call Redirection (NCR) offers a call redirection method between sites on a public network or a Public Switched Telephone Network (PSTN) Virtual Private Network, to help reduce trunking costs.

Audience

This document is intended for external customers, and for Lucent internal audiences. External customers include *DEFINITY*[®] administrators and Call Management System (CMS) administrators.

In this document

This document contains information on the following topics:

- Feature description
- Feature administration
- Troubleshooting and things to know

Before you start: Platform

Network Call Redirection is a new *DEFINITY* ECS feature available starting with the Release 8.3 ECS. Full administration support of the feature is provided with the *DEFINITY* ECS R8.3 SAT. In addition, `route-to-number` support for `~r` vector administration will be added with Release 3 Version 9 *CentreVu*[®] CMS and *CentreVu* Visual Vectors Version 9.0, scheduled for release in 2001. Existing R3V6 or later CMS and Visual Vectors administration support for BSR will support NCR. NCR is not supported on Category B switches - *DEFINITY* BCS and GuestWorks.

NCR may only be activated for incoming ISDN trunk calls where the associated trunk group has been enabled by the public network service provider to use Network Call Transfer or Network Call Deflection features. Additionally, incoming ISDN calls can be redirected using NCT only over ISDN two-way trunks that are in the same trunk group with the same signaling group.

NCR uses the *DEFINITY* Best Service Routing feature's `queue-to-best` vector step, which is the best approach for implementation. See the *DEFINITY* Enterprise Communications Server Call Vectoring/Expert Agent Selection Guide, 585-230-521 for complete information on BSR.

Important

Network Call Transfer (NCT) works with only the *MCI*[®] DMS250 network switches as of June 12, 2000. NCT is not offered on MCI DEX600 switches.

Until NCR has been tested on specific PSTNs, performance is not guaranteed. To verify operability, contact your CRM Regional Offer Manager.

Compliance

DEFINITY R8.3 Network Call Deflection support is compliant with ETSI Supplementary Services Network Call Deflection ETS 300 207-1 (partial call rerouting in the public network). Network Call Transfer is compliant with ANSI Explicit Network Call Transfer T1.643 (1995).

In the United States, NCR (specifically Network Call Transfer) is currently only supported by *MCI*[®] WorldCom (only using the DMS-250 network switches). Outside of the United States, there are several carriers supporting NCR (specifically Network Call Deflection). These carriers include Deutsche Telekom in Germany and British Telecom in Britain, as well as carriers in France and Belgium. Other carriers and countries are expected to add support in the near future.

Important

The compliance requirements are needed to negotiate service with your PSTN.

Trunking considerations

The network requires that NCT be invoked over the same signaling group as is used by the incoming call. This must be the same D-channel with associated signaling, or it can be the associated D-channel with Non-Facility Associated Signaling (NFAS).

With vector-invoked NCT (BSR or route-to-number), the second leg of the call is placed over an idle trunk in the same trunk group as the incoming call to ensure that invocation of NCT is done over the same signaling group. Therefore, vectoring activation of NCT requires that the trunk group be a two-way trunk group.

Usage Allocation is used to reserve two trunks in the two-way trunk group. Using the *DEFINITY isdn network facilities* screen, assign an incoming NSF (type 2) and use Usage Allocation to prevent incoming calls from using more than $N-x$ trunks where N is the number of trunks in the group and x is the number to be reserved.

With station, ACD agent, or CTI-initiated conference/transfer, if the second leg of the call is set up over an outgoing trunk with the same signaling group as the incoming call, then NCT can be invoked when the transfer is requested. If an outgoing trunk group is assigned to the same signaling group as the incoming trunk group and that outgoing trunk is selected by the outgoing call (using ARS) placed by the user/CTI application for transfer, then a two-way trunk group is not required.

*MCI is a registered trademark of MCI WorldCom.

Interactions with other call center features

NCR interacts with or affects the following *DEFINITY* components:

- station transfer by DCP set Transfer button/hangup or switch hook flash transfer by hangup
- station transfer by DCP set Conference button, in which the conferencing (middle) party connects the two calls and then hangs up
- ASA1 third-party call transfer
- ISDN trunk administration
- Attendant Vectoring
- Call Vectoring and Best Service Routing (BSR)

CMS, Visual Vectors, and CentreVu Supervisor

Currently, the ~r vector step cannot be administered with CMS. Beginning with R3V9 CMS and Release 9 Visual Vectors, the ~r vector step can be administered using those products.

CMS Reporting and/or administration on public network calls that have been rerouted to another public network endpoint using NCR will be provided by the following Lucent products:

- Release 3 Version 6 (R3V6) *CentreVu* CMS or later (reporting), administration of ~r with R3V9
- Release 6 *CentreVu* Supervisor or later (reporting)
- *CentreVu* Visual Vectors Version 1.0 or later (administration, BSR vector support)
- *CentreVu* Network Reporting Version 8 or later (reporting)

Reporting of calls that have been rerouted to another public switched telephone network (PSTN) endpoint by NCR will be available on the following products when used with a *DEFINITY* ECS R8.3 or later:

- Release 3 Version 6 (R3V6) *CentreVu* CMS
- Release 9 *CentreVu* Supervisor

ISDN calls that are rerouted by NCR to multiple *DEFINITY* ECS sites will be tracked by *CentreVu* Explorer Version 1.0 or later when used with R3V6 or later CMS by using the Universal Call ID (UCID) information that is part of the User-to-User Information for ISDN calls rerouted by NCR.

CMS database changes

CMS database items are affected by NCR, as follows:

- **DEFLECTCALLS:** In the vector and VDN tables, the DEFLECTCALLS item includes the number of calls redirected using NCR through the BSR feature by using the route-to-number ~r or queue-to-best commands. Successful NCR attempts are pegged as DEFLECTCALLS.
- **INTERFLOWCALLS:** In the vector and VDN tables, the INTERFLOWCALLS item includes successful BSR interflows using NCR redirections
- **LOOKATTEMPTS:** In the vector and VDN tables, the LOOKATTEMPTS item includes the number of times the Lookahead Interflow or BSR Interflow was attempted for calls in the vector. Successful Lookahead Interflow or BSR attempts are also counted. NCR invoke attempts (Network Call Deflection or Network Call Transfer) are also reflected in LOOKFLOWCALLS.
- **LOOKFLOWCALLS:** In the vector and VDN tables, the LOOKFLOWCALLS item includes the number of INTERFLOWCALLS that were redirected by the Lookahead Interflow or BSR features. LOOKFLOWCALLS is a subset of INTERFLOWCALLS and includes LOOKATTEMPTS for the Lookahead Interflow or BSR interflows. With BSR interflow via trunk-to-trunk transfer or NCR, every LOOKATTEMPT will also be counted as a LOOKFLOWCALLS unless a failure occurs.

Station Call Transfer/Conference

An incoming ISDN call (over a trunk with NCT PSTN service) is answered at the station or voice response unit (VRU or IVR). The station user/VRU answers the call and initiates a “station call transfer” using the transfer feature button or a switch hook flash. The *DEFINITY* automatically sends the `invoke NCT ISDN FACility` message when the transfer is complete, only if NCT is assigned to the incoming trunk group and the call is eligible for NCT — that is, if the second leg of the call has been set up over a trunk with the same signaling group as the incoming call. If the station user initiates and completes a three-way conference instead, the *DEFINITY* automatically sends an `invoke NCT ISDN` message when the initiating station user drops from the three-way conference.

What is Network Call Redirection?

Overview

Call redirection using NCR is accomplished by using either the public network's NCT or NCD options. For NCD, there are two operations that can be used for call redirection: "retain call until alerting/connect" or "clear call upon invocation." NCD is only offered outside of the United States. At this time, it is offered in Britain, Germany, Belgium, and France. In the United States, only NCT is allowed, whereas in Western Europe, only the NCD "clear call upon invocation" option is available. Currently, the NCD "retain call until alerting/connect" option is not available.

Network Call Transfer

NCT occurs after the call is initially answered. With NCT, the *DEFINITY* is required to set up the second leg of the call and then wait for the second site to acknowledge before requesting the PSTN to transfer the first leg of the call to the second leg, and before the PSTN drops the trunks to the *DEFINITY*. The benefit is that the *DEFINITY* retains control over the call and can redirect the call using the trunk-to-trunk method should the NCT invocation fail. Therefore, the NCT option is the most reliable.

After the second leg of the call is initiated and acknowledged by the public switch, the public network joins the original ISDN caller to the redirected-to endpoint and then drops both the original ISDN call and the second leg of the call at the redirecting *DEFINITY* ECS.

Network Call Deflection

NCD occurs before the call is initially answered. With NCD, the public network sets up the second leg of the call to the redirected-to location when the *DEFINITY* deflects the call. There are two PSTN options for NCD, per the ETSI standards: "retain call until alerting/connect" and "clear call upon invocation." This is commonly referred to as a partial call reroute. The "retain call until alerting/connect" option is not widely available (no known PSTN offers it at this time). With this option, the PSTN sets up the second leg of the call and waits until an alerting message is received before the first leg of the call is dropped. In this case, if the second leg of the call fails, then the *DEFINITY* can redirect the call through another method (such as trunk-to-trunk connection) and not lose the call.

With the “clear call on invocation,” which is the only NCD operation currently available, the *DEFINITY* loses control of the call once the call has been transferred to the public network for redirection. The *DEFINITY* does not retain control of the call until it has been acknowledged by the network, so there is no alternative transfer possible if the public switch cannot acknowledge and transfer the call to the second location.

Important

There may be limits placed on the number of times a call may be redirected over the public network. These limits are imposed by the public network service provider. For example, in the United States, MCI currently allows only one redirection per call. In Britain and France, there are no limits. In addition, there may be additional charges associated with redirected calls.

Additionally, some public network service providers do not support forwarding of User-to-User Information (UUI), including ASAI User data, collected digits, VDN name, the VDN in-time (as reflected by the NETINTIME database items), and the UCID. This means that Information Forwarding will be lost and the second leg of the redirected call will look like an entirely new call to the redirected-to *DEFINITY* at the second location. What is lost is the VDN name, which is originally called service (DNIS) information. The indication that the call has been forwarded can be achieved by using dedicated VDNs for call forwarding, but it does reduce the benefits of information forwarding inherent in NCR. Also, this option limits CTI applications as there is no ASAI information or UCID forwarded.

Important

At this time, no PSTNs are offering the Network Call Deflection “retain call until alerting/connect” operation. Therefore, only the Network Call Deflection “clear call upon invocation” offer is available from PSTNs. Both methods are described in this document. It is advised that you negotiate with your PSTN as the NCR feature will work on either platform. NCR is limited by which PSTN platform is available to you.

Implementation

Overview

The NCR feature uses either the Network Call Transfer (NCT) or Network Call Deflection (NCD) operations provided by the PSTN to redirect an incoming ISDN call from a *DEFINITY* Enterprise Communications System (ECS) to another PSTN endpoint. In the call center environment, NCR is intended for multi-site configurations where ISDN calls are interflowed between *DEFINITY* Enterprise Communications Systems (ECSs) over the PSTN by Best Service Routing feature's `queue-to-best` vector step, which is the best approach for administration.

The NCR feature can also be used to redirect an incoming ISDN call by either of the following methods:

- as a substitute for the Lookahead Interflow or non-attendant call vectoring
- attendant call vectoring, by using the `route-to-number` vector step to have the network redirect the call
- ASAI Third-Party Merge/Call Transfer Operation (Network Call Transfer only)
- station transfer by DCP set Transfer button/hangup or switch hook flash transfer by hangup
- station transfer by DCP set Conference button, in which the conferencing (middle) party connects the two calls and then hangs up

The NCR feature is designed to optimize the rerouting of ISDN calls over the public network since no *DEFINITY* ECS trunks are retained at the redirecting *DEFINITY* after the call is rerouted.

Additionally, NCR may be activated and tracked with ASAI/CTI. The ASAI event reporting capabilities allow tracking of the NCR-redirected calls by their Universal Call ID or ASAI User-to-User Information.

Before you start: Platform

Network Call Redirection is a new *DEFINITY* ECS feature available starting with the Release 8.3 ECS. Full administration support of the feature is provided with the *DEFINITY* ECS R8.3 SAT. For detailed information, see “Before you start: Platform” on page 2 of this document.

NCR activation using *DEFINITY* ECS Call Vectoring

If NCR is activated using either the `route-to-number` or `queue-to-best` vector steps, either the NCT or the NCD options may be used to redirect an incoming call while the call is still being processed by the *DEFINITY* ECS vector.

The NCR feature is activated by *DEFINITY* call vectoring if:

- The Best Service Routing feature selection of a “best location” has been administered with the `Net Redir?` option set to `Y` on the BSR Application Table form (with both BSR and LAI active), followed by the execution of the `queue-to-best` vector step (see “Administration” in this document).
- The `route-to-number` vector step is administered with a `~r` as the first item in the `number` field (with or without the LAI option set to “Y” or with Attendant Call Vectoring active — the administration for `~r` in `route-to-number` vector steps will be supported by R3V9 CMS and Version 9 Visual Vectors).

⇒ NOTE:

Until R3V9 CMS is available, the `~r` in the `route-to-number` vector steps must be administered directly on *DEFINITY*, and these vectors cannot be accessed by CMS or Visual Vectors. BSR vectors can be administered on R3V6 or later CMS.

NCT

If the NCT feature is enabled for the trunk over which an incoming call is routed to the *DEFINITY*, then NCR redirection will be attempted only if a CONNect ISDN message (answer supervision) has been sent to the public network for the original call. Any vector step of this type, such as wait hearing music or collect x digits (refer to the list below) will send the CONNect ISDN message to the public network and NCR will be attempted with either the `route-to-number` or `queue-to-best` vector steps. If none of the vector steps listed below have been executed, then the *DEFINITY* will automatically send a CONNect ISDN message to the public network *before* call transfer is requested from the PSTN. This will start PSTN charging for the call, which is done after the second leg call is established.

If NCT is used, a second call is set up by the redirecting *DEFINITY* to redirect the call using the public network.

NCT call success

With NCT, a call transfer is considered to be successful if:

- The public network responds to the FACility message that requested the NCT operation with a FACility message to the requesting *DEFINITY* indicating “PSTN success.” The requesting *DEFINITY* should then receive a DISConnect message for both the first and second leg of the call after the original call and the second leg are joined by the PSTN.
- If the public network responds with a “PSTN failure” FACility message to the requesting *DEFINITY*, which will result in a trunk-to-trunk connection between the first leg of the call and the second leg of the call. *DEFINITY* vector call processing considers this to be successful for the NCR attempt because the original call was not lost; however, a vector event will be generated indicating that the NCT public network operation failed, and this call will not be indicated as “deflected” in CMS.

NCD

NCD may only be activated if a CONNect ISDN message has not been sent to the public network for the call; this is call answer supervision. In that case, the following vector steps should *not* be used by a vector in prior steps if the NCD feature is going to be used for NCR:

- wait hearing music
- collect *x* digits
- announcement
- converse-on split

If NCD is used, the *DEFINITY* does not set up a second call to redirect the call on the public network, and only the incoming ISDN D-channel is used by the public network to redirect the call. The second call is actually set up by the public network.

NCD call success

With NCD, an NCR attempt is considered successful if:

- The public network has validated the NCR request and returned a `call reroute return result` in a DISConnect message to the requesting *DEFINITY* for the first leg of the call when the NCD “clear call on invocation” public network service has been subscribed to for the incoming ISDN call’s trunk group. This indicates invoke success.
- The public network has sent a `call reroute return result` indication in a FACility message, followed some time later by a DISConnect message (for the first leg of the call) to the requesting *DEFINITY* when the NCD “retain call until alerting/connect” operation has been subscribed to for the incoming ISDN call’s trunk group. The DISConnect is sent after the PSTN has successfully set up the second leg of the call; that is, the public network has received an ALERting or CONNect ISDN message from the redirected-to public network endpoint. This indicates successful call deflection.

NCR and ASAI

NCR is activated by ASAI call processing when the Third-Party Merge/Call Transfer operation is requested by a CTI operation. This occurs in the following manner:

1. This is typically initiated by the CTI user selecting an icon, menu item, or button to transfer an incoming ISDN call to another user on the public network.

Since the incoming ISDN call must be connected to a station user before the Third-Party Merge/Call Transfer operation was requested, NCR can only initiate the call redirection if NCT is optioned on the trunk.

2. If a call arrives at an ASAI monitored VDN and either the NCT or NCD feature is used, then ASAI will send appropriate information in the disconnect event to tell the application that the call has been redirected by NCR.

ASAI event reporting allows tracking of ISDN ACD calls that were redirected by NCR in a multi-*DEFINITY* ECS call center environment. These calls can be tracked by the UCID assigned to each call, or by the UUI information inserted by the application through either the Third Party Make Call or Adjunct Routing features.

Station Call Transfer/Conference

The following steps provide additional information about NCR activation using station call transfer or conference:

1. An incoming ISDN call (over trunk with NCT PSTN service) is answered at the *DEFINITY* station/VRU line port.
2. A station or ACD agent user initiates “station call transfer” using feature button or switch-hook flash
3. VRU (out of vector processing) initiates “station call transfer” using a switch-hook flash.
4. The *DEFINITY* automatically sends an “invoke NCT” ISDN FACility message when the transfer is completed after the second leg is set up.
5. If the station user initiates and completes a three-way conference instead, the *DEFINITY* automatically sends an “invoke NCT” ISDN message when the initiating station/VRU user drops from the three-way conference.

The initiator (station/agent user or VRU) dials the second leg connection by using an access code plus the PSTN number after initiating the transfer. The access code must select an idle outgoing trunk in a trunk group with the same signaling group as the incoming call with NCT active. The transfer is completed when the Transfer button is pressed or the initiator hangs up.

Administration

Overview

This section describes how NCR is administered on the *DEFINITY* ECS.

NCR activation by BSR vector call processing

Network Call Redirection of ISDN calls will be attempted if the following vector administration has occurred within Best Service Routing. Network Call Redirection on the *DEFINITY* Customer Options form must have been set to Y for this installation to be able to administer NCR:

1. An incoming ISDN call has entered *DEFINITY* vector processing.
2. The call may or may not encounter a vector step, such as an announcement, that causes an “answer” ISDN message (the ISDN CONNect message) to be returned to the trunk associated with the call.
3. The call has encountered one or more `consider location` BSR vector steps that returned valid data (such as Expected Wait Time) and then executed a `queue-to-best` BSR vector step.
4. *DEFINITY* BSR call processing has determined that the call should be interflowed to one of the remote BSR locations previously considered as the best location.
5. The interflow VDN number in the BSR Application Table associated with the best location has been administered with the `Net Redir?` field set to Y.
6. The administered interflow number is the public network phone number (without trunk/ARS/AAR access codes) that reaches the remote call center site. The long-distance access (dial “1” in the United States) may also be required depending on the PSTN requirements for the trunk group. This number is used during the invoke process differently depending on which redirection service is available from the public network service provider.
7. With call vectoring activation of NCR, either NCT or NCD will be initiated based on which type of redirection is administered to the trunk group for the incoming call. In either case, a FACility message is sent to the public network over the D-channel associated with the incoming trunk to invoke redirection of the call.

A *successful* NCR completion (when the PSTN indicates a successful NCT invoke) will terminate vector call processing while the original call is connected through the interflowed to call center site by the public network. CMS will track this as a successful network call redirection for the call.

An *unsuccessful* NCR attempt (NCD invoke failure or NCT secondary call failure) results in vector processing going to the next step in the vector following the `queue-to-best` vector step. NCT invocation failure after the second call is established results in the *DEFINITY* reverting to the trunk-to-trunk call connection.

Network Call Transfer

The following steps are used when NCT is used for network call redirection:

1. The call arrives at the first location.
2. The call is processed by a vector that has a `~r` in the leftmost two character positions in the number field or the `Network Redir?` field on **BSR Application Table** form is set to `Y` for the location specified in the `consider` step for the active VDN application.
3. The *DEFINITY* sends the call to the public network.
4. The public network switch sets up the second leg of the call and passes the codeset 0 UUI information in the SETUP message if this is supported.
5. The *DEFINITY* “tells” the public switch to transfer the call over the public network.
6. The public network merges the second leg of the call to the second site and drops the *DEFINITY*. With NCT, at this point, if the second call fails, the *DEFINITY* can pick up the call again and attempt trunk-to-trunk transfer.

Sample Vectors

The following vectors are examples of vectors administered using the `route-to-number` command to use NCR:

Sample BSR Vector:

1. wait 2 seconds hearing ringback
2. consider skill 1 pri b adjust-by 0
3. consider location 1 adjust-by 0
4. consider location 2 adjust-by 0
5. queue-to-best

Sample ACD Vector:

1. wait 0 seconds hearing ringback
2. goto step 4 if skill oldest-call < 30 secs
3. route-to number ~r13035403001
4. queue-to skill 35 priority m
5. ...

Sample Attendant Vector:

1. goto step 6 if time-of-day is all 17:00 to 09:00
2. wait 0 seconds hearing ringback
3. queue-to attd-group
4. wait 999 secs hearing music
5. stop
6. route-to number ~r13035551002

DEFINITY administration overview

The following fields must be set on the *DEFINITY* administration forms for NCR to work:

Form	Field	Value
For both NCT and NCD		
System Parameters Customer Options	Call Center Release	8.3 or later
System Parameters Customer Options	ISDN Network Call Redirection	Y
Best Service Routing Application form (for the location to receive the call)	Net Redir?	Y
For NCT		
Trunk Group form	Group Type	isdn
	Supplementary Services Protocol	g
	Network Call Redirection	Nortel-transfer (for MCI DMS250 switches)
Signaling Group form	Network Call Transfer	Y

Form	Field	Value
For NCD		
Trunk Group Form	Group Type	isdn
	Supplementary Service Protocol	c
	Network Call Redirection	deflect
Signaling Group Form	Network Call Transfer	N
For non-BSR applications or for standard or enhanced Lookahead Interflow applications replaced by NCR supplementing BSR applications		
Call Vector form	leftmost position in the route-to number vector step	~r for each vector that will invoke NCR.

The ~r command takes up two digit positions in the vector step. This works with `queue-to-best` or `check-best` vector steps. No change to the vector steps is required for NCR with BSR.

Trunk Group form

For Network Call Transfer, the `Group Type` field on the **Trunk Group** form must be set to `isdn` and the `Network Call Redirection` field must be set to `transfer`. The `Supplementary Service Protocol` field must be set to `g` and the `Network Call Redirection` field must be set to `Nortel-transfer` for MCI DMS250 switches. If the NCT feature is subscribed to for the DEFINITY NCR feature, only PRI ISDN 2-way trunks may be used for the incoming-call trunk groups to be administered for vectoring activation of NCT, since the software selects a trunk from the same trunk group to set up the second leg call. Refer to the following figures:

Supplementary Service Protocol: NCT:

```

change trunk-group 29                                     Page 1 of 23
                                                         TRUNK GROUP
Group Number: 29                                         Group Type: isdn           CDR Reports: y
  Group Name: MCI-1                                     COR: 1                    TN: 1          TAC: 729
  Direction: two-way                                   Outgoing Display? y
  Dial Access? n                                       Busy Threshold: 255       Night Service:
Queue Length: 0
Service Type: sdn                                       Auth Code? n             TestCall ITC: rest
                                                         Far End Test Line No:
TestCall BCC: 4
TRUNK PARAMETERS
  Codeset to Send Display: 7                           Codeset to Send National IEs: 7
  Max Message Size to Send: 260                       Charge Advice: none
  Supplementary Service Protocol: g                    Digit Handling (in/out): enbloc/enbloc
Trunk Hunt: descend
                                                         Digital Loss Group: 13
Calling Number - Delete:                               Insert:                    Numbering Format:
  Bit Rate: 1200                                       Synchronization: async   Duplex: full
Disconnect Supervision - In? y Out? y
Answer Supervision Timeout: 0

```

Network Call Redirection: for NCT:

For NCD, the Supplementary Service Protocol field must be set to `c` and the Network Call Redirection field must be set to `deflect`. Refer to the following figures:

Supplementary Services field: for NCD:

```

change trunk-group 30                                     Page 1 of 23
                                     TRUNK GROUP

Group Number: 30                Group Type: isdn                CDR Reports: y
  Group Name: BT-1                COR: 1                TN: 1                TAC: 729
  Direction: two-way            Outgoing Display? y
  Dial Access? n                Busy Threshold: 255            Night Service:
Queue Length: 0
Service Type: sdn                Auth Code? n                TestCall ITC: rest
                                     Far End Test Line No:

TestCall BCC: 4
TRUNK PARAMETERS
  Codeset to Send Display: 7    Codeset to Send National IEs: 7
  Max Message Size to Send: 260 Charge Advice: none
  Supplementary Service Protocol: c Digit Handling (in/out): enbloc/enbloc

  Trunk Hunt: descend

                                     Digital Loss Group: 13
Calling Number - Delete:      Insert:                Numbering Format:
  Bit Rate: 1200                Synchronization: async    Duplex: full
Disconnect Supervision - In? y Out? y
Answer Supervision Timeout: 0

```

Network Call Transfer field: for NCD:

```

change trunk-group 30                                     Page 2 of 23
TRUNK FEATURES
  ACA Assignment? n                Measured: both                Wideband Support? n
                                     Maintenance Tests? y
                                     Data Restriction? n            NCA-TSC Trunk Member:
  Send Name: n                Send Calling Number: n

  Used for DCS? n
  Suppress # Outpulsing? n
Outgoing Channel ID Encoding: preferred    UUI IE Treatment: shared
                                     Maximum Size of UUI IE Contents: 128
                                     Replace Restricted Numbers? n
                                     Replace Unavailable Numbers? n
                                     Send Connected Number: n

Network Call Redirection: deflect
  Send UCID? y                BSR Reply-best DISC Cause Value: 31
Send Codeset 6/7 LAI IE? n

                                     Network (Japan) Needs Connect Before Disconnect? N

```

Signaling Group form

For NCT, the Network Call Transfer field on the **Signaling Group** form must be set to Y. Refer to the following figure:

```

change signaling-group 4                                     Page 1 of 5
                                     SIGNALING GROUP

Group Number: 4
Associated Signaling? y                                     Max number of NCA TSC: 0
Primary D-Channel: 01B1024                               Max number of CA TSC: 0
Trunk Group for NCA TSC:
Trunk Group for Channel Selection:
Supplementary Service Protocol: a                         Network Call Transfer? y
  
```

For NCD, the Network Call Transfer field on the **Signaling Group** form must be set to N. Refer to the following figure:

```

change signaling-group 4                                     Page 1 of 5
                                     SIGNALING GROUP

Group Number: 4
Associated Signaling? y                                     Max number of NCA TSC: 0
Primary D-Channel: 01B1024                               Max number of CA TSC: 0
Trunk Group for NCA TSC:
Trunk Group for Channel Selection:
Supplementary Service Protocol: a                         Network Call Transfer? n
  
```

Best Service Routing Application form

On the *DEFINITY* **Best Service Routing Application** form, the **Net Redir?** field must be set to **Y** for each location to which calls are to be directed using NCR. Refer to the following figure.

⚠ CAUTION:

The number administered in the interflow VDN field on the Best Service Routing form (or in the ~r vector step on the Call Vector form) should *not* have any ARS prefix or trunk access code. Some PSTN numbers will need to include the long-distance access code. Contact your PSTN for specific information.

BEST SERVICE ROUTING APPLICATION

Number: 1 Name: ARS Maximum Suppression Time: 30 Lock? n

Num	Location Name	Switch Node	Status Poll	VDN	Interflow VDN	Net Redir?
1			95022011		3035551222	y
2			95022111		3035551111	y
3			95032211		95032221	n

Call Vector form

For non-BSR applications or for standard or enhanced Lookahead Interflow applications replaced by NCR, supplementing BSR applications, on the *DEFINITY Call Vector* form, the leftmost position in the `route-to` vector step (vector step 2 in the example on the next page) must be set to `~r` for each vector that will invoke NCR.

⚠ CAUTION:

The number administered in the `~r` vector step on the Call Vector form should *not* have any ARS prefix or trunk access code. Refer to the following figure.

```

                                CALL VECTOR                                \
Number: 37                        Name _Reroute using NCR_Feature_      Lock? n
Basic? y   EAS? y   G3V4 Enhanced? y   ANI/II-Digits? y   ASAI Routing? y
Prompting? y   LAI? y   G3V4 Adv Route? y           CINFO? n           BSR? y

01 wait _____ 0 _____ secs hearing ringback
02 route-to _____ number ~r3035551222
03
04
05
06
07
08
09
10
11
12
13
14
15

```

Troubleshooting and Things to Know

Overview

This section contains basic information on troubleshooting, as well as important information about administering NCR.

Troubleshooting

General troubleshooting of NCR can be accomplished by using:

- the ISDN message trace information provided by the Message Sequence Tool (MST)
- Vector events displayed by the `display events` *DEFINITY* system administration command.
- To see the behavior of a particular VDN or vector, use the `list trace vdn` and/or `list trace vector` commands to check for NCR errors.
- To check for NCR errors using BSR processing, enter the `ch MST` switch administration terminal command to set the `BSR` and `vector` fields to `Y`, and use the `enable mst` and the `list mist cont` switch administration terminal commands to see NCR-related MST trace data.
- To see NCR-related BSR `peg counts`, enter the `go tcm switch` administration terminal command or enter the `rdd :dpm_mgr Bsr_appl_loc` command to see NCR-related BSR attempts, `int errors`, `net errors`, `redirs`, and `discs peg counts`.

NCR troubleshooting

If NCR vector activation fails, use the `display events` switch administration terminal command to check for the following NCR vector events:

- NCR: Invoke trunk not ISDN
- NCR: Bad NCR trunk admin
- NCR: No NCT PSTN service
- NCR: No NCT outgoing trk
- NCR: NCT outgo trk drop
- NCR: PSTN NCT invoke err
- NCR: PSTN NCT netwrk err
- NCR: Used NCT trk-to-trk
- NCR: No NCD PSTN service
- NCR: NCD invalid PSTN nmb
- NCR: NCD call connect err
- NCR: PSTN NCD invoke err
- NCR: PSTN NCD netwrk err
- NCR: PSTN NCD max redirs
- NCR: PSTN NCD no disc
- NCR: Internal system err

Things to know

The following important items should be known.

Failures

Failures can occur in NCR after the `queue-to-best` vector command is executed. Vector steps are not used to log vector events (this happens automatically), so vector steps following the `queue-to-best` command are needed to provide alternate call treatments. To prepare for this, use one of the following:

- **If the second leg of the call cannot be set up, use the second vector step to log the event that caused this.** Administer the second vector step to anticipate this problem by administering it to record call failure events.
- **Try to invoke Network Call Transfer.** If Network Call Transfer is invoked and the public network rejects the call, the call should revert to a trunk-to-trunk transfer. In this case, the call is not lost.

NCT

With NCT, the transferring vector may or may not answer the first leg of the call before redirecting the call over the public network. The vector can set up the second leg of the call before answering the first leg, but the public network cannot redirect the call until the first leg is answered. If the call has not been answered, DEFINITY will answer the call before requesting NCT.

NCD

With NCD, no steps in the vector can answer the call when it is being redirected, or the redirection will not occur. In other words, vector steps *must not* answer the call before requesting NCR.

Current offerings for NCD will not “clear the call on alerting.”

Announcement Vector Steps

At this time, announcement vector steps cannot be used with NCD before NCD is to be invoked. Announcement vector steps can be used in following vector steps if NCD fails. Announcement vector steps can be used with NCT.

Feature Interactions

Network Call Redirection interacts with several existing call center features. The features, and the effect NCR has on them, are described in this section.

Best Service Routing

The BSR `queue-to-best` vector step is used to transfer a call using NCR if the `Net Redir?` field on the BSR Application Table for the location has been set to `Y`.

Attendant Vectoring

The `route-to-number` vector step uses `~r` before the number to transfer a call using NCR, where the `~r` activates NCR. For example, `~r112920414`. The `route-to-number` vector step replaces Lookahead Interflow. An incoming ISDN call is then redirected. Similarly, the call will be routed using NCD or NCT. The PSTN feature will connect the original call to the diverted-to user. The original connection will be disconnected to free up *DEFINITY* resources.

The `~r` vector step cannot be administered with CMS or Visual Vectors until R3V9 is available. Until that time, the `~r` vector step must be administered using *DEFINITY* system administration.

ASAI Drop Event

Successful NCR call redirection causes an ASAI “drop” event to be sent to the CTI application with a `CV_REDIR` cause value of `decimal(30)` after the redirection is completed. Only one NCR “drop” event is received for a successful NCR operation when the NCT PSTN feature is used, even though two trunks are dropped by the PSTN.

ASAI Third-Party Merge/Call Transfer

The CTI application requests a third-party merge/call transfer ASAI operation to transfer the call to the second switch. This is only used if Network Call Transfer is not available. Once the two calls merge, then ASAI sends a third-party acknowledgement, and when the call is completed, ASAI sends a drop event report, and the third-party call ends.