



555-4001-317

Nortel Networks Meridian SL-100/Communication Server 2100

# **M3900/EXPEC Firmware Manager (MEFM)**

## User Guide

SE07 Standard 01.04 January 2005

---

---



**NORTEL**



---

Nortel Networks Communication Server 2100

# M3900/EXPEC Firmware Manager

## User Guide

---

Publication number: 555-4001-317

Product release: SE07

Document release: Standard 01.04

Date: January 2005

---

Copyright © 2005 Nortel Networks,  
All Rights Reserved

Printed in the United States of America.

**NORTEL NETWORKS CONFIDENTIAL:** The information contained in this document is the property of Nortel Networks. Except as specifically authorized in writing by Nortel Networks, the holder of this document shall keep the information contained herein confidential and shall protect same in whole or in part from disclosure and dissemination to third parties and use same for evaluation, operation, and maintenance purposes only. Changes or modifications to the Meridian SL-100 without the express consent of Nortel Networks may void its warranty and void the user's authority to operate the equipment.

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

\*Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, DMS, MAP, Meridian, MSL, Nortel, Northern Telecom, NT, OPTera, SL-100, and SuperNode are trademarks of Nortel Networks.

---





v

---

## Publication history

---

### January 2005

Version 01.04 SE07, Standard. Added peer edits and test case changes.

### November 2004

Version 01.03 SE07, Draft. Added “Navigating the MEFM” chapter, which duplicates the Help Files found on the server.

### October 2004

Version 01.02, SE07, Draft. Initial changes and edits are included in this version.

### August 2004

Version 01.01, SE07, Draft. This is the first draft issue of the document for SE07.



---

# Contents

---

<b>About this document</b>	<b>13</b>
<hr/>	
<b>Introduction</b>	<b>15</b>
Background	15
Functional Description	15
Security	16
Scheduler	16
Web interface	16
EXPEC load management	17
Integrated Element Management Systems (IEMS)	17
M3900 firmware maintenance	17
Logging	18
Database	18
Web server	18
Integration with the CS2100 NMS	18
System architecture	18
System requirements	19
MEFM application system requirements	19
MEFM Web Client requirements	20
<hr/>	
<b>Installation and setup</b>	<b>21</b>
Installation and setup	21
Installing the MEFM, Sun Java JDK, and Tomcat web server	21
Uninstalling the MEFM, JDK, and Tomcat	22
<hr/>	
<b>Navigating the MEFM</b>	<b>23</b>
Administration (Admin)	24
Initial Login (Admin)	24
Admin Login	25
Adding a User	26
Admin update of user information	28
Admin delete of User	28
Change password for Admin type	29
Login and User Administration	31
Initial Login for General and Guest type users	31
Login for General and Guest type users	32
User Logout	32
Changing passwords for General or Guest type user	33

- EXPEC 33
  - Adding an EXPEC 33
  - Deleting an EXPEC 35
  - Editing an EXPEC 35
  - Verifying changes in EXPEC list 36
  - Get EXPEC file directory information on selected EXPECs 36
  - Determine available memory on the EXPEC 37
  - Release EXPECs that have been selected 37
  - Add a load to a selected EXPEC 37
  - Delete a non-bootable EXPEC load from EXPEC list 38
  - Set a boot load on an EXPEC from the EXPEC list 38
- M3900 39
  - Get EXPEC file directory information on selected EXPECs (M3900) 39
  - Check available memory in EXPEC (M3900) 41
  - Release EXPECs that have been selected (M3900) 41
  - Add firmware load to selected EXPEC (M3900) 41
  - Download firmware to an M3900 41
  - Download firmware to multiple M3900s on multiple EXPECs 42
  - Delete a non-bootable EXPEC load from EXPEC list (M3900) 43
  - Schedule a firmware download (M3900) 43
- File servers 44
  - Add a file server 44
  - Modify a file server 44
  - Delete a file server 45
  - Cancel a file server deletion 46
  - Modify new file server before submitting to database 46
- Viewing Log files 48
  - View log files 48

---

**Security** **51**

- Security benefits of the M3900/EXPEC Firmware Manager 51
- MEFM Password rules 52

---

**List of terms** **53**



---

## About this document

---

### This document

This document describes the Meridian SL-100/Communication Server M3900/EXPEC Firmware Manager (MEFM).

### Purpose and audience

This document describes the functionality and requirements of the M3900/EXPEC Firmware Manager and is a companion to the MEFM Help files and MEFM Quick Start Guide that are supplied with the product.

This document's audience is service provisioning, administrative and network management and planning personnel.

### How to check the version and issue of this document

The version and issue of the document are indicated by numbers (for example, 01.01). For example, the first release of a document is 01.01. In the next software release cycle, the first release of the same document is 02.01.

The first two digits indicate the version. The version number increases each time the document is updated to support a new software release. The second two digits indicate the issue. The issue number increases each time the document is revised, but re-released in the same software release cycle. For example, the second release of a document in the same software release cycle is 01.02.



#### FOR MORE INFORMATION

To determine whether you have the latest version of this document, check the release information in the *Meridian SL-100 Master Index of Publications*.

---

## Related documents

Table 1 lists related documents for the Meridian SL-100/Communication Server 2100 M3900/EXPEC Firmware Manager.

**Table 1**  
**Related documents**

Description	Document number
Meridian SL-100 M3900 Digital Telephones Reference Guide	NTP 555-4001-136
MEFM Help Files	None
Meridian SL-100/Communication Server 2100 MEFM Quick Start Guide	None



---

# Introduction

---

## Background

The M3900/EXPEC Firmware Manager (MEFM) provides a web-based interface through which the firmware on the M3900 telephone sets and EIPE controller, that is, the EXPEC (Enhanced Extended Peripheral Equipment Controller) can be downloaded.

The M3900/EXPEC Firmware Manager tool includes the following functions:

- Telnet and FTP
- Scheduling
- EXPEC controller card load management
- M3900 firmware maintenance
- Secure web-based user interface

The M3900/EXPEC Firmware Manager will support SL-100 customers and SL-100 customers who transition to CS2100.

## Functional description

The MEFM application has the following responsibilities:

- authenticate client's login and provide Client Sessions
- maintain client profile information in the database
- manage connections to the EXPECs
- manage the connections to the file servers for firmware downloads
- manage secure connections to the web clients
- schedule downloads
- maintain a log of activity and errors

The following sections describe the features provided by the MEFM.

## 16 Introduction

---

### Security

The MEFM provides the following security features

- Limited user access – only users who have logged in with a correct password may use the MEFM system. An administrator has full access to all the features of the system.
- Secure web access – Secure Socket Layer (SSL) will be used between the web clients and the web server.
- Encryption – encryption will be used for passwords and other confidential information stored on the server.

### Scheduler

The scheduler feature is used to schedule downloads of software either to the M3900 sets or the EXPEC. Current status of all scheduled jobs is available from the web client. Scheduled jobs is kept in a “database” until they are executed.

### Web interface

The web client has the following functions:

- user login
- ability to add:
  - file server
  - user
  - EXPEC
- ability to view:
  - EXPEC load details
  - activities
  - active jobs
- list EXPECs
- ability to edit/delete:
  - EXPECs
  - file servers
  - users
  - jobs
- get firmware load
- schedule status
- list M3900 sets

- view M3900 load details
- set bootable load
- remove load
- view log report
- view scheduled job list
- view active job list/status
- display error

### **EXPEC load management**

MEFM provides load management for the EIPE controller card (EXPEC). Load management of the EXPEC loads includes the ability to

- view loads on the EXPEC
- initiate the transfer of loads to the EXPEC
- delete loads from the EXPEC
- set the “bootable” load for the EXPEC
- see the space remaining on the EXPEC
- initiate the transfer of a load file to multiple EXPECs
- provide a record of the completion of each load transfer

The loads are transferred through the Ethernet portion of the EXPEC card. The advantage of transferring the load files through Ethernet is that the transfer time is greatly reduced and that the Intelligent Peripheral Equipment (IPE) remains in service while the load file is being transferred. Once a load is transferred to the IPE and set as the “bootable” load, the IPE must be BSY'd (busied) and RTS'd (returned to service) from a MAPCI, before the new load takes effect on that IPE.

### **Integrated Element Management Systems (IEMS)**

For information about configuration management in Nortel Networks Integrated EMS, please refer to the *Meridian SL-100/Communication Server 2100 Product Guide*, 555-4001-806 and the *Integrated EMS Configuration Management*, NN10330-511.

### **M3900 firmware maintenance**

MEFM provides load management and load maintenance for the M3900 sets. The load management functions include the following:

- view loads on the EXPEC and M3900 sets
- initiate the transfer of loads to the EXPEC
- delete loads from the EXPEC

## 18 Introduction

---

- set a “bootable” load for each version of the M3900 on the EIPE
- see the space remaining on the EXPEC
- initiate the transfer of a load file to multiple EXPECs
- provide a record of the completion of each firmware load operation

The maintenance of the loads includes the ability to schedule sending the loads to one M3900, or sequentially to all M3900s, on an IPE or multiple IPEs.

### Logging

A flat file is used to store information about items including

- errors
- critical events such as startup of the application
- firmware load operation

### Database

An XML database is kept for persistent information including

- user information
- scheduled jobs
- EXPECs
- M3900s
- other application configuration information

### Web server

The Apache Tomcat web server handles transaction handling, client sessions, and serving up web pages.

### Integration with the CS 2100 Network Management System (NMS)


The cross-platform of Java and the web interface makes the integration with the CS 2100 NMS possible since the CS 2100 NMS strategy is to be on the Solaris platform with web interfaces.

## System architecture

The M3900/EXPEC Firmware Manager architecture allows the load transfer function of the M3900 and EXPEC to be integrated into the CS 2100 management system. The web application is written in Java and runs on the Apache Tomcat web, server providing cross-platform support. The Model/View/Controller 2 (MVC2) pattern provides ease of maintenance and robustness. The architecture consists of the EXPEC controller card which communicates with the M3900 sets. The MEFM application communicates with the EXPEC through Telnet. The web

clients communicate with the MEFM application through secure HTTP using a browser. FTP can be used, if necessary, to retrieve the firmware load from a file server.

**Figure 1**  
**M3900/EXPEC Firmware Manager Web Application/Tomcat Web Server**



## System requirements

### MEFM application system requirements

The MEFM application has the following system requirements

#### Hardware

- 500 MHZ Pentium II, or equivalent processor
- minimum of 128 MB of RAM
- minimum of 300 MB hard drive space available
- a network connection to EXPEC/M3900 Firmware Manager client

#### Software

- Sun Java JDK
- Tomcat Web server
- Windows 2000 Operating Systems with latest service pack installed

### **MEFM Web Client requirements**

The web client application has the following requirements:

#### **Hardware**

- a network connection to the EXPEC/M3900 Firmware Manager server
- a color monitor
- a computer system capable of running Microsoft Internet Explorer 4.0 or above

#### **Software**

- Microsoft Internet Explorer 4.0 or above.



---

# Installation and setup

---

## Installation and setup

Installation of the ME3900/EXPEC Firmware Manager (MEFM) application requires no license key. Install and uninstall MEFM, Sun Java JDK, and Tomcat web server using the following procedures.

**Note:** Refer to “System requirements” on page 19 before you proceed.

---

### Procedure 1 Installing the MEFM, Sun Java JDK, and Tomcat web server

#### *From your PC browser*

- 1 Enter the following link and download and install Sun’s JDK 1.4.2\_04:  
**`http://java.sun.com/j2se/`**
- 2 Enter the following link and download and install Tomcat 5.0.28:  
**`http://jakarta.apache.org/site/binindex.cgi`**
- 3 Download and install MEFM. You must install MEFM in the webapps directory of the Tomcat installation.
- 4 Open a command prompt.

#### *From the Command prompt*

- 5 Go to the **<Java\_Home>\bin** directory, where **<Java\_Home>** is the directory where you installed the JDK in step 1. Execute the following command:  
**`keytool -genkey -alias tomcat -keyalg RSA`**
- 6 After executing this command, you will first be prompted for the keystore password. The default password used by Tomcat is **changeit** (all lower case).  
**Note:** You may specify a custom password, but if you do so, you must also specify this custom password in the server.xml configuration file (found in the **<Tomcat>\conf** directory, where **<Tomcat>** is the directory where you installed Tomcat server in Step 2).
- 7 Enter the general information about this certificate that you are prompted for, such as company, contact name, and so on.  
**Note:** This information will be displayed to users who attempt to access a secure page in your application, so make sure that the information provided here matches what they will expect.

## 22 Installation and setup

---

- 8 Enter the **key password**. This password is specifically for this certificate (as opposed to any other certificates stored in the same keystore file).  
**Note:** You must use the same password here as was used for the keystore password itself. (Currently, the keytool prompt will tell you that clicking on the **ENTER** key does this for you automatically.)
- 9 The previous steps created a keystore file with a certificate that can be used by your server.

### *From the Start Menu*

- 10 Select: Programs > Apache Tomcat > Start Tomcat
- 11 Select: Programs > MEFM > Start MEFM Client.

---

*This procedure is now complete*

---

## Procedure 2 Uninstalling the MEFM, Tomcat, and JDK

### *From the Start Menu*

- 1 Select: Programs > MEFM > Start MEFM> Shutdown Tomcat.
- 2 Select: Programs > MEFM > Uninstall MEFM.  
**Note:** SSL keystore files must be manually uninstalled.  
**Note:** Open a command prompt.

### *From the Command prompt*

- 3 Go to the <Java\_Home>\bin directory, where <Java\_Home> is the directory where you installed the JDK in Step 1 of [Procedure 1 on page 21](#).
- 4 Type **keystore -delete**.
- 5 Enter the alias name (the default was **tomcat**).
- 6 Enter your **key password** (the default was **changeit**).
- 7 The next step uninstalls the Tomcat.

### *From the Start Menu*

- 8 Select: Programs > Tomcat> Uninstall Tomcat.
- 9 The next step uninstalls the JDK.
- 10 Select: Control Panel > Add/Remove Programs. Select the JDK you installed.  
**Note:** If you are going to reinstall MEFM, it is not necessary to uninstall the keystore file, Tomcat, or the JDK.  
When reinstalling MEFM, perform only Step 3 of [Procedure 1 on page 21](#).

---

*This procedure is now complete*

---



---

## Navigating the MEFM

---

This chapter provides steps that help you navigate and perform various tasks using the M3900/EXPEC Firmware Manager (MEFM). The chapter is broken down into the following sections:

- Admin (see [“Administration \(Admin\)” on page 24](#))
- Login and User Administration (see [“Login and user administration” on page 31](#))
- EXPEC (see [“EXPEC” on page 33](#))
- M3900 (see [“M3900” on page 39](#))
- File servers (see [“File servers” on page 44](#))
- Viewing Log Files (see [“Viewing Log files” on page 48](#))

When you first enter the MEFM by entering the MEFM’S URL in your browser address window (for example, <http://localhost:8080/mefm>), you will be presented with a login screen.

These navigation procedures also appear as Help Files on the MEFM.

**Note:** Please see [“MEFM Password rules” on page 52](#) for the MEFM password requirements.

## 24 Navigating the MEFM

---

### Administration (Admin)

The Admin section includes the following tasks

- Initial Login
- Admin Login
- Adding a User
- Admin update of User information
- Admin delete of User
- Change password for Admin type

**Note:** See “MEFM Password rules” on page 52 for the MEFM password requirements.

### Initial Login (Admin)

---

#### Procedure 3 Initial Login

##### *In Login window*

- 1 Type “Admin” for the **User Name** and “admin” for **Password** (case sensitive), when first presented with the Login window. Click on **Submit**.

The Change Password page is presented.

##### *In Change Password page*

- 2 Type **admin** for **Current Password** (case sensitive) and enter a new (compliant) password for the next two boxes. Click on **Submit**.


---

*This procedure is now complete*

---

Figure 2 on page 25 shows an example of the login screen.

**Figure 2**  
**Login screen**



## Admin Login

### Procedure 4 Admin Login


#### *In Login window*

- 1 Type in valid "Admin" type **User Name** and **Password** (case sensitive), when presented with the Login window. Click on **Submit** (see "Changing Access Type").

The Welcome page is presented (**User Admin** option on the sidebar is optional).

*This procedure is now complete*

**Figure 3**  
**M3900/EXPEC Firmware Manager Home Screen**



### Adding a User

---

#### **Procedure 5** **Adding a User**

##### *In the MEFM Home screen*

- 1 Select the **User Admin** option on the sidebar.
- 2 Select the **Add User** option on the sidebar.
- 3 Type the new users's properties in each field.
- 4 Click on the **Submit** button.
- 5 Verify the user information and click on the **Submit** button.  
**Note:** To make changes click on the **Make Changes** link and repeat Step 3.
- 6 Confirm that the user was added by selecting **Home** and **User Admin** in the Activities log and in the User list.
- 7 Provide the user name and password to the new user.

---

*This procedure is now complete*

---

Figure 4 shows an example of adding a user and Figure 5 on page 27 is an example of the screen confirming a new user has been added.

**Figure 4**  
**Add a user**

The screenshot shows the 'Add a user' form in the M3900 / EXPEC Firmware Manager interface. The form includes a navigation menu on the left with options: Home, User Admin, Add User, Change Password, and Logout. The main form fields are: User Name (newUser), Password (masked with asterisks), Verify Password (masked with asterisks), First Name (highlighted in yellow), Last Name (highlighted in yellow), and Email (email@work.com). There are radio buttons for user type: Admin, General User (selected), and Guest. A checkbox for 'Require password change on first login' is checked. At the bottom right, there are 'Submit' and 'Reset' buttons.

**Figure 5**  
**Confirm a new user**

The screenshot shows the confirmation screen for adding a new user. The navigation menu on the left includes: Home, User Admin, EXPEC Admin, 3900 Admin, File Servers, Log Reports, Scheduler Jobs, and Logout. The main content area displays the following information: Username: newUser, Name: FirstName LastName, Email: email@work.com, Access Level: 1, and Change Password Required: true. There is a 'Submit' button and a 'Make changes' link.

## 28 Navigating the MEFM

### Admin update of user information

#### Procedure 6 Administrator update of user information


##### *In MEFM home screen*

- 1 Select the **User Admin** option on the sidebar.
- 2 Select a user from the user list.
- 3 Click on the **Edit User** button.
- 4 Make changes to the appropriate fields.
- 5 Click on the **Submit** button.

*This procedure is now complete*

Figure 6 on page 28 shows an example of the Current Existing Users list.

**Figure 6**  
**Current Existing Users list (User Admin screen)**



### Admin deletion of user

#### Procedure 7 Administrator deletion of user

##### *In MEFM home screen*


- 1 Select the **User Admin** option on the sidebar.
- 2 Select a user from the user list.
- 3 Click on the **Delete User** button.

- 4 Click on the **Continue** button to delete the user, or **Cancel** button to return to the previous screen.

*This procedure is now complete*

Figure 7 on page 29 shows the screen to delete a new user.

**Figure 7**  
**Delete new user**



## Change password for Admin type user

### Procedure 8 Changing a password for Admin type user


#### *In MEFM home screen*

- 1 Select the **User Admin** option on the sidebar.
- 2 Select the **Change Password** option on the sidebar.
- 3 Fill in the fields with the old and new passwords.
- 4 Click on the **Submit** button.

*This procedure is now complete*

Figure 8 on page 30 shows the screen for Admin to change a user password.


**Figure 8**  
**Change password for user: Administration**



The screenshot displays the M3900 / EXPEC Firmware Manager interface. At the top left is the Nortel Networks logo. To its right, a blue header bar contains the text "M3900 / EXPEC Firmware Manager". Below the logo, a navigation menu lists: Home, User Admin, Add User, Change Password, and Logout. The "Change Password" option is selected. The main content area shows the heading "Change password for user: Admin" followed by three input fields: "Current Password:", "New Password:", and "Verify Password:". Below these fields are "Submit" and "Reset" buttons. A smaller Nortel Networks logo is visible in the bottom left corner of the interface.

Figure 9 on page 31 shows the M3900/EXPEC Firmware Manager Home screen.

**Figure 9**  
**M3900/EXPEC Firmware Manager Home Screen**



## Login and user administration

The section includes the following tasks for non-Admin users

- Login
- User logout
- Changing passwords for General or Guest Users

### Initial Login for General and Guest type users

#### Procedure 9 Initial Login

##### *In Login window*

- 1 Type in **User Name** and **Password** you have been provided with (case sensitive), and click **Submit**.

##### *The Change Password page is presented*

- 2 Type in the password used in Step 1 and enter a new (compliant) password for the next two boxes, and submit.

## 32 Navigating the MEFM

---

**Note:** See “MEFM Password rules” on page 52 for password requirements.

The user is now logged in.

### Login for General and Guest type users

---

#### Procedure 10 Login

##### *In Login window*

- 1 Type in valid “Admin” type **User Name** and **Password** (case sensitive), and click **Submit**.

##### *The “Welcome” page is presented*

- When logging in as a “General or “Guest” type user, the User Admin option is not available
- When logging in as a “Guest” type user, the **Fileservers** and **Add Expec** options are not available
- No internal MEFM web page can be bookmarked

---

*This procedure is now complete*

---

### User Logout

---

#### Procedure 11 User Logout

##### *On MEFM Home screen*

- 1 Click on the **Logout** option on the sidebar menu.

---

*This procedure is now complete*

---

### Changing passwords for General or Guest type users

---

#### Procedure 12 Changing passwords for General or Guest type users

##### *In MEFM home screen*

- 2 Select the **Change Password** option on the sidebar.
- 3 Fill in the fields with the old and new passwords
- 4 Click on the **Submit** button.

---

*This procedure is now complete*

---

---

## EXPEC

The section includes the following tasks for working with EXPECs

- Adding an EXPEC
- Deleting an EXPEC
- Verifying changes in EXPEC list
- Get EXPEC file directory information on selected EXPECs
- Determine available memory on the EXPEC
- Release EXPECs that have been selected
- Add a load to a selected EXPEC
- Delete a firmware load from the EXPEC list
- Set a boot load on an EXPEC from the EXPEC list

### Adding an EXPEC

---

#### Procedure 13 Adding an EXPEC

##### *In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select the **Add EXPEC** option on the sidebar.
- 3 Fill in the fields and add an EXPEC by clicking on the **Add EXPEC** button.
- 4 Verify the information and click on the **Submit** button.

**Note:** If the information is not correct, click on the **Make changes** link and correct the information.

---


*This procedure is now complete*

---

Figure 10 on page 34 shows the Add Expec screen, and Figure 11 on page 34 shows the screen that confirms that an EXPEC was added.

## 34 Navigating the MEFM


**Figure 10**  
**Add EXPECs**



The screenshot shows the M3900 / EXPEC Firmware Manager interface. On the left is a navigation menu with links: Home, EXPEC Admin, Add Expec, Expec List, Log Reports, File Servers, Active Job Status, and Logout. The main content area has two input fields: 'EXPEC Name to add:' and 'EXPEC IP Address to add:'. Below these fields are two buttons: 'Add Expec' and 'Reset'. A blue arrow points to the 'Add Expec' button. A text box with a black border contains the following instructions:

- Press Add Expec to submit name and IP of new EXPEC
- The IP and name must not match any in the database
- Verification of EXPECs will not be done at this time
- The IP address must be for a valid IP
- There is no limit on what the name can be

**Figure 11**  
**Confirming an EXPEC was added**



The screenshot shows the M3900 / EXPEC Firmware Manager interface after an EXPEC has been added. The navigation menu is the same as in Figure 10. The main content area now displays the details of the added EXPEC: 'Expec Name: ipe1' and 'IP Address: 47.104.40.68'. Below this information, there is a 'Submit' button under the 'Add Expec' label, and a link labeled 'Make changes' under the 'Expec List' label. The 'Home' link in the navigation menu is highlighted.

## Deleting an EXPEC

### Procedure 14 Deleting an EXPEC


#### *In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select the **EXPEC List** option on the sidebar.
- 3 Select the EXPEC to be deleted.
- 4 Click on the **Delete EXPEC** button.
- 5 Verify that you want to delete the EXPEC or cancel the action (the **Item removed** screen will be displayed).

*This procedure is now complete*

Figure 12 on page 35 shows the screen for deleting an EXPEC.

### Figure 12 Deleting an EXPEC



## Editing an EXPEC

### Procedure 15 Editing an EXPEC

#### *In MEFM home screen*


- 1 Select the **EXPEC Admin** option on the sidebar.

## 36 Navigating the MEFM

- 2 Select the **EXPEC List** option on the sidebar.
- 3 Select the EXPEC to be edited from the list.
- 4 Modify the IP address.
- 5 Click on the **Update** button. (Figure 13 on page 36 shows the EXPEC list).

*This procedure is now complete*

**Figure 13**  
**The EXPEC List**



### Verifying changes in EXPEC list

#### Procedure 16 Verifying changes in EXPEC list

*In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select the **EXPEC List** option on the sidebar.
- 3 Verify the changes you made.

*This procedure is now complete*

### Get EXPEC file directory information on selected EXPECs

#### Procedure 17 Get EXPEC file directory information on selected EXPECs

*In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.

- 2 Click on single or multiple EXPECS from the list (to select multiple EXPECS, hold down control key while selecting).
- 3 Click on the **Submit** button.

**Note:** The status message and table are updated. The table shows the directory contents of the EXPECS selected.

*This procedure is now complete*

## Determine available memory on the EXPEC

### Procedure 18

#### Determine available memory on the EXPEC

##### *In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select single, or multiple, EXPECS from the list and click on the **Submit button**.

**Note:** A table will display the available memory on the EXPEC.

*This procedure is now complete*

## Release EXPECS that have been selected

### Procedure 19

#### Release EXPECS that have been selected

##### *In Expec Admin screen*

- 1 Select single, or multiple, EXPECS from the list and click on the **Release button**.

**Note:** The status message and table should update. Only the EXPECS that are selected will be released.

*This procedure is now complete*

## Add a load to a selected EXPEC

### Procedure 20

#### Add a load to a selected EXPEC

##### *In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select single or multiple EXPECS from the list and click on the **Select** button.
- 3 Select the EXPEC/EXPECS and press the **Add Load** button.
- 4 Select the file server from the list and press the **List Files** button.
- 5 Select the load to be transferred from the list and click on the **Select** button.

**Note:** The status message and table are updated. The table shows the load that was added on each EXPEC that was selected.

*This procedure is now complete*

Figure 14 on page 38 shows examples of EXPEC loads.

Figure 14  
EXPEC Loads

Select	EXPEC	IP Address	Load Files				Free Space	Total	
			Select	Load File	Boot Load	Timestamp	Size		
<input checked="" type="radio"/>	ipe0	47.104.40.67	<input type="radio"/>	EIPE17AA	-	05Mar2002-15:38:12	00482886	220160	1638400
			<input type="radio"/>	EIPE17AH	*	22Jan2004-14:11:43	00482814		
			<input checked="" type="radio"/>	EIPE17AB	-	04Sep2002-16:34:39	00482942		

Status:

**Delete a firmware load from EXPEC list**

**Procedure 21**  
Delete a firmware load from EXPEC list

*In MEFM home screen*

- 1 Select the **EXPEC Admin** option on the sidebar.
- 2 Select an EXPEC from the Expec List and press the **Select** button.
- 3 Select the firmware load from the list and press the **Delete Load** button.

**Note:** The status message and table are updated. The table displays only the loads that were not selected to be removed.

*This procedure is now complete*

**Set a boot load on an EXPEC from the EXPEC list**

**Procedure 22**  
Set a boot load on an EXPEC form the EXPEC list

*In MEFM home screen*

- 1 Select the **Expec Admin** option on the sidebar.
- 2 Select an EXPEC from the list and click on the **Select** button.
- 3 Select the file on the Expec List and click on the **Set Boot Load** button.

**Note:** The status message and table are updated. The table displays a marker next to the new boot load. The EXPEC must now be BSY'd (busied)

or RTS'd (Returned to Service) for the changes to take effect. This must be done from the MAPCI;MTC;PM level on the switch.

*This procedure is now complete*

---

## M3900

### Get EXPEC file directory information on selected EXPECs (M3900)

The M3900 section includes the following tasks for M3901, M3902, M3903, M3904, and M3905 telephones:

- Get EXPEC file directory information on selected EXPECs (for M3900)
- Check available memory in EXPEC (for M3900)
- Release EXPECs that have been selected (for M3900)
- Add firmware load to selected EXPEC (for M3900)
- Download firmware to an M3900
- Download firmware to multiple M3900s on multiple EXPECs
- Delete a firmware load from the EXPEC list (for M3900)
- Schedule a firmware download

[Figure 15 on page 40](#) shows the M3900 Administration screen.

**Figure 15**  
**M3900 Administration screen**



**Procedure 23**  
**Get EXPEC file directory information on selected EXPECs (M3900)**

**In MEFM home screen**

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select an EXPEC from the list and click on the **Submit** button.

**Note:** The status message and table are updated. The table displays a marker next to the new boot load. If the IP address is for a valid EXPEC, the table will show the directory contents of the M3900 loads.

*This procedure is now complete*

---

## Check available memory in EXPEC (M3900)

---

### Procedure 24

#### Check available memory in EXPEC (M3900)

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select single or multiple EXPECs from the list and click on the **Submit** button.
- 3 Find the available memory in the table for the EXPEC/s.

*This procedure is now complete*

---

## Release EXPECs that have been selected (M3900)

---

### Procedure 25

#### Release EXPECs that have been selected (M3900)

##### *In the M3900 Admin screen*

- 1 Select single or multiple EXPECs from the list and click on the **Release** button.

**Note:** The status message and table are updated. Only the EXPECs that are selected are released.

*This procedure is now complete*

---

## Add firmware load to selected EXPEC (M3900)

---

### Procedure 26

#### Add firmware load to selected EXPEC (M3900)

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select single or multiple EXPECs from the list and click on the **Select** button.
- 3 Select single or multiple EXPECs and click on the **Add Load** button.
- 4 Select the file server from the list and click on the **List Files** button.
- 5 Select the firmware load to be transferred from the list and click on the **Select** button.

**Note:** The status message and table are updated. The table displays the firmware loads that were added on each EXPEC that was selected.

*This procedure is now complete*

---

## Download firmware to an M3900

---

### Procedure 27

#### Download firmware to an M3900

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.

## 42 Navigating the MEFM

---

- 2 Select the **Expec List** option on the sidebar.
- 3 Select single or multiple EXPECs from the list and click on the **Select** button.
- 4 Select an EXPEC and click on the **Get Sets** button.
- 5 Select which set to transfer the load to and click on the **Select Firmware Download** button.
- 6 Select the file server from the list and press the **List Files** button.
- 7 Select the firmware load to be transferred from the list and click on the **Select** button.
- 8 Confirm the job selections and enter a job title in the form.
- 9 Click on the **Download Firmware** button.
- 10 The Active Job status is displayed. Watch the page until the job completes (or select the job and click on the **Cancel Job** button).

**Note:** The status message and table are updated and states that the job completed successfully. The Active Job page shows the job status as "Completed Successfully".

---

*This procedure is now complete*

---

### Download firmware to multiple M3900s on multiple EXPECs

---

#### Procedure 28

#### Download firmware to multiple M3900s on multiple EXPECs

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select the **Expec List** option on the sidebar.
- 3 Select multiple EXPECs from the list and click on the **Get Sets** button.
- 4 Select multiple sets of the same type and on multiple EXPECs to transfer the load to.
- 5 Select which set to transfer the load to and click on the **Select Firmware Download** button.
- 6 Select the file server from the list and press the **List Files** button.
- 7 Select the firmware load to be transferred from the list and click on the **Select** button.
- 8 Confirm the job selections and enter a job title in the form.
- 9 click on the **Download Firmware** button.
- 10 The Active Job status is displayed. Watch the page until the job completes (or select the job and click on the **Cancel Job** button).

**Note:** The status message and table are updated and states that the job completed successfully. The Active Job page shows the job status as "Completed Successfully".

---

*This procedure is now complete*

---

---

## Delete a firmware load from EXPEC list (M3900)

---

### Procedure 29

#### Delete a non-bootable EXPEC load from EXPEC list (M3900)

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select an EXPEC from EXPEC list and press the **Select** button.
- 3 Select the firmware load from the list and press the **Delete Load** button.

**Note:** The status message and table are updated. The table displays only loads that were not selected to be removed.

---

*This procedure is now complete*

---

## Schedule a firmware download (M3900)

---

### Procedure 30

#### Schedule a firmware download (M3900)

##### *In MEFM home screen*

- 1 Select the **M3900 Admin** option on the sidebar.
- 2 Select the **Expec List** option on the sidebar.
- 3 Select an EXPEC from the list and click on the **Select** button.
- 4 Select an EXPEC and click on the **Get Sets** button.
- 5 Select which set to transfer the load to and click on the **Select Firmware Download** button.
- 6 Select the file server from the list and press the **List Files** button.
- 7 Select the firmware load to be transferred from the list and click on the **Select** button.
- 8 Confirm the job selections and enter a job title in the form.
- 9 Click on the **Schedule Download Firmware** button.
- 10 Enter start date, start time, end time, repeat interval, and comments, and click on the **Submit** button.
- 11 Confirm that the information is correct and click on the **Submit**.
- 12 The Active Job status is displayed. Watch the page until the job completes.

**Note:** The download will be scheduled and will occur at the designated time.

---

*This procedure is now complete*

---

## 44 Navigating the MEFM

### File servers

This section includes the following tasks:

- Add a file server
- Modify a file server
- Delete a file server
- Cancel a file server
- Modify new file server before submitting to database

#### Add a file server

##### Procedure 31 Add a file server

###### *In MEFM home screen*

- 1 Select the **File Servers** option on the sidebar.
- 2 Select the **Add File Server** option on the sidebar.
- 3 Type in the new file server's properties in each field.
- 4 Click on the **Submit** button.
- 5 Verify that the information that is displayed is correct and click on the **Submit** button.

**Note:** The file server lists and the database are updated with the new file server.

*This procedure is now complete*

Figure 16 on page 44 shows the Add Fileserver screen.

##### Figure 16 Add a file server screen

The screenshot displays the 'Add Fileserver' screen in the M3900 / EXPEC Firmware Manager. The interface includes a sidebar on the left with navigation options: Home, File Servers, Add Fileserver (highlighted), and Logout. The main content area contains a form with the following fields:

File Server Name:	myfileserver
IP Address:	47.102.193.131
Path:	c:\fileserver
Port:	21
User Name:	user
Password:	*****
Password Verify:	*****

At the bottom of the form are two buttons: **Submit** and **Reset**.

## Modify a file server

### Procedure 32 Modify a file server

#### *In MEFM home screen*


- 1 Select the **File Servers** option on the sidebar.
- 2 Select a file server from the list.
- 3 Click on the **Edit File Server** button.
- 4 Change the file server's properties in each field.
- 5 Click on the **Submit** button.
- 6 Verify that the information that is displayed is correct and click on the **Submit** button.

**Note:** The file server lists and the database are updated with the new information.

*This procedure is now complete*

Figure 17 on page 45 shows the screen to confirm file server information.

### Figure 17 Confirm file server information



## Delete a file server

### Procedure 33 Delete a file server

#### *In MEFM home screen*

- 1 Select the **File Servers** option on the sidebar.
- 2 Select a file server from the list.
- 3 Click on the **Delete File Server** button.

## 46 Navigating the MEFM

---

- 4 Confirm that the file server to be deleted is the correct one.
- 5 Click on the **Submit** button.
- 6 Verify that the information that is displayed is correct and click on the **Submit** button.

**Note:** The file is deleted and the server lists and the database are updated.

---

*This procedure is now complete*

---

### Cancel a file server deletion

---

#### Procedure 34 Cancel a file server deletion

##### *In MEFM home screen*

- 1 Select the **File Servers** option on the sidebar.
- 2 Select a file server from the list.
- 3 Click on the **Delete File Server** button.
- 4 View the “Confirm the file server deleted” page.
- 5 Click on the **Cancel** button.

**Note:** The file is not deleted and the server lists and the database are intact.

---

*This procedure is now complete*

---

### Modify new file server before submitting to database

---

#### Procedure 35 Modify new file server before submitting to database

##### *In MEFM home screen*

- 1 Select the **File Servers** option on the sidebar.
- 2 Select a file server from the list.
- 3 Click on the **Edit File Server** button.
- 4 Click on the **Submit** button.
- 5 The **Confirm File Server Fields** page is displayed.
- 6 Click on the **Make Changes** link (the **Add FTP file server** page is displayed).
- 7 Modify the fields and click on the **Submit** button.
- 8 Verify that the information that is displayed is correct and click on the **Submit** button.

**Note:** The file server lists and the database are updated with the new information.

---

*This procedure is now complete*

---

Figure 18 on page 47 shows an example of file server errors.

**Figure 18**  
**File server errors**

The screenshot shows the 'M3900 / EXPEC Firmware Manager' interface. On the left is a navigation menu with 'Home', 'File Servers', 'Add Fileserver', and 'Logout'. The main area contains a form with the following fields and error messages:

- File Server Name:  Please enter a name.
- IP Address:  Please enter an IP address.
- User Name:  Please enter user name.
- Password:  Please enter password.
- Password Verify:  Please enter password.
- Path:  Please enter the path.
- Port:  Please enter the port.
- FTP Type:  Please enter the FTP type.

At the bottom of the form are 'Submit' and 'Reset' buttons.

Figure 19 on page 48 shows the screen to list and select file servers.

## 48 Navigating the MEFM

**Figure 19**  
List file server and select load



## Viewing Log files

This section includes information about how to view Log Files.

### View log files

#### Procedure 36 View logfiles

##### *In MEFM home screen*


- 1 Select the **Log Reports** option on the sidebar.
- 2 From the pull-down menu, select a log file to view.
- 3 Click on the **Select** button.

**Note:** The log file contents are displayed.

*This procedure is now complete*

Figure 20 on page 49 shows the Log File Administration screen.

Figure 20  
View log files







---

# Security

---

## Security benefits of the M3900/EXPEC Firmware Manager

The MEFM/EXPEC firmware down loader application provides the following capabilities:

- secure page indication in toolbar
- allows user to change password
- provides the following levels of user access and privileges:
  - Admin – an administrator can add users
  - General user – can add EXPECS and fileservers
  - Guest user – can download files
- SSL – Secure Socket Level (SSL) is used to secure communication between client and server
- encryption – all passwords, IP addresses and similar information are encrypted
- log of major events – users who are active on the system (logged in) are logged in a file and displayed as recent activity on the main page
- Login – Admin

For Administrator login, “Admin” is the user name and password for the first-time login.

**Note:** Bookmarks cannot be set within the application.

See “[MEFM Password rules](#)” on page 52 for MEFM password requirements.

**MEFM Password rules**

Table 2 contains the requirements for M3900/EXPEC Firmware Manager (MEFM) passwords.

**Table 2  
MEFM Password requirements**

<b>Your password must</b>	<b>Your password must not</b>
contain at least 8 characters.	be a previously used password.
contain both upper and lower case letters.	be a password that matches an account name.
contain at least one number or symbol.	have sequentially repeating characters.
	contain: <ul style="list-style-type: none"><li>• a space</li><li>• editing characters (@, #, \$)</li><li>• field separator characters (:, or ;)</li><li>• single or double quotation marks</li></ul>
	contain letters in forward or reverse alphabetic sequence.
	contain letters in forward or reverse keyboard patterns or sequence, for example, "qwerty".
	contain only numbers or only punctuation characters.
	contain the same character for the first three positions.



---

## List of terms

---

<b>API</b>	Application Programming Interface
<b>DMS</b>	Digital Multiplex System
<b>EIPE</b>	Enhanced Intelligent Peripheral Equipment
<b>EXPEC</b>	Enhanced Extended Peripheral Equipment Controller
<b>GUI</b>	Graphic User Interface
<b>IPE</b>	Intelligent Peripheral Equipment
<b>JRE</b>	Java Runtime Environment
<b>MAP</b>	Maintenance and Administration Position.
<b>MAPCI</b>	Maintenance and Administration Position Command Interpreter
<b>MEFM</b>	M3900/EXPEC Firmware Manager
<b>MSL</b>	Meridian Stored Logic
<b>NMS</b>	Network Management System
<b>OA&amp;M</b>	Operations, Administration, and Maintenance
<b>ODBMS</b>	Object Oriented Database Management System
<b>SNMP</b>	Simple Network Management Protocol
<b>SSL</b>	Secure Socket Layer
<b>SWACT</b>	Switch Activity
<b>UTR</b>	Universal Tone Receiver
<b>WUI</b>	Web User Interface







Nortel Networks Meridian SL-100/Communication Server 2100

## M3900/EXPEC Firmware Manager

### User Guide

Copyright © 2005 Nortel Networks,  
All Rights Reserved

**NORTEL NETWORKS CONFIDENTIAL:** The information contained in this document is the property of Nortel Networks. Except as specifically authorized in writing by Nortel Networks, the holder of this document shall keep the information contained herein confidential and shall protect same in whole or in part from disclosure and dissemination to third parties and use same for evaluation, operation, and maintenance purposes only. Changes or modifications to the Meridian SL-100 without the express consent of Nortel Networks may void its warranty and void the user's authority to operate the equipment.

Information is subject to change without notice. Nortel Networks reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant.

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules, and the radio interference regulations of the Canadian Department of Communications. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense. Allowing this equipment to be operated in such a manner as to not provide for proper answer supervision is a violation of Part 68 of the FCC Rules, Docket No. 89-114, 55FR46066.

\*Nortel Networks, the Nortel Networks logo, the Globemark, Unified Networks, DMS, MAP, Meridian, MSL, Nortel, Northern Telecom, NT, OPTera, SL-100, and SuperNode are trademarks of Nortel Networks.

---

Publication number: 555-4001-317  
Product release: SE07  
Document release: Standard 01.04  
Date: January 2005  
Printed in the United States of America.

---

