

# Avaya™ C460 Version 2.0.5 Release Notes

---

## Introduction

This document contains information related to the Avaya C460 switch that was not included in the documentation on the *Avaya C460 Documentation and Utilities CD*. This document also describes known issues and other information required for proper installation and use of the product.

## What's New

C460 version 2.0.5 supports the following new features:

- PoE (Power over Ethernet) hardware:
  - M4648ML-T-PWR: 48 10/100 Mbps PoE ports
  - M4648ML-T-2G-PWR: 48 10/100 Mbps PoE + 2 GBIC ports
  - MPS4610-AC 1000W AC PSU (power supply unit)
- PoE (Power over Ethernet) software
- IEEE 802.1x PBNAC (Port-based network access control)
- IEEE 802.1w Rapid Spanning Tree
- MAC aging
- Multilayer policy
- AnyLayer SMON

## Problems Fixed

- The port redundancy interval time is now copied from the active supervisor module to the standby supervisor module.
- Port-level Static VLAN definitions for a module are now cleared when you replace the module with one of a different type.
- You can now configure the SMON license on the active supervisor module in either slot 1 or slot 2.
- All stations on the managers trap list now receive traps from the C460.

---

## Important Notes

### Mixing 300W and 1000W Power Supplies

You should not install both MPS300-AC 300W and MPS1000-AC 1000W PSUs in the same C460 switch. If you do so, the switch may not operate correctly.

## Known Issues

### C460 Device Manager

The inband and outband interfaces always appear as “enabled”.

#### Workaround

Check the status with the CLI using the `show interface` command.

### PPP

#### Changing PPP Configuration

Do not change PPP configuration/parameters during a PPP session.

If you do, the supervisor module may reset in rare cases.

#### PPP on a Standby Supervisor Module

If you wish to use a PPP session on a standby supervisor module, set the interface to “enable-always”

### show environment power CLI command

The total power drawn for PoE shown in the output of the `show environment power` CLI command may differ slightly from the actual aggregated power drawn by the modules.

### Policy “trust-cos-dscp” trust mode

“Trust-cos-dscp” trust mode is not supported. If you configure this trust mode, it acts the same as trust-cos.

---

## Edge port remains in blocking state

### Problem

When global Spanning Tree is enabled, an edge port remains in blocking status after you enable Spanning Tree on the port.

### Workaround

- 1 Set the port to non-edge using the  
`set port edge admin non-edge-port <module/port>` CLI command.
- 2 Enable spanning tree for the port using the  
`set port spantree enable <module/port>` CLI command.
- 3 Set the port to edge using the  
`set port edge admin edge-port <module/port>` CLI command

## LAG and Flow Control Function LEDs

The port status LEDs of the PoE I/O modules do not display LAG and Flow Control information when those functions are selected on the Active SPV

## “deny-and-notify” trap

When using Access Control in Layer 2, applying a rule with a “deny-and-notify” action does not generate a “deny-and-notify” trap.

## show port channel CLI command

The `show port channel` CLI command incorrectly displays “Link Aggregation Group of 1000Base -x ports” instead of “Link Aggregation Group of 100Base -x ports” for 10/100 Mbps LAGs on PoE I/O modules.

## IEEE 802.1X PBNAC (Port-Based Access Control)

The C460 only supports EAP-MD5.

---

## Previous Software Versions

Version	Changes
1.0.7	<ul style="list-style-type: none"><li data-bbox="515 261 771 290">• First release (P460)</li></ul>

### **avaya.com**

© 2003 Avaya Inc. All rights reserved. All trademarks identified by the ® or TM are registered trademarks or trademarks, respectively, of Avaya Inc.

Document no. 555-500-702