

28 TAPE PRINTER UNIT (STOCK TICKER)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Pressure roller spring	31
MANUAL OPERATION OF THE UNIT	2	Print hammer accelerator trip lever overtravel	24
CONDITIONING OPERATIONS	3	Print hammer head spring	33
2. TAPE PRINTER	4	Print hammer lever spring.	26
Codebar Mechanism		Print hammer mechanism selector slide	23
Clutch drum position	19	Print hammer trip lever.	25
Clutch shoe lever	19	Print hammer trip lever spring	26
Clutch shoe lever spring.	20	Ribbon feed mechanism drive slide	32
Clutch shoe spring	20	Ribbon ratchet wheel torsion	32
Codebar cam follower spring	18	Tape margin	29
Codebar clutch and function clutch trip levers	17	Tape feed pawl spring	30
Codebar clutch latchlever spring	17	Tape feed ratchet detent	30
Codebar detent spring	16	Tape feed - ribbon feed cam follower spring	29
Codebar mechanism.	16	Tape feed wheel centering	31
Codebar shift lever drive arm	12	Tape feed wheel detent	30
Codebar shift lever link bracket	15	Trip shaft lever spring	17
Intermediate arm downstop bracket	14	Positioning Mechanism	
Transfer lever eccentric	13	Aggregate motion spring	22
Transfer lever spring	13	Character alignment.	35
Trip shaft lever spring	17	Clutch latchlevers.	21
Function Mechanism		Clutch latchlever springs	22
Accelerator drive spring	25	Clutch shoe lever spring	23
Clutch drum position	19	Typebox alignment	36
Clutch shoe lever	19	Typebox alignment (front to rear).	33
Clutch shoe lever spring	20	Typebox alignment (transverse).	34
Clutch shoe spring	20	Typebox carriage roller arm spring.	36
Detent spring (print hammer).	23	Typebox clutch shoe lever	20
Detent spring (ribbon)	32	Typebox rack and pinion	28
Feed pawl spring	32	Typebox rail positioning trip slide	27
Function cam follower spring	24	Selector Mechanism	
Function clutch trip lever follower spring	18	Clutch shoe lever	19
Function clutch trip levers.	17	Clutch shoe lever spring.	20
Function clutch latchlever spring	17	Clutch shoe spring.	20
		Marking locklever spring	7
		Push lever reset bail spring	10

CONTENTS	PAGE
Push lever spring	10
Range finder knob phasing	4
Selector armature	5
Selector armature spring	7
Selector armature stop	6
Selector cam lubricator	9
Selector clutch drum	9
Selector clutch latchlever spring	11
Selector clutch stop arm	4
Selector lever spring	10
Selector magnet bracket	8
Selector receiving margin	9
Spacing locklever spring	11
Start lever spring	11

1. GENERAL

1.01 This section is issued to provide adjustment and maintenance information for the tape printer unit (stock ticker) and to present that information as a separate section.

1.02 In the adjustments covered in this section, location of clearances, position of parts, and point and angle of scale applications are illustrated by line drawings. Requirements and procedures are set forth in the several texts that accompany the line drawings. Required tools, not furnished with the tape printer unit, are listed in the appropriate maintenance tools publication.

1.03 The sequence in which the adjustments appear is that which should be followed when a complete readjustment of the tape printer is undertaken. No single adjustment should be undertaken without first completely understanding the procedure and requirements. Therefore, read a procedure all the way through before making an adjustment or checking a spring tension.

1.04 The spring tensions specified in this section are indications, not exact values. Therefore, to obtain reliable readings, it is important that spring tensions be measured by spring scales placed in the positions shown on pertinent line drawings. Springs that do not meet their requirements shall be replaced by new ones.

1.05 When disengaged, a clutch is latched so that a shoe lever is held in its stop position between a trip lever, which bears against the shoe lever, and a latchlever, which seats in a notch in a clutch cam disc. The shafts and clutch drums will then turn freely without the clutch shoes dragging. When the clutch is engaged or tripped, the shoe lever and cam disc stop-lug are moved apart, and the clutch shoes are wedged against the drum so that the clutch turns in unison with the shaft.

Note: When rotating the main shaft by hand, the clutches will not fully disengage upon reaching the stop position. In order to relieve the drag on the clutch and permit the main shaft to rotate freely, apply pressure on the lug of the clutch disc to permit the latchlever to fully latch. This procedure should be followed prior to applying power to the unit.

1.06 Where applicable, all adjustments should be made with the related cam follower on that half of the two-cycle cam which causes the clearance to be least, unless otherwise specified.

MANUAL OPERATION OF THE UNIT

1.07 To manually operate the unit, apply current to the selector coils while the adjustments are being made to hold the armature in the marking position. To manually select the "rubout" code combination, push the armature to the rear into the spacing position momentarily to permit the selector clutch to engage. Rotate the main shaft slowly, using a handwheel (see the appropriate tools section) until no. 6 push lever has been selected by no. 6 selector lever and no. 6 lever is on the high part of its cam. Levers are numbered 1 to 6 from left to right.

1.08 Strip levers from under selector levers corresponding to the spacing elements of the code combination to be set up. For example, the letter R code combination (-2-4--), has code elements 1, 3, 5, and 6 spacing. By stripping no. 1, 3, 5, and 6 push levers, R is selected.




Figure 1 — Tape Printer Unit (Stock Ticker)

Then rotate the main shaft until the required condition is set up or the character has been cleared through the tape printer unit.

CONDITIONING OPERATIONS

1.09 To prevent damage when making a complete adjustment to the tape printer unit, observe the following conditions before proceeding with any adjustments:

- (a) Loosen the scissors operating lever clamp.
- (b) Loosen the print hammer shift link clamp screw.

1.10 Before mounting the tape printer on its base, loosen the four mounting screws on the two rear legs. Fasten unit to base before tightening the leg screws.

2. TAPE PRINTER

2.01 Selector Mechanism

RANGE FINDER KNOB PHASING

To Check

Turn the range finder knob to its extreme right and left positions.



Requirement

0 mark---120 mark should overtravel the scribed line on the knob mounting plate by an equal amount.

To Adjust

Position range scale knob with its mounting nut loosened.

(TOP VIEW)



(LEFT SIDE VIEW)

SELECTOR CLUTCH STOP ARM

To Check

Set range scale at 60. Place armature in marking position. Disengage (latch) clutch.

Requirement


As gauged by eye, the clutch stop arm should engage the clutch shoe lever by the full thickness of the stop arm.

To Adjust

Position the stop arm with its clamp screw loosened.

2.02 Selector Mechanism (continued)

Note 1: To facilitate making the following adjustments, remove the range finder assembly and selector magnet assembly. (For instructions, see the appropriate tape printer disassembly and reassembly section.)



(LEFT SIDE VIEW)

SELECTOR ARMATURE


Note 2: This requirement need not be made or checked if the SELECTOR MAGNET BRACKET and SELECTOR RECEIVING MARGIN requirements are met.

Requirement

- (1) Armature Clamp Strip
Min 0.015 inch---Max 0.045 inch
clearance between armature clamp strip
and casting.
- (2) Armature Alignment
Outer edge of the armature should be
flush, within 0.015 inch
with outer edge of pole pieces.

To Adjust

Position the armature spring adjusting nut to hold the lower button of the armature firmly against casting. Position armature with mounting screws loosened.



(TOP VIEW)

2.03 Selector Mechanism (continued)

SELECTOR ARMATURE STOP

To Check


Place gauge between armature and upper pole piece. Check requirement when magnets are de-energized and armature is resting against its stop button.

Requirement


Min 0.020 inch---Max 0.025 inch between the end of the armature and the rear edge of the upper pole piece.

To Adjust

Position the stop bracket with its mounting screw loosened.



(TOP VIEW)



(LEFT SIDE VIEW)

2.04 Selector Mechanism (continued)

SELECTOR ARMATURE SPRING

To Check

With no distortion test set available, place marking locklever, spacing locklever, and start lever on high part of their cams.

(1) Requirement

Min 4-1/2 oz---Max 5-1/2 oz
to pull armature to marking position.

To Check



Use distortion test set.

(2) Requirement

The selector should be relatively free from internal bias when checked as specified in the instructions furnished with the set.

To Adjust

Rotate the adjusting nut.

MARKING LOCKLEVER SPRING

To Check

Energize magnets. Select "letters" code combination, selector clutch disengaged.

Requirement

Min 9 oz---Max 12 oz
to start marking locklever moving.

2.05 Selector Mechanism (continued)

SELECTOR MAGNET BRACKET



To Check

Marking and spacing locklever on high part of their cams. Magnets de-energized.

- (1) Requirement
Min 0.010 inch---Max 0.015 inch
between end of armature extension and the shoulder on the marking locklever or the tip of the spacing locklever, whichever is least.

To Adjust

Position the magnet bracket by means of the adjusting link with magnet bracket mounting screws loosened. Tighten link clamp screw only.



To Check

Marking locklever on low part of cam. Magnets energized. Armature in contact with both pole pieces.

- (2) Requirement

Some---to---0.003 inch
clearance between rear surface of armature extension and forward surface of marking locklever. With magnet de-energized, should have barely perceptible motion of armature.

To Adjust

Position forward end of magnet bracket with mounting screws loosened.

To Recheck

Rotate selector cam and check for smooth operation of start lever over armature extension. Refine requirements if necessary.


2.06 Selector Mechanism (continued)

SELECTOR CLUTCH DRUM

To Check
 Latch clutch in stop position with clutch drum against shoulder on main shaft.

Requirement
 Some---Max 0.010 inch endplay between cam-clutch assembly and shoulder on main shaft.

To Adjust
 Position clutch drum with mounting screw loosened.




(REAR VIEW)

SELECTOR CAM LUBRICATOR

To Check
 Rotate cam sleeve until high part of selector cam is opposite lubricator tube.

(1) Requirement
 The lubricator tube should clear the high part of the cam by at least 0.020 inch.

(2) Requirement
 The high part of the selector lever cams should contact the wick but not deflect it more than 1/32 inch.



(LEFT SIDE VIEW)

SELECTOR RECEIVING MARGIN

To Check
 Use signal distortion test set as specified in the instructions furnished with the set.

Requirement


Overall bias	33 percent
End distortion	32 percent (at same range scale setting).

2.07 Selector Mechanism (continued)

PUSH LEVER SPRING


To Check
Place push levers in spacing position.

Requirement
Min 1 oz---Max 2 oz
to move push levers from the selector lever. Check all push levers.



(LEFT SIDE VIEW)

SELECTOR LEVER



SELECTOR LEVER SPRING

SELECTOR LEVER SPRING


To Check
Rotate shaft until push lever reset bail is latched up on lever guide, and selector levers are on high part of their cams.

Requirement
Min 1-1/2 oz---Max 2-1/2 oz
to start each lever moving.

PUSH LEVER RESET BAIL SPRING

To Check
Place push lever in spacing position and push lever bail on low part of cam.

Requirement
Min 1 oz---Max 2 oz
to move the bail from the cam.




2.08 Selector Mechanism (continued)

SPACING LOCKLEVER SPRING

To Check
Energize selector magnets. Disengage selector clutch.


Requirement
Min 19 oz---Max 26 oz
to start the spacing locklever moving.



SELECTOR CLUTCH LATCHLEVER SPRING

To Check
Rotate shaft so that latchlever is resting on low part of cam.

Requirement
Min 2-1/2 oz---Max 4 oz
to start latchlever moving.




START LEVER SPRING

To Check
Unhook latchlever spring. Rotate shaft until stop arm bail is in indent of cam. Set range scale at 60.

Requirement
Min 9-1/2 oz---Max 13 oz
to start stop arm moving.

2.09 Codebar Mechanism



CODEBAR SHIFT LEVER DRIVE ARM

To Check

Rotate main shaft until codebar shift lever link is in its forwardmost position. Play in shift lever and link taken up toward rear.

Requirement

Min 0.010 inch---Max 0.020 inch between forward surface of the rollers and the rear surface of the cam slot in the shift levers which provides the minimum clearance.

To Adjust

Position the cam follower arm on its drive shaft with its clamp screw loosened. Provide up to 0.006 inch endplay.

2.10 Codebar Mechanism (continued)


TRANSFER LEVER SPRING

To Check

Place transfer levers in spacing position and hold them while pulling on spring.

Requirement

Min 1-1/2 oz---Max 2-1/2 oz to move the intermediate arm.

TRANSFER LEVER ECCENTRIC

To Check


Set up "rubout" code combination on the pushbars. Disengage (latch) selector clutch. Rotate codebar shift lever link to its forwardmost position.

Requirement


Min 0.010 inch---Max 0.025 inch clearance between the lower shift lever and the lower edge of codebar shiftbar which is farthest from the lower shift lever when play is taken up to make clearance maximum.

To Adjust

Loosen the transfer lever clamp screw. Rotate the eccentric bushing to the desired position by using the adjusting holes. Keep the high part of the eccentric to the front of the vertical centerline.



2.11 Codebar Mechanism (continued)




INTERMEDIATE ARM DOWNSTOP BRACKET

To Check

Rotate selector clutch to stop position. Strip the pushbars. Rotate shaft until codebar shift lever link is in rearward position.

Requirement


Min 0.010 inch---Max 0.025 inch between the upper codebar shift lever and the upper edge of inner step on the codebar shiftbar which is farthest from the upper shift lever when play is taken up for maximum clearance.



To Adjust

Position downstop bracket with its clamp screws loosened.

2.12 Codebar Mechanism (continued)



(TOP VIEW)

CODEBAR SHIFT LEVER LINK BRACKET**To Check (Upper)**

Select "blank" code combination. Rotate main shaft until codebar shift lever link reaches its forwardmost position.

Requirement

The motion of front and rear codebar shift levers should be equalized with respect to codebar travel. Clearance between upper codebar shift lever and shoulder on nearest codebar shiftbar

Min 0.002 inch---Max 0.012 inch when play is taken up to make clearance maximum.

To Check (Lower)


Select "rubout" code combination. Check clearance between lower codebar shift lever and shoulder on nearest codebar shiftbar in the same manner.

Requirement

Min 0.002 inch---Max 0.012 inch when play is taken up to make clearance maximum.

To Adjust

Position adjusting plate (upper and lower) with clamp screws loosened.



(FRONT VIEW)

2.13 Codebar Mechanism (continued)

CODEBAR DETENT

To Check (No. 1 Codebar)

Select blank combination and put unit in stop position. Shift No. 1 codebar to marking. Rotate main shaft until stop lug just clears stop slide extension. Apply 32 oz scale to No. 1 trip slide extension and pull to spacing. Note force required to return to marking position when codebar is manually shifted to spacing. Apply scale to keep trip slide in spacing position and manually detent codebar to marking position. Note force required.

Requirement

The force should be Min 9 oz---Max 16 oz and equal within 3 oz

To Check (No. 5 Codebar)


Unhook print hammer detent spring and apply scale to pry point opening. Apply same procedure as that used for No. 1 codebar.

Requirement

The force should be Min 12 oz---Max 20 oz and equal within 3 oz

To Adjust

Equalize the detenting by adding or removing shims between detent casting and codebar bracket.



2.14 Codebar Mechanism (continued)
and Function Mechanism

CODEBAR CLUTCH AND FUNCTION CLUTCH TRIP LEVERS


To Check
Latch each clutch in stop position.

Requirement
The clutch trip levers should engage their respective clutch shoe lever by the full thickness of the shoe lever, when checked at the stop position with the least bite.

To Adjust
Position the trip lever on its shaft with its clamp screw loosened. Leave some endplay
Max 0.006 inch.

CODEBAR CLUTCH LATCHLEVER SPRING
FUNCTION CLUTCH LATCHLEVER SPRING

Requirement
Min 5 oz---Max 7-1/4 oz
to move latchlever away from disc.




TRIP SHAFT LEVER SPRING

To Check
Trip shaft lever on low part of cam.


Requirement
Min 1 oz---Max 2 oz
to start trip shaft lever moving.

2.15 Codebar Mechanism and Function Mechanism (continued)



To Check
Place cam follower on low part of cam. Unhook cam follower spring from its bracket.

Requirement
Min 20 oz---Max 24 oz
to pull spring to its installed length.




CODEBAR CAM FOLLOWER SPRING

To Check
Place codebar clutch in stop position. Unhook codebar cam follower spring from follower.

Requirement
Min 11 oz---Max 14 oz
to pull spring to installed length

2.16 Selector Mechanism, Codebar Mechanism, and Function Mechanism (continued)

CLUTCH SHOE LEVER
(Selector, Codebar, Function)



To Check

With clutch disengaged and latched in stop position, measure the gap between the clutch shoe lever and stop-lug. Trip the clutch and rotate the clutch until the shoe lever is toward the rear of the unit. Apply 32 oz pressure against stop lug to make gap maximum. Again measure the gap between the shoe lever and lug.

Note 1: When measuring, use the stop-lug adjacent to the notch in the clutch adjustment plate.

Requirement

The gap between the clutch shoe lever and stop-lug should be
Min 0.055 inch---Max 0.070 inch
greater when clutch is engaged (unlatched) than when it is disengaged (latched). Measure clearance at the stop-lug which has the least.

To Adjust

Rotate the adjusting plate by means of a screwdriver or wrench with the plate clamp screws loosened.

Note 2: After making this adjustment, disengage the clutch, remove the drum screw, and rotate the drum in the normal direction. There should be no drag on the drum. If necessary, refine the adjustment toward the maximum clearance.


CLUTCH DRUM POSITION
(Except Selector)

Requirement


Each clutch should have some endplay
Max 0.015 inch.

To Adjust

Position the clutch drum on the main shaft with its mounting screw and spacing clutch set collar mounting screw loosened.



2.18 Positioning Mechanism



2.19 Positioning Mechanism


AGGREGATE MOTION SPRING

To Check

Select "E" code combination, and rotate unit to stop position. Unhook the spring.

Requirement

Min 22 oz---Max 26 oz
to pull spring to installed length.
Check both springs.



CLUTCH LATCHLEVER SPRINGS (4 Springs)

To Check


Place latchlevers in latched position. Unhook spring.

Requirement

Min 8 oz---Max 10 oz
to pull spring to installed length.

Note: This adjustment applies to all four positioning clutches.

2.20 Positioning Mechanism (continued) and Function Mechanism: (continued)



CLUTCH SHOE LEVER SPRING

To Check
Trip (engage) clutch. Hold clutch.


Requirement
Min 9 oz---Max 11 oz
to move shoe lever into contact with stop-lug.

PRINT HAMMER MECHANISM SELECTOR SLIDE

To Check
Select "rubout" code combination, rotate shaft to stop position, and have selector slide roller fully detented.

Requirement
Min 0.002 inch---Max 0.008 inch
clearance between left edge of selector lever fork and
no. 6 codebar extension roller.

To Adjust
Position selector lever by means of pry point with clamp screw loosened.



DETENT SPRING

To Check
Operate unit to stop position with
detent lever fully detented.

Requirement
Min 2-1/2 oz---Max 3-1/4 oz
to start lever moving.

2.21 Function Mechanism (continued)

PRINT HAMMER ACCELERATOR TRIP LEVER OVERTRAVEL

To Check


Select "rubout" code combination, and rotate main shaft until the print mechanism cam follower is on high part of function cam. Select "blank" code combination and check other trip lever.

Requirement

Min 0.002 inch---Max 0.010 inch clearance between latch surface of the accelerator and trip latch on the side with least clearance.

To Adjust

Position cam follower on drive shaft with its clamp screw loosened. Refine with eccentric.



FUNCTION CAM FOLLOWER SPRING



To Check

Place function clutch in stop position. Unhook spring.


Requirement

Min 20 oz---Max 25 oz to pull spring to position length.

2.22 Function Mechanism (continued)



2.23 Function Mechanism (continued)



PRINT HAMMER TRIP LEVER SPRING


To Check
Place unit in stop position.

Requirement
Min 3 oz---Max 5 oz
to start lever moving away from the accelerator.

PRINT HAMMER LEVER SPRING

To Check
Place unit in stop position.

Requirement
Min 1 oz---Max 2 oz
to move lever away from accelerator.



2.24 Positioning Mechanism (continued)

TYPEBOX RAIL POSITIONING TRIP SLIDE**To Check**


Detent the no. 5 codebar alternately in the marking and spacing position.

Requirement

The clutch shoe lever should engage the marking and spacing stop surfaces of the trip slide by approximately equal amount when the no. 5 codebar is detented to each position.

To Adjust

Position the trip slide arm operating arm by rotating the eccentric.



2.25 Positioning Mechanism (continued)

TYPEBOX RACK AND PINION

To Check


Take up play between typebox rack and pinion.

Requirement

Some---to---0.003 inch clearance between the typebox rack and its roller. This requirement applies to both racks.

To Adjust

Position the guide lever at its pry point with its clamp screw loosened.



2.26 Function Mechanism (continued)

TAPE MARGIN

To Check

Hold the tape against the rear edge of the tape guide.


Requirement

The margin between the top edge of the tape and the top edge of the letter T

Min 0.170 inch---Max 0.210 inch (Min 11/64 inch---Max 7/32 inch)

To Adjust

Position the mounting bracket by means of the eccentric with the bracket mounting screws loosened.



(LEFT SIDE VIEW)

TAPE CHUTE BRACKET

ECCENTRIC

MOUNTING SCREWS

TAPE

TAPE CHUTE

(RIGHT SIDE VIEW)


TAPE FEED - RIBBON FEED CAM FOLLOWER SPRING

To Check

Unhook the function cam follower spring from its bracket.

Requirement

Min 18 oz---Max 23 oz
to pull spring to installed length.



SPRING

TAPE FEED
CAM FOLLOWER

CAM

2.27 Function Mechanism (continued)

TAPE FEED PAWL SPRING

To Check

Place unit in stop position with typebox rail toward rear (no. 5 codebar marking).

Requirement

Min 2 oz---Max 3 oz to start lever moving.


TAPE FEED RATCHET DETENT

To Check

Place unit in stop position with typebox rail toward the front (no. 5 codebar spacing).

Requirement

Min 5 oz---Max 7 oz to start the detent lever moving.



TAPE FEED WHEEL DETENT

To Check

Trip codebar clutch, rotate main shaft until feed pawl just contacts ratchet tooth. Step feed shaft to detented position. Rotate main shaft until feed pawl is in lowest position.

Requirement

Feed pawl should advance feed ratchet one full tooth with minimum perceptible overtravel beyond fully detented position.


To Adjust

Position detent by rotating the detent eccentric. Keep high part of eccentric to left of center.

Note: If necessary, loosen clamp screw on feed arm hub and take up play in hole to favor adjustment.

2.28 Function Mechanism (continued)


PRESSURE ROLLER SPRING TENSION



TAPE FEED WHEEL CENTERING

Requirement
The tape feed wheel should be centered within the tape chute opening, as gauged by eye.

To Adjust
Position the feed wheel on its shaft with its clamp screw loosened.



2.29 Function Mechanism (continued)

RIBBON FEED MECHANISM DRIVE SLIDE

To Check

Place ribbon feed cam follower on high part of function cam.

Requirement

Some clearance between the blocking edge of the ribbon reverse arm and the reversing extension of the feed pawl when the ribbon is moved under the lower reversing extension of the feed pawl. The feed pawl should not feed more than two teeth. This applies to both upper and lower feed pawl extensions.

To Adjust

Position adjusting plate with clamp screw loosened.

RIBBON RATCHET WHEEL TORSION

Requirement

Min 1 oz---Max 3 oz
to start ratchet wheel moving

FEED PAWL SPRING

Requirement

Min 4 oz---Max 6 oz
to pull spring to
installed length.


DETENT SPRING

To Check

Place detent in either
fully detented position.

Requirement

Min 2 oz---Max 4 oz
to pull spring to
installed length



(RIGHT SIDE VIEW)

2.30 Positioning Mechanism (continued)
and Function Mechanism (continued)


TYPEBOX ALIGNMENT (FRONT TO REAR)

To Check

Select no. 5 and 6 codebars marking, and place unit in stop position. Push Figures print hammer down against pallet stem.

Requirement

Print hammer should be centered (front to rear) on the extreme outer left hand pallet, as gauged by eye.



PRINT HAMMER HEAD SPRING

To Check


Place unit in stop position.

Requirement

Min 2 oz---Max 3 oz to start hammer head moving.

To Adjust

Position the typebox rail with two clamp screws on the eccentric follower lever of the typebox rail positioning clutch.



2.31 Positioning Mechanism (continued)

TYPEBOX ALIGNMENT (TRANSVERSE)

To Check

Under power, select rubout (1, 2, 3, 4, 5, 6 marking) followed by E (1 marking). Push print hammer straight downward.

(1) Requirement

The print hammer should be centered on the stem of the E type pallet. Gauged by eye.

To Adjust

Rotate the eccentric on the typebox positioning link.

To Check

Under power, select rubout followed by selection of 5 (1 and 6 marking). Push figures print hammer straight downward.


(2) Requirement

Print hammer should be centered on stem of 5 type pallet.


To Adjust

Loosen the two plunger guide mounting screws and position the guide by pivoting it around its left mounting screws.


Note: Both hammers must engage their respective type pallet stems fully. Refine adjustments if necessary. Recheck PRINT HAMMER TRIP LEVER.




2.32 Positioning Mechanism (continued)



(TOP VIEW)



TURN ADJUSTING SCREW
COUNTERCLOCKWISE



TURN ADJUSTING SCREW
CLOCKWISE

CHARACTER ALIGNMENT

To Check

Select two character code combinations
"E" and "Z."

Requirement

Characters should be in line within
Max 0.008 inch.

To Adjust


Position the eccentric on the typebox rail drive arm so that the slot is aligned vertically and the large chamfer on its head is facing upward. Under power, select "E" code combination (no. 1 codebar marking) and "Z" code combination (no. 1 and 5 codebars marking). If E is higher than Z, turn the eccentric screw clockwise. If Z is higher than E, turn the eccentric screw counterclockwise. Recheck TYPEBOX ALIGNMENT (FRONT TO REAR).

2.33 Positioning Mechanism (continued)

TYPEBOX CARRIAGE ROLLER ARM SPRING

Requirement

Min 18 oz---Max 23 oz
to start front roller nearest typebox
latch moving away from carriage track.



TYPEBOX ALIGNMENT

Requirement

The impression printed by a type pallet should be equal at the top and bottom of the characters, as gauged by eye.

To Adjust

Position the typebox carriage so that the adjusting screw is accessible. Loosen its lock nut. Operate the printer with the character code combinations "E" and "7/8." If the impression at the top of the character is light, turn the screw in. If the impression at the bottom of the character is light, turn the screw out.

Note: If necessary, reposition the tape chute mounting bracket with its mounting screws loosened. See TAPE MARGIN adjustment.