

33 KEYBOARD

LUBRICATION

CONTENTS	PAGE
1. GENERAL.	1
2. BASIC UNIT	2
Auxiliary contact block	4
Codebar mechanism	5
Contact block.	4
CTRL keylever	4
HERE IS, BREAK, and REPT keylevers	3
Keyboard	2
Keylevers	3
Latchlever hooks	5
Numeric keyboard (cover removed) . .	6
Numeric keylevers	7
Reset bail	5
Spacebar	3
SPACE, BLOCK, and O keylevers . .	7
Universal lever	6

1. GENERAL

1.01 This section provides lubrication requirements for the 33 keyboard. It is reissued to provide exclusive eight level keyboard coverage and incorporate engineering changes and additions. Since this is a general revision, marginal arrows used to indicate changes are omitted.

1.02 The general lubrication areas are illustrated by photographs. The specific points to receive lubricant are indicated on line drawings with appropriate textual instructions. The line drawings and textual instructions follow a photograph and are keyed to the photograph by paragraph numbers.

1.03 Thoroughly lubricate the keyboard, but avoid overlubrication that might permit the lubricant to drip or be thrown onto adjacent parts.

1.04 Lubricate the keyboard before placing it into service or prior to storage. After a short period of service, relubricate it to make sure no areas have been missed. Thereafter, lubricate the keyboard at regular intervals as indicated:

<u>Operating Speed</u> (Words per Minute)	<u>Lubrication</u> <u>Interval</u>
100	500 hours* or 6 months**

*Station set operating hours.
 **Whichever comes first.

1.05 The textual instructions that accompany each line drawing consist of abbreviated directions, specific lubrication points, and parts affected. The meanings of the abbreviated directions (symbols) are given below:

<u>Symbol</u>	<u>Meaning</u>
D	Keep dry -- no lubricant permitted.
O	Oil (KS7470).
G	Apply thin coat of grease (KS7471).

1.06 References to left, right, front, or rear, etc, consider the keyboard to be viewed from a position where the spacebar faces up and the contact mechanism is located to the viewer's right.

CAUTION: DO NOT USE ALCOHOL, MINERAL SPIRITS, OR OTHER SOLVENTS TO CLEAN PLASTIC PARTS OR PARTS WITH PROTECTIVE-DECORATIVE FINISHES. NORMALLY, A SOFT, DRY CLOTH SHOULD BE USED TO REMOVE DUST, OIL, GREASE, OR OTHERWISE CLEAN PARTS OR SUBASSEMBLIES. IF NECESSARY, A SOFT CLOTH

DAMPENED WITH SOAP OR MILD DETERGENT MAY BE USED. RINSE WITH A SOFT, DAMP CLOTH AND BUFF WITH A SOFT, DRY CLOTH.


1.08 Disassembly and reassembly Instructions are given in Section 574-121-702TC.

1.07 Materials needed for lubrication are listed in Section 570-005-800TC.

CAUTION: REMOVE ALL ELECTRICAL POWER FROM UNIT BEFORE LUBRICATION OR DISASSEMBLY.

2. BASIC UNIT


2.01 Keyboard




(Right Front View
Cover Removed)

(Left Front View)


2.02 Keylevers




2.03 Spacebar



2.04 HERE IS, BREAK, and REPT Keylevers




2.05 CTRL Keylever



D	Top Surface	Keytop
O	Seat (Each End)	Spring

(Left Front View)

2.06 Contact Block




D	Contact Surface	Contact Wires
D	Springs	Contact Wires
D	Contact Surface	Contact Wires
O	Seat	Springs (2)

(Front Views)

CAUTION: DO NOT CLEAN THE KEYBOARD CONTACT BLOCK WITH ALCOHOL, MINERAL SPIRITS, OR OTHER SOLVENTS.


2.07 Auxiliary Contact Block



D	Contact Surfaces	Contact Wires
D	Springs	Contact Wires
D	Contact Surface	Contact Wires


(Front View)

2.08 Latchlever Hooks



- O Hooks (Each End) Latchlever Spring
- O Pivot Latchlever and Nonrepeat Lever
- O Contact Surface Latchlever
- O Hooks (Each End) Nonrepeat Spring


2.09 Reset Bail



- G* Contact Surface Universal Lever
- O Pivots (2) Reset Bail
- G* Camming Surface Reset Bail
- O Hooks (Each End) Bail Spring


*At 1500 hour lubrication intervals, apply a coat of thoroughly mixed 50 percent KS7470 oil and 50 percent KS7471 grease.

2.10 Codebar Mechanism



- O Pivots T-Levers
- O Contact Surface Universal Link
- O Hooks (Each End) Link Spring


2.11 Universal Lever



- O Engaging Tabs H-Lever
- O Pivot Universal Lever
- O Engaging Surfaces Universal Lever
- O Hooks (Each End) Spring


(Right Side View)

2.12 Numeric Keyboard (Cover Removed)



(Right Front View)


2.13 SPACE, BLOCK, and O Keylevers



Top Surface	Keytop
Seat (Each End)	Spring
Contact Surface	Keylever Springs

(Right Side View)

2.14 Numeric Keylevers



Top Surface	Keytops
Seat (Each End)	Spring
Contact Surface	Keylever Springs

(Right Side View)