

35 TRANSMITTER-DISTRIBUTOR (MULTICONTRACT)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL . . . . .	2	Pusher stripper bail spring . . . . .	29
2. BASIC UNIT . . . . .	3	Push lever . . . . .	29
Cam Shafts		Push lever spring . . . . .	31
Cam shaft bearing retainer . . . . .	4	Sensing Pin Assembly	
Cam sleeve endplay . . . . .	4	Sensing bail springs . . . . .	26
Idler gear assembly . . . . .	4	Sensing pin . . . . .	26
Clutch Mechanism		Sensing pin springs . . . . .	26
Clutch shoe lever . . . . .	7	Start-Stop Switch Assembly	
Clutch shoe lever spring . . . . .	3	Control lever switch bracket . . . . .	24
Clutch shoe spring . . . . .	3	Start-stop bail yield spring . . . . .	24
Clutch trip lever upper extension . . . . .	7	Tape Feed Mechanism	
Clutch Trip Mechanism		Feed pawl . . . . .	28
Armature bail spring . . . . .	5	Feed pawl spring . . . . .	28
Clutch armature air gap . . . . .	5	Feed ratchet detent spring . . . . .	27
Clutch latchlever spring . . . . .	6	Feed wheel detent . . . . .	27
Clutch trip assembly mounting plate . . . . .	5	Tape Guideplate	
Clutch trip lever spring . . . . .	6	Tape guide . . . . .	19
Magnet bracket . . . . .	6	Tape guideplate . . . . .	19
Cover and Panel Assembly		Tape Lid Mechanism	
Coverplate . . . . .	32	Tape lid . . . . .	17
Front panel . . . . .	32	Tape lid release plunger spring . . . . .	18
Distributor Contact Mechanism		Tape lid spring . . . . .	18
Cam follower guide . . . . .	8	Start-stop lever detent spring . . . . .	18
Cam follower lever spring . . . . .	8	Tape-Out and Tape Lid Pin Mechanism	
Distributor block assembly . . . . .	10	Tape lid pin . . . . .	35
Distributor contact gap . . . . .	10	Tape lid pin spring . . . . .	35
Distributor cover bracket positioning . . . . .	11	Tape-out and tape lid pin downstop . . . . .	34
Distributor rocker compression spring . . . . .	9	Tape-out and tape lid switch bracket . . . . .	34
Distributor rocker spring . . . . .	9	Tape-out pin spring bracket . . . . .	34
Feed Lever Mechanism		Tape-Out and Tape Lid Switch Assembly	
Feed lever set collar . . . . .	12	Instructions for removing tape-out and tape lid switch assembly . . . . .	33
Feed lever spring . . . . .	12	Tape-out and tape lid switch . . . . .	33
Sensing Mechanism		Tape-Out Switch Assembly	
Auxiliary lever spring . . . . .	29	Tape-out bail yield spring . . . . .	23
Latchlever spring . . . . .	31	Tape-out extension bail spring . . . . .	23
Latch stripper bail spring . . . . .	30		
Oil reservoir . . . . .	30		

CONTENTS	PAGE
Tape-out pin . . . . .	22
Tape-out pin spring . . . . .	23
Tape-out switch . . . . .	21
Tape-out switch bracket . . . . .	22
Tight-Tape Mechanism	
Tight-tape arm . . . . .	25
Tight-tape bail yield spring . . . . .	25
Tight-tape, control lever switch . . . . .	25
Top Plate Assembly	
Top plate . . . . .	20
Transfer Type Storing Switch Mechanism	
Instructions for replacing and positioning storing switch assembly (transfer type) . . . . .	
	15
Normally closed contact backstop . . . . .	13
Normally closed contact spring . . . . .	13
Normally open contact gap . . . . .	14
Normally open contact spring . . . . .	14
Slide lever . . . . .	16
Slide lever spring . . . . .	16
Storing switch assembly . . . . .	15
Swinger spring . . . . .	13
3. CONTACT STROBING . . . . .	36
Distributor Contacts	
Contacts #0 - #7 . . . . .	36
Contacts #1 - #8 . . . . .	40
Distributor auxiliary contact . . . . .	37, 40
Final operating requirements . . . . .	39, 40
Sensing auxiliary contacts . . . . .	38, 40
Stop contact . . . . .	36, 40
Transmitter contacts . . . . .	38, 40
1. GENERAL	
1.01 This section provides adjustments and requirements for the 35 transmitter-distributor (multicontact). The section has been revised to include recent engineering changes and additions and to rearrange the text. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions are omitted.	
1.02 The adjustments are arranged in a sequence that should be followed if a complete readjustment is undertaken. A complete adjusting procedure should be read before attempting to make the adjustment. After an ad-	

justment is completed, be sure to tighten any nuts or screws that may have been loosened, unless otherwise instructed.

1.03 The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angle at which scales should be applied. The tools required to make adjustments and check spring tensions are not supplied with the equipment, but are listed in Section 570-005-800. Springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced by new springs.

1.04 When rotating the drive shaft gear by hand, the rotation is counterclockwise as viewed from the exposed side of the drive shaft gear.

1.05 When the requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch lever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

Note: When rotating either the sensing or distributor shaft by hand, the respective clutch may not fully disengage upon reaching its stop position. To disengage the clutch, rotate the clutch to its stop position, apply a screwdriver to the cam disc stop-lug, and move the disc in the normal direction of the shaft rotation until the latch lever seats in its notch in the disc.

1.06 The covers may be removed for inspection and minor repair of the unit. However, when more extensive maintenance is to be undertaken, it is recommended that the unit be removed from its subbase to disconnect the power and to permit it to be inverted.


1.07 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 percent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustment tolerance measurement. Avoid sharp kinks or bends in the contact springs.

Note: Keep all electrical contacts free of oil and grease.

1.08 References made to left or right, up or down, front or rear, etc, apply to the unit in its normal operating position as viewed from the operator position in front of the unit.

2. BASIC UNIT

2.01 Clutch Mechanism




(A) CLUTCH SHOE LEVER SPRING

Requirement

Clutch engaged and cam disc held to prevent turning. Scale pulled at tangent to clutch.

Min 15 oz---Max 20 oz to move clutch shoe lever in contact with stop-lug.

Note: Requirements (A) and (B) are adjusted at the factory and should not be disturbed unless associated mechanisms have been removed for servicing or there is reason to believe that the requirements are not met. Requirements (A) and (B) apply to both the sensing clutch and distributor clutch.



(B) CLUTCH SHOE SPRING

Note: It is necessary to remove the clutch from the main shaft to facilitate this check.

Requirement

Clutch drum removed. Scale applied to primary shoe at a tangent to the friction surface.

Min 3 oz---Max 5 oz to start primary shoe moving away from secondary shoe at point of contact.

2.02 Cam Shafts

Note: The following adjustments apply to both the distributor and sensing cam sleeves. These mechanisms should not be disturbed unless there is reason to believe the requirements are not met.

(A) CAM SLEEVE ENDPLAY


Note: Make this adjustment prior to assembling gear.

Requirement

Min some---Max 0.010 inch play between sleeve and spacer.

To Adjust

Remove clutch drum drive gear and loosen drum mounting screw. Release clutch and position cam sleeve. Tighten cam sleeve mounting screw and reinstall drive gear.



(C) IDLER GEAR ASSEMBLY


Requirement

Clearance between idler gear and sensing shaft gear and between idler gear and distributor shaft gear at point where backlash is minimum

Min some---Max 0.003 inch

To Adjust

Position idler gear assembly with locknut loosened. Recheck gear play through one revolution of gears.




(B) CAM SHAFT BEARING RETAINER

Requirement

When mounting shaft assembly, bearing should seat properly. (No clearance permissible between bearing and mounting surface.)

To Adjust

Rotate bearing retainer 180 degrees and position by pushing downward firmly.



2.03 Clutch Trip Mechanism

Note: Adjustments apply to both clutch trip mechanisms.


(A) CLUTCH ARMATURE AIR GAP

**Requirement**

Air gap between armature and magnet assembly bracket should be  
 Min 0.004 inch---Max 0.008 inch  
 with armature flush against magnet core.

**To Adjust**

Remove armature extension spring.  
 Position hinge with spring post and hinge mounting screw loosened.  
 Recheck air gap and replace spring.




(B) CLUTCH TRIP ASSEMBLY MOUNTING PLATE

**Requirement**

Clearance between end of armature bail and latching surface of clutch trip lever lower extension with clutch trip lever reset extension on high part of cam  
 Min 0.020 inch---  
 Max 0.030 inch  
 (Take up play in parts for minimum clearance.)

**To Adjust**


Position plate with screwdriver in lower adjusting slot with plate adjusting screw and plate mounting screw loosened. (Take up play in trip lever in direction of cam.)



(C) ARMATURE BAIL SPRING

**Requirement**

Trip lever reset extension on high part of cam. Scale applied to latching end of armature bail  
 Min 3 oz---Max 4-1/2 oz  
 to start armature bail moving.



2.04 Clutch Trip Mechanism (continued)


Note: Refer to adjustments in 2.03.

(A) CLUTCH LATCHLEVER SPRING

Requirement

Clutch latchlever on low part of clutch disc and unit upright. Scale applied to bent ear of latchlever horizontally.

Min 2-1/2 oz---Max 4-1/2 oz to start latchlever moving.



(B) CLUTCH TRIP LEVER SPRING

Requirement

With clutch just tripped, hold armature against core. Scale applied to trip lever lower extension in line with spring.

Min 2 oz---Max 3-1/2 oz to start trip lever lower extension moving.

(C) MAGNET BRACKET


Requirement

Clearance between armature bail and top edge of trip lever lower extension with clutch trip lever reset extension on high part of cam and armature flush against core

Min 0.030 inch---Max 0.040 inch  
(Take up play for minimum clearance.)

To Adjust

With bracket mounting screw and clamp screw loosened, insert screwdriver in upper slot and pivot bracket.



2.05 Clutch Mechanism (continued)

Note: Adjustments (A) and (B) apply to both clutches.


(A) CLUTCH TRIP LEVER UPPER EXTENSION

- (1) Requirement  
Clutch trip lever latched (Clutch in stop position). Clutch trip lever upper extension should fully engage clutch shoe lever.

To Adjust  
Position upper extension, with clutch trip lever clamping screw loosened.

- (2) Requirement  
With armature in attracted position, there should be some clearance between clutch trip lever upper extension and stop-lug when clutch is rotated to make clearance a minimum.

To Adjust  
Refine requirement (1), if necessary, so that clutch trip lever upper extension is under or over flush with stop-lug by not more than 0.015 inch.




(B) CLUTCH SHOE LEVER

- (1) To Check  
Disengage clutch. Measure clearance.
- (2) To Check  
Align head of clutch drum mounting screw with stop-lug. Engage clutch. Manually press shoe lever and stop-lug together and allow to snap apart. Measure clearance.

Requirement  
Clearance between shoe lever and stop-lug  
Min 0.055 inch---Max 0.085 inch greater when clutch engaged (2) than when disengaged (1).

To Adjust  
Engage wrench or screwdriver with lug on adjusting disc. Rotate disc with clamp screws loosened.



(Top View)


2.06 Distributor Contact Mechanism

Note: Remove oil reservoir and distributor block assembly to facilitate adjustment.

(A) CAM FOLLOWER GUIDE

- (1) Requirement  
Center cam follower engages cam by full thickness of follower when moved from side to side in its guide slot.
- (2) Requirement  
In manner similar to requirement (1), other follower should engage cam by at least 75 percent of follower thickness.
- (3) Requirement  
All followers should move freely in their guide slots.

To Adjust  
Position cam follower guide with its mounting screws loosened.



(B) CAM FOLLOWER LEVER SPRING

- Requirement  
Cam follower lever on high part of cam. Scale applied just below sliding surface of lever horizontally.  
Min 1/2 oz---Max 1-1/2 oz  
to start each lever moving.

## 2.07 Distributor Contact Mechanism (continued)


**(A) DISTRIBUTOR ROCKER SPRING****To Check**

Position each contact screw so its contact surface is about 1/32 inch from edge of block.

**Requirement**

With compression springs removed, hold distributor block in horizontal position. Push spring scale downward (vertically).

Min 3-1/2 oz---Max 4-1/2 oz  
to separate contacts.

**(B) DISTRIBUTOR ROCKER COMPRESSION SPRINGS****Requirement**

With compression springs installed, and block in a horizontal position, apply spring scale at lower end of rocker and push downward.

Min 6-1/2 oz---Max 9-1/2 oz  
to separate contacts.

2.08 Distributor Contact Mechanism (continued)

(D) DISTRIBUTOR CONTACT GAP


Requirement

With cam follower on high part of cam, contact gap should be

Min 0.020 inch---Max 0.030 inch

To Adjust

Trip clutch manually to position cam.  
Turn contact screw to adjust. Check all contacts.



(C) DISTRIBUTOR BLOCK ASSEMBLY

Requirement

Rockers should fully engage insulated portions of respective cam follower levers.

To Adjust

Position distributor or block with mounting screws loosened.

Note: For refinement of distributor adjustments, refer to Part 3, CONTACT STROBING.

2.09 Distributor Contact Mechanism (continued)

DISTRIBUTOR COVER BRACKET POSITIONING

To Check

With the cover held flat against the top of the distributor block so that the right side is vertical as gauged by eye.

Requirement


Manually rotate the distributor shaft and check the two outermost cam follower levers.

Min 0.025 inch---Max 0.040 inch clearance between cover and levers measured at closest point when levers are on high part of their cams.

To Adjust


Position the cover bracket with its mounting screws friction tight.

Note: Distributor contacts can be serviced without disturbing this adjustment by removing cover from bracket.



2.10 Feed Lever Mechanism

(A) FEED LEVER SET COLLAR



(Top View)

Requirement

Clearance between feed lever and collar should be  
 Min some---Max 0.015 inch  
 when feed lever is free in its guide slot.

To Adjust

Position feed lever with set collar screws loosened. Feed lever should move freely without binding at guide or collars.

Note: After tightening setscrews, recheck adjustment for binds between feed lever and collars, and between feed lever and guide.


(B) FEED LEVER SPRING

To Check

Rotate sensing shaft until clutch is in stop position.

Requirement

Min 10 oz---Max 17 oz  
 to move feed lever away from cam.




(Front View)

Note: This adjustment is made with the feed lever cam follower roller on the low part of the sensing cam.

2.11 Transfer Type Storing Switch Mechanism

Note: The following five adjustments (A thru E) are to be made with the contact assemblies removed from the unit. Use a TP172060 adjusting tool to bend the contacts. For each adjustment start with the contact pile-up farthest from the handle of the bending tool to avoid disturbing completed adjustments.




(B) NORMALLY CLOSED CONTACT SPRING

Requirement  
With swinger contact held away  
Min 2 oz---Max 6 oz  
to move each normally closed leaf away from backstop.

To Adjust  
Bend normally closed leaf spring.


Note: To increase tension of normally closed leaf, it may be necessary to bend backstop away from leaf, bend leaf, and then remake adjustment (A).





(C) SWINGER SPRING

Requirement  
Min 35 grams---Max 50 grams  
to open normally closed contact.

To Adjust  
Bend swinger leaf.



2.12 Transfer Type Storing Switch Mechanism (continued)



Note: To increase tension of normally open leaf spring, it may be necessary to bend backstop away from leaf, bend leaf, and then remake adjustment (D).

## 2.13 Transfer Type Storing Switch Mechanism (continued)

INSTRUCTIONS FOR REPLACING AND POSITIONING STORING SWITCH ASSEMBLY  
(TRANSFER TYPE)

Place switch assembly on lower surface of main casting. Exercise care in seating slide levers against pusher levers and latchlevers in appropriate slot of slide lever guide.

STORING SWITCH ASSEMBLY


## Requirement

With top plate in place, select a RUBOUT-NULL-RUBOUT combination and observe latch and pusher lever action. Storing switch should align with latchlever so that latchlevers and slides function without binding.


## To Adjust

Position switch assembly with its mounting screws loosened. Recheck requirement after tightening screws.

Note: A minor adjustment of the sensing pin and pusher lever guide may be necessary.



2.14 Transfer Type Storing Switch Mechanism (continued)



SLIDE LEVER

To Check


Storing switch assembly installed (see 2.13).  
Sensing slides selected and latched.

Requirement

Clearance between all sensing slides and  
contact swingers should be  
Min 0.005 inch---Max 0.020 inch

To Adjust

Loosen mounting bar locknuts and bracket  
mounting screws to friction tight. Insert  
a hex wrench in end of contact assembly  
mounting bar. Position contact assembly  
by rotating bar to pivot contact assembly.  
Check at all swingers.




SLIDE LEVER SPRING

To Check

Place slide levers in uppermost position  
(NULL selected, latches stripped).  
Hook spring scale in the spring loop.

Requirement

Min 6 oz---Max 9 oz  
to pull each spring to its installed  
length.



## 2.15 Tape Lid Mechanism

TAPE LID

Note: Remove top and tape guideplates. Lubricate mating surfaces prior to adjustment.

## (1) Requirement

Clearance between pivot shoulder and tape lid should be


Min some---Max 0.010 inch

when lid is pressed against notch in tape guideplate, and feed wheel slots and tape-out pin holes are lined up.

## To Adjust

Loosen tape lid bracket mounting nuts. Using a TP156743 gauge, line up feed wheel groove in tape lid with slot in tape guideplate. Position tape lid bracket to meet requirement. Tighten nuts.

## (2) Requirement - (See 2.16).



## (3) Requirement

Some endplay in release plunger when lid is latched against tape guideplate.

## To Adjust

With eccentric mounting post nut friction tight and tape lid raised, rotate high part of eccentric post towards mounting bracket. Close tape lid. Rotate eccentric counter-clockwise (as viewed from slotted end of eccentric post) until flat of latch post fully engages latch bail flat. Rotate eccentric clockwise to take up all play in parts, and to seat open end of tape lid against tape guideplate.

## To Check

With tape lid held down manually, latch tip should clear latch post when release button is operated. With tape lid latched, tip of latch should project beyond flat of latch post, and there should be some endplay in release button.

2.16 Tape Lid Mechanism (continued)

TAPE LID (continued)

(2) Requirement


With tape lid front bearing surface touching tape guideplate, clearance between tape lid and tape guideplate should be  
 — Min 0.010 inch---Max 0.018 inch  
 measured at tape lid fin in line with rear tape guide (second fin from rear).

Note: When both top and tape guideplates are assembled on unit, left edge of lid may touch top plate and some change in this clearance may be expected.

To Adjust

With tape lid bearing bracket mounting screws friction tight, and tape lid pressed against tape guideplate, position bearing bracket. Recheck requirement (1).

(1) and (3) requirements - (See 2.15).




TAPE LID SPRING

To Check

Open tape lid. Hold unit so tape guideplate is horizontal. Apply scale at top of lid immediately left of tape-out pin hole. Hold plunger fully depressed.

Requirement

— Min 3-1/2 oz---Max 4-1/2 oz  
 to move open end of tape lid against tape guideplate.



START-STOP LEVER DETENT SPRING

To Check

Place start-stop lever in run position.

Requirement

— Min 14 oz---Max 22 oz  
 to start detent bail moving away from control lever detent.

TAPE LID RELEASE PLUNGER SPRING


To Check

Hold tape guideplate so top surface is horizontal. Open tape lid.

Requirement

— Min 28 oz---Max 48 oz  
 to start tape lid bail moving.

2.17 Tape Guideplate



TAPE GUIDE

Requirement

With gauge properly positioned  
Min some---Max 0.003 inch  
between gauge and tape guides.

To Adjust

Loosen tape guide mounting nuts to friction tight. Properly position gauge on tape guideplate. Position tape guides to meet requirement.

TAPE GUIDEPLATE

(1) Requirement

Shoulder of feed wheel post should not interfere with top plate or tape guideplate mounting brackets.

To Adjust

Rotate feed wheel post with its mounting nut loosened.

(2) Requirement

Tape guideplate should rest firmly against at least three projections of the front and rear plate.

To Adjust


With tape-out downstop in its lowermost position, and tape guideplate mounting bracket (front and rear) nuts friction tight, trip clutch and rotate shaft until sensing pins are in their uppermost position. With tape lid raised and start-stop lever in run position, press tape guideplate into position. Guide mounting screws into notch of front and rear plate, and place sensing pins adjacent to left edge of guideplate. Place tape-out pin into its hole. Tighten each bracket mounting.

(3) Requirement

Outer edges of mounting brackets and outer edges of mounting stud shoulders should align and project equally on front and rear brackets.

To Adjust

Move tape guideplate toward front or rear. Tighten nuts only after TOP PLATE (2.18) is adjusted.



2.18 Top Plate Assembly

TOP PLATE

(1) Requirement

Top plate flush to 0.003 inch under flush with tape guideplate within width of tape lid.

To Adjust


Loosen mounting bracket nuts until brackets are friction tight. Press top plate into position. Top plate should rest on at least three projections of side plates. Make sure the tight-tape arm extension is under the top plate.

(2) Requirement

Feed wheel slot and tape guide plate slot should line up.

To Adjust

Move top plate to line up feed wheel slot. Do not disturb requirement (2) of TAPE GUIDEPLATE (2.17) adjustment.



(Front View)

(3) Requirement

With tape lid latched, clearance between tape lid extension covering feed wheel slot and top plate should be

Min 0.010 inch---Max 0.020 inch

measured at curved portion of top plate and

Min 0.010 inch---Max 0.025 inch

measured at flat portion of top plate. Also, clearance between tape lid and tape guideplate should be

Min 0.010 inch---Max 0.018 inch

measured in area between tape guides (play in tape lid taken up toward tape guideplate).

To Adjust

Loosen two screws holding tape lid mounting brackets together and position tape lid. Recheck TAPE LID (2.15) adjustment, requirements (1) and (2).

## 2.19 Tape-Out Switch Assembly

(A) TAPE-OUT SWITCH

## To Check


Remove cover and top plate. Loosen tape-out spring adjusting bracket. Position bracket so tape-out extension is not touching swinger pad.

## (1) Requirement

Min 8 grams---Max 15 grams  
to just separate normally closed contacts (scale at center of swinger pad).

## To Adjust

Disconnect tape-out extension bail.  
Remove switch assembly (see 2.30).  
Form contact swinger with a  
TP110445 spring bender.



## (2) Requirement

Min 0.008 inch---Max 0.015 inch  
clearance between normally open contacts.

## To Adjust

Form upper contact leaf with a  
TP110445 spring bender.

Note: When replacing switch assembly, make sure contact swinger is over tape-out pin extension, and extension bail spring clip is kept horizontal.

2.20 Tape-Out Switch Assembly (continued)

(B) TAPE-OUT PIN

(1) Requirement

When start-stop lever is in free wheel or stop position, tape-out should be flush to 0.010 inch below surface of tape guideplate.

To Adjust


Position tape-out pin down-stop with its mounting nut loosened. Refer to adjustments in 2.21, Tape-Out Switch Assembly.

(2) Requirement

With control lever in run position  
Min 0.055 inch clearance between tape-out pin extension and control lever bail extension.

To Adjust

Position extension bail with its spring post screw loosened. Tighten spring post screw. Refer to adjustments in 2.21, Tape-Out Switch Assembly.



(C) TAPE-OUT SWITCH BRACKET

To Check

Insert piece of unperforated tape under tape lid.

Requirement

Min 0.006 inch---Max 0.020 inch clearance between tape-out pin extension and contact swinger pad.

To Adjust


Position switch bracket with its mounting screw loosened. Refer to adjustments in 2.21, Tape-Out Switch Assembly.

2.21 Tape-Out Switch Assembly (continued)

(A) TAPE-OUT BAIL YIELD SPRING

To Check  
Place start-stop lever in run position.


Requirement  
Min 3 oz ---Max 5 oz  
to separate bails.



(B) TAPE OUT EXTENSION BAIL SPRING

To Check  
Place start-stop lever in run position.

Requirement  
Min 1 oz ---Max 2-1/2 oz  
to start bail moving.




(C) TAPE-OUT PIN SPRING

To Check  
Place start-stop lever in run position.

Requirement  
Min 38 grams ---Max 45 grams  
to move pin flush with tape guideplate.

To Adjust  
Position spring bracket with its  
mounting screws loosened. Recheck  
requirement.




2.22 Start-Stop Switch Assembly

START-STOP BAIL YIELD SPRING

To Check  
Place start-stop lever in run position.

Requirement  
Min 4 oz ---Max 6 oz  
to separate bails.



(Front View)


CONTROL LEVER SWITCH BRACKET

(1) Requirement  
With start-stop lever in run position  
Min 0.006 inch ---Max 0.015 inch  
clearance between switch actuator and  
bakelite pad on swinger.

(2) Requirement  
Start-stop lever and tight-tape switch  
actuators should fully engage bakelite  
pad on swinger.


To Adjust  
Position switch bracket with its mount-  
ing screws loosened.

Note: If tight-tape switch actuator  
rests against bakelite pad, hold  
actuator away.



(Front View)

2.23 Tight-Tape Mechanism



(A) TIGHT-TAPE, CONTROL LEVER SWITCH

(2) Requirement  
 With start-stop lever in run position  
 Min 0.050 inch  
 Max 0.070 inch  
 clearance between switch backstop and bakelite pad on swinger when switch contacts are closed.

To Adjust  
 Bend switch backstop with TP110445 spring bender.

Note: Make requirement (1) adjustment before assembling switch to unit.


(1) Requirement  
 Min 3 oz---Max 4 oz  
 to just separate contacts.

To Adjust  
 Bend contact swinger with a TP110455 spring bender.

(C) TIGHT-TAPE BAIL YIELD SPRING

To Check  
 Open tape lid. Operate start-stop lever to free-wheeling position.

Requirement  
 Min 2 oz---Max 3-1/2 oz  
 to separate bails.



(B) TIGHT TAPE ARM

To Check  
 Operate start-stop lever to run position.

Requirement  
 Tight-tape switch contacts should open when tight-tape arm is raised.  
 Min 0.090 inch---Max 0.120 inch  
 above tape guideplate.

To Adjust  
 With clamp screw friction tight, position bails, by means of pry point, to meet requirement.

2.24 Sensing Pin Assembly

(A) SENSING BAIL SPRINGS

To Check

Remove top plate. With blank tape under tape lid, trip clutch magnet and manually rotate shaft until sensing bail is in uppermost position. Apply scale to bail between springs.

Requirement

Min 1/4 oz---Max 2 oz to start bail moving.

(C) SENSING PIN

To Check


Replace top plate. Disengage sensing clutch.

Requirement

With sensing bail eccentric indent toward right, tip on highest sensing pin should be flush to 0.005 inch below top surface of tape guideplate.

To Adjust

Loosen eccentric shaft locknut and position eccentric. Recheck requirement after locknut is tightened.



(B) SENSING PIN SPRING


To Check

Trip sensing clutch and rotate shaft until sensing pins are in their uppermost position. Hold pusher levers away manually.

Requirement

Min 2 oz---Max 3 oz to move each pin flush with top surface of tape guideplate.

2.25 Tape Feed Mechanism



(A) FEED WHEEL DETENT

Note: Place start-stop lever in stop position.

To Check

Place a RUBOUT perforated tape over feed wheel, taking up play in feed holes toward the right.


Requirement

Sensing pins centrally located in code holes.

To Adjust

Position feed wheel detent eccentric with its lock screw friction tight. High part of eccentric should be toward right. Hold eccentric and tighten guidepost and lock screw. Recheck adjustment.

Note: Hold feed pawl away to facilitate adjustment.



(B) FEED RATCHET DETENT SPRING

Requirement

With feed pawl held away from ratchet wheel

Min 7 oz --- Max 13 oz to move detent roller away from fully detented position.

2.26 Tape Feed Mechanism (continued)

(B) FEED PAWL SPRING

To Check

Place start-stop lever in stop position.  
Remove top plate. Disengage clutch.

Requirement

Min 1/4 oz---Max 1-1/2 oz  
to start feed pawl moving.

(A) FEED PAWL

To Check


Place start-stop lever in run position.  
Remove top plate. Trip clutch, and  
rotate cam shaft until feed roller is on  
high part of cam. Rotate ratchet  
wheel until oil hole is up. Take up  
play by pressing down lightly on right  
end of feed pawl bail.

Requirement

Min some---Max 0.003 inch  
clearance between feed pawl and  
ratchet tooth.

To Adjust

Position feed lever by means of the  
adjusting slot with its locknut loosened.



2.27 Sensing Mechanism


(A) PUSHER STRIPPER BAIL SPRING

To Check

Select NULL combination. Trip clutch and rotate shaft to stop position.

Requirement

Min 7 oz --- Max 11 oz  
to start bail moving away from cam.




(C) AUXILIARY LEVER SPRING

To Check

Each auxiliary lever on low part of its cam. Scale applied to lever just right of spring. Pusher lever held away.

Requirement

Min 1/2 oz --- Max 3 oz  
to start auxiliary lever moving.



(B) PUSH LEVER

Requirement


With first one and then the other of the two auxiliary levers on the low part of the cam, the auxiliary lever with the least clearance should clear the tip of its push lever by

Min 0.020 inch --- Max 0.045 inch

To Adjust

With push lever eccentric shaft locknut (front plate) loosened and high part of eccentric located toward the upper right, rotate eccentric toward right or left.

2.28 Sensing Mechanism (continued)



(B) OIL RESERVOIR

Requirement

Each oil wick rests lightly on high parts of front and rear cam of each cam sleeve.

To Adjust

Trip both armatures and rotate shaft until high part of front and rear cam of each sleeve is under its wick. Position oil reservoir assembly with its mounting screws (4) loosened. When cam sleeve is rotated, teeth of wick retainer should not deflect upward more than 1/32 inch (gauge by eye). Refine adjustment by slightly bending teeth on wick comb spring.


(A) LATCH STRIPPER BAIL SPRING

To Check


Trip clutch, rotate shaft so latch bail follower roller is on low part of cam. Apply scale to top of latch stripper bail.

Requirement

Min 2-3/4 oz --- Max 6 oz to start latch stripper bail moving.



2.29 Sensing Mechanism (continued)



LATCHLEVER SPRING


To Check

Select NULL combination. Trip sensing clutch and rotate shaft to stop position. Slide levers should be in uppermost position.

Requirement

Min 1 oz---Max 3 oz to start latchlever moving.

Note: Take care not to damage push lever springs in checking requirement.



PUSH LEVER SPRING

To Check

Select RUBOUT combination, and latch sensing clutch. Trip clutch and rotate shaft until push levers are stripped.

Requirement

Min 1/4 oz---Max 1-1/2 oz to start push lever moving.

Note: Be sure contact slides do not interfere with movement of push levers.

2.30 Cover and Panel Assembly

(A) COVERPLATE

- (1) Requirement  
Coverplate held flush against top plate by detent action.
- (2) Requirement  
Coverplate rests on at least three side frame projections.
- (3) Requirement  
Front edge of cover and top plates in line.


To Adjust

Loosen detent nuts on side frames, and move them to extreme lower right position. Tighten nuts. Loosen four bracket mounting nuts on coverplate. Place cover into position, and position to meet requirements. Tighten nuts. Recheck and re-fine requirements.

(C) COVERPLATE DETENT SPRING

To Check  
Remove coverplate.

Requirement  
Min 28 oz ---  
Max 48 oz  
to start plunger moving.



(B) FRONT PANEL

Note: Remove coverplate prior to installing or removing front panel. Panel slides should engage guides on base so that top edge of panel passes under tape guideplate.

- (1) Requirement  
Front panel latches securely at lower right and left corners, and panel slides fully engage base guides.  
Min 0.085 inch --- Max 0.105 inch  
clearance between bottom edge of base rail and panel guide flange.

To Adjust

Remove transmitter from base. Use shims to obtain lateral position of panel slides, and position guides vertically (place unused shims under head of mounting screw). Replace transmitter on base.

- (2) Requirement  
Min 0.015 inch --- Max 0.060 inch  
clearance between panel top edge and front edge of cover and tape guideplates. The upper panel sides should not touch the cover and tape guideplate eaves.

To Adjust

With front panel in place, loosen panel guide mounting screws and position the guide. To facilitate adjustment, remove the four vibration mounting nuts and swing subbase away.

## 2.31 Tape-Out and Tape Lid Switch Assembly

Note: Make this adjustment before assembling switch to unit.

TAPE-OUT AND TAPE LID SWITCH

(1) Requirement

Min 8 grams---Max 15 grams  
to just separate normally closed contacts (apply scale to center of nylon pad).

To Adjust


Bend contact swinger with a TP110445 spring bender.

(2) Requirement

Min 0.008 inch---Max 0.015 inch  
gap between normally open contacts.

To Adjust

Bend upper contact leaf with a TP110445 spring bender.



INSTRUCTIONS FOR REMOVING TAPE-OUT AND TAPE LID SWITCH ASSEMBLY

Remove the cover and top plate. Remove the guide post at the top on which the switch assembly pivots. This is accomplished by removing the TP111342 spring and partially removing the screw that secures the post to the rear plate. Remove the nut and washer from the front end of the post. The post can now be removed far enough to release the switch assembly. Remove the adjusting screw from the lower end of the switch bracket. Withdraw the switch assembly, taking care not to distort the switch members. To replace the tape-out and tape lid switch assembly, reverse the procedure followed in removal. Take precaution not to disrupt the adjustments.

2.32 Tape-Out and Tape Lid Pin Mechanism

(B) TAPE-OUT PIN SPRING BRACKET

Requirement

Min 38 grams---Max 45 grams  
to depress tape-out pin until flush with  
tape guideplate.

To Adjust

Position tape-out pin spring bracket  
with its mounting screws friction tight.  
Tighten screws and recheck require-  
ment.

(A) TAPE-OUT AND TAPE LID SWITCH  
BRACKET

Requirement

Min 0.006 inch---Max 0.020 inch  
clearance between tape-out pin exten-  
sion and contact swinger insulator  
when tape-out pin is held down.

To Adjust

Insert a length of unperforated tape  
under tape lid. Adjust switch bracket  
with its mounting screw loosened.


(C) TAPE-OUT AND TAPE LID PIN DOWN-  
STOP

Requirement

When depressed to their lowermost  
positions, tape-out and tape lid pins  
should be flush to 0.005 inch below  
surface of tape guideplate.


To Adjust

Position respective downstop post with  
its mounting nut loosened.



(Front View)

2.33 Tape-Out and Tape Lid Pin Mechanism (continued)



3. CONTACT STROBING

3.01 Distributor Contacts

Note: Use a 7.42 unit code distortion test disc for checking all contacts. Refer to Paragraph 3.05 if an 11 unit distortion test set disc is available.

DISTRIBUTOR CONTACTS (See Figures 1 and 2)

(a) Stop Contact

- (1) With a Distortion Test Set (DXD) operating at the same speed as transmitter-distributor, load the unit with NULL perforated tape.
- (2) Adjust the stop contact adjusting screw so that stop pulse length is 135 scale divisions.




Figure 1

(b) Contacts #1 - #8

- (1) Load the transmitter-distributor with tape punched in levels 1, 3, 5, and 7. Align the end of the stop pulse with the 142 scale division on the stop segment of the test scale.
- (2) Adjust the distributor contact screws so that images are 67.5 scale divisions in total length, within  $\pm 3$  percent on each end.
- (3) Repeat the above procedures for levels 2, 4, 6, and 8.

Note: It may be necessary to hold stop contact open to determine length of #8 pulse.




Figure 2

3.02 Distributor Contacts (continued)

EIGHT-LEVEL PULSE IMAGE TRANSITION POINTS  
ON FIVE-LEVEL TEST SET SCALE - 11.00 UNIT CODE

CODE PULSE	END AT SCALE DIVISION	BEGIN AT SCALE DIVISION
STOP	7 IN STOP SEGMENT	142 IN STOP SEGMENT
1	67 IN START SEGMENT	35 IN #1 SEGMENT
2	35 IN #1 SEGMENT	2 IN #2 SEGMENT
3	2 IN #2 SEGMENT	70 IN #2 SEGMENT
4	70 IN #2 SEGMENT	37 IN #3 SEGMENT
5	37 IN #3 SEGMENT </td <td>5 IN #4 SEGMENT</td>	5 IN #4 SEGMENT
6	5 IN #4 SEGMENT	72 IN #4 SEGMENT
7	72 IN #4 SEGMENT	40 IN #5 SEGMENT
8	40 IN #5 SEGMENT	7 IN STOP SEGMENT

DISTRIBUTOR AUXILIARY CONTACT (See Figures 3 and 4)

- (a) Align end of stop pulse image with 142 mark on test scale stop segment. Adjust the auxiliary contact to:

Close at 110, +5 divisions in stop segment.  
Open at 31, +8 divisions in stop segment.




Figure 3

## 3.03 Distributor Contacts (continued)

- (b) Transmitter Contacts: With unit sensing RUBOUT tape, and end of stop pulse aligned with 142 mark on test scale stop segment, the beginning and end of each contact trace should occur:

Before 80 divisions in start segment.  
After 20 divisions in stop segment.

To adjust, position respective contact screw or refine transfer contact adjustments as necessary.




Figure 4

- (c) Sensing Auxiliary Contacts (See Figures 5 and 6)

- (1) Both magnets de-energized, distributor and transmitter shaft clutches latched and in the stop position. Turn motor off.
- (2) Hold distributor and transmitter shaft gears against rotation. Energize both clutch trip magnets.
- (3) Release gears and turn motor on.
- (4) Align the end of the distributor stop pulse image with the 142 scale division on the stop segment of the test set scale.
- (5) Clutch trip marking contacts should:
  - Close at  $90 + 10$  divisions in start segment.
  - Open at  $64 + 20$  divisions in #2 segment.
- (6) Clutch trip spacing contacts should:
  - Open at  $80 + 10$  divisions in start segment.
  - Close at  $74 + 20$  divisions in #2 segment.
- (7) Auxiliary marking contacts should:
  - Close at  $80 + 10$  divisions in #2 segment.
  - Open at  $31 + 20$  divisions in stop segment.

3.04 Distributor Contacts (continued)

(8) Auxiliary spacing contacts should:

Open at  $72 +10$  divisions in #2 segment.

Close at  $41 -20$  divisions in stop segment.

To adjust, refine transfer contact adjustment as necessary.




Figure 5





Figure 6

FINAL OPERATING REQUIREMENTS

- (a) There should be no breaks in the transmitted signal pulses.
- (b) The beginning and end of the transmitted pulses should not deviate more than  $+3$  percent.
- (c) The tape-out contact should operate from the normally closed position with tape in unit. With no tape in the unit, the tape-out contact should operate from the open position.

## 3.05 Distributor Contacts (continued)

Note: An 11-unit code distortion test set disc is now available for checking all contacts. Refer to Paragraph 3.01 when using a 7.42 unit distortion test set disc.

DISTRIBUTOR CONTACTS

## (a) Stop Contact

- (1) With a distortion test set (DXD) operating at the same speed as the transmitter distributor, load the unit with a NULL perforated tape. Operate the distributor shaft clutch magnet.
- (2) Adjust the contact adjusting screw so that stop pulse length is 200 scale divisions (11-unit code).

## (b) Contacts #1 - #8

- (1) Remove the NULL tape and load the transmitter distributor with tape punched in levels 2, 4, 6 and 8. Align the end of the stop pulse with the 200 scale division on the stop segment of the test scale.
- (2) Adjust the 2, 4, 6, and 8 distributor contact adjusting screws so that the image lengths are 100 scale divisions in total length within  $\pm 5$  percent on each end of the image. The same procedure is used when the 1, 3, 5, and 7 code is selected and adjusted.
- (3) In order to determine the end of the number 8 pulse image, it is necessary to hold the stop contact open.

DISTRIBUTOR AUXILIARY CONTACT

- (1) Align the end of the stop pulse image with 200 mark on test scale stop segment and adjust the auxiliary contact.
- (2) The distributor auxiliary contact should:
  - Close at 155,  $\pm 6$  divisions in stop segment.
  - Open at 45,  $\pm 10$  divisions in stop segment.

TRANSMITTER CONTACTS - Refer to 3.03 (b).

SENSING AUXILIARY CONTACTS - Refer to 3.03 (c).

FINAL OPERATING REQUIREMENTS - Refer to 3.04.