

Lucent Technologies
Bell Labs Innovations



INTUITY™ Messaging Solutions

Release 4
MAP/100 Maintenance

585-310-174
Comcode 108097320
Issue 3
October 1997

Notice

Every effort was made to ensure that the information in this book was complete and accurate at the time of printing. However, information is subject to change.

Your Responsibility for Your System's Security

Toll fraud is the unauthorized use of your telecommunications system by an unauthorized party, for example, persons other than your company's employees, agents, subcontractors, or persons working on your company's behalf. Note that there may be a risk of toll fraud associated with your telecommunications system and, if toll fraud occurs, it can result in substantial additional charges for your telecommunications services.

You and your system manager are responsible for the security of your system, such as programming and configuring your equipment to prevent unauthorized use. The system manager is also responsible for reading all installation, instruction, and system administration documents provided with this product in order to fully understand the features that can introduce risk of toll fraud and the steps that can be taken to reduce that risk. Lucent Technologies does not warrant that this product is immune from or will prevent unauthorized use of common-carrier telecommunication services or facilities accessed through or connected to it. Lucent Technologies will not be responsible for any charges that result from such unauthorized use.

Lucent Corporate Security

Whether or not immediate support is required, all toll fraud incidents involving Lucent products or services should be reported to Lucent Corporate Security at 1 800 821-8235. In addition to recording the incident, Lucent Corporate Security is available for consultation on security issues, investigation support, referral to law enforcement agencies, and educational programs.

Lucent Technologies Fraud Intervention

If you *suspect that you are being victimized* by toll fraud and you need technical support or assistance, call the Lucent Technologies National Customer Care Center Toll Fraud Intervention Hotline at 1 800 643-2353.

Federal Communications Commission Statement

Part 15: Class A Statement. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Part 68: Network Registration Number. This equipment is registered with the FCC in accordance with Part 68 of the FCC Rules. It is identified by an FCC registration number.

Part 68: Answer-Supervision Signaling. Allowing this equipment to be operated in a manner that does not provide proper answer-supervision signaling is in violation of Part 68 Rules. This equipment returns answer-supervision signals to the public switched network when:

- Answered by the called station
- Answered by the attendant
- Routed to a recorded announcement that can be administered by the CPE user

This equipment returns answer-supervision signals on all DID calls forwarded back to the public switched telephone network. Permissible exceptions are:

- A call is unanswered
- A busy tone is received
- A reorder tone is received

Canadian Department of Communications (DOC)

Interference Information

This digital apparatus does not exceed the Class A limits for radio noise emissions set out in the radio interference regulations of the Canadian Department of Communications.

Le Présent Appareil Numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la class A prescrites dans le reglement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

Trademarks

See the section titled "About This Book."

Ordering Information

Call: Lucent Technologies Publications Center
Voice 1 800 457-1235 International Voice 317 361-5353
Fax 1 800 457-1764 International Fax 317 361-5355

Write: Lucent Technologies Publications Center
P.O. Box 4100
Crawfordsville, IN 47933

You can be placed on a standing order list for this and other documents you may need. Standing order will enable you to automatically receive updated versions of individual documents or document sets, billed to account information that you provide. For more information on standing orders, or to be put on a list to receive future issues of this document, contact the Lucent Technologies Publications Center.

Warranty

Lucent Technologies provides a limited warranty on this product. Refer to the "Limited Use Software License Agreement" card provided with your package.

European Union Declaration of Conformity

Lucent Technologies Business Communications Systems declares that the equipment specified in this document conforms to the referenced European Union (EU) Directives and Harmonized Standards listed below:

EMC Directive	89/336/EEC
Low-Voltage Directive	73/23/EEC



The "CE" mark affixed to the equipment means that it conforms to the above directives.

Comments

To comment on this document, return the comment card at the front of the document.

Acknowledgment

This document was prepared by Product Documentation, Lucent Technologies, Columbus, OH.

Contents

Contents	iii
About This Book	xiii
■ Purpose	xiii
■ Intended Audiences	xiii
■ Release History	xiii
■ How to Use This Book	xiv
For Troubleshooting Information	xiv
For Diagnostic Information	xiv
For Common System Procedures	xiv
For Hardware Information	xiv
For Software Information	xiv
■ Conventions Used in This Book	xv
Terminology	xv
Terminal Keys	xviii
Screen Displays	xviii
Other Typography	xix
Safety and Security Alert Labels	xix
■ Trademarks and Service Marks	xx
■ Related Resources	xxii
Documentation	xxii
Training	xxii
■ How to Comment on This Book	xxiii
1 Troubleshooting	1-1
■ Overview	1-1
■ Purpose	1-1
■ Modem Does Not Answer	1-2
■ The Tape Backup Alarm Is Activated Daily at 3:00 A.M.	1-3
■ The DCIU Link Is Not Functioning	1-4
■ The Voice Ports Are Answering in Standalone Mode	1-5
■ DCS AUDIX® Does Not Work	1-6
■ Cannot Assign Voice Ports	1-7
■ System Will Not Outcall	1-7
■ System Will Not Boot	1-8

- [Optional Features Not Working](#) 1-9
- [System Memory Test Fails](#) 1-10
- [The Keyboard Is Not Operating](#) 1-10
- [Monitor Is Not Operating](#) 1-11
- [Tip/Ring Circuit Card Is Not Recognized by the Lucent INTUITY System](#) 1-12
- [The Printer Is Not Operating](#) 1-13
- [Hard Disk Drive Access Troubleshooting](#) 1-14
 - [The System Displays No Boot Device Available Message with Ident-Strings](#) 1-14
 - [The System Displays SCSI Target 0 LUN 0 Not Found Message with Several Additional Messages](#) 1-17
 - [The System Displays SCSI Target 0 LUN 0 Not Found Message and Stalls](#) 1-19
 - [No Ident-Strings Are Displayed during Boot Procedure](#) 1-20
 - [The System Displays Failure to Load MIP, SIP, or vfs_mount Message](#) 1-21
 - [A Working System Displays WARNING Disk Drive HA0 TC0 LUX - Check Condition Message](#) 1-22
 - [The System is Up but Not Fully Operational or Is Unpredictable](#) 1-23
 - [System with Remote Maintenance Circuit Card Displays SCSI Disk Failure Message after POST](#) 1-24
- [Troubleshooting Defective Blocks on Hard Disk Drives](#) 1-25

2 [Diagnostics](#) 2-1

- [Overview](#) 2-1
- [Purpose](#) 2-1
- [Conducting Audits](#) 2-2
 - [Auditing Voice Messaging Databases](#) 2-2
 - [Auditing Networking Databases](#) 2-8
- [Conducting Diagnostics](#) 2-13
 - [AMIS Analog Networking Diagnostics](#) 2-13
 - [INTUITY AUDIX Digital Networking Diagnostics](#) 2-16
 - [Performing a Network Snapshot](#) 2-30
 - [Multi-Port Serial Card Diagnostics](#) 2-31

Switch Integration Diagnostics	2-41
TCP/IP Diagnostics	2-50
Voice Port Diagnostics	2-57
Tip/Ring Circuit Card Diagnostics	2-59

[3 Common System Procedures](#) [3-1](#)

■ Overview	3-1
■ Purpose	3-1
■ Accessing the Product ID	3-2
■ About Cartridge Drives and Tapes	3-3
Types of Cartridge Tape Drives	3-3
When to Change Cartridge Tapes	3-3
Inserting and Removing Cartridge Tapes	3-4
Formatting Cartridge Tapes	3-7
■ About Diskette Drives and Diskettes	3-8
Types of Diskettes	3-8
Inserting and Removing Diskettes	3-8
Formatting Diskettes	3-9
■ Backing Up (Unattended)	3-10
How to Manage Tapes	3-10
What Data Are Backed Up	3-10
Verifying the Unattended Backup	3-14
■ Backing Up (Attended)	3-18
Data Types	3-18
Attended Backup	3-19
■ Restoring Backups	3-22
When to Do a Restore	3-22
When to Reinstall Software	3-22
How to Do a Restore	3-22
■ Administering Voice Messaging	3-25
Starting the Voice System	3-25
Stopping the Voice System	3-26
■ Shutting Down and Rebooting the Lucent INTUITY System	3-27
Shutting Down the System	3-27
Rebooting the System	3-28

- [Verifying the Date and Time](#) 3-30
 - [Checking the UNIX Date and Time Window](#) 3-30
 - [Changing the UNIX Date and Time Window](#) 3-31

4 Getting Inside the Computer 4-1

- [Overview](#) 4-1
- [Purpose](#) 4-1
- [Protecting against Damage from Electrostatic Discharge](#) 4-2
- [Removing Power from the MAP/100](#) 4-5
- [Opening and Removing the Front Doors](#) 4-7
 - [Opening and Removing the Right Door](#) 4-7
 - [Opening and Removing the Left Door](#) 4-7
- [Removing the Dress Covers](#) 4-8
 - [Removing the Top Dress Cover](#) 4-8
 - [Removing the Side Dress Covers](#) 4-8
- [Accessing the Peripheral Bay](#) 4-9
- [Accessing the Circuit Card Cage](#) 4-12
- [Closing the Circuit Card Cage](#) 4-13
- [Closing the Peripheral Bay](#) 4-13
- [Replacing the Dress Covers](#) 4-14
 - [Replacing the Side Dress Cover](#) 4-14
 - [Replacing the Top Dress Cover](#) 4-14
- [Replacing the Front Doors](#) 4-14
- [Restoring Power to the MAP/100](#) 4-15

5 Replacing or Installing Circuit Cards 5-1

- [Overview](#) 5-1
- [Purpose](#) 5-1
- [General Procedures](#) 5-2
 - [Removing a Circuit Card](#) 5-2
 - [Installing a Circuit Card](#) 5-3
- [Settings for Optional Circuit Cards](#) 5-6
 - [Multi-Port Serial Circuit Card](#) 5-6
 - [ACCX \(AYC22\) Circuit Card](#) 5-7
 - [Switch Interface Circuit Cards](#) 5-9
 - [Ethernet LAN Circuit Cards](#) 5-12

	Speech and Signal Processor (AYC43) Circuit Card	5-18
■	Settings for Standard Circuit Cards	5-24
	Tip/Ring Circuit Cards	5-24
	P5 120 MHz CPU Circuit Card	5-27
	External SCSI Connector Circuit Card	5-41
	Video Controller Circuit Cards	5-43
	Remote Maintenance Circuit Cards	5-48
■	Installing a Remote Maintenance Circuit Card, Version 2	5-58
	Types of Remote Maintenance Circuit Cards	5-58
	Setting the Resource Options	5-60
	Installing the Remote Maintenance Circuit Card Software Package	5-61
	Replacing a Defective Remote Maintenance Circuit Card	5-63
	Replacing a Modem with a Remote Maintenance Circuit Card	5-70
6	Replacing the Hard Disk Drive	6-1
■	Overview	6-1
■	Purpose	6-1
■	Identifying a Failed Hard Disk Drive	6-2
	Hard Disk Drive Contents in Six Hard Disk Drive Systems	6-2
	Identifying a Hard Disk Drive 0 Failure in a Nonmirrored System	6-3
	Identifying a Hard Disk Drive 6 (audfs) Failure in a Nonmirrored System	6-4
	Identifying Other Hard Disk Drive Failures in a Nonmirrored System	6-7
	Identifying a Hard Disk Drive Failure in a Mirrored System	6-7
■	Software and Hardware Procedures for Replacing Hard Disk Drive 0	6-8
	Software and Hardware Procedures for Replacing Hard Disk Drive 0 (Nonmirrored System)	6-8
	Software and Hardware Procedures for Replacing Hard Disk Drive 0 (Mirrored System)	6-25
■	Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5	6-32
	Performing an Attended Backup	6-32

	Activating Alarm Suppression	6-32
	Hardware Procedures for Replacing the Hard Disk Drive	6-33
	Initializing the New Hard Disk Drive	6-33
	Inactivating Alarm Suppression	6-33
■	Software and Hardware Procedures for Replacing Hard Disk Drive 6 (audfs)	6-34
	Performing an Attended Backup	6-34
	Activating Alarm Suppression	6-34
	Hardware Procedures for Replacing the Hard Disk Drive	6-35
	Initializing the New Hard Disk Drive	6-35
	Installing the Default Voice Mail Database	6-35
	Restoring the Lucent INTUITY System from the Backup Tapes	6-36
	Inactivating Alarm Suppression	6-36
■	Software and Hardware Procedures for Installing an Lucent INTUITY System with All New Hard Disk Drives	6-37
■	Adding a Hard Disk Drive	6-38
■	Cleaning a Hard Disk Drive	6-41
	Using the fdisk Command	6-41
	Performing a Low-Level Format	6-42
7	Replacing Other Components	7-1
	Overview	7-1
	Purpose	7-1
	Replacing Electromagnetic Conductance Reduction Components	7-2
	Toroid and Ferrite Placement	7-2
	General Toroid and Ferrite Installation Guidelines	7-4
	Installing a Toroid	7-5
	Installing a Ferrite	7-7
	Replacing Defective Memory Modules	7-8
	Identifying a Damaged SIMM	7-9
	Removing SIMMs	7-11
	Installing SIMMs	7-12
	Replacing the Fan Filter	7-13

Removing Fan Filters	7-13
Cleaning the Fan Filter	7-13
Installing Fan Filters	7-13
■ Replacing a Fan	7-14
Replacing a Circuit Card Cage Fan	7-14
Replacing the Peripheral Bay Fan	7-17
■ Replacing the Diskette Drive	7-21
Removing the Diskette Drive	7-22
Installing a Diskette Drive	7-25
■ Replacing the Power Supply	7-27
Replacing a Power Supply with a UPS	7-29
Replacing the Power Supply in a Power Module Assembly with Redundant Power Supply Capability	7-36
■ Replacing the SCSI Cartridge Tape Drive	7-42
Types of SCSI Cartridge Tape Drives	7-42
Removing a SCSI Cartridge Tape Drive	7-43
Verifying Jumper Settings	7-44
Installing a SCSI Cartridge Tape Drive	7-45
■ Replacing the 25-Slot Backplane	7-46
Removing the 25-Slot Backplane	7-46
Installing the 25-Slot Backplane	7-48
■ Replacing a Terminator SIP	7-50
8 Installing the Tip/Ring Distribution Hardware	8-1
■ Overview	8-1
■ Purpose	8-1
■ Function	8-2
■ Capacity	8-2
■ Types of Tip/Ring Distribution Hardware	8-2
Tip/Ring Distribution Hardware with a 356B Adapter	8-2
Tip/Ring Distribution Hardware without a 356B Adapter	8-4
■ Installing and Connecting the Tip/Ring Distribution Hardware with the 356B Adapter	8-7

[Installing the Tip/Ring Distribution Hardware with the 356B Adapter](#) 8-7

[Connecting the Tip/Ring Distribution Hardware with the 356B Adapter](#) 8-9

■ [Installing and Connecting the Tip/Ring Distribution Hardware without the 356B Adapter](#) 8-10

[Installing the Tip/Ring Distribution Hardware without the 356B Adapter](#) 8-10

■ [Completing the Installation](#) 8-13

9 [Installing Base System Software](#) 9-1

■ [Overview](#) 9-1

■ [Purpose](#) 9-1

■ [Installing UnixWare](#) 9-2

[Preparing the System](#) 9-2

[Starting the Unixware Installation](#) 9-2

[Loading the Host Bus Adapter](#) 9-4

[Continuing the UnixWare Installation](#) 9-4

[Setting Up the Keyboard](#) 9-6

[Configuring the System Date and Time](#) 9-8

[Choosing the Continent Location](#) 9-9

[Partitioning Hard Disk Drive 0](#) 9-10

[Partitioning Hard Disk Drive 1](#) 9-14

[Choosing the Installation Type](#) 9-15

[Setting the Slice Sizes](#) 9-16

[Performing a Hard Disk Drive Surface Analysis](#) 9-17

[Copying the Unix System Files](#) 9-18

[Loading the Application Server Software](#) 9-20

■ [Installing the INTUNIX+e Software](#) 9-22

■ [Running installit](#) 9-24

■ [Installing the Platform Software](#) 9-25

■ [Installing the Switch Interface Software Packages](#) 9-27

[Installing the DCIU Switch Integration Set](#) 9-27

[Installing the Serial-Inband Switch Integration Set](#) 9-28

[Installing the Digital Station Interface Switch Integration Set](#) 9-30

10	<u>Installing Lucent INTUITY System Software</u>	<u>10-1</u>
	■ <u>Overview</u>	<u>10-1</u>
	■ <u>Purpose</u>	<u>10-1</u>
	■ <u>Installing Lucent INTUITY System Software</u>	<u>10-2</u>
	■ <u>Installing the INTUITY AUDIX Voice Messaging System</u>	<u>10-2</u>
	■ <u>Installing the Lucent INTUITY System Default Announcement Set and/or Optional Language Package Announcement Sets</u>	<u>10-4</u>
11	<u>Installing the Optional Feature Software</u>	<u>11-1</u>
	■ <u>Overview</u>	<u>11-1</u>
	■ <u>Purpose</u>	<u>11-1</u>
	■ <u>Installing UNIX Multi-User Software</u>	<u>11-2</u>
	■ <u>Installing INTUITY Lodging Software Packages</u>	<u>11-5</u>
	<u>Installing INTUITY Lodging Software Set</u>	<u>11-5</u>
	<u>Installing the Optional Lodging Language Package</u>	<u>11-9</u>
	■ <u>Installing the Enhanced List Administration Package</u>	<u>11-10</u>
12	<u>Installing an RFU</u>	<u>12-1</u>
	■ <u>Overview</u>	<u>12-1</u>
	■ <u>Purpose</u>	<u>12-1</u>
	■ <u>Installing an RFU</u>	<u>12-2</u>
	<u>Removing an Existing RFU</u>	<u>12-2</u>
	<u>Installing a New RFU</u>	<u>12-4</u>
	<u>Verifying the RFU Installation</u>	<u>12-6</u>
A	<u>System Configuration</u>	<u>A-1</u>
	■ <u>Memory Configuration</u>	<u>A-1</u>
	■ <u>Component Assignments</u>	<u>A-1</u>
	<u>Bay Assignments</u>	<u>A-3</u>
	<u>Slot Assignments</u>	<u>A-4</u>
	<u>Assignment Rules</u>	<u>A-5</u>
	■ <u>Resource Allocation</u>	<u>A-5</u>
B	<u>Component Ordering Numbers</u>	<u>B-1</u>
	■ <u>Component Ordering Numbers</u>	<u>B-1</u>

<u>C</u>	<u>How to Build a System Using This Book</u>	<u>C-1</u>
	■ <u>Checklist for Building a System</u>	<u>C-1</u>
<u>D</u>	<u>Disaster Recovery Checklists</u>	<u>D-1</u>
	■ <u>Disaster Recovery Checklists</u>	<u>D-1</u>
	<u>Checklist for Software Reloading on Nonmirrored Lucent INTUITY Systems with Existing Hard Disk Drives</u>	<u>D-1</u>
	<u>Checklist for Lucent INTUITY Systems with All New Hard Disk Drives</u>	<u>D-5</u>
	<u>Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives</u>	<u>D-8</u>
	<u>Checklist for Nonmirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives</u>	<u>D-12</u>
	<u>Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives</u>	<u>D-14</u>
	<u>Checklist for Mirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives</u>	<u>D-17</u>
	<u>Checklist for Replacing Hard Disk Drive 6 (audfs) on a Nonmirrored Lucent INTUITY System</u>	<u>D-19</u>
	<u>Checklist for Field Reloading a Lodging Only System</u>	<u>D-21</u>
<u>GL</u>	<u>Glossary</u>	<u>GL-1</u>
<u>IN</u>	<u>Index</u>	<u>IN-1</u>

About This Book

Purpose

This book, *Lucent™ INTUITY™ Messaging Solutions Release 4 MAP/100 Maintenance, Issue 3, 585-310-174* contains information for troubleshooting and diagnosing problems associated with the MAP/100 hardware. Component replacement procedures and common system procedures are also included in the book. Installation procedures for base system software, Lucent system software, UNIX Multi-User software, and RFUs are also included. Appendices contain a system configuration description, a list of component ordering numbers, a checklist for building a system, and checklists for disaster recovery.

Intended Audiences

This book is intended primarily for the on-site service technician and system administrators. Secondary audiences include the following from Lucent:

- Field support — Technical Service Organization (TSO)
- Helpline personnel

We assume that the primary users of this book have completed the Lucent MAP/100 hardware installation training course (see “Related Documentation and Training” below).

Release History

This is the first release of this book.

How to Use This Book

This book is designed to help you maintain your Lucent system. It should be used as a quick-reference to obtain specific information you may need on a particular topic.

For Troubleshooting Information

Basic troubleshooting information is available in [Chapter 1, "Troubleshooting"](#).

For Diagnostic Information

Instructions for conducting diagnostics are available in [Chapter 2, "Diagnostics"](#).

For Common System Procedures

Instructions for conducting common system procedures are available in [Chapter 3, "Common System Procedures"](#).

For Hardware Information

Instructions for replacing or installing hardware components of the MAP/100 are available in [Chapter 4, "Getting Inside the Computer"](#), [Chapter 5, "Replacing or Installing Circuit Cards"](#), [Chapter 6, "Replacing the Hard Disk Drive"](#), [Chapter 7, "Replacing Other Components"](#), and [Chapter 8, "Installing the Tip/Ring Distribution Hardware"](#).

For Software Information

Instructions for replacing or installing software components of the MAP/100 are available in [Chapter 9, "Installing Base System Software"](#), [Chapter 10, "Installing Lucent Intuity System Software"](#), [Chapter 11, "Installing the Optional Feature Software"](#), and [Chapter 12, "Installing an RFU"](#).

Conventions Used in This Book

This section describes the conventions used in this book.

Terminology

- The word “type” means to press the key or sequence of keys specified. For example, an instruction to type the letter “y” is shown as
Type **y** to continue.
- The word “enter” means to type a value and then press **ENTER**. For example, an instruction to type the letter “y” and press **ENTER** is shown as
Enter **y** to continue.
- The word “select” means to move the cursor to the desired menu item and then press **ENTER**. For example, an instruction to move the cursor to the start test option on the Network Loop-Around Test screen and then press **ENTER** is shown as
Select **Start Test**.
- The Lucent INTUITY system displays *windows*, *screens*, and *menus*. “Windows” show and request system information ([Figure 1](#) and [Figure 2](#), respectively). “Screens” request that you enter a command at the `enter command: prompt` ([Figure 3](#)). “Menus” ([Figure 4](#)) present options from which you can choose to view another menu, or a screen or window.
- The words “subscriber” and “user” are interchangeable terms that describe a person administered on the Lucent INTUITY system. The word “user” is the preferred term in the text; however, “subscriber” appears on most of the screens.




Figure 1. Example of an Lucent INTUITY Window




Figure 2. Example of an Lucent INTUITY Window




Figure 3. Example of an Lucent INTUITY Screen



Figure 4. Example of an Lucent INTUITY Menu

Terminal Keys

- Keys that you press on your terminal or PC are represented as rounded boxes. For example, an instruction to press the enter key is shown as

Press **ENTER**.

- Two or three keys that you press at the same time on your terminal or PC (that is, you hold down the first key while pressing the second and/or third key) are represented as a series of separate rounded boxes. For example, an instruction to press and hold **ALT** while typing the letter “d” is shown as

Press **ALT** **D**.

- Function keys on your terminal, PC, or system screens, also known as *soft keys*, are represented as round boxes followed by the function or value of that key enclosed in parentheses. For example, an instruction to press function key 3 is shown as

Press **F3** (Choices).

- Keys that you press on your telephone keypad are represented as square boxes. For example, an instruction to press the first key on your telephone keypad is shown as

Press **1** to record a message.

Screen Displays

- Values, system messages, field names, and prompts that appear on the screen are shown in typewriter-style `constant-width` type, as shown in the following examples:

Example 1:

```
Enter the number of ports to be dedicated to outbound traffic in the
Maximum Simultaneous Ports field.
```

Example 2:

```
Alarm Form Update was successful.
Press <Enter> to continue.
```

- The sequence of menu options that you must select to display a specific screen or submenu is shown as follows:

Start at the Lucent INTUITY Main menu and select

```
> Customer/Services Administration
```

```
> Alarm Management
```

In this example, you would access the Lucent INTUITY Main menu and select the Customer/Service Administration menu. From the Customer/Service Administration menu, you would then select the Alarm Management screen.

- Screens shown in this book are examples only. The screens you see on your machine will be similar, but not exactly the same.

Other Typography

- Commands and text you type in or enter appear in **bold type**, as in the following examples:

Example 1:

Enter **change-switch-time-zone** at the `enter` command: prompt.

Example 2:

Type **high** or **low** in the `Speed:` field.

- Command variables are shown in ***bold italic*** type when they are part of what you must type in and *regular italic* type when they are not, for example

Enter **ch ma *machine_name***, where *machine_name* is the name of the call delivery machine you just created.

Safety and Security Alert Labels

This book uses the following symbols to call your attention to potential problems that could cause personal injury, damage to equipment, loss of data, service interruptions, or breaches of toll fraud security:

CAUTION:

Indicates the presence of a hazard that if not avoided can or will cause minor personal injury or property damage, including loss of data.



WARNING:

Indicates the presence of a hazard that if not avoided can cause death or severe personal injury.



DANGER:

Indicates the presence of a hazard that if not avoided will cause death or severe personal injury.



SECURITY ALERT:

Indicates the presence of a toll fraud security hazard. Toll fraud is the unauthorized use of a telecommunications system by an unauthorized party.

Trademarks and Service Marks

The following trademarked products are mentioned in books in the Lucent document set:

- AT is a trademark of Hayes Microcomputer Products, Inc.
- AUDIX is a registered trademark of Lucent Technologies.
- cc:Mail is a registered trademark of cc:Mail, a subsidiary of Lotus Development Corporation.
- COMSPHERE is a registered trademark of Paradyne Corp.
- CONVERSANT Voice Information System is a registered trademark of Lucent Technologies.
- DEFINITY is a registered trademark of Lucent Technologies.
- DMS-100 is a trademark of Northern Telecom Limited.
- Dterm is a trademark of NEC Telephones, Inc.
- Equinox is a trademark of Equinox Systems, Inc.
- 5ESS is a registered trademark of Lucent Technologies.
- is a trademark of Lucent Technologies.
- Lotus Notes is a registered trademark of Lotus Development Corporation.
- MEGAPORT is a trademark of Equinox Systems, Inc.
- MEGAPLEX is a trademark of Equinox Systems, Inc.
- Meridian is a trademark of Northern Telecom Limited.
- MERLIN LEGEND is a registered trademark of Lucent Technologies.
- Microcom Networking Protocol is a registered trademark of Microcom, Inc.

- Microsoft is a registered trademark of Microsoft Corporation.
- MS is a registered trademark of Microsoft Corporation.
- MS-DOS is a registered trademark of Microsoft Corporation.
- Mitel is a trademark of Mitel Corporation.
- NEAX is a trademark of NEC Telephone, Inc.
- NEC is a registered trademark of NEC Telephone, Inc.
- Netware is a registered trademark of Novell, Inc.
- Netware Loadable Module is a registered trademark of Novell, Inc.
- Northern Telecom is a registered trademark of Northern Telecom Limited.
- Novell is a registered trademark of Novell, Inc.
- Paradyne is a registered trademark of AT&T.
- Phillips is a registered trademark of Phillips Screw Company.
- Rolm is a registered trademark of International Business Machines.
- SL-1 is a trademark of Northern Telecom Limited.
- softFAX is a registered trademark of VOXEM, Inc.
- SUPERSET is a trademark of Mitel Corporation.
- SX-100 is a trademark of Mitel Corporation.
- SX-200 is a trademark of Mitel Corporation.
- SX-2000 is a trademark of Mitel Corporation.
- TMI is a trademark of Texas Micro Systems, Inc.
- UNIX is a registered trademark of UNIX Systems Laboratories, Inc.
- Voice Bridge is a registered trademark of Voice Technologies Group, Inc.
- VOXEM is a registered trademark of VOXEM, Inc.
- VT100 is a trademark of Digital Equipment Corporation.
- Windows is a trademark of Microsoft Corporation.

Related Resources

This section describes additional documentation and training available for you to learn more about installation of the Lucent INTUITY product.

Documentation

⇒ NOTE:

The *INTUITY Messaging Solutions Release 4 Documentation Guide*, 585-310-540, contains a detailed description of all books included in the Release 4 Lucent INTUITY documentation library. Always refer to the appropriate book for specific information on planning, installing, administering, or maintaining an Lucent INTUITY system.

It is suggested that you obtain and use the following books in conjunction with this installation book:

- *INTUITY Messaging Solutions System Description*, 585-310-235, for a complete description of the Lucent INTUITY product and features
- *INTUITY Messaging Solutions Release 4 MAP/100 System Installation*, 585-310-173, for a detailed source of complete maintenance procedures and troubleshooting information

It is suggested that you obtain and use the following book for information on security and toll fraud issues:

- *BCS Products Security Handbook*, 555-025-600

See the inside front cover for information on how to order Lucent INTUITY documentation.

Training

The following training class is recommended as a prerequisite to installing a Release 4 Lucent INTUITY system:

- Course No. MO1616A, INTUITY Messaging Solutions Installation and Maintenance

For more information on Lucent INTUITY training, call the BCS Education and Training Center at one of the following numbers:

- Organizations within Lucent: (904) 636-3261
- Lucent customers and all others: (800) 255-8988

How to Comment on This Book

We are interested in your suggestions for improving this book. Please complete and return the reader comment card that is located behind the title page.

If the reader comment card has been removed, send your comments to:

Lucent Technologies
Product Documentation
Room 22-2H15
11900 North Pecos Street
Denver, Colorado 80234

Please be sure to mention the name and order number of this book.

Troubleshooting

1

Overview

This chapter describes some basic troubleshooting procedures for the most common system problems.

Purpose

The purpose of this chapter is to provide the on-site technician or system administrator with repair procedures for the most common system procedures. All of the troubleshooting procedures can be accomplished with a craft login.

Modem Does Not Answer

Table 1-1. Modem Does Not Answer

Possible Cause	Check/See	Probable Fix
There is no power to the modem.	Check the power source.	Apply power to the modem.
The modem is not connected.	The modem should be connected with a D25F cord through a 25 to 9 pin adapter to COM2.	Connect the modem correctly.
The normal D4 conductor cord is not plugged in to the correct port.	Make sure that the normal D4 cord is plugged into the Dial portion of the 3820 Modem. This cord should not be plugged into the Phone portion.	Plug the normal D4 cord into the Dial portion of the modem.
There is no continuity.	Check the Alarm Management window by doing the following: <ol style="list-style-type: none"> Starting at the Lucent™ INTUITY™ Main menu window, select <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"> > Customer/Serv. Admin </div> <div style="border: 1px solid black; padding: 2px; margin: 5px 0;"> > Alarm Management </div> 	Fill in the Alarm Screen. <ol style="list-style-type: none"> Enter the product ID in the Product ID field. If the product ID is not known, enter 2200000000 Enter a valid telephone number in the Alarm Destination field. Press F8 (Chg-Keys). Press F1 (Test_Alm). If the product ID was not known in Step 1 call INADS for the correct number.

The Tape Backup Alarm Is Activated Daily at 3:00 A.M.

Table 1-2. The Tape Backup Alarm Is Activated Daily at 3:00 A.M.

Possible Cause	Check/See	Probable Fix
The tape is not in the drive.	Check the position of the tape in the drive.	Position the tape correctly.
The tape is write protected.	Check the read/write dial on the tape.	Place the read/write dial in the "not safe" position. The small dial on the front of the tape should be in the horizontal position.
The tape is not compatible with the drive.	Check the type of tape in the drive. All tapes created in a 2-Gbyte tape drive can be read by a 525-Mbyte tape drive. The only tapes, created in a 525-Mbyte tape drive, which can be read by a 2-Gbyte tape drive, are Lucent INTUITY system backup tapes.	Replace the tape with a compatible tape.
The tape is not formatted.	Check the format status.	Format the tape. See "Formatting Cartridge Tapes" , in Chapter 3 , "Common System Procedures" for the procedure.
The tape drive is not working correctly.	Check the operation of the tape drive during a backup. If the tape drive is spinning but there is no processor time being allotted to the cpio process, the tape drive is not working correctly.	Replace the tape drive. See "Replacing the SCSI Cartridge Tape Drive" , in Chapter 7 , "Replacing Other Components" for the procedure.


The DCIU Link Is Not Functioning

Table 1-3. The DCIU Link Is Not Functioning

Possible Cause	Check/See	Probable Fix
The DCIU Link is not assigned properly.	<p>Check the administrator's log for translation error entries.</p> <p>Check the assignment parameters in the installation manual for both the switch and the Lucent system.</p>	Reassign the DCIU Link.
The assigned node number is not correct.	<p>System 85 and G2 Refer to procedure 275, word 3, field 8.</p>	<p>Change the Lucent node setting to match the switch setting.</p> <p>If the node number listed in the Lucent INTUITY system is above 20 escalate to tier 3.</p>
	<p>DEFINITY® G1 Refer to the Display Dial Plan.</p> <p>If UDP is off then the correct node number is 1.</p> <p>If UDP is on then refer to page two and determine the correct node number from the RNX field. If this field is blank then escalate to tier 3.</p>	Change the Lucent INTUITY node number to match the switch.
	<p>DEFINITY G3 Refer to the Display Dial Plan page one.</p>	<p>Change the Lucent INTUITY node setting to match the switch setting.</p> <p>If the node number listed in the Lucent INTUITY system is above 20 escalate to tier 3.</p>
Incorrect link connections.	Check for proper connections.	Adjust the connections as needed.

The Voice Ports Are Answering in Standalone Mode

Table 1-4. The Voice Ports Are Answering in Standalone Mode

Possible Cause	Check/See	Probable Fix
The ports are not assigned in the correct order.	Check the connection order by dialing the ports directly and through the UCD.	To reassign the ports, do the following: <ol style="list-style-type: none">Starting at the Lucent INTUITY Main menu window, select <pre>> Voice System Admin. > Voice Equipment</pre>Press F8 (Chg-Keys).Press F2 (Renumber).

Continued on next page

Table 1-4. The Voice Ports Are Answering in Standalone Mode — Continued

Possible Cause	Check/See	Probable Fix
Incorrect entry in Services to Call Numbers field or Startup Services field.	Refer to the Chapter 6, “Initial Administration and Test for Messaging” of the Installation Manual.	To enter the correct numbers in the Services to Call Numbers field, do the following: <ol style="list-style-type: none"> Starting at the Lucent INTUITY Main menu window, select <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> > Voice System Admin. </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> > Voice Equipment </div> Enter the correct numbers.
The link to the switch is out of service.	Check the link to the switch.	Restore the link to service.
Subscribers have the wrong host PBX assigned.	Check the host PBX.	Reassign the host PBX.

DCS AUDIX® Does Not Work

Table 1-5. DCS AUDIX Does Not Work

Possible Cause	Check/See	Probable Fix
The DCS is not functional.	Check the DCS status.	Escalate to tier 3.
The Lucent INTUITY system is blank on the switch screen.	Refer to design personnel for the correct translations.	Input correct translations and save. If this does not work escalate to tier 3.

Cannot Assign Voice Ports

Table 1-6. Cannot Assign Voice Ports

Possible Cause	Check/See	Probable Fix
Additional port activation has not been purchased by the customer.	Verify number of ports purchased by the customer. Access Customer/Services Administration from the Lucent INTUITY Administration menu. Access the Feature Options screen and refer to the voice_ports line.	Refer the customer to sales personnel.

System Will Not Outcall

Table 1-7. System Will Not Outcall

Possible Cause	Check/See	Probable Fix
The voice port translations are incorrect for trunk access.	Check the voice port translations for the FRL and access.	Correct the voice port translations.

System Will Not Boot

Table 1-8. System Will Not Boot

Possible Cause	Check/See	Probable Fix
There is a diskette in the "A" drive.	Check the "A" drive.	Remove the diskette.
The external SCSI connector circuit card terminating module is not properly connected.	Check the terminating module connection.	Properly connect the terminating module.
There is an odd number of SIMMs installed on the P5 120 MHz CPU circuit card.	Check the number of SIMMs on the P5 120 MHz CPU circuit card.	Correct the SIMM configuration. See "Memory Configuration" , in Appendix A, "System Configuration" for the correct configuration.
<p>If the system displays the following message, the problem could be the diskette cable orientation.</p> <p>BIOS Not Installed</p>	<p>Check the diskette cable orientation on the P5 120 MHz CPU circuit card.</p> <p>The tracer on the cable should be on the right as you look at the P5 120 MHz CPU circuit card.</p>	<p>To fix the problem, do the following:</p> <ol style="list-style-type: none"> 1. Access the circuit card cage. See "Accessing the Circuit Card Cage" in Chapter 4, "Getting Inside the Computer", for the procedure. 2. Fix the diskette cable orientation. 3. Close the circuit card cage. See "Closing the Circuit Card Cage" in Chapter 4, "Getting Inside the Computer", for the procedure. 4. Restore power to the system. See "Restoring Power to the MAP/100" in Chapter 4, "Getting Inside the Computer", for the procedure.

Optional Features Not Working

Table 1-9. Optional Features Not Working

Possible Cause	Check/See	Probable Fix
The Lucent INTUITY version does not support the optional feature.	Check the Lucent INTUITY version.	Refer the customer to their sales representative concerning a migration or upgrade.
The optional feature is not activated.	Check the activated optional features by: <ol style="list-style-type: none">1. Starting at the Lucent INTUITY Main menu.2. Accessing Customer/Services Administration.3. Accessing Feature Options.	If the customer has purchased the optional feature, activate the optional feature. If the customer has not purchased the optional feature, refer them to their sales representative.

System Memory Test Fails

Table 1-10. System Memory Test Fails

Possible Cause	Check/See	Probable Fix
There is a SIMM missing from the P5 120 MHz CPU circuit card.	Check the number of SIMMs on the P5 120 MHz CPU.	Correct the SIMM configuration. See “Memory Configuration” , in Appendix A, “System Configuration” for the correct configuration.
There is a a defective SIMM on the P5 120 MHz CPU circuit card.	Check the condition of the SIMMs on the P5 120 MHz CPU. See “Identifying a Damaged SIMM” , in Chapter 7, “Replacing Other Components” for the procedure.	Replace the defective SIMM. See “Replacing Defective Memory Modules” , in Chapter 7, “Replacing Other Components” for the procedure.

The Keyboard Is Not Operating

Table 1-11. The Keyboard Is Not Operating

Possible Cause	Check/See	Probable Fix
The keyboard is not plugged in.	Check the keyboard connection.	Shut down the system and plug in the keyboard.
The keyboard is “frozen.”	Check the keyboard connection.	Reboot the system.

Monitor Is Not Operating

Table 1-12. Monitor Is Not Operating

Possible Cause	Check/See	Probable Fix
The video controller circuit card which has been installed is not compatible with the P5 120 MHz CPU circuit card.	Check the video controller circuit card. The following circuit cards are supported by the Lucent INTUITY system: <ul style="list-style-type: none">■ STB Horizon■ WDXLR831124■ WDXLR83160	Replace the video controller circuit card with a supported circuit card. See “Video Controller Circuit Cards” , in Chapter 5, “Replacing or Installing Circuit Cards” for the procedure.
The monitor has not been turned on.	Check the monitor switch.	Turn on the monitor.
The monitor brightness has been turned down.	Check the monitor brightness knob.	Turn up the brightness.

Tip/Ring Circuit Card Is Not Recognized by the Lucent INTUITY System

Table 1-13. Tip/Ring Circuit Card Is Not Recognized by the Lucent INTUITY System

Possible Cause	Check/See	Probable Fix
The Tip/Ring card has incorrect switch settings.	Check the switch settings on the Tip/Ring cards. See “Tip/Ring Circuit Cards” , in Chapter 5, “Replacing or Installing Circuit Cards” for the correct settings.	Correct the switch settings.
The Tip/Ring cards are incorrectly numbered.	There is nothing to check in this instance. If this is the suspected problem continue with the probable fix.	<p>Renumber the Tip/Ring circuit cards by doing the following:</p> <p>This will start and stop the voice system.</p> <ol style="list-style-type: none"> Starting at the Lucent INTUITY Main menu window, select <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <pre>> Voice System Admin.</pre> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <pre>> Voice Equipment</pre> </div> </div> <ol style="list-style-type: none"> Press F8 (Chg-Keys). Select Renumber. Press F2 (Renumber).

The Printer Is Not Operating

Table 1-14. The Printer Is Not Operating

Possible Cause	Check/See	Probable Fix
The printer is not turned on.	Check the power indicator light.	Turn the printer on.
The printer cable is not connected correctly.	Check the printer connection.	Reconnect the printer.
The Lucent INTUITY system has not been configured correctly.	Check the system configuration.	Reconfigure the system. See Chapter 4, "Connecting Peripherals and Powering Up" in <i>Lucent INTUITY Messaging Solutions Release 4 System Installation</i> .
The printer has not been configured correctly.	Check the printer configuration.	Reconfigure the printer. See Chapter 4, "Connecting Peripherals and Powering Up" in <i>Lucent INTUITY Messaging Solutions Release 4 System Installation</i> .
The printer is out of paper.	Check the paper supply.	Add paper.
The printer is jammed.	Check the printer operating panel.	Remove the paper jam.

Hard Disk Drive Access Troubleshooting

In the event of a SCSI Bus cable or hard disk drive failure the system will stall during the boot procedure. When the system stalls it will display one of several messages.

The System Displays No Boot Device Available Message with Ident-Strings

If the system displays the following message along with one or more SCSI device ident-strings see the troubleshooting procedures in [Table 1-15](#).

```
SCSI target 0 LUN 0 not found
Target-LUN x-0.....
....
Target-LUN y-0....
```

```
No boot device available
Strike F1 to retry boot, F2 for setup utility
```

Table 1-15. The System Displays No Boot Device Available Message with Ident-Strings

Possible Cause	Check/See	Probable Fix
Insufficient power voltages.	Check the power supply output voltage.	<ol style="list-style-type: none"> 1. If the power voltage is not 5V, replace the power supply. 2. Reboot the system.
The power cable is not properly attached to Hard Disk Drive 0.	Check the Hard Disk Drive 0 power cable connection.	<ol style="list-style-type: none"> 1. Correct the power cable connection to Hard Disk Drive 0. 2. Reboot the system.
The SCSI Bus cable is not properly attached to Hard Disk Drive 0.	Check the Hard Disk Drive 0 SCSI Bus cable connection.	<ol style="list-style-type: none"> 1. Correct the SCSI Bus cable connection to Hard Disk Drive 0. 2. Reboot the system.
The SCSI Bus cable is defective.	Check the SCSI Bus cable.	<ol style="list-style-type: none"> 1. Replace the SCSI Bus cable. 2. Reboot the system.

Continued on next page

Table 1-15. The System Displays No Boot Device Available Message with Ident-Strings
— *Continued*

Possible Cause	Check/See	Probable Fix
A pin on the Hard Disk Drive 0 SCSI Bus cable connector is bent or broken.	Check the pins on Hard Disk Drive 0 by doing the following: <ol style="list-style-type: none">1. Remove the SCSI Bus cable.2. Check the pins on the hard disk drive.	<ol style="list-style-type: none">1. If a pin is bent, straighten the pin. If a pin is broken, replace the hard disk drive.2. Reboot the system.
A pin on the P5 CPU circuit card SCSI Bus cable connector is bent or broken.	Check the pins on the P5 120 MHz circuit card by doing the following: <ol style="list-style-type: none">1. Remove the SCSI Bus cable.2. Check the pins on the circuit card.	<ol style="list-style-type: none">1. If a pin is bent, straighten the pin. If a pin is broken, replace the circuit card.2. Reboot the system.

Continued on next page

Table 1-15. The System Displays No Boot Device Available Message with Ident-Strings
 — *Continued*

Possible Cause	Check/See	Probable Fix
<p>Hard Disk Drive 0 has been corrupted and the system can not access the boot image.</p>	<p>Check the status of Hard Disk Drive 0.</p>	<ol style="list-style-type: none"> 1. If the system has a remote maintenance circuit card diagnose the hard disk drive and replace if necessary. 2. If the system is mirrored, boot off of the backup hard disk drive. 3. If the system did not boot perform the following steps: <ol style="list-style-type: none"> a. Perform a surface analysis on both Hard Disk Drive 0 and its backup hard disk drive. b. If the surface analysis indicates either hard disk drive must be replaced, replace the disk. 4. If the system is not mirrored complete the following steps: <ol style="list-style-type: none"> a. Perform a surface analysis. b. If the surface analysis indicates the hard disk drive must be replaced, replace the disk. c. If the surface analysis does not indicate that the disk should be replaced, reload the system.

The System Displays SCSI Target 0 LUN 0 Not Found Message with Several Additional Messages

If the system displays the following series of messages see the troubleshooting procedures in [Table 1-16](#).

The system displays the following message:

```
Checking for SCSI target 0 LUN 0
```

After several minutes the system displays the following messages:

```
SCSI target 0 LUN 0 not found  
Target-LUN x-0.....  
.....  
Target-LUN y-0....
```

```
No boot device available  
Strike F1 to retry boot, F2 for setup utility
```

Table 1-16. The System Displays SCSI Target 0 LUN 0 Not Found Message with Several Additional Messages

Possible Cause	Check/See	Probable Fix
Hard Disk Drive 0 has been corrupted and the system can not access the boot image.	Check the status of Hard Disk Drive 0.	<ol style="list-style-type: none">1. If the system has a remote maintenance circuit card diagnose the hard disk drive and replace if necessary.2. If the system is mirrored, boot off of the backup hard disk drive.3. If the system did not boot perform the following steps:<ol style="list-style-type: none">a. Perform a surface analysis on both Hard Disk Drive 0 and its backup hard disk drive.b. If the surface analysis indicates either hard disk drive must be replaced, replace the disk.4. If the system is not mirrored complete the following steps:<ol style="list-style-type: none">a. Perform a surface analysis.b. If the surface analysis indicates the hard disk drive must be replaced, replace the disk.c. If the surface analysis does not indicate that the disk should be replaced, reload the system.

The System Displays SCSI Target 0 LUN 0 Not Found Message and Stalls

If the system displays the following message and stalls see the troubleshooting procedures in [Table 1-17](#).

```
SCSI target 0 LUN 0 not found
```

At this point the system stalls.

NOTE:

If you press **CONTROL** **ALT** **DELETE** the system displays the following message:

```
No boot device available
```

```
Strike F1 to retry boot, F2 for setup utility
```

Table 1-17. The System Displays SCSI Target 0 LUN 0 Not Found Message and Stalls

Possible Cause	Check/See	Probable Fix
Hard Disk Drive 0 is defective.	Check the status of Hard Disk Drive 0.	1. Replace Hard Disk Drive 0.

No Ident-Strings Are Displayed during Boot Procedure

If the system does not display ident-strings during the boot procedure see the troubleshooting procedures in [Table 1-18](#).



NOTE:

Once the system has tried to access the SCSI devices it will try to access Hard Disk Drive 0. If the system displays the UNIX logo, Hard Disk Drive 0 has been successfully accessed.

Table 1-18. No Ident-Strings Are Displayed during Boot Procedure

Possible Cause	Check/See	Probable Fix
The SCSI Bus cable is not connected properly to the P5 120 MHz CPU circuit card.	Check the SCSI cable connection to the circuit card.	<ol style="list-style-type: none"> 1. Correct the SCSI cable connection to the circuit card. 2. Reboot the system.
A pin on the SCSI Bus cable connection to the P5 120 MHz CPU circuit card is broken or bent.	Check the pins on the P5 120 MHz circuit card by doing the following: <ol style="list-style-type: none"> 1. Remove the SCSI Bus cable. 2. Check the pins on the circuit card. 	<ol style="list-style-type: none"> 1. If a pin is bent, straighten the pin. If a pin is broken, replace the circuit card. 2. Reboot the system.

The System Displays Failure to Load MIP, SIP, or vfs_mount Message

If the system displays one of the following messages see the troubleshooting procedures in [Table 1-19](#).



NOTE:

Once the system has tried to access the SCSI devices it will try to access Hard Disk Drive 0. If the system displays the UNIX logo, Hard Disk Drive 0 has been successfully accessed.

Can not load MIP

Can not load SIP

vfs_mount failed



NOTE:

A system panic may occur at this point.

Table 1-19. The System Displays Failure to Load MIP, SIP, or vfs_mount Message

Possible Cause	Check/See	Probable Fix
The stand file system is corrupted.	Check the stand file status.	<ol style="list-style-type: none">1. If the system is mirrored, boot off of the backup hard disk drive.2. If the system is not mirrored, or if the problem persists, restore or reload the system.

A Working System Displays WARNING Disk Drive HA0 TC0 LUX - Check Condition Message

If the system displays the following message see the troubleshooting procedures in [Table 1-20](#).

WARNING: Disk Drive HA0 TC0 LUX - Check Condition

where x is a small integer

Table 1-20. A Working System Displays WARNING Disk Drive HA0 TC0 LUX - Check Condition Message

Possible Cause	Check/See	Probable Fix
Hard Disk Drive 0 is defective.	Check the status of Hard Disk Drive 0.	1. Replace Hard Disk Drive 0.

The System is Up but Not Fully Operational or Is Unpredictable

If the system is up but it is not fully operational or it is unpredictable see the troubleshooting procedures in [Table 1-21](#).

Table 1-21. The System is Up but not Fully Operational or is Unpredictable

Possible Cause	Check/See	Probable Fix
The input voltage is not correct.	Check the voltage on the line entering the power supply.	<ol style="list-style-type: none"> 1. Shut down the system. 2. Inform the customer of the problem in their wiring.
The power supply output voltage is not correct.	Check the voltage on the power supply output cables.	<ol style="list-style-type: none"> 1. Replace the power supply.
The file system is partially corrupted.	Check the system file system.	<ol style="list-style-type: none"> 1. If the system is mirrored, boot off of the backup hard disk drive. 2. If the system is not mirrored, or if the problem persists, restore or reload the system.

System with Remote Maintenance Circuit Card Displays SCSI Disk Failure Message after POST

If, after completing the POST and memory test, the system stalls and displays messages indicating a remote maintenance circuit card and SCSI hard disk drive failure see the troubleshooting procedures in [Table 1-22](#).

**Table 1-22. System with Remote Maintenance Circuit Card
 Displays SCSI Disk Failure Message after POST**

Possible Cause	Check/See	Probable Fix
The remote maintenance circuit card address is set to C000-CFFF.	Check the remote maintenance circuit card address.	<ol style="list-style-type: none"> 1. Place the BEE selector switch in the off position. 2. Shut down the system. 3. Reboot the system. 4. Set the remote maintenance circuit card address to DC000-DCFFF. 5. Place the BEE selector switch in the on position. 6. Stop the voice system. 7. Start the voice system.

Troubleshooting Defective Blocks on Hard Disk Drives

It is not always necessary to replace a hard disk drive with defective blocks. If the defective blocks do not affect the overall system performance it is not necessary to replace the hard disk drive. Monitor the system performance prior to replacing a hard disk drive.

1 Troubleshooting
Troubleshooting Defective Blocks on Hard Disk Drives

Page 1-26

Diagnostics

2

Overview

This chapter describes:

- Conducting audits
- Diagnosing digital networking
- Diagnosing Multi-port serial circuit cards
- Diagnosing switch integration
- Diagnosing TCP/IP
- Diagnosing voice ports
- Diagnosing Tip/Ring circuit cards

Purpose

The purpose of this chapter is to provide the on-site technician or system administrator with the correct procedures to diagnose trouble with the Lucent™ INTUITY™ system.

Conducting Audits

You can conduct audits on:

- Voice messaging databases
- Networking databases

Auditing Voice Messaging Databases

During normal operation the Lucent INTUITY system databases work independently under the direction of a set of software managers. These managers, in tandem with hardware and firmware managers, allow the files, databases, and system hardware to work together.

Because databases are handled separately, it is possible for different databases to contain conflicting information. For example, if a subscriber is removed from INTUITY AUDIX® Voice Messaging, other databases may contain messages addressed to that subscriber. In addition, mailing lists that include the deleted subscriber's name could still exist.

To reconcile possible conflicts among databases, software programs called audits run automatically to check for inconsistencies. Audits can also be run on demand by you.

Voice Messaging Database Audit Types

[Table 2-1](#) lists the types of voice messaging database audits.

Table 2-1. INTUITY AUDIX Voice Messaging Database Audits

Audit	Function	Frequency
Mailboxes	Checks and deletes old messages and log-in announcements	Daily
	Clears broadcast-deleted messages from subscriber mailboxes	Daily
	Verifies that Lucent INTUITY MWL status matches with the switch's MWL status for each subscriber	Daily
	Checks for valid mailbox structure	Weekly
	Makes space-accounting corrections on a per-subscriber and system basis	Weekly
	Checks for valid message subscriber IDs	Weekly

Continued on next page

Table 2-1. INTUITY AUDIX Voice Messaging Database Audits — Continued

Audit	Function	Frequency
Mailing Lists	Counts subscriber lists and entries on a system and per-subscriber basis to ensure that they are not exceeding internal limits	Weekly
	Removes deleted subscribers from lists	Weekly
	Removes deleted remote subscribers from local mailing lists	Daily
	Audits delivery manager queues and makes undeliverable entries for deleted subscribers	Daily
Names	Matches each voice name with a valid local or remote subscriber	Weekly
	Logs messages in the administrator's log for the first 20 local subscribers not having voiced names	Weekly
Network Data	Deletes information on remote nodes that have been eliminated from the network	Weekly
	Compares internal network files to synchronize information on nodes and subscribers, for example, which node each subscriber belongs to	Weekly
Personal Directories	Removes deleted subscribers (local and remote) from local subscribers' personal directories	Weekly

Continued on next page

Table 2-1. INTUITY AUDIX Voice Messaging Database Audits — Continued

Audit	Function	Frequency
Subscriber Data	Checks delivery lists associated with current outgoing messages	Weekly
	Validates fields in class-of-service templates, subscriber profiles, and automated attendant profiles	Weekly
	Counts subscribers to ensure that the number is not exceeding internal limits	Weekly
	Checks the system guest password against individual subscriber passwords, and makes appropriate entries in the administration log	Weekly
	Checks subscriber profiles against class-of-service templates and changes subscribers to class-of-service	Weekly
	Deletes remote unverified subscribers who have not been on delivery lists in the last 24 hours	Daily
	Deletes remote subscribers with no valid nodes	Daily
	Deletes unadministered remote subscribers who have not used the system for a specified time period	Daily
	Cross-checks name, extension, touch-tone, user directory, and remote node list translations files for consistency with subscriber profiles	Weekly

Voice Messaging Database Audits General Procedure

All of the voice messaging database audit types use the same general procedure.

Procedure

To audit a voice messaging database, do the following:

1. Start at the Lucent INTUITY Main menu ([Figure 2-1](#)).




Figure 2-1. Lucent INTUITY Main Menu

2. Select

```
> AUDIX Administration
```

The system displays the AUDIX Administration screen ([Figure 2-2](#)).




Figure 2-2. AUDIX Administration Screen

3. Enter the appropriate command from [Table 2-2](#) after the `enter` command prompt.

Table 2-2. Voice Messaging Database Audit Commands

To Audit	Enter
Mailboxes	audit mailboxes or au mailb
Mailing lists	audit mailing-lists or au maili
Names	audit names or au na
Network data	audit network-data or au ne  NOTE: This audit is available only if the system has Digital or AMIS Analog Networking. For more information on networking, see <i>AMIS Analog Networking</i> , 585-300-512, or <i>INTUITY AUDIX Digital Networking Administration</i> , 585-310-533.
Personal directories	audit personal-directories or au p
Subscriber data	audit subscriber-data or au su

The system displays an Audit screen ([Figure 2-3](#)).




Figure 2-3. Audit Screen

4. Press **F3** (Enter).
5. The system displays the audit name and Result code R, which indicate that the audit is running.
6. Wait for the audit to finish or take one of the following steps:
 - Press **F1** (Cancel) to abort the audit and exit the form.
 - OR
 - Press **F3** (Enter) to put the audit in the background mode and return to the command line. Enter **status audit** to reconnect to the screen.

Field Descriptions

A description of each display field is provided below.

- Date — This field displays the date and time that the audit was requested.
- Audit Name — This field displays the name of the audit being run.

- Result — This field displays a 1-character code that indicates the last result of the named audit, and up to 20 characters of text of additional audit-result information. [Table 2-3](#) lists the result codes and their meanings.

Table 2-3. Auditing Result Codes

Code	Meaning
blank	Audit has not been executed.
R	Audit is running.
P	Last audit passed.
F	Last audit failed.
A	Last audit aborted.

If the Audit Fails

If the audit fails, do the following:

1. Resolve any active alarms and rerun the audit. See Chapter 1, “Getting Started,” in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages* 585-310-566, for the alarm resolve procedure.
2. If the audit fails again, contact the remote service center.
3. If the system is not providing service and the remote service center cannot help immediately, restart the system. See “[Rebooting the System](#),” in [Chapter 3, “Common System Procedures”](#), for the procedure.

Auditing Networking Databases

The networking database consists of two parts: the networking administration database and the remote subscriber update status database. The networking administration database contains data relevant to the following areas:

- Connectivity to other Lucent INTUITY systems and AMIS machines
- Local machine connectivity
- Channel configuration information

The remote subscriber update status database contains the information used by the Lucent INTUITY system to request and send remote updates of subscriber information.

Networking Database Audit

The networking database audit consists of a series of internal checks which verify, for example, that files are not corrupted and that values within the files are within the proper ranges.

The networking database audit is performed automatically nightly, before the nightly unattended backup. This audit occurs whenever the voice system is restarted or the UNIX system is rebooted. You may want to perform this audit on demand when directed to do so by alarm repair actions.

To perform this audit on demand, do the following:

```
> Customer/Services Administration  
> Database Audits
```

The system displays the Database Audit menu ([Figure 2-4](#)).

```
Database Audits  
> Networking Audit  
Platform User Database Audit
```

Figure 2-4. Database Audit Menu

4. Make sure the cursor is on `Networking Audit`.
5. Press `F8` (Chg-Keys).
6. Press `F1` (Run Audit).

The system displays the Confirm Audit window ([Figure 2-5](#)).




Figure 2-5. Confirm Audit Window

7. Press **y**.



NOTE:

The audit takes approximately 5 minutes.

8. Press **F8** (Chg-Keys).
9. Press **F4** (View_Res).

If the audit is successful the system displays the following message:

```
Networking Database Audit completed successfully.
```

If the audit fails, the system displays the following message:

```
Networking Database Audit failed.
```

If a failure message appears, look for related alarms such as NW SOFTWARE-1004. Follow the repair actions for any active alarms as appropriate. See "Accessing the Alarm Log" in Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages* 585-310-566, for the procedure.

Platform User Database Audit

Because the Lucent INTUITY system switch integration software acts as the interface between the applications and the switch, the Lucent INTUITY system switch integration database must periodically be synchronized with the applications' databases. The Station Manager Subscriber Database audit performs this synchronization.

The Lucent INTUITY system switch integration database monitors the applications with which each user is registered. When the audit is executed, the station manager matches its user's extension and MWL status with each user application database. When successful matches are made, the audit progresses to the next user. If a match is not found, a message is printed in the audit report (see below).

This audit is performed automatically at 12:10 am. You may want to perform this audit on demand when alarms (SOFTWARE VP-12) indicate that subscribers cannot be found, users report message-waiting light problems, or the system was shutdown improperly causing databases to become unsynchronized.

Platform User Database Audit Procedure

To perform this audit on demand, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
```

```
> Database Audits
```

The system displays the Database Audit menu ([Figure 2-4](#)).

2. Make sure the cursor is on Platform User Database Audit.
3. Press **F8** (Chg-Keys).
4. Press **F1** (Run Audit).

The system displays the Confirm Audit screen ([Figure 2-5](#)).

5. Press **y** to confirm that you want to run the audit.

NOTE:

The audit takes approximately 60 minutes, depending on the system's load and may degrade service.

6. Press **F8** (Chg-Keys).
7. Press **F4** (View_Res).

If the audit is successful, the system displays the following message:

```
Station Manager Subscriber Audit is successfully done.
```

If the audit terminates before completion, the system displays the following message:

```
Station Manager Subscriber Audit is terminated because  
of <reason>.
```

If the Audit Fails

The audit could have prematurely terminated because of problems in the application with which it was synchronizing. For example, if a database could not be opened or the package is down the audit will prematurely terminate. Follow the repair actions for any active alarms as appropriate. See "Accessing the Alarm Log" in Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages* 585-310-566, for the procedure.

- If a user exists in the Lucent INTUITY system switch integration database but does not exist in any of the registered applications, the system displays the following message:

```
Station Manager Subscriber Database Audit found an  
extra subscriber user's extension requesting Station  
Manager to delete it from database
```

The user is automatically deleted from the Lucent INTUITY system switch integration database.

- If a user exists in one of the application databases and not in the Lucent INTUITY system switch integration database, the system displays the following message:

```
Station Manager Subscriber Database Audit found a  
missing subscriber user's extension requesting Station  
Manager to add it to database
```

The user is automatically added to the Lucent INTUITY system switch integration database.

- If the MWL status in the Lucent INTUITY system switch integration database does not match the MWL status in the application databases, the system displays the following message:

```
Station Manager Subscriber Database Audit found a  
mismatched subscriber user's extension requesting  
Station Manager to update its database
```

The user MWL status is automatically updated in the Lucent INTUITY system switch integration database.

Conducting Diagnostics

You can diagnose:

- AMIS Analog Networking
- INTUITY AUDIX Digital Networking
- Multi-port serial circuit cards
- Switch integration
- TCP/IP
- Voice circuit cards
- Voice ports

AMIS Analog Networking Diagnostics

AMIS analog networking diagnostics allow you to perform a trace of the system. The trace display information that describes the interaction between two voice messaging systems during an AMIS call.

Performing an AMIS Analog Networking Trace

To perform an AMIS analog networking trace, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> AUDIX Administration
```

The system displays the AUDIX Administration screen ([Figure 2-2](#)).

2. Enter **trace**

The system displays the AMIS Trace Activation screen ([Figure 2-6](#)).




Figure 2-6. AMIS Trace Activation Screen

3. In the AMIS-TRACE Activated? field, enter **y**
4. In the Trace Level: field, enter one of the following choices:
 - **full** - to trace errors, protocol, and touch tone information
 - **normal** - to trace errors and protocol
 - **error** - to trace errors
5. Press **ⓔ** (Enter).

Viewing the AMIS Analog Networking Trace Log

To view the AMIS analog networking trace log, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> AUDIX Administration
```

The system displays the AUDIX Administration screen ([Figure 2-2](#)).

2. Enter **display amis-trace**

The system displays the AMIS Trace Log screen ([Figure 2-7](#)).




Figure 2-7. AMIS Trace Log Screen

3. In the `Start Date:` field, enter the appropriate date.
4. In the `Time:` field, enter the appropriate time.
5. In the `Search String:` field, enter any key words.
6. Press **F3** (Enter).

The system displays the AMIS Trace Log screen ([Figure 2-8](#)).




Figure 2-8. AMIS Trace Log Screen

INTUITY AUDIX Digital Networking Diagnostics

INTUITY AUDIX Digital Networking diagnostics allow you to check all aspects of the networking feature including hardware connections, remote and local machine administration, and basic functions of INTUITY AUDIX Digital Networking. The INTUITY AUDIX Digital Networking diagnostics include the following tests:

- Remote connection
- Channel internal loop-around
- Modem loop-around
- Networking board reset
- Busyout digital networking channels
- Release digital networking channels

Remote Connection Test

The remote connection test checks the transmission path from the local machine to the remote machine. You can perform a remote connection test for each remote machine with which voice messages are exchanged. The test assumes that all components of the network, from the ACCX card to the remote machine administration, are operating and complete. If the remote connection test fails, see "[Network Connections Test](#)" below.

Requirements


The following requirements are necessary to perform a remote connection test:

- The remote machine name is needed
- The channel can be DCP or RS-232
- The channel must be equipped

Procedure

To perform a remote connection test, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Networking Diagnostics window ([Figure 2-9](#)).

Networking Diagnostics					
CHANNEL	TYPE	RATE	STATUS	MACHINE	ACTIVITY
-----	----	----	-----	-----	-----
1	DCP		NOT EQUIPPED		
2	DCP		NOT EQUIPPED		
3	DCP		NOT EQUIPPED		
4	DCP		NOT EQUIPPED		
5	DCP		NOT EQUIPPED		
6	DCP		NOT EQUIPPED		
7	DCP		NOT EQUIPPED		
8	DCP		NOT EQUIPPED		
9	DCP		NOT EQUIPPED		
10	DCP		NOT EQUIPPED		
11	DCP		NOT EQUIPPED		
12	DCP		NOT EQUIPPED		

Figure 2-9. Networking Diagnostics Window

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Networking Diagnostics menu ([Figure 2-10](#)).





Figure 2-10. Networking Diagnostics Menu

4. Select



The system displays the Remote Connection Test window ([Figure 2-11](#)).




Figure 2-11. Remote Connection Test Window

5. Enter the name of the remote machine to be tested.

If you do not know the remote machine name, press **F2** (Choices) to access a menu of remote machines. Select from the menu by moving the selection bar over a machine name and pressing **ENTER**.

6. If you are testing a dedicated RS-232 connection, enter the number of the dedicated channel.

The system displays the message `working...` and attempts to connect with the remote machine.

When the process completes, the system displays the Test Results window ([Figure 2-12](#)).




Figure 2-12. Test Results Screen for a Remote Connection Test

7. If the screen contains a message stating that the test completed successfully, continue with [Step 8](#).

If the screen contains a message stating that the test failed, press **F6** (Cancel) to exit the screen and return to the Networking Diagnostics menu ([Figure 2-10](#)). See "[Network Connections Test](#)" below for the procedure to determine the reason for the remote connection test failure.

8. Press **F6** (Cancel) to exit the screen and return to the Networking Diagnostics window ([Figure 2-9](#)).
9. Repeat Steps [2](#) through [8](#) for each remote machine to be tested.

The network's abilities to exchange voice messages can also be tested. *INTUITY AUDIX Digital Networking Administration*, 585-310-533, contains instructions for exchanging voice messages with test remote subscribers on each remote machine in the digital network after completing a remote connection test.

Network Connections Test

Use the instructions in this section to test each component of the digital network. Perform the following tests when a remote connection test fails or when voice messages cannot be exchanged with remote subscribers.

- Channel internal loop-around
- Modem loop-around (if applicable)
- Network loop-around

One other test may be performed to test or reset the network, the networking board reset. Do not perform this procedure unless instructed by the remote service center.

Channel Internal Loop-Around Test

The channel internal loop-around test checks the operation of an individual channel on the ACCX board. Perform this test first to make sure the board is operating correctly. If the board does not operate properly, the other acceptance tests will fail.

Requirements. The following requirements are necessary to perform a channel internal loop-around test.

- The channel can be DCP or RS-232.
- The channel must be equipped.

Procedure. To perform a channel internal loop-around test, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
```

```
> Diagnostics
```

```
> Networking Diagnostics
```

The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Networking Diagnostics menu ([Figure 2-10](#)).

4. Select

```
> Channel Internal Loop-Around Test
```

The system displays the Channel Internal Loop-Around Test window (Figure 2-13).



Figure 2-13. Channel Internal Loop-Around Test Window

5. Enter the channel number to be tested.

The system displays the message `working...` in the upper right corner of the screen and begins the test on the ACCX board channel.

When the process is complete, the system displays the Test Results window (Figure 2-14).




Figure 2-14. Test Results Window for a Channel Internal Loop-Around Test

6. If the screen contains a message stating the test completed successfully, continue with [Step 7](#).

If the screen shows that the test failed, access the Alarm Log enter **NW** as the application, and look for alarms related to the networking board. See Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages 585-310-566*, for the procedure.

7. Press **F6** (Cancel) until the system displays the Networking Diagnostics window ([Figure 2-9](#)).
8. Repeat Steps [2](#) through [7](#) for each equipped channel on the ACCX board.

Modem Loop-Around Test

⇒ NOTE:

This test does not function with all modems. Before conducting the test, contact the remote service center and verify that the test works for the modem.


The modem loop-around test checks the connectivity between the ACCX board and the modem through a channel configured as RS-232. The test sends a signal from the ACCX board to the modem and back. Perform this test to make sure the board and the modem are communicating and that the modem is configured correctly.

Requirements. The following requirements are necessary to perform a modem loop-around test:

- The channel state must be in a busyout. Check the status of the channel on the Networking Diagnostics screen. If the channel is not in a busyout state, see "[Busyout and Release Networking Channels](#)" in this chapter.
- The channel must be RS-232 with a modem.
- The channel must be equipped.

Procedure. To perform a modem loop-around test, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select




The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Networking Diagnostics menu ([Figure 2-10](#)).

4. Select



The system displays the Modem Loop-Around Test window ([Figure 2-15](#)).



Figure 2-15. Modem Loop-Around Test Window

5. Enter the channel number to be tested. The channel must be RS-232 and have a modem connected.

The system displays the message `working...` in the upper right corner of the screen. The system begins the test on the channel with the modem connected. When the process completes, the system displays the Test Results screen ([Figure 2-14](#)).

6. If the screen contains a message stating the test completed successfully, proceed to [Step 7](#) below.

If the screen shows that the test failed, see Chapters 3 and 4 of *INTUITY AUDIX Digital Networking Administration*, 585-310-533, for information on modem settings and cabling. In addition, access the Alarm Log enter **NW** as the application, and look for alarms related to networking modems. See Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages* 585-310-566, for the procedure.

7. Press **F6** (Cancel) to exit the screen and return to the Networking Diagnostics screen ([Figure 2-9](#)).
8. Repeat Steps [2](#) through [7](#) for each equipped channel that is RS-232 and has a modem connected.

Network Loop-Around Test

The network loop-around test checks the data transmission path that connects the local Lucent INTUITY machine with the service office (SO) and the public network. When a channel is in loop-around mode, the channel cannot exchange information with remote machines.

Requirements. This test can only be performed on DCP channels. The test should be coordinated with the local SO.

Operation. The test operates in the following manner.

- To perform the test, specify the channel number and data rate and start the channel in network loop-around mode.
- Notify the SO to send information to the channel to be tested.
- The SO sends a message which loops through the INTUITY AUDIX Digital Network and returns to the SO.
- The SO checks the message to verify that the same information sent was returned by Lucent INTUITY.

Procedure. To perform a network loop-around test, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
```

```
> Diagnostics
```

```
> Networking Diagnostics
```

The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Networking Diagnostics menu ([Figure 2-10](#)).

4. Select

```
> Network Loop-Around Test
```

```
> Start Test
```

The system displays the Start Network Loop-Around Test window ([Figure 2-16](#)).




Figure 2-16. Start Network Loop-Around Test Window

5. Enter **High** or **Low** in the `Speed:` field.

- High speed refers to channels configured as 64 Kbps DCP.
- Low speed refers to channels configured as 56 Kbps DCP.

6. Enter the channel number to be tested.

Make sure the channel number corresponds to the channel data rate entered in the previous step.

7. Press `F3` (Save).

The system displays the message `working...` in the upper right corner of the screen, places the channel in loop-around mode, and displays a Test Results window ([Figure 2-17](#)).




Figure 2-17. Start Test Results Window for a Network Loop-Around Test

8. Press `F6` (Cancel) to exit the screen and return to the Networking Diagnostics menu ([Figure 2-10](#)).

9. Contact the local telephone SO and instruct them to place a call to the telephone number assigned to the channel placed in the loop-around mode. If the test is successful, any data sent by the SO will pass through the Lucent INTUITY channel and return to the SO.

10. Stop the test and remove the channel from the loop-around mode by completing the following Steps a through c:

a. Select

```
> Network Loop-Around Test  
> Stop Test
```

The system displays the Stop Network Loop-Around Test window ([Figure 2-18](#)).



Figure 2-18. Stop Network Loop-Around Test Window

b. To stop testing the channel, enter the appropriated channel number in the Channel: field. This is the same channel number entered in [Step 6](#) above.

The system displays the message *working...* in the upper right corner of the screen, removes the channel from loop-around mode, and displays the Test Results window ([Figure 2-19](#)).




Figure 2-19. Stop Test Results Window for a Network Loop-Around Test

11. Press **F6** (Cancel) to exit the screen and return to the Networking Diagnostics menu ([Figure 2-10](#)).
12. Repeat Steps [2](#) through [11](#) for each channel to be tested.


Networking Board Reset

This section provides instructions for resetting the ACCX card.

Requirements. The card may need to be reset after other networking diagnostic tests have been performed. In addition, the card may need to be reset as part of an alarm repair procedure.

Procedure. To reset the networking card, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Networking Diagnostics menu ([Figure 2-10](#)).

4. Select



The system displays the Networking Board Reset window ([Figure 2-20](#)).




Figure 2-20. Networking Board Reset Window

5. Enter the number of the ACCX card to be reset.

The Lucent INTUITY system resets the networking card. The process takes several minutes. When the process completes, the system displays the Test Results window ([Figure 2-21](#)).



Figure 2-21. Networking Board Reset Results Screen

6. Press **F6** (Cancel) to exit the screen and return to the Networking Diagnostics menu ([Figure 2-10](#)).
7. Repeat Steps [2](#) through [6](#) for each ACCX card to be reset.

Busyout and Release Networking Channels


CAUTION:

Do not perform this procedure unless instructed to do so.

Busyout a channel refers to the process of taking a channel out of service so that no data is sent to the channel. *Releasing* a channel refers to the process of making the channel active again and changing the state from *busyout* to *idle*.

Busyout Networking Channels

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F2** (Busyout).

The system displays the Busyout Networking Channel window ([Figure 2-22](#)).



Figure 2-22. Busyout Networking Channel Window


4. Enter the number of the channel to busyout.

The system displays the message `working...` in the upper right corner of the screen. When the process completes, the Status field on the Networking Diagnostics window ([Figure 2-9](#)) updates and shows `busyout` for the channel entered.

5. Repeat Steps [2](#) through [4](#) for each channel to busyout.

Release Networking Channels

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Networking Diagnostics window ([Figure 2-9](#)).

2. Press **F8** (Chg-Keys).
3. Press **F2** (Release).

The system displays the Release Networking Channel window ([Figure 2-23](#)).



Figure 2-23. Release Networking Channel Window


4. Enter the number of the channel to be released.

The system displays the message `working...` in the upper right corner of the screen. When the process completes, the Status field on the Networking Diagnostics window ([Figure 2-9](#)) updates and shows `idle` for the channel entered.


5. Repeat Steps [2](#) through [4](#) for each channel to be released.

Performing a Network Snapshot

To perform a network snapshot, start at the Lucent INTUITY Main menu ([Figure 2-1](#)), and select



```
> Networking Administration
```



```
> Network Snapshot
```

The system displays the Network Snapshot window ([Figure 2-24](#)).

Network Snapshot						
LOG START DATE: 03/25			LOG END DATE: 05/02			
			OUTGOING CONNECTIONS		INCOMING CONNECTIONS	
MACHINE	LAST CONN.	STATUS	RETRY	LAST CONN.	STATUS	
drmid10						
a123456789						
drbig12						
lztiny1	04/30	03:20	success	04/28	11:12	success
lzccs21	04/24	10:45	success	04/24	10:42	success
lzintuit						
lzbig2						
test1						
scott_ss						
lzccs30	04/12	01:10	success	04/04	04:33	success
lzmid2	04/30	03:35	success	04/28	20:27	success
lzmid3						

Figure 2-24. Network Snapshot Window

Multi-Port Serial Card Diagnostics

The multi-port serial card is equipped with diagnostic utilities that allow you to monitor lead status, view port parameter settings, and test board functionality.

Accessing Multi-Port Serial Card Diagnostics

To access the multi-port serial card diagnostics, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
> Diagnostics
> Serial Port Diagnostics
```

The system displays the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)). This screen contains a menu bar with the options Driver Stats, Port Stats, and Diagnostics.




Figure 2-25. Megaport and Megaplex Configuration and Diagnostics Screen

- Use the right and left arrow keys on the keyboard to move between the menu bar options.
- Use the up and down arrow keys to move between menu options.
- Press (ENTER) to select a menu option.
- Press (F1) for help.
- Press (ESC) to exit.

Displaying Serial Port Driver Stats

The serial port driver stats include:

- Drive Status
- Board Status

Driver Status

The Driver Status option displays the device driver's current configuration including the driver version, number of boards configured, number of boards found, and memory mapping.

To display the drive status, do the following:

1. Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select

```
>Driver Stats
>Driver Status
```

2. Press **(ENTER)**.

The system displays the Driver Status window ([Figure 2-26](#)).

```
Driver Status
Equinox Megaport STREAMS Device Driver, Version 2.24a
Currently configured for 1 board(s) (logical).
Number of boards found: 1
Board address      BUFFER      REGISTER
Board # 1         0x000D0000  0x000D2000
```

Figure 2-26. Driver Status Window

Board Status

To display the board status, do the following:

1. Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select

```
>Driver Stats
>Board Status
```

2. Press **(ENTER)**.

The system displays the Board Status menu ([Figure 2-27](#)).

```
Board
/dev/ttysa[a-x]
/dev/ttysb[a-x]
/dev/ttysc[a-x]
/dev/ttysd[a-x]
/dev/ttyse[a-x]
/dev/ttysf[a-x]
/dev/ttysg[a-x]
/dev/ttysh[a-x]
/dev/ttysi[a-x]
/dev/ttysj[a-x]
```

Figure 2-27. Board Status Menu

Displaying Port Stats

Three options are available on the Port Stats menu:

- Port Status
- Termio
- Register Dump

These options allow the system to show certain port characteristics.

Port Status

The Port Status selection is a real-time representation of the RS-232 leads. It includes:

- Transmit rate
- Receive rate
- Total characters received
- Total characters transmitted
- Buffered data counts

The Port Status display is useful in troubleshooting wiring problems, chattering lines or devices (modems) and in monitoring load activity over a single line. Activity measurements can be taken by noting the Transmitted and Received counts and comparing them with other serial ports.

To display the port status, do the following:

- Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select

```
> Port Stats
> Port Status
```

- Press **ENTER**.

The system displays the Prompt window ([Figure 2-28](#)).

```
device: /dev/ttysaa
```

Figure 2-28. Prompt Window

- Enter the name of the device to be verified.

The system displays the Port Status window ([Figure 2-29](#)).

OUTPUT		INPUT	
TD	OFF	RD	OFF
DTR	OFF	DCD	OFF
XON/XOFF	XON'ed		
Status	CLOSED		
CPS	0	CPS	0
Transmitted	0	Received	0
Buffered	0	Buffered	0


Figure 2-29. Port Status Window

Termio

The Termio option displays the general terminal interface data associated with the serial card. It is similar to the “stty” command in that it prints all enabled termio flags.

To display the termio, do the following:

1. Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select



```
> Port Stats
> Termio
```


2. Press **(ENTER)**.
The system displays the Prompt window ([Figure 2-28](#)).
3. Enter the name of the device to be verified.
The system displays the Termio window.

Register Dump

The Register Dump option displays a real-time window of the on-board registers. The data is in raw form and useful to only Equinox technical personnel. It is used to obtain information about the hardware status and various software flags.

To display the Register Dump, do the following:

1. Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select



```
> Port Stats
> Register Dump
```

2. Press **(ENTER)**.
The system displays the Prompt window ([Figure 2-28](#)).
3. Enter the name of the device to be verified.
The system displays the Register Dump window ([Figure 2-30](#)).

```

Reg. dump for /dev/ttyxaa
State: 00000000 mp_flags: 00000000
cflag: 00000000 iflag: 0522 oflag: 0000 lflag: 0000

txbase: 00000000 txidx: 00000000 txend: 00000000
rxbase: 00000001 rxidx: 00000000 rxend: 00000000
txcs: 00000088 txbaud: 000000FE out_ct: 00000003
rxcs: 00000088 rxbaud: 000000FE in_ctl: 000000FF
txcsr: 00002081 rxcsr: 00002081 sample: 00000021
mie: 00000000 cie: 00000000 cis: 00000200
rxtdm: 000000CF txtdm: 000000C3
equlz: 00000000 eqmin: 00000000 eqmax: 00000000 linkst: 00000000
Transmit: 00000000 Receive: 00000000
  
```

Figure 2-30. Register Dump Window

Conducting Diagnostics

There are two options on the Diagnostics portion of the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)):

- Loopback
- Send

These tests are intended for the experienced user. The Loopback test is designed to diagnose the board's primary components and their functionalities. There are two types of loopback tests: internal and external. The Send test simply writes a continuous stream of data to the specified port, which is helpful in resolving wiring issues.

Serial Port External Loopback Test


Although the option for the serial port external loopback test appears on the screen, this option is not available. Use the internal loopback test option instead.

Serial Port Internal Loopback Test

The internal loopback test is the same as the external loopback test except that it does not require that the transmit and receive pins be wired together. Because it does not test the full cabling of the port, the internal loopback test is not as thorough as the external loopback test.

To perform the serial port internal loopback test, do the following:

1. Starting at the Megaport and Megaplex Configuration and Diagnostics screen ([Figure 2-25](#)), select



2. Press **ENTER**.

The system displays the Loopback menu ([Figure 2-31](#)).




Figure 2-31. Loopback Menu

3. Select



4. Press **ENTER**.

The system displays the Configure menu ([Figure 2-32](#)).



Figure 2-32. Configure Menu

5. Select



6. Press **(ENTER)**.

The system displays the Board menu ([Figure 2-27](#)).

7. Press **(ENTER)** to select the first group of ports.
8. Press **(ESC)**.

The system displays the Loopback menu ([Figure 2-31](#)).

9. Select



10. Press **(ENTER)**.

The system displays the Run menu ([Figure 2-33](#)).



Figure 2-33. Run Menu

11. Place the cursor on 8 Ports.
12. Press **(ENTER)**.

The system displays the Loop Type menu ([Figure 2-34](#)).




Figure 2-34. Loop Type Menu

13. Place the cursor on Internal Loopback.
14. Press **(ENTER)**.

The system displays the Internal Loopback window ([Figure 2-35](#)).

Port	Xmit	Rcv	Errors	Rate	Note
saa	156825	151264	0	3874	ESC to exit F2 Reset Errors F3 Reset Test F4 Refresh Screen
sab	156825	151237	0	3874	
sac	156825	151258	0	3875	
sad	156825	151230	0	3876	
sae	156825	151219	0	3875	
saf	156825	151195	0	3870	
sag	156825	151170	0	3861	
sah	156825	151160	0	3857	


Figure 2-35. Internal Loopback Window

Serial Port Send Test

The Send test simply writes a continuous stream of printable alphanumeric characters to the specified port. This is helpful when a new device is being added to the system and a continuous stream of data is required to resolve wiring issues.

To perform the serial port send test, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



2. Press `(ENTER)`.
 The system displays the Prompt window ([Figure 2-28](#)).
3. Press `(ENTER)`.
 The system displays the Speed menu ([Figure 2-36](#)).




Figure 2-36. Speed Menu

4. Select the appropriate speed.
5. Press **ENTER**.

The system displays the Characters Transmitted window ([Figure 2-37](#)).




Figure 2-37. Characters Transmitted Window

Switch Integration Diagnostics

Switch integration is the mechanism by which the Lucent INTUITY system and the switch share information. The method of integration is determined by the switch.



NOTE:

At this time, switch integration diagnostic utilities are available only for Lucent data communications interface unit (DCIU) integrations. Therefore, the procedures in the section only apply to those customers with DCIU integrations.

The following switch integration diagnostic utilities are available:

- View switch link status
- Diagnose switch integration card

- Reset switch integration hardware and software
- Busy-out switch integration link
- Release switch integration link

View Switch Link Status

View in the switch link status provides information on the switch link.

Procedure

To view the status of the switch link, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
```

```
> Diagnostics
```

```
> Switch Interface Diagnostics
```

The system displays the Diagnose Switch Link window ([Figure 2-38](#)).

```
Diagnose Switch Link
STATUS SWITCH-LINK
Type  Baud   State
DCIU  9600   In Service

Link Level 2 is Up

DCIU switches (In/Out of data transfer)
  1  2  3  4  5  6  7  8  9 10 11 12 13 14 15 16 17 18 19 20
  I
```

Figure 2-38. Diagnose Switch Link Window

Results

[Table 2-4](#) explains each field on the STATUS SWITCH-LINK portion of the Diagnose Switch Link screen. When troubleshooting, first make sure that the link is In service (State field) and Up (Link Level 2 field). If the link is Down, there is likely a physical connection problem (cabling) or a translation problem on the switch. Access the alarm log for more information. See Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4 Alarms and Log Messages* 585-310-566, for the procedure.

Table 2-4. Switch Link Status Fields

Status Field	DCIU Value	Definition
Type	DCIU	This is the mode of switch integration for the Lucent INTUITY system.
Baud	9600	This is the speed at which the Lucent INTUITY system and the switch communicate.
State	In Service or BUSIED	This is the status of the link. In Service means that the link is up and running and functioning normally. BUSIED means that the link has been manually busied out.
Link Level 2 is	Up or Down	The field tells you whether the link is Up (actively processing data for calls) or Down (not processing data for calls).
DCIU Switches (In/Out Of Data Transfer)	I, O, or blank	The numbers 1 through 20 represent switches in a DCS network. An "I" indicates that the switch is "in data transfer" and operational. An "O" indicates that the switch is "out of data transfer" and not operational. If the space under the switch number is blank, that particular switch is not being translated for use with the Lucent INTUITY system.

DCIU Circuit Card Diagnostics

The DCIU circuit card is equipped with diagnostic utilities that test circuit card functionality. This diagnostic checks the circuit card's timer and parity. It also does several local loopback tests.

If the system detects a switch link problem, it can invoke this diagnostic automatically.

It may be necessary to diagnose the switch link in order to troubleshoot problems on the Lucent INTUITY system. Do not diagnose the switch link unless instructed to do so.


CAUTION:

Diagnosing the switch integration card disables all lines associated with the switch link, including all INTUITY AUDIX Voice Messaging lines. Subscribers calling AUDIX will hear a fast busy signal. Callers sent to AUDIX coverage will hear ringing with no answer.

Diagnostics Procedure

To diagnose the switch integration card, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Diagnose Switch Link window ([Figure 2-38](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Test Type menu ([Figure 2-39](#)).



Figure 2-39. Test Type Menu

4. Select

```
> Board
```

The diagnostic test takes about one minute. The word `working` appears in the upper right corner of the screen.

Diagnostic Results

If the diagnosis of the DCIU circuit card is successful, the system displays the following series of messages.

```
EiconCard Self-Test Utility  
ectest 3.03 Rev. 08  
Copyright (c) Eicon Technology Corporation 1995. All  
Rights Reserved.
```

```
-----  
Card #1: EC C20
```

```
ectest: Warning #FA304  
The application software running on EiconCard #1 was  
stopped.
```

```
CARD CONFIGURATION:
```

```
I/O Port Address      : 240  
Interrupt Request Level : 12  
Memory size           : 1024K
```

```
CARD DIAGNOSTIC
```

```
In progress...
```

```
EiconCard EC C20, Diagnostic: Passed
```

```
-----  
DIAGNOSTIC SUMMARY:
```

```
Card #1: Success.  
-----
```

⇒ NOTE:

Not all of the information displayed by the diagnostics appears in the first Command Output window. You must scroll down the window using the function keys.

If the diagnostics fail, replace the DCIU circuit card. See [“DCIU Circuit Card”](#) in [Chapter 5, “Replacing or Installing Circuit Cards”](#).

Reset Procedure

This diagnostic command resets and initializes the DCIU circuit card and its associated software (DCIU software). Occasionally, the DCIU link “hangs.” Resetting the switch integration hardware and software often remedies the problem without a lot of down time.

To reset the switch integration card and its software, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
```

```
> Diagnostics
```

```
> Switch Interface Diagnostics
```

The system displays the Diagnose Switch Link window ([Figure 2-38](#)).

2. Press **F8** (Chg-Keys).
3. Press **F4** (Diagnose).

The system displays the Test Type menu ([Figure 2-39](#)).

4. Select

```
> Board
```

The reset takes approximately one minute. When it is finished the system displays the following message:

```
Reset completed.
```


Digital Station Interface Circuit Card Diagnostics

To diagnose a digital station interface circuit card, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Switch Interface Administration  
> Call Data Interface Administration  
> Switch Link Administration  
>VB-PC Interface  
Link Status
```

The system displays the Link Status window ([Figure 2-40](#)).



UBPC Port Number	Usage	Link Status
1	Main Port	LINK_UP
2	Integration	LINK_UP
3	Integration	LINK_UP
4	Integration	LINK_UP
5	Integration	LINK_UP
6	Integration	LINK_UP
7	Integration	LINK_UP
8	Integration	LINK_UP

Figure 2-40. Link Status Window

Switch Integration Link Busy-Out Procedure

Busying out the switch link disables all lines associated with the switch link, including all INTUITY AUDIX Voice Messaging lines. Subscribers calling AUDIX will hear a fast busy signal. Callers sent to AUDIX coverage will hear ring/no answer. It may be necessary to busy-out the switch link in order to troubleshoot or replace the switch card or its cables. Do not busy-out the switch link unless instructed to do so.

CAUTION:

In order to prevent alarms being generated by the switch, also busy out the switch link at the switch any time you busy out the switch from the Lucent INTUITY system. See the appropriate switch documents for the procedures.

To busy-out the switch link, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select

```
> Customer/Services Administration
> Diagnostics
> Switch Interface Diagnostics
```

The system displays the Diagnose Switch Link window ([Figure 2-38](#)).

2. Press **F8** (Chg-Keys).
3. Press **F2** (Busyout).

The system displays the Confirm window ([Figure 2-41](#)).

```
Confirm
WARNING: The DCIU board is currently in
use. Removing it from service will
disable all lines associated with the
DCIU, including all AUDIX lines.

Press <y> to confirm.
Press <n> to cancel.
```

Figure 2-41. Confirm Window



CAUTION:

The DCIU board is currently in use. Removing it from service will disable all lines associated with DCIU, including all voice lines. Subscribers calling will hear a fast busy signal. Callers sent to coverage will hear ring/no answer.

4. Press **y**

The system displays a Busyout Command Output window ([Figure 2-42](#)).





Figure 2-42. Busyout Command Output Window

Switch Integration Link Release Procedure

Releasing the switch link puts the link back in service so that it can accept and process data.

To release the switch link, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Diagnose Switch Link window ([Figure 2-38](#)).

2. Press **F8** (Chg-Keys).
3. Press **F3** (Release).

The system displays Release Command Output window ([Figure 2-43](#)).




Figure 2-43. Release Command Output Window

TCP/IP Diagnostics

Use the TCP/IP diagnostics screens when subscribers are experiencing problems with Lucent INTUITY Message Manager. These screens can help diagnose TCP/IP problems and can determine if the Lucent INTUITY system is communicating properly with other machines.

You can use the TCP/IP diagnostics screens to do the following:

- Test the Lucent INTUITY system's TCP/IP software.
- Test the connection between the Lucent INTUITY system and a subscriber's PC.
- View the statistics for the LAN card.

For the two tests, test data (packets) are sent back and forth from the Lucent INTUITY system to a networked machine. If no problems exist, the data is returned exactly as it was sent.


Testing the TCP/IP Software

If subscribers are experiencing difficulties with Lucent INTUITY Message Manager, first ensure that the problem is not with the Lucent INTUITY system's UNIX TCP/IP software. For this procedure, run the diagnostic on the Lucent INTUITY system itself. This test does *not* involve the LAN card or the network.

Procedure

To test the TCP/IP software, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Send & Receive Test Packets From window ([Figure 2-44](#)).



Figure 2-44. Send and Receive Test Packets Window

2. Enter the Internet Protocol (IP) address of the Lucent INTUITY system (*not* a PC address).

For this information, see the TCP/IP Administration screen.

3. Press **F3** (Save).

The system displays the message *working...* in the upper right corner of the screen. While the cursor flashes, the system is performing the test.

When finished, the system displays the Test Packets Results window ([Figure 2-45](#)). This screen shows the results of sending 10 test packets from the Lucent INTUITY system to itself.

```

Test Packets Results
72 bytes from xxx.xx.xx.xx: icmp_seq=0. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=1. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=2. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=3. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=4. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=5. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=6. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=7. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=8. time=0. ms
72 bytes from xxx.xx.xx.xx: icmp_seq=9. time=0. ms

---- xxx.xx.xx.xx PING Statistics----
10 packets transmitted, 10 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 0/0/0

Note: High packet loss, long round-trip time, or packets received out
of order (icmp_seq) may indicate a network problem.

Press <HELP> for more information, <CANCEL> to continue.
  
```

Figure 2-45. Sample Test Packets Results Window

Results

Examine the packet loss field in the PING Statistics displayed on the Test Packets Results screen. The value for this field will be either 0% or 100%, as described below.

- If 0% packet loss is reported, the test is successful. This result indicates that the problem is *not* with the Lucent INTUITY system's TCP/IP software; however, the problem may be with the LAN card or the network. To further isolate the problem, test the connection between the Lucent INTUITY system and the troubled subscriber's PC. See "[Testing the Connection Between the Lucent Intuity System and a Subscriber's PC](#)" below for the procedure.
- If 100% packet loss is reported, the test failed. Check with your LAN administrator to ensure that you used the correct IP address for the system. This result may indicate a problem with the Lucent INTUITY system's UNIX TCP/IP software. Reboot the system, and repeat this test. If the test still fails, contact your remote services center. See "[Rebooting the System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.


Testing the Connection Between the Lucent INTUITY System and a Subscriber's PC

Once it has been determined that the Lucent INTUITY system's TCP/IP software is functioning correctly (see ["Testing the TCP/IP Software"](#) above), it needs to be determined that the Lucent INTUITY system can properly communicate with the troubled subscriber's PC.

Procedure

To test the LAN card and the network, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Send & Receive Test Packets From window ([Figure 2-44](#)).

2. Enter the Internet Protocol (IP) address for the PC to which you want to have test packets sent and received.
3. Press **F3** (Save).

The system displays *working* and a flashing cursor at the upper right corner of the screen. While the cursor flashes, the system is performing the test.

The system displays the Sample Test Packets Results window ([Figure 2-45](#)) when the test is finished.

Results

The results for the LAN test are described below:

- *icmp_seq*: The sequence identifier of the packet. The packets are numbered from 0 to 9, in the order that they were sent, and are displayed on the screen in the order that they were returned. If one or two packets are returned out-of-sequence, the condition is acceptable to the Lucent INTUITY system. However, if more than two packets are out-of-sequence (for example, 0, 2, 5, 3, 1...), inform the LAN or system administrator. Out-of-sequence packets may indicate network congestion or misrouting.
- *time*: The round trip transmission time, in milliseconds (ms), of the packet. Round trip delays greater than 10,000 ms may indicate a network problem.
- *packet loss*: The percentage of packets that were not returned during the test. The number of lost packets will vary from network to network. Percentage of loss depends upon the number of users, the number of machines, and the distance between machines.
 - Consider the test successful if the Lucent INTUITY system reports a packet loss percentage between 0 and 49%. Do, however, inform the LAN or system administrator if the loss is above 10%. Slow response time may be the result of such a loss.
 - Consider the test a failure if the Lucent INTUITY system reports a packet loss percentage between 50% and 99%. In this range, Lucent INTUITY Message Manager performance will be extremely slow or will completely fail.
 - A 100% packet loss indicates that the Lucent INTUITY system has not established communication to the test machine address. The test will not report if packets are being sent to an incorrect or non-existent machine. Verify that you used the correct IP address for the PC. To further isolate the problem, repeat the test for a PC *not* experiencing problems with Lucent INTUITY Message Manager. If this test succeeds, the problem is with the first test PC. If this test fails, the problem is likely with the Lucent INTUITY system's LAN card or the network connection to the Lucent INTUITY system.


Viewing LAN Circuit Card Packet Statistics

The Packet Statistics screen displays data concerning traffic on the LAN card used for Lucent INTUITY Message Manger. Use this screen to identify problems occurring with the LAN card and the network.

Procedure

To view the packet statistics, do the following:

- Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Packet Statistics window ([Figure 2-46](#)).

Packet Statistics									
Name	Mtu	Network	Address	Ipkts	Ierrs	Opkts	Oerrs	Collis	
lo0	8256	127	127.0.0.1	10661201	0	10661201	0	0	
sme0	1500	135.9.181	135.9.181.76	0	0	22185759	77962	0	

Note: The Ethernet board is named sme00. Abnormally high values in the "Ierrs", "Oerrs", or "Collis" columns may indicate a network problem.

Press <HELP> for more information, <CANCEL> to continue.

Figure 2-46. Packet Statistics Window

Interpreting the Packet Statistics Window

[Table 2-5](#) explains each field on the Packet Statistics window. Once the system is turned on, packets (data) are sent over the network as interactions occur.

To see the statistics for the LAN card, examine the data for the line beginning with "sme00." When the data on this screen indicates problems with the network, contact your LAN administrator.

Table 2-5. Fields on Packet Statistics Screen

Field	Description
Name	The name of the interface. The LAN card is "sme00." An asterisk (*) in the field indicates that the interface is not enabled.
Mtu	The maximum transmission unit in bytes. This field indicates the longest packet that can be transmitted without needing to be split.
Network	The network to which the interface provides access. For the LAN card (sme00), the value for this field is always "none."
Address	The IP address assigned to this interface. For the LAN card (sme00), the value for this field is always "none."
Ipkts	The number of packets received over the network since the Lucent INTUITY system was turned on.
Ierrs	The number of damaged packets received. A value for this field greater than 10% of the packets received (Ipkts) indicates that the network is too busy and performance is slow.
Opkts	The number of packets sent over the network since the Lucent INTUITY system was turned on.
Oerrs	The number of packets damaged while being sent. A value for this field greater than 10% of the packets sent (Opkts) indicates that the network is too busy and performance is slow.
Collis	The number of collisions occurring on the network. A collision occurs when two machines on the network attempt to transmit a packet at the same time. Packets will be sent again; however, too many collisions can slow down the network. A value for this field greater than 10% of the packets sent (Opkts) indicates that the network is too busy and performance is slow.

- loop current/dial tone detection
- manipulation of hook state
- play
- ring detection
- speed control
- touch tone receive
- touch tone transmit



NOTE:

The gain control, loop current/dial tone detection, manipulation of hook state, ring detection, speed control, touch tone receive, and touch tone transmit test types will be run during a voice port loop around test regardless of the entry in the `Test Type:` field.

5. Enter **no** in the `Immediate Diagnose?` field.

If you enter **yes** in this field the diagnosis will be performed immediately regardless of the current state of the dialing channel.

6. Press **F3** (Save).

The system completes the diagnostics and displays the Voice Port Loop Around Test Results screen ([Figure 2-48](#)).

Voice Port Loop Around Test Results

```
manipulation of hook state      pass
gain control                    pass
speed control                   pass
ring detection                  pass
touch tone transmit             pass
play                            pass
touch tone receive              pass
record                          pass
fax receive                     pass
fax transmit                    pass
loop current/dial tone detection pass
```

Press Enter to continue.

Figure 2-48. Voice Port Loop Around Test Results Screen

7. Press **(ENTER)**.

The system displays the Voice Port Loop Around Test window ([Figure 2-47](#)).


Tip/Ring Circuit Card Diagnostics

To determine which Tip/Ring circuit card is having a problem, look at the alarm log. See Chapter 1, "Getting Started," in *Lucent INTUITY Alarms and Log Messages* 585-310-566, for more information on the alarm log.

Procedure

To diagnose one or more Tip/Ring circuit cards, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Diagnose Equipment window ([Figure 2-49](#)).




Figure 2-49. Diagnose Equipment Window

Each voice card has a number (0 through 2) which is determined by the card's address set by dip switches. A card's number is shown on the first line of its display.

2. Enter **card** in the `Equipment to diagnose:` field.

3. Enter the number of the card(s) you want to diagnose in the `Equipment Number` field.



CAUTION:

Do not diagnose all of the voice cards at once. This may leave no channels available on the system to accept incoming calls.

You can enter card numbers in several forms:

- A single card number (for example: 1)
 - A range of card numbers (for example: 0-2)
 - A list of single card numbers (for example: 0,1,2)
 - A list of single cards and ranges (for example: 0-2)
4. Enter **n** in the `Immediate Diagnosis?` field so that the card will be diagnosed when it is free of calls.



CAUTION:

*Diagnosing voice cards immediately by entering **y** in the `Immediate Diagnosis?` field will disconnect calls in progress. Do not enter **y** unless call traffic is extremely low. Diagnosing voice cards only when they are free of calls may take longer, but no calls will be disconnected.*

5. Press `F3` (Save).

Depending on the number of cards selected, diagnosis can take several minutes. When the diagnosis is complete the system displays the following message:

```
Request to diagnose Tip/Ring card <number> is
completed.
```

```
Press Enter to continue.
```

6. Press `ENTER`.

Results

The voice card diagnostics progress through three main steps.

- Each channel (and as a result the entire card) is taken out of service by changing its state to MANOOS (manually out of service).
- Each channel is checked for loop current. Loop current is present on a channel when a live telephone line is physically connected between the IVC6 port and a properly administered switch port.
- Each channel (and as a result the entire card) is put back into service by changing their states to INSERV (in-service).

If a card and all of its channels pass diagnostics, each channel is returned to its previous state (prior to the diagnostic), and the following message is shown in the Diagnose Equipment Results screen.

Diag TR *number*, Passed.

The following messages are normal outputs of the diagnostic process and do not affect the operation of the card.

- Diag TR *number*, Not attempting dial tone training
(/vs/switch/analog/noDTtrain exists)

For some switches, dial tone training is turned off because if the Lucent INTUITY system tries to get dial tone from many switch ports at one time, failures can occur on the switch side.

- Found Loop current on channel *number*

This message indicates that there is a working telephone line attached to the voice port.

- Request to diagnose Tip/Ring *number* completed

This message indicates that all requested tests have been completed.

The following list shows messages printed in the Diagnose Equipment Results screen that could signal problems.

- No loop current on channel *number*

OR

Channel number changed to state FOOS

The Lucent INTUITY system does not detect a working telephone line connected to the voice port. If this occurs, do the following:

1. Verify that the telephone line is securely connected to the voice card and the switch.
2. Verify that the analog line is set up properly on the switch. See the switch integration document included with your Lucent INTUITY system documentation set for more information.
3. Verify that the switch port has a dial tone, by removing the analog line, plugging in an analog telephone, and listening with the handset for dial tone. If there is dial tone, the voice card is likely the problem. If there is no dial tone, the problem is on the switch side. Verify switch wiring and administration.

- Diag TR *number*: No dial tone frequencies set

The Lucent INTUITY system did not detect dial tone, but it did detect loop current (phone line is attached). This could be a result of excessive load on the switch circuit pack. If this occurs, do the following:

1. Verify that Lucent INTUITY system analog lines are distributed over several switch circuit packs.
 2. Verify that the switch administration for the ports is valid.
 - Channel number changed to state BROKEN
- OR
- Card number changed to state BROKEN


The channel or card is not working. Replace the Tip/Ring circuit card. See [“Tip/Ring Circuit Cards”](#) in [Chapter 5, “Replacing or Installing Circuit Cards”](#).

Busying out a Tip/Ring Circuit Card

Busying out a Tip/Ring circuit card takes all channels on that card out of service (MANOOS or manually out of service state) so that calls are not forwarded to those channels. You may also busy out one or more individual channels.

To busy out a Tip/Ring circuit card, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Busyout of Voice Equipment window ([Figure 2-50](#)).




Figure 2-50. Busyout of Voice Equipment Window

The `New State:` field displays `manoos`. This is the state to which the cards or channels selected will be changed. This field cannot be changed.

2. Enter **card** or **channel** in the `Equipment:` field.
3. Enter the number of the card(s) or channel(s) you want to busyout in the `Equipment Number:` field.

 **CAUTION:**

Do not busyout all of the voice cards at once. This may leave no channels available on the system to accept incoming calls.

Card numbers range from 0 through 2, channel numbers range from 0 through 17. You can enter card and channel numbers in several forms.

- A single card number (for example: 1)
 - A range of card numbers (for example: 0-2)
 - A list of single card numbers (for example: 0,1,2)
 - A list of single cards and ranges (for example: 0-2)
4. Enter **n** in the `Change Immediately?` field so that the card or channel will busy out when it is free of calls.

 **CAUTION:**

*Busying out voice cards or channels immediately by entering **y** in the `Change Immediately?` field will disconnect calls in progress. Do not enter **y** unless call traffic is extremely low. If **n** is entered, the voice cards or channels will busy out when they are free of calls. Busying out voice cards and channels only when they are free of calls may take longer, but no calls will be disconnected.*

5. Press **F3** (Save).


When the state change is complete, the system displays a Command Output screen.

Releasing a Tip/Ring Circuit Card

Releasing a Tip/Ring circuit card puts all channels on that card in service (INSERV) so that they can accept and process calls. You can also release one or more individual channels.

To release a Tip/Ring circuit card or channels, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 2-1](#)), select



The system displays the Release of Voice Equipment window ([Figure 2-51](#)).




Figure 2-51. Release of Voice Equipment Window

The `New State:` field displays `insert` (in service). This is the state that the cards or channels selected will be changed to. This field can not be changed.

2. Enter **card** or **channel** in the `Equipment:` field.
3. Enter the number of the card(s) or channel(s) you want to release in the `Equipment Number:` field.

Card numbers range from 0 through 10, channel numbers range from 0 through 63. The card and channel numbers can be entered in several forms.

- A single card number (for example: 1)
- A range of card numbers (for example: 0-2)
- A list of single card numbers (for example: 0,1,2)
- A list of single cards and ranges (for example: 0-2)

4. Enter **y** in the Change Immediately? field so that the card or channel will be released immediately.
5. Press **F3** (Save).

Common System Procedures

3

Overview

This chapter describes:

- Cartridge tape and diskette drive operating procedures
- Backup and restore procedures
- Voice system administration procedures

Purpose

The purpose of this chapter is to provide the procedures necessary to perform the most common procedures associated with the Lucent™ INTUITY™ system.

Accessing the Product ID

The product ID is a 10-digit number used to identify each Lucent INTUITY system. You must have the product ID when contacting your remote maintenance service center.

To access the product ID, do the following:

1. Start at the Lucent INTUITY Main menu ([Figure 3-1](#)).





Figure 3-1. Lucent INTUITY Main Menu

2. Select



The system displays the Alarm Management window ([Figure 3-2](#)).

Alarm Management	
Product ID	2999999999
Alarm Destination	916148606427
Alarm Origination	ACTIVE
Alarm Level	MINOR
Alarm Suppression	ACTIVE
Clear Alarm Notification	ACTIVE

Figure 3-2. Alarm Management Window

- Record the product ID for use with the remote maintenance center.

About Cartridge Drives and Tapes

Cartridge tapes provide for the storage of information used by the Lucent INTUITY system. The MAP/100 reads information from and writes information to cartridge tapes through the tape drive. The tape drive is located in Bay 9.

Types of Cartridge Tape Drives

The MAP/100 uses two types of tape drives:

- 2-Gbyte
- 525-Mbyte



NOTE:

All tapes created in a 2-Gbyte tape drive can be read by a 525-Mbyte tape drive. The only tapes, created in a 525-Mbyte tape drive, which can be read by a 2-Gbyte tape drive, are Lucent INTUITY system backup tapes.

When to Change Cartridge Tapes

The manufacturers of the cartridge tapes recommend that you replace a tape after approximately 30 full-capacity write or read operations. For example, if two tapes are being alternated for the unattended nightly backup, replace both tapes every 2 months.

Inserting and Removing Cartridge Tapes

2-Gbyte Drive

Inserting the Cartridge Tape

1. Locate the tape drive on the front of the MAP/100 ([Figure 3-3](#)).
-




Figure 3-3. Front View of the MAP/100

2. Check the read/write dial to make sure that the tape is not write-protected. The small dial on the front of the tape should be in the horizontal position.
3. Complete Steps a through c to insert the tape:
 - a. Press the button on the upper right corner of the drive to open the drive door.
 - b. Insert the tape ([Figure 3-4](#)).
 - c. Close the door to push in the tape.




Figure 3-4. Tape Insertion with a 2-Gbyte Tape Drive



NOTE:

The light on the 2-Gbyte drive will blink when the drive is in use. If the light is lit and not blinking, the tape drive is idle.

Removing the Cartridge Tape

1. Press the button on the upper right corner of the drive to reveal part of the tape.
2. Pull out the tape.



CAUTION:

You can only remove the tape when the drive is idle, that is, when the light is not blinking.

525-Mbyte Drive

Inserting the Cartridge Tape

1. Locate the tape drive on the front of the MAP/100 ([Figure 3-3](#)).
2. Check the read/write dial to make sure that the tape is not write-protected. The small black dial on the front of the tape should be in the horizontal position.
3. Insert the tape firmly and the door locks automatically ([Figure 3-5](#)).




Figure 3-5. Tape Insertion with a 525-Mbyte Tape Drive



NOTE:

The light on the 525-Mbyte tape drive is on when the drive is in use. If the light is not on, the tape drive is idle.

Removing the Cartridge Tape

1. Place your middle and index fingers on the side of the tape currently in the drive, press firmly inward, then release.
2. The tape should pop out.



CAUTION:

You can only remove the tape when the drive is idle, that is, when the light is not on.

Formatting Cartridge Tapes

Formatting prepares a cartridge tape to receive data. To format a cartridge tape, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)), select

```
> Customer/Services Administration
```

```
> System Management
```

```
> UNIX Management
```

```
>Format UNIX Floppy/Tape
```

The system displays the Format UNIX Floppy/Tape menu ([Figure 3-6](#)).

```
Format UNIX Floppy/Tape
>Format 3.5 inch 1.44 Mbyte (High Density)
Format 3.5 inch 720 Kbyte (Low Density)
Format Cartridge Tape
```

Figure 3-6. Format UNIX Floppy/Tape Menu

2. Select `Format Cartridge Tape`.
3. Verify that the tape is not write-protected and insert the tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" below for more information.
4. Press `y`
The system displays a screen stating that the tape has been formatted.
5. Remove the tape from the tape drive.
6. Press `(ENTER)` to continue.

About Diskette Drives and Diskettes

Floppy disks can provide for the storage of information used by the Lucent INTUITY system. If information must be transferred from an Lucent INTUITY system without a LAN card, floppy disks must be used.

NOTE:

In the past, disks made of a soft pliable material were used, and hence were called “floppy” disks and their drives “floppy” drives. Diskettes are used exclusively now.

Types of Diskettes

The Lucent INTUITY system is not shipped with disks. If you need disks, obtain unformatted 3.5-inch disks. The disks can be either:

- High density (1.44-Mbyte)
- Low density (720-Kbyte)

Inserting and Removing Diskettes

Inserting the Diskette

1. Locate the diskette drive on the front of the MAP/100 ([Figure 3-3](#)).
2. Check the read/write switch to make sure that the diskette is not write-protected. The small dial on the front of the tape should be in the horizontal position.
3. Insert the diskette in the drive.

NOTE:

The light on the diskette drive is on when the drive is in use. If the light is not on, the diskette drive is idle.

Removing the Diskette

1. Press the button on the lower right corner of the diskette drive to reveal part of the diskette.
2. Pull out the diskette.

CAUTION:

You can only remove the diskette when the drive is idle, that is, when the light is not on.

Formatting Diskettes

Formatting prepares a diskette to receive data. To format a diskette, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)), select

```
> Customer/Services Administration
```

```
> System Management
```

```
> UNIX Management
```

```
>Format UNIX Floppy/Tape
```

The system displays the Format UNIX Floppy/Tape menu ([Figure 3-6](#)).

2. Select `Format 3.5 inch 1.44 Mbyte (High Density)` or `Format 3.5 inch 720 Kbyte (Low Density)` depending on the type of diskette being used.
3. Verify that the diskette is not write-protected and insert the tape into the tape drive. See "[Inserting the Diskette](#)" above for more information.
4. Press **y**
The system displays a screen stating that the diskette has been formatted.
5. Remove the diskette from the diskette drive.
6. Press `(ENTER)` to continue.

Backing Up (Unattended)

The unattended backup contains all of the information necessary to bring the system back to an operational state after a service affecting event. However, the unattended backup alone cannot completely restore the system to its previous state. The unattended backup can only bring the system back to an operational state. Employ the disaster recovery procedures outlined in [Chapter 9, "Installing Base System Software"](#) to restore a system to the previous state.

Unattended backups do not require supervision and occur automatically. However, for the backup to be successful you must ensure that a cartridge tape is in the tape drive.

Unattended backups occur nightly at 3:00 a.m. and may take up to four hours. Unattended backups do not degrade service.

After verifying that the unattended backup was successful, remove the tape. Label it (with date and backup data type, for example, System Data), and store it. A second tape should then be inserted into the tape drive. See "[Verifying the Unattended Backup](#)" below for backup verification procedures.

How to Manage Tapes

CAUTION:

Do not leave the same tape in the tape drive day after day. Once the unattended backup begins, the previous day's data is overwritten and unretrievable. Should today's unattended backup fail, neither today's nor yesterday's data will be available.

In order to better manage the backed up data it is recommended that two tapes be used.

These two tapes can be alternated daily or additional tapes may be used to implement a longer cycle (for example, seven tapes labeled with the days of the week).

What Data Are Backed Up

An unattended backup saves:

- Detailed system data on shared memory, speech filesystem pointers, etc.
- Alarm management information
- A list of enabled features
- A list of installed software

- INTUITY AUDIX® Digital Networking connectivity and communication information
- INTUITY AUDIX Voice Messaging message headers, mailing lists, subscriber profiles (including automated attendant administration), and message-waiting indicator status
- Switch integration parameters
- Serial port assignments
- Hard disk configuration

[Table 3-1](#) lists the network information stored during an unattended backup.

Table 3-1. Network Information Stored During an Unattended Backup

Directory	Description
/netw/db/vexnet.dbd	Connectivity to other INTUITY, AUDIX R1, and AMIS Analog Networking machines in the network, local machine connectivity, and channel configurations
/netw/db/db_anet.dbd	Information regarding how to request and send remote updates of subscriber information
/netw/db/delta /netw/db/delta.txt	Subscriber administration change records (binary and ascii)
/netw/db/deltactl /netw/db/deltactl.txt	Control record for the delta table (binary and ascii)
/netw/db/kmach	Index file for the node data
/netw/db/kport	Index file for the port table
/netw/db/kdelta	Index file for the delta table
/netw/db/krmail	Index file for the rmail table
/netw/db/kupdstat	Index file for the updstat table
/netw/db/kvnq	Index file for the vnq table
/netw/db/mach /netw/db/node.txt	Data of machines in the network (binary and ascii)
/netw/db/nodeid /netw/db/nodeid.txt	Data used to allocate new node id's (binary and ascii)

Continued on next page

Table 3-1. Network Information Stored During an Unattended Backup

Directory	Description
/netw/db/port /netw/db/port.txt	Networking channel configuration on local machine (binary and ascii)
/netw/db/rmail /netw/db/rmail.txt	Table that keeps track of outgoing voice mail messages that have not been accessed (binary and ascii)
/netw/db/rmailctl /netw/db/rmailctl.txt	Control record for the rmail table (binary and ascii)
/netw/db/updstat /netw/db/updstat.txt	Table containing update status of every remote machine (binary and ascii)
/netw/db/vnq /netw/db/vnq.txt	Temporary table used to identify which remote subscribers require voiced name updates (binary and ascii)

[Table 3-2](#) lists the voice mail information stored during and unattended backup.

Table 3-2. Voice Mail Information Stored During an Unattended Backup

Directory	Description
/vm/audix/md/mdata	Message headers, mailing lists, subscriber profiles, and message-waiting indicator status
/vm/audix/md/mdata/ocserv	Outgoing call queue status files
/vm/audix/md/config/hlrfil	High-level resource control file
/vm/audix/sd/mail/dr	Message delivery queue
/vm/audix/sd/mail/mb	Mailbox record (incoming and outgoing mailbox data)
/vm/audix/sd/mail/node	Mailbox node status file (for networking)
/vm/audix/sd/mail/xmq	Remote transmission queue

Continued on next page

Table 3-2. Voice Mail Information Stored During an Unattended Backup

Directory	Description
/vm/audix/sd/mesg/mh	Message headers (stores information per message such as original extension number, etc.)
/vm/audix/sd/mesg/vf	Voice file reference count (number of references per voice file)
/vm/audix/sd/sdata/attend	Automated attendant data
/vm/audix/sd/sdata/cls	Class-of-service data
/vm/audix/sd/sdata/netport	
/vm/audix/sd/sdata/netprof	
/vm/audix/sd/sdata/pdir	Personal directory data
/vm/audix/sd/sdata/rmatrix	Sending restriction matrix data
/vm/audix/sd/sdata/sdl	Mailing and delivery list file
/vm/audix/sd/sdata/sup	Subscriber profile file
/vm/audix/sd/sdata/syp	System-wide data

[Table 3-3](#) lists the voice platform information stored during an unattended backup.

Table 3-3. Voice Platform Information Stored During an Unattended Backup

Directory	Description
/vs/data	Platform data files containing information such as performance parameters, text screens, and speech filesystem mount points
/vs/shmem	All files related to shared memory operations
/vs/switch	All files and directories related to switch integration

Verifying the Unattended Backup


The system administrator should check the administrator's log daily to ensure that a successful unattended backup occurred. There are two ways to check the log:

- Using the Log Administration menu
- Using the AUDIX Administration screen

Successful Backup Verification Using the Log Administration Menu

To verify a successful unattended backup from the Log Administration menu do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the Administrator's Log Display Selection window ([Figure 3-7](#)).





Figure 3-7. Administrator's Log Display Selection Window

2. Place the cursor in the `Event ID` field.
3. Enter **BKRST001**
4. Press **F3** (Save).

The system displays the Administrator's Log window ([Figure 3-8](#)).



Date	Time	App	Event ID	Cnt	Message
04/22/96	13:42:46	MT	UDTADM00022	1	parcrypf1 creation passed
04/22/96	14:13:26	MT	UDTADM00022	1	parcrypf1 creation passed

Figure 3-8. Administrator's Log Window

5. Verify that there is an entry with today's date and the following text:

`Backup process has been completed successfully.`

If an entry with today's date does not exist the unattended backup was not successful.

Successful Backup Verification using the AUDIX Administration Screen

To verify a successful unattended backup from the AUDIX Administration screen do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select

```
> AUDIX Administration
```

The system displays the AUDIX Administration screen ([Figure 3-9](#)).


```
AUDIX           Active           Alarms: MmW           Logins: 1
display administrator's-log           Page 1 of 1
ADMINISTRATOR'S LOG

The following options control which entries will be displayed.

Start Date: 10/13/95           Time: 12:12
Application:  _           Event ID: _____
Search String:
_____

enter command: display administrator's-log
```

Figure 3-10. AUDIX Administrator's Log Display Selection Screen

3. Move the cursor to the `Event ID` field.
4. Enter **BKDONE001**
5. Press **F3** (Save).

The system displays the AUDIX Administrator's Log screen ([Figure 3-11](#)).

```

AUDIX Active Alarms: mw Logins: 2
display administrator's-log Page 1
ADMINISTRATOR'S LOG

Date Time App Event ID Cnt Message
02/12/96 15:44 MT AOMADM00001 1 Alarm Origination Level on Alarm Manage
ment Form changed to MINOR
02/12/96 15:44 MT AOMADM00001 1 Clear Alarm Notification on Alarm Manag
ement Form changed to ACTIVE
02/12/96 15:44 MT UDTADM00022 3 parcrypf1 creation passed
02/12/96 15:48 MT UDTADM00022 1 parcrypf1 creation passed
02/12/96 15:49 MT UDTADM00022 2 parcrypf1 creation passed
02/12/96 15:50 MT UDTADM00022 3 parcrypf1 creation passed
02/12/96 15:52 MT UDTADM00022 2 parcrypf1 creation passed
02/12/96 17:25 MT UDTADM00022 1 parcrypf1 creation passed

Press [NextPage], [PrevPage] or [Cancel] to abort
enter command: display administrator's-log
    
```

Figure 3-11. AUDIX Administrator's Log Screen

Backing Up (Attended)

Unattended backups do not save everything, therefore you may want to copy other types of information for security and recovery purposes. The attended backup does not cause a degradation in service. However, for best results perform these backups at a time when the Lucent INTUITY system experiences low usage.

Data Types

You can manually backup any combination of the following data types at any time.

System Data

System data is automatically backed up nightly through the unattended backup commands. See "[Backing Up \(Unattended\)](#)" above for a list of the items included in system data. In addition to the unattended backup, you should also back up the system data manually whenever you make extensive changes to the subscriber profiles.

Announcements

Announcements are the prompts and phrases that guide the user through INTUITY AUDIX Voice Messaging. This data type does not require a backup unless the system has customized announcements that have just been changed. If customized announcements are not being used, a backup of announcements already exists on the original factory tape.

INTUITY AUDIX Greetings and Messages

INTUITY AUDIX voice messaging greetings include each subscriber's primary voice greeting, multiple personal greetings, automated attendant menus and messages, and bulletin board messages. INTUITY AUDIX voice messaging are all of the call answer and voice mail messages that subscribers send and receive every day.


INTUITY AUDIX Names

The INTUITY AUDIX names data type contains voiced subscriber names. After additional subscriber names have been recorded, you should conduct an attended backup of this filesystem.

Attended Backup

To perform an attended backup, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the Backup window ([Figure 3-12](#)).

Backup	
<u>S</u> ystem Data	<u>Y</u> es
<u>A</u> UDIX Announcements	<u>Y</u> es
<u>A</u> UDIX Names	<u>Y</u> es
<u>G</u> reetings and Messages	<u>Y</u> es
_____	_____
_____	_____
_____	_____
_____	_____
_____	_____

Figure 3-12. Backup Window

2. Enter **y** in the fields to be backed up.



NOTE:

The fields displayed on the Backup window are based on the system's configuration. Therefore, the window you see may look different than the one shown here.

3. Enter **n** in all of the other fields.
4. Press **F3** (Save).

The system displays the following message.

```
backup started
calculating approximate number of tape(s) required
please wait
```

```
the backup will need approximately:
x yyy MB cartridge tape(s)
```

5. Make sure that there are enough cartridge tapes to accommodate the backup.

The system displays the following message:

```
Verify whole backup tape(s) will double the amount of
backup time.
Do you really want to verify tape(s)?
(Strike y or n)
```

6. The Lucent INTUITY system verifies a backup tape by reading back the entire set of data it has just written on the tape.

⇒ NOTE:

Verifying the back-up tape increases the total time for backup from 1-1/2 hours to 3 hours. Verification is not necessary to ensure a good back-up tape.

To verify the back-up tape press **y**. If you do not want to verify the backup tape press **n**.

The system displays the following message:

```
please insert a tape into the tape drive to back up
tape 1
press <Enter> when tape is inserted
press <Esc> key to terminate the backup
```

7. Insert the first cartridge tape in the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" above for this procedure.
8. Press when the tape drive is idle.

The system displays a series of messages indicating what is being stored on the backup tape.

⇒ NOTE:

The light on the 2-Gbyte drive will blink when the drive is in use. If the light is not blinking, the tape drive is idle. The light on the 525-Mbyte tape drive is on when the drive is in use. If the light is not on, the tape drive is idle.

9. If another tape is necessary:
 - a. Remove the current tape. See "[Inserting and Removing Cartridge Tapes](#)" above for this procedure.
 - b. Label the tape with the current date and back-up data type(s).
 - c. Insert the next tape. See "[Inserting and Removing Cartridge Tapes](#)" above for this procedure.

If another tape is not necessary, continue with Step 10.

When the backup is complete and the system displays the following message.

```
backup process has been completed successfully  
press any key to continue
```

10. Press **ENTER**.
11. Press **CANCEL** three times to return to the Lucent INTUITY Main menu ([Figure 3-1](#)).

Restoring Backups

The information stored on cartridge tapes during the unattended and attended backup procedures is used to restore the system to an operational state.

When to Do a Restore

If a system problem or failure occurs, backups can be invaluable in returning the system to an operational state. You will likely only restore backups when directed to do so by an alarm repair action.

When to Reinstall Software

Depending on the severity of the situation, Lucent INTUITY software may have to be reinstalled before restoring any backups. See [Chapter 10, "Installing Lucent Intuity System Software"](#) for these procedures.

How to Do a Restore

NOTE:

It takes approximately 2 hours to restore one tape.

This procedure works for both attended and unattended backups.

1. Stop the voice system. See "[Stopping the Voice System](#)" below for more information.
2. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select

```
> Customer/Services Administration
```

```
> Backup/Restore
```

```
> Restore
```

The system displays the following message.

```
please insert a tape into the tape drive to restore  
press <Enter> when tape is inserted  
press <Esc> key to terminate the restore
```

3. Insert the cartridge tape that contains the data to be restored into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" above for more information.
4. Press to continue.

The system displays the header information for the tape. That information includes:

- Tape label
- Date
- List of packages (with release and version) installed on the machine when the tape was made
- Data types

The following is an example of tape header information:

```
PRODUCT_ID=2299999999  
DATE=09/11/93 09:51  
PKG=VM:0:R1.1  
PKG=mtce:1.0:1.0-4  
PKG=netw:0:1.0-4.3  
PKG=vs:1.0:1.0-4  
TYPE=System Data:  
Press <Enter> to select data type.  
Press <Esc> to terminate the restore.
```

5. Check the data types listed under `TYPE=System Data` to verify that this tape contains the appropriate data.

If it does not:

- a. Press .
- b. Return to Step 3.
- c. Try another tape.

If it does, continue with Step 6.

6. Press to continue.

The system displays the Restore window.

7. Enter **y** in the fields that display the data types you want to restore.



NOTE:

The fields displayed on the Restore window are based on the data stored on the tape.

8. Enter **n** in all of the other fields.
9. Press **F3** (Save) to restore the data types selected.
10. Insert subsequent tapes if prompted.
11. Press **ENTER** when the restore is complete and the system displays the following message:

```
restore process has been completed successfully  
press any key to continue
```

If the restore fails, the system displays the following message:

```
Restore Failed.
```

Do the following:

- a. Rewind the tape by removing it from the tape drive and then reinserting it.
 - b. Return to Step 4 and attempt the restore again.
 - c. If the restore fails a second time, access the alarm log. See Chapter 1, "Getting Started" in *Lucent INTUITY Alarms and Log Messages* and follow associated repair actions for any active alarms in the log.
12. Reboot the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" above for this procedure.

Administering Voice Messaging

The voice system is the Lucent INTUITY system's base voice processing software.

Starting the voice system brings the software into a state where it can accept and process calls. Stopping the voice system brings the software into a lower level state in which it cannot accept calls.

Starting the Voice System

To start the voice system, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select

```
> Customer/Services Administration
> System Management
> System Control
>Start Voice System
```

The system displays the following message:

```
The Voice System is starting.
The Voice System is initializing cards.
Startup of the Voice System is complete.
```

Hit acknowledge key to continue.

2. Press **F1** (Acknowledge).

The system displays the System Control menu ([Figure 3-13](#)).

```
System Control
Shutdown System
Start Voice System
Stop Voice System
```

Figure 3-13. System Control Menu

3. You have completed this procedure.


Stopping the Voice System

CAUTION:

Only stop the voice system when it is absolutely necessary. All calls in progress will be disconnected. Users calling AUDIX will hear a fast busy signal. Callers sent to AUDIX coverage will hear ringing with no answer.

To stop the voice system, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the Wait Time window ([Figure 3-14](#)).



Figure 3-14. Wait Time Window

2. Enter a number between 60 and 600 to designate how long the system will wait for calls in progress to finish before stopping the voice system.
3. Press **F3** (Save).

The system displays the following message:

The Voice System is now stopping.

Initiating request to clear all calls in the next 60 seconds.

Orderly idling of the system succeeded.

After the Voice System has completely stopped, use the "Start Voice System" choice from the System Control menu to restart the Voice System.

The Voice System has stopped.

Press Enter to Continue.

⇒ NOTE:

When the voice system is stopped, the user cannot access INTUITY AUDIX administration screens. AUDIX Administration still appears as an option on the Lucent INTUITY Main menu, but the user cannot select this option. To view INTUITY AUDIX administration screens, the user must restart the voice system. See "[Starting the Voice System](#)" above for the procedure.


4. Press **ENTER**.

Shutting Down and Rebooting the Lucent INTUITY System

You must shut down the Lucent INTUITY system before you perform a reboot. This section describes both procedures.

Shutting Down the System

1. Stop the voice system. See "[Stopping the Voice System](#)" above for the procedure.
2. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the Wait Time window ([Figure 3-14](#)).

3. Enter a number between 0 and 60 to designate how long the system will wait for users to log off.

4. Press **F3** (Save).

The system displays the following message:

```
Shutdown started.
```

When the system is completely shut down, the system will display the following message.

```
The system is down.
```

```
Press Ctrl-Alt-Del to reboot your computer.
```

5. Continue with the next procedure "[Rebooting the System.](#)"

Rebooting the System

Rebooting the system can be done in two ways:

- A *warm reboot* (performed while the computer is on)
- A *cold reboot* (turning the computer off, then back on again)

Performing a Warm Reboot

1. Make sure that there is no diskette in the diskette drive or tape in the tape drive.
2. Press **Ctrl-Alt-Del** .

The system performs a power-on self test (POST). The screen lists various hardware components and the status of the tests performed on those components.

NOTE:

If the system displays the message:

```
WARNING ixfs:UX_unmounted root file system is busy  
and cannot be unmounted cleanly
```

ignore it. The reboot will continue normally.

When the reboot is complete, the system displays the following prompt:

```
Startup of the Voice System is complete.  
Console Login:
```

3. If **FAIL** appears in the status column for any component do the following:
 - a. Record the component's name.
 - b. Access the alarm log to begin troubleshooting. See Chapter 1, "Getting Started," in "*Lucent INTUITY Alarms and Log Messages*" for this procedure.

Performing a Cold Reboot

1. Make sure that there is no diskette in the diskette drive.
2. To perform a cold reboot turn the MAP/100 off by pressing the power button on the rear of the unit ([Figure 3-15](#)).




Figure 3-15. Rear View of the MAP/100

3. Wait 30 seconds to allow the drives to come to a complete stop.
4. Turn the power on by pressing the power button on the rear of the MAP/100 ([Figure 3-15](#)).


Verifying the Date and Time

This section details:

- Checking the UNIX Date and Time window
- Changing the UNIX Date and Time window

Checking the UNIX Date and Time Window

1. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the UNIX Date and Time window ([Figure 3-16](#)).




Figure 3-16. UNIX Date and Time Window

2. Check each of the fields under UNIX Date and Time.

If all of the fields are correct, press **F6** (Cancel).

If a field contains incorrect information, continue with the next procedure, "[Changing the UNIX Date and Time Window](#)."

Changing the UNIX Date and Time Window

The user can change any of the displayed fields. To change one field in the Date and Time window, the user must either change or acknowledge the information in each field.

Changing the Date Field

The date field contains the month, day, and year.

Changing the Month

1. Place the cursor on the `Month` field in the UNIX Date and Time window.
2. If the month shown is not correct, complete Steps a through c:
 - a. Press `F2` (Choices) to display the months of the year ([Figure 3-17](#)).



Figure 3-17. UNIX Month Choices Menu

- b. Use `▲` or `▼` to move the cursor and highlight the correct month.
- c. Press `ENTER` to place the name of the correct month into the month field.



NOTE:

The user can also select the current month by entering the corresponding alphabetic abbreviation from this list: **Ja, F, Mar, Ap, May, Jun, Jul, Au, S, O, N, D.**

- d. Continue with the next procedure “Changing the Day.”

If the month shown is correct, press `ENTER` for no change and continue with the next procedure “[Changing the Day.](#)”

Changing the Day

If the day of the month shown is not correct, enter the correct day as a number from 1 to 31 and continue with the next procedure "[Changing the Year.](#)"

If the day of the month shown is correct, press **ENTER** for no change and continue with the next procedure "[Changing the Year.](#)"

Changing the Year

If the year shown is not correct, enter the correct year as a number from 1996 to 2038 and continue with the next procedure "[Changing the Time Field.](#)"

If the year shown is correct, press **ENTER** for no change and continue with the next procedure "[Changing the Time Field.](#)"

Changing the Time Field

If the time shown is not correct, enter the correct time in the form of *hours:minutes* and continue with the next procedure "[Changing the AM/PM Field.](#)"

NOTE:

Use a 12-hour a.m./p.m. standard. Do not use the 24-hour military standard.

If the time shown is correct, press **ENTER** for no change and continue with the next procedure "[Changing the AM/PM Field.](#)"

Changing the AM/PM Field

If AM/PM is not correct as shown, type **a** for a.m. or **p** for p.m. and continue with the next procedure "[Changing the Time Zone Field.](#)"

If AM/PM is correct as shown, press **ENTER** for no change and continue with the next procedure "[Changing the Time Zone Field.](#)"

Changing the Time Zone Field

If the time zone shown is not correct, complete Steps 1 through 3 and continue with the next procedure "[Changing the Is Daylight Savings Time Used Field.](#)"

1. Press **F2** (Choices) to display the list of time zones ([Figure 3-18](#)).




Figure 3-18. UNIX Time Zone Choices Menu

2. Use **▲** or **▼** to move the cursor and highlight the correct time zone.
3. Press **ENTER** to place the name of the correct time zone into the Timezone field.

If the time zone shown is correct, press **ENTER** for no change and continue with the next procedure [“Changing the Is Daylight Savings Time Used Field.”](#)

Changing the Is Daylight Savings Time Used Field

1. Type **y** for yes or **n** for no depending upon whether or not daylight savings time is used at any time during the year.
2. Press **F3** (Save) to save the changes and continue with the next procedure [“Acknowledging the Changes to the Date and Time Window.”](#)


Acknowledging the Changes to the Date and Time Window

After the changes have been made to the Date and Time window the user must ensure that the system recognizes the new information. To acknowledge the new information, do the following:

1. Reboot the Lucent INTUITY system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#) for the procedure.

At this time the date and time changes will take affect.

2. Starting at the Lucent INTUITY Main menu ([Figure 3-1](#)) select



The system displays the UNIX Date and Time window ([Figure 3-16](#)).

3. Check each of the fields under UNIX Date and Time to ensure that the changes have been recorded.

Getting Inside the Computer

4

Overview

This chapter describes:

- Proper electrostatic discharge protection procedures
- Power removal and restoration procedures
- Computer chassis access procedures

Purpose

The purpose of this chapter is to provide the correct procedures for accessing the internal components of the MAP/100.

Protecting against Damage from Electrostatic Discharge

CAUTION:

*Read this section before unpacking the MAP/100. You **must** observe proper grounding techniques to prevent the discharge of static electricity from your body into ESD-sensitive components.*

Circuit cards and packaging materials that contain ESD-sensitive components are usually marked with a yellow-and-black warning symbol ([Figure 4-1](#)).



Figure 4-1. ESD Warning Symbol

To avoid damaging ESD-sensitive components, follow these rules:

- Handle ESD-sensitive circuit cards only after attaching a wrist strap to the bare wrist. Attach the other end of the wrist strap to a ground that terminates at the system ground, such as any unpainted metallic chassis surface.
- Handle a circuit card by the faceplate or side edges only ([Figure 4-2](#) and [Figure 4-3](#)).

CAUTION:

Ensure that your palm is not in contact with the non-component side of the board.




Figure 4-2. How to Hold a Small Circuit Card




Figure 4-3. How to Hold a Large Circuit Card

- Keep circuit cards away from plastics and other synthetic materials such as polyester clothing.
- Do not hand circuit cards to another person unless that person is grounded at the same potential level.
- Hold devices such as a hard disk, diskette drive, or streaming tape in the same manner as a large circuit card. The ESD-sensitive area of these components is located on the bottom surface ([Figure 4-4](#)).




Figure 4-4. ESD-Sensitive Area of an Electronic Component

Removing Power from the MAP/100

The MAP/100 requires a dedicated power line. The power cord connects to the rear of the MAP/100 at the point labeled AC power input receptacle ([Figure 4-5](#)). Before you begin any work in the MAP/100 you must disconnect the incoming power.




Figure 4-5. MAP/100 Power Connections

To remove power from the MAP/100, do the following:

1. Shut down the voice system. See [Appendix 3, "Shutting Down and Rebooting the Lucent Intuity System"](#), in [Chapter 3, "Common System Procedures"](#).
2. Turn off the monitor's power switch.

The green or amber lamp on the front bottom of the monitor should be off.

3. Turn off the power switch on the lower front of the MAP/100 peripheral bay ([Figure 4-6](#)).




Figure 4-6. MAP/100 Power Switch

4. Turn off the circuit breaker on the back of the MAP/100 ([Figure 4-5](#)).
5. Unplug the MAP/100 from the power outlet.
6. Remove the MAP/100 power cord from the AC power input receptacle on the rear of the MAP/100 ([Figure 4-5](#)).
7. Observe the correct lock-out/tag-out precautions for isolating power as outlined in the Lucent™ lock-out/tag-out procedure.

Opening and Removing the Front Doors

The doors on the MAP/100 must be opened to view the peripheral bay or the circuit card cage fans. The doors can be removed to allow for easier access to either of these areas.

Opening and Removing the Right Door

You can view the peripheral bay by opening the right door.

1. Place your finger in the indentation on the bottom right corner of the door.
2. Pull the door towards you.
3. With the door fully opened, remove it by pushing up to slide it off its hinges.
4. Set the door aside.

Opening and Removing the Left Door

You can view the card cage fans by opening the left door.



NOTE:

The left door contains the circuit card cage filters. This door should remain attached and closed to allow for proper air filtration.

1. Place your finger in the indentation on the bottom left corner of the door.
2. Pull the door towards you.
3. With the door fully opened, remove it by pushing up to slide it off its hinges.
4. Set the door aside.

Removing the Dress Covers

There are three dress covers on the MAP/100, one top dress cover and two side dress covers. The dress covers provide protection for the internal components of the MAP/100. You must remove these dress covers to access these components.



WARNING:

Shut power off before removing the dress cover or access panel of the MAP/100. See ["Removing Power from the MAP/100"](#) above for the procedure.

Removing the Top Dress Cover

To remove the top dress cover, do the following:

1. Place your fingertips in one corner of the top dress cover, in the space between the top cover and the side cover.
2. Gently pry off the dress cover by pulling up at each corner.

Removing the Side Dress Covers

To remove the top dress cover, do the following:

1. Place your fingertips at the top of the side dress cover.
2. Gently pry off the dress cover by pulling out at each corner.

Accessing the Peripheral Bay

The peripheral bay houses the hard disk drives, the diskette drive, and the SCSI tape drive. See [Appendix A, "System Configuration"](#) for the placement of these components within the peripheral bay.

To access the peripheral bay, do the following:

1. Remove the dress covers. See ["Removing the Dress Covers"](#) above for the procedure.
2. Remove the right door. See ["Opening and Removing the Right Door"](#) above for the procedure.
3. Loosen the four 1/4-turn fasteners around the perimeter of the peripheral bay ([Figure 4-7](#)).
4. Loosen the seven 1/4-turn fasteners around the perimeter of the peripheral bay access door ([Figure 4-7](#)).




Figure 4-7. 1/4-Turn Fasteners Around the Peripheral Bay and Peripheral Bay Access Door

5. Open the door ([Figure 4-8](#)).
6. Remove the 17 screws around the perimeter of the cover on top of the peripheral bay ([Figure 4-8](#)).
7. Remove the cover ([Figure 4-8](#)).
8. Grasp the peripheral bay steel framework and carefully pull the peripheral bay out ([Figure 4-8](#)).
9. Make sure that no cables are caught within the MAP/100.



NOTE:

Observe the cables through the peripheral bay access door.

10. Pull the assembly forward to the mechanical stop.




Figure 4-8. Accessing the Peripheral Bay

Accessing the Circuit Card Cage

The circuit card cage houses the circuit cards used by the Lucent™ INTUITY™ system. See [Appendix A, "System Configuration"](#) for the placement of the circuit cards within the circuit card cage.

To access the circuit card cage, do the following:

1. Remove the dress covers. See ["Removing the Dress Covers"](#) above for the procedure.
2. Loosen the eight 1/4-turn fasteners around the card cage access door ([Figure 4-9](#)).
3. Open the door.




Figure 4-9. Fasteners Around the Card Cage Access Door

Closing the Circuit Card Cage

To close the circuit card cage, do the following:

1. Close the circuit card cage access door.
2. Tighten the eight 1/4-turn fasteners around the card cage access door ([Figure 4-9](#)).
3. Replace the dress covers. See "[Replacing the Dress Covers](#)" below for the procedure.

Closing the Peripheral Bay

To access the peripheral bay, do the following:

1. Push the peripheral bay assembly back in to the MAP/100.
2. Make sure that no cables are caught as the assembly is pushed into the MAP/100.



NOTE:

Observe the cables through the peripheral bay access door.

3. Replace the top cover.
4. Replace the 17 screws around the perimeter of the cover on top of the peripheral bay.
5. Close the peripheral bay access door.
6. Tighten the seven 1/4-turn fasteners around the perimeter of the peripheral bay access door ([Figure 4-7](#)).
7. Tighten the four 1/4-turn fasteners around the perimeter of the peripheral bay ([Figure 4-7](#)).
8. Replace the dress covers. See "[Replacing the Dress Covers](#)" below for the procedure.
9. Replace the right door. See "[Replacing the Front Doors](#)" below for the procedure.

Replacing the Dress Covers

The MAP/100 has both top and side dress covers.

Replacing the Side Dress Cover

To replace the side dress cover, do the following:

1. Align the holes on the back of the cover with the pegs on the MAP/100.
2. Push the cover on by pressing in at each of the corners.

Replacing the Top Dress Cover

To replace the top dress cover, do the following:

1. Align the holes on the bottom of the cover with the pegs on the MAP/100.
2. Push the cover on by pressing down at each of the corners.

Replacing the Front Doors

To replace the front doors, do the following:

1. With the door in the fully open position, align the hinge pins on the door with the hinges on the chassis.
2. Slide the hinge pins downward into the hinges.
3. Close the door.

NOTE:

The left door contains the circuit card cage filters. This door should remain attached and closed to allow for proper air filtration.

Restoring Power to the MAP/100

To restore power to the MAP/100, do the following:

1. Place the MAP/100 power cord in the AC input receptacle on the rear of the unit ([Figure 4-5](#)).
2. Plug the MAP/100 power cord into the designated power outlet.
3. Turn on the circuit breaker on the back of the MAP/100 ([Figure 4-5](#)).
4. Turn on the power switch on the lower front of the MAP/100 peripheral bay ([Figure 4-5](#)).

The green lamp, labeled “Main Power Available,” on the front of the unit should be lit ([Figure 4-10](#)).




Figure 4-10. MAP/100 Monitoring Panel

5. Turn on the monitor's power switch.

The green or amber lamp on the front bottom of the monitor should be lit.

Replacing or Installing Circuit Cards

5

Overview

This chapter describes:

- Configuring circuit cards in the MAP/100
- Types of circuit cards
- General steps for circuit card installation
- Specific procedures for installation of standard and optional MAP/100 circuit cards
- Settings for resource options

Purpose

The purpose of this chapter is to ensure that:

- Circuit cards are installed correctly
- Resource options are set correctly

General Procedures

The general procedures include:

- Removing a circuit card
- Installing a circuit card

Removing a Circuit Card

WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#) in [Chapter 4, “Getting Inside the Computer”](#) for detailed electrostatic discharge precautions.

To remove a circuit card, do the following:

1. verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.

NOTE:

If the circuit card being replaced is defective, note all symptoms of failure and include this information with the circuit card when it is returned.

2. If the system is in service, perform the following steps.
 - a. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#) for voice system administration.
 - b. Shut down the voice system. See [“Shutting Down the System”](#) in [Chapter 3, “Common System Procedures”](#) for voice system administration.
3. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#) for power removal procedures.
4. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#) in [Chapter 4, “Getting Inside the Computer”](#), for component removal procedures.
5. Locate the card to be replaced within the card cage. Disconnect any attached cables. Note the connectivity of each cable.
6. If there are ribbon cables attached to other cards which would impede the removal of the card, disconnect them and place them to the side. Note the connectivity of each cable.
7. Remove the retaining screw from the circuit card faceplate and save it.

8. Remove the circuit card from the backplane slot by gently pulling on each corner of the card.

 NOTE:

The backplane connector slots are labeled 1 through 12. Make sure to install the replacement card in the same backplane slot. See [Appendix A, "System Configuration"](#) for circuit card slot assignments.

9. Remove the circuit card from the MAP/100 chassis.

 CAUTION:

Hold the circuit card carefully by the edges and place it on a grounded mat. See "[Protecting against Damage from Electrostatic Discharge](#)" in [Chapter 4, "Getting Inside the Computer"](#) for detailed electrostatic discharge precautions.

Installing a Circuit Card

 WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See "[Protecting against Damage from Electrostatic Discharge](#)" in [Chapter 4, "Getting Inside the Computer"](#), for detailed electrostatic discharge precautions.

To install a circuit card, do the following:

1. Remove the new circuit card from its ESD protective wrapping.

 NOTE:

Keep the package and all ESD protective wrapping. If you must return a card for repair, re-use of the replacement unit packaging is necessary to meet the manufacturer's warranty.

2. Verify the circuit card switch and jumper settings. Ensure address switches and jumpers are set to match the old card.

 NOTE:

See the specific instructions, listed later in this chapter, for each type of circuit card being installed then continue with [Step 3](#).

3. Holding the circuit card by its upper corners, slide the card into the backplane connector slot position from which you removed the damaged card. If necessary, refer to [Appendix A, "System Configuration"](#) to determine the correct slot in which to place the card.

4. Apply even pressure to both corners of the circuit card until it is locked into the backplane.
5. Secure the circuit card faceplate into position by replacing the retaining screw.
6. Replace all cables on the new card. Make sure these cables are attached to their proper terminations.
7. Replace all cables removed from other cards. Make sure these cables are attached to their proper terminations.
8. Replace the circuit card retaining bracket, circuit card access panel, and MAP/100 dress panel. See [Chapter 4, "Getting Inside the Computer"](#) for component replacement procedures.
9. Apply power to the unit. See "[Restoring Power to the MAP/100](#)" in [Chapter 4, "Getting Inside the Computer"](#) for instructions on restoring power.
10. Reboot the voice system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
11. Verify the installation of the circuit card by doing the following:



NOTE:

This procedure will only verify the installation of Tip/Ring and ACCX circuit cards.

- a. Start at the Lucent™ INTUITY™ Main menu ([Figure 5-1](#)).




Figure 5-1. Lucent INTUITY Main Menu

b. Select

```
> Customer/Services Administration
```

```
> System Verification
```

```
> View Installed Hardware
```

The system displays the View Installed Hardware window
([Figure 5-2](#)).

```
View Installed Hardware
Installed Hardware of mtce
2047 megabyte Hard Drive Installed at SCSI id 0
47 megabytes of memory installed.

Installed Hardware of netw

Networking Board      Equipped      Version Number
1                      no            N/A
2                      no            N/A
3                      no            N/A
```

Figure 5-2. View Installed Hardware Window

c. Verify that the system has identified the new circuit card.

Settings for Optional Circuit Cards

The following sections list the specific jumper and switch settings for optional circuit cards.

WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See "[Protecting against Damage from Electrostatic Discharge](#)" in [Chapter 4, "Getting Inside the Computer"](#) for detailed electrostatic discharge precautions.

This section provides the following information on the optional feature circuit cards:

- Switch and jumper settings
- Other installation requirements that are specific to the particular circuit card you are installing

In general, circuit cards are not preset at the factory. You must set the switches and jumpers (resource options) *before* you install the cards. When you set the switches according to the instructions in this book, remember that OFF is equivalent to open and ON is equivalent to closed.

Multi-Port Serial Circuit Card

The multi-port serial card for the MAP/100 ([Figure 5-3](#)) has eight serial ports. Each port is a 6-wire, RJ-11 modular jack.

Modular adapters convert the modular jacks to RS-232 connectors. You need one adapter for each device to be connected. All eight serial ports can be used for modem, terminal, or other DTE or DCE components, provided they are not being used for switch integration.

You can install only one multi-port serial card in the MAP/100.




Figure 5-3. Multi-Port Serial Circuit Card

Setting the Resource Options

The multi-port serial circuit card requires no hardware configuration. Verify that no jumpers are set on this card.

Placing the Multi-port Serial Circuit Card in the MAP/100

See "[General Procedures](#)" above for multi-port serial circuit card installation procedure.

ACCX (AYC22) Circuit Card

The Lucent INTUITY system supports up to eight networking channels on the MAP/100 via digital and analog remote connections using DCP and RS-232 links respectively from the ACCX circuit card ([Figure 5-4](#)). An ACCX circuit card terminates four data channels in one of the following combinations:

- Two DCP lines, each providing two I-channels for data. Depending on the version of the switch you are connecting to, you may only be able to use one of the two I-channels of each DCP circuit as shown in the following list:
 - System 75 R1V3, DEFINITY G1 R1V4, and DEFINITY G3i, G3s, or G3vs Version 1 only support one I-channel
 - DEFINITY G3i, G3s, and G3vs Version 2 can use both I-channels. The option must be purchased, installed, and administered on the switch before system administration is performed
- Four RS-232 ports
- One DCP line (two I-channels) and two RS-232 ports

You can install a maximum of three ACCX cards in the MAP/100.





Figure 5-4. ACCX Networking Circuit Card


Setting the Resource Options

Each ACCX card includes eight dip switches. These switches represent SA4 through SA11 on the ISA Bus and are used to set the address of the card ([Figure 5-5](#)).

Base I/O address = 140 hex
ACCX (AYC22) Card #1



Base I/O address = 340 hex
ACCX (AYC22) Card #2



Base I/O address = 540 hex
ACCX (AYC22) Card #3




Figure 5-5. Switch Settings for the MAP/100 ACCX Card

Placing the ACCX Circuit Card in the MAP/100

See "[General Procedures](#)" above for the ACCX circuit card installation procedure.

Switch Interface Circuit Cards

The Lucent INTUITY system interfaces with the customer switch through:

- DCIU circuit card
- VBPC circuit card


DCIU Circuit Card

The DCIU circuit card ([Figure 5-6](#)) connects to Lucent switches through an X.25 link. Your system may interface with the link through this circuit card.

⇒ NOTE:

In order to use this circuit card the DCIU Switch Integration set must be installed on the Lucent INTUITY system. See [“Installing the DCIU Switch Integration Set”](#) in [Chapter 9, “Installing Base System Software”](#), for the procedure.

You can install only one DCIU circuit card in the MAP/100.



dciiu KLC 080696

Figure 5-6. DCIU Circuit Card

Setting the Resource Options

The DCIU circuit card contains no jumpers or switches that you must set before you install the circuit card.

Replacing a DCIU Circuit Card

See [“General Procedures”](#) for the DCIU circuit card removal and installation procedures.

Installing a DCIU Circuit Card

Use the following procedure to install a DCIU circuit card in a system which previously did not have a DCIU circuit card installed.

1. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
2. Install the Lucent INTUITY DCIU Switch Integration set. See "[Installing the DCIU Switch Integration Set](#)" in "[Installing Base System Software](#)" for the procedure.
3. Install the DCIU circuit card. See "[Installing a Circuit Card](#)" for the procedure.
4. Reboot the Lucent INTUITY system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.

Digital Station Interface Circuit Card

The digital station interface circuit card ([Figure 5-7](#)) connects to Lucent switches. Your system may interface with the switch through this circuit card.

NOTE:

In order to use this circuit card the Digital Station Interface Switch Integration set must be installed on the Lucent INTUITY system. See "[Installing the Digital Station Interface Switch Integration Set](#)" in [Chapter 9, "Installing Base System Software"](#), for the procedure.

You can install only one digital station interface circuit card in the MAP/100.




Figure 5-7. Digital Station Interface Circuit Card

The digital station interface circuit card on set of jumpers which must be verified before you install the circuit card. There should be no jumpers placed on the jumper field.

Ethernet LAN Circuit Cards

There are two versions of the Ethernet LAN circuit card supported by the Lucent INTUITY system. Both versions allow you to connect the Lucent INTUITY system to your local area network.

Version 1

Version 1 of the Ethernet LAN circuit card is shown in [Figure 5-8](#).




Figure 5-8. Ethernet LAN Circuit Card - Version 1

The default software configuration is as follows:

- IRQ - 10
- I/O base address - 280
- RAM base address - D8000

The default setting for the jumper on W1 is "1," (Figure 5-9). This position configures the card to be software programmable beginning at the default settings.





Figure 5-9. Ethernet LAN Circuit Card Software Programmable Jumper Setting

There are no switches to set on the Ethernet LAN circuit card.

Version 2

Version 2 of the Ethernet LAN circuit card is shown in [Figure 5-10](#).



ethrlan1 C.JL 072396

Figure 5-10. Ethernet LAN Circuit Card - Version 2

The default software configuration is as follows:

- IRQ - 10
- I/O base address - 280
- RAM base address - D8000

There are no jumpers or switches associated with Version 2 of the Ethernet LAN circuit card.

Placing the Ethernet LAN Circuit Card in the MAP/100

See "[General Procedures](#)" above for the Ethernet LAN circuit card installation procedure.

CAUTION:

Do NOT cable the LAN circuit card until after the system has ben powered up and TCP/IP administration has been completed. This will ensure that the customer's LAN is not disrupted. See Chapter 8, "Initial Administration and Testing for TCP/IP Networking and Message Manager" in "Lucent INTUITY Messaging Solutions Release 4.0 MAP/100 System Installation" for more information on cabling and TCP/IP administration.

Installation of the Ethernet LAN circuit card must include the following sequence of operation.

1. Install the Ethernet LAN circuit card in the MAP/100.
2. Restore power to the system. See "[Restoring Power to the MAP/100](#)" in [Chapter 4, "Getting Inside the Computer"](#) for the procedure.
3. Administer the TCP/IP. See Chapter 8, "Initial Administration and Testing for TCP/IP Networking and Message Manager" in "Lucent INTUITY Messaging Solutions Release 4.0 MAP/100 System Installation" for more information on TCP/IP administration.
4. Shut down the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
5. Cable the Ethernet LAN circuit card. See the *EtherCard Elite Ultra Adapters Users Guide* packaged with the Ethernet LAN circuit card for cabling procedures.
6. Reboot the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.

Configuring the LAN Circuit Card

To configure the LAN circuit card, do the following:

1. Enter **smc_setup**

The system displays the SMC LAN Adapter Setup screen ([Figure 5-11](#)).

```
SMC LAN Adapter Setup Program -- Version 1.21
```

```
Board Type: 8416  
Node Address:
```

```
Current Setup
```

```
I/O Base Address 280  
IRQ 10  
RAM Size 8 K  
WIN Size 8 K  
RAM Base Address 0D8000  
Add Wait States Yes  
Network Connection TwPr-No Link  
Link Integrity Disabled  
ROM Size Disabled  
ROM Base Address Disabled  
Pnpboot Disabled
```

```
Do you want to change the setup? (y)->
```

Figure 5-11. SMC LAN Adapter Setup Screen

2. Make sure your settings match those shown in [Figure 5-11](#).
3. If the settings do not match, complete the following Steps a and b:
 - a. Change the settings
 - b. Reboot the system by entering **shutdown -y -g0 -i6**

4. Enter **/etc/confnet.d/configure -i**

The system displays the following message:

```
These are the device(s) available on your system:  
1 sme_0
```

```
Type the number of the device(s) to be configured with  
inet [?,??,q]
```

5. Enter the appropriate number.

The system displays the following message:

```
Please enter the IP host name for device sme_0:
```

6. Enter the your machine name.



CAUTION:

Do not take the default.

The system displays the following message:

```
Please initialize the IP address for host XXX:
```

7. Enter the IP address.

The system displays the following message:

```
Configure host XXX with default Ethernet(TM)ifconfig
options?
Info message is long. (yes no ClassC BerkeleyC info;
default: info)
```

8. Enter the **ClassC**.

The system displays the system prompt.

Speech and Signal Processor (AYC43) Circuit Card

The SSP circuit card ([Figure 5-12](#)) contains switches and jumpers that you must set before you install the circuit card in the MAP/100.




Figure 5-12. Speech and Signal Processor Circuit Card

Jumper Settings

[Figure 5-12](#) shows the location of the SSP circuit card jumpers. There should be no jumpers installed on the SSP circuit card.

Switch Settings

There are two types of switches on the SSP circuit card:

- Two-position switches
- Rotary switch

Two-Position Switch Settings

[Figure 5-13](#) shows the location of the SSP circuit card two-position switches. If the SSP circuit card is not located at the end of the TDM bus, both switches should be set to open. The switches should be set to closed if the SSP circuit card is located at the end of the bus.




Figure 5-13. SSP Circuit Card Two-Position Switches

Rotary Switch Settings

[Figure 5-14](#) shows the rotary switch which must be set at zero.




Figure 5-14. SSP Circuit Card Rotary Switch

Memory

The SSP circuit card is equipped with 16 Mbytes of memory contained on a dual in-line memory module (DIMM). The DIMM is located in the lower portion of the SSP circuit card ([Figure 5-12](#)).



CAUTION:

The DIMM is not field serviceable.

Replacing a Defective SSP Circuit Card

To replace a defective SSP circuit card, complete the procedures listed in "[General Procedures](#)."

Adding an SSP Circuit Card

CAUTION:

Use this procedure when adding an SSP circuit card to a system which is not currently equipped with one. Do not use this procedure when replacing a defective circuit card.


NOTE:

The Lucent INTUITY system supports only one SSP circuit card.

To add an SSP circuit card to a Lucent INTUITY system, do the following:

1. Make sure you have a TDM bus cable.
The TDM bus cable connects all of the Tip/Ring circuit cards as well as the SSP circuit card.
2. Remove the Tip/Ring circuit card from Slot 1. See "[Removing a Circuit Card](#)," above for the procedure.
3. Verify that the TDM bus terminator SIPs have been installed on the Tip/Ring circuit card. See "[Replacing a Terminator SIP](#)" in [Chapter 7](#), "[Replacing Other Components](#)".
4. Replace the Tip/Ring circuit card in Slot 1. See "[Installing a Circuit Card](#)," above for the procedure.
5. Remove the remaining Tip/Ring circuit cards. See "[Removing a Circuit Card](#)," above for the procedure.
6. Remove the TDM bus terminator SIPs from the Tip/Ring circuit cards. See "[Replacing a Terminator SIP](#)" in [Chapter 7](#), "[Replacing Other Components](#)".
7. Replace the remaining Tip/Ring circuit cards. See "[Installing a Circuit Card](#)," above for the procedure.
8. Verify the two-position selector switches, on the SSP circuit card, are set as shown in [Figure 5-13](#).
9. Install the SSP circuit card in Slot 12. See "[Installing a Circuit Card](#)," above for the procedure.
10. Install the TDM bus cable.

Attach the TDM bus cable to the SSP circuit card or AYC30 Tip/Ring circuit cards using the TDM Bus A termination ([Figure 5-12](#) and [Figure 5-15](#)). Attach the TDM bus cable to AYC10 Tip/Ring circuit cards using the only TDM bus termination point ([Figure 5-16](#)).



ngr KLC 070296

Figure 5-15. AYC30 Tip/Ring Circuit Card




Figure 5-16. AYC10 Tip/Ring Circuit Card

Settings for Standard Circuit Cards



WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See "[Protecting against Damage from Electrostatic Discharge](#)," in [Chapter 4](#), "[Getting Inside the Computer](#)" for detailed electrostatic discharge precautions.

This section provides the following information on the standard circuit cards that are included with every MAP/100:

- Switch and jumper settings
- Other installation requirements that are specific to the particular circuit card you are installing

Tip/Ring Circuit Cards

The Tip/Ring circuit cards provide the channels which are used by the Lucent INTUITY system. There are three channel on each Tip/Ring circuit card. The MAP/100 accommodates up to eleven Tip/Ring circuit cards. You will install either of the following Tip/Ring circuit cards:

- AYC10 (IVC6) ([Figure 5-16](#))
- AYC29 (IVC6A)
- AYC30 (NGTR) ([Figure 5-15](#))

AYC10 (IVC6) Tip/Ring Circuit Card

Each of the possible eleven AYC10 Tip/Ring circuit cards in the MAP/100 has a unique address. The addresses are set on the card switch bank ([Figure 5-17](#)). There are no jumpers to set on the AYC10 Tip/Ring circuit card.




Figure 5-17. IVC6 (AYC10) Tip/Ring Switch Settings

AYC29 (IVC6A) Tip/Ring Circuit Card

The AYC29 Tip/Ring circuit card is the Australian version of the AYC10 Tip/Ring circuit card. See [“AYC10 \(IVC6\) Tip/Ring Circuit Card”](#) above for jumper information.

AYC30 (NGTR) Tip/Ring Circuit Card

Each of the possible eleven AYC30 Tip/Ring circuit cards in the MAP/100 has a unique address. The addresses are set on the card switch bank (Figure 5-18). There are no jumpers to set on the AYC30 Tip/Ring circuit card.




Figure 5-18. AYC30 Tip/Ring Circuit Card Switch Settings

Placing the Tip/Ring Circuit Card in the MAP/100

See “[General Procedures](#)” above for the Tip/Ring circuit card installation procedure.

P5 120 MHz CPU Circuit Card

The P5 120 MHz CPU is packaged on a single PC/AT-compatible circuit card ([Figure 5-19](#)) that plugs into the backplane. There is one P5 120 MHz CPU circuit card installed in the MAP/100.




Figure 5-19. P5 120 MHz CPU Circuit Card and Jumper Locations

Setting the Resource Options

The resource options for the P5 120 MHz CPU circuit card are set by jumpers and switches.

Jumper Settings

The P5 120 MHz CPU card has jumpers that you must verify before you install the circuit card. [Figure 5-20](#) shows the jumper locations. [Figure 5-21](#) shows the jumper settings.





Figure 5-20. Jumper Settings for the P5 120 MHz CPU Circuit Card

Figure 5-21 shows the jumper settings.



pent-j LJK 041296

Figure 5-21. Jumper Settings for the P5 120 MHz CPU Circuit Card

Switch Settings

The P5 120 MHz CPU card has switches that you must set before you install the circuit card ([Figure 5-22](#)).



NOTE:

The switch ([Figure 5-22](#)) has been rotated 180 degrees.




Figure 5-22. Switch Settings for the P5 120 MHz CPU Circuit Card

Placing the P5 120 MHz CPU Circuit Card in the MAP/100

See "[General Procedures](#)" for procedures on P5 120 MHz CPU circuit card installation.

1. Remove the remote maintenance circuit card, if installed, from Slot 19. See "[Removing a Circuit Card](#)" above for the procedure.
2. Remove the external SCSI connector circuit card from Slot 22. See "[Removing a Circuit Card](#)" above for the procedure.
3. Remove the video controller card from Slot 20. See "[Removing a Circuit Card](#)" above for the procedure.
4. Complete [Step 1](#) and [Step 2](#) under "[General Procedures](#)".
5. Attach the keyboard cable to the keyboard pins on the P5 120 MHz CPU circuit card ([Figure 5-23](#)).





Figure 5-23. Attaching Cables to the P5 120 MHz CPU Circuit Card - Part 1

6. Complete [Step 3](#) under “[General Procedures](#)” above.
7. Attach the disk activity cable to the P5 120 MHz CPU circuit card with the red lead toward the back of the MAP/100 ([Figure 5-23](#)).
8. Install the rear COM2 cable to the P5 120 MHz CPU circuit card ([Figure 5-23](#)).
9. Dress this cable to the side ([Figure 5-23](#)).
10. Attach the SCSI cable to the SCSI controller pins on the P5 120 MHz CPU circuit card ([Figure 5-24](#)).



pentsc02 LJK 060796

Figure 5-24. Attaching Cables to the P5 120 MHz CPU Circuit Card - Part 2



NOTE:

The SCSI cable has a label which contains the following message
([Figure 5-24](#)):

H600-449 6() ISS. ()
MAP/100 SCSI CA
(SCSI/() -P5/100)



NOTE:

The SCSI cable will be routed over top of the disk activity cable
([Figure 5-24](#)).

11. Attach the mouse cable to the P5 120 MHz CPU circuit card ([Figure 5-24](#)).

12. Attach the SCSI cable to the external SCSI connector circuit card ([Figure 5-24](#)).
13. Install the external SCSI connector circuit card. See "[External SCSI Connector Circuit Card](#)" below for the procedure.
14. Attach the SCSI cable to the hard disk drive or drives.
15. Attach the SCSI cable to the cartridge tape drive.
16. Attach the diskette drive cable to the diskette drive cable pins on the P5 120 MHz CPU circuit card ([Figure 5-25](#)).




Figure 5-25. Attaching Cables to the P5 120 MHz CPU Circuit Card - Part 3



NOTE:

The diskette drive cable has a label which contains the following message ([Figure 5-25](#)):

H600-449 6() ISS. ()
MAP/100 Floppy CA
(Floppy/() -P5/100)

17. Dress this cable through the SCSI cable and beneath the external SCSI connector circuit card ([Figure 5-25](#)).
18. Install the video controller circuit card. See "[Video Controller Circuit Cards](#)" below for the procedure.
19. Install the remote maintenance circuit card, if equipped. See "[Remote Maintenance Circuit Cards](#)" below for the procedure.
20. Complete [Step 4](#) through [Step 11](#) under "[Installing a Circuit Card](#)".

Verifying the Parameter Settings

P5 120 MHz CPU circuit card parameter settings are pre-loaded into each card. To verify these settings, do the following.

Host Adapter Parameter Settings

To verify the host adapter parameter settings, do the following:



CAUTION:

Do not change the settings if there is a mismatch. Contact your remote maintenance center for assistance.

1. Reboot the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
2. After the power on self test (POST) but before the system boots the UNIX operating system, press **CONTROL** + **A** when prompted.

The system displays the Host Adapter Configuration screen ([Figure 5-26](#)).

Would you like to configure the Host Adapter, or run the SCSI disk utilities? Select the option and press <Enter>. Press <F5> to switch between color and monochrome modes.

```
Options
Configure/View Host Adapter Settings
SCSI Disk Utilities
```

Figure 5-26. Host Adapter Configuration Screen

3. Place the cursor on `Configure/View Host Adapter Settings`. Use the up (▲) and down (▼) arrows to move the cursor.
4. Press (ENTER).
5. Compare the settings shown on the screen with the correct parameters listed in [Table 5-1](#).

Table 5-1. SCSI Bus Interface Definitions

Option	Setting
Host Adapter SCSI ID	7
SCSI Parity Checking	Enabled
Host Adapter SCSI Termination	Disabled

6. Place the cursor on `SCSI Device Configuration`. Use the up (▲) and down (▼) arrows to move the cursor.
7. Press (ENTER).
Compare the settings shown on the screen with the correct parameters listed in [Table 5-2](#).



NOTE:

These settings must be applied to all SCSI IDs (0 - 7) shown.

Table 5-2. SCSI Device Configuration

Option	Setting
Initiate Sync Negotiation	Yes
Maximum Sync Transfer Rate	5.0
Enable Disconnection	Yes
Send Start Unit Command	No
Include In BIOS Scan	Yes

8. Press **[ESC]**.

The system displays the SCSI bus interface definitions screen.

9. Place the cursor on **Advanced Configuration Options**. Use the up **[▲]** and down **[▼]** arrows to move the cursor.

10. Press **[ENTER]**.

Compare the settings shown on the screen with the correct parameters listed in [Table 5-3](#).

Table 5-3. Advanced Configuration Options

Option	Setting
Reset SCSI Bus	Enabled
Host Adapter BIOS	Enabled
Support Removable Disks	Disabled
Extended BIOS Translations	Disabled
BIOS Support > 2 Drives	Disabled

11. Press **[ESC]**.

The system displays the SCSI bus interface definitions screen.

12. Press **[ESC]**.

The system displays the following message:

```
Exit Utilities
  Yes
  No
```

13. Place the cursor on `Yes`. Use the up  and down  arrows to move the cursor.
14. Press `ENTER`.
The system displays the following message:
`Please press any key to reboot.`
15. Press `ENTER`.
The system reboots and responds with the UNIX prompt (`#`).

You have completed verifying the host adapter settings.

CMOS Parameter Settings

To verify the CMOS parameter settings, do the following:

CAUTION:

Do not change the settings if there is a mismatch. Contact your local technical support representative for assistance.

1. Perform a hard reboot of the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.



NOTE:

You must perform a hard reboot to access the CMOS parameter settings.

2. During the POST, press `S`.

The system displays the following message:

`Please standby for SETUP Utility...`

After the system has installed the BIOS it displays the CMOS basic options setup menu.

3. Compare the P5 120 MHz CPU circuit card settings in the setup menu with the default parameters listed in [Table 5-4](#).



NOTE:

The following settings may differ from the default parameters due to other equipped feature circuit cards in your system:

Table 5-4. CMOS Basic Option Settings for the P5 120 MHz CPU Circuit Card

Option	Setting
Time and Date	
Set the time and date to the current time and date.	
Time/Date Boot Errors	ON
Floppy Disks	
On-board floppy controller	ON
Select Drive A: Type	3.5 Inch, 1.44 MB
Select Drive B: Type	Not Installed
Floppy Configuration Errors	ON
Fixed Disks	
On-board IDE Interface	OFF
Set Hard Disk 1 Type	SCSI Drive Installed
Set Hard Disk 2 Type	Not Installed (Use this setting regardless of the number of SCSI disks installed.)
Video Adapter	
Select Video Adapter Type	VGA/EGA
Video Configuration Errors	ON
Keyboard	
Keyboard Configuration Errors	ON
Set Keyboard Typematic Rate	NO
Shadow RAM	
Address: C000:0 Status	SHADOW
Address: C800:0 Status	SHADOW
Address: D400:0 Status	ROM (This item may or may not be present.)
Address: E000:0 Status	SHADOW
Address: F000:0 Status	SHADOW
Boot Options	
Boot Drive Sequence	Drive A: then C:

Continued on next page

Table 5-4. CMOS Basic Option Settings for the P5 120 MHz CPU Circuit Card —
Continued

Option	Setting
Keyboard Numlock at Boot	OFF
Password Options	
Password Protect Options	None
Password Edit	
Skip these options.	

4. Place the cursor on `Advanced Options`.
5. Press `(ENTER)`.
 The system displays the CMOS advanced options set-up menu.
6. Compare the P5 120 MHz CPU circuit card settings in the setup menu with the default parameters listed in [Table 5-5](#).



NOTE:

The following settings may differ from the default parameters due to other equipped feature circuit cards in your system:

Table 5-5. CMOS Advanced Option Settings for the P5 120 MHz CPU Circuit Card

Option	Setting
Serial Ports	
16550 Compatible UART 1:	03F8, IRQ4
16550 Compatible UART 2:	02F8, IRQ3
Parallel Ports	
Select Parallel Port Address:	0378
Select Parallel Port IRQ:	IRQ7
Select Parallel Port Mode:	ISA Compatible
PS/2 Mouse	
On-board PS/2 Mouse Port	OFF

Continued on next page

**Table 5-5. CMOS Advanced Option Settings for the P5 120 MHz CPU
 Circuit Card — *Continued***

Option	Setting
Cache	
Internal 16K Code/Data Cache:	Enabled
Level 2 Write Back Cache:	Enabled
Level 2 Cache Test:	Disabled
PCI Configuration	
Is C800 Available?	YES
Is CC00 Available?	YES
Is D000 Available?	NO
Is D400 Available?	NO
Is D800 Available?	NO
Is DC00 Available?	NO
Is IRQ5 Available?	NO
Is IRQ9 Available?	NO
Is IRQ10 Available?	NO
Is IRQ11 Available?	NO
Is IRQ12 Available?	NO
Is IRQ14 Available?	YES
Is IRQ15 Available?	NO
Integrated Adeptec PCI SCSI:	Enabled
PCI Bus Device 00:00:	OK
PCI Bus Device 00:01:	OK
PCI Bus Device 00:02:	OK
PCI INT/IRQ Binding	
INTA IRQ Availability	IRQ14
INTB IRQ Availability	IRQ14
INTC IRQ Availability	IRQ14
INTD IRQ Availability	IRQ14

Continued on next page

**Table 5-5. CMOS Advanced Option Settings for the P5 120 MHz CPU
 Circuit Card — Continued**

Option	Setting
Memory Options	
Base Memory Size:	640K
Memory Gap Block Size:	Disabled
Memory Gap Address Range	N/A
System Performance	
ISA Bus Speed	7.5 MHz
Guaranteed Access Time:	Disabled
DRAM Performance Mode:	Enhanced
PCI Burst Mode:	Standard
PCI to Memory Posting:	Standard
Host to PCI Posting:	Standard
DMA Performance Mode:	Standard
ISA Performance Mode:	Standard
8-Bit I/O Recovery Time:	6 SYSCLK
16-Bit I/O Recovery Time:	6 SYSCLK
Miscellaneous	
Watchdog Timer Delay:	1.2 sec
ISA/PCI Option ROM Scan Order	PCI ROM Scan First
Console Redirection	
COM1 Baud Rate:	NOT USED
COM2 Baud Rate:	NOT USED
COM3 Baud Rate:	NOT USED
COM4 Baud Rate:	NOT USED

7. To change the parameter settings, do the following [Step a](#) through [Step d](#):
 - a. Place the cursor on the appropriate heading. Use the up (▲) and down (▼) arrows to move the cursor.
 - b. Press (ENTER).
 - c. Change the parameters. Use the up (▲) and down (▼) arrows to move the cursor.
 - d. Press (ENTER).
8. Place the cursor on `Basic Options`.
9. Press (ENTER).

The system displays the CMOS basic options set-up menu.

10. Place the cursor on `Flash It!`.
11. Press (ENTER).

The system displays the following message.

```
Make Settings Permanent
      Yes
      No
```

12. Place the cursor on `Yes`.
13. Press (ENTER).

The system displays the following message.

```
Reset in progress.
```

After approximately three minutes, the system reboots and displays the UNIX prompt (#).

You have completed verifying the CMOS parameter settings.

External SCSI Connector Circuit Card

The external SCSI connector card provides an the ability to interface with external SCSI devices ([Figure 5-27](#)). There is only one external SCSI connector circuit card installed on the system.




Figure 5-27. External SCSI Connector Circuit Card and Terminating Resistor Module

Setting the Resource Options

There are no switches or jumpers to set.

Placing the External SCSI Connector Circuit Card in the MAP/100

See "[General Procedures](#)" above for the external SCSI connector card installation procedure. Once the external SCSI connector circuit card has been installed, the terminating resistor can be attached. The terminating resistor must remain on the external SCSI connector circuit card whenever the MAP/100 is in operation.

Video Controller Circuit Cards

The Lucent INTUITY system supports three video controller circuit cards which are compatible with an ISA backplane and one video controller circuit card which is compatible with PCI backplane.

The video controller circuit cards allow the MAP/100 to interface with a monitor. There is one video controller card installed on the system.

ISA Video Controller Circuit Cards

The three ISA compatible video controller cards supported by the Lucent INTUITY are:

- STB Horizon
- WDXLR831124
- WDXLR83160



NOTE:

The WDXLR833124 is not supported by the Lucent INTUITY system because it will not work with the P5 120 MHz CPU circuit card.

STB Horizon Circuit Card

[Figure 5-28](#) shows the STB Horizon video controller circuit card.





Figure 5-28. STB Horizon Video Controller Circuit Card

Jumpers on the STB Horizon video controller card are set by the manufacturer. However, you must confirm the setting before you install the card ([Figure 5-29](#)). There are no switches on the STB Horizon video controller card.



vid-4j LJK 041696

Figure 5-29. STB Horizon Video Controller Circuit Card Jumper Settings

WDXLR831124 Circuit Card

[Figure 5-30](#) shows the WDXLR831124 video controller circuit card. There are no jumpers on the WDXLR831124 video controller card. There are switches which must be set before the circuit card can be installed in the MAP/100 ([Figure 5-30](#)).




Figure 5-30. WDXLR831124 Video Controller Circuit Card and Switch Settings

WDXLR83160 Circuit Card

[Figure 5-31](#) shows the WDXLR83160 video controller circuit card. There are no jumpers on the WDXLR83160 video controller card. There are switches which must be set before the circuit card can be installed in the MAP/100 ([Figure 5-31](#)).




Figure 5-31. WDXLR83160 Video Controller Circuit Card and Switch Settings

PCI Video Controller Circuit Card

[Figure 5-32](#) shows the PCI video controller circuit card.




Figure 5-32. PCI Video Controller Circuit Card

There are no jumpers to set on the PCI video circuit card.

You can determine the type of remote maintenance circuit card installed on you system by viewing the faceplate. [Figure 5-34](#) shows the faceplate of a remote maintenance circuit card with an internal modem (AYC54).

NOTE:

The AYC54 remote maintenance circuit card can be connected to an external modem.




Figure 5-34. AYC54 Remote Maintenance Circuit Card Faceplate

[Figure 5-35](#) shows the faceplate of a remote maintenance circuit card without an internal modem (AYC55).




Figure 5-35. AYC55 Remote Maintenance Circuit Card Faceplate

Setting the Resource Options

The remote maintenance circuit card is equipped with a BEC enable switch (Figure 5-33). Ensure that this switch is set to the ON position (Figure 5-36).



swr2bec LJK 063097

Figure 5-36. BEC Enable Switch

Installing the Remote Maintenance Circuit Card Software Package

To install the remote maintenance circuit card software package, do the following:

1. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
2. Start at the Lucent INTUITY Main menu ([Figure 5-1](#)).
3. Select

```
> Customer/Services Administration
> System Management
> UNIX Management
>Software Install
```

The system displays the Software Install menu ([Figure 5-37](#)).

```
Software Install
>Floppy drive
Tape drive
```

Figure 5-37. Software Install Menu

4. Select Tape drive.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
    or [q] to quit: (default:go)
```

5. Insert the tape labeled "RMB Software Set" into the tape drive.

6. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge
tape.
```

The following sets are available:

```
1   RMBset   Remote Maintenance Board Package
          (AYC54/55)
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

7. Press **ENTER**.

The system displays the following message:

```
Processing:
```

```
Set: RMB Software Set R2.0 (RMBset) from <ctapel>.
```

```
Intuity RMB Software Set R2.0
(i486)
```

```
Using </> as the package base directory.
```

```
Please select the country code:
```

```
01 - United States
02 - International
```

Country code [01]:

8. Enter the appropriate code.

The system displays the following message:

```
Please select the location of the UPS:
```

```
0 - MAP/100C with -40V central office power
1 - Only MAP/100 with old internal supply
2 - Any other configuration
```

If you have a MAP/100, examine the faceplate. At the top, just under the POWER light are the words "BATTERY STATUS" or "PWR SUPPLY STATUS". If the words are "BATTERY STATUS", this indicates the old internal supply, so enter 1. If the words are "PWR SUPPLY STATUS", this indicates the new power supply, so enter 2.

UPS Location [2]:

9. If your system has the power supply with the redundant power capability, enter **2**

If your system has a power supply with a battery backup, enter **1**

See ["Replacing the Power Supply"](#) in [Chapter 7, "Replacing Other Components"](#) for identification information.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.  
Type [go] when ready  
    or [q] to quit: (default: go)
```

10. Enter **q**
11. Remove the cartridge tape.
12. Start the voice system. See [“Starting the Voice System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.

Replacing a Defective Remote Maintenance Circuit Card

See [“General Procedures”](#) for procedures on remote maintenance circuit card installation.

1. Complete the procedures listed in [“Removing a Circuit Card”](#) above for the defective circuit card.
2. Complete the procedures listed in [“Installing a Circuit Card”](#) above.

NOTE:

Make sure the BEC enable switch on the remote maintenance circuit card is in the ON position ([Figure 5-36](#)).

3. Connect the modem line to the remote maintenance circuit card and the switch.
4. Connect the EMI suppression cable to the remote maintenance circuit card and the switch.
5. Restore the system to service.
6. Call the remote maintenance center and inform them that you have replaced the remote maintenance circuit card.

The remote maintenance center will log in through the remote maintenance circuit card and:

- Set the passwords
- Verify the product ID
- Verify the alarm destination
- Configure all parameters as specified by the Services Organization

Replacing a Modem with a Remote Maintenance Circuit Card

See [“General Procedures”](#) for procedures on remote maintenance circuit card installation.

1. If the system is in service, perform the following steps:
 - a. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
 - b. Shut down the voice system. See [“Shutting Down the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
2. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#), for power removal procedures.
3. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#) in [Chapter 4, “Getting Inside the Computer”](#), for power removal procedures.
4. Complete the procedures listed in [“Installing a Circuit Card”](#) above.



NOTE:

Make sure the BEC enable switch on the remote maintenance circuit card is in the ON position ([Figure 5-36](#)).

5. Connect the modem line to the remote maintenance circuit card and the switch.



CAUTION:

Step 6 must be completed during the reboot of the system.

6. Disable COM2 by changing the Serial Ports 16550 Compatible UART 2 to DISABLED.

This setting is located in the CMOS advanced option settings for the CPU. See [“P5 120 MHz CPU Circuit Card”](#) above for the procedure.
7. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
8. Install the Remote Maintenance Circuit Card Software package. See [“Installing the Remote Maintenance Circuit Card Software Package”](#) above for the procedure.
9. Place the BEC enable switch on the remote maintenance circuit card in the ON position ([Figure 5-36](#)).
10. Press **(ENTER)**.
11. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.

12. Call the remote maintenance center and inform them that you have installed the remote maintenance circuit card.

The remote maintenance center will log in through the remote maintenance circuit card and:

- Set the passwords
- Verify the product ID
- Verify the alarm destination

Replacing a Remote Maintenance Circuit Card with a Modem

See ["Removing a Circuit Card"](#) for procedures on remote maintenance circuit card removal.

1. Call the remote maintenance center and inform them that you are removing a remote maintenance circuit card and restoring the COM2 Port.

The remote maintenance center will do [Step a](#) and [Step b](#):

- a. Log in through the remote maintenance circuit card and retest the password.
 - b. Log off.
2. Starting at the Lucent INTUITY Main menu ([Figure 5-1](#)), select

```
> Customer/Services Administration
> System Management
> UNIX Management
> Software Remove
```

The system displays the Software Remove screen ([Figure 5-38](#)).

```

The following packages are available:
 1 I16rfu+c      Remote Field Update C for IP16
                   (486) 1.0-16
 2 IVR          Intuity Intro Voice Response Set
                   (486) 1.0.16.1
 3 UM           AUDIX(R) Module marker file
                   (AUDIX) NA
 4 UM+3        AUDIX(R) Software Patches
                   (AUDIX) 2.0-16
 5 UM-britsh    British System Announcements
                   (AUDIX) 2.0-14
 6 UM-dfltdb   AUDIX(R) Default db
                   (AUDIX) 2.0-14
 7 UM-french   French-c System Announcements
                   (AUDIX) 2.0-14
 8 UM-sat      AUDIX(R) English Announcements
                   (AUDIX) 2.0-14
 9 UM-spansh   Lat-Span System Announcements
                   (AUDIX) 2.0-14
10 UM-sw       AUDIX(R) Software
                   (AUDIX) 2.0-16

... 53 more menu choices to follow;
<RETURN> for more choices, <CTRL-D> to stop display:
  
```

Figure 5-38. Software Remove Screen

3. Locate and record the numbers for the RMBset software package.
4. Press **CONTROL** **D**.

The system displays the following message:

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?, ??, q]
```

5. Enter the first number you recorded in [Step 3](#).

The system displays the following message:

```
The following set is currently installed:
<package title>      <package information>
```

```
Do you want to remove this set [y, n, q]
```

6. Enter **y**
7. Repeat [Step 5](#) and [Step 6](#) for all remote maintenance circuit card packages.
8. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
9. Shut down the Lucent INTUITY system. See [“Shutting Down the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
10. Remove the remote maintenance circuit card from the MAP/100. See [“Removing a Circuit Card”](#) for the procedure.

11. Make sure the COM2 port is correctly connected to the motherboard.
12. Close the circuit card cage. See [“Closing the Circuit Card Cage”](#) in [Chapter 4, “Getting Inside the Computer”](#), for power removal procedures.
13. Apply power to the MAP/100. See [“Restoring Power to the MAP/100,”](#) in [Chapter 4, “Getting Inside the Computer”](#) for this procedure.
14. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
15. Enable COM2 by changing the Serial Ports 16550 Compatible UART 2 to 02F8, IRQ3.

This setting is located in the CMOS advanced option settings for the CPU. See [“P5 120 MHz CPU Circuit Card”](#) above for the procedure.
16. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
17. Install the modem. See Chapter 5, “Administration and Test for Lucent INTUITY Peripherals,” in *Lucent INTUITY Messaging Solutions Release 4 MAP/100 System Installation 585-310-196* for the procedure.
18. Contact the remote maintenance center and inform them that the remote maintenance circuit card has been removed, the COM2 port has been enabled, and the modem has been installed.
19. The remote maintenance center will complete the procedure.



NOTE:

At this point the modem should have 3 LEDs lit.

20. Have the remote maintenance center login through the modem and change the tsc password back to the original.

Installing a Remote Maintenance Circuit Card, Version 2

The remote maintenance circuit card provides remote diagnostics of basic components ([Figure 5-33](#)). There is one remote maintenance circuit card installed on the system.




Figure 5-39. Remote Maintenance Circuit Card

Types of Remote Maintenance Circuit Cards

The Lucent INTUITY system supports remote maintenance circuit cards:

- With an internal modem (AYC54)
- Without an internal modem (AYC55)

You can determine the type of remote maintenance circuit card installed on you system by viewing the faceplate. [Figure 5-34](#) shows the faceplate of a remote maintenance circuit card with an internal modem (AYC54).

NOTE:
The AYC54 remote maintenance circuit card can be connected to an external modem.




Figure 5-40. AYC54 Remote Maintenance Circuit Card Faceplate

[Figure 5-35](#) shows the faceplate of a remote maintenance circuit card without an internal modem (AYC55).




Figure 5-41. AYC55 Remote Maintenance Circuit Card Faceplate

Setting the Resource Options

The remote maintenance circuit card is equipped with a BEC enable switch (Figure 5-33). Ensure that this switch is set to the ON position (Figure 5-36).



swr2bec LJK 063097

Figure 5-42. BEC Enable Switch

Installing the Remote Maintenance Circuit Card Software Package

To install the remote maintenance circuit card software package, do the following:

1. Stop the voice system.
2. Start at the Lucent™ INTUITY™ Main menu ([Figure 5-43](#)).





Figure 5-43. Lucent INTUITY Main Menu

3. Select



The system displays the Software Install menu ([Figure 5-37](#)).




Figure 5-44. Software Install Menu

4. Select Tape drive.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.  
Type [go] when ready,  
    or [q] to quit: (default:go)
```

5. Insert the tape labeled "RMB Software Set" into the tape drive.

6. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remote the cartridge  
tape.
```

The following sets are available:

```
1      RMBset      INTUITY RMB V2 set  
                    (i486) i.2.2
```

```
Select package(s) you wish to process (or 'all' to  
process all packages). (default: all) [?,??,q]
```

7. Press **ENTER**.

The system displays the following message:

```
Processing:
```

```
Set: RMB Software Set R2.0 (RMBset) from <ctapel>.
```

```
Intuity RMB Software Set R2.0  
(i486)
```

```
Using </> as the package base directory.
```

```
Please select the country code:
```

```
01 - United States  
02 - International
```

```
Country code [01]:
```

8. Enter the appropriate code.

The system displays the following message:

```
Please select the location of the UPS:
```

```
0 - MAP/100C with -40V central office power  
1 - Only MAP/100 with old internal supply  
2 - Any other configuration
```

If you have a MAP/100, examine the faceplate. At the top, just under the POWER light are the words "BATTERY STATUS" or "PWR SUPPLY STATUS". If the words are "BATTERY STATUS", this indicates the old internal

5 Replacing or Installing Circuit Cards

Installing a Remote Maintenance Circuit Card, Version 2

Page 5-63

supply, so enter 1. If the words are "PWR SUPPLY STATUS", this indicates the new power supply, so enter 2.

UPS Location [2]:

- a. If your system has the power supply with the redundant power capability, enter **2**

If your system has a power supply with a battery backup, enter **1**

9. Enter **q**
10. Remove the cartridge tape.
11. Start the voice system.

Replacing a Defective Remote Maintenance Circuit Card

To replace a defective remote maintenance circuit card, you must:

- Remove the defective remote maintenance circuit card
- Install the new remote maintenance circuit card
- Attach external cables to the remote maintenance circuit card

Removing the Defective Remote Maintenance Circuit Card

To remove the defective remote maintenance circuit card, do the following:

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.

NOTE:

Note all symptoms of failure and include this information with the remote maintenance circuit card when it is returned.

2. If the system is in service, perform the following steps.
 - a. Stop the voice system.
 - b. Shut down the voice system.
3. Remove power from the computer.
4. Access the circuit card cage.
5. Locate the remote maintenance circuit card.
6. If there are ribbon cables attached to other cards which would impede the removal of the card, disconnect them and place them to the side. Note the connectivity of each cable.
7. Remove the retaining screw from the circuit card faceplate and save it.

8. Remove the circuit card from the backplane slot by gently pulling on each corner of the card.



NOTE:

Make sure to install the replacement remote maintenance circuit card in the same backplane slot.

9. Remove the circuit card from the chassis.



CAUTION:

Hold the circuit card carefully by the edges and place it on a grounded mat.

Installing the New Remote Maintenance Circuit Card

To install the new remote maintenance circuit card, you must:

- Insert the circuit card
- Attach cables to the circuit card
- Restore the system
- Verify the installation

Inserting the Circuit Card

To insert the new remote maintenance circuit card, do the following:

1. Remove the new circuit card from its ESD protective wrapping.



NOTE:

Keep the package and all ESD protective wrapping. If you must return a card for repair, re-use of the replacement unit packaging is necessary to meet the manufacturer's warranty.

2. Make sure the BEC enable switch on the remote maintenance circuit card is in the ON position ([Figure 5-36](#)).
3. Holding the circuit card by its upper corners, slide the card into the backplane connector slot position from which you removed the damaged card.

[Table 5-6](#) lists the correct slot for each platform.

Table 5-6. Remote Maintenance Circuit Card Slot Locations

Platform	Correct Slot
MAP/5P	ISA Slot 2
MAP/40	Slot 9
MAP/40P	ISA Slot 9
MAP/100	Slot 19

4. Apply even pressure to both corners of the circuit card until it is locked into the backplane.
5. Secure the circuit card faceplate into position by replacing the retaining screw.

Attaching Cables to the Circuit Card

The type and number of cables depend upon the platform. See [Figure 5-45](#) to distinguish among the cables that may be present in each of the platforms. The following list details cabling requirements:

- MAP/5P – MAP/5P reset cable
- MAP/40 – 486 reset cable
- MAP/40P - keyboard cable
- MAP/100 – fan-status cable and 486 reset cable
(If the MAP/100 has an internal UPS, connect the UPS cable)

 **WARNING:**

If the UPS cable is connected to a MAP/100 with dual/redundant power supplies, then damage to the RMB results when power is supplied to the platform.





Figure 5-45. RMB cables

The cable code (printed on the cable) is as follows:


- ED5P 208-30 G 32 – fan status cable
- ED5P 208-30 GR 31 – reset cable

[Figure 5-46](#) and [Figure 5-47](#) show the cable connectors on the remote maintenance circuit card.



cdr2rmb1 LJK 041597

Figure 5-46. RMB connectors (top view)



cdr2edg LJK 041597

Figure 5-47. RMB connectors (side view)

You can dress the cables above or below the RMB. Use your judgement to determine the best way to connect to the board with the least amount of strain on the cables.

MAP/100 Cable Connections. Two vintage MAP/100 configurations require special attention:

- MAP/100 with internal UPS shipped with the RMB UPS cable
 If the MAP/100 has an internal UPS, then you must attach the UPS monitoring cable.
- MAP/100 dual/redundant power supplies shipped with the RMB UPS cables

⚠ WARNING:

If the UPS cable is connected to a MAP/100 with dual/redundant power supplies, then damage to the RMB results when power is supplied to the platform.

If the MAP/100 does not have an internal UPS — that is, if it uses dual/redundant power supplies — **DO NOT** attach the UPS monitoring cable to the RMB. **Ignore any UPS cable shipped with the platform.**

The remote maintenance circuit card attaches to connector J135 on the MAP/100 backplane (Figure 5-48).




Figure 5-48. MAP/100 Backplane

Restoring the System

To restore the system, do the following:

1. Replace all cables removed from other cards. Make sure these cables are attached to their proper terminations.
2. Close the computer.
3. Reboot the voice system.

Verifying the Installation

To verify the installation of the circuit card, do the following:

1. Starting at the Lucent™ INTUITY™ Main menu ([Figure 5-43](#)), select

```
> Customer/Services Administration
```

```
> System Verification
```

```
> View Installed Hardware
```

The system displays the View Installed Hardware window ([Figure 5-2](#)).

```
View Installed Hardware
Installed Hardware of mtce
2047 megabyte Hard Drive Installed at SCSI id 0
47 megabytes of memory installed.

Installed Hardware of netw

Networking Board      Equipped      Version Number
1                     no            N/A
2                     no            N/A
3                     no            N/A
```

Figure 5-49. View Installed Hardware Window

2. Verify that the system has identified the new circuit card.

Attaching External Cables to the Remote Maintenance Circuit Card

To connect the remote maintenance circuit card, do the following:

1. Connect the modem line to the remote maintenance circuit card and the switch.
2. Connect the external UPS line to the modem.
3. Connect the EMI suppression cable to the remote maintenance circuit card and the switch.
4. Restore the system to service.
5. Call the remote maintenance center and inform them that you have installed the remote maintenance circuit card.

The remote maintenance center will log in through the remote maintenance circuit card and:

- Set the passwords
- Verify the product ID
- Verify the alarm destination
- Configure all parameters as specified by the Services Organization

Replacing a Modem with a Remote Maintenance Circuit Card

To replace a modem with a remote maintenance circuit card, do the following:

1. Stop the voice system.
2. Install the RMBset software package. See [“Installing the Remote Maintenance Circuit Card Software Package”](#) above for the procedure.
3. Shut down the voice system.
4. Remove power from the computer.
5. Access the circuit card cage.
6. Complete the procedures listed in [“Installing the New Remote Maintenance Circuit Card”](#) above.
7. Connect the modem line to the remote maintenance circuit card and the switch.
8. Turn the computer on.



CAUTION:

Step [6](#) must be completed during the reboot of the system.

9. After memory check, enter CMOS setup.

5 Replacing or Installing Circuit Cards

Installing a Remote Maintenance Circuit Card, Version 2

Page 5-71

10. Disable COM2 by changing the Serial Ports 16550 Compatible UART 2 to DISABLED.

This setting is located in the CMOS advanced option settings for the CPU.

11. Exit CMOS Setup.

The system will begin booting. The UNIX kernel will be rebuilt to include the remote maintenance circuit card changes.

12. Make sure the system has returned to service.

13. Call the remote maintenance center and inform them that you have installed the remote maintenance circuit card.

The remote maintenance center will log in through the remote maintenance circuit card and:

- Set the passwords
- Verify the product ID
- Verify the alarm destination

5 Replacing or Installing Circuit Cards
Installing a Remote Maintenance Circuit Card, Version 2

Page 5-72

Replacing the Hard Disk Drive

6

Overview

This chapter describes:

- Identifying a failed hard disk drive
- Software procedures for preparing the system for a new hard disk drive
- Hardware procedures for replacing a hard disk drive
- Software procedures for initializing a hard disk drive

Purpose

The purpose of this chapter is to ensure that hard disk drives are installed in the proper manner.

Identifying a Failed Hard Disk Drive

Before a hard disk drive can be replaced you must identify which drive has failed. This section details how to identify a failed hard disk drive in Lucent™ INTUITY™ systems with two hard disk drives (both mirrored and unmirrored).

⇒ NOTE:

If your system is configured with only one hard disk drive, see [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.

Hard Disk Drive Contents in Six Hard Disk Drive Systems

In order to determine which hard disk drive has failed it is necessary to know what type of information is stored on each drive. [Table 6-1](#) show the information contained on each hard disk drive in a nonmirrored system.

Table 6-1. Nonmirrored Hard Disk Drive Contents

Disk Identity	Information Contained on Disk
Hard Disk Drive 0 SCSI ID 0 Bay 1, first installed	UNIX operating system, all Lucent INTUITY software, system data, and speech/voice storage
Hard Disk Drive 4 SCSI ID 4 Bay 2, fifth installed	Speech/voice storage
Hard Disk Drive 6 audfs disk SCSI ID 6 Bay 3, second installed	User data
Hard Disk Drive 5 SCSI ID 5 Bay 4, sixth installed	Speech/voice storage
Hard Disk Drive 1 SCSI ID 1 Bay 5, third installed	Speech/voice storage
Hard Disk Drive 2 SCSI ID 2 Bay 6, fourth installed	Speech/voice storage

[Table 6-2](#) show the information contained on each hard disk drive in a mirrored system.



NOTE:

A mirrored MAP/100 system requires a minimum of 4 hard disk drives, because Hard Disk Drive 0 and Hard Disk Drive 6 must both be mirrored.

Table 6-2. Mirrored Hard Disk Drive Contents

Disk Identity	Information Contained on Disk
Hard Disk Drive 0 SCSI ID 0 Bay 1	UNIX operating system, all Lucent INTUITY software, system data, and speech/voice storage
Hard Disk Drive 1 SCSI ID 1 Bay 5	Identical copy of Hard Disk Drive 0 information
Hard Disk Drive 6 audfs disk SCSI ID 6 Bay 3	User data
Hard Disk Drive 2 SCSI ID 2 Bay 6	Identical copy of Hard Disk Drive 6 (audfs disk) information
Hard Disk Drive 4 SCSI ID 4 Bay 2	Speech/voice storage
Hard Disk Drive 5 SCSI ID 5 Bay 4	Identical copy of Hard Disk Drive 4 information

Identifying a Hard Disk Drive 0 Failure in a Nonmirrored System

Because Hard Disk Drive 0 contains the only copy of the operating software in a nonmirrored system, a failure of this drive will result in a complete failure of the system. If this occurs you will not be able to reboot the system. See [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the replacement procedure.

Identifying a Hard Disk Drive 6 (audfs) Failure in a Nonmirrored System

Hard Disk Drive 6 contains user data. If this hard disk drive fails:

- The Lucent INTUITY system may not accept calls.
- Subscribers may not be able to log in and hear the message: "Login incorrect. Try again."
- Users cannot access their mailboxes and messages.
- SM errors appear in the maintenance log.
- The following error message is displayed at the system console:

```
c0t6d0s0: get contents failed.  
disk device is offline.
```
- Hardware error messages are displayed on the screen during reboot.

To verify that Hard Disk Drive 6 has failed, do the following:

1. Start at the Lucent INTUITY Main menu ([Figure 6-1](#)).





Figure 6-1. Lucent INTUITY Main Menu

2. Select



The system displays the Maintenance Log Display Selection window ([Figure 6-2](#)).

Maintenance Log Display Selection

Maintenance Log

The following options control which entries will be displayed.

Errors? Y Resolutions? Y Events? Y

Start Date: 7/24/95 Time: __:__:__

Application: __ Event ID: _____

Problem Resource: Type: _____ Location: __ __ __

Reporting Resource: Type: _____ Source: _____

Search String:

Figure 6-2. Maintenance Log Display Selection Window

3. Enter **MT** in the `Application` field and **FSY001** in the `Event ID` field.
4. Press **F3** (Save).

The system displays the appropriate Maintenance Log window ([Figure 6-3](#)).

Maintenance Log						
PROBLEM Type	RESOURCE Inst	Location	Msg Typ	REPORTING Type	RESOURCE Inst	Source
NIGHT_AUD	1		EUN	MPM	1	192
App: VM EventID:NIGHT_AUD0239 Date/Time Rec:04/01/96 01:01:48 Cnt: 1 aux1/2=45/0, Starting Audit AUD_NIGHTLY						
AUDIT	1		EUN	AUDIT	1	3
App: VM EventID:AUDIT0239 Date/Time Rec:04/01/96 01:01:48 Cnt: 1 aux1/2=0/0, file chk: recs=18						
AUDIT	1		EUN	AUDIT	1	2
App: VM EventID:AUDIT0239 Date/Time Rec:04/01/96 01:01:58 Cnt: 1 aux1/2=0/0, dsub: cleared SIDs=0 refs=0						
AUDIT	1		EUN	AUDIT	1	1
App: VM EventID:AUDIT0239 Date/Time Rec:04/01/96 01:02:09 Cnt: 1 aux1/2=0/0, age: msgs=0 rm=0 space=0 blks rm_out=0						
NIGHT_AUD	1		EUN	MPM	1	193

Figure 6-3. Maintenance Log Window

- Verify that there is an entry for a hard disk drive failure.

The hard disk drive will be identified by the name and jumper id.

The disk name is shown in the message text after the word `name:.` The jumper id is embedded in the string of numbers and letters that follow the word `id:.` The jumper id is the single digit number that follows the letter "t". For example, if the text reads `id: c0t6d0s0`, the jumper id is 6.

⇒ NOTE:

Note that the jumper ID is the same as the SCSI ID.

See ["Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5"](#) for the replacement procedure.

⇒ NOTE:

A hard disk drive failure can also be identified by entering **MT** in the Application Code and **DISK** in the Resource Type of the alarm log. However, to identify the failed disk you must access the maintenance log. See Chapter 1, "Getting Started," in *Lucent INTUITY Messaging Solutions Release 4.0 Alarms and Log Messages* for the procedure to access the alarm log.

Identifying Other Hard Disk Drive Failures in a Nonmirrored System

Hard Disk Drives 1 through 5 contain voice storage. If one of these hard disk drives fails user information will be lost. Users will not be able to access their messages and may not be able to log in to the system.

To verify that one of these hard disk drives has failed, see [“Identifying a Hard Disk Drive 6 \(audfs\) Failure in a Nonmirrored System”](#) above for the procedure.

Identifying a Hard Disk Drive Failure in a Mirrored System

In a mirrored system every hard disk drive is paired with another hard disk drive which contains the same information. As a result, if either hard disk drive fails the other drive will continue to operate the system. There will be no noticeable difference in service. A hard disk drive failure will be identified by checking the maintenance log. See [“Identifying a Hard Disk Drive 6 \(audfs\) Failure in a Nonmirrored System”](#) above for the procedure.

If Hard Disk Drive 0 has failed, see [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Mirrored System\)”](#) for the replacement procedure.

If Hard Disk Drive 1 has failed, see [“Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5”](#) for the replacement procedure.

Software and Hardware Procedures for Replacing Hard Disk Drive 0

The following procedure explains how to replace a hard disk drive on an existing Lucent INTUITY system.

The following sections list the procedures for replacing Hard Disk Drive 0 in both mirrored and nonmirrored systems.

Software and Hardware Procedures for Replacing Hard Disk Drive 0 (Nonmirrored System)

Because Disk 0 contains the base system software, you must reinstall the entire Lucent INTUITY system if this disk fails on a nonmirrored system.

Hardware Procedures for Replacing the Hard Disk Drive

The following procedures detail removing and installing a hard disk drive in the MAP/100. [Figure 6-4](#) shows the positions of the hard disk drives.



WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#) in [Chapter 4, “Getting Inside the Computer”](#) for the procedure.




Figure 6-4. Front View of the MAP/100

Removing a Hard Disk Drive

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. If the system is in service, perform the following Steps a and b.
 - a. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
3. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#) for the procedure.
4. Access the peripheral bay. See [“Accessing the Peripheral Bay”](#) in [Chapter 4, “Getting Inside the Computer”](#) for the procedure.
5. Locate and remove the power cord and bus cable assembly connections for the hard disk drive.

6. Locate the two screws on each side of the peripheral bay chassis that secure the hard disk drive. Holding the rear of the drive, loosen and remove the mounting screws.
7. Slide the hard disk drive forward within the peripheral bay and remove the unit through the front opening of the MAP/100 chassis.
8. Place the defective hard disk drive upside down, with the circuit board facing up, on an ESD-protected surface.
9. Loosen and remove two screws on each side of the drive to release it from the mounting brackets.

These screws are shown as Item 8 in [Figure 6-5](#).




Figure 6-5. Hard Disk Drive Mounting Kit

10. Return the hard disk drive to the remote maintenance center. Include the following information with the hard disk drive:
 - The name and phone number of the technician
 - The symptoms associated with the disk failure
 - The TSCSS ticket number

Readying a New Hard Disk Drive for Installation

1. Remove the universal installation kit from the top of the hard disk drive carton.
2. Open the carton.

Cut the top seam and side seams so that the carton can be used again if the hard disk needs to be returned to the factory.

 **NOTE:**

You must return any piece of equipment in the original shipping carton and packing materials to ensure warranty.

3. Remove the hard disk drive from the antistatic bag. Keep the bag with the shipping carton.
4. Place the hard disk drive upside down, with the circuit board facing up, on an ESD-protected surface.
5. Verify that all jumpers are correctly positioned.

There are three types of hard disk drives supported by the Lucent INTUITY system. The Starfire hard disk drive has the jumpers located in the rear of the drive. [Figure 6-6](#) shows the location of the jumpers on the Starfire hard disk drive. [Figure 6-7](#) through [Figure 6-12](#) show the jumper settings.




Figure 6-6. Jumper Locations on the Starfire Hard Disk Drive




Figure 6-7. Jumper Settings for the First Starfire Hard Disk Drive Installed; Bay 1, SCSI ID = 0




Figure 6-8. Jumper Settings for the Second Starfire Hard Disk Drive Installed; Bay 3, SCSI ID = 6




Figure 6-9. Jumper Settings for the Third Starfire Hard Disk Drive Installed; Bay 5, SCSI ID = 1




Figure 6-10. Jumper Settings for the Fourth Starfire Hard Disk Drive Installed; Bay 6, SCSI ID = 2




Figure 6-11. Jumper Settings for the Fifth Starfire Hard Disk Drive Installed; Bay 2, SCSI ID = 4





Figure 6-12. Jumper Settings for the Sixth Starfire Hard Disk Drive Installed; Bay 4, SCSI ID = 5

The Orion hard disk drive has the jumpers located in the center of the unit ([Figure 6-13](#)). [Figure 6-14](#) through [Figure 6-19](#) show the jumper settings for the Orion hard disk drive.

CAUTION:

The Orion hard disk drive is shipped with a third jumper placed on the thirteenth and fourteenth pins. This jumper must be removed prior to installing the hard disk drive.



orion2a C.JL 050796

Figure 6-13. Jumper Locations on the Orion Hard Disk Drive




Figure 6-14. Jumper Settings for the First Orion Hard Disk Drive Installed;
Bay 1, SCSI ID = 0




Figure 6-15. Jumper Settings for the Second Orion Hard Disk Drive Installed;
Bay 3, SCSI ID = 6




Figure 6-16. Jumper Settings for the Third Orion Hard Disk Drive Installed;
Bay 5, SCSI ID = 1




Figure 6-17. Jumper Settings for the Fourth Orion Hard Disk Drive Installed;
Bay 6, SCSI ID = 2




Figure 6-18. Jumper Settings for the Fifth Orion Hard Disk Drive Installed;
Bay 2, SCSI ID = 4




Figure 6-19. Jumper Settings for the Sixth Orion Hard Disk Drive Installed;
Bay 4, SCSI ID = 5

The Seagate hard disk drive has the jumpers located in the center of the unit ([Figure 6-20](#)). [Figure 6-21](#) through [Figure 6-26](#) show the jumper settings for the Seagate hard disk drive.

CAUTION:

The Seagate hard disk drive is shipped with the jumpers set to SCSI ID 3. This ID is used by the cartridge tape drive.




Figure 6-20. Jumper Locations on the Seagate Hard Disk Drive




Figure 6-21. Jumper Settings for the First Seagate Hard Disk Drive Installed;
Bay 1, SCSI ID = 0




Figure 6-22. Jumper Settings for the Second Seagate Hard Disk Drive Installed; Bay 3, SCSI ID = 6




Figure 6-23. Jumper Settings for the Third Seagate Hard Disk Drive Installed; Bay 5, SCSI ID = 1




Figure 6-24. Jumper Settings for the Fourth Seagate Hard Disk Drive Installed; Bay 6, SCSI ID = 2




Figure 6-25. Jumper Settings for the Fifth Seagate Hard Disk Drive Installed; Bay 2, SCSI ID = 4




Figure 6-26. Jumper Settings for the Sixth Seagate Hard Disk Drive Installed; Bay 4, SCSI ID = 5

6. Set the disk aside and open the Universal Installation Kit which contains the installation hardware.

The kit contains two bags. The first bag contains the:

- LED lenses
- LED with the connector cable assembly
- Faceplate

The second bag contains the:

- Mounting rails
- Spacer bar
- Bag of screws needed for assembly and mounting

7. Discard the following items:

- LED lenses
- LED connector cable assembly
- Spacer bar



NOTE:

If the hard disk drive you are replacing is in Position 4 also discard the faceplate.

8. Place the mounting rails parallel to each other with the smaller of the two flanges of the rails on the inside ([Figure 6-5](#)).
9. Position the hard disk drive with the circuitry down between the rails; the connector end of the drive unit should be flush with the ends of the mounting rails.
10. Align the mounting holes of the drive and the mounting rails.
11. Insert #6-32 x 3/16 in. screws (two screws per side) in the lowest row of slots in the mounting rails and tighten.
12. If the hard disk drive you are replacing is in Position 3, mount the plastic faceplate and secure it to extended bracket ends using two #6-32 x 3/16 in. screws.

Mounting a Hard Disk Drive in the MAP/100

1. Locate the appropriate set of slots on either side of the MAP/100 just behind the front of the peripheral bay.

You will use the screws provided with the Universal Mounting Kit to secure the drive to the MAP/100 peripheral bay.

NOTE:

Use only the bottom position to secure the disk drive/mounting brackets inside the MAP/100. Do not use the threaded holes.

2. Place the drive in the MAP/100 with the aluminum case facing up. Slide the hard disk drive through the front entry area.
3. Hold the drive unit from inside the peripheral bay area and align the bracket with the holes.
4. Insert the mounting screws on each side of the hard disk drive.
Lock the screws in place, but do not tighten.
5. Adjust the bracket depth so the faceplate is aligned with back edge of the bezel.
6. Tighten the screws.

Connecting Cables to the Hard Disk Drive

1. Attach the SCSI cable by aligning it with the pins on the cable receptacle and pushing it on. All connectors are "keyed" to prevent incorrect installation.
2. Attach the power cable to the hard disk drive in the same manner.

3. Dress all cables together neatly and affix the hard disk drive to the peripheral bay assembly by adjusting the plastic cable retainer that is part of the assembly. This cable retainer can be seen by looking through the right side door.

All disk cables are held in place by this retainer as shipped from the factory. Pull on the tab at the top of the retainer to release it. Press on the retainer to secure it.

4. Close the peripheral bay. See [“Closing the Peripheral Bay”](#) in [Chapter 4, “Getting Inside the Computer”](#) for component replacement procedures.
5. Apply power to the unit. See [“Restoring Power to the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#) for instructions on restoring power.
6. Continue with the next step [“Reinstalling the Lucent Intuity System Software.”](#)

Reinstalling the Lucent INTUITY System Software

To reinstall the Lucent INTUITY system software, do the following:

1. Reinstall the base system software. See [“Installing UnixWare”](#) and [“Installing the Platform Software”](#) in [Chapter 9, “Installing Base System Software”](#) for the procedure.
2. Reinstall the Lucent INTUITY system software. See [Chapter 10, “Installing Lucent Intuity System Software”](#) for the procedure.
3. Reinstall the multi-user software, if used. See [Chapter 11, “Installing the Optional Feature Software”](#) for the procedure.
4. If you are installing a system equipped with an internal remote maintenance circuit card, install the corresponding software. See [“Remote Maintenance Circuit Cards”](#) in [Chapter 5, “Replacing or Installing Circuit Cards”](#) for the procedure.

Restoring the Attended and Unattended Backups

1. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#), in [Chapter 3, “Common System Procedures”](#) for the procedure.
2. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
3. Restore the unattended backup tape. See [“Restoring Backups”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.

NOTE:

Only restore the *unattended* backup at this time.

If you do not have an unattended backup tape available complete Steps a through h:

- a. Log in as init.

The system displays the following message:

```
Enter system password:
```

- b. Enter the init password.

The system displays the following message:

```
TERM= [ AT386 ] ?
```

Press **ENTER**.

The system displays the Feature Forms Update window.

- c. Use the down arrow **▼** to place the cursor on the `hours of speech` line.
- d. Enter the same number as is shown in the `current` field of the `hours of speech` line.

For the example screen you would enter 90.

- e. Press **F3** (Save).

The system displays the Confirm window.

- f. Press **y**

The system displays the Feature Forms File Successfully Updated window ([Figure 6-27](#)).

11. Start the voice system. See [“Starting the Voice System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.

You have completed the procedure for replacing Hard Disk Drive 0 in a nonmirrored system.

 **WARNING:**

*After installing a 2-Gbyte hard disk drive into a system as Disk 0, **DO NOT ATTEMPT TO INSTALL AN OLDER VERSION OF UNIXWare.** The version of the operating system tape that should be used contains the phrase “Independent Image.” If the operating system tape does not contain this phrase, notify the remote maintenance center immediately.*

Software and Hardware Procedures for Replacing Hard Disk Drive 0 (Mirrored System)

The system is still up and running even if Hard Disk Drive 0 fails on a mirrored system. The following procedure explains how to replace Hard Disk Drive 0 on a mirrored system.

 **CAUTION:**

This initial synchronization of data on a mirrored system can degrade service, depending on system load. Therefore, perform this procedure only during off-peak hours.

Performing an Attended Backup

See [“Backing Up \(Attended\)”](#) in [Chapter 3, “Common System Procedures”](#) for the attended back-up procedure. Continue with the next procedure “Activating Alarm Suppression.”

Activating Alarm Suppression

 **NOTE:**

If your system has alarm origination perform this procedure before continuing with the next procedure “Hardware Procedures for Replacing a Hard Disk Drive.” If your system does not have alarm origination only perform an attended back-up.

To activate alarm suppression, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
```

```
> Alarm Management
```

The system displays the Alarm Management window ([Figure 6-28](#)).

Alarm Management	
Product ID	<u>2999999999</u>
Alarm Destination	<u>916148606427</u>
Alarm Origination	<u>ACTIVE</u>
Alarm Level	<u>MINOR</u>
Alarm Suppression	<u>ACTIVE</u>
Clear Alarm Notification	<u>ACTIVE</u>

Figure 6-28. Alarm Management Window

2. Move the cursor to the Alarm Suppression field and type **active**
3. Press **F3** (Save).

The system displays the Information window ([Figure 6-29](#)).

```
Information
Alarm Form Update was successful
Press <Enter> to continue.
```

Figure 6-29. Information Window

4. Press **(ENTER)**.
The system displays the Alarm Management window ([Figure 6-28](#)).
5. Continue with the next procedure "[Hardware Procedures for Replacing the Hard Disk Drive.](#)"

Hardware Procedures for Replacing the Hard Disk Drive

To replace the hard disk drive, do the following:

1. Remove both Hard Disk Drive 0 and Hard Disk Drive 1 from the system. See "[Hardware Procedures for Replacing the Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure.
2. Set Hard Disk Drive 0, which was removed from Bay 1, aside.
3. Change the jumpers for Hard Disk Drive 1 to the correct positions for Hard Disk Drive 0 ([Figure 6-7](#) or [Figure 6-14](#)).
4. Replace the changed Hard Disk Drive 1 in Bay 1. See "[Mounting a Hard Disk Drive in the MAP/100](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure.



NOTE:

This hard disk drive is now Hard Disk Drive 0.

5. Set the jumpers on the new hard disk drive to the correct positions for Hard Disk Drive 1 ([Figure 6-9](#) or [Figure 6-16](#)).
6. Place the new hard disk drive in Bay 5. See "[Mounting a Hard Disk Drive in the MAP/100](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure.



NOTE:

This drive is now Hard Disk Drive 1.

7. Complete the procedure in "[Connecting Cables to the Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)".
8. Reboot the Lucent INTUITY system. See "[Rebooting the System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
9. Continue with the next procedure "[Initializing the New Hard Disk Drive.](#)"


Initializing the New Hard Disk Drive

Before You Begin

A hard disk drive that contains data cannot be initialized until the data is removed and the drive is cleaned. If the drive you are installing is not brand new, you must clean it before you can continue. See [“Cleaning a Hard Disk Drive”](#) below for the procedure. If you do not clean the drive now, you will be prompted to do so when you attempt to initialize the drive.

To initialize the hard disk drive, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select



The system displays the Replace Disk window ([Figure 6-30](#)).




Figure 6-30. Replace Disk Window

2. Enter the Disk Name at the following prompt:
Enter the logical name of the disk:
The disk name is the name you copied from the Maintenance Log window.
3. Enter the jumper id at the following prompt:
Enter jumper id of the disk being added (0-1):
The disk jumper id is the id you copied from the Maintenance Log window.

4. Press **F3** (Save).

- If the disk name and jumper id you entered match those of the failed disk drive, the system displays the following message:

This operation will require approximately 10 minutes per gig to complete.

Continue with Step 5.

- If you entered a disk name and/or jumper id that does not exist on the system, the system displays the following message.

Error: disk at selected jumper id not found.
Make sure disk is physically installed properly.
Hit Enter to continue.

The disk name you enter must be the same as the old (failed) disk's name. The jumper id must match the jumper settings on the disk with the above specified name. Therefore, you entered either the disk name and/or jumper id incorrectly on the Replace Disk screen, or you incorrectly set the jumpers on the disk.

Press **ENTER**, return to the appropriate step in this procedure, and correct the mismatch.

Verify the hard disk drive installation was done correctly.

- If you entered a disk name and jumper id for a disk other than the one being replaced, the system displays the following message:

The selected disk appears to be ok. Make sure correct disk name and jumper id were entered on the disk replace screen.
Hit Enter to continue.

The disk name you enter must be the same as the old (failed) disk's name. The jumper id must match the jumper settings on the disk with the above specified name. Therefore, you incorrectly entered the disk name and/or jumper id on the Replace Disk screen.

Press **ENTER**, return to the appropriate step in this procedure, and correct the mismatch.

Verify the disk name and jumper id that you copied in Step 9 above.

6 Replacing the Hard Disk Drive

Software and Hardware Procedures for Replacing Hard Disk Drive 0

Page 6-30

- If you entered the correct disk name and jumper id but the disk that was installed is not brand new, the system displays the following message.

```
The disk being installed at the selected jumper id
has been installed previously. It is recommended
that only new disks from the factory be installed
on this system. Any existing data on this disk
will be lost if you continue.
Do you wish to continue hit [y/n], and then hit
Enter.
```

Complete Steps a through c:

- a. Press y.

The system displays the following message:

```
Option to auto clean disk not supported
in this version.
You must run the shell command fdisk
/dev/rdisk/c0t1d0s0 and delete any active
partitions.
Hit Enter to continue.
```

⇒ NOTE:

If you were referred to this procedure from a procedure for a disk other than Disk Drive 0, the disk name in the fdisk command will differ.

- b. Press .
- c. Clean the hard disk drive. See ["Cleaning a Hard Disk Drive"](#) below for the procedure.
- d. Return to Step 1.

5. Press when the system displays the following message:

```
Disk replace was successful
Hit Enter to continue.
```

Hardware Procedures for Restoring the SCSI IDs for the Hard Disk Drives

In "Hardware Procedures for Replacing the Hard Disk Drive" you were instructed to change the jumper settings and positions for the hard disk drives. In this procedure you will switch the jumper settings and hard disk drives again so that the original Hard Disk Drive 1 has been restored to its correct position and the new hard disk drive becomes Hard Disk Drive 0.

To restore the SCSI IDs for the hard disk drives, do the following:

1. Remove both hard disk drives from the system. See [“Hardware Procedures for Replacing the Hard Disk Drive”](#) in [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.
2. Change the jumpers for the drive removed from Bay 1 to the correct positions for Hard Disk Drive 1 ([Figure 6-9](#) or [Figure 6-16](#)).
3. Change the jumpers for the drive removed from Bay 5 to the correct positions for Hard Disk Drive 0 ([Figure 6-7](#) or [Figure 6-14](#)).
4. Place Hard Disk Drive 0 in Bay 1. See [“Mounting a Hard Disk Drive in the MAP/100”](#) in [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.
5. Place Hard Disk Drive 1 in Bay 5. See [“Mounting a Hard Disk Drive in the MAP/100”](#) in [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.
6. Complete the procedure in [“Connecting Cables to the Hard Disk Drive”](#) in [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.
7. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
8. Continue with the next procedure [“Inactivating Alarm Suppression.”](#)

Inactivating Alarm Suppression

⇒ NOTE:

This procedure only applies to systems with alarm origination. If your system does not have alarm origination, you have completed the procedure for replacing Hard Disk Drive 0 in a mirrored system.

To inactivate alarm suppression, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
```

```
> Alarm Management
```

The system displays the Alarm Management window ([Figure 6-28](#)).

2. Move the cursor to the Alarm Suppression field and type **inactive**
3. Press **F3** (Save).

The system displays the Information window ([Figure 6-29](#)).

4. Press **ENTER**.

Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5

The following procedure explains how to replace a hard disk drive on an existing Lucent INTUITY system.

This procedure applies to all hard disk drives *except Hard Disk Drive 0*. If it is not possible to log in to the Lucent INTUITY system, it is possible that Hard Disk Drive 0 has failed. Refer to one of the “Hardware and Software Procedures for Replacing Hard Disk Drive 0” procedures (nonmirrored or mirrored, depending on the current configuration) for instructions.

⇒ NOTE:

These procedures apply to both mirrored and nonmirrored systems. The only difference between the two systems when replacing hard disk drives other than Hard Disk Drive 0 is the method by which data is restored to the new disk. This difference is clearly noted in this procedure.

Performing an Attended Backup

See [“Backing Up \(Attended\)”](#) in [Chapter 3, “Common System Procedures”](#) for the attended back-up procedure. Continue with the next procedure [“Activating Alarm Suppression”](#).

Activating Alarm Suppression

⇒ NOTE:

If your system has alarm origination perform this procedure before continuing with the next procedure “Hardware Procedures for Replacing a Hard Disk Drive.” If your system does not have alarm origination only perform an attended back-up.

To activate alarm suppression, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
```

```
> Alarm Management
```

The system displays the Alarm Management window ([Figure 6-28](#)).

2. Move the cursor to the Alarm Suppression field and type **active**

3. Press **F3** (Save).
The system displays the Information window ([Figure 6-29](#)).
4. Press **ENTER**.
The system displays the Alarm Management window ([Figure 6-28](#)).
5. Continue with the next step "[Hardware Procedures for Replacing the Hard Disk Drive.](#)"

Hardware Procedures for Replacing the Hard Disk Drive

See "[Hardware Procedures for Replacing the Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure. Continue with the next step "[Initializing the New Hard Disk Drive.](#)"

Initializing the New Hard Disk Drive

See "[Initializing the New Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Mirrored System\)](#)" for the procedure. Continue with the next step "[Inactivating Alarm Suppression.](#)"

Inactivating Alarm Suppression

⇒ NOTE:
This procedure only applies to systems with alarm origination. If your system does not have alarm origination, you have completed the procedure for replacing Hard Disk Drive 1.

To inactivate the alarm origination, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
> Alarm Management
```

The system displays the Alarm Management window ([Figure 6-28](#)).

2. Move the cursor to the Alarm Suppression field and type **inactive**

3. Press **F3** (Save).

The system displays the Information window ([Figure 6-29](#)).

4. Press **ENTER**.
5. For nonmirrored systems restore all backups (attended and unattended), beginning with the oldest first. The last backup restored should be the previous night's automatic unattended backup. See "[Restoring Backups](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
6. For mirrored systems the Lucent INTUITY system automatically replenishes the data on the new disk once the disk is successfully replaced. No further action is necessary

You have completed the procedure for replacing a hard disk drive.

Software and Hardware Procedures for Replacing Hard Disk Drive 6 (audfs)

The following procedure explains how to Hard Disk Drive 6 on an existing Lucent INTUITY system. The procedures listed below apply to nonmirrored systems. For mirrored systems see "[Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5](#)", above.

Performing an Attended Backup

See "[Backing Up \(Attended\)](#)" in [Chapter 3, "Common System Procedures"](#) for the attended back-up procedure. Continue with the next procedure "[Activating Alarm Suppression](#)".

Activating Alarm Suppression

⇒ NOTE:

If your system has alarm origination perform this procedure before continuing with the next procedure "Hardware Procedures for Replacing a Hard Disk Drive." If your system does not have alarm origination only perform an attended back-up.

To activate alarm suppression, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
```

```
> Alarm Management
```

6 Replacing the Hard Disk Drive

Software and Hardware Procedures for Replacing Hard Disk Drive 6 (audfs)

Page 6-35

The system displays the Alarm Management window ([Figure 6-28](#)).

2. Move the cursor to the Alarm Suppression field and type **active**
3. Press **F3** (Save).

The system displays the Information window ([Figure 6-29](#)).

4. Press **ENTER**.

The system displays the Alarm Management window ([Figure 6-28](#)).

5. Continue with the next step "Hardware Procedures for Replacing the Hard Disk Drive."

Hardware Procedures for Replacing the Hard Disk Drive

See "[Hardware Procedures for Replacing the Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure. Continue with the next step "[Initializing the New Hard Disk Drive](#)."

Initializing the New Hard Disk Drive

See "[Initializing the New Hard Disk Drive](#)" in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Mirrored System\)](#)" for the procedure. Continue with the next step "[Inactivating Alarm Suppression](#)".

Installing the Default Voice Mail Database

The default voice mail database must be reinstalled prior to restoring the Lucent INTUITY system from the backup tapes.

To reinstall the default voice mail database, do the following:

1. Log in to the system as root.

NOTE:

If a message appears requesting the terminal type (TERM=AT386) press **ENTER** to accept this default.

2. Insert the AUDIX Platform Set cartridge tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)", in [Chapter 3, "Common System Procedures"](#), for the procedure.
3. Enter **pkgadd -d ctape1 VM-dfltodb**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.  
Type [go] when ready  
or [q] to quit: (default: go)
```

⇒ NOTE:

For this step, **/VM/bin/cleardb** is required. If it is not on the disk, you will be prompted to load it.

4. Press **(ENTER)**.

The system displays the following message:

```
Installation of VM default database was successful.
```

```
Insert a diskette into Floppy Drive 1.
```

```
Type [go] when ready
```

```
or [q] to quit: (default: go)
```

5. Remove the AUDIX Platform Set cartridge tape from the tape drive. See [“Inserting and Removing Cartridge Tapes”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
6. Enter **q**

Restoring the Lucent INTUITY System from the Backup Tapes

To restore the Lucent INTUITY system from the backup tape, do the following:

1. Restore all backups (attended and unattended), beginning with the oldest first. The last backup restored should be the previous night’s automatic unattended backup. See [“Restoring Backups”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.

Inactivating Alarm Suppression

⇒ NOTE:

This procedure only applies to systems with alarm origination. If your system does not have alarm origination, you have completed the procedure for replacing Hard Disk Drive 1.

To inactivate the alarm origination, do the following:

1. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
```

```
> Alarm Management
```

The system displays the Alarm Management window ([Figure 6-28](#)).

6 Replacing the Hard Disk Drive

Software and Hardware Procedures for Installing an Lucent INTUITY System with All

Page 6-37

2. Move the cursor to the Alarm Suppression field and type **inactive**.
3. Press **(F3)** (Save).
The system displays the Information window ([Figure 6-29](#)).
4. Press **(ENTER)**.

You have completed the procedure for replacing Hard Disk Drive 6.

Software and Hardware Procedures for Installing an Lucent INTUITY System with All New Hard Disk Drives

To install the Lucent INTUITY system in a MAP/100 with all new hard disk drives, do the following:

1. Install the hard disk drives. See [“Hardware Procedures for Replacing the Hard Disk Drive”](#) in [“Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)”](#) for the procedure.
2. Complete Steps 1 through 41 in [“Installing UnixWare”](#) in [Chapter 9, “Installing Base System Software”](#).
3. Clean Hard Disk Drives 1 through 6. See [“Cleaning a Hard Disk Drive”](#) below for the procedure.
4. Reboot the Lucent INTUITY system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
5. Complete Steps 42 through 46 in [“Installing UnixWare”](#) in [Chapter 9, “Installing Base System Software”](#).
6. Install the AUDIX software. See [“Installing the Platform Software”](#) in [Chapter 9, “Installing Base System Software”](#).
7. Initialize Hard Disk Drives 1 through 6. Complete Steps 8 through 13 in [“Adding a Hard Disk Drive”](#) below for the procedure.
8. From the UNIX prompt, enter **voledit rename disk06 audfsdisk**
This will rename Hard Disk Drive 6 the audfs disk.
9. Reinstall the Lucent INTUITY system software. See [Chapter 10, “Installing Lucent Intuity System Software”](#) for the procedure.
10. Reinstall the multi-user software, if used. See [Chapter 11, “Installing the Optional Feature Software”](#) for the procedure.
11. If you are installing a system equipped with an internal remote maintenance circuit card, install the corresponding software. See [“Remote Maintenance Circuit Cards”](#) in [Chapter 5, “Replacing or Installing Circuit Cards”](#) for the procedure.

12. Reboot the Lucent INTUITY system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
13. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
14. Restore the attended and unattended backup tapes, beginning with the oldest first. See "[Restoring Backups](#)" in [Chapter 3, "Common System Procedures"](#) for the procedure.
15. You have completed the procedure for installing the Lucent INTUITY system in a MAP/100 with two all hard disk drives.

Adding a Hard Disk Drive

This section details the procedures for adding another hard disk drive to an Lucent INTUITY system. If you are replacing an existing drive see "[Software and Hardware Procedures for Replacing Hard Disk Drive 0](#)" or "[Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5](#)" or "[Software and Hardware Procedures for Replacing Hard Disk Drive 6 \(audfs\)](#)" for the procedure.

To add a hard disk drive, do the following:

NOTE:

This procedure only applies to adding a second hard disk drive to a system which originally had only one hard disk drive.

1. Verify that the new hard disk drive is on site and appears to be in usable condition, with no obvious shipping damage.
2. Prepare the new hard disk drive for installation. See "[Readying a New Hard Disk Drive for Installation](#)" in [Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#) for the procedure.
3. If the system is in service, perform the following Steps a and b:
 - a. Stop the voice system. See "[Stopping the Voice System](#)," in [Chapter 3, "Common System Procedures"](#) for the procedure.
 - b. Shut down the voice system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)," in [Chapter 3, "Common System Procedures"](#) for the procedure.
4. Remove power from the MAP/100. See "[Removing Power from the MAP/100](#)" in [Chapter 4, "Getting Inside the Computer"](#) for the procedure.
5. Access the peripheral bay. See "[Accessing the Peripheral Bay](#)," in [Chapter 4, "Getting Inside the Computer"](#) for the procedure.

6. Install the new hard disk drive. See "[Mounting a Hard Disk Drive in the MAP/100](#)," and "[Connecting Cables to the Hard Disk Drive](#)," in "[Software and Hardware Procedures for Replacing Hard Disk Drive 0 \(Nonmirrored System\)](#)" for the procedure.
7. Reboot the Lucent INTUITY system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)," in [Chapter 3, "Common System Procedures"](#) for the procedure.
8. Starting at the Lucent INTUITY Main menu ([Figure 6-1](#)), select

```
> Customer/Services Administration
> System Management
> Disk Management
> Install Disk
```

The system displays the Install Disk window ([Figure 6-31](#)).

```
Install Disk
Enter jumper id of the disk being added (0-7): _
```

Figure 6-31. Install Disk Window

9. Enter the SCSI ID number of the disk you are installing. See "[Hard Disk Drive Contents in Six Hard Disk Drive Systems](#)," above for the SCSI ID.
10. Press **F3** (Save).

The system displays the following message:

```
clean
Install Disk Operation In Progress..

This operation will require approximately 10 minutes
per gig to complete.

The disk install was successful
Press Enter to continue.
```

If you entered a hard disk drive that was installed is not brand new, the system displays the following message.

```
The disk being installed at the selected jumper id has
been installed previously. It is recommended that only
new disks from the factory be installed on this system.
Any existing data on this disk will be lost if you
continue.
```

Do you wish to continue hit [y/n], and then hit Enter.

Complete Steps a through c:

- a. Press **y**.

The system displays the following message:

```
Option to auto clean disk not supported in this
version.
```

```
You must run the shell command fdisk
/dev/rdisk/c0t1d0s0 and delete any active
partitions.
```

```
Hit Enter to continue.
```

- b. Press **(ENTER)**.
- c. Contact the remote maintenance center. Ask them to remotely log in to the system and clean the disk. Provide them with the jumper id. When the disk has been cleaned, return to Step 8.

11. Press **(ENTER)**.

The system displays the Disk Management menu ([Figure 6-32](#)).



Figure 6-32. Disk Management Menu

12. Reboot the Lucent INTUITY system. See [“Rebooting the System”](#) in [Chapter 3, “Common System Procedures”](#) for the procedure.
13. If the system is to be mirrored, contact the remote maintenance center and ask them to turn on mirroring.

If the system is not to be mirrored, contact the remote maintenance center and ask them to add voice hours to the system.

You have completed the procedure for adding a hard disk drive.

Cleaning a Hard Disk Drive

A hard disk drive which contains data cannot be installed in a Lucent INTUITY system. The hard disk drive must be cleaned before use. The hard disk drives can be cleaned:

- Using the **fdisk** command
- Performing a low-level format

Using the fdisk Command

To clean a hard disk drive using the fdisk command, do the following:

1. Log in to the system as root.
2. Enter fdisk **/dev/rdisk/c0t1d0s0**



CAUTION:

The phrase c0t1d0s0 is the name of the disk to be cleaned. The phrase c0t1d0s0 is correct for Hard Disk Drive 1. Hard Disk Drive 0 is named c0t0d0s0.

The system displays the Disk Cleaning screen ([Figure 6-33](#)).

Total disk size is 2048 cylinders (2048.0MB)

Partition	Status	Type	Start	End	Length	%	Approx MB
1	Active	UNIX System	0	2047	2048	100	2048.0

SELECT ONE OF THE FOLLOWING

0. Overwrite system master boot code
1. Create a partition
2. Change Active (Boot from) partition
3. Delete a partition
4. Update (Update disk configuration and exit)
5. Exit (Exit without updating disk configuration)

Enter selection:

Figure 6-33. Disk Cleaning Screen

3. Enter **3**

The system displays the following message:

```
Enter the number of the partition you want to delete
(or enter x to exit)
```

4. Enter the number of the partition.

For the example given in [Figure 6-33](#), you would enter **1**

The system displays the following message:

```
Do you want to delete partition X? This will erase all
files and programs in this partition (type "y" or "n").
```

5. Enter **y**

The system displays the following message:

```
Partition X has been deleted.
```

The system displays the Disk Cleaning screen ([Figure 6-33](#)).

6. Enter **4**

The system displays the following message:

```
If you have created or altered a partition, you must
initialize the partition to reflect the new
configuration. For a UNIX System partition run the
disksetup(1m) command. For a DOS partition, run the DOS
format command. Changes limited to the "Active" status
field require no additional action.
```

You have completed the procedure for cleaning a hard disk drive.

Performing a Low-Level Format

To low-level format a hard disk drive, do the following:

1. Reboot the system. See ["Rebooting the System"](#) in [Chapter 3, "Common System Procedures"](#).
2. Press **(CONTROL)-(A)** when prompted.

The system displays the Host Adapter Configuration screen ([Figure 6-34](#)).

Would you like to configure the host adapter or run the SCSI disk utilities? Select the option and press <Enter>. Press <F5> to switch between color or monochrome.

Options
Configure/View Host Adapter Settings
SCSI Disk Utilities

Figure 6-34. Host Adapter Configuration Screen

3. Place the cursor on `SCSI Disk Utilities`. Use the up  and down  arrows to move the cursor.
4. Press `ENTER`.

The system displays the SCSI Disk Utilities screen ([Figure 6-35](#)).




Figure 6-35. SCSI Disk Utilities Screen

5. Place the cursor on the SCSI Disk to be formatted. Use the up (▲) and down (▼) arrows to move the cursor.
6. Press (ENTER).

The system displays the Configure/Format Disk screen ([Figure 6-36](#)).



Figure 6-36. Configure/Format Disk Screen

7. Place the cursor on the `Format Disk`. Use the up  and down  arrows to move the cursor.
8. Press `ENTER`.
The system will ask you to confirm that the disk is to be formatted.
9. Enter **y**

6 Replacing the Hard Disk Drive
Cleaning a Hard Disk Drive

Page 6-46

Replacing Other Components



Overview

This chapter describes the procedures for replacing:

- Electromagnetic conductance reduction components
- Memory modules
- Fan filters
- Card cage fans
- Diskette drives
- Power supplies
- SCSI cartridge tape drives
- 25-slot backplane
- Terminator SIPs

Purpose

The purpose of this chapter is to ensure that the correct procedures are used to replace the internal components of the MAP/100. This chapter also provides information on the correct configuration and settings for the individual components.

Replacing Electromagnetic Conductance Reduction Components

Before connecting peripherals or external devices, install toroids and/or ferrites to each interface cable. All installations require the use of toroids and ferrites to meet the individual country agency EMC (electromagnetic conductance) regulations. Installation of toroids and ferrites must be in accordance with these procedures to meet individual country compliances.

A toroid is a 2.5 inch (6.4 cm) circular ferrite. Toroids are made of a highly conductive carbon type of material that is very brittle. If a toroid ring fractures, it should immediately be replaced.

A ferrite is a 1 inch (2.5 cm) rectangular device. Ferrites are made of a variable conductive carbon type material to reduce special EMC frequency band width. Available in split and solid ferrite forms, a special snap-back protective cover is used to install and keep the halves together.

Handle toroids and ferrites with care. Toroids and ferrites are easily fractured and broken. Immediately replace any fractured or broken toroids or ferrites as they are no longer effective for EMC control.

Toroid and Ferrite Placement

The following table contains a summary of special toroid and ferrite installation. See the following sections "[Installing a Toroid](#)" and "[Installing a Ferrite](#)" for detailed installation instructions. [Table 7-1](#) lists the toroid and ferrite placement.

Table 7-1. Toroid and Ferrite Placement

Installed Component:	Cable:	Toroid/Ferrite Placement:	Type:	Number of Cable Ties:
MAP Chassis	Power cord	3 ferrites	B	1 large
Keyboard	Keyboard cable	1 toroid Wrap the cable 3 turns on the toroid	A	2 small
Monitor	Monitor power cable	3 ferrites	B	1 large
Monitor	Monitor video cable	1 ferrite	B	1 large

Continued on next page

Table 7-1. Toroid and Ferrite Placement — Continued

Installed Component:	Cable:	Toroid/Ferrite Placement:	Type:	Number of Cable Ties:
CPU serial port COM1 or COM2	CPU serial port cable	1 ferrite	B	1 large
CPU parallel port (only used if optional printer will be installed)	Printer cable	1 ferrite	B	1 large
DCIU circuit card	Cable from a DEFINITY® switch to the Lucent™ INTUITY™ system	none	none	none
ACCX Circuit Card	80-pin cable that plugs into a breakout box	none	none	none
T/R Circuit Card AYC10 or AYC29	Two 3 foot unshielded flat modular cables for each T/R circuit card	1 ferrite on each modular cable Wrap each cable 1 turn through the ferrite	none	none

Continued on next page

Table 7-1. Toroid and Ferrite Placement — *Continued*

Installed Component:	Cable:	Toroid/Ferrite Placement:	Type:	Number of Cable Ties:
T/R Circuit Card AYC30	Two 3 foot unshielded flat modular cables for each T/R circuit card	1 ferrite on each modular cable Wrap each cable 1 turn through a pair of toroids Each pair of toroids may support a maximum of 11 cables	B A	none 1 small on the cable 2 small on the toroid
LAN Circuit Card	Unshielded modular cable	1 ferrite Wrap the cable 1 turn through the ferrite	B	none
Multi-Port Serial Circuit Card	Unshielded modular cable	1 ferrite on each modular cable Wrap the cable 1 turn through the ferrite	B	none


General Toroid and Ferrite Installation Guidelines

 **CAUTION:**

Handle all toroids and ferrites with care. They are easily broken. Do not use any that are broken or fractured.

When installing toroids and ferrites:

- Place toroids and ferrites as close as possible to the computer chassis ([Figure 7-1](#)).



toroid1a LJK 082696

Figure 7-1. Toroid and Ferrite Placement

- Minimize the amount of cable between the toroids and ferrites and the chassis.
- Wrap cables as tightly as possible. Do not leave large amounts of slack in the loop(s).
- Place small cable ties to hold the cable wrap(s) tightly in place around the toroids. Use large cable ties behind the ferrite(s) to help them to stay in place.

Installing a Toroid

The following is the general toroid installation procedure. [Figure 7-2](#) shows a paired toroid example installation.




Figure 7-2. Toroid Pair Installation

Installing a Single Toroid

To install a single toroid, do the following:

1. Wrap each modular cable tightly around the toroid.
2. Secure each cable with a small cable tie to reduce cable movement.
3. Trim the cable tie.

Installing Paired Toroids

To install paired toroids, do the following:

1. Place two toroids together.
2. Secure the toroids with a small cable tie.
3. Trim the cable tie.
4. Wrap each modular cable around the toroid tightly. Wrap the cables around the toroid opposite of the small cable tie.
5. Secure the modular cables with a cable tie to reduce cable movement.
6. Trim the cable tie.

Installing a Ferrite

To install a ferrite, do the following:

1. Open the ferrite by gently pulling the fastener away from the body of the ferrite.
 2. Place the cord or cable in the groove inside the ferrite ([Figure 7-3](#)).
-




Figure 7-3. Example Ferrite (Type B) Installation

3. If the cable is to be wrapped around the ferrite, loop the cable tightly around half of the ferrite and place the cable into the groove ([Figure 7-4](#)).




Figure 7-4. Example Ferrite (Type B) Installation

4. Gently snap the ferrite shut.
5. Attach a large cable tie directly behind the ferrite to secure it. If the cable is installed looped through the ferrite, no cable tie is required.
6. Trim the cable tie.

Replacing Defective Memory Modules

This section describes:

- How to determine if the memory modules are damaged
- How to replace the memory

⚠ WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

The MAP/100 memory is located on the P5 120 MHz CPU circuit card ([Figure 7-5](#)).




Figure 7-5. CPU Circuit Card SIMM Location

Identifying a Damaged SIMM

To determine which of the SIMMs is defective, you must test each pair. One pair of SIMMs must be removed and the system then rebooted using the remaining SIMMs to obtain a reading on the amount of memory available.

Checking for Proper SIMM Seating

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. If the system is in service, perform the following steps.
 - a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.

7 Replacing Other Components

Replacing Defective Memory Modules

Page 7-10

3. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#), for power removal procedures.
4. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
5. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
6. Carefully remove the CPU circuit card. See [“Removing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for more information on removing the CPU circuit card.
7. Verify that all SIMMs are properly seated in their slots. If all are properly seated, continue with the next procedure [“Checking for Defective SIMMS.”](#)

If one or more of the SIMMs are not properly installed or seated, do the following.

- a. Properly seat the SIMM.
- b. Replace the CPU circuit card. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
- c. Reboot the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.

If the system shows an amount of memory equal to that installed on the card, the problem has been corrected.

If the system shows an amount of memory less than that installed on the card, continue with the next procedure, [“Checking for Defective SIMMS.”](#)

Checking for Defective SIMMS

1. Remove one pair of the SIMMs. See [“Removing SIMMS”](#), below for more information on removing the SIMMs.

If the CPU circuit card is equipped with only one pair of SIMMS the pair must be replaced. See [“Installing SIMMS”](#), below for more information on installing the new pair of SIMMs.

2. Reinstall the CPU circuit card. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
3. Restore power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for more information on restoring the power.
4. Reboot the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
5. Verify the amount of memory as the system reboots.

7 Replacing Other Components

Replacing Defective Memory Modules

Page 7-11

6. If the amount of memory shown by the system is not equal to the amount of memory still installed on the card, one of the remaining SIMMS is defective. Complete Steps a through c. If the memory is not correct continue with Step 7.
 - a. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for more information on removing the power.
 - b. Replace the SIMMs which were removed in Step 1. See [“Installing SIMMs”](#), below for more information on replacing the SIMM.
 - c. Return to Step 1 and continue, removing the second pair of SIMMs.
7. If the amount of memory shown by the system equals the amount of memory still installed on the card, one of the SIMMs you removed is defective. Replace the pair with a new pair of SIMMs. See [“Installing SIMMs”](#), below for more information.
8. Close the circuit card cage. See [“Closing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
9. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
10. Apply power to the unit. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.

Removing SIMMs

1. Verify that the new/replacement SIMMs are on site and appear to be in usable condition.
2. Shut down the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
3. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
4. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
5. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
6. Remove the CPU circuit card. See [“Removing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for more information on removing the CPU circuit card.
7. Lay the CPU circuit card on a flat, clean, ESD-protected surface.

7 Replacing Other Components

Replacing Defective Memory Modules

Page 7-12

8. Release the metal snap locks gently at the edge of the SIMM connectors.
9. Rotate the SIMM back and downward to approximately a 60-degree angle.
10. Remove the SIMM.

Installing SIMMs

1. Shut down the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
2. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
3. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
4. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
5. Remove the CPU circuit card. See [“Removing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for this procedure.
6. Install the SIMM by positioning the new SIMM at approximately a 60-degree angle with respect to the CPU circuit card.

All SIMMs are keyed to prevent them from being inserted incorrectly.



NOTE:

Install a new SIMM in the slot adjacent to the last SIMM installed. Do not leave any empty sockets between SIMMS.

7. Push down at that angle until the SIMM is reset into the SIMM carrier.
8. Snap the SIMM into place by rotating it to an upright position.
The metal snap lock on the ends of the connector for the SIMM will be forced open and then lock when in the upright position.
9. Ensure the connector guide pins are seated into the clearance holes provided at each end of the SIMM.
When properly seated, the guides should be fully extended into the circuit card clearance holes.
10. Reinstall the CPU circuit card. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for this procedure.
11. Reboot the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
12. Verify the amount of memory as the system reboots.

13. Close the circuit card cage. See [“Closing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
14. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
15. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.

Replacing the Fan Filter

The MAP/100 is equipped with two fan filters located behind the front doors. The fan filters are designed to remove dust and debris from the air before the air circulates inside the chassis. The fan filter should be checked on a regular basis to determine the condition and cleaned if necessary.

Removing Fan Filters

The filters can be removed by opening the front doors and detaching the filter material from the velcro fasteners.

Cleaning the Fan Filter

Cleaning the fan filter should be a part of routine maintenance. Clean the fan filter with mild soap and water. Allow it to air dry before you replace it.



CAUTION:

Do not use heat to dry the filter and do not place a wet or damp filter into the MAP/100.

Installing Fan Filters

To install a filter, position it behind the doors and press on the velcro fasteners.

Replacing a Fan

The MAP/100 contains six fans that provide forced-air cooling for the unit. There are four circuit card cage fans, one peripheral bay fan and one power supply fan. The circuit card cage fans and the peripheral bay fan are serviceable. The power supply fan is *not* serviceable and repairs should *never* be attempted.

Replacing a Circuit Card Cage Fan

The circuit card cage fans are located in a bracket behind the left front door. The circuit card cage fans are attached to an assembly. All four circuit card cage fans must be removed from the system to replace one.

Removing a Circuit Card Cage Fan

To remove a circuit card cage fan, do the following:

1. Locate the defective fan.

The MAP/100 monitoring panel includes indicator lamps which are lit when the associated fan in operation ([Figure 7-6](#)). The indicator lamp for the defective lamp will not be lit.




Figure 7-6. MAP/100 Monitoring Panel

2. If the system is in service, perform the following steps.
 - a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
3. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
4. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
5. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.

6. Locate and disconnect the fan assembly connector.
This connector is located adjacent to the fan bracket in the upper part of the unit.
7. Remove the two screws which hold the fan assembly in the MAP/100.
8. Remove the fan assembly from the MAP/100.
9. Disconnect the red and black wires which attach to the defective circuit card cage fan.
10. Remove the four screws and washers from the mounting holes.
11. Remove the circuit card cage fan from the fan assembly.

Installing a Circuit Card Cage Fan

To install a circuit card cage fan, do the following:

1. Place the circuit card cage fan on the fan assembly.



NOTE:

The circuit card cage fan unit must be installed so that air travels through the mounting plate hole towards the circuit card cage area. Locate the air-flow direction indicators to ensure that the fan is properly mounted.

2. Secure it with the four bolts.
3. Reconnect the red and black wires.
Be sure to attach the wires in the same position as they are attached in the other fans.
4. Replace the fan assembly.
5. Replace the two screws which secure the fan assembly in the MAP/100.
6. Reconnect the fan assembly connector.
7. Tuck the connector inside the unit so that it is adjacent to the fan bracket assembly.
8. Close the circuit card cage. See [“Closing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
9. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
10. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.

11. Verify that the fan is working by observing the MAP/100 monitoring panel ([Figure 7-6](#)).



CAUTION:

Do not leave the MAP/100 powered up for any length of time until the circuit card cage fans are fully operational.

Replacing the Peripheral Bay Fan

The peripheral bay fan is located in the rear of the MAP/100 behind the power supply ([Figure 7-7](#)).




Figure 7-7. Peripheral Bay Fan Location

Removing the Peripheral Bay Fan

To remove the peripheral bay fan, do the following:

1. If the system is in service, perform the following steps.
 - a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
2. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
3. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
4. Remove the 17 screws which hold the top access panel to the MAP/100.
5. Remove the top access panel ([Figure 7-7](#)).
6. Disconnect the red and black wires attached to the peripheral bay fan.
7. Remove the four screws, washers, and nuts from the mounting holes.
8. Remove the fan and grill from the rear wall of the unit.

Installing the Peripheral Bay Fan

To install the peripheral bay fan, do the following:

1. Place the peripheral bay fan and the grill against the inside rear fan opening.



NOTE:

The grill must go to the inside of the chassis.



NOTE:

The peripheral bay fan must be installed so that air travels through the mounting plate hole towards the peripheral bay area. Locate the air-flow direction indicators to ensure that the fan is properly mounted.

2. Secure the peripheral bay fan with the four screws, washers, and nuts. Be sure to orient the fan so that the electrical connections to it are accessible once the fan is mounted.



NOTE:

The nuts should be on the inside of the unit when the fan is mounted.

3. Replace the red and black wires.

The red wire attaches to the "+" terminal and the black wire attaches to the "-" terminal.

4. Replace the top cover.
5. Secure it with the 17 screws.
6. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
7. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
8. Verify that the fan is working by observing the MAP/100 monitoring panel ([Figure 7-6](#)).



CAUTION:

Do not leave the MAP/100 powered up for any length of time until the peripheral bay fan is fully operational.

Replacing the Diskette Drive

The 1.44 Mbyte, 3.5-inch diskette drive is assembled by the manufacturer with a mounting kit. The diskette drive is located in Bay 8 of the peripheral bay, as shown in [Figure 7-8](#).




Figure 7-8. Front View of the MAP/100



WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

Removing the Diskette Drive

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. If the system is in service, perform the following Steps a and b.
 - a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for voice system administration.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for voice system administration.
3. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
4. Access the peripheral bay. See [“Accessing the Peripheral Bay”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
5. Remove the power cord connector from the back of the diskette drive. Move it to the side.
6. Remove the bus cable assembly connection from the back of the diskette drive. Move it to the side.
7. Locate the four 3-millimeter screws on the peripheral bay chassis. Holding the rear of the diskette drive, remove these screws.



CAUTION:

Keep these four screws separate. These screws are metric. Using any of the other screws associated with the MAP/100 will damage the threads in the diskette drive mounting hardware.

8. Slide the diskette drive forward within the peripheral bay and remove it through the front opening of the MAP/100 chassis.



CAUTION:

Handle the diskette drive with care. The spindle motor, stepping motor, and printed circuit board are located on the bottom of the diskette drive. Do not place any force or strain on these components and do not touch the surface of the diskette drive printed circuit board.

9. Place the diskette drive assembly on an ESD-protected surface and carefully remove the PCBA 5-inch adapter card ([Figure 7-9](#)).



CAUTION:

Do not bend or twist the PCBA 5-inch adapter card connector pins.




Figure 7-9. Diskette Drive Unit PCBA 5-Inch Adapter Card

10. Remove the four 3-millimeter screws that secure the drive unit to the 5.25-inch diskette drive hardware mounting kit. These screws are shown as item 8 in [Figure 7-10](#).




Figure 7-10. Diskette Drive Assembly

11. Slide the drive unit back to clear the front bezel. The bezel is shown as item 2 in [Figure 7-10](#).
12. Place the diskette drive upside down, with the printed circuit board facing up, on an ESD-protected surface.

Installing a Diskette Drive

1. Remove the new diskette drive unit from its ESD-protective wrapping.



NOTE:

Keep the package and all ESD-protective wrapping to return the defective unit. Re-use of the original replacement unit packaging is necessary to meet the manufacturer's warranty.

2. The diskette drive for the MAP/100 is produced in six versions:
 - FD-235HF-201
 - FD-235HF-3201
 - FD-235HF-4429
 - FD-235F-5429
 - FD-235HF-6429
 - FD-235HF-6529
 - FD-235HF-7529

Identify the diskette drive you are installing.

3. Verify that the jumpers are set as shown in [Figure 7-11](#) and [Figure 7-12](#).




Figure 7-11. Diskette Drive Jumper Connections (6429, 6529, and 7529)




Figure 7-12. Diskette Drive Jumper Connections (201, 3201, 4429, and 5429)

4. Hold the diskette drive by the metal sides and carefully attach it to the 5.25-inch mounting hardware and bezel.
5. Secure the diskette drive using the four 3-millimeter screws removed in [10](#) of ["Removing the Diskette Drive"](#).
6. Attach the PCBA adapter card, being careful to align the tabs shown in [Figure 7-9](#).
7. Slide the new diskette drive unit into the MAP/100 peripheral bay. Ensure the front of the diskette drive is flush with the other units in the peripheral bay.
8. Secure the diskette drive to the peripheral bay with the four 3-millimeter screws removed in [7](#) of ["Removing the Diskette Drive"](#).


9. Attach the diskette drive cable assembly to the PCBA adapter card. Ensure that the red bus cable No. 1 conductor tracer indicator is towards the *bottom* of the peripheral bay. Both the PCBA card and the diskette drive cable assembly are keyed to prevent improper connection.
10. Attach the mini power-cable assembly that is provided with the system power supply wiring.
11. Close the peripheral bay. See [“Closing the Peripheral Bay”](#), in [Chapter 4, “Getting Inside the Computer”](#), for these procedures.
12. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
13. Replace the right front door. See [“Replacing the Front Doors”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
14. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.

Replacing the Power Supply


There are two types of power supply available with the MAP/100.

- Power supply with an uninterruptible power supply (UPS)
- Power supply with redundant power supply capability

You can determine which power supply your system is equipped with by viewing the front display panel on the MAP/100 ([Figure 7-13](#)).



Display panel of MAP/100
equipped with UPS



Display panel of MAP/100
equipped with redundant
power supply capability

fponted C.J.L. 082996

Figure 7-13. MAP/100 Front Display Panels

Replacing a Power Supply with a UPS

The power supply with a UPS provides 110/220-VAC and is located behind the peripheral bay. The UPS is a battery included with the power supply. Both the power supply and the battery are housed within a removable module ([Figure 7-14](#)).




Figure 7-14. Battery Backup Type Power Supply

The following section details the procedures for replacing a power supply and battery module with another power supply and battery module.

Removing the Battery Backup Type Power Supply

To remove the battery backup type power supply, do the following:

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. If the system is in service, perform the following steps.

- a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
- b. Shut down the voice system. See [“Shutting Down the System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
3. Remove the incoming power. See [“Removing Power from the MAP/100”](#) in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
4. Remove the dress covers. See [“Removing the Dress Covers”](#) in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
5. Open and remove the right front door. See [“Opening and Removing the Front Doors”](#) in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
6. Access the peripheral bay. See [“Accessing the Peripheral Bay”](#) in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
7. Loosen the 13 1/4-turn fasteners around the perimeter of the Power Supply A chassis ([Figure 7-14](#)).



CAUTION:

The power supply chassis weighs 50 pounds. There is a handle on the back of the receptacle panel so that two persons can lift and move it.


8. Grasp the power supply chassis external pull handle and pull the power supply chassis from the unit until it rests against the safety stop.



NOTE:

Make sure no cables are caught inside the MAP/100.

9. Remove the mating plugs from the panel-mounted receptacles. The receptacles are located on top of the power supply ([Figure 7-15](#)).



pinout2 CJL 050896

Figure 7-15. Battery Backup Type Power Supply Cable Receptacles

10. Push the power supply chassis slightly forward and lift it so that the slot on the MAP/100 and safety stops on the power supply chassis are aligned.
11. Remove the power supply chassis from the MAP/100.



CAUTION:

It is important that the defective power supply be returned to the remote maintenance center in the same condition as it was in the Lucent INTUITY system. If the power supply is damaged during removal, packaging, or shipping adequate failure analysis can not be conducted.

Installing the Battery Backup Type Power Supply

To install the battery backup type power supply, do the following:

1. Tilt the power supply chassis down and away from you, so that the slot in the MAP/100 and safety stop are aligned.
2. Slide the power supply chassis into the MAP/100. Leave the power supply chassis extending from the MAP/100 ([Figure 7-14](#)).



NOTE:

Make sure no cables become caught.

3. Attach the mating plugs from the panel-mounted receptacles.

All cables are marked, and a label on the power supply chassis is provided to facilitate attachment of the cables.

- Slide the power supply chassis back into the MAP/100 so that the front of the chassis is flush with the side of the MAP/100.
- Tighten the 13 1/4-turn fasteners on the power supply chassis.



CAUTION:

The maximum tightening torque for the 1/4-turn fasteners is 6 in-lbs (0.68 N-M). Applying excessive force will permanently damage these fasteners.

- Close the peripheral bay. See "[Closing the Peripheral Bay](#)" in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.
- Replace the dress covers. See "[Replacing the Dress Covers](#)" in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.
- Replace the right front door. See "[Replacing the Front Doors](#)" in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.
- Apply power to the MAP/100. See "[Restoring Power to the MAP/100](#)" in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.

Replacing the Battery

The following procedures detail removing and installing the battery module on the MAP/100. The battery module should be replaced approximately every two years.



WARNING:

Before replacing the MAP/100 Battery Module, carefully read through these instructions. They include cautionary notes about safe handling and proper disposal of the sealed lead-acid batteries.



CAUTION:

Protective clothing should be worn in case of accidental battery electrolyte leakage. See "[Battery Safety](#)", below for more details.

Removing the Battery Module

All AC powered MAP/100 units are equipped with four battery cells to provide the uninterruptable power supply during power failures. These batteries are housed in the power supply chassis. To replace the batteries, do the following:

- Remove the power supply chassis. See "[Replacing the Power Supply](#)", above for the procedure.
- Remove the screws which attach the battery module to the power supply chassis. These screws are marked "A" in [Figure 7-16](#).

3. Disconnect the black lead that connects the power supply to the top lug of the top battery ([Figure 7-16](#)).
4. Disconnect the red lead that connects the power supply to the bottom lug of the bottom battery ([Figure 7-16](#)).
5. Remove the quick-connect contacts from all battery terminals of the new Battery module. Use these contacts to insulate the terminals of the old batteries.



CAUTION:

Refer to the [“Battery Safety”](#) section of these instructions for information regarding proper handling, storage, and disposal of used lead-acid batteries.

6. Remove the battery module from the power supply chassis.
7. Disconnect the three red jumpers that connect the batteries together ([Figure 7-16](#)).
8. Remove the two screws which hold the battery module sheet metal pieces together. These screws are marked “B” in [Figure 7-16](#).
9. Separate the two pieces of sheet metal.
10. Remove the four batteries.
11. Discard the two pieces of sheet metal from the old batteries.




Figure 7-16. Battery Module

Installing the Battery Module

To install the battery module, do the following:

1. Orient the new battery module as shown in [Figure 7-16](#).
2. Attach the two screws which were removed in [8](#) of "[Removing the Battery Module](#)."
3. Connect the batteries with the three red jumpers ([Figure 7-16](#)).
4. Place the battery module into the power supply chassis.
5. Secure it with the three screws removed in [2](#) of "[Removing the Battery Module](#)."
6. Connect the black lead from the power supply to the top lug of the top battery ([Figure 7-16](#)).

7. Connect the red lead from the power supply to the bottom lug of the bottom battery ([Figure 7-16](#)).
8. Remove the paper backing from the caution label, included in the battery kit. Affix this label above the power supply chassis outside handle.
9. Install the power supply module. See [“Installing the Battery Backup Type Power Supply”](#) above for the procedure.
10. Repackage the old batteries in the new battery module shipping container for disposal. Be sure to place the old batteries in the bag included with the shipping container.

Battery Safety

CAUTION:

Read and understand these safety instructions before handling the lead-acid batteries in the MAP/100 Battery Module.

Rechargeable lead-acid batteries contain a small amount of fluid electrolyte that could escape if the batteries were damaged or beyond their end of life. This fluid electrolyte is corrosive to most materials, and should not be allowed to contact clothing, skin, or other parts of the MAP/100 platform. Rubber gloves, eye protection (i.e. safety glasses or goggles), and clothing should be worn, and a protective place mat should be used for placement of the removed battery module.

If the electrolyte comes in contact with skin, hair, or eyes, immediately flush the affected area with water. If the electrolyte contacts clothing, immediately flush the affected area with water and remove or change clothing as soon as possible. If the electrolyte is ingested, do not induce vomiting. Instead, drink large quantities of water and seek medical attention immediately.

To minimize the possibility of injury or damage during handling, all battery terminals should be covered with an insulator. A fully insulated quick-connect contact, thick non-conductive tape, or a dab of silicon caulking will serve this function. When handling batteries take care not to allow bracelets, watch bands, and necklaces contact the battery terminals.

Always store batteries in a cool, dry, well ventilated place. Never allow batteries near flames, sparks, or high heat sources. If there is evidence of leaking electrolyte (liquid present, corrosion, strong acrid odor, etc.) cover the liquid with absorbent clay, kitty litter or sand. Neutralize the electrolyte with sodium bicarbonate (baking soda), soda ash, or lime.

WARNING:

FEDERAL, STATE AND LOCAL LAWS PROHIBIT THE IMPROPER DISPOSAL OF LEAD-ACID BATTERIES AND HAZARDOUS WASTE

CLEAN-UP MATERIALS. THE ONLY PROPER DISPOSAL METHOD FOR SPENT (NON-LEAKING) LEAD-ACID BATTERIES IS RECYCLING THEM.

The responsibility for disposal of spent batteries lies with the user. The batteries must be transported to a licensed recycling facility for proper disposal. Check your local telephone directory for facilities nearby. If none are listed, call your local state or federal EPA office for alternate locations.

See the instructions located in the battery replacement kit for recycling options.

If battery casings have failed so that any quantity of electrolyte has escaped, package batteries for shipping in a plastic bag and box (the box that contained the replacement batteries). Do not the leaking electrolyte touch your skin or the customer's floor or other equipment! If necessary, follow safety procedures included with the replacement batteries. Seal the box now containing the old batteries with tape and mark it clearly:

**CONTAINS CORROSIVE MATERIALS; HOLD FOR PICKUP BY BURNHAM
TRANSPORT COMPANY, A LICENSED TRANSPORTER OF SUCH
MATERIALS.**

See the instructions located in the battery replacement kit for disposal of leaking batteries.

Replacing the Power Supply in a Power Module Assembly with Redundant Power Supply Capability

The following sections pertain only to MAP/100 platforms which have redundant power supply capability.

There are two indicators, on the front panel ([Figure 7-13](#)), for each power supply in a MAP/100 equipped with a power module assembly with redundant power supply capability. The "PS1 OK" and the "PS2 OK" lights indicate that the power supplies are working properly. If one of these lights is not lit, the system has detected a fault.


The "PS1 FAN" and the "PS2 FAN" lights indicate that the fans in the power supplies are operating properly. If one of these lights is not lit, the system has detected a fault. The power supply fan can not be serviced. As a result, the entire power supply must be replaced.

The power module assembly with redundant power supply capability may be equipped with either one or two power supplies. In either case, the power supply module assembly with redundant power supply capability is not equipped with an internal UPS. The procedure for replacing power supplies differs depending on the number of power supplies present.

MAP/100s equipped with a single power supply, installed by the Lucent factory, will have the power supply located in position PS1 ([Figure 7-17](#)). A filler panel will be located in position PS2 ([Figure 7-17](#)).

⚠ CAUTION:

Do not operate the MAP/100 for extended periods without both positions, PS1 and PS2, being equipped with either a power supply or a filler panel.




m100pwr1 C.J.L 050896

Figure 7-17. Power Module Assembly with Redundant Power Supply Capability

The power supplies installed in the power module assembly automatically sense whether the incoming voltage is 110 or 220 VAC. There are no manual adjustments necessary to prepare the power supply for the incoming voltage.

The power module assembly with redundant power supply capability should never be removed from the MAP/100 when replacing or installing new power supplies. There are no serviceable components in the power module assembly.

The power supplies attach to the power module assembly using a male connector and a backplane receptor (Figure 7-18).



pscvpb1 C.J.L. 082696

Figure 7-18. Power Supply Back View

Removing the Power Supply in a Power Module Assembly Equipped with a Single Power Supply

To remove the power supply in a power module assembly equipped with a single power supply, do the following:

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. If the system is in service, perform the following steps.
 - a. Stop the voice system. See “[Stopping the Voice System](#)” in [Chapter 3, “Common System Procedures”](#), for the procedure.
 - b. Shut down the voice system. See “[Stopping the Voice System](#)” in [Chapter 3, “Common System Procedures”](#), for the procedure.
3. Remove the dress covers. See “[Removing the Dress Covers](#)” in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
4. Place the power switch on the power supply in the off position ([Figure 7-17](#)).



CAUTION:

The power supply surface may be hot.

5. Make sure the power supply status indicator is off.
 If the power supply status indicator is not off repeat [4](#).
6. Loosen the two 1/4-turn fasteners that hold the power supply to the power module assembly ([Figure 7-17](#)).



NOTE:

Do not loosen the 1/4-turn fasteners which hold the power module assembly to the MAP/100.

7. Grasp the power supply external pull handle and pull the power supply from the power module assembly.
8. Place the power supply to the side.



CAUTION:

It is important that the defective power supply be returned to the remote maintenance center in the same condition as it was in the Lucent INTUITY system. If the power supply is damaged during removal, packaging, or shipping adequate failure analysis can not be conducted.

Installing the Power Supply in a Power Module Assembly Equipped with a Single Power Supply

To install the power supply in a power module assembly equipped with a single power supply, do the following:

1. Make sure the AC power switch on the power supply being installed is in the "OFF" position.
2. Align the power supply with the slot in the power module assembly. Make sure the male power receptacle on the power supply is at the bottom.
3. Slide the power supply into the power supply module assembly.
4. Apply pressure to ensure that the power supply is seated properly.
5. Tighten the two 1/4-turn fasteners on the power supply.



CAUTION:

The maximum tightening torque for the 1/4-turn fasteners is 6 in-lbs (0.68 N-M). Applying excessive force will permanently damage these fasteners.

6. Place the AC power switch on the power supply in the "ON" position.
7. Make sure the power supply status indicator on the power supply is lit.
This indicates the power supply is operational.
8. Make sure the "PS1 OK" and "PS1 FAN" light on the front panel of the MAP/100 are both lit ([Figure 7-13](#)).



NOTE:

The "PS2 OK" and "PS2 FAN" lights will not be lit because the MAP/100 is not equipped with a second power supply.

9. Replace the dress cover. See "[Replacing the Dress Covers](#)" in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

Adding a Second Power Supply in a Power Module Assembly that has Redundant Power Supply Capability

The following section details the procedure for adding a second power supply to a system which was supplied with only one.

Removing the Filler Panel

The filler panel must be removed before a second power supply can be installed. It is not necessary to take the system out of service to remove or install the filler panel.

CAUTION:

Do not operate the MAP/100 for extended periods without both positions, PS1 and PS2, being equipped with either a power supply or a filler panel.

To remove a filler panel, do the following:

1. Remove the dress covers. See "[Removing the Dress Covers](#)" in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

CAUTION:

The power supply surface may be hot.

2. Loosen the two 1/4-turn fasteners that hold the filler panel to the power supply module assembly ([Figure 7-17](#)).
3. Grasp and remove the filler panel.

Installing a Second Power Supply

1. Verify that the replacement equipment is on site and appears to be in usable condition, with no obvious shipping damage.
2. Make sure the AC power switch on the power supply being installed is in the "OFF" position.
3. Align the power supply with the slot in the power module assembly. Make sure the female power receptacle on the power supply is at the bottom.
4. Slide the power supply into the power supply module assembly.
5. Apply pressure to ensure that the power supply is seated properly.
6. Tighten the two 1/4-turn fasteners on the power supply.

 **CAUTION:**

The maximum tightening torque for the 1/4-turn fasteners is 6 in-lbs (0.68 N-M). Applying excessive force will permanently damage these fasteners.

7. Place the AC power switch on the power supply in the "ON" position.

 **WARNING:**

Do not turn off the active power supply if the INTUITY CONVERSANT system is operating.

8. Make sure all four of the power supply indicator lights on the front panel of the MAP/100 are lit ([Figure 7-13](#)).

These lights indicate the power supplies are operational.

If any of the four indicator lights are not lit, replace the respective power supply.

9. Replace the dress cover. See "[Removing the Dress Covers](#)" in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

Removing a Power Supply in a Power Module Assembly Equipped with Two Power Supplies

MAP/100 platforms equipped with two power supplies (redundant supplies) allow replacement of one of the power supplies while the INTUITY CONVERSANT system remains in service. The following procedures must be followed carefully to ensure that the MAP/100 operation is not unintentionally interrupted.

1. Identify the power supply to be replaced by observing the power supply status indicators on the front panel of the MAP/100 ([Figure 7-13](#)).

The defective power supply will have at least one indicator light not lit.

2. Remove the dress covers. See "[Removing the Dress Covers](#)" in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

 **CAUTION:**

The power supply surface may be hot.

3. Place the power switch on the defective power supply in the off position ([Figure 7-17](#)).

 **CAUTION:**

Make sure you shut off the correct power supply to avoid a loss of service.

4. Make sure the power supply status indicator is off.
If the power supply status indicator is not off repeat Step 3.
5. Loosen the two 1/4-turn fasteners that hold the power supply to the power module assembly ([Figure 7-17](#)).



NOTE:

Do not loosen the 1/4-turn fasteners which hold the power module assembly to the MAP/100.

6. Grasp the power supply external pull handle and pull the power supply from the power module assembly.
7. Place the power supply to the side.



CAUTION:

It is important that the defective power supply be returned to the remote maintenance center in the same condition as it was in the Lucent INTUITY system. If the power supply is damaged during removal, packaging, or shipping adequate failure analysis can not be conducted.

Installing a Power Supply in a Power Module Assembly Equipped with Two Power Supplies

See [“Installing a Second Power Supply”](#), above for the procedure.

Replacing the SCSI Cartridge Tape Drive

The SCSI cartridge tape drive is located in Bay 9 of the peripheral bay. The following procedures detail removal and installation of the SCSI cartridge tape drive for the MAP/100.



WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

Types of SCSI Cartridge Tape Drives

Two types of tape drives are currently used with the MAP/100:

- 525-Mbyte
- 2-Gbyte

Installation procedures are the same for either type of drive, but jumper settings are different. See [Chapter 3, "Common System Procedures"](#), for more information on the tape drives and their usage. [Figure 7-19](#) shows how to insert a 2-Gbyte tape.




Figure 7-19. SCSI Tape Drive

Removing a SCSI Cartridge Tape Drive

1. Verify that the replacement equipment is on site and appears to be in usable condition with no obvious shipping damage.
2. If the system is in service, perform the following Steps a and b.
 - a. Stop the voice system. See ["Stopping the Voice System"](#), in [Chapter 3, "Common System Procedures"](#), for voice system administration.
 - b. Shut down the voice system. See ["Shutting Down and Rebooting the Lucent Intuity System"](#), in [Chapter 3, "Common System Procedures"](#), for voice system administration.
3. Remove the incoming power. See ["Removing Power from the MAP/100"](#), in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.
4. Remove the dress covers. See ["Removing the Dress Covers"](#), in [Chapter 4, "Getting Inside the Computer"](#), for these procedures.
5. Access the peripheral bay. See ["Accessing the Peripheral Bay"](#), in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

6. Locate the cartridge tape drive power lead and bus cable assembly connections. Remove the power cord connector and bus cable assembly connections. Move them carefully to the side.
7. Locate the four screws on peripheral bay chassis that secure the drive in Position 1 of the peripheral bay. Holding the rear of the drive, loosen and remove these mounting screws.
8. Slide the drive forward within the peripheral bay and remove through the front opening of the chassis.



CAUTION:

The drive fits tightly in the peripheral bay. Do not to scrape wiring or components on the underside of the drive against the Position 2 diskette drive plastic faceplate.

Verifying Jumper Settings

The manufacturer sets the jumpers on both tape drives. However, before installing the drive, verify that these settings are correct. See [Figure 7-20](#) for jumper settings on the 540-Mbyte tape drive and [Figure 7-21](#) for jumper settings on the 2-Gbyte tape drive.




Figure 7-20. Jumper Settings for the 525-Mbyte SCSI Cartridge Tape Drive, SCSI ID = 3




Figure 7-21. Jumper Settings for the 2-Gbyte SCSI Cartridge Tape Drive, SCSI ID = 3

Installing a SCSI Cartridge Tape Drive

1. Remove the new cartridge tape unit from its ESD-protective wrapping.



NOTE:

Keep the package and all ESD-protective wrapping to return the defective unit. Re-use of the original replacement unit packaging is necessary to meet the manufacturer's warranty.

2. Place the new drive in the chassis with the printed circuit board side down.
3. Mount the new drive into the peripheral bay by sliding the unit into the Position 1 opening. Position the unit so that the mounting bracket screw holes line up with the appropriate holes in the peripheral bay.
4. Secure the drive in the peripheral bay using the four screws removed in [7](#) of the procedure ["Removing a SCSI Cartridge Tape Drive"](#).
5. Attach the SCSI bus cable assembly. Ensure that the red bus cable tracer is connected to Pin 1 on the SCSI controller card.
6. Close the peripheral bay. See ["Closing the Peripheral Bay"](#), in [Chapter 4, "Getting Inside the Computer"](#), for these procedures.
7. Replace the dress covers. See ["Replacing the Dress Covers"](#), in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.
8. Replace the right front door. See ["Replacing the Front Doors"](#), in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.
9. Apply power to the MAP/100. See ["Restoring Power to the MAP/100"](#), in [Chapter 4, "Getting Inside the Computer"](#), for this procedure.

Replacing the 25-Slot Backplane

The following procedures detail removing and installing the 25-slot backplane, to which all of the circuit cards and peripheral device connections are made. The backplane (Figure 7-22) is located in the MAP/100 circuit card cage.




Figure 7-22. 25-Slot Backplane LED Indicators and Cabling

Removing the 25-Slot Backplane

⚠ WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

To remove the 25-slot backplane, do the following:

1. Verify that the replacement equipment is on site and appears to be in usable condition with no obvious shipping damage.
2. If the system is in service, perform the following Steps a and b.
 - a. Stop the voice system. See [“Stopping the Voice System”](#), in [Chapter 3, “Common System Procedures”](#), for voice system administration.
 - b. Shut down the voice system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for voice system administration.
3. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
4. Remove the dress covers. See [“Removing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for these procedures.
5. Access the circuit card cage. See [“Accessing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
6. Disconnect the upper and lower serial cables, located behind the backplane near the power distribution board, from the rear backplane interface pin fields.
7. Disconnect the keyboard cable from the PCI portion of the backplane (pin field J138).
8. Disconnect the CPU reset cable from the PCI portion of the backplane, pin field J135.
9. Disconnect the SCSI activity cable from the backplane, pin field J129, red lead facing the faceplate.
10. Pull the following cables through the top of the rear panel access hole:
 - Serial
 - Diskette
 - SCSI
11. Disconnect the following cables located in the card cage area:
 - Fan Detection
 - Power Supply Voltage Sensing
 - CPU Reset
12. Disconnect the following cable assemblies from the CPU circuit card:
 - COM2 serial port to J7 CPU pin field
 - Keyboard to J1 CPU pin field
 - Disk Activity to JP15 CPU pin field, red lead away from the faceplate

7 Replacing Other Components

Replacing the 25-Slot Backplane

Page 7-48

- PS/2 Mouse I/O interface between the J4 CPU pin header and the external SCSI/PS/2 Mouse I/O interface board, JP1 CPU pin field
 - Diskette to J6 CPU pin field
 - SCSI controller to J2 CPU
13. Remove the circuit cards. See [“Removing a Circuit Card”](#), in [Chapter 5](#), [“Replacing or Installing Circuit Cards”](#), for the procedure.
 14. Remove the 16 backplane mounting screws.
 15. Remove the backplane from the power distribution board connectors.

Installing the 25-Slot Backplane



WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4](#), [“Getting Inside the Computer”](#).

To install the 25-slot backplane, do the following:

1. Place the 25-slot backplane in the MAP/100.
2. Partially install two mounting screws in opposite ends of the backplane corners.
3. Press the backplane firmly into the power distribution board connectors.
4. Install the remaining 14 backplane mounting screws and tighten enough to secure the hardware.
5. Pull the peripheral bay forward to gain access into the interior cabling area. See [“Accessing the Peripheral Bay”](#), for the procedure.
6. Redress the fan detection cable assembly by refolding the cable down into the center back panel access hole.
7. Mount the two screws into the power distribution board.
8. Connect the upper and lower serial cables, located behind the backplane near the power distribution board, to the rear backplane interface pin fields.
9. Connect the keyboard cable to the PCI portion of the backplane (pin field J138).
10. Connect the CPU reset cable to the PCI portion of the backplane, pin field J135.
11. Connect the SCSI activity cable to the backplane, pin field J129, red lead facing the faceplate.

12. Pull the following cables through the top of the rear panel access hole:
 - Serial
 - Diskette
 - SCSI
13. Install the remote maintenance circuit card in slot 19. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
14. Connect the following cables located in the card cage area:
 - Fan Detection
 - Power Supply Voltage Sensing
 - CPU Reset
15. Install the video circuit card in slot 20. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
16. Install the external SCSI connector card in slot 22. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
17. Install the CPU circuit card in slot-21. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
18. Connect the following cable assemblies to the CPU circuit card, while observing pin 1:
 - COM2 serial port to J7 CPU pin field
 - Keyboard to J1 CPU pin field
 - Disk Activity to JP15 CPU pin field, red lead away from the faceplate
 - PS/2 Mouse I/O interface between the J4 CPU pin header and the external SCSI/PS/2 Mouse I/O interface board, JP1 CPU pin field
 - Diskette to J6 CPU pin field
 - SCSI controller to J2 CPU



NOTE:

The keyboard, serial, diskette, and SCSI cable assemblies, when properly routed and connected to the CPU circuit card, should appear neat and properly folded.

19. Install the remaining circuit cards. See [“Installing a Circuit Card”](#), in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.
20. Mount the top cover.
21. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.

22. Perform a soft reboot to ensure that the keyboard and CPU circuit card are properly connected. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
If a problem occurs, verify that the video and CPU circuit cards are properly seated into the 25-slot backplane.
23. Verify that all cable connections are secure.
24. Remove power from the MAP/100. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
25. Close the peripheral bay. See [“Closing the Peripheral Bay”](#), in [Chapter 4, “Getting Inside the Computer”](#), for these procedures.
26. Close the circuit card cage. See [“Closing the Circuit Card Cage”](#), in [Chapter 4, “Getting Inside the Computer”](#), for these procedures.
27. Replace the dress covers. See [“Replacing the Dress Covers”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
28. Replace the right front door. See [“Replacing the Front Doors”](#), in [Chapter 4, “Getting Inside the Computer”](#), for the procedure.
29. Apply power to the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.

Replacing a Terminator SIP

If the circuit card is the last circuit card connected to either end of the TDM bus, you must ensure that the TDM bus terminator single in-line packages (SIPs) are in place on the circuit card. If the circuit card is not the last circuit card on the bus, you must remove the SIPs.

NOTE:

“Last circuit card connected” means that there are no other cards between the circuit card and the end of the bus. There may, however, be empty connectors.

To replace a terminator SIP, complete the following:

1. Align the terminator SIP with the SIP socket on the circuit card ([Figure 7-23](#)).

There are markings on both the terminator SIP and the circuit card which should be used to align the terminator SIP.

2. Insert the terminator SIP.




Figure 7-23. Replacing Terminator SIPs on the TDM Bus

Installing the Tip/Ring Distribution Hardware

8

Overview

This chapter describes the two types of Tip/Ring distribution hardware and the installation procedures for both.

Purpose

The purpose of this chapter is to provide the correct installation and connection procedures for the Tip/Ring distribution hardware.

Function

As the number of lines served by the Lucent™ INTUITY™ system increases, the number of 6-pin modular cords also increases. These 6-pin modular cords connect the system with the customer-premises equipment or the on-premises terminal block provided by the central office.

Optional Tip/Ring (T/R) distribution hardware is available to help simplify the wiring scheme.

Capacity

The T/R distribution hardware allows you to connect to a maximum of 64 channels (eleven T/R circuit cards) through four 25-pair, high-density cables (RJ21X).

Types of Tip/Ring Distribution Hardware

There are two types of Tip/Ring distribution hardware:

- Distribution hardware with a 356B adapter
- Distribution panel without a 356B adapter

Tip/Ring Distribution Hardware with a 356B Adapter

The Tip/Ring distribution hardware with the 356B adapter ([Figure 8-1](#)) comes in a kit which consists of:


- A 356B adapter
- An adapter bracket
- A mounting plate
- A 25-pair, high-density cable for the first 24 channels

 **NOTE:**

An additional 25-pair, high-density cable is required for the second 24 channels to be supported by the distribution panel. Therefore, if you are connecting 48 channels, you will need another cable that is not part of this kit.

 **NOTE:**

Two kits will have to be purchased to accommodate all 64 channels.



- SIDE VIEW -




Figure 8-1. Assembly of the MAP/100 Tip/Ring Distribution Hardware

Tip/Ring Distribution Hardware without a 356B Adapter


The Tip/Ring distribution hardware without the 356B adapter ([Figure 8-2](#)) comes in a kit which consists of:

- A distribution panel with a circuit pack assembly mounted in its base
- A top cover plate
- A 25-pair, high-density cable for the first 24 channels



NOTE:

An additional 25-pair, high-density cable is required for the second 24 channels to be supported by the distribution panel. Therefore, if you are connecting 48 channels, you will need another cable that is not part of this kit.



40dstp1 LJK 010995

Figure 8-2. MAP/100 Tip/Ring Distribution Panel Assembly

If you want to support 64 channels a second kit must be purchased ([Figure 8-3](#)). The second kit contains:

- A 25-ft. 50-conductor interface cable
- A T/R distribution panel that is mounted onto a larger cover



NOTE:

If you are installing a second T/R distribution panel, you will use this larger cover and discard the original, smaller cover. See [“Installing and Connecting the Tip/Ring Distribution Hardware without the 356B Adapter”](#), below for the procedure.




Figure 8-3. MAP/100 Tip/Ring Distribution Panel Assembly Mounted inside a Larger Cover

Installing and Connecting the Tip/Ring Distribution Hardware with the 356B Adapter

WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

Installing the Tip/Ring Distribution Hardware with the 356B Adapter

1. Verify that the distribution hardware is on site and appears to be in usable condition.
2. If the system is currently connected to the telephone network, notify the service provider that the system is about to be disconnected. The service provider will ask which extensions will be affected.
3. If the system is in service, perform Steps a and b:
 - a. Stop the voice system. See [“Administering Voice Messaging”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
 - b. Shut down the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#) in [Chapter 3, “Common System Procedures”](#), for this procedure.
4. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
5. Verify that all of the necessary components are included. See [“Tip/Ring Distribution Hardware with a 356B Adapter”](#), above for the components.
6. Install the distribution mounting plate on the back of the MAP/100 ([Figure 8-4](#)).

8 Installing the Tip/Ring Distribution Hardware

Installing and Connecting the Tip/Ring Distribution Hardware with the 356B




Figure 8-4. Tip/Ring Distribution Hardware after Assembly

8 Installing the Tip/Ring Distribution Hardware

Installing and Connecting the Tip/Ring Distribution Hardware with the 356B

Page 8-9

7. Install the u-shaped adapter brackets with the screws provided. Attach the brackets to the mounting plate.

The u-shape of the bracket should face out with the grounding lug towards the MAP/100 surface ([Figure 8-4](#)).

8. Plug the 3-foot, 6-pin modular cords from the T/R cards into the 356B adapters. Each adapter can accommodate eight modular cords ([Figure 8-1](#)).
9. Using the connector provided, attach the 25-pair, high-density cable to the 356B adapter.
10. Snap the 356B adapters into the adapter bracket. Ensure the modular cords are inside the adapter bracket.



NOTE:

The 356B adapters can be removed by spreading the bracket sides apart.



CAUTION:

The 25-pair, high-density cables should come from the top of the adapter brackets.

11. Connect the grounding wire and strap to the top of the adapter bracket.

Connecting the Tip/Ring Distribution Hardware with the 356B Adapter

The numbering scheme for pinouts and channels which shows how to connect the short modular cords provided with the T/R cards to the distribution hardware is shown in [Chapter 5, "Replacing or Installing Circuit Cards"](#).

1. Referring to those tables and using the channel numbers on the T/R cards and the number of the T/R circuit cards in the system, connect the T/R card modular jacks to the appropriate jacks on the 356B connectors.

Installing and Connecting the Tip/Ring Distribution Hardware without the 356B Adapter

WARNING:

Observe proper electrostatic discharge precautions when you handle computer components. Wear an antistatic wrist strap that touches your bare skin and connect the strap cable to an earth ground. See [“Protecting against Damage from Electrostatic Discharge”](#), in [Chapter 4, “Getting Inside the Computer”](#).

Installing the Tip/Ring Distribution Hardware without the 356B Adapter

1. Verify that the distribution hardware is on site and appears to be in usable condition.
2. If the system is currently connected to the telephone network, notify the service provider that the system is about to be disconnected. The service provider will ask which extensions will be affected.
3. If the system is in service, perform Steps a and b:
 - a. Stop the voice system. See [“Administering Voice Messaging”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
 - b. Shut down the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#) in [Chapter 3, “Common System Procedures”](#), for this procedure.
4. Remove the incoming power. See [“Removing Power from the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for this procedure.
5. Verify that all of the necessary components are included. See [“Tip/Ring Distribution Hardware without a 356B Adapter”](#), above for the components.
6. If you are installing a second T/R distribution panel, verify that the second distribution panel assembly kit is on site and appears to be in usable condition.
7. Remove the seven screws that secure the distribution panel cover. This cover is located in the center of the rear of the MAP/100 and extends approximately 1-1/2 in. out from the chassis ([Figure 8-5](#)).




Figure 8-5. Where to Attach the Tip/Ring Distribution Panel

8. Put the distribution panel cover aside.
9. Position the distribution panel (or the first of the two distribution panels if you are installing two) so that the two 50-pin connectors point toward the floor and the modular jacks face away from the cabinet.
10. Align the mounting holes in the distribution panel with the threaded stand-offs on the cabinet.
11. Fasten the distribution panel to the cabinet using the five 6-32X.25-in. screws and lockwashers provided.
12. [Table 8-1](#) shows the numbering scheme for connecting the short modular cords provided with the T/R boards to the panel. Use this information, the channel numbers on the T/R circuit cards, and the number of T/R circuit cards in the system to connect the T/R circuit card modular jacks to the appropriate jacks on the T/R distribution panel.



NOTE:

You can connect a maximum of eight T/R circuit cards to each distribution panel.

8 Installing the Tip/Ring Distribution Hardware

Installing and Connecting the Tip/Ring Distribution Hardware without the 356B

Table 8-1. Connecting the Modular Cords from the MAP/100 Tip/Ring Circuit Cards to the Tip/Ring Distribution Panels

T/R Card	Channel Numbers on the T/R Card	First Distribution Panel Jack Number	Second Distribution Panel Jack Number
1st	1,2,3	J1	—
	4,5,6	J2	—
2nd	1,2,3	J3	—
	4,5,6	J4	—
3rd	1,2,3	J5	—
	4,5,6	J6	—
4th	1,2,3	J7	—
	4,5,6	J8	—
5th	1,2,3	J9	—
	4,5,6	J10	—
6th	1,2,3	J11	—
	4,5,6	J12	—
7th	1,2,3	J13	—
	4,5,6	J14	—
8th	1,2,3	J15	—
	4,5,6	J16	—
9th	1,2,3	—	J1
	4,5,6	—	J2
10th	1,2,3	—	J3
	4,5,6	—	J4
11th	1,2,3	—	J5
	4,5,6	—	J6
12th	1,2,3	—	J7
	4,5,6	—	J8

13. After you insert the modular cord into the appropriate jack, remove any slack in the cable on the back of the unit by dressing it so that it is stored in the area above the distribution panel.

Use cable ties, if necessary, to dress the cables neatly and tie them to the vertical cable-support bracket in the center of the unit.

14. Make telephone line connections to the MAP/100 with the 25-ft 50-conductor shielded cable(s) equipped with USOC RJ21X connections.
15. If you are installing only one T/R distribution panel, reinstall the panel cover to complete this procedure.

If you are installing a second T/R distribution panel, repeat Steps 12 through 14 above for the second panel and then continue with Step 16.

16. Mount the second panel and cover onto the MAP/100 chassis. You need only two screws on each side of the panel to secure it instead of the seven you originally removed.

Completing the Installation

To complete the installation and put the system back in service, do the following:

1. Power up the MAP/100. See [“Restoring Power to the MAP/100”](#), in [Chapter 4, “Getting Inside the Computer”](#), for more information on restoring power to the unit.
2. Reboot the system. See [“Shutting Down and Rebooting the Lucent Intuity System”](#), in [Chapter 3, “Common System Procedures”](#), for the procedure.
3. Run diagnostics to verify the hardware is functioning properly. See [““Tip/Ring Circuit Card Diagnostics”](#),” in [Chapter 2, “Diagnostics”](#), for more information on running the diagnostics.
4. Notify the service provider that the system is back on-line, if necessary.

Installing Base System Software

9

Overview

This chapter describes:

- Installation procedures for the Unixware software
- Installation procedures for the AUDIX® software

Purpose

This purpose of this chapter is to provide the information necessary to reload the operating system to a computer which has experienced a disk failure. This chapter should be used in conjunction with [Appendix D, "Disaster Recovery Checklists".](#)



NOTE:

The installer must have the root password to complete this procedure.

Installing UnixWare

Installing the UnixWare operating system unmounts file systems. The maintenance module in the Lucent™ INTUITY™ software has been designed to detect unmounted file systems and attempt to recover them. If the MTCE module does not detect any unmounted file systems, all of the software will load.

If this software is being loaded onto a system that has clean hard disks that have not been previously loaded, the system will not detect file systems.

If this is a recovery installation, the system will detect previously loaded file systems.

CAUTION:

*If you use the **DELETE** key to stop the UnixWare installation at any time during this process, you will have to restart the software installation process at Step 1.*

Preparing the System

To prepare the system, do the following:

1. Verify the CMOS settings. See “[P5 120 MHz CPU Circuit Card](#)” in [Chapter 5, “Replacing or Installing Circuit Cards”](#).”
2. Verify the SCSI adapter settings. See “[P5 120 MHz CPU Circuit Card](#)” in [Chapter 5, “Replacing or Installing Circuit Cards”](#).”
3. Low level format Hard Disk Drive 0. See “[Performing a Low-Level Format](#)” in [Chapter 6, “Replacing the Hard Disk Drive”](#).”
4. Continue with the next procedure, “[Starting the Unixware Installation](#).”

Starting the Unixware Installation

To start the Unixware installation, do the following:

1. Insert the diskette labeled “Lucent INTUITY UNIX Boot Floppy 1 of 3” into the floppy disk drive.
2. If the system is off, turn it on using the power switch on the front of the MAP/100 ([Figure 9-1](#)).

If the system is on, reboot the system. See “[Rebooting the System](#)” in [Chapter 3, “Common System Procedures”](#), for the procedure.




Figure 9-1. Front View of the MAP/100

The system displays the UnixWare introduction screen as it begins to load the base system software. When the system is done with the first boot floppy it displays the following message:

```
Remove the diskette labeled 'Boot Floppy 1 of 3'.
```

```
If you have a diskette labeled 'Host Bus Adapter Drivers', insert that diskette now.
```

```
For more information on Host Bus Adapter diskettes, see the UnixWare Installation Handbook.
```

```
Otherwise, if you do not have (or do not need to use) a Host Bus Adapter diskette, insert the diskette labeled 'Boot Floppy 2 of 3' now.
```

```
Press 'ENTER' to continue.
```

3. Remove Lucent INTUITY UNIX Boot Floppy 1 of 3 from the floppy disk drive.
4. Continue with the next procedure, "[Loading the Host Bus Adapter.](#)"

Loading the Host Bus Adapter

To load the host bus adapter, do the following:

1. Insert the diskette labeled "Pentium HBA Floppy" into the floppy disk drive.
2. Press **ENTER**.

The system displays the following message:

```
The Host Bus Adapter driver(s) on the Host Bus Adapter
diskette have been loaded and you can now remove the
diskette.
```

If you have another Host Bus Adapter diskette (for different adapters) insert that disk now.

For more information, see the UnixWare Installation Handbook.

Otherwise, if you do not have (or do not need to use) another Host Bus Adapter diskette, insert the diskette labeled 'Boot Floppy 2 of 3' now.

3. Remove the diskette labeled "Pentium HBA Floppy" from the floppy disk drive.
4. Continue with the next procedure, "[Continuing the UnixWare Installation](#)."

Continuing the UnixWare Installation

To continue the UnixWare installation, do the following:

1. Insert the diskette labeled "Unixware for INTUITY Boot Floppy 2 of 3" into the floppy disk drive.
2. Press **ENTER**.

The system displays the Introduction screen ([Figure 9-2](#)).

NOTE:

If the system displays a message that the system must have at least 60 MBytes of space in the hard disk drive to install UNIX, the hard disk drive is experiencing problems. The cable may not be connected, or the hard disk drive may be damaged. Power down the system and check the hard disk drive cables. See "[Removing Power from the MAP/100](#)" in [Chapter 4, "Getting Inside the Computer"](#), for the procedure.

Unixware Installation

Introduction

Welcome to the UnixWare installation process!

If you have never installed UnixWare before, it is recommended that you press the 'F1' (or '?') key now to learn more about the installation process and the hardware requirements of UnixWare.

-Pressing the 'F1' (or '?') key at any time during installation will display more information or help.

-Pressing the 'Del' key at any time cancels the installation.

Press the 'F1' (or '?') key for more information or 'ENTER' to

Figure 9-2. Introduction Screen

3. Press **ENTER**.

If Disk 0 has been replaced with a new hard disk drive, the system displays the UnixWare Installation Files Deleted Warning screen ([Figure 9-3](#)).

If the system does not display the UnixWare Installation Files Deleted Warning, continue with the next procedure, "[Setting Up the Keyboard](#)."

WARNING: Files have been detected in the active partition(s) of your hard disk(s).

In order to install the operating system, you must have an active UNIX partition occupying 100% of your hard disk. No other partitions may share the disk.

You have the option of removing the existing partitions at this point and creating a new UNIX partition. You should only remove the existing partitions if you don't want to save any files on your disk.

If you elect to abort the installation, the existing partitions will not be removed and installation will be halted.

1. Destroy existing partitions and create a new UNIX partition.
2. Abort the installation, leaving existing partitions untouched.

Type '1' or '2' followed by 'ENTER':1

Figure 9-3. UnixWare Installation Files Deleted Warning Screen

Setting Up the Keyboard

To setup the keyboard, do the following:

1. Starting at the UnixWare Installation Files Deleted Warning screen ([Figure 9-3](#)), press **ENTER**.

The system displays the Keyboard Setup screen ([Figure 9-4](#)).




Figure 9-4. Keyboard Setup Screen

2. Use the left and right arrows on your keyboard to move through the field selections.
3. Select U.S. ASCII.
4. Press the down arrow to move to the `Apply` field and press .
5. Continue with the next procedure, "[Configuring the System Date and Time](#)."

Unixware Installation Configure Date and Time
On this screen, you will check the current date and time that is set on your computer and change them if necessary. You also select what timezone configuration you require. Either set a continent(s) which will lead you onto a further screen with locations or manual entry for a custom timezone.

The current date:
The current Time:
Enter the current year:
Enter the month of the year:
Enter the day of the month:
Enter the hour of the day:
Enter the minute of the hour:
Timezone configuration:

Apply

Reset

Press 'TAB' to move the cursor between fields. When finished, move the cursor to 'APPLY' and then press 'ENTER' to continue.

Figure 9-5. Configure Date and Time Screen

Configuring the System Date and Time

To configure the system date and time, do the following:

1. Starting at the Configure Date and Time screen ([Figure 9-5](#)), use the left  and right  arrows on your keyboard to move through the field selections. Use the down  arrow to move to the next field.
2. Select the appropriate data for each field.
3. Press the down  arrow to move to the Apply field and press .
The system displays the Continent Location Choice screen ([Figure 9-6](#)).
4. Continue with the next procedure, "[Choosing the Continent Location](#)."

Unixware Installation

Primary Hard Disk Partitioning

In order to install UnixWare, you must reserve a partition (a portion of your hard disk's space) on your primary hard disk for the UNIX System. After you press 'ENTER' you will be shown a screen that will allow you to create new partitions, delete existing partitions or change the active partition of your primary hard disk (the partition that your computer will boot from).

WARNING: All files in any partition(s) you delete will be destroyed. If you wish to attempt to preserve any files from an existing UNIX System, do not delete its partition(s).

The UNIX System partition that you intend to use on the primary hard disk must be at least 120 MBs and labeled 'ACTIVE.'

Figure 9-7. Primary Hard Disk Partitioning Screen

Partitioning Hard Disk Drive 0

To partition Hard Disk Drive 0, do the following:

1. Starting at the Primary Hard Disk Partitioning screen ([Figure 9-7](#)), press **ENTER**.

The system displays the Partition Creation screen ([Figure 9-8](#)).

```
Unixware Installation                Hard Disk Partitioning - Disk 1

Total disk size is 2063 cylinders (2063.0MB)


```

Partition	Status	Type	Start	End	Length	%	Approx MB

```


1. Overwrite system master boot code
2. Delete a partition
3. Exit (Update disk configuration and exit)
4. Cancel (Exit without updating disk configuration)

Enter Selection
```

Figure 9-8. Partition Creation Screen

2. Enter 2

The system displays the Partition Configuration screen ([Figure 9-9](#)).

Partition Type -
Percentage of disk -

Apply

Reset

Press 'TAB' to move the cursor between fields. When finished, move the cursor to 'APPLY' and then press 'ENTER' to continue.

Figure 9-9. Partition Configuration Screen

3. Use the left  and right  arrows on your keyboard to move through the field selections.
4. Select UNIX system for the Partition Type field.
5. Select 100 for the Percentage of disk field.
6. Press the down  arrow to move to the Apply field and press .

The system displays the Partition Confirmation screen ([Figure 9-10](#)).

Total disk size is 2048 cylinders (2048.0MB)

Partition	Status	Type	Start	End	Length	%	Approx MB
1	Active	UNIX System	0	2047	2048	100	2048.0

1. Overwrite system master code
2. Delete a partition
3. Exit (Update disk configuration and exit)
4. Cancel (Exit without updating disk configuration)

Figure 9-10. Partition Confirmation Screen

7. Enter **3**

The system displays the Secondary Hard Drive Partitioning screen ([Figure 9-11](#)).

8. Continue with the next procedure, "[Partitioning Hard Disk Drive 1.](#)"

You may use a partition of your secondary hard disk. If you choose to use a partition of your secondary hard disk you will be shown a screen that will allow you to partition your secondary hard disk.

WARNING: All files in any partition(s) you delete will be destroyed.

If you choose to create a UNIX System partition on your secondary hard disk, it must be at least 40 MBs.

Your Options are:

1. Do not use a partition of the secondary hard disk for the UNIX System.
2. Use a partition of the secondary hard disk for the UNIX System.

Figure 9-11. Secondary Hard Disk Partitioning Screen

Partitioning Hard Disk Drive 1

NOTE:

This screen will not appear if you do not have a second hard disk drive. Continue with the next procedure, "[Choosing the Installation Type.](#)"

To partition Hard Disk Drive 1, do the following:

1. Starting at the Secondary Hard Disk Partitioning screen ([Figure 9-11](#)), select "1".
2. Press .
- The system displays the Installation Type Selection screen ([Figure 9-12](#)).
3. Continue with the next procedure, "[Choosing the Installation Type.](#)"

Unix System Installation Installation Type Selection

You must choose a system type. The system type you choose will determine the default file system sizes you will specify on the next screen.

Press the 'F1' or '?' key to see more information about these different system types.

Platform Type: MAP/100
CPU Type: Pentium
Offer Type: INTUITY AUDIX

Apply

Reset

Press 'TAB' to move between fields. Press 'ENTER' to apply fields.

Figure 9-12. Installation Type Selection Screen

Choosing the Installation Type

To choose the installation type, do the following:

1. Starting at the Installation Type Selection screen ([Figure 9-12](#)), use the left  and right  arrows on your keyboard to move through the field selections. Use the down  arrow to move to the next field.
2. Select MAP/100 for the Platform Type field.
3. Select Pentium for the CPU Type field.
4. Select INTUITY AUDIX for the Offer Type field.
5. Press the down  arrow to move to the Apply field.
6. Press .

The system displays the UnixWare Installation Set Slice Sizes screen ([Figure 9-13](#)).

7. Continue with the next procedure, "[Setting the Slice Sizes](#)."




Figure 9-13. UnixWare Installation Set Slice Sizes Screen

Setting the Slice Sizes

To set the slice sizes, do the following:

1. Starting at the UnixWare Installation Set Slice Sizes screen ([Figure 9-13](#)), use the left and right arrows on your keyboard to move through the field selections. Use the down arrow to move to the next field.
2. Enter the appropriate number of megabytes of space needed for each slice as specified in [Table 9-1](#).

Table 9-1. Space Requirements for the MAP/100

Slice	Space Requirements (MBytes)
/stand	10
/dev/dump	65
/dev/swap	129
/	200

3. Press the down arrow to move to the Apply field.

4. Press **ENTER**.

The system displays the Hard Disk Surface Analysis screen ([Figure 9-14](#)).

5. Continue with the next procedure, "[Performing a Hard Disk Drive Surface Analysis](#)."

```
UNIX System Installation                               Hard Disk Surface Analysis
```

```
Surface analysis is recommended but not required.  Here you must
choose to skip or perform surface analysis.
```

```
Press the 'F1' or '?' key to see more information about these
different system types.
```

```
You choices are:
```

- ```
1. Perform surface analysis
2. Skip surface analysis
```

```
Press '1' or '2' followed by 'ENTER':1
```

**Figure 9-14. Hard Disk Surface Analysis Screen**

## Performing a Hard Disk Drive Surface Analysis

### **CAUTION:**

*Surface analysis is required for all systems because it makes a configuration change to the disk. Failure to perform surface analysis may cause the Lucent INTUITY system to fail.*

To perform a hard disk drive surface analysis, do the following:

1. Starting at the Hard Disk Surface Analysis screen ([Figure 9-14](#)), press **ENTER**.

This will accept the default of 1 and perform the surface analysis. The system displays the following message:

```
Checking the hard disk for defects and creating file
systems. This will take a few minutes. Please wait.
```

The system displays the UnixWare Installation screen ([Figure 9-15](#)).

UnixWare Installation Exchange Diskette

Remove the diskette from the drive and insert the diskette labeled  
"Boot Floppy 3 of 3".

Press 'Enter' to continue

**Figure 9-15. Hard Disk Surface Analysis Screen**

- Remove boot floppy 3 of 3 from the drive now.
2. Remove the Lucent INTUITY UNIX Boot Floppy 2 of 3 from the floppy disk drive.
  3. Continue with the next procedure, "[Copying the Unix System Files.](#)"

## Copying the Unix System Files

To copy the Unix system files, do the following:

1. Insert the diskette labeled "Lucent INTUITY UNIX Boot Floppy 3 of 3" into the floppy disk drive.
2. Press **ENTER**.

The system displays the following message:

Copying Unix System files from the diskette onto you hard drive. This will take a few minutes. Please wait.

The system then displays the following message:

Making file systems on your hard disk. This will take a few minutes. Please wait

The system displays the Remove Diskette screen ([Figure 9-16](#)).

UnixWare Installation

Remove Diskette 3

Remove boot floppy 3 of 3 from the drive now.

Press 'Enter' to continue.

**Figure 9-16. Remove Diskette Screen**

3. Remove the "Lucent INTUITY UNIX Boot Floppy 3 of 3" from the floppy disk drive.
4. Press **ENTER**.  
The system displays the Application Server Media Type screen ([Figure 9-17](#)).
5. Continue with the next procedure, "[Loading the Application Server Software](#)."

UnixWare Installation Application Server Media Type

The Application Server software is available on diskette or tape or network server. You must select the source you will use to install the software.

Your choices are:

1. Diskette Drive 1
2. Cartridge Tape Drive
3. Network Install Server
4. INTUITY Image/Snap Tape

Press a number between '1' and '4'  
followed by 'ENTER':

Figure 9-17. Application Server Media Type Screen

## Loading the Application Server Software

To load the application server software, do the following:

1. Insert the cartridge tape labeled "Lucent INTUITY R4.0 UnixWare Image Tape" into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
2. Enter **4**

The system displays the Insert Lucent INTUITY Tape screen ([Figure 9-18](#)).

```
UnixWare Installation Insert Intuity Image Tape

Please insert the INTUITY Image cartridge tape into the tape drive
and press 'ENTER'.

Your choices are:

1. The tape has been inserted in the tape drive.
2. Go back to previous menu.
```

Figure 9-18. Insert Lucent INTUITY Tape Screen

3. Press **(ENTER)**.

This will accept the default of 1 to indicate the tape has been inserted and is ready for access.

The system displays the following message:

```
Installation in progress. This will take several
minutes. Please do not remove the tape.
```

The system displays a series of informational messages.

When all files are loaded, the system displays the following message:

```
The system is ready.
```

```
The system's name is Lucent Intuity.
```

```
Welcome to USL UnixWare System V Release 4.2 Version 1
Console Login:
```

**⇒ NOTE:**

Ignore the following message, if it is displayed:

```
Error: IRQ chosen for driver does not match adapter
configuration XXXXXX Equinox Megaport STREAMS
Device Driver.
```

4. Remove the cartridge tape labeled "Lucent INTUITY UnixWare Image" from the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
5. Continue with the next procedure, "[Running installit.](#)"

## Installing the INTUNIX+e Software

To install the INTUNIX+e software, do the following:

1. Verify that the floppy disk drive is empty.



### CAUTION:

*If the floppy disk drive contains a diskette, the system reboot will fail. If this happens, remove the floppy from the floppy disk drive and press **Ctrl-Alt-Del**.*



### NOTE:

If you are installing the operating system onto a machine that is not equipped with a LAN circuit card, the system may display a message that states that an invalid check sum occurred. Ignore this message.

2. Log in to the system as root.
3. Press **ENTER** at the password prompt.



### NOTE:

If the current password has expired, enter **Intuity1** for the password. Use this password instead of pressing **ENTER** for the remainder of the procedure. As soon as the Lucent INTUITY system tape is reloaded, you will change this password.

The system displays with the UNIX prompt (#).

4. Enter **pkgadd -d ctape1**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

5. Insert the Lucent INTUITY INTUNIX+e cartridge tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.

6. Press **(ENTER)**.

The system displays the following message:

The following sets are available:

1. INTUNIX+e INTUITY UnixWare 1.1.2 Enhancement Set  
- Update E  
(i486)

Select package(s) you wish to process (or 'all' to process all packages). (default: all) [?,??,q]:

7. Press **(ENTER)**.

The system displays the following message:

The following packages are available:

1. ezsetup SMC LAN Adapter Setup Program
2. smcUW11 SMC Ethernet Device Driver ISA
3. audfs AUDIX File System
4. rpcfix
5. year2000

Select package(s) you wish to process (or 'all' to process all packages). (default: all) [?,??,q]:

8. Press **(ENTER)**.

The system displays a series of messages and then the following message:

A version of the LAN driver is already installed.  
Do you want to overlay that driver and re-use the kernel options for the driver? The overlay option, which is often used during field upgrades, will preserve the network environment.

y) to overlay

q) to quit (default: quit)

Do you want to overlay the driver:

9. Enter **y**

The system displays the following message:

The board currently installed in the system is the 8416 LAN adapter.

1) 8216 LAN adapter

2) 8416 LAN adapter

q) to abort installation

Please enter the board type you wish to use:

10. Enter **2**



**NOTE:**

Ignore any warning messages displayed by the system.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
 or [q] to quit: (default: go)
```

11. Enter **q**
12. Remove the Lucent INTUITY INTUNIX+e cartridge tape from the tape drive. See [“Inserting and Removing Cartridge Tapes”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
13. If your system is using a LAN circuit card, configure the LAN circuit card. See [“Configuring the LAN Circuit Card”](#) in [Chapter 5, “Replacing or Installing Circuit Cards”](#), for the procedure.

## Running *installit*

---

To run *installit*, do the following:

1. Enter **installit**



**CAUTION:**

*Make sure the **installit** command and the associated reboots have been completed prior to continuing with any other procedure.*

The system displays the following message:

```
Installit execution started: <date>

The system will attempt to perform a new installation

Press <ENTER> to continue the Volume Manager
installation
```

2. Press **(ENTER)**.

The system is rebooted and then displays the following message:

```
The UNIX Operating system kernel will be rebuilt now.

The system must now be rebooted to continue the
reconfiguration

Hit RETURN to continue.
```

3. Press **(ENTER)**.

The system is rebooted and then displays the following message:

```
The system must now be rebooted.
```

```
Hit RETURN to continue.
```

4. Press **(ENTER)**.

The system is rebooted and then displays the following message:

```
Console Login:
```

5. Continue with the next procedure, "[Installing the Platform Software](#)."

## Installing the Platform Software

---

To install the platform software, do the following:

1. Log in to the system as root.
2. Enter **pkgadd -d ctape1**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
```

```
Type [go] when ready
```

```
or [q] to quit: (default: go)
```

3. Insert the Lucent INTUITY Platform AUDIX Set cartridge tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
4. Press **(ENTER)**.



### NOTE:

Ignore any messages which indicate that the base ORACLE package has not been loaded and gives installation procedures.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

```
The following sets are available:
```

```
1 AUDIXset INTUITY Platform AUDIX Set
 (;486)
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

5. Press **ENTER**.

The system displays the following message:

```
Processing:
```

```
Set: Lucent Intuity Platform AUDIX Set (AUDIXset) from
<ctapel>.
```

```
Lucent Intuity Platform AUDIX Set
(i486)
```

```
Using </> as the package base directory.
```

```
Do you want to run default set installation? (default:
y)
```

6. Press **ENTER**.

The system displays prompts for the craft and tsc passwords.

7. Enter the passwords you want to use for these logins.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

8. Enter **q**

9. Enter **cd /**

10. Enter **shutdown -y -g0 -i6**

The system displays the following message:

```
Shutdown started. Date
```

```
INIT: New run level: 6
```

```
The UNIX Operating kernel will be rebuilt now.
This will take some time. Please wait.
```

The system responds with a series of memory check displays and copyright notices. These messages also note that the system is fine and coming up, the system is ready, and that the voice system is automatically being started.

This reboot is finished when the system displays the following message:

```
Startup of the Voice System is complete
```

11. Press **ENTER**.

## Installing the Switch Interface Software Packages

---

There are two switch interface software packages available with the Lucent INTUITY system:

- DCIU Switch Integration set
- Serial-Inband Switch Integration set
- Digital Station Interface Switch Integration set

### Installing the DCIU Switch Integration Set

To install the DCIU Switch Integration set, do the following:

1. Log in to the system as root.
2. Stop the voice system.
3. Enter **pkgadd -d ctape1**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
 or [q] to quit: (default: go)
```

4. Insert the Lucent INTUITY DCIU Switch Integration Set cartridge tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
5. Press **(ENTER)**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.

The following sets are available:
 1 DCIUset INTUITY Platform DCIU set (V2)
 (:486)
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

6. Press **(ENTER)**.

The system displays the following message:

```
Processing:

Set: INTUITY Platform DCIU set (DCIUset) from <ctape1>.

INTUITY Platform DCIU set
(i486)
Using </> as the package base directory.
```

```
Select your Intuity DCIU card type:
 1) DCIU (Eicon) card [this card has a green LED
 on the faceplate]
 2) GPSynch card
```

```
Enter 1 or 2: [1]
```

7. Press **ENTER**.

The system displays several status messages, then the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
 or [q] to quit: (default: go)
```

8. Enter **q**

9. Enter **cd /**

10. Enter **shutdown -y -g0 -i6**

The system displays the following message:

```
Shutdown started. Date
```

```
INIT: New run level: 6
```

```
The UNIX Operating kernel will be rebuilt now.
This will take some time. Please wait.
```

The system responds with a series of memory check displays and copyright notices. These messages also note that the system is fine and coming up, the system is ready, and that the voice system is automatically being started.

This reboot is finished when the system displays the following message:

```
Startup of the Voice System is complete
```

## Installing the Serial-Inband Switch Integration Set

---

To install the Serial-Inband Switch Integration set, do the following:

1. Log in to the system as root.
2. Stop the voice system. See [“Stopping the Voice System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.
3. Enter **pkgadd -d ctape1**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
 or [q] to quit: (default: go)
```

4. Insert the Lucent INTUITY Serial-Inband Switch Integration Set cartridge tape into the tape drive. See [“Inserting and Removing Cartridge Tapes”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.

5. Press **(ENTER)**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

```
The following sets are available:
```

```
1 SWINset Serial-Inband Switch Integration
 Set
 (:486)
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

6. Press **(ENTER)**.

The system displays the following message:

```
Processing:
```

```
Set: Serial-Inband Switch Integration Set (SWINset)
from <ctapel>.
```

```
Serial-Inband Switch Integration Set
(i486)
```

```
Using </> as the package base directory.
```

```
The following types of host switches are available.
They are:
```

- 1) NEC NEAX
- 2) Siemens HICOM
- 3) Ericsson MD110
- 4) Merlin Legend
- 5) DMS100
- 6) Intecom
- 7) Norstar
- 8) System 25
- 9) 5ESS
- 10) Definity Mode Code

The system displays several status messages, then the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

7. Enter **q**
8. Enter **cd /**
9. Start the voice system. See [“Starting the Voice System”](#) in [Chapter 3, “Common System Procedures”](#), for the procedure.

## Installing the Digital Station Interface Switch Integration Set

---

To install the Digital Station Interface Switch Integration set, do the following:

1. Log in to the system as root.
2. Stop the voice system.
3. Enter **pkgadd -d ctape1**

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

4. Insert the Lucent INTUITY Digital Station Interface Switch Integration Set cartridge tape into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
5. Press **(ENTER)**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

```
The following sets are available:
```

```
1 VBPCset VB-PC Switch Integration Set
 (;486)
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

6. Press **(ENTER)**.

The system displays the following message:

```
Processing:
```

```
Set: VB-PC Switch Integration Set (VBPCset) from
<ctape1>.
```

```
VB-PC Switch Integration Set
(i486)
```

```
Using </> as the package base directory.
```

```
The following types of host switches are available.
They are:
```

```
1) NORTEL MERIDIAN 1
```

The system displays several status messages, then the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

7. Enter **q**

8. Enter **cd /**
9. Enter **shutdown -y -g0 -i6**

The system displays the following message:

```
Shutdown started. Date
```

```
INIT: New run level: 6
```

```
The UNIX Operating kernel will be rebuilt now.
This will take some time. Please wait.
```

The system responds with a series of memory check displays and copyright notices. These messages also note that the system is fine and coming up, the system is ready, and that the voice system is automatically being started.

This reboot is finished when the system displays the following message:

```
Startup of the Voice System is complete
```

10. Press **ENTER**.



# Installing Lucent INTUITY System Software

# 10

---

## Overview

---

This chapter details installation procedures for the following packages:

- INTUITY AUDIX® Voice Messaging System R4.0
- Lucent™ INTUITY™ Announcement sets

## Purpose

---

This purpose of this chapter is to provide the information necessary to reload the Lucent INTUITY system to a computer which has experienced a disk failure. This chapter should be used in conjunction with [Appendix D, "Disaster Recovery Checklists"](#).

## Installing Lucent INTUITY System Software

---

[Table 10-1](#) lists the steps required to install Lucent INTUITY system software.

**Table 10-1. Installation Checklist for Installing Lucent INTUITY System Software**

| ✓ | Task                                  | Source                    |
|---|---------------------------------------|---------------------------|
|   | Install INTUITY AUDIX Voice Messaging | <a href="#">Chapter 9</a> |
|   | Stop the voice system                 | <a href="#">Chapter 3</a> |
|   | Install announcement sets             | This chapter              |
|   | Install switch integration software   | <a href="#">Chapter 9</a> |
|   | Install Intunix software              | This chapter              |
|   | Reboot the system                     | <a href="#">Chapter 3</a> |

 **NOTE:**

The voice system should be stopped to load all the packages except for the INTUITY AUDIX Voice Messaging R4.0 software.

## Installing the INTUITY AUDIX Voice Messaging System

---

The INTUITY AUDIX Voice Messaging System software includes:


- Disk mirroring
- Lucent INTUITY Message Manager (IMAPI)
- Lucent INTUITY FAX messaging
- AMIS analog networking
- Digital networking

 **NOTE:**

It is necessary to contact the remote maintenance center to have these features activated.

Use the following procedure to load the INTUITY AUDIX Voice Messaging System software.


1. Stop the voice system.
2. Start at the Lucent INTUITY Main menu ([Figure 10-1](#)).




---

Figure 10-1. Lucent INTUITY Main Menu

3. Select



The system displays the Software Install menu ([Figure 10-2](#)).



---

Figure 10-2. Software Install Menu

4. Insert the cartridge tape labeled "INTUITY AUDIX Voice Messaging System" into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.

10 Installing Lucent INTUITY System Software

Installing the Lucent INTUITY System Default Announcement Set and/or Optional

5. Select Tape drive.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
or [q] to quit: (default:go)
```

6. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

The following sets are available:

```
1 APPLset AUDIX (R) Application Set
 (AUDIX) 4.x-xx
```

```
Select package(s) you wish to process (or 'all' to
process
```

```
all packages). (default: all) [?,??,q]
```

7. Press **ENTER**.

The system displays a series of messages, then the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

8. Enter **q**

## Installing the Lucent INTUITY System Default Announcement Set and/or Optional Language Package Announcement Sets

---

Use the following procedure to install both the system default announcement set and any optional language (announcement set) packages.

### CAUTION:

*Do not install optional language announcement sets from earlier or later Lucent INTUITY releases. All optional language tapes used with the Lucent INTUITY system R4.0 should be labeled 4.0 and installed with INTUITY AUDIX R4.0.*

1. Starting at the Lucent INTUITY Main menu ([Figure 10-1](#)), select

```
> Customer/Services Administration
> System Management
> UNIX Management
>Software Install
```

The system displays the Software Install menu ([Figure 10-2](#)).

2. Insert the cartridge tape labeled "System Announcements" into the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
3. Select Tape drive.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
or [q] to quit: (default:go)
```

4. Press **(ENTER)**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

```
The following sets are available:
```

```
1 language x Language Name System Announcements
(AUDIX) R3.x
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

5. Press **(ENTER)**.

The system displays following message:

```
Processing:
(Language Name) System Announcements
(AUDIX) R3.x
Using</> as the package base directory.
Lucent Bell Laboratories
Is this to be the default language set?
(default: y) [y,n,?,q]
```

6. If you are installing the default language set, enter **y**



**NOTE:**

If you are installing an optional or secondary language set, enter **n**

The system displays the following message:

```
Installation of <optional language name> System
Announcements (VM-<optional language abbreviation>) was
successful.
```

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
 or [q] to quit: (default:go)
```

7. Enter **q**
8. Remove the cartridge tape labeled "System Announcements" from the tape drive. See "[Inserting and Removing Cartridge Tapes](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
9. Press **(F6)** (Cancel) until the system displays the Lucent INTUITY Main menu ([Figure 10-1](#)).

# Installing the Optional Feature Software

# 11

---

## Overview

This chapter provides installation procedures for the UNIX Multi-User software.

## Purpose

This purpose of this chapter is to provide the information necessary to reload the UNIX Multi-User software to a computer which has experienced a disk failure.

## Installing UNIX Multi-User Software

---

UNIX Multi-User software is used in systems that require more than two active logins at one time. This software is contained on two floppy disks.

1. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
2. Start at the Lucent™ INTUITY™ Main menu ([Figure 11-1](#)).





Figure 11-1. Lucent INTUITY Main Menu

3. Select



The system displays the Software Install menu ([Figure 11-2](#)).




Figure 11-2. Software Install Menu

4. Select Floppy drive.

The system displays the following message:

```
Insert a diskette into Floppy Drive 1.
Type [go] when ready,
 or [q] to quit: (default:go)
```

5. Insert the diskette labeled "UNIX Multi-User Package Installation Diskette 1 of 1" into the floppy drive.

6. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the diskette.
```

```
The following sets are available:
```

```
 1 multiusr Multi-user Set
 (386) 1
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

7. Press **ENTER**.

The system displays the Package Selection screen for Multi-User Software ([Figure 11-3](#)).




Figure 11-3. Package Selection Screen for Multi-User Software

8. Select **yes** for the User Upgrade.
9. Press **(ENTER)** with the cursor on Apply.

The system displays the following message:

```
READY TO PROCESS
 Set: Multi-user Set (multiusr)
 Package: User Upgrade (license)
 diskette 1 of 1
```

10. Remove the diskette labeled "UNIX Multi-User Package Installation Diskette 1 of 1" from the floppy drive.
11. Insert the diskette labeled "User Upgrade (license) diskette 1 of 1" into the drive.
12. Press **(ENTER)** to install the software.

The system displays the following message:

```
Tunable Parameter "NPROC" is currently set to 750.
Is it OK to change it to 200? (y/n)
```

13. Enter **n**

When the process is finished, the system displays the following message:

```
Installation of <Multi-user set> is completed.
```

```
 Insert a into Floppy Drive 1.
 Type [go] when ready,
 or [q] to quit: (default:go)
```

14. Enter **q**
15. Shut down and reboot the system. See "[Shutting Down and Rebooting the Lucent Intuity System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
16. Verify the Multi-User software package installation by accessing the View Installed Software window.

To access the View Installed Software window, do the following:

- a. Starting at the Lucent INTUITY Main menu ([Figure 11-1](#)), select

```
> Customer/Services Administration
```

```
>System Verification
```

```
>View Installed Software
```

The system displays the View Installed Software window ([Figure 11-4](#)).

```
View Installed Software

Displaying pkginfo (long version) for only the application
packages...

Displaying pkginfo for package Vex

 PKGINST: Vex
 NAME: Intuity Application Software Set
 CATEGORY: set
 ARCH: 486
 VERSION: 3.0-38
 PSTAMP: 3.38.0 R3.0 IP38 Tue Jul 11 10:22:32 EDT 1995
```

Figure 11-4. View Installed Software Window

- b. Verify that the UNIX Multi-User software has been installed on the system.

## Installing INTUITY Lodging Software Packages

To install the INTUITY Lodging Software packages, you must install the:

- INTUITY Lodging Software Set
- Optional Lodging Language package

### Installing INTUITY Lodging Software Set

To install the INTUITY Lodging Software set, do the following:

1. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
2. Starting at the Lucent INTUITY Main menu ([Figure 11-1](#)), select

```
> Customer/Services Administration
> System Management
> UNIX Management
>Software Install
> Tape drive
```

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready,
 or [q] to quit: (default:go)
```

3. Insert the tape labeled "INTUITY Lodging Software Set" into the tape drive.
4. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge
tape.
```

The following sets are available:

```
1 LODGING Intuity Lodging Software Set R2.0
 (586) 2.0-1
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

5. Press **ENTER**.

The system displays the following message:

```
Processing:
```

```
Set: Intuity Lodging Software Set R2.0 (LODGING) from
<ctapel>.
```

```
Intuity Lodging Software Set R2.0
(i486)
```

```
Using </> as the package base directory.
```

```
The following types of installations are available.
They are:
```

- 1 - All Lodging software with GuestWorks Server PMS interface
- 2 - All Lodging software with stand-alone PMS interface

3 - Custom - Installs one or more packages selected by the installer

Select type of installation:

- 1) Software with GuestWorks Server PMS interface
- 2) Software with stand-alone PMS interface
- 3) Custom installation

Enter Selection

6. To install all Lodging software with GuestWorks Server PMS, complete the following Steps a through d:

a. Enter **1**

The system displays the following message:

Confirm: You selected option 1. (y/n)

b. Enter **y**

The system installs the package and displays the following message:

Insert a cartridge into Tape Drive 1.

Type [go] when ready

or [q] to quit: (default: go)

c. Enter **q**

d. Remove the cartridge tape.

7. To install all Lodging software with stand-alone PMS, complete the following Steps a through d:

a. Enter **2**

The system displays the following message:

Confirm: You selected option 2. (y/n)

b. Enter **y**

The system installs the package and displays the following message:

Insert a cartridge into Tape Drive 1.

Type [go] when ready

or [q] to quit: (default: go)

c. Enter **q**

d. Remove the cartridge tape.

8. To perform a custom installation, complete the following Steps a through [h](#):

a. Enter **3**

The system displays the following message:

```
Confirm: You selected option 3. (y/n)
```

b. Enter **y**

The system displays the following message:

```
Install vlodg? (default:n)
```

c. If you want to install Lodging, enter **y**

If you do not want to install Lodging, enter **n**

The system displays the following message:

```
Install vfax? (default:n)
```

d. If you want to install fax, enter **y**

If you do not want to install fax, enter **n**

The system displays the following message:

```
Install vpms? (default:n)
```

e. If you want to install PMS, enter **y**

If you do not want to install PMS, enter **n**

 **NOTE:**

You can not install both Guest Works PMS and PMS on the same system.

The system displays the following message:

```
Install gwpm? (default:n)
```

f. If you want to install Guest Works PMS, enter **y**

If you do not want to install Guest Works PMS, enter **n**

 **NOTE:**

You can not install both Guest Works PMS and PMS on the same system.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
or [q] to quit: (default: go)
```

g. Enter **q**

h. Remove the cartridge tape.

## Installing the Optional Lodging Language Package

---

To install the optional Lodging Language package, do the following:

1. Starting at the Software Install menu ([Figure 11-2](#)), select

```
> Floppy drive
```

The system displays the following message:

```
Insert a floppy disk into the diskette drive
Type [go] when ready
 or [q] to quit: (default: go)
```

2. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the diskette.

The following sets are available:
 1 useng Intuity Lodging Language Package
 (586) 2.0-1
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

3. Press **ENTER**.

The system displays the following message:

```
Processing:

Set: Intuity Lodging Language Package (useng) from
<ctapel>.

Intuity Lodging Language Package
(i486)
Using </> as the package base directory.
```

When the process is finished, the system displays the following message:

```
Installation of <useng> is completed.

 Insert a into Floppy Drive 1.
 Type [go] when ready,
 or [q] to quit: (default:go)
```

4. Enter **q**
5. Start the voice system. See [“Starting the Voice System”](#) in [Chapter 3](#), [“Common System Procedures”](#), for the procedure.
6. The Fax for Lodging feature option must be activated. Contact your remote maintenance service center.

## Installing the Enhanced List Administration Package

---

To install the Enhanced List Administration (ELA) package, do the following:

1. Log in to the Lucent INTUITY system using `craft` or `tsc`.
2. Stop the voice system. See "[Stopping the Voice System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.
3. Starting at the Lucent INTUITY Main menu ([Figure 11-1](#)), select

```
> Customer/Services Administration
```

```
> System Management
```

```
> UNIX Management
```

```
>Software Install
```

The system displays the Software Install menu ([Figure 11-2](#)).

4. Insert the tape labeled "Enhanced-List Application" into the tape drive.
5. Select

```
> Tape drive
```

The system displays the following message:

```
Insert a diskette into Floppy Drive 1.
Type [go] when ready,
or [q] to quit: (default:go)
```

6. Press **(ENTER)**.

The system displays the following message:

```
Installation in progress. Do not remove the tape.
```

```
The following packages are available:
```

```
1 ELA Enhanced List Application Package
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?, ??, q].
```

7. Press **ENTER**.

The system installs the software and displays several status messages. When the software installation is complete, the system displays the following message:

```
Installation of Enhanced List Application Package
was successful.
```

```
Insert a tape into the Tape Drive.
```

```
Type [go] when ready
```

```
or [q] to quit: (default: go)
```

8. Remove the tape from the cartridge tape drive.
9. Enter **q**
10. Reboot the system. See "[Rebooting the System](#)" in [Chapter 3, "Common System Procedures"](#), for the procedure.

**11** Installing the Optional Feature Software  
*Installing the Enhanced List Administration Package*

*Page 11-12*

# Installing an RFU

# 12

---

## Overview

---

This chapter describes the procedures for installing an Remote Field Update (RFU) on the customers site.

## Purpose

---

The purpose of this chapter is to ensure that if the RFU needs to be loaded on site, it is done correctly.

## Installing an RFU

---

The Lucent™ INTUITY™ system uses two procedures for loading a RFU:

1. On-site installation
2. Remote download

Remote downloads of an RFU are done by your remote maintenance center. If the remote maintenance center downloads an RFU, it will not be necessary to install the RFU on-site. RFUs contain updates to the basic system software.

### ⇒ NOTE:

If Lucent INTUITY system software (operating system and base software) is being installed, see [Installing UnixWare](#), in [Chapter 9, "Installing Base System Software"](#).

### ⚠ CAUTION:


*Always verify with the remote maintenance center that the RFU is the most recent RFU available before loading.*

*The following procedures are to be used for installing an RFU to an existing system that requires a new RFU. Do not use these procedures to load an RFU to an ALT (assembled, loaded, and tested) system which already has the RFU installed. Contact the remote maintenance center with questions about RFU identity and procedures.*

## Removing an Existing RFU

---


1. Stop the voice system. See ["Stopping the Voice System"](#), in [Chapter 3, "Common System Procedures"](#), for this procedure.
2. Start at the Lucent INTUITY Main menu ([Figure 12-1](#)).



---

Figure 12-1. Lucent INTUITY Main Menu

3. Select



The system displays the Software Remove screen ([Figure 12-2](#)), which lists the software installed on the system.

```

The following packages are available:
 1 I16rfu+c Remote Field Update C for IP16
 (486) 1.0-16
 2 IVR Intuity Intro Voice Response Set
 (486) 1.0.16.1
 3 UM AUDIX(R) Module marker file
 (AUDIX) NA
 4 UM+3 AUDIX(R) Software Patches
 (AUDIX) 2.0-16
 5 UM-british British System Announcements
 (AUDIX) 2.0-14
 6 UM-dfltdb AUDIX(R) Default db
 (AUDIX) 2.0-14
 7 UM-french French-c System Announcements
 (AUDIX) 2.0-14
 8 UM-sat AUDIX(R) English Announcements
 (AUDIX) 2.0-14
 9 UM-spansh Lat-Span System Announcements
 (AUDIX) 2.0-14
10 UM-sw AUDIX(R) Software
 (AUDIX) 2.0-16

... 53 more menu choices to follow;
<RETURN> for more choices, <CTRL-D> to stop display:

```

**Figure 12-2. Software Remove Screen**

4. Locate the existing RFUs.

Existing RFUs are marked "IXrfu+n," where X is a number such as 15 or 16 and n is the letter a, b, c, or d.

For example, the system may display the RFUs I15rfu+a, I15rfu+b, I16rfu+a, I16rfu+b, or IP16rfu+a.

5. Note the number of the RFU given in the first column.

⇒ NOTE:

In [Figure 12-2](#) that number is 1.

If there is no RFU listed, enter **q** to quit and see "[Installing an RFU](#)" to install the new RFU.

6. Press **CONTROL** **D**.

The system displays the following message:

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??,q]
```

7. Enter the number of the RFU package.

The system displays the name and version number for the package selected as shown below for the sample screen in [Figure 12-2](#):

```
Remote Field Update C for IP16 (486) 1.0-16
```

8. Enter **y**

The system removes the existing RFU.

⇒ NOTE:

If the system displays any messages warning of dependencies, enter **y** again to continue with the software removal.

9. Press **ENTER**.

10. Continue with the next procedure, "[Installing a New RFU](#)."

## Installing a New RFU

⇒ NOTE:

The letter x's that appear in the examples represent the IP load number for the software and the letter designation (a, b, c,...) for the RFU.

1. Starting at the Lucent INTUITY Main menu ([Figure 12-1](#)) select


```
> Customer/Services Administration
```

```
> System Management
```

```
> UNIX Management
```

```
>Software Install
```

The system displays the Software Install menu ([Figure 12-3](#)).



**Figure 12-3. Software Install Menu**

2. Insert the tape labeled “Lucent INTUITY RFU Software” into the tape drive. See [“Inserting and Removing Cartridge Tapes”](#), in [Chapter 3, “Common System Procedures”](#), for this procedure.
3. Select Tape drive.

The system displays the following message:

```
Insert a cartridge into Tape Drive 1.
Type [go] when ready
 or [q] to quit: (default: go)
```

4. Press **ENTER**.

The system displays the following message:

```
Installation in progress. Do not remove the cartridge.
```

```
The following pkgs are available:
```

```
1 Ixxrfu+x Remote Field Update X for IPxx
 (486) 3.0-xx
```

```
Select package(s) you wish to process (or 'all' to
process all packages). (default: all) [?,??, q]
```

**⚠ CAUTION:**

*RFUs apply to a particular software load. Lucent INTUITY software loads are labeled with the release number such as 2.0-x or 3.0-x, where x is a number such as 15 or 16. The RFU software cartridge tape will list x as IP15 or IP16.*

*If the RFU does not match the software loaded onto the Lucent INTUITY system, do not load the RFU. Contact the remote maintenance center for assistance if there is a question about whether or not the RFU matches the system's software load.*

5. Press **ENTER**.

The system displays:

```
Processing of <Remote Field Update X for IPxx> is
completed.
```

```
Insert a cartridge into Tape Drive 1.
```

```
Type [go] when ready
```

```
or [q] to quit: (default: go)
```

6. Enter **q**
7. Remove the tape labeled "Lucent INTUITY RFU Software Update" from the tape drive. See ["Inserting and Removing Cartridge Tapes"](#), in [Chapter 3, "Common System Procedures"](#), for this procedure.
8. Shut down and reboot the system. See ["Inserting and Removing Cartridge Tapes"](#), in [Chapter 3, "Common System Procedures"](#), for this procedure.

## Verifying the RFU Installation

1. Starting at the Lucent INTUITY Main menu ([Figure 12-1](#)), select

```
> Customer/Services Administration
> System Verification
> View Installed Software
```

The system displays the View Installed Software window ([Figure 12-4](#) and [Figure 12-5](#)).

```
View Installed Software

Displaying pkginfo (long version) for only the application
packages...

Displaying pkginfo for package Vex

 PKGINST: Vex
 NAME: Intuity Application Software Set
 CATEGORY: set
 ARCH: 486
 VERSION: 3.0-38
 PSTAMP: 3.38.0 R3.0 IP38 Tue Jul 11 10:22:32 EDT 1995
```

Figure 12-4. Sample View Installed Software Window  
(Detailed Version)

```
View Installed Software

Displaying pkginfo for all packages installed on this system...

application IVC6DI AT&T Intuity IVC6 Device Interface for
softFAX 2.0
intuity OSmods Intuity Operating System Modifications
Module
application VM AUDIX(R) Module marker file
intuity VM-dfltdb AUDIX(R) Default db
intuity VM-files AUDIX(R) Files
intuity VM-sw AUDIX(R) Software
system acp Enhanced Application Compatibility
```

Figure 12-5. Sample View Installed Software Window  
(Abbreviated Version)

2. Locate the RFU title.



## System Configuration



---

## Memory Configuration

The MAP/100 supports 64-Mbytes of memory packaged on two 32-Mbyte or four 16-Mbyte single in-line memory modules (SIMM). These modules are placed in sockets located in the bottom left corner of the CPU circuit card.

The CPU circuit card must be equipped with SIMMs in matched pairs and the SIMMs must be in the following configuration:

- Two identical 32-Mbyte SIMMs located in the SIMM1 and SIMM2 sockets plus two identical 16-Mbyte SIMMs located in the SIMM3, and SIMM4 sockets

---

## Component Assignments

Circuit cards are placed in the MAP/100 in locations called *slots*. Slots are numbered 1 through 25 from the bottom of the MAP/100 to the top of the card cage ([Figure A-1](#)).




Figure A-1. Back View of the MAP/100

Operating hardware is placed in the MAP/100 in locations called *bays*. Bays are also numbered from the top to the bottom, 1 through 9 (Figure A-2).




Figure A-2. Front View of the MAP/100

The following sections detail the fixed and variable assignments for circuit cards and other components installed in the MAP/100.

### Bay Assignments

[Table A-1](#) lists bay assignments which are fixed in the MAP/100 and are not variable in their arrangement:

Table A-1. MAP/100 Bay Assignments

| Bay | Device            | SCSI ID | Terminations |
|-----|-------------------|---------|--------------|
| 1   | Hard Disk Drive 0 | 0       | Disabled     |
| 2   | Hard Disk Drive 4 | 4       | Disabled     |
| 3   | Audfs disk        | 6       | Disabled     |

**Table A-1. MAP/100 Bay Assignments — Continued**

| Bay | Device            | SCSI ID | Terminations |
|-----|-------------------|---------|--------------|
| 4   | Hard Disk Drive 5 | 5       | Disabled     |
| 5   | Hard Disk Drive 1 | 1       | Disabled     |
| 6   | Hard Disk Drive 2 | 2       | Disabled     |
| 7   | Vacant            | -       | -            |
| 8   | Diskette drive    | -       | -            |
| 9   | SCSI tape drive   | 3       | Installed    |

## Slot Assignments

[Table A-2](#) lists slot assignments which are fixed in the MAP/100 and are not variable in their arrangement. The slot assignments apply to both required and optional circuit cards.

**Table A-2. MAP/100 Slot Assignments**

| Slot Number | Circuit Card                        | Required? |
|-------------|-------------------------------------|-----------|
| 1,2         | Tip/Ring                            | Yes       |
| 3-11        | Tip/Ring                            | No        |
| 12          | Vacant                              | -         |
| 13-15       | ACCX                                | No        |
| 16          | GP-Synch or DCIU Interface          | No        |
| 17          | multi-port serial                   | No        |
| 18          | Ethernet LAN                        | No        |
| 19          | Remote Maintenance                  | No        |
| 20          | Video controller                    | Yes       |
| 21          | P5 120 MHz CPU                      | Yes       |
| 22          | External SCSI Connector/Termination | Yes       |
| 23-25       | Vacant                              | -         |

## Assignment Rules

The following rules apply to the placement of optional boards in the MAP/100:

- A maximum of eleven Tip/Ring circuit cards is supported.
- A maximum of three ACCX circuit cards is supported.
- All other circuit cards are supported as one per system.
- Tip/Ring circuit cards are assigned slots sequentially, starting with slot 1.
- ACCX circuit cards are assigned slots sequentially, starting with slot 13.

## Resource Allocation

[Table A-3](#) lists the resource assignments for all devices in the MAP/100. It includes the circuit cards as well as devices which are included on the CPU circuit card.

**Table A-3. Resource Allocation**

| Device                | IRQ | I/O Address | RAM Address                | Notes                                                |
|-----------------------|-----|-------------|----------------------------|------------------------------------------------------|
| VGA controller board  | -   | 3B0-3DF     | A0000-BFFFF<br>C0000-C7FFF | 128K Video RAM, required<br>32K Video BIOS, required |
| System BIOS           | -   | -           | E0000-FFFF                 | Located on CPU, required                             |
| CPU watchdog register | -   | 370         | -                          | Located on CPU, required, not used                   |
| LPT1 port             | 7   | 378-37F     | -                          | Located on CPU, required                             |
| COM1 port             | 4   | 3F8-3FF     | -                          | Located on CPU, required                             |
| COM2 port             | 3   | 2F8-2FF     | -                          | Located on CPU, disable for RMB                      |
| PCI SCSI              | 14  | Plug & Play | C8000-CBFFF                | Located on CPU, SCSI ID 7, required                  |
| 2-Gbyte SCSI disk     | -   | -           | -                          | 2 required, 4 optional                               |
| 2-Gbyte SCSI tape     | -   | -           | -                          | 1 required                                           |

Table A-3. Resource Allocation — *Continued*

| Device                                               | IRQ | I/O Address | RAM Address | Notes                                        |
|------------------------------------------------------|-----|-------------|-------------|----------------------------------------------|
| Diskette drive                                       | 6   | 3F0-3F7     | -           | DMA 2, controller located on CPU, required   |
| LAN circuit card                                     | 10  | 280-29F     | D8000-DBFFF | optional                                     |
| Multi-port circuit card                              | -   | -           | D0000-D3FFF | 1 optional                                   |
| Tip/Ring circuit card                                | 2   | x00-x1F     | -           | x=1-3,5-7,9,A,B,D,E,2 required<br>9 optional |
| ACCX circuit card                                    | 5   | x40-x4F     | -           | x=1-3,5<br>3 optional                        |
| GP-Synch circuit card or DCIU interface circuit card | 12  | 240-24F     | D4000-D7FFF | 1 optional                                   |
| Remote maintenance circuit card                      | 3   | 180-187     | DC000-DCFFF | Disable COM2 port on the CPU                 |

## Component Ordering Numbers

# B

## Component Ordering Numbers

**Table B-1. Component Ordering Numbers**

| <b>Basic Component Description</b>               | <b>Order Number</b> |
|--------------------------------------------------|---------------------|
| Adapter, 356B                                    | 105197297           |
| Adapter, electrical, DCE female                  | 407345776           |
| Adapter, electrical, DCE male (wyse trm, prntrs) | 407050111           |
| Adapter, electrical, DTE female                  | 407345768           |
| Adapter, electrical, DTE male (modems)           | 407050095           |
| Adapter, electrical, jack to jack                | 407005255           |
| Adapter, electrical, external SCSI               | 407524073           |
| Adapter, SPM port connector                      | 105012645           |
| Backplane, 20-ISA, 3-PCI, 1-CPU                  | 407518539           |
| Backplane, 25-slot                               | 406548719           |
| Battery, 12VDC, 6.5 AH                           | 406666420           |
| Bracket, Cable                                   | 406667519           |
| Brackets, PC filter (20)                         | 406798686           |
| Cable assembly kit, hard disk drive              | 406664912           |

*Continued on next page*

**Table B-1. Component Ordering Numbers — Continued**

| Basic Component Description                       | Order Number |
|---------------------------------------------------|--------------|
| Cable assembly, 486 keyboard adapter              | 601436082    |
| Cable assembly, 486 reset                         | 601436090    |
| Cable assembly, ACCX                              | 407027564    |
| Cable assembly, ACCX                              | 601436124    |
| Cable assembly, ACCX/DCP                          | 601447170    |
| Cable assembly, ACCX/DCP                          | 601447188    |
| Cable assembly, CPU/keyboard interface            | 406664938    |
| Cable assembly, disk power                        | 406664946    |
| Cable assembly, EMI suppression (RMB)             | 407265529    |
| Cable assembly, diskette drive                    | 406664920    |
| Cable assembly, internal fan status               | 601436108    |
| Cable assembly, port/line                         | 601447014    |
| Cable assembly, port/line                         | 601447162    |
| Cable assembly, remote maint. MAP/100 UPS Mtr     | 601436116    |
| Cable assembly, SCSI peripheral control           | 601415235    |
| Cable assembly, telephone cord, 3-foot            | 601448632    |
| Cable assembly, VGA port jumper                   | 406664979    |
| Cable assembly, bus activity (PC, 100-PCI)        | 601818206    |
| Cable assembly, bus mouse (P5 MAPs)               | 601818222    |
| Cable assembly, diskette (P5, 100-PCI)            | 601818354    |
| Cable assembly SCSI (P5, 100_PCI & 2-Gbyte Tp PR) | 601818388    |
| Cable assembly, keyboard (P5, 100-PCI, 100C-PCI)  | 601818412    |
| Caster                                            | 406976126    |
| Cord, 6-pin modular, 14-foot                      | 102937604    |
| Cord, AC power, Australia, 8-foot                 | 407051630    |
| Cord, AC power, Germany, 6-foot                   | 407051648    |
| Cord, AC power, India, 8-foot                     | 407406735    |
| Cord, AC power, United Kingdom, 6-foot            | 406999243    |

*Continued on next page*

**Table B-1. Component Ordering Numbers — Continued**

| Basic Component Description          | Order Number |
|--------------------------------------|--------------|
| Cord, power, monitor (PC style)      | 407115591    |
| Cord, power, monitor (wall outlet)   | 406666263    |
| Cord, AC power                       | 406504399    |
| Cord, AC power , 9-foot              | 406900092    |
| Cord, telephone, 25-foot             | 103623195    |
| CP, 8-port asynchronous interface    | 407009406    |
| CP, ACCX interface                   | 106930944    |
| CP, CPU, 50-MHz, 0-Mbyte memory      | 407019306    |
| CP, CPU, 50-MHz, 0-Mbyte memory      | 407300342    |
| CP, CPU, P5120, 0-Mbyte memory       | 407515204    |
| CP, ethernet LAN interface           | 407199538    |
| CP, GP-Synch                         | 406801647    |
| CP, IVC6 analog interface            | 106406580    |
| CP, IVC6-1A analog interface         | 107213944    |
| CP, Tip/Ring, Next Generation (NGTR) | 107224586    |
| CP, remote maintenance kit           | 406969238    |
| CP, SCSI drive controller            | 406830356    |
| CP, SCSI drive controller            | 407021856    |
| CP, synchronous interface            | 601824956    |
| CP, serial, hi-speed                 | 407429398    |
| CP, video controller                 | 406365809    |
| CP, video controller                 | 406901884    |
| CP, video controller                 | 407095835    |
| CP, video controller                 | 407356955    |
| CP, video controller                 | 4075300013   |
| Deskside base kit assembly           | 406664888    |
| Deskside dress package               | 406548677    |
| Deskside H/W kit                     | 406664896    |

*Continued on next page*

**Table B-1. Component Ordering Numbers — Continued**

| Basic Component Description          | Order Number |
|--------------------------------------|--------------|
| Deskside panel, top                  | 406568899    |
| Disk drive, SCSI, 1.75-Gbyte         | 407071950    |
| Disk drive, SCSI, 2-Gbyte            | 407340942    |
| Disk drive, SCSI, 2--Gbyte           | 407596857    |
| Fan bracket assembly                 | 406591321    |
| Fan, 12VDC, TA450                    | 406568899    |
| Filter, left door                    | 406568873    |
| Filter, right door                   | 406568832    |
| Diskette drive, 1.44-Mbyte           | 406664573    |
| Diskette drive, 1.44-Mbyte           | 406832584    |
| Fuse, 65VDC, 30A, VFB                | 406666412    |
| Hardware, SID, Nor Telcom (Meridian) | 407024702    |
| Hardware, SID, Nor Telcom (SL-1)     | 407024694    |
| Hardware, SID, Mitel                 | 407024728    |
| Hardware, SID, NEAX                  | 407024710    |
| Hardware, SID, Rolm                  | 407024686    |
| IC, 16-Mbyte SIMM                    | 406997601    |
| IC, 16-Mbyte SIMM                    | 407244094    |
| IC, 16-Mbyte SIMM                    | 407420116    |
| IC, 10-Mbyte SIMM                    | 407608199    |
| IC, 32-Mbyte SIMM                    | 407420124    |
| IC 32-Mbyte SIMM                     | 407608207    |
| Interface unit, AYC22 cable          | 107221467    |
| Interface unit, AYC22 cable          | 407020510    |
| Keyboard                             | 406649657    |
| Keyboard                             | 406743336    |
| Keyboard (GIS gray)                  | 407104066    |
| Main power distribution board        | 406798231    |

*Continued on next page*

**Table B-1. Component Ordering Numbers — Continued**

| Basic Component Description             | Order Number |
|-----------------------------------------|--------------|
| Monitor, color, VGA                     | 406518779    |
| Monitor, color, VGA                     | 406594952    |
| Monitor, color, VGA (GIS gray)          | 407088335    |
| Panel, left side                        | 406568907    |
| Panel, right side                       | 406568915    |
| Power module, AC (ATT4)                 | 406568808    |
| Power module, AC (ATT8), with filter    | 407121805    |
| Power module, redundant, AC             | 407571553    |
| Power supply, redundant, AC (IPS)       | 407571579    |
| PWB assembly, LED for redundant PS      | 407572056    |
| Rack mount package                      | 4065448669   |
| Receptacle, 1/4-turn                    | 403291354    |
| Resistor SIP, TDM terminator            | 403789167    |
| Retainer, push-on                       | 403867005    |
| Stud, 1/4-turn                          | 900491069    |
| Tape drive, SCSI streaming              | 407194729    |
| Tape drive, SCSI streaming, 2-Gbyte     | 407334507    |
| Terminator, single-ended active, SCSI-2 | 407524719    |
| Tester, RS-232 mini                     | 407515139    |
| Toroid, ring type                       | 405853458    |
| Toroid, split type                      | 407616846    |



# How to Build a System Using This Book



## Checklist for Building a System

The following checklist assumes that you are starting with a MAP/100 shell which has only the power supply and the 12-slot backplane.


If your system does not have a power supply or a 12-slot backplane included, see [Chapter 7, "Replacing Other Components"](#), for the installation procedures.

| Task | Description                                                   | Comments | Refer to                                                   | Done |
|------|---------------------------------------------------------------|----------|------------------------------------------------------------|------|
| 1    | Acquire all of the components necessary to build your system. |          | <a href="#">Appendix B, "Component Ordering Numbers"</a>   |      |
| 2    | Determine the slot and bay locations for the equipment.       |          | <a href="#">Appendix A, "System Configuration"</a>         |      |
| 3    | Install the hard disk drive(s).                               |          | <a href="#">Chapter 6, "Replacing the Hard Disk Drive"</a> |      |
| 4    | Install the tape drive.                                       |          | <a href="#">Chapter 7, "Replacing Other Components"</a>    |      |
| 5    | Install the diskette drive.                                   |          | <a href="#">Chapter 7, "Replacing Other Components"</a>    |      |

*Continued on next page*

| Task | Description                                            | Comments                              | Refer to                                                                          | Done |
|------|--------------------------------------------------------|---------------------------------------|-----------------------------------------------------------------------------------|------|
| 6    | Install the circuit cards.                             |                                       | <a href="#">Chapter 5, "Replacing or Installing Circuit Cards"</a>                |      |
| 7    | Apply power to the unit.                               |                                       | <a href="#">Chapter 4, "Getting Inside the Computer"</a>                          |      |
| 8    | Install the base system software.                      |                                       | <a href="#">Chapter 9, "Installing Base System Software"</a>                      |      |
| 9    | Install the Lucent™ INTUITY™ system software.          |                                       | <a href="#">Chapter 10, "Installing Lucent Intuity System Software"</a>           |      |
| 10   | Install the UNIX multi-user software.                  | This is an optional feature software. | <a href="#">Chapter 11, "Installing the Optional Feature Software"</a>            |      |
| 11   | Perform initial administration and test on the system. |                                       | <i>Lucent INTUITY Messaging Solutions Release 4.0 MAP/100 System Installation</i> |      |

# Disaster Recovery Checklists



---

## Disaster Recovery Checklists

The following checklists are included in this section:

- Checklist for Software Reloading on Nonmirrored Lucent™ INTUITY™ Systems with Existing Hard Disk Drives
- Checklist for Lucent INTUITY Systems with All New Hard Disk Drives
- Checklist for Nonmirrored Lucent INTUITY Systems With a New Hard Disk Drive 0 and Existing Other Hard Disk Drives
- Checklist for Nonmirrored Lucent INTUITY Systems With an Existing Hard Disk Drive 0 and Other New Hard Disk Drive
- Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives
- Checklist for Mirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drive
- Checklist for Replacing Hard Disk Drive 6 (audfs) on a Nonmirrored System

### Checklist for Software Reloading on Nonmirrored Lucent INTUITY Systems with Existing Hard Disk Drives

The procedures in this checklist should be conducted when your Lucent INTUITY system experiences a software disaster. This checklist should not be used if hard disk drives are being replaced.

**Table D-1. Checklist for Software Reloading for Nonmirrored Lucent INTUITY Systems with Existing Hard Disk Drives**

| ✓ | Task                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Reference Documentation                                                                                                                    |
|---|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>Locate the most recent full attended backup tape. You will also need to use the nightly unattended backup tape which should be located in the cartridge tape drive.</p> <p><b>⚠ WARNING:</b><br/> <i>The attended backup tape contains subscriber data. If you do not have the attended backup tape, the Lucent INTUITY system will lose all subscriber data and messages, and you will need to re-administer all subscribers. Contact your remote maintenance center and inform them of the condition.</i></p> |                                                                                                                                            |
|   | <p>Shutdown the Lucent INTUITY system.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <p><a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a>, in <a href="#">Chapter 3, “Common System Procedures”</a></p>   |
|   | <p>Leave all hard disks connected to the SCSI bus.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                            |
|   | <p>Install UnixWare.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           | <p><a href="#">“Installing UnixWare”</a> in <a href="#">Chapter 9, “Installing Base System Software”</a></p>                               |
|   | <p>Install the INTUNIX+e update package.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <p><a href="#">“Installing the INTUNIX+e Software”</a> in <a href="#">Chapter 9, “Installing Base System Software”</a></p>                 |
|   | <p>Install the platform software.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <p><a href="#">“Installing the Platform Software”</a> in <a href="#">Chapter 9, “Installing Base System Software”</a></p>                  |
|   | <p>Install the switch interface software package.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                              | <p><a href="#">“Installing the Switch Interface Software Packages”</a> in <a href="#">Chapter 9, “Installing Base System Software”</a></p> |

*Continued on next page*

**Table D-1. Checklist for Software Reloading for Nonmirrored Lucent INTUITY Systems with Existing Hard Disk Drives — *Continued***

| ✓ | Task                                                                                                                                                                        | Reference Documentation                                                                                                               |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
|   | Install the Lucent INTUITY System software.                                                                                                                                 | <a href="#">Chapter 10, "Installing Lucent Intuity System Software"</a>                                                               |
|   | Reboot the Lucent INTUITY system.                                                                                                                                           | <a href="#">"Shutting Down and Rebooting the Lucent Intuity System"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>    |
|   | Stop the voice system.                                                                                                                                                      | <a href="#">"Stopping the Voice System"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>                                |
|   | Load optional software packages such as CAS or UNIX® Multi-User software.                                                                                                   | <a href="#">Chapter 11, "Installing the Optional Feature Software"</a><br><br>or<br><br>The appropriate feature option documentation. |
|   | Load RFU software update if any. Contact the remote maintenance center for the identity of the current RFU.                                                                 | <a href="#">Chapter 12, "Installing an RFU"</a>                                                                                       |
|   | If you are restoring a system equipped with an internal remote maintenance circuit card, install the corresponding software.                                                | <a href="#">"Remote Maintenance Circuit Cards"</a> , in <a href="#">Chapter 5, "Replacing or Installing Circuit Cards"</a>            |
|   | Reboot the Lucent INTUITY system.                                                                                                                                           | <a href="#">"Shutting Down and Rebooting the Lucent Intuity System"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>    |
|   | Restore the backup tape(s) (attended and unattended).                                                                                                                       | <a href="#">"Restoring Backups"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>                                        |
|   | View the features option screen to verify that all of the customer features purchased are activated. Contact your remote maintenance center if there are any discrepancies. |                                                                                                                                       |

*Continued on next page*

**Table D-1. Checklist for Software Reloading for Nonmirrored Lucent INTUITY Systems with Existing Hard Disk Drives — *Continued***

| ✓ | Task                                                                                                             | Reference Documentation                                                                                                                                           |
|---|------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Check the system date and time.                                                                                  | <a href="#">“Verifying the Date and Time”</a> , in <a href="#">Chapter 3</a> , <a href="#">“Common System Procedures”</a>                                         |
|   | Place test calls to the system to verify installation.                                                           |                                                                                                                                                                   |
|   | Perform alarm origination test or ask your remote maintenance center to dial in to ensure that they can connect. | <a href="#">“Software and Hardware Procedures for Replacing Hard Disk Drive 0”</a> in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a> |

## Checklist for Lucent INTUITY Systems with All New Hard Disk Drives

The procedures in this checklist should be conducted when you are replacing all of the hard disk drives on your Lucent INTUITY system. There are no provisions in this checklist for recovering existing file system. As a result, this checklist should not be used if any hard disk drive has been previously used in your Lucent INTUITY system.

Table D-2. Checklist for Lucent INTUITY Systems with All New Hard Disk Drives

| ✓ | Task                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Reference Documentation                                                                                                               |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>Locate the most recent full attended backup tape. You will also need to use the nightly unattended backup tape which should be located in the cartridge tape drive.</p> <p><b>⚠ WARNING:</b><br/> <i>The attended backup tape contains subscriber data. If you do not have the attended backup tape, the Lucent INTUITY system will loose all subscriber data and messages, and you will need to re-administer all subscribers. Contact your remote maintenance center and inform them of the condition.</i></p> |                                                                                                                                       |
|   | Install the hard disk drives.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | <a href="#">“Hardware Procedures for Replacing the Hard Disk Drive”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Install UnixWare.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | <a href="#">“Installing UnixWare”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                                 |
|   | Install the INTUNIX+e update package.                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | <a href="#">“Installing the INTUNIX+e Software”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                   |
|   | Install the platform software.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <a href="#">“Installing the Platform Software”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                    |

Continued on next page

Table D-2. Checklist for Lucent INTUITY Systems with All New Hard Disk Drives  
 — Continued

| ✓ | Task                                                                      | Reference Documentation                                                                                                                                        |
|---|---------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Install the switch interface software package.                            | <a href="#">“Installing the Switch Interface Software Packages”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                            |
|   | Clean the Hard Disk Drives 1 through 6.                                   | <a href="#">“Cleaning a Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                                                   |
|   | Run <b>installit</b>                                                      | <a href="#">“Installing UnixWare”</a> and <a href="#">“Installing the Platform Software”</a> , in Chapter 9, <a href="#">“Installing Base System Software”</a> |
|   | Install the Lucent INTUITY system software.                               | Chapter 10, <a href="#">“Installing Lucent Intuity System Software”</a>                                                                                        |
|   | Complete the software procedures to add Hard Disk Drives 1 through 6.     | <a href="#">“Adding a Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                                                     |
|   | Rename Hard Disk Drive 6 as <b>audfsdisk</b>                              | <a href="#">“Adding a Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                                                     |
|   | Stop the voice system.                                                    | <a href="#">“Stopping the Voice System”</a> in Chapter 3, <a href="#">“Common System Procedures”</a>                                                           |
|   | Load optional software packages such as CAS or UNIX® Multi-User software. | Chapter 11, <a href="#">“Installing the Optional Feature Software”</a><br><br>or<br><br>The appropriate feature option documentation.                          |

Continued on next page

**Table D-2. Checklist for Lucent INTUITY Systems with All New Hard Disk Drives**  
 — *Continued*

| ✓ | Task                                                                                                                                                                       | Reference Documentation                                                                                                                            |
|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Load RFU software update if any. Contact the remote maintenance center for the identity of the current RFU.                                                                | <a href="#">Chapter 12, "Installing an RFU"</a>                                                                                                    |
|   | If you are restoring a system equipped with a remote maintenance circuit card, install the corresponding software.                                                         | <a href="#">"Remote Maintenance Circuit Cards"</a> , in <a href="#">Chapter 5, "Replacing or Installing Circuit Cards"</a>                         |
|   | Reboot the Lucent INTUITY system.                                                                                                                                          | <a href="#">"Shutting Down and Rebooting the Lucent Intuity System"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>                 |
|   | Stop the voice system.                                                                                                                                                     | <a href="#">"Stopping the Voice System"</a> in <a href="#">Chapter 3, "Common System Procedures"</a>                                               |
|   | Restore the system from the backup tape(s) (attended and unattended).                                                                                                      | <a href="#">"Restoring Backups"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>                                                     |
|   | View the features option screen to verify that all of the customer features purchased are activated Contact your remote maintenance center if there are any discrepancies. |                                                                                                                                                    |
|   | Check the system date and time.                                                                                                                                            | <a href="#">"Verifying the Date and Time"</a> , in <a href="#">Chapter 3, "Common System Procedures"</a>                                           |
|   | Place test calls to the system to verify installation.                                                                                                                     |                                                                                                                                                    |
|   | Perform alarm origination test or ask your remote maintenance center to dial in to ensure that they can connect.                                                           | <a href="#">"Software and Hardware Procedures for Replacing Hard Disk Drive 0"</a> , in <a href="#">Chapter 6, "Replacing the Hard Disk Drive"</a> |

## Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives

The procedures in this checklist should be conducted on a nonmirrored Lucent INTUITY system in which Hard Disk Drive 0 has failed. This checklist should not be used if Hard Disk Drive 6 or any other hard disk drive has also failed.

**Table D-3. Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives**

| ✓ | Task                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Reference Documentation                                                                                                                               |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | <p>Locate the most recent full attended backup tape. You will also need to use the nightly unattended backup tape which should be located in the cartridge tape drive.</p> <p><b>⚠ WARNING:</b><br/> <i>The attended backup tape contains subscriber data. If you do not have the attended backup tape, the Lucent INTUITY system will loose all subscriber data and messages, and you will need to re-administer all subscribers. Contact your remote maintenance center and inform them of the condition.</i></p> |                                                                                                                                                       |
|   | Remove the hard disk drive.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         | <a href="#">“Removing a Hard Disk Drive”</a> , in <a href="#">Chapter 6</a> ,<br><a href="#">“Replacing the Hard Disk Drive”</a>                      |
|   | Set the jumpers for the new hard disk drive to the correct settings for Hard Disk Drive 0.                                                                                                                                                                                                                                                                                                                                                                                                                          | <a href="#">“Readying a New Hard Disk Drive for Installation”</a> , in <a href="#">Chapter 6</a> ,<br><a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Install the hard disk drive.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | <a href="#">“Mounting a Hard Disk Drive in the MAP/100”</a> , in <a href="#">Chapter 6</a> ,<br><a href="#">“Replacing the Hard Disk Drive”</a>       |
|   | Install UnixWare.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | <a href="#">“Installing UnixWare”</a> in <a href="#">Chapter 9</a> ,<br><a href="#">“Installing Base System Software”</a>                             |

*Continued on next page*

**Table D-3. Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives — Continued**

| ✓ | Task                                                                                                               | Reference Documentation                                                                                                                                |
|---|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Install the INTUNIX+e update package.                                                                              | <a href="#">“Installing the INTUNIX+e Software”</a> in <a href="#">Chapter 9</a> , <a href="#">“Installing Base System Software”</a>                   |
|   | Install the platform software.                                                                                     | <a href="#">“Installing the Platform Software”</a> in <a href="#">Chapter 9</a> , <a href="#">“Installing Base System Software”</a>                    |
|   | Install the switch interface software package.                                                                     | <a href="#">“Installing the Switch Interface Software Packages”</a> in <a href="#">Chapter 9</a> , <a href="#">“Installing Base System Software”</a>   |
|   | Load optional software packages such as CAS or UNIX Multi-User software.                                           | <a href="#">Chapter 11</a> , <a href="#">“Installing the Optional Feature Software”</a><br><br>or<br><br>The appropriate feature option documentation. |
|   | Load RFU software update if any. Contact the remote maintenance center for the identity of the current RFU.        | <a href="#">Chapter 12</a> , <a href="#">“Installing an RFU”</a>                                                                                       |
|   | If you are restoring a system equipped with a remote maintenance circuit card, install the corresponding software. | <a href="#">“Remote Maintenance Circuit Cards”</a> , in <a href="#">Chapter 5</a> , <a href="#">“Replacing or Installing Circuit Cards”</a>            |
|   | Reboot the Lucent INTUITY system.                                                                                  | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in <a href="#">Chapter 3</a> , <a href="#">“Common System Procedures”</a>    |
|   | Stop the voice system.                                                                                             | <a href="#">“Stopping the Voice System”</a> , in <a href="#">Chapter 3</a> , <a href="#">“Common System Procedures”</a>                                |

*Continued on next page*

**Table D-3. Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives — Continued**

| ✓ | Task                                                                                                                                                                                                                  | Reference Documentation                                                                                                         |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
|   | Restore the unattended backup tape.<br><br><b>⇒ NOTE:</b><br>Only restore the unattended backup at this time.                                                                                                         | <a href="#">“Restoring Backups”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a>                                  |
|   | Login as tsc.                                                                                                                                                                                                         |                                                                                                                                 |
|   | Restore the attended backup from the UNIX prompt.                                                                                                                                                                     | <a href="#">“Restoring the Attended and Unattended Backups”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Remove the system from the disaster recovery state.                                                                                                                                                                   | <a href="#">“Restoring the Attended and Unattended Backups”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Login as craft.                                                                                                                                                                                                       |                                                                                                                                 |
|   | Start the voice system.                                                                                                                                                                                               | <a href="#">“Starting the Voice System”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a>                          |
|   | View the features option screen to verify that all of the customer features purchased are activated Contact your remote maintenance center if there are any discrepancies.                                            |                                                                                                                                 |
|   | Check the system date and time.                                                                                                                                                                                       | <a href="#">“Verifying the Date and Time”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a>                        |
|   | Place test calls to the system to verify installation.                                                                                                                                                                |                                                                                                                                 |
|   | Perform alarm origination test or ask your remote maintenance center to dial in to ensure that they can connect.<br><br><b>⇒ NOTE:</b><br>If your system is not equipped with alarm origination, skip this procedure. |                                                                                                                                 |

*Continued on next page*

**Table D-3. Checklist for Nonmirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives — Continued**

| ✓ | Task                                                                       | Reference Documentation                                                                    |
|---|----------------------------------------------------------------------------|--------------------------------------------------------------------------------------------|
|   | Complete the initial administration and test of the Lucent INTUITY system. | <i>Lucent INTUITY Messaging Solutions Release 4 MAP/40 and MAP/40s System Installation</i> |

## Checklist for Nonmirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives

The procedures in this checklist should be conducted on a nonmirrored Lucent INTUITY system in which a hard disk drive other than Hard Disk Drive 0 has failed. This checklist should not be used if Hard Disk Drive 0 has also failed.

**Table D-4. Checklist for Nonmirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives**

| ✓ | Task                                                                                                                                                                                                                                                                                   | Reference Documentation                                                                                                                                                        |
|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Locate the most recent full attended backup or nightly unattended backup tape which should be located in the cartridge tape drive.<br><br> <b>NOTE:</b><br>Use the most recent backup tape available. |                                                                                                                                                                                |
|   | Activate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure.                                                                              | <a href="#">“Activating Alarm Suppression”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                                                |
|   | Install Hard Disk Drive 1 in Bay 3.                                                                                                                                                                                                                                                    | <a href="#">“Software and Hardware Procedures for Replacing Hard Disk Drives 1 through 5”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Reboot the Lucent INTUITY system.                                                                                                                                                                                                                                                      | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in <a href="#">Chapter 3</a> , <a href="#">“Common System Procedures”</a>                            |
|   | Initialize Hard Disk Drive 1.                                                                                                                                                                                                                                                          | <a href="#">“Initializing the New Hard Disk Drive”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                                        |
|   | Inactivate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure.                                                                          | <a href="#">“Inactivating Alarm Suppression”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                                              |

*Continued on next page*

**Table D-4. Checklist for Nonmirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives — *Continued***

| ✓ | Task                     | Reference Documentation                                                                                |
|---|--------------------------|--------------------------------------------------------------------------------------------------------|
|   | Stop the voice system.   | <a href="#">“Stopping the Voice System”</a> in <a href="#">Chapter 3, “Common System Procedures”</a>   |
|   | Restore the backup tape. | <a href="#">“Restoring Backups”</a> , in <a href="#">Chapter 3, “Common System Procedures”</a>         |
|   | Start the voice system.  | <a href="#">“Starting the Voice System”</a> , in <a href="#">Chapter 3, “Common System Procedures”</a> |

## Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives

The procedures in this checklist should be conducted on a mirrored Lucent INTUITY system in which Hard Disk Drive 0 has failed. This checklist should not be used if Hard Disk Drive 1 has also failed.

**Table D-5. Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives**

| ✓ | Task                                                                                                                                                                                                      | Reference Documentation                                                                                                            |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|   | Perform an attended backup.                                                                                                                                                                               | <a href="#">“Backing Up (Attended)”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a>                                 |
|   | Shutdown the Lucent INTUITY system.                                                                                                                                                                       | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a> |
|   | Activate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Inactivating Alarm Suppression”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                   |
|   | Remove Hard Disk Drive 0 and Hard Disk Drive 1.                                                                                                                                                           | <a href="#">“Removing a Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                       |
|   | Change the jumper settings on Hard Disk Drive 1 to the correct positions for Hard Disk Drive 0.                                                                                                           | <a href="#">“Readying a New Hard Disk Drive for Installation”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>  |
|   | Set the jumpers for the new hard disk drive to the correct position for Hard Disk Drive 1.                                                                                                                | <a href="#">“Readying a New Hard Disk Drive for Installation”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>  |
|   | Place the modified Hard Disk Drive 1 in Bay 1 and the new hard disk drive in Bay 5.                                                                                                                       | <a href="#">“Mounting a Hard Disk Drive in the MAP/100”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>        |

*Continued on next page*

**Table D-5. Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives — *Continued***

| ✓ | Task                                                                                                                                                                                                                                                                                   | Reference Documentation                                                                                                            |
|---|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|   | Reboot the Lucent INTUITY system.                                                                                                                                                                                                                                                      | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a> |
|   | Initialize the new hard disk drive to reflect the correct settings for Hard Disk Drive 0.                                                                                                                                                                                              | <a href="#">“Initializing the New Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>             |
|   | Shutdown the Lucent INTUITY system.                                                                                                                                                                                                                                                    | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a> |
|   | Remove the hard disk drives.                                                                                                                                                                                                                                                           | <a href="#">“Removing a Hard Disk Drive”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                       |
|   | Change the jumper settings on the hard disk drive removed from Bay 1 to the correct positions for Hard Disk Drive 1.<br><br> <b>NOTE:</b><br>This hard disk drive was originally Hard Disk Drive 1. | <a href="#">“Readying a New Hard Disk Drive for Installation”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>  |
|   | Change the jumpers for the new hard disk drive to the correct position for Hard Disk Drive 0.                                                                                                                                                                                          | <a href="#">“Readying a New Hard Disk Drive for Installation”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>  |

*Continued on next page*

**Table D-5. Checklist for Mirrored Lucent INTUITY Systems with a New Hard Disk Drive 0 and Existing Other Hard Disk Drives — *Continued***

| ✓ | Task                                                                                                                                                                                                        | Reference Documentation                                                                                                            |
|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|   | Place Hard Disk Drive 0 in Bay 1 and Hard Disk Drive 1 in Bay 5.                                                                                                                                            | <a href="#">“Mounting a Hard Disk Drive in the MAP/100”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>        |
|   | Reboot the Lucent INTUITY system.                                                                                                                                                                           | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in Chapter 3, <a href="#">“Common System Procedures”</a> |
|   | Inactivate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Inactivating Alarm Suppression”</a> , in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                   |

## Checklist for Mirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives

The procedures in this checklist should be conducted on a mirrored Lucent INTUITY system in which a hard disk drive other than Hard Disk Drive 0 has failed. This checklist should not be used if Hard Disk Drive 0 has also failed.

**Table D-6. Checklist for Mirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives**

| ✓ | Task                                                                                                                                                                                                      | Reference Documentation                                                                                                          |
|---|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|   | Perform an attended backup.                                                                                                                                                                               | <a href="#">“Backing Up (Attended)”</a> in Chapter 3, <a href="#">“Common System Procedures”</a>                                 |
|   | Identify the failed hard disk drive.                                                                                                                                                                      | <a href="#">“Identifying a Failed Hard Disk Drive”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>             |
|   | Activate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Activating Alarm Suppression”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                     |
|   | Shutdown the Lucent INTUITY system.                                                                                                                                                                       | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> in Chapter 3, <a href="#">“Common System Procedures”</a> |
|   | Remove the failed hard disk drive.                                                                                                                                                                        | <a href="#">“Removing a Hard Disk Drive”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>                       |
|   | Set the jumpers on the new hard disk drive to reflect the correct hard disk drive number.                                                                                                                 | <a href="#">“Initializing the New Hard Disk Drive”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>             |
|   | Install the new hard disk drive.                                                                                                                                                                          | <a href="#">“Mounting a Hard Disk Drive in the MAP/100”</a> in Chapter 6, <a href="#">“Replacing the Hard Disk Drive”</a>        |

**Table D-6. Checklist for Mirrored Lucent INTUITY Systems with an Existing Hard Disk Drive 0 and Other New Hard Disk Drives — Continued**

| ✓ | Task                                                                                                                                                                                                        | Reference Documentation                                                                                                          |
|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
|   | Reboot the Lucent INTUITY system.                                                                                                                                                                           | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> in <a href="#">Chapter 3, “Common System Procedures”</a> |
|   | Initialize the new hard disk drive to reflect the correct settings.                                                                                                                                         | <a href="#">Chapter 6, “Initializing the New Hard Disk Drive”</a> in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>  |
|   | Inactivate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Inactivating Alarm Suppression”</a> in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>                   |

## Checklist for Replacing Hard Disk Drive 6 (audfs) on a Nonmirrored Lucent INTUITY System

The procedures in this checklist should be conducted on a nonmirrored Lucent INTUITY system in which a Hard Disk Drive 6 has failed.

**Table D-7. Checklist for Hard Disk Drives 6 (audfs) on a Nonmirrored Lucent INTUITY System**

| ✓ | Task                                                                                                                      | Reference Documentation                                                                                                            |
|---|---------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------|
|   | Perform an attended backup.                                                                                               | <a href="#">“Backing Up (Attended)”</a> , in <a href="#">Chapter 3, “Common System Procedures”</a>                                 |
|   | Activate alarm suppression.<br><br><b>⇒ NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Activating Alarm Suppression”</a> , in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>                     |
|   | Shutdown the Lucent INTUITY system.                                                                                       | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in <a href="#">Chapter 3, “Common System Procedures”</a> |
|   | Remove the failed hard disk drive.                                                                                        | <a href="#">“Removing a Hard Disk Drive”</a> , in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>                       |
|   | Set the jumpers on the new hard disk drive to reflect the correct hard disk drive number.                                 | <a href="#">“Initializing the New Hard Disk Drive”</a> , in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>             |
|   | Install the new hard disk drive.                                                                                          | <a href="#">“Mounting a Hard Disk Drive in the MAP/100”</a> , in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a>        |
|   | Reboot the Lucent INTUITY system.                                                                                         | <a href="#">“Shutting Down and Rebooting the Lucent Intuity System”</a> , in <a href="#">Chapter 3, “Common System Procedures”</a> |

*Continued on next page*

**Table D-7. Checklist for Hard Disk Drives 6 (audfs) on a Nonmirrored Lucent INTUITY System — Continued**

| ✓ | Task                                                                                                                                                                                                        | Reference Documentation                                                                                                                                      |
|---|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|
|   | Initialize the new hard disk drive to reflect the correct settings.                                                                                                                                         | <a href="#">“Initializing the New Hard Disk Drive”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                      |
|   | Install the default voice mail database.                                                                                                                                                                    | <a href="#">“Installing the Default Voice Mail Database”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                |
|   | Restore the Lucent INTUITY system using the back-up tapes.                                                                                                                                                  | <a href="#">“Restoring the Lucent Intuity System from the Backup Tapes”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a> |
|   | Inactivate alarm suppression.<br><br> <b>NOTE:</b><br>If your system does not have alarm origination, skip this procedure. | <a href="#">“Inactivating Alarm Suppression”</a> , in <a href="#">Chapter 6</a> , <a href="#">“Replacing the Hard Disk Drive”</a>                            |

## Checklist for Field Reloading a Lodging Only System

Table D-8. Checklist for Field Reloading a Lodging Only Systems

| ✓ | Task                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Source                                                                                                                     |
|---|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------|
|   | <p>Locate the most recent full attended backup tape. You will also need to use the nightly backup tape which should be located in the cartridge tape drive.</p> <p><b>⚠ WARNING:</b><br/> <i>The attended backup tape contains subscriber data. If you do not have the attended backup tape, the system will loose all subscriber data and messages, and you will need to re-administer all subscribers. Contact your remote support center and inform them of the condition.</i></p> |                                                                                                                            |
|   | <p>Shutdown the system if the system is responding to commands.</p> <p><b>⇒ NOTE:</b><br/>           If the system is not responding to commands, then continue with the procedures in this checklist.</p>                                                                                                                                                                                                                                                                            | <p><a href="#">“Shutting Down the System”</a> in <a href="#">Chapter 3, “Common System Procedures”</a></p>                 |
|   | <p>Leave Hard Disk Drive 0 connected to the SCSI bus.</p>                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                            |
|   | <p>Verify the CMOS settings.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                      | <p><a href="#">“P5 120 MHz CPU Circuit Card”</a> in <a href="#">Chapter 5, “Replacing or Installing Circuit Cards”</a></p> |
|   | <p>Verify the SCSI host adapter settings.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                         | <p><a href="#">“P5 120 MHz CPU Circuit Card”</a> in <a href="#">Chapter 5, “Replacing or Installing Circuit Cards”</a></p> |
|   | <p>Low level format the hard disk drive.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                          | <p><a href="#">“Performing a Low-Level Format”</a> in <a href="#">Chapter 6, “Replacing the Hard Disk Drive”</a></p>       |

Continued on next page

Table D-8. Checklist for Field Reloading a Lodging Only Systems — *Continued*

| ✓ | Task                                                                                                                       | Source                                                                                                                                   |
|---|----------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|   | Install UnixWare.                                                                                                          | <a href="#">“Installing UnixWare”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                                    |
|   | Install the INTUNIX+e update package.                                                                                      | <a href="#">“Installing the INTUNIX+e Software”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                      |
|   | Install the platform software.                                                                                             | <a href="#">“Installing the Platform Software”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>                       |
|   | Install the switch interface software package.                                                                             | <a href="#">“Installing the Switch Interface Software Packages”</a> in Chapter 9, <a href="#">“Installing Base System Software”</a>      |
|   | Load RFU Software Update cartridge tape if any. Contact the remote maintenance center for the identity of the current RFU. | <a href="#">Chapter 12, “Installing an RFU”</a>                                                                                          |
|   | Install the Lodging software package.                                                                                      | <a href="#">“Installing Intuity Lodging Software Packages”</a> in Chapter 11, <a href="#">“Installing the Optional Feature Software”</a> |
|   | Install the optional Lodging language packages.                                                                            | <a href="#">“Installing Intuity Lodging Software Packages”</a> in Chapter 11, <a href="#">“Installing the Optional Feature Software”</a> |
|   | Install the UNIX Multi-User software package, if used.                                                                     | <a href="#">“Installing UNIX Multi-User Software”</a> in Chapter 11, <a href="#">“Installing the Optional Feature Software”</a>          |
|   | Reboot the system.                                                                                                         | <a href="#">“Rebooting the System”</a> in Chapter 3, <a href="#">“Common System Procedures”</a>                                          |

*Continued on next page*

Table D-8. Checklist for Field Reloading a Lodging Only Systems — *Continued*

| ✓ | Task                                                                                                             | Source                                                                                       |
|---|------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
|   | Restore the system from the backup tape(s) (attended and nightly).                                               | <a href="#">“Restoring Backups”</a> in <a href="#">Chapter 3, “Common System Procedures”</a> |
|   | Place test calls to the system to verify installation.                                                           |                                                                                              |
|   | Perform alarm origination test or ask your remote maintenance center to dial in to ensure that they can connect. |                                                                                              |



# Glossary

## 5ESS Switch

A central office switch manufactured by Lucent Technologies that can be integrated with the Lucent INTUITY system.

---

## A

### accessed message

A message that was received and scanned (either the entire message or just the header).

### ACA

See *automatic circuit assurance*.

### ACD

See *automatic call distribution*.

### activity menu

The list of options spoken to users when they first access a messaging system. Selecting an activity is the starting point for all user operations.

### ADAP

See *administration and data acquisition package*.

### address

INTUITY AUDIX user identification, containing the user's extension and machine, that indicates where the system needs to deliver a message. An address may include several users or mailing lists. Name or number addressing can be selected with the   (Address) command.

### adjunct

A separate system closely integrated with a switch, such as a Lucent INTUITY system or a call management system (CMS).

### administration

The process of setting up a system (such as a switch or a messaging system) to function as desired. Options and defaults are normally set up (translated) by the system administrator or service personnel.

### administration and data acquisition package (ADAP)

A software package that allows the system administrator to transfer system user, maintenance, or traffic data from an INTUITY AUDIX system to a personal computer (PC).

### ADU

See *asynchronous data unit*.

### alarm log

A list of alarms that represent all of the active or resolved problems on a Lucent INTUITY system. The alarm log is stored in a software file on disk and can be accessed either locally or remotely on a terminal connected to the system.

**alarms**

Hardware, software, or environmental problems that may affect system operation. Alarms are classified as *major*, *minor*, or *warning*.

**alphanumeric**

Consisting of alphabetic and numeric symbols or punctuation marks.

**ALT**

See *assemble, load, and test*.

**American wire gauge (AWG)**

A standard measuring gauge for nonferrous conductors.

**AMIS**

See *Audio Messaging Interchange Specification*.

**AMIS prefix**

A number added to the destination number to indicate that it is an AMIS analog networking number.

**analog networking**

A method of transferring a message from one messaging system to another whereby the message is played back (voiced) during the transfer.

**analog signal**

In teleprocessing usage, a communications path that usually refers to a voice-grade telephone line.

**announcement**

A placeholder within the Lucent INTUITY system for playing fragments. Each event that may occur within AUDIX has one or more announcement numbers permanently assigned to it. Fragment numbers are then assigned to the announcement numbers.

**announcement fragment**

A numbered piece of spoken information that makes up a system message or prompt.

**antistatic**

A treatment for material to prevent the build-up of static electricity.

**API**

See *application programming interface*.

**application**

A computer software program.

**application identifier**

A two-letter code used in the administrator's log to identify the application or subsystem for which an alarm is being generated. There are eight application identifiers as follows: CA (Call Accounting), ML (MERLIN LEGEND), MT (Maintenance), NW (Digital Networking), SW (Switch Integration), VM (Voice Messaging), VP (Voice Processing), and VR (Voice Response).

**application programming interface (API)**

A set of formalized software calls and routines that an application program can reference to access underlying network services.

**assemble, load, and test (ALT)**

The Lucent factory process that preloads software, installs hardware, and tests the system prior to shipping.

**ASP**

advanced signal processor

**asynchronous communication**

A method of data transmission in which bits or characters are sent at irregular intervals and spaced by start and stop bits rather than time. See also *synchronous communication*.

**asynchronous data unit (ADU)**

An electronic communications device that can extend data transmission over asynchronous lines more than 50 feet in length. Recommended ADUs for use with the Lucent INTUITY system include Z3A1 or Z3A4.

**asynchronous transmission**

A form of serial communications where each transmitted character is bracketed with a start bit and one or two stop bits. The Lucent INTUITY system provides asynchronous EIA-232 capabilities for INTUITY AUDIX Digital Networking, if required.

**attendant console**

A special-purpose telephone with numerous lines and features usually located at the front desk of a business or other organization. The front desk attendant uses this telephone to answer and transfer calls.

**Audio Messaging Interchange Specification (AMIS)**

An analog networking protocol that allows users to exchange messages with any messaging system that also has AMIS Analog Networking capabilities. Messages can be exchanged with users on Lucent INTUITY systems as well as with users on remote messaging systems made by vendors other than Lucent.

**Audio Information Exchange (AUDIX)**

A complete messaging system accessed and operated by touch-tone telephones and integrated with a switch.

**audit**

A software program that resolves filesystem incompatibilities and updates restored filesystems to a workable level of service. Audits are done automatically on a periodic basis, or can be performed on demand.

**AUDIX**

See *Audio Information Exchange*.

**autodelete**

An INTUITY AUDIX feature that allows users to designate that faxes be automatically deleted from their mailboxes after they are printed.

**automated attendant**

A Lucent INTUITY system feature that allows users to set up a main extension number with a menu of options that routes callers to an appropriate department at the touch of a button.

**automatic call distribution (ACD)**

The System 85, Generic 2, or Generic 3 call-distribution group of analog ports that connects Lucent INTUITY users to the system. See also *call-distribution group*.

**automatic circuit assurance (ACA)**

A feature of the switch that keeps records of both very long and very short calls and notifies the attendant when these calls exceed a certain parameter. The logic is that many very short calls or one very long one may suggest a trunk that is hung, broken, or out of order. The attendant can then physically dial into the trunk to check it.

**automatic message scan**

An INTUITY AUDIX feature that allows users to scan all message headers and messages at the touch of two buttons. With Lucent INTUITY FAX Messaging, this feature allows all new faxes to be bundled and transmitted over a single fax call delivery call. Also called *autoscan*.

**autoprint**

An INTUITY AUDIX feature that allows users to designate that faxes be automatically sent to a specified print destination.

**autoscan**

See *automatic message scan*.

**AWG**

See *American wire gauge*.

---

**B**

**background testing**

Testing that runs continuously when the system is not busy doing other tasks.

**backplane**

A centrally located device within a computer to which individual circuit cards are plugged for communication across an internal bus.

**backup**

A duplicate copy of files and directories saved on a removable medium such as floppy diskette or tape. The back-up filesystem can be copied back (restored) if the active version is damaged (corrupted) or lost.

**basic input/output system (BIOS)**

A system that contains the buffers for sending information from a program to the actual hardware device for which the information is intended.

**basic call transfer**

The switch-hook flash method used to send the INTUITY AUDIX transfer command over analog voice ports.

**basic rate access**

See *basic rate interface*.

**basic rate interface (BRI)**

International standard protocol for connecting a station terminal to an integrated systems digital network (ISDN) switch. ISDN BRI supports two 64-Kbps information-bearer channels (B1 and B2), and one 16-Kbps call status and control (D) channel (a 2B + D format). Also called *basic rate access*.

**binary synchronous communications (BSC)**

A character-oriented synchronous link protocol.

**BIOS**

See *basic input/output system*.

**body**

The part of a Lucent INTUITY voice mail that contains the actual spoken message. For a leave word calling (LWC) message, it is a standard system announcement.

**boot**

The operation to start a computer system by loading programs from disk to main memory (part of system initialization). Booting is typically accomplished by physically turning on or restarting the system. Also called *reboot*.

**boot filesystem**

The filesystem from which the system loads its initial programs.

**BRI**

See *basic rate interface*.

**broadcast messaging**

An INTUITY AUDIX feature that enables the system administrator and other designated users to send a message to all users automatically.

**BSC**

See *binary synchronous communications*.

**buffer**

A temporary storage area used to equalize or balance different operating speeds. A buffer can be used between a slow input device, such as a terminal keyboard, and the main computer, which operates at a very high speed.

**bulletin board**

An INTUITY AUDIX feature that allows a message to be played to callers who dial the bulletin board extension. Callers cannot leave a message since it is a listen-only service. Also called *information service*.

**bundling**

Combining several calls and handling them as a single call. See also *automatic message scan*.

**bus**

An electrical connection/cable allowing two or more wires, lines, or peripherals to be connected together.

**busy-out/release**

To remove a Lucent INTUITY device from service (make it appear busy or in use), and later restore it to service (release it). The Lucent INTUITY switch data link, voice ports, or networking ports can be busied out if they appear faulty or when maintenance tests are run.

---

**C**

**CA**

Call accounting system application identifier. See *application identifier*.

**call accounting system (CAS)**

A software device that monitors and records information about a calling system.

**call-answer**

An INTUITY AUDIX feature that allows the system to answer a call and record a message when the user is unavailable. Callers can be redirected to the system through the call coverage or call forwarding switch features. INTUITY AUDIX users can record a personal greeting for these callers.

**call-answer language choice**

The capability of user mailboxes to accept messages in different languages. For the INTUITY AUDIX application, this capability exists when the multilingual feature is turned on.

**callback number**

In AMIS analog networking, the telephone number transmitted to the recipient machine to be used in returning messages that cannot be delivered.

**call classification analysis (CCA)**

A process that enables application designers to use information available within the system to classify the disposition of originated and transferred calls.

**call coverage**

A switch feature that defines a preselected path for calls to follow if the first (or second) coverage points are not answered. The Lucent INTUITY system can be placed at the end of a coverage path to handle redirected calls through call coverage, send all calls, go to cover, etc.

**call data handler process (CDH)**

A software process that accumulates generic call statistics and application events.

**call detail recording (CDR)**

A switch feature that uses software and hardware to record call data. See also *call detail recording utility*.

**call detail recording utility (CDRU)**

Applications software that collects, stores, optionally filters, and outputs call detail records for direct or polled output to peripheral devices. See also *call detail recording*.

**call delivery**

See *message delivery*.

**call-distribution group**

The set of analog port cards on the switch that connects switch users to the Lucent INTUITY system by distributing new calls to idle ports. This group (or split) is called automatic call distribution (ACD) on System 85, Generic 2, and Generic 3 and uniform call distribution (UCD) on System 75, Generic 1, and Generic 3. See also *automatic call distribution* and *uniform call distribution*.

**call management system (CMS)**

An inbound call distribution and management reporting package.

**called tone (CED tone)**

The distinctive tone generated by a fax endpoint when it answers a call (a constant 2100-Hz tone).

**called subscriber information (CSI)**

The identifier for the answering fax endpoint. This identifier is sent in the T.30 protocol and is generally the telephone number of the fax endpoint.

**calling tone (CNG tone)**

The distinctive tone generated by a fax endpoint when placing a call (a constant 1100-Hz tone that is on for 1/2 second, off for 3 seconds).

**call vectoring**

A System 85 R2V4, Generic 2, and Generic 3 feature that uses a vector (switch program) to allow a switch administrator to customize the behavior of calls sent to an automatic call distribution (ACD) group.

**card cage**

An area within the Lucent INTUITY hardware platform that contains and secures all of the standard and optional circuit cards used in the system.

**cartridge tape drive**

A high-capacity data storage/retrieval device that can be used to transfer large amounts of information onto high-density magnetic cartridge tape based on a predetermined format. This tape is to be removed from the system and stored as a backup.

**CAS**

See *call accounting system*.

**CCA**

See *call classification analysis*.

**CDH**

See *call data handler process*.

**CDR**

See *call detail recording*.

**CDRU**

See *call detail recording utility (CDRU)*.

**CED tone**

See *called tone*.

**CELP**

See *code excited linear prediction*.

**central office (CO)**

An office or location in which large telecommunication equipment such as telephone switches and network access facilities are maintained. In a CO, private customer lines are terminated and connected to the public network through common carriers.

**central processing unit (CPU)**

The component of the computer that manipulates data and processes instructions coming from software.

**channel**

A telecommunications transmission path for voice and/or data.

**channel capacity**

A measure of the maximum bit rate through a channel.

**class of restriction (COR)**

A feature that allows up to 64 classes of call-origination and call-termination restrictions for telephones, telephone groups, data modules, and trunk groups. See also *class of service*.

**class of service (COS)**

The standard set of INTUITY AUDIX features given to users when they are first administered (set up with a voice mailbox). See also *class of restriction*.

**clear to send (CTS)**

Located on Pin 5 of the 25-conductor RS-232 interface, CTS is used in the transfer of data between the computer and a serial device.

**client**

A computer that sends, receives and uses data, but that also shares a larger resource whose function is to do most data storage and processing. For Lucent INTUITY Message Manager, the user's PC running Message Manager is the client. See also *server*.

**CMS**

See *call management system*.

**CNG tone**

See *calling tone*.

**CO**

See *central office*.

**COR**

See *class of restriction*.

**COS**

See *class of service*.

**code excited linear prediction (CELP)**

An analog-to-digital voice coding scheme.

**collocated**

A Lucent INTUITY system installed in the same physical location as the host switch. See also *local installation*.

**collocated adjunct**

Two or more adjuncts that are serving the same switch (that is, each has voice port connections to the switch) or that are serving different switches but can be networked through a direct RS-232 connection due to their proximity.

**comcode**

A numbering system for telecommunications equipment used by Lucent Technologies. Each comcode is a 9-digit number that represents a specific piece of hardware, software, or documentation.

**command**

An instruction or request given by the user to the software to perform a particular function. An entire command consists of the command name and options. Also, one- or two-key touch tones that control a mailbox activity or function.

**community**

A group of telephone users administered with special send and receive messaging capabilities. A community is typically comprised of people who need full access to each other by telephone on a frequent basis. See also *default community*.

**compound message**

A message that combines a voice message and a fax message into one unit, which INTUITY AUDIX then handles as a single message.

**configuration**

The particular combination of hardware and software components selected for a system, including external connections, internal options, and peripheral equipment.

**controller circuit card**

A circuit card used on a computer system that controls its basic functionality and makes the system operational. These cards are used to control magnetic peripherals, video monitors, and basic system communications.

**COS**

See *class of service*.

**coverage path**

The sequence of alternate destinations to which a call to a user on a Lucent INTUITY system is automatically sent when it is not answered by the user. This sequence is set up on the switch, normally with the Lucent INTUITY system as the last or only destination.

**CPU**

See *central processing unit*.

**cross connect**

Distribution-system equipment used to terminate and administer communication circuits.

**cross connection**

The connection of one wire to another, usually by anchoring each wire to a connecting block and then placing a third wire between them so that an electrical connection is made.

**CSI**

See *called subscriber information*.

**CTS**

See *clear to send*.

---

**D**

**DAC**

See *dial access code*.

**database**

A structured set of files, records, or tables. Also, a collection of filesystems and files in disk memory that store the voice and nonvoice (program data) necessary for Lucent INTUITY system operation.

**data communications equipment (DCE)**

Standard type of data interface normally used to connect to data terminal equipment (DTE) devices. DCE devices include the data service unit (DSU), the isolating data interface (IDI), and the modular processor data module (MPDM).

**data communications interface unit (DCIU)**

A switch device that allows nonvoice (data) communication between a Lucent INTUITY system and a Lucent switch. The DCIU is a high-speed synchronous data link that communicates with the common control switch processor over a direct memory access (DMA) channel that reads data directly from FP memory.

**data link**

A term used to describe the communications link used for data transmission from a source to a destination, for example, a telephone line for data transmission.

**data service unit (DSU)**

A device used to access digital data channels. DATAPHONE II 2500 DSUs are synchronous data communications equipment (DCE) devices used for extended-local Lucent INTUITY system connections. The 2600 or 2700 series may also be used; these support diagnostic testing and the DATAPHONE II Service network system.

**data set**

Another term for a modem, although a data set usually includes the telephone. See also *modem*.

**data terminal equipment (DTE)**

Standard type of data interface normally used for the endpoints in a connection. Normally the Lucent INTUITY system, most terminals, and the switch data link are DTE devices.

**DBP**

See *data base processor*.

**DCE**

See *data communications equipment*.

**DCIU**

See *data communications interface unit*.

**DCP**

See *digital communications protocol*.

**DCS**

See *distributed communications system*.

**debug**

See *troubleshooting*.

**dedicated line**

A communications path that does not go through a switch. A dedicated (hard-wired) path can be formed with directly connected cables. MPDMs, DSUs, or other devices can also be used to extend the distance that signals can travel directly through the building wiring.

**default**

A value that is automatically supplied by the system if no other value is specified.

**default community**

A group of telephone users administered with restrictions to prevent them from sending messages to or receiving messages from other communities. If a system is administered to use communities, the default community is comprised of all the AUDIX users defined on that system.

**default print number**

The user-administered extension to which autoprinted faxes are redirected upon their receipt into the user's mailbox. This default print destination is also provided as a print option when the user is manually retrieving and printing faxes from the mailbox.

**delivered message**

A message that has been successfully transmitted to a recipient's incoming mailbox.

**demand testing**

Testing performed on request (usually by service personnel).

**diagnostic testing**

A program run for testing and determining faults in the system.

**dial-ahead/dial-through**

The act of interrupting or preceding INTUITY AUDIX system announcements by typing (buffering) touch-tone commands in the order the system would normally prompt for them.

**dial string**

A series of numbers used to initiate a call to a remote AMIS machine. A dial string tells the switch what type of call is coming (local or long distance) and gives the switch time to obtain an outgoing port, if applicable

**dialed number identification service (\*DNIS\_SVC)**

An available channel service assignment on the Lucent INTUITY system. Assigning this service to a channel permits the Lucent INTUITY system to interpret information from the switch and operate the appropriate application for the incoming telephone call.

**DID**

See *direct inward dialing*.

**digital communications protocol (DCP)**

A 64-Kbps digital data transmission code with a 160-Kbps bipolar bit stream divided into two information (I) channels and one signaling (S) channel.

**digital networking**

A method of transferring messages between messaging systems in a digital format. See also *INTUITY AUDIX Digital Networking*.

**digital signal processor (DSP)**

A specialized digital microprocessor that performs calculations on digitized signals that were originally analog and then sends the results on.

**DIP switch**

See *dual in-line package switch*.

**direct inward dialing (DID)**

The ability for an outside caller to call an internal extension without having to pass through an operator or attendant.

**direct memory access (DMA)**

A quick method of moving data from a storage device directly to RAM, which speeds processing.

**directory**

1. A Lucent INTUITY AUDIX feature that allows you to hear a user's name and extension after pressing **\* \* N** at the activity menu. 2. A group of related files accessed by a common name in software.

**display terminal**

A data terminal with a screen and keyboard used for displaying Lucent INTUITY screens and performing maintenance or administration activities.

**distributed communications system (DCS)**

A network of two or more switches that uses logical and physical data links to provide full or partial feature transparency. Voice links are made using tie trunks.

**distribution list**

See *mailing list*.

**DMA**

See *direct memory access*.

**DNIS**

See *dialed number identification service*.

**domain**

An area where data processing resources are under common control. The INTUITY AUDIX system is one domain and an e-mail system is another domain.

**DSP**

See *digital signal processor*.

**DSU**

See *data service unit*.

**DTE**

See *data terminal equipment*.

**DTMF**

See *dual tone multifrequency*.

**dual in-line package (DIP) switch**

A small switch, usually attached to a printed circuit card, in which there are only two settings: on or off (or 0 or 1). DIP switches are used to configure the card in a semipermanent way.

### **dual language greetings**

The capability of INTUITY AUDIX users to create personal greetings in two different languages—one in a primary language and one in a secondary language. This capability exists when the multilingual feature is turned on and the prompts for user mailboxes can be in either of the two languages.

### **dual tone multifrequency (DTMF)**

A way of signaling consisting of a pushbutton or touch-tone dial that sends out a sound consisting of two discrete tones that can be picked up and interpreted by telephone switches.

---

## **E**

### **EIA interface**

A set of standards developed by the Electrical Industries Association (EIA) that specifies various electrical and mechanical characteristics for interfaces between electronic devices such as computers, terminals, and modems. Also known as *RS-232*.

### **ELA**

Enhanced-List Application

### **electrostatic discharge (ESD)**

Discharge of a static charge on a surface or body through a conductive path to ground. ESD can be damaging to integrated circuits.

### **electronic mail**

See *e-mail*.

### **electrostatic discharge (ESD)**

The discharge of a static charge on a surface or body through a conductive path to ground, ESD can damage integrated circuits.

### **e-mail**

The transfer of a wide variety of message types across a computer network (LAN or WAN). E-mail messages may be text messages containing only ASCII or may be complex multimedia messages containing embedded voice messages, software files, and images.

### **enabled/disabled**

The state of a hardware device that indicates whether it is available for use by the Lucent INTUITY system. Devices must be equipped before they can be enabled (made active). See also *equipped/unequipped*.

### **endpoint**

See *fax endpoint*.

### **enhanced call transfer**

An INTUITY AUDIX feature that allows compatible switches to transmit messages digitally over the BX.25 (data) link. This feature is used for quick call transfers and requires a fully integrated digital switch. Callers can only transfer to other extensions in the switch dial plan.

### **enhanced serial data interface (ESDI)**

A software- and hardware-controlled method used to store data on magnetic peripherals.

### **equipped/unequipped**

The state of a networking channel that indicates whether Lucent INTUITY software has recognized it. Devices must be equipped before they can be enabled (made active). See also *enabled/disabled*.

**error message**

A message on the screen indicating that something is wrong and possibly suggesting how to correct it.

**errors**

Problems detected by the system during operation and recorded in the maintenance log. Errors can produce an alarm if they exceed a threshold.

**escape from reply**

The ability to quickly return to getting messages for a user who encounters a problem trying to respond to a message. To escape, the user presses [#].

**escape to attendant**

An INTUITY AUDIX feature that allows users with the call answer feature to have a personal attendant or operator administered to pick up their unanswered calls. A system-wide extension could also be used to send callers to a live agent.

**ESD**

See *electrostatic discharge*.

**ESDI**

See *enhanced serial data interface*.

**event**

An informational messages about the system's activities. For example, an event is logged when the system is rebooted. Events may or may not be related to errors and alarms.

---

## F

**facilities restriction level (FRL)**

A value that determines which types of calls the users of a switch are allowed to make.

**facility out-of-service (FOOS)**

State of operation during which the current channel is not receiving a dial tone and is not functioning.

**facsimile**

1. A digitized version of written, typed, or drawn material transmitted over telephone lines and printed out elsewhere. 2. Computer-generated text or graphics transmitted over computer networks. A computer-generated fax is typically printed to a fax machine, but can remain stored electronically.

**fax**

See *facsimile*.

**fax addressing prefix**

Uniquely identifies a particular fax nodepoint to the Lucent INTUITY system. Used by the system as a "template" to differentiate all call-delivery machines on the network from each other.

**fax endpoint**

Any device capable of receiving fax calls. Fax endpoints include fax machines, individual PC fax modems, fax ports on LAN fax servers, and ports on fax-enabled messaging systems.

**fax print destination prefix**

A dial string that the Lucent INTUITY system adds to the fax telephone number the user enters to print a fax. The system takes the full number (fax print destination prefix + fax telephone extension) and hunts through the machine translation numbers until it finds the specific fax endpoint.

**field**

An area on a screen, menu, or report where information can be typed or displayed.

**FIFO**

See *first-in/first-out*.

**file**

A collection of data treated as a basic unit of storage.

**filename**

Alphanumeric characters used to identify a particular file.

**file redundancy**

See *mirroring*.

**file system**

A collection of related files (programs or data) stored on disk that are required to initialize a Lucent INTUITY system.

**first-in/first-out (FIFO)**

A method of processing telephone calls or data in which the first call or data to be received is the first call or data to be processed.

**F key**

See *function key*.

**FNPAC**

See *foreign numbering-plan area code*.

**FOOS**

See *facility out-of-service*.

**foreign exchange (FX)**

A central office (CO) other than the one providing local access to the public telephone network.

**foreign numbering-plan area code (FNPAC)**

An area code other than the local area code that must be dialed to call outside the local geographical area.

**format**

To set up a disk, floppy diskette, or tape with a predetermined arrangement of characters so that the system can read the information on it.

**FRL**

See *facilities restriction level*.

**function**

Individual steps or procedures within a mailbox activity.

**function key (F key)**

A key on a computer keyboard programmed to perform a defined function when pressed. The user interface for the Lucent INTUITY system defines keys F1 through F8.

**FX**

See *foreign exchange*.

---

## G

### Generic 1, 2, or 3

Lucent switch system software releases, designed for serving large communities of System 75 and System 85 users.

### generic tape

A copy of the standard software and stand-alone tape utilities that is shipped with a new Lucent INTUITY system.

### GOS

See *grade of service*.

### grade of service (GOS)

A parameter that describes the delays in accessing a port on the Lucent INTUITY system. For example, if the GOS is P05, 95% of the callers hear the system answer and 5% hear ringing until a port becomes available to answer the call.

### guaranteed fax

A feature of Lucent INTUITY FAX Messaging that temporarily stores faxes sent to a fax machine. In cases where the fax machine is busy or does not answer a call, the call is sent to an INTUITY AUDIX mailbox.

### guest password

A feature that allows callers who are not INTUITY AUDIX users to leave messages on the system by dialing a user's extension and entering a system-wide guest password.

---

## H

### hard disk drive

A high-capacity data-storage and -retrieval device that is located inside a computer. A hard disk drive stores data on nonremovable high-density magnetic media based on a predetermined format for retrieval by the system at a later date.

### hardware

The physical components of a computer system. The central processing unit, disks, tape, and floppy drives are all hardware.

### header

Information that the system creates to identify a message. A message header includes the originator or recipient, type of message, creation time, and delivery time.

### help

A command run by pressing **HELP** or **CTRL ?** on a Lucent INTUITY display terminal to show the options available at your current screen position. In the INTUITY AUDIX system, press **\* (H)** on the telephone keypad to get a list of options. See also *on-line help*.

### host switch

The switch directly connected to the Lucent INTUITY system over the data link. Also, the physical link connecting a Lucent INTUITY system to a distributed communications system (DCS) network.

**hunt group**

A group of analog ports on a switch usually administered to search for available ports in a circular pattern.

---

**I**

**I/O**

Input/output.

**IDI**

See *isolating data interface*.

**IMAPI**

See *INTUITY messaging application programming interface*.

**INADS**

See *initialization and administration system*.

**information service**

See *bulletin board*.

**initialization**

The process of bringing a system to a predetermined operational state. The start-up procedure tests hardware; loads the boot filesystem programs; locates, mounts, and opens other required filesystems; and starts normal service.

**initialization and administration system (INADS)**

A computer-aided maintenance system used by remote technicians to track alarms.

**initialize**

To start up the system for the first time.

**input**

A signal fed into a circuit or channel.

**integrated services digital network (ISDN)**

A network that provides end-to-end digital connectivity to support a wide range of voice and data services.

**integrated voice processing CELP (IVC6) card**

A computer circuit card that supports both fax processing and voice processing capabilities. It provides two analog ports to support six analog channels. All telephone calls to and from the Lucent INTUITY system are processed through the IVC6 card.

**interface**

The device or software that forms the boundary between two devices or parts of a system, allowing them to work together. See also *user interface*.

**internal e-mail**

Software on a PC that provides messaging capability between users on the same AUDIX system, or to administered remote AUDIX systems and users. Users can create, send, and receive a message that contains multiple media types; specifically, voice, fax, text, or file attachments (software files, such as a word processing or spreadsheet file).

**interrupt request (IRQ)**

Within a PC, a signal sent from a device to the CPU to temporarily suspend normal processing and transfer control to an interrupt handling routine.

**INTUITY AUDIX Digital Networking**

A Lucent INTUITY feature that allows customers to link together up to 500 remote Lucent INTUITY machines for a total of up to 500,000 remote users. See also *digital networking*.

**INTUITY Message Manager**

A Windows-based software product that allows INTUITY AUDIX users to receive, store, and send their voice/FAX messages from a PC. The software also enables users to create and send multimedia messages that include voice, fax, file attachments, and text.

**INTUITY messaging application programming interface (IMAPI)**

A software function-call interface that allows INTUITY AUDIX to interact with Lucent INTUITY Message Manager.

**IRQ**

See *interrupt request*.

**ISDN**

See *integrated services digital network*.

**isolating data interface (IDI)**

A synchronous, full duplex data device used for cable connections between a Lucent INTUITY GPSC-AT/E card and the switch data communications interface unit (DCIU).

**IVC6**

See *integrated voice processing CELP (IVC6) card*.

---

**J**

**jumper**

Pairs or sets of small prongs or pins on circuit cards and mother boards the placement of which determines the particular operation the computer selects. When two pins are covered, an electrical circuit is completed. When the jumper is uncovered, the connection is not made. The computer interprets these electrical connections as configuration information.

---

**K**

---

**L**

**label**

The name assigned to a disk device (either a removable tape cartridge or permanent drive) through software. Cartridge labels may have a generic name (such as 3.3) to show the software release, or a descriptive name if for back-up copies (such as back01). Disk drive labels usually indicate the disk position (such as disk00 or disk02).

## LAN

See *local area network*.

## last-in/first-out (LIFO)

A method of processing telephone calls or data in which the last call (or data) received is the first call (or data) to be processed.

## LCD

See *liquid crystal display*.

## leave word calling (LWC)

A switch feature that allows the calling party to leave a standard (nonvoice) message for the called party using a feature button or dial access code.

## LED

See *light emitting diode*.

## LIFO

See *last-in/first-out*.

## light emitting diode (LED)

A light on the hardware platform that shows the status of operations.

## liquid crystal display (LCD)

The 10-character alphanumeric display that shows the status of the system, including alarms.

## load

The process of reading software from external storage (such as disk) and placing a copy in system memory.

## local area network (LAN)

A network of PCs that communicate with each other and that normally share the resources of one or more servers. Operation of Lucent INTUITY Message Manager requires that the INTUITY AUDIX system and the users' PCs be on a LAN.

## local AUDIX machine

The Lucent INTUITY system where a user's INTUITY AUDIX mailbox is located. All users on this home machine are called *local users*.

## local installation

A switch, adjunct, or peripheral device installed physically near the host switch or system. See also *collocated*.

## local network

An INTUITY AUDIX Digital Network in which all Lucent INTUITY systems are connected to the same switch.

## login

A unique code a user must enter to gain approved access to the Lucent INTUITY system. See also *password*.

## login announcement

A feature enabling the system administrator and other designated users to create a mail message that is automatically played to all INTUITY AUDIX users every time they log in to the system.

## Lotus Notes

Information management software for work groups that allows individuals to share and manipulate information over a local or wide area network

## LWC

See *leave word calling*.

---

# M

## magnetic peripherals

Data storage devices that use magnetic media to store information. Such devices include hard disk drives, floppy disk drives, and cartridge tape drives.

## mailbox

A portion of disk memory allotted to each Lucent INTUITY system user for creating and storing outgoing and incoming messages.

## mailing list

A group of user addresses assigned a list ID# and public or private status. A mailing list may be used to simplify the sending of messages to several users.

## maintenance

The process of identifying system errors and correcting them, or taking steps to prevent problems from occurring.

## major alarm

An alarm detected by Lucent INTUITY software that affects at least one fourth of the Lucent INTUITY ports in service. Often a major alarm indicates that service is affected.

## MANOOS

See *manually out-of-service*.

## manually out-of-service

State of operation during which a unit has been intentionally taken out of service.

## MAP

See *multi-application platform*.

## mean time between failures

The average time a manufacturer estimates will elapse before a failure occurs in a component or system.

## media type

The form a message takes. The media types supported by the Lucent INTUITY system are voice, text, file attachments, and fax.

## memory

A device that stores logic states such that data can be accessed and retrieved. Memory may be temporary (such as system RAM) or permanent (such as disk).

## menu

A list of options displayed on a computer terminal screen or spoken by a voice processing system. Users choose the option that reflects what action they want the system to take.

## menu tree

The way in which nested automated attendants are set up.

**message categories**

Groups of messages in INTUITY AUDIX users' mailboxes. Categories include *new*, *unopened*, and *old* for the incoming mailbox and *delivered*, *accessed*, *undelivered*, *undeliverable* (not deliverable), and *file cabinet* for the outgoing mailbox.

**message component**

A media type included in a multimedia message. These types include voice, text, file attachments, and fax messages.

**message delivery**

An optional Lucent INTUITY feature that permits users to send messages to any touch-tone telephone, as long as the telephone number is in the range of allowable numbers. This feature is an extension of the AMIS analog networking feature and is automatically available when the AMIS feature is activated.

**Message Manager**

See *INTUITY Message Manager*.

**message waiting indicator (MWI)**

An indicator that alerts Lucent INTUITY users that they have received new mail messages. An MWI can be an LED or neon lamp, or an audio tone (stutter dial tone).

**message waiting lamp (MWL)**

See *message-waiting indicator*.

**migration**

An installation that moves data to the Lucent INTUITY system from another type of Lucent messaging system, for example, from AUDIX R1, DEFINITY AUDIX, or AUDIX Voice Power.

**minor alarm**

An alarm detected by maintenance software that affects less than one fourth of the Lucent INTUITY ports in service, but has exceeded error thresholds or may impact service.

**mirroring**

A Lucent INTUITY system feature that allows data from crucial filesystems to be continuously copied to back-up (mirror) filesystems while the system is running. If the system has some problem where an original filesystem cannot be used, the backup filesystem is placed in service automatically.

**ML**

MERLIN LEGEND application identifier. See *application identifier*.

**mode code**

A string of touch-tones from a MERLIN LEGEND switch. A mode code may send the INTUITY AUDIX system information such as call type, calling party, called party, and on/off signals for message waiting indicators.

**modem**

A device that converts data from a form that is compatible with data processing equipment (digital) to a form compatible with transmission facilities (analog), and vice-versa.

**modular**

A term that describes equipment made of plug-in units that can be added together to make the system larger, improve its capabilities, or expand its size.

**modular processor data module (MPDM)**

A data device that converts RS-232C or RS-449 protocol signals to digital communications protocol (DCP) used by System 75/85, Generic1, and Generic 3 switches. MPDMs can connect the Lucent INTUITY system to a switch DCIU or SCI link or connect terminals to a switch port card.

**MPDM**

See *modular processor data module*.

**MT**

Maintenance application identifier. See *application identifier*.

**MTBF**

See *mean time between failures*.

**multi-application platform (MAP)**

The computer hardware platform used by the Lucent INTUITY system.

**multilingual feature**

A feature that allows announcement sets to be active simultaneously in more than one language on the system. Mailboxes can be administered so that users can hear prompts in the language of their choice.

**MWI**

See *message waiting indicator*.

**MWL**

See *message waiting lamp*.

---

**N**

**networking**

See *INTUITY AUDIX Digital Networking*.

**networking prefix**

A set of digits that identifies a Lucent INTUITY machine.

**night attendant**

The automated attendant created on a MERLIN LEGEND switch that automatically becomes active during off-hours. The night attendant substitutes for one or more daytime attendants.

**not deliverable message**

A message that could not be delivered after a specified number of attempts. This usually means that the user's mailbox is full.

**NPA**

See *numbering plan area*.

**NT**

Networking application identifier. See *application identifier*.

**Numbering plan area**

Formal name for 3-digit telephone area codes in North America. Within an area code, no two telephone lines may have the same 7-digit phone number. The code is often designated as NXX, to indicate the three digits.

---

## O

### off-hook

See *switch hook*.

### on-hook

See *switch hook*.

### on-line help

A Lucent INTUITY system feature that provides information about user interface windows, screens, and menus by pressing a predetermined key. See also *help*.

### open systems interconnection (OSI)

An internationally accepted framework of standards for communication between systems made by different vendors.

### operating system (OS)

The set of software programs that runs the hardware and interprets software commands.

### option

A choice selected from a menu, or an argument used in a command line to specify program output by modifying the execution of a command. When you do not specify any options, the command executes according to its default options.

## OS

See *operating system*.

## OSI

See *open systems interconnection*.

### outcalling

A Lucent INTUITY system feature that allows the system to dial users' numbers to inform them they have new messages.

### outgoing mailbox

A storage area on the Lucent INTUITY system where users can keep copies of messages for future reference or action.

---

## P

### parallel transmission

The transmission of several bits of data at the same time over different wires. Parallel transmission of data is usually faster than serial transmission.

### password

1. A word or character string recognized automatically by the Lucent INTUITY system that allows a user access to his/her mailbox or a system administrator access to the system data base. 2. An alphanumeric string assigned to local and remote networked machines to identify the machines or the network. See also *login*.

### password aging

An INTUITY AUDIX feature that allows administrators to set a length of time after which a user's AUDIX password or the administrator's system password expires. The user or administrator must then change the password.

**PBX**

See *private branch exchange*.

**PC**

See *power converter*.

**PDM (processor data module)**

See *modular processor data module (MPDM)*.

**peripheral device**

Equipment such as a printer or terminal that is external to the Lucent INTUITY cabinet but necessary for full operation and maintenance of the system. Also called a *peripheral*.

**personal directory**

An INTUITY AUDIX feature that allows each user to create a private list of customized names.

**personal fax extension**

See *secondary extension*.

**PI**

See *processor interface*.

**PIB**

See *processor interface*.

**pinouts**

The signal description per pin number for a particular connector.

**PMS**

See *property management system*.

**port**

A connection or link between two devices that allows information to travel to a desired location. For example, a switch port connects to a Lucent INTUITY voice port to allow a caller to leave a message.

**POST**

See *power-on self test*.

**power on self test (POST)**

A set of diagnostics stored in ROM that tests components such as disk drives, keyboard, and memory each time the system is booted. If problems are identified, a message is sent to the screen.

**priority call answer**

An INTUITY AUDIX feature that allows users to designate a call answer message as a priority message. To make a message a priority message, the caller presses (2) after recording.

**priority messaging**

An INTUITY AUDIX feature that allows some users to send messages that are specially marked and preferentially presented to recipients. See also *priority outcalling*.

**priority outcalling**

An INTUITY AUDIX feature that works with the priority messaging feature by allowing the message recipient to elect to be notified by outcalling only when a priority message has been received. See also *priority messaging*.

**private branch exchange (PBX)**

An analog, digital, or electronic telephone switching system where data and voice transmissions are not confined to fixed communications paths, but are routed among available ports or channels. See also *switch*.

**private mailing list**

A list of addresses that only the Lucent INTUITY system user who owns it can access.

**private messaging**

A feature of INTUITY AUDIX that allows a user to send a message that cannot be forwarded by the recipient.

**processor data module (PDM)**

See *modular processor data module (MPDM)*.

**processor interface (PI)**

A System 75, Generic 1, Generic 3i, Generic 3s, and Generic 3vs switch data link. Also called *processor interface board (PIB)*.

**programmed function key**

See *function key*.

**property management system (PMS)**

A product used by lodging establishments to automate the management of guest records, reservations, room assignments, and billing. In an integrated PMS environment, special software links the PMS to the Lucent INTUITY Lodging system so that both systems share a common set of messages and commands.

**protocol**

A set of conventions or rules governing the format and timing of message exchanges (signals) to control data movement and the detection and possible correction of errors.

**public mailing list**

A list of addresses that any INTUITY AUDIX user can use if that user knows the owner's list ID number and extension number. Only the owner can modify a public mailing list.

**pulse-to-tone converter**

A device connected to the switch that converts signals from a rotary pulses to touch tones. This device allows callers to use rotary telephones to access options in a Lucent INTUITY user's mailbox or in an automated attendant.

---

## R

**RAM**

See *random access memory*.

**random access memory (RAM)**

The memory used in most computers to store the results of ongoing work and to provide space to store the operating system and applications that are actually running at any given moment.

**read-only memory (ROM)**

A form of computer memory that allows values to be stored only once; after the data is initially recorded, the computer can only read the contents. ROM is used to supply constant code elements such as bootstrap loaders, network addresses, and other more or less unvarying programs or instructions.

**reboot**

See *boot*.

**remote access**

Sending and receiving data to and from a computer or controlling a computer with terminals or PCs connected through communications (that is, telephone) links.

**remote installation**

A system, site, or piece of peripheral equipment that is installed in a different location from the host switch or system.

**remote maintenance**

The ability of Lucent personnel to interact with a remote computer through a telephone line or LAN connection to perform diagnostics and some system repairs. See also *remote service center*.

**remote network**

A network in which the systems are integrated with more than one switch.

**remote service center**

A Lucent or Lucent-certified organization that provides remote support to Lucent INTUITY customers. Depending upon the terms of the maintenance contract, your remote service center may be notified of all major and minor alarms and have the ability to remotely log in to your system and remedy problems. See also *remote maintenance*.

**remote terminal**

A terminal connected to a computer over a telephone line.

**remote users**

INTUITY AUDIX users whose mailboxes reside on a remote INTUITY AUDIX Digital Networking machine.

**REN**

See *ringer equivalence number*.

**reply loop escape**

An INTUITY AUDIX feature that allows a user the option of continuing to respond to a message after trying to reply to a nonuser message.

**reply to sender**

An INTUITY AUDIX feature that allows users to immediately place a call to the originator of an incoming message if that person is in the switch's dial plan.

**request to send (RTS)**

One of the control signals on an EIA-232 connector that places the modem in the originate mode so that it can begin to send.

**restart**

1. A Lucent INTUITY feature that allows INTUITY AUDIX users who have reached the system through the call answer feature to access their own mailboxes by entering the **\*R** (Restart) command. This feature is especially useful for long-distance calls or for users who want to access the Lucent INTUITY system when all the ports are busy. 2. The reinitialization of certain software, for example, *restarting* the messaging system.

**restore**

The process of recovering lost or damaged files by retrieving them from available back-up tapes, floppy diskette, or another disk device.

**retention time**

The amount of time messages are saved on disk before being automatically deleted from a user's mailbox.

**reusable upgrade kit (RUK)**

A package shipped to the customer's site prior to an upgrade that contains materials the technician needs to complete the installation. This package includes an A/B switch box, a keyboard, a 25-foot coaxial cable, two T adapters, and terminations to a LAN circuit card. It remains the property of Lucent once the installation is finished.

**right-to-use (RTU) fee**

A charge to the customer to access certain functions or capacities that are otherwise restricted, for example, additional voice or networking ports or hours of speech storage. Lucent personnel can update RTU parameters either at the customer's site or remotely via a modem.

**ringer equivalence number (REN)**

A number required in the United States for registering your telephone equipment with a service provider.

**ROM**

See *read-only memory*.

**RS-232**

See *EIA interface*.

**RTS**

See *request to send*.

**RUK**

See *reusable upgrade kit*.

---

**S**

**SCA**

See *switch communications adapter*.

**scan**

To automatically play mail messages, headers, or both.

**scheduled delivery time**

A time and/or date that an INTUITY AUDIX user can assign to a message that tells the system when to deliver it. If a delivery time is omitted, the system sends the message immediately.

**screen**

That portion of the Lucent INTUITY user interface through which most administrative tasks are performed. Lucent INTUITY screens request user input in the form of a command from the `enter` command: prompt.

**SCSI**

See *small computer system interface*.

**secondary extension**

A second, fax-dedicated extension that directs incoming faxes directly into a user's mailbox without ringing the telephone. The secondary extension shares the same mailbox as the voice extension, but acts like a fax machine. Also called *personal fax extension*.

**serial transmission**

The transmission of one bit at a time over a single wire.

**server**

A computer that processes and stores data that is used by other smaller computers. For Lucent INTUITY Message Manager, INTUITY AUDIX is the server. See also *client*.

**shielded cables**

Cables that are protected from interference with metallic braid or foil.

**SID**

See *switch integration device*.

**SIMM**

See *single in-line memory module*.

**simplified message service interface (SMSI)**

Type of data link connection to an integrated 1A ESS or 5ESS switch in the Lucent INTUITY system.

**simplified message desk interface (SMDI)**

Also known as station message desk interface. Type of data link from the central office that contains information and instructions for the Lucent INTUITY system. With SMDI, the caller need not re-enter the called number once the call terminates to the Lucent INTUITY system. See also *simplified message service interface*.

**single in-line memory module (SIMM)**

A method of containing random access memory (RAM) chips on narrow strips that attach directly to sockets on the CPU circuit card. Multiple SIMMs are sometimes installed on a single CPU circuit card.

**small computer systems interface (SCSI)**

An interface standard defining the physical, logical, and electrical connections to computer system peripherals such as tape and disk drives.

**SMDI**

See *station message desk interface*.

**SMDR**

See *station message detail recording*.

**SMSI**

See *simplified message service interface*.

**SP**

signal processor

**SSP**

scaleable signal processor

**station message desk interface (SMDI)**

See *simplified message desk interface*.

**station message detail recording**

See *call detail recording (CDR)*.

**subscriber**

A Lucent INTUITY user who has been assigned the ability to access the INTUITY AUDIX Voice Messaging system.

**surge**

A sudden rise and fall of voltage in an electrical circuit.

**surge protector**

A device that plugs into the telephone system and the commercial AC power outlet to protect the telephone system from damaging high-voltage surges.

**SW**

Switch integration application identifier. See *application identifier*.

**switch**

An automatic telephone exchange that allows the transmission of calls to and from the public telephone network. See also *private branch exchange (PBX)*.

**switched access**

A connection made from one endpoint to another through switch port cards. This allows the endpoint (such as a terminal) to be used for several applications.

**switch hook**

The device at the top of most telephones which is depressed when the handset is resting in the cradle (that is, when the telephone is *on hook*). This device is raised when the handset is picked up (that is, when the telephone is *off hook*).

**switch-hook flash**

A signaling technique in which the signal is originated by momentarily depressing the switch hook.

**switch integration**

Sharing of information between a messaging system and a switch to provide a seamless interface to callers and system users. A fully integrated INTUITY AUDIX system, for example, answers each incoming telephone call with information taken directly from the switch. Such information includes the number being called and the circumstances under which the call was sent to it, for example, covered from a busy or unanswered extension.

**switch integration device (SID)**

A combination of hardware and software that passes information from the switch to the Lucent INTUITY system thus allowing it to share information with non-Lucent switches. The operation of a SID is unique to the particular switch with which it interfaces.

**switch network**

Two or more interconnected switching systems.

**synchronized mailbox**

A mailbox that is paired with a corresponding mailbox in another domain and linked via software that keeps track of changes to either mailbox. When the contents of one mailbox change, the software replicates that change in the other mailbox.

**synchronizer**

The name given to the trusted server by the e-mail vendor, Lotus Notes.

**synchronous communication**

A method of data transmission in which bits or characters are sent at regular time intervals, rather than being spaced by start and stop bits. See also *asynchronous communication*.

**synchronous transmission**

A type of data transmission where the data characters and bits are exchanged at a fixed rate with the transmitter and receiver synchronized. This allows greater efficiency and supports more powerful protocols.

**System 75**

An advanced digital switch manufactured by Lucent Technologies that supports up to 800 lines for voice and data communications.

**System 75**

An advanced digital switch manufactured by Lucent Technologies that supports up to 3000 lines for voice and data communications.

**system configuration**

See *configuration*.

---

## T

**T.30**

The standard for Group III fax machines that covers the protocol used to manage a fax session and negotiate the capabilities supported by each fax endpoint.

**tape cartridge**

One or more spare removable cartridges required to back up system information.

**tape drive**

The physical unit that holds, reads, and writes to magnetic tape.

**TCP/IP**

See *transmission control protocol/internet protocol*.

**TDD**

See *telecommunications device for the deaf*.

**TDM**

See *time division multiplexing*.

**telecommunications device for the deaf (TDD)**

A device with a keyboard and display unit that connects to or substitutes for a telephone. The TDD allows a deaf or hearing-impaired person to communicate over the telephone lines with other people who have TDDs. It also allows a deaf person to communicate with the INTUITY AUDIX system.

**terminal**

See *display terminal*.

**terminal type**

A number indicating the type of terminal from which a user is logging in to the Lucent INTUITY system. Terminal type is the last required entry before gaining access to the Lucent INTUITY display screens.

**terminating resistor**

A grounding resistor placed at the end of a bus, line, or cable to prevent signals from being reflected or echoed.

**time division multiplexing (TDM)**

A method of serving multiple channels simultaneously over a common transmission path by assigning the transmission path sequentially to the channels, with each assignment being for a discrete time interval.

**tip/ring**

A term used to denote the analog telecommunications interface.

**tone generator**

A device acoustically coupled to a rotary telephone used to produce touch-tone sounds.

**traffic**

The flow of attempts, calls, and messages across a telecommunications network.

**translations**

Software assignments that tell a system what to expect on a certain voice port or the data link, or how to handle incoming data. Translations customize the Lucent INTUITY system and switch features for users.

**transmission control protocol/internet protocol (TCP/IP)**

A suite of protocols that allow disparate hosts to connect over a network. Transmission control protocol (TCP) organizes data on both ends of a connection and ensures that the data that arrives matches that which was sent. Internet protocol (IP) ensures that a message passes through all the necessary routers to the proper destination.

**T/R**

See *tip/ring*.

**troubleshooting**

The process of locating and correcting errors in computer programs (also called *debugging*) or systems.

**trusted server**

A server that uses IMAPI to access an INTUITY AUDIX mailbox on behalf of a user and is empowered to do everything to a user message that INTUITY AUDIX can do.

**TTS**

Text-to-Speech

---

**U**

**UCD**

See *uniform call distribution*.

**Undelete**

An INTUITY AUDIX feature that allows users to restore the last message deleted by pressing \* .

**undelivered message**

A message that has not yet been sent to an INTUITY AUDIX user's incoming mailbox. The message resides in the sender's outgoing mailbox and may be modified or redirected by the sender.

**unequipped**

See *equipped/unequipped*.

**unfinished message**

A message that was recorded but not approved or addressed, usually as the result of an interrupted INTUITY AUDIX session. Also called *working message*.

**uniform call distribution (UCD)**

The type of call-distribution group (or hunt group) of analog port cards on some switches that connects users to the INTUITY AUDIX system. System 75, Generic 1, Generic 3, and some central office switches use UCD groups. See also *call-distribution group*.

**uninterruptable power supply (UPS)**

An auxiliary power unit that provides continuous power in cases where commercial power is lost.

**UNIX operating system**

A multi-user, multi-tasking computer operating system.

**upgrade**

An installation that moves a Lucent INTUITY system to a newer release.

**untouched message**

An INTUITY AUDIX feature that allows a user to keep a message in its current category by using the [\*] [\*] [H] (Hold) command. If the message is in the new category, message-waiting indication remains active (for example, the message-waiting lamp remains lit).

**UPS**

See *uninterruptable power supply*.

**U. S. 123**

An alternate announcement set in U. S. English whose prompts use numbers, not letters, to identify telephone keypad presses. For example, a prompt might say, "Press star three," instead of, "Press star D."

**user interface**

The devices by which users access their mailboxes, manage mailing lists, administer personal greetings, and use other messaging capabilities. Types of user interfaces include a touch-tone telephone keypad and a PC equipped with Lucent INTUITY Message Manager.

**user population**

A combination of different types of users on which Lucent INTUITY configuration guidelines are based.

---

**V**

**vector**

A customized program in the switch for processing incoming calls.

**VM**

Voice messaging application identifier. See *application identifier*.

**voice link**

The Lucent INTUITY analog connection(s) to a call-distribution group (or hunt group) of analog ports on the switch.

**voice mail**

See *voice message*.

**voice mailbox**

See *mailbox*.

**voice message**

Digitized information stored by the Lucent INTUITY system on disk memory. Also called *voice mail*.

**voice port**

The IVC6 port that provides the interface between the Lucent INTUITY system and the analog ports on the switch.

**voice terminal**

A telephone used for spoken communications with the Lucent INTUITY system. A touch-tone telephone with a message-waiting indicator is recommended for INTUITY AUDIX users.

**voicing**

1. Speaking a message into the Lucent INTUITY system during recording. 2. Having the system play back a message or prompt to a user.

**VP**

Voice platform application identifier. See *application identifier*.

**VR**

Voice response application identifier. See *application identifier*.

---

**W**

**WAN**

See *wide area network*.

**wide area network (WAN)**

A data network typically extending a local area network (LAN) over telephone lines to link with LANS in other buildings and/or geographic locations.

**window**

That portion of the Lucent INTUITY user interface through which you can view system information or status.



# Index

---

## Numerics

- 2-Gbyte tape drives
    - inserting cartridge tapes, [3-4](#)
    - jumper settings, [7-45](#)
    - removing cartridge tapes, [3-5](#)
  - 486 reset cable, [5-66](#)
  - 525-Mbyte tape drives
    - inserting cartridge tapes, [3-5](#)
    - jumper settings, [7-44](#)
    - removing cartridge tapes, [3-6](#)
- 

## A

- ACCX circuit card
  - configuration, [5-7](#)
  - function, [5-7](#)
  - I/O address, [A-6](#)
  - IRQ, [A-6](#)
  - location, [A-4](#)
  - maximum installed, [5-8](#)
  - resource options, [5-9](#)
  - switch settings, [5-9](#)
  - view, [5-8](#)
- alarm suppression
  - activating, [6-25](#), [6-32](#), [6-34](#)
  - inactivating, [6-31](#)
- AMIS analog networking, installing, [10-2](#)
- announcements
  - default set, installation, [10-4](#)
  - optional language package set, installation, [10-4](#)
  - storing during attended backup, [3-19](#)
- attended back-ups
  - backed-up data, [3-18](#)
  - procedure, [3-19](#)
  - storing
    - announcements, [3-19](#)
    - AUDIX greetings, [3-19](#)
    - AUDIX messages, [3-19](#)
    - AUDIX names, [3-19](#)
    - system data, [3-18](#)
- audits, [2-2](#)
- databases, [2-2](#)
  - mailboxes, [2-2](#), [2-6](#)
  - mailing lists, [2-3](#), [2-6](#)
  - names, [2-3](#), [2-6](#)
  - network data, [2-3](#), [2-6](#)
  - personal directories, [2-3](#), [2-6](#)
  - subscriber data, [2-4](#), [2-6](#)
- networking, [2-8](#)
  - networking database, [2-9](#)
  - platform user database, [2-10](#)

## AUDIX

- greetings, storing during attended backup, [3-19](#)
- messages, storing during attended backup, [3-19](#)
- names, storing during attended backup, [3-19](#)

AYC10, see Tip/Ring circuit card

AYC30 Tip/Ring circuit card

- switch settings, [5-26](#)
  - view, [5-22](#)
- 

## B

backplane

- installing, [7-48](#)
- location, [7-46](#)
- removing, [7-46](#)
- view, [7-46](#)

back-ups

attended

- backed-up data, [3-18](#)
- procedure, [3-19](#)
- storing

- announcements, [3-19](#)
- AUDIX greetings, [3-19](#)
- AUDIX messages, [3-19](#)
- AUDIX names, [3-19](#)
- system data, [3-18](#)

restoring

- procedure, [3-22](#)
- when to restore, [3-22](#)

unattended

- backed-up data, [3-10](#)
- stored network information, [3-11](#)
- stored voice mail information, [3-12](#)
- verifying

- using AUDIX administration screen, [3-15](#)
- using log administration menu, [3-14](#)

batteries

- installing, [7-34](#)
- removing, [7-32](#)
- safety, [7-35](#)
- view, [7-34](#)

bay assignments, [A-3](#)

busying out

- channels, [2-28](#)
  - switch links, [2-48](#)
  - Tip/Ring circuit cards, [2-62](#)
- 

## C

cartridge tape drives

- location, [A-4](#)
- SCSI ID, [A-4](#)

- cartridge tapes
  - drives
    - installing, [7-45](#)
    - jumper settings
      - 2-Gbyte, [7-45](#)
      - 525-Mbyte, [7-44](#)
    - location, [7-42](#)
    - removing, [7-43](#)
    - troubleshooting, [1-3](#)
    - types, [7-42](#)
  - formatting, [3-7](#)
  - inserting
    - into 2-Gbyte drives, [3-4](#)
    - into 525-Mbyte drives, [3-5](#)
  - managing, [3-10](#)
  - removing
    - from 2-Gbyte drives, [3-5](#)
    - from 525-Mbyte drives, [3-6](#)
  - when to change, [3-3](#)
- channels
  - busying out, [2-28](#)
  - releasing, [2-29](#)
- circuit cards
  - ACCX
    - configuration, [5-7](#)
    - function, [5-7](#)
    - I/O address, [A-6](#)
    - IRQ, [A-6](#)
    - location, [A-4](#)
    - maximum installed, [5-8](#)
    - resource options, [5-9](#)
    - switch settings, [5-9](#)
    - view, [5-8](#)
- cage
  - accessing, [4-12](#)
  - closing, [4-13](#)
  - fan
    - installing, [7-16](#)
    - location, [7-14](#)
    - removing, [7-14](#)
- DCIU interface
  - function, [5-10](#)
  - I/O address, [A-6](#)
  - IRQ, [A-6](#)
  - location, [A-4](#)
  - maximum installed, [5-10](#), [5-11](#)
  - RAM address, [A-6](#)
  - resource options, [5-10](#), [5-12](#)
  - view, [5-10](#)

- circuit cards, (cont)
  - Ethernet LAN
    - configuration, [5-13](#), [5-15](#)
    - diagnostics, [2-54](#)
    - function, [5-13](#), [5-14](#)
    - I/O address, [A-6](#)
    - installation, [5-16](#)
    - IRQ, [A-6](#)
    - jumper settings, [5-14](#)
    - location, [A-4](#)
    - RAM address, [A-6](#)
    - view, [5-13](#), [5-15](#)
  - external SCSI connector
    - function, [5-41](#)
    - location, [A-4](#)
    - maximum installed, [5-41](#)
    - resource options, [5-42](#)
    - terminating resistor
      - function, [5-42](#)
      - view, [5-42](#)
    - view, [5-42](#)
  - holding
    - large, [4-3](#)
    - small, [4-3](#)
  - installing, [5-3](#)
  - multi-port serial
    - function, [5-6](#)
    - location, [A-4](#)
    - maximum installed, [5-6](#)
    - RAM address, [A-6](#)
    - resource options, [5-7](#)
    - view, [5-7](#)
  - P5 120 MHz CPU
    - CMOS parameter settings, [5-36](#)
    - component
      - I/O addresses, [A-5](#)
      - IRQ, [A-5](#)
      - RAM addresses, [A-5](#)
    - host adapter settings
      - accessing, [5-33](#)
      - advanced configuration options, [5-35](#)
      - SCSI bus interface definitions, [5-34](#)
      - SCSI device configuration, [5-35](#)
    - installation, [5-29](#)
    - jumper settings, [5-28](#)
    - location, [A-4](#)
    - maximum installed, [5-27](#)
    - resource options, [5-27](#)

- circuit cards, (cont)
    - P5 120 MHz CPU, (cont)
      - SIMMs
        - configuration, [A-1](#)
        - description, [A-1](#)
        - identifying defective, [7-9](#)
        - installing, [7-12](#)
        - removing, [7-11](#)
      - switch settings, [5-29](#)
      - view, [5-27](#)
    - remote maintenance
      - function, [5-48](#), [5-58](#)
      - I/O address, [A-6](#)
      - IRQ, [A-6](#)
      - location, [A-4](#)
      - maximum installed, [5-48](#), [5-58](#)
      - RAM address, [A-6](#)
      - replacing, [5-53](#), [5-63](#)
      - replacing with a modem, [5-55](#)
      - resource options, [5-50](#), [5-60](#)
      - upgrading to, [5-54](#), [5-70](#)
      - view, [5-48](#), [5-58](#)
    - removing, [5-2](#)
    - speech and signal processor, [5-18](#)
    - Tip/Ring
      - AYC10
        - view, [5-23](#)
      - AYC30
        - switch settings, [5-26](#)
        - view, [5-22](#)
    - busying out, [2-62](#)
    - diagnostics, [2-59](#)
    - function, [5-24](#)
    - I/O address, [A-6](#)
    - IRQ, [A-6](#)
    - location, [A-4](#)
    - maximum installed, [5-24](#)
    - releasing, [2-63](#)
    - switch settings, [5-25](#)
  - verifying installation, [5-4](#), [5-69](#)
  - video controller
    - function, [5-43](#)
    - I/O address, [A-5](#)
    - jumper settings, [5-44](#)
    - location, [A-4](#)
    - maximum installed, [5-43](#)
    - RAM address, [A-5](#)
    - resource options, [5-44](#)
    - switch settings, [5-45](#), [5-46](#)
    - types, [5-43](#)
    - view, [5-44](#), [5-45](#), [5-46](#)
- comcodes, [B-1](#)

configuration

- assignment rules, [A-5](#)
- bay assignments, [A-3](#)
- resource allocation, [A-5](#)
- slot assignments, [A-4](#)

connectivity testing, [2-53](#)

connectors, [5-67](#)

- see also fan status connector
- see also platform reset output
- see also UPS connector

CPU, see P5 120 MHz CPU circuit card

---

## D

database audits

- mailboxes, [2-2](#), [2-6](#)
- mailing lists, [2-3](#), [2-6](#)
- names, [2-3](#), [2-6](#)
- network data, [2-3](#), [2-6](#)
- networking, [2-9](#)
- personal directories, [2-3](#), [2-6](#)
- platform user, [2-10](#)
- subscriber data, [2-4](#), [2-6](#)

date

- acknowledging changes, [3-33](#)
- changing, [3-31](#)
- checking, [3-30](#)

DCIU

- circuit card, diagnostics, [2-44](#)
- interface circuit card
  - function, [5-10](#)
  - I/O address, [A-6](#)
  - IRQ, [A-6](#)
  - location, [A-4](#)
  - maximum installed, [5-10](#), [5-11](#)
  - RAM address, [A-6](#)
  - resource options, [5-10](#), [5-12](#)
  - view, [5-10](#)

- link troubleshooting, [1-4](#)

DCS AUDIX, troubleshooting, [1-6](#)

diagnostics

- Ethernet LAN circuit card, [2-54](#)
- INTUITY AUDIX Digital Networking, [2-16](#)

network connection tests

- channel internal loop-around test, [2-20](#)
- modem loop-around test, [2-22](#)
- network loop-around test, [2-23](#)

networking

- board resetting, [2-27](#)
- busying out channels, [2-28](#)
- releasing channels, [2-29](#)

- remote connection test, [2-16](#)

- diagnostics, (cont)
  - multi-port serial circuit card
    - accessing, [2-31](#)
    - board status, [2-33](#)
    - driver status, [2-32](#)
    - port status, [2-34](#)
    - register dump, [2-36](#)
    - serial port tests
      - external loopback, [2-37](#)
      - internal loopback, [2-37](#)
      - send, [2-40](#)
    - termio, [2-35](#)
  - switch integration
    - circuit card, [2-44](#)
    - viewing link status, [2-42](#)
  - TCP/IP, [2-50](#)
  - Tip/Ring circuit card, [2-59](#)
- digital networking
  - diagnostics, [2-16](#)
    - network connection tests
      - channel internal loop-around test, [2-20](#)
      - modem loop-around test, [2-22](#)
      - network loop-around test, [2-23](#)
  - networking
    - board resetting, [2-27](#)
    - busyng out channels, [2-28](#)
    - releasing channels, [2-29](#)
  - remote connection test, [2-16](#)
  - software, installing, [10-2](#)
- diskette drive
  - I/O address, [A-6](#)
  - installing, [7-25](#)
  - IRQ, [A-6](#)
  - jumper settings, [7-25](#)
  - location, [7-21](#), [A-4](#)
  - PCBA adapter, [7-23](#)
  - RAM address, [A-6](#)
  - removing, [7-22](#)
  - size, [7-21](#)
  - types, [7-25](#)
  - view, [7-24](#)
- diskettes, [3-8](#)
  - formatting, [3-9](#)
  - inserting, [3-8](#)
  - removing, [3-8](#)
  - types, [3-8](#)
- doors
  - removing, [4-7](#)
  - replacing, [4-14](#)
- dress covers
  - removing, [4-8](#)
  - replacing, [4-14](#)

drives

cartridge tape

2-Gbyte

inserting tapes, [3-4](#)

jumper settings, [7-45](#)

removing tapes, [3-5](#)

525-Mbyte

inserting tapes, [3-5](#)

jumper settings, [7-44](#)

removing tapes, [3-6](#)

installing, [7-45](#)

location, [7-42](#), [A-4](#)

removing, [7-43](#)

SCSI ID, [A-4](#)

troubleshooting, [1-3](#)

types, [7-42](#)

diskette

I/O address, [A-6](#)

installing, [7-25](#)

IRQ, [A-6](#)

jumper settings, [7-25](#)

location, [7-21](#), [A-4](#)

PCBA adapter, [7-23](#)

RAM address, [A-6](#)

removing, [7-22](#)

size, [7-21](#)

types, [7-25](#)

view, [7-24](#)

hard disk

adding, [6-38](#)

audfs

location, [A-3](#)

SCSI ID, [A-3](#)

audfs disk

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-4](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

replacing, [6-32](#), [6-34](#)

cleaning, [6-41](#)

connecting, [6-21](#)

drives, hard disk, (cont)

Drive 0

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-3](#)

jumper settings, [6-12](#), [6-15](#), [6-18](#)

location, [A-3](#)

replacing

mirrored system, [6-25](#)

nonmirrored system, [6-8](#)

SCSI ID, [A-3](#)

Drive 1

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

location, [A-4](#)

replacing, [6-32](#), [6-34](#)

SCSI ID, [A-4](#)

Drive 2

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

location, [A-4](#)

replacing, [6-32](#), [6-34](#)

SCSI ID, [A-4](#)

drives, hard disk, (cont)

Drive 4

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-14](#), [6-17](#), [6-20](#)

location, [A-3](#)

replacing, [6-32](#), [6-34](#)

SCSI ID, [A-3](#)

Drive 5

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-14](#), [6-17](#), [6-20](#)

location, [A-4](#)

replacing, [6-32](#), [6-34](#)

SCSI ID, [A-4](#)

initializing, [6-28](#)

jumper locations, [6-12](#), [6-15](#), [6-18](#)

mounting, [6-21](#)

preparing, [6-11](#)

removing, [6-9](#)

view, [6-10](#)

dual/redundant power supplies, [5-68](#)

---

## E

electromagnetic interference, see "EMI reduction components"

electrostatic discharge

protecting against damage from, [4-2](#)

sensitive area of electronic components, [4-4](#)

warning symbol, [4-2](#)

Ethernet LAN circuit card

configuration, [5-13](#), [5-15](#)

diagnostics, [2-54](#)

function, [5-13](#), [5-14](#)

I/O address, [A-6](#)

installation, [5-16](#)

IRQ, [A-6](#)

jumper settings, [5-14](#)

location, [A-4](#)

RAM address, [A-6](#)

view, [5-13](#), [5-15](#)

external SCSI connector circuit card

- function, [5-41](#)
  - location, [A-4](#)
  - maximum installed, [5-41](#)
  - resource options, [5-42](#)
  - terminating resistor
    - function, [5-42](#)
    - view, [5-42](#)
  - view, [5-42](#)
- 

## F

fan filters

- cleaning, [7-13](#)
- location, [7-13](#)
- removing, [7-13](#)

fans

- circuit card cage
  - installing, [7-16](#)
  - location, [7-14](#)
  - removing, [7-14](#)
- peripheral bay
  - installing, [7-19](#)
  - location, [7-17](#)
  - removing, [7-19](#)
- power supply, [7-14](#)

fax messaging, installing, [10-2](#)

floppy disks, see diskettes

formatting

- cartridge tapes, [3-7](#)
  - diskettes, [3-9](#)
- 

## G

Glossary, [GL-1](#)

greetings, storing during attended backup, [3-19](#)

---

## H

hard disk drives

adding, [6-38](#)

audfs disk

contents

- mirrored system, [6-3](#)
- nonmirrored system, [6-2](#)

identifying failure

- mirrored system, [6-7](#)
- nonmirrored system, [6-4](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

replacing, [6-32](#), [6-34](#)

hard disk drives, (cont)

cleaning, [6-41](#)

connecting, [6-21](#)

Drive 0

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-3](#)

jumper settings, [6-12](#), [6-15](#), [6-18](#)

replacing

mirrored system, [6-25](#)

nonmirrored system, [6-8](#)

Drive 1

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

replacing, [6-32](#), [6-34](#)

Drive 2

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-13](#), [6-16](#), [6-19](#)

replacing, [6-32](#), [6-34](#)

Drive 4

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-14](#), [6-17](#), [6-20](#)

replacing, [6-32](#), [6-34](#)

hard disk drives, (cont)

Drive 5

contents

mirrored system, [6-3](#)

nonmirrored system, [6-2](#)

identifying failure

mirrored system, [6-7](#)

nonmirrored system, [6-7](#)

jumper settings, [6-14](#), [6-17](#), [6-20](#)

replacing, [6-32](#), [6-34](#)

initializing, [6-28](#)

jumper locations, [6-12](#), [6-15](#), [6-18](#)

mounting, [6-21](#)

preparing, [6-11](#)

removing, [6-9](#)

view, [6-10](#)

---

I

IMAPI, installing, [10-2](#)

internal UPS, [5-68](#)

IVC6, see Tip/Ring circuit card

---

L

LAN circuit card, see Ethernet LAN circuit card

Lodging software, installing, [11-5](#)

Lucent Intuity system

date

acknowledging changes, [3-33](#)

changing, [3-31](#)

checking, [3-30](#)

rebooting

cold, [3-29](#)

warm, [3-28](#)

shutting down, [3-27](#)

time

acknowledging changes, [3-33](#)

changing, [3-32](#)

checking, [3-30](#)

---

M

mailboxes, auditing, [2-2](#), [2-6](#)

mailing lists, auditing, [2-3](#), [2-6](#)

memory

amount, [A-1](#)

modules, see SIMMs

troubleshooting, [1-10](#)

Message Manager, installing, [10-2](#)

- messages, storing during attended backup, [3-19](#)
  - modems
    - replacing a remote maintenance circuit card with, [5-55](#)
    - replacing with a remote maintenance circuit card, [5-54](#), [5-70](#)
    - troubleshooting, [1-2](#)
  - multi-port serial circuit card
    - diagnostics
      - accessing, [2-31](#)
      - board status, [2-33](#)
      - driver status, [2-32](#)
      - port status, [2-34](#)
      - register dump, [2-36](#)
      - serial port tests
        - external loopback, [2-37](#)
        - internal loopback, [2-37](#)
        - send, [2-40](#)
    - termio, [2-35](#)
    - function, [5-6](#)
    - location, [A-4](#)
    - maximum installed, [5-6](#)
    - RAM address, [A-6](#)
    - resource options, [5-7](#)
    - view, [5-7](#)
  - Multi-User software, installing, [11-2](#)
- 

## N

- names
    - auditing, [2-3](#), [2-6](#)
    - storing during attended backup, [3-19](#)
  - network
    - connection tests
      - channel internal loop-around test, [2-20](#)
      - modem loop-around test, [2-22](#)
      - network loop-around test, [2-23](#)
    - data auditing, [2-3](#), [2-6](#)
    - information stored during unattended backup, [3-11](#)
  - networking
    - AMIS analog, installing, [10-2](#)
    - auditing, [2-8](#)
    - board resetting, [2-27](#)
    - channels
      - busyng out, [2-28](#)
      - releasing, [2-29](#)
    - database auditing, [2-9](#)
    - digital, software installing, [10-2](#)
  - NGTR, see AYC30 Tip/Ring circuit card
- 

## O

- optional features, troubleshooting, [1-9](#)
- ordering numbers, [B-1](#)
- outcalling, troubleshooting, [1-7](#)

## P

### P5 120 MHz CPU circuit card

CMOS parameter settings, [5-36](#)

component

I/O addresses, [A-5](#)

IRQ, [A-5](#)

host adapter settings

accessing, [5-33](#)

advanced configuration options, [5-35](#)

SCSI bus interface definitions, [5-34](#)

SCSI device configuration, [5-35](#)

installation, [5-29](#)

jumper settings, [5-28](#)

location, [A-4](#)

maximum installed, [5-27](#)

RAM addresses, [A-5](#)

resource options, [5-27](#)

SIMMs

configuration, [A-1](#)

description, [A-1](#)

identifying defective, [7-9](#)

installing, [7-12](#)

removing, [7-11](#)

switch settings, [5-29](#)

view, [5-27](#)

peripheral bay

accessing, [4-9](#)

closing, [4-13](#)

fan

installing, [7-19](#)

location, [7-17](#)

removing, [7-19](#)

personal directories, auditing, [2-3](#), [2-6](#)

platform user database, auditing, [2-10](#)

power

connections, [4-5](#)

removing, [4-5](#)

restoring, [4-15](#)

switch, [4-6](#)

power supplies

fan, [7-14](#)

size, [7-29](#)

with battery backup

cable receptacles, [7-31](#)

installing, [7-31](#)

removing, [7-29](#)

view, [7-29](#)

with redundant supply

adding, [7-40](#)

installing, [7-39](#)

---

## R

- rebooting
    - cold, [3-29](#)
    - troubleshooting, [1-8](#)
    - warm, [3-28](#)
  - releasing
    - channels, [2-29](#)
    - switch links, [2-49](#)
    - Tip/Ring circuit cards, [2-63](#)
  - remote
    - connection test, [2-16](#)
    - field update, see RFUs
    - maintenance circuit card
      - function, [5-48](#), [5-58](#)
      - I/O address, [A-6](#)
      - IRQ, [A-6](#)
      - location, [A-4](#)
      - maximum installed, [5-48](#), [5-58](#)
      - RAM address, [A-6](#)
      - replacing, [5-53](#), [5-63](#)
      - replacing with a modem, [5-55](#)
      - resource options, [5-50](#), [5-60](#)
      - upgrading to, [5-54](#), [5-70](#)
      - view, [5-48](#), [5-58](#)
  - reset cable, [5-66](#)
  - resource allocation, [A-5](#)
  - restoring back-ups
    - procedure, [3-22](#)
    - when to restore, [3-22](#)
  - RFUs
    - installing, [12-4](#)
    - removing existing, [12-2](#)
    - verifying, [12-6](#)
  - RMB, see remote maintenance circuit card
- 

## S

- SCSI
  - external connector card, see external SCSI connector card
- shutting down the system, [3-27](#)
- SIMMs
  - description, [A-1](#)
  - identifying defective, [7-9](#)
  - installing, [7-12](#)
  - removing, [7-11](#)
  - view, [7-9](#)
- SIPs, terminator, replacing, [7-50](#)
- slot assignments, [A-4](#)

software

AMIS analog networking, installing, [10-2](#)

announcements

default set, installation, [10-4](#)

optional language package set, installation, [10-4](#)

digital networking, installing, [10-2](#)

fax messaging, installing, [10-2](#)

IMAPI, installing, [10-2](#)

Lodging, installing, [11-5](#)

Message Manager, installing, [10-2](#)

RFUs

installing, [12-4](#)

removing existing, [12-2](#)

verifying, [12-6](#)

UNIX Multi-User, installing, [11-2](#)

speech and signal processor circuit card, [5-18](#)

SSP circuit card, see speech and signal processor circuit card

subscriber data, auditing, [2-4](#), [2-6](#)

switches

DCIU circuit card diagnostics, [2-44](#)

integration diagnostics, [2-42](#)

links

busyng out, [2-48](#)

determining DCIU switches status, [2-43](#)

determining level status, [2-43](#)

determining speed, [2-43](#)

determining state, [2-43](#)

determining type, [2-43](#)

releasing, [2-49](#)

status, [2-42](#)

system

data, storing during attended backup, [3-18](#)

date

acknowledging changes, [3-33](#)

changing, [3-31](#)

checking, [3-30](#)

rebooting

cold, [3-29](#)

warm, [3-28](#)

shutting down, [3-27](#)

time

acknowledging changes, [3-33](#)

changing, [3-32](#)

checking, [3-30](#)

## T

### tapes

- formatting, [3-7](#)
- inserting
  - into 2-Gbyte drives, [3-4](#)
  - into 525-Mbyte drives, [3-5](#)
- managing, [3-10](#)
- removing
  - from 2-Gbyte drives, [3-5](#)
  - from 525-Mbyte drives, [3-6](#)
- when to change, [3-3](#)

### TCP/IP

- diagnostics, [2-50](#)
- software testing, [2-50](#)

### TDM bus, [7-50](#)

terminal, troubleshooting, [1-11](#)

terminator SIPs, replacing, [7-50](#)

### tests

- channel internal loop-around, [2-20](#)
- connectivity, [2-53](#)
- multi-port serial circuit card
  - serial port
    - external loopback, [2-37](#)
    - internal loopback, [2-37](#)
    - send, [2-40](#)
- network connection
  - modem loop, [2-22](#)
  - network loop-around, [2-23](#)
- remote connection, [2-16](#)
- TCP/IP software, [2-50](#)

### time

- acknowledging changes, [3-33](#)
- changing, [3-32](#)
- checking, [3-30](#)

### Tip/Ring circuit card

- AYC10
  - view, [5-23](#)
- AYC30
  - switch settings, [5-26](#)
  - view, [5-22](#)
- busyng out, [2-62](#)
- diagnostics, [2-59](#)
- function, [5-24](#)
- I/O address, [A-6](#)
- IRQ, [A-6](#)
- location, [A-4](#)
- maximum installed, [5-24](#)
- releasing, [2-63](#)
- switch settings, [5-25](#)

Tip/Ring distribution hardware

- capacity, [8-2](#)
- function, [8-2](#)
- with 356B adapter
  - components, [8-2](#)
  - connecting, [8-9](#)
  - installing, [8-7](#)
  - view, [8-3](#)
- without 356B adapter
  - components, [8-4](#)
  - connecting, [8-12](#)
  - installing, [8-10](#)
  - view, [8-5](#)

Tip/Ring distribution panel, see Tip/Ring distribution hardware without 356B adapter

troubleshooting

- DCIU link, [1-4](#)
  - DCS AUDIX, [1-6](#)
  - memory, [1-10](#)
  - modems, [1-2](#)
  - optional features, [1-9](#)
  - outcalling, [1-7](#)
  - rebooting, [1-8](#)
  - tape drives, [1-3](#)
  - terminal, [1-11](#)
  - voice ports, [1-5](#), [1-7](#)
- 

## U

unattended back-ups

- backed-up data, [3-10](#)
- stored network information, [3-11](#)
- stored voice mail information, [3-12](#)
- verifying
  - using AUDIX administration screen, [3-15](#)
  - using log administration menu, [3-14](#)

UNIX Multi-User software, installing, [11-2](#)

UPS cable, [5-66](#)

UPS monitoring cable, [5-68](#)

---

## V

video controller circuit card

- function, [5-43](#)
- I/O address, [A-5](#)
- jumper settings, [5-44](#)
- location, [A-4](#)
- maximum installed, [5-43](#)
- RAM address, [A-5](#)
- resource options, [5-44](#)
- switch settings, [5-45](#), [5-46](#)
- types, [5-43](#)
- view, [5-44](#), [5-45](#), [5-46](#)

voice

card, see Tip/Ring circuit card

mail, information stored during unattended backup, [3-12](#)

ports, troubleshooting, [1-5](#)

system

starting, [3-25](#)

stopping, [3-26](#)

voice ports, troubleshooting, [1-7](#)