



Nortel Networks Multiservice Switch 7400/15000/20000

Commands Reference

Document status: Standard
Document issue: sPCR6.1S1
Document date: February 2005
Product release: sPCR6.1
Job function: Basics
Type: NTP
Language type: U.S. English

Copyright © 2005 Nortel Networks.
All Rights Reserved.

NORTEL, NORTEL NETWORKS, the globemark design, and the NORTEL NETWORKS corporate logo are trademarks of Nortel Networks.

Contents

About this document	13
Who should read this document and why	13
What you need to know	13
What's new in this document	14
PVG - Customer Accessible PING	14
Text conventions	14
Entering commands	15
Abbreviations	16
Keyboard shortcuts	17
Command wildcarding	18
Type wildcarding	18
Instance wildcarding	18
Command categories	20
How to get more help	23
Command reference	24
Creating a valid command	24
Activate Prov command	25
Properties for activate Prov	25
Syntax for activate Prov	26
Parameters for activate Prov	26
Examples for activate Prov	28
Related information for activate Prov	30
Add command	31
Properties for add	31
Syntax for add	31
Parameters for add	32
Examples for add	32
Related information for add	33
Apply Prov command	34
Properties for apply Prov	34
Syntax for apply Prov	34
Parameters for apply Prov	35
Examples for apply Prov	35

- Related information for apply Prov 36
- Cancel command 38
 - Properties for cancel 38
 - Syntax for cancel 39
 - Canceling a command example 39
 - Related information for cancel 39
- Chdir Fs command 40
 - Properties for chdir Fs 40
 - Syntax for chdir Fs 40
 - New working directory parameter for chdir Fs 40
 - Changing the current working directory example 41
 - Related information for chdir Fs 41
- Check Prov command 42
 - Properties for check Prov 42
 - Syntax for check Prov 42
 - Parameters for check Prov 43
 - Examples for check Prov 44
 - Related information for check Prov 47
- Clear -notificationId(<id>) -comment(<text>) aaserv command 48
 - Properties for clear -notificationId(<id>) -comment(<text>) aaserv 48
 - Syntax for clear -notificationId(<id>) -comment(<text>) aaserv 48
 - Examples of the clear -notificationId(<id>) -comment(<text>) aaserv command 49
 - Related information for clear -notificationId(<id>) -comment(<text>) aaserv 50
- Clear Aps command on Multiservice Switch 7400 51
 - Properties for clear Aps 51
 - Syntax for clear Aps 51
 - Component instance parameter for clear Aps 52
 - Clearing APS overrides example 52
 - Related information for clear Aps 52
- Clear Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 53
 - Properties for clear Laps 53
 - Syntax for clear Laps 53
 - Component instance parameter for clear Laps 54
 - Clearing LAPS overrides example 54
 - Related information for clear Laps 54
- Clear Nmis <interface> Session command 55
 - Properties for clear Nmis <interface> Session 55
 - Syntax for clear Nmis <interface> Session 55
 - Session parameters for clear Nmis <interface> Session 56
 - Clearing a session example 56
 - Related information for clear Nmis <interface> Session 57
- Clear Prov command 58

- Properties for clear Prov 58
- Syntax for clear Prov 58
- Deleting the components of a removed feature parameter for clear Prov 59
- Examples for clear Prov 59
- Related information for clear Prov 60
- Commit Prov command 61
 - Properties for commit Prov 61
 - Syntax for commit Prov 62
 - Parameters for commit Prov 62
 - Examples for commit Prov 62
 - Related information for commit Prov 63
- Confirm Prov command 64
 - Properties for confirm Prov 64
 - Syntax for confirm Prov 64
 - Confirming the activation of a new view into the current view example 65
 - Related information for confirm Prov 65
- Continue Prov command 66
 - Properties for continue Prov 66
 - Syntax for continue Prov 66
 - Force parameter for continue Prov 66
 - Examples for continue Prov 66
 - Related information for continue Prov 67
- Copy Fs command 68
 - Properties for copy Fs 68
 - Syntax for copy Fs 68
 - Parameters for copy Fs 69
 - Examples for copy Fs 70
 - Related information for copy Fs 70
- Copy Prov command 72
 - Properties for copy Prov 72
 - Syntax for copy Prov 72
 - Parameters for copy Prov 73
 - Examples for copy Prov 74
 - Related information for copy Prov 76
- Delete command 77
 - Properties for delete 77
 - Syntax for delete 78
 - Examples for delete 78
 - Related information for delete 78
- Display command 80
 - Properties for display 80
 - Syntax for display 81
 - Parameters for display 81

- Examples for display 84
- Related information for display 90
- End Prov command 91
 - Properties for end Prov 91
 - Syntax for end Prov 91
 - Exiting the provisioning mode example 91
 - Related information for end Prov 92
- Find command 93
 - Properties for find 93
 - Syntax for find 93
 - Parameters for find 94
 - Examples for find 95
 - Related information for find 96
- Format Fs Disk command 97
 - Properties for format Fs Disk 97
 - Syntax for format Fs Disk 97
 - Parameters for format Fs Disk 98
 - Examples for format Fs Disk 99
 - Related information for format Fs Disk 99
- Help command 100
 - Properties for help 100
 - Syntax for help 100
 - Parameters for help 101
 - Examples for help 103
 - Related information for help 106
- Install command 107
 - Properties for install 107
 - Syntax for install 107
 - Parameters for install 108
 - Examples for install 108
 - Related information for install 109
- List command 110
 - Properties for list 110
 - Syntax for list 110
 - Parameters for list 111
 - Examples for list 113
 - Related information for list 116
- ListFile Fs command 117
 - Properties for listFile Fs 117
 - Syntax for listFile Fs 117
 - Parameters for listFile Fs 118
 - Examples for listFile Fs 119
 - Related information for listFile Fs 120

- Load Prov command 121
 - Properties for load Prov 121
 - Syntax for load Prov 121
 - Parameters for load Prov 121
 - Examples for load Prov 122
 - Related information for load Prov 123
- Lock command 124
 - Properties for lock 124
 - Syntax for lock 125
 - Parameters for lock 125
 - Examples for lock 126
 - Related information for lock 127
- Logout command 128
 - Properties for logout 128
 - Syntax for logout 128
 - Ending your session example 129
 - Related information for logout 129
- MakeDirectory Fs command 130
 - Properties for makeDirectory Fs 130
 - Syntax for makeDirectory Fs 130
 - New directory parameter for makeDirectory Fs 130
 - Creating a new directory example 131
 - Related information for makeDirectory Fs 131
- Me command 132
 - Properties for me 132
 - Syntax for me 132
 - Displaying information about current session example 132
 - Related information for me 133
- Move Fs command 134
 - Properties for move Fs 134
 - Syntax for move Fs 134
 - Source and destination parameters for move Fs 135
 - Examples for move Fs 135
 - Related information for move Fs 136
- Newfile Col Sp command 137
 - Properties for newfile Col Sp 137
 - Syntax for newfile Col Sp 137
 - Data type parameter for newfile Col Sp 137
 - Creating a new spooling file example 138
- Optimize command 139
 - Syntax for optimize 140
 - Examples for optimize 141
 - Related information for optimize 144

- Ping -ip(<address>) <component> command 145
 - Properties for Ping -ip(<address>) <component> 146
 - Syntax for Ping -ip(<address>) <component> 146
 - Parameters for Ping -ip(<address>) <component> 146
 - Examples for Ping -ip(<address>) <component> 147
- Ping <connection> Vc command 149
 - Properties for ping <connection> Vc 150
 - Syntax for ping <connection> Vc 150
 - Parameters for ping <connection> Vc 150
 - Examples for ping <connection> Vc 152
 - Related information for ping <connection> Vc 153
- Ping Rtg Dpn <node> command 154
 - Properties for ping Rtg Dpn <node> 155
 - Syntax for ping Rtg Dpn <node> 155
 - Parameters for ping Rtg Dpn <node> 155
 - Examples for ping Rtg Dpn <node> 158
 - Related information for ping Rtg Dpn <node> 159
- Protect Fs command 160
 - Properties for protect Fs 160
 - Syntax for protect Fs 160
 - File to protect parameter for protect Fs 160
 - Protecting a file example 161
 - Related information for protect Fs 161
- ProtectionLockout Aps command on Multiservice Switch 7400 162
 - Properties for protectionLockout Aps 162
 - Syntax for protectionLockout Aps 162
 - Component instance parameter for protectionLockout Aps 163
 - Examples for protectionLockout Aps 163
 - Related information for protectionLockout Aps 163
- ProtectionLockout Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 165
 - Properties for protectionLockout Laps 165
 - Syntax for protectionLockout Laps 165
 - Component instance parameter for protectionLockout Laps 166
 - Examples for protectionLockout Laps 166
 - Related information for protectionLockout Laps 166
- Quit command 168
- Reconnect command 169
 - Properties for reconnect 170
 - Syntax for reconnect 170
 - Parameters for reconnect 170
 - Examples for reconnect 171
- ReloadCp Lp command 173
 - Properties for reloadCp Lp 173

- Syntax for reloadCp Lp 173
- Parameters for reloadCp Lp 174
- Examples for reloadCp Lp 174
- Related information for reloadCp Lp 175
- Remove Fs command 176
 - Properties for remove Fs 176
 - Syntax for remove Fs 176
 - Parameters for remove Fs 177
 - Examples for remove Fs 178
 - Related information for remove Fs 178
- Remove Sw Av command 179
 - Properties for remove Sw Av 180
 - Syntax for remove Sw Av 180
 - Application version parameter for remove Sw Av 180
 - Removing an unused application version example 180
 - Related information for remove Sw Av 180
- Replay aaserv command 181
 - Properties for replay aaserv 181
 - Syntax for replay aaserv 181
 - Related information for replay aaserv 182
- Reset <processor> command 183
 - Properties for reset <processor> 184
 - Syntax for reset <processor> 184
 - Processor identifier parameters for reset <processor> 185
 - Examples for reset <processor> 185
 - Related information for reset <processor> 187
- Restart command 188
 - Properties for restart 188
 - Syntax for restart 188
 - Examples for restart 189
- Restart <processor> command 190
 - Properties for restart <processor> 191
 - Syntax for restart <processor> 191
 - Processor identifier parameters for restart <processor> 191
 - Examples for restart <processor> 192
 - Related information for restart <processor> 193
- Restore Prov command 194
 - Properties for restore Prov 194
 - Syntax for restore Prov 194
 - Examples for restore Prov 195
 - Restoring the current journaled view example 195
 - Related information for restore Prov 195
- Run Shelf Test command 196

- Properties for run Shelf Test 196
- Syntax for run Shelf Test 196
- Running a bus clock source test example 197
- Related information for run Shelf Test 197
- Save Prov command 198
 - Properties for save Prov 199
 - Syntax for save Prov 199
 - Parameters for save Prov 200
 - Examples for save Prov 201
 - Related information for save Prov 203
- Set command 204
 - Properties for set 204
 - Syntax for set 205
 - Parameters for set 205
 - Examples for set 209
 - Related information for set 210
- Start <hardware> Test command 212
 - Properties for start <hardware> Test 212
 - Syntax for start <hardware> Test 213
 - Testable hardware components parameter for start <hardware> Test 213
 - Starting a hardware test example 214
 - Related information for start <hardware> Test 215
- Start Prov command 216
 - Properties for start Prov 216
 - Syntax for start Prov 216
 - Remove another operator from provisioning mode parameter for start Prov 216
 - Examples for start Prov 217
 - Related information for start Prov 218
- Start Sw DId command 219
 - Properties for start Sw DId 220
 - Syntax for start Sw DId 220
 - Parameters for start Sw DId 220
 - Examples for start Sw DId 221
 - Related information for start Sw DId 222
- Stop <hardware> Test command 223
 - Properties for stop <hardware> Test 223
 - Syntax for stop <hardware> Test 224
 - Testable hardware components parameter for stop <hardware> Test 224
 - Stopping a hardware test example 225
 - Related information for stop <hardware> Test 225
- Stop Prov command 227
 - Properties for stop Prov 227
 - Syntax for stop Prov 227

- Stopping a provisioning system command example 227
- Related information for stop Prov 228
- Stop Sw DId command 229
 - Properties for stop Sw DId 229
 - Syntax for stop Sw DId 229
 - Stopping a software download example 230
 - Related information for stop Sw DId 230
- Switch Aps command on Multiservice Switch 7400 231
 - Properties for switch Aps 231
 - Syntax for switch Aps 232
 - Parameters for switch Aps 232
 - Examples for switch Aps 233
 - Related information for switch Aps 235
- Switch Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 236
 - Properties for switch Laps 236
 - Syntax for switch Laps 237
 - Parameters for switch Laps 237
 - Examples for switch Laps 238
 - Related information for switch Laps 240
- Switchover Lp command 240
 - Properties for switchover Lp 241
 - Syntax for switchover Lp 242
 - Parameters for switchover Lp 242
 - Examples for switchover Lp 243
 - Related information for switchover Lp 245
- Synchronize Fs command 246
 - Properties for synchronize Fs 246
 - Syntax for synchronize Fs 246
 - Synchronizing disks example 247
 - Related information for synchronize Fs 247
- Telnet Vr command 248
 - Properties for telnet Vr 248
 - Syntax for telnet Vr 249
 - Parameters for telnet Vr 249
 - Telnet command mode 249
 - Examples for telnet Vr 250
 - Related information for telnet Vr 251
- Tidy Prov command 252
 - Properties for tidy Prov 253
 - Syntax for tidy Prov 253
 - Parameters for tidy Prov 253
 - Examples for tidy Prov 254
 - Related information for tidy Prov 256

- Tidy Sw command 257
 - Properties for tidy Sw 258
 - Syntax for tidy Sw 258
 - Applications to remove query parameter 258
 - Deleting all unused software example 258
 - Related information for tidy Sw 259
- Touch Fs command 260
 - Properties for touch Fs 260
 - Syntax for touch Fs 260
 - Parameters for touch Fs 260
 - Examples for touch 261
 - Related information for touch Fs 262
- Trace command 263
 - Path trace test connection 263
 - Path trace filters 265
 - Connection trace command 269
 - Properties for connection trace 269
 - Syntax for connection trace 269
 - Parameters for connection trace 270
 - Examples for connection trace 271
 - Related information for path filter trace 271
- Unlock command 272
 - Properties for unlock 272
 - Syntax for unlock 272
 - Unlocking a locked component example 272
 - Related information for unlock 273
- Unprotect Fs command 274
 - Properties for unprotect Fs 274
 - Syntax for unprotect Fs 274
 - File to unprotect parameter for unprotect Fs 274
 - Unprotecting a file example 275
 - Related information for unprotect Fs 275
- WorkingDir Fs command 276
 - Properties for workingDir Fs 276
 - Syntax for workingDir Fs 276
 - Displaying the current working directory example 276
 - Related information for workingDir Fs 276
- Zero Nsta/n Vgs Digit Collection/n command 277
 - Properties for Zero Nsta/n Vgs Digit Collection/n 277
 - Syntax for Zero Nsta/n Vgs Digit Collection/n 277

About this document

NN10600-050 Nortel Networks Multiservice Switch 7400/15000/20000 Command Reference explains how to use system commands to operate and maintain Nortel Networks Multiservice Switch nodes or network through a text interface device such as a VT100 terminal. This document contains an alphabetical reference of most Multiservice Switch commands. Each command description includes detailed examples.

The following topics are discussed in this section:

- [Who should read this document and why \(page 13\)](#)
- [What you need to know \(page 13\)](#)
- [What's new in this document \(page 14\)](#)
- [Text conventions \(page 14\)](#)
- [Entering commands \(page 15\)](#)
- [Command wildcarding \(page 18\)](#)
- [Command categories \(page 20\)](#)
- [How to get more help \(page 23\)](#)

Who should read this document and why

This guide is for persons who perform operational, administration, and maintenance tasks.

What you need to know

This guide assumes that you understand the architecture and operation of Nortel Networks Multiservice Switch and DPN-100 products and networks. Knowledge of DPN-100 is required if your network incorporates a call server resource module (CSRM). You also require a basic knowledge of UNIX.

You can acquire product knowledge by reading NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*. Before undertaking operations and maintenance activities, you should have an understanding of the following product areas:

- Multiservice Switch concepts
 - Multiservice Switch hardware and software
 - Multiservice Switch installation, commissioning, and provisioning
 - Multiservice Switch node-to-Multiservice Switch node interworking
 - Multiservice Switch node-to-DPN-100 module interworking
- DPN-100 concepts
 - routing, trunking, and addressing
 - network installation, provisioning, operation, and maintenance
 - service protocols
- UNIX
 - a working knowledge of UNIX workstations
 - a working knowledge of the UNIX operating system, its facilities and commands (such skills are those typically acquired through an introductory UNIX course, and through experience performing tasks such as file creation, maintenance, and manipulation)
- standard network operations and maintenance activities
- Multiservice Data Manager workstation concepts

What's new in this document

The following features were added to this document:

- PVG - Customer Accessible PING (page 14)

PVG - Customer Accessible PING

The following section was updated for this feature:

- Ping -ip(<address>) <component> command (page 145)

Text conventions

This document uses the following text conventions:

- nonproportional spaced plain type

Nonproportional spaced plain type represents system generated text or text that appears on your screen.

- `nonproportional spaced bold type`
Nonproportional spaced bold type represents words that you should type or that you should select on the screen.
- *italics*
Statements that appear in italics in a procedure explain the results of a particular step and appear immediately following the step.
Words that appear in italics in text are for naming.
- `[optional_parameter]`
Words in square brackets represent optional parameters. The command can be entered with or without the words in the square brackets.
- `<general_term>`
Words in angle brackets represent variables which are to be replaced with specific values.
- UPPERCASE, lowercase
Nortel Networks Multiservice Switch commands are not case-sensitive and do not have to match commands and parameters exactly as shown in this document, with the exception of string options values (for example, file and directory names) and string attribute values.
There are two exceptions. Multiservice Switch nodes distinguish between upper- and lowercase characters in attribute values and option values that are strings. Filenames, for example, are string option values and are case sensitive.
- |
This symbol separates items from which you may select one; for example, ONIOFF indicates that you may specify ON or OFF. If you do not make a choice, a default ON is assumed.
- ...
Three dots in a command indicate that the parameter may be repeated more than once in succession.

The term absolute pathname refers to the full specification of a path starting from the root directory. Absolute pathnames always begin with the slash (/) symbol. A relative pathname takes the current directory as its starting point, and starts with any alphanumeric character (other than /).

Entering commands

To successfully enter a command, you must consider the following:

- [Abbreviations \(page 16\)](#)
- [Keyboard shortcuts \(page 17\)](#)

When responding to a command requiring a large number of responses, the Component Administration System (CAS) continues to process new requests however the responses to these new requests will be interleaved with the response from the first command (requiring a large number of responses). You do not need to input the same command repeatedly, as the response is already interleaved in the previous response.

Abbreviations

Many verbs, options, components, groups, and attributes have explicit abbreviations. For example, the explicit abbreviation for the verb `display` is `d` and the explicit abbreviation for the component `FileSystem` is `fs`. To display information about the file system, you can enter the whole name:

```
display FileSystem
```

Or its abbreviation:

```
d Fs
```

You can also abbreviate a command by entering only the first few characters of any of its parts. Multiservice Switch system attempt to match the characters you typed to a valid command. For example, you can abbreviate the `FileSystem` component in the `display FileSystem` command using its first four characters:

```
display File
```

Since there are no other displayable components that begin with the characters `File`, the system can match this abbreviation to a single valid command.

In some cases, the abbreviation matches more than one valid command, giving you an ambiguous match. Multiservice Switch system prompt you to specify more characters to clear up the ambiguity. For example, you can use the `list` and the `listFile` verb with the `FileSystem` component. If you enter the following command, you will get an ambiguous match between the two verbs:

```
li File
```

If you intended to use the `listFile` verb, you would have to enter the first five characters to clear up the ambiguity, or use its explicit abbreviation of `ls`.

Some verbs have a minimum number of matching characters to prevent you from accidentally entering a command that can have a serious impact on the system. The `activate` verb, for example, requires that you enter at least the first three characters. The following command gives an unambiguous match, but fails because it only uses the first two characters of the `activate` verb:

```
ac prov
```

You can find the explicit abbreviation for parts of a command and the minimum matching characters required for a verb using the help command (see [Help command \(page 100\)](#)). The explicit abbreviation is in parenthesis following the full name. The minimum matching characters are indicated in uppercase in the full verb name. For example, the activate verb is represented as ACTivate.

Keyboard shortcuts

The text interface provides a set of keyboard shortcuts you can use in either provisioning or operational mode. The shortcuts allow you to edit the command line and control the display of command responses. The table [Keyboard shortcuts \(page 17\)](#) summarizes these shortcuts.

Keyboard shortcuts

Key	Description
Up Arrow and Down Arrow	Recalls recently used commands for edit or reuse. Multiservice Switch system stores the last 10 commands in a queue. Each time you press the Up Arrow key, you step back through the command queue. The Down Arrow key steps forward through the command queue.
Left Arrow and Right Arrow	Moves the cursor over the command without affecting the characters in the command.
Backspace or Delete	Deletes the character preceding the cursor.
Control-D	Deletes the character under the cursor.
Control-A	Moves the cursor to the beginning of the command line.
Control-E	Moves the cursor to the end of the command line.
Control-H	Moves the cursor back one character at a time.
Control-J or Control-M	Inserts a paragraph return.
Control-K	Deletes text from the character under the cursor to the end of the command line.
Control-N	Moves the cursor down one line at a time.
Control-P	Moves the cursor up one line at a time.
Return or Enter	Sends the command to the Multiservice Switch node for processing.

(1 of 2)

Keyboard shortcuts (continued)

Key	Description
Control-S	<p>Suspends the response from a command.</p> <p>This shortcut is useful where a command response is longer than 24 lines.</p> <p>If you suspend output for a long period of time, the text interface discards some subsequent output. If the session is registered to display a data stream (alarm, SCN, log, or debug data), the session discards all the data generated while response is suspended.</p> <p>If you suspend a telnet interface for a long time and a large amount of subsequent output is queued, the underlying TCP connection can terminate, bringing down the telnet session.</p>
Control-Q	Resumes suspended output.
Control-C	Cancels a response. One Control-C cancels only the current response, and does not affect other queued responses.

(2 of 2)

Command wildcarding

Command wildcarding means using a wildcard character (*) or wildcard pattern to match more than one component or attribute. The commands display, list, and find support wildcarding.

Nortel Networks Multiservice Switch has two kinds of wildcarding:

- [Type wildcarding \(page 18\)](#)
- [Instance wildcarding \(page 18\)](#)

You cannot combine the two types of wildcarding in a single command.

Type wildcarding

Type wildcarding allows you to view information about all subcomponents of a component. You can match all subcomponents by substituting an asterisk for the component type. For example, the following command lists all *Bus* or *FabricCard*, *Card*, and *Test* subcomponents of the *Shelf* component:

```
list Shelf *
```

Type wildcarding only works if the asterisk is the last parameter of the command. In other words, you can only substitute an asterisk for the last component type.

Instance wildcarding

With instance wildcarding, you can view information about instances of a particular component type.

You can match all instances by substituting a wildcard (*) for the instance value. For example, the following command lists the attributes in the *OsiState* group from all instances of the *Lp* component:

```
display Lp/* OsiState
```

You can match a subset of instances by substituting a wildcard pattern for the instance value. For example, the following command will list all full provisioning views that also contain "Test" within the name portion of the view:

```
list Prov View/*Test*.full.*
```

You can substitute a wildcard (*) for more than one instance to view all instances from multiple component types in the component hierarchy. For example, the following command lists all instances of the *V35* component from all instances of the *Lp* component:

```
list Lp/* V35/*
```

For multi-indexed components you can substitute a wildcard (*) or a wildcard pattern for one or more of the indexes. You must specify the first index in a multi-index component and any unspecified indexes will default to *. For example, the command:

```
display Vr/* IP Fwd/* ,255.*
```

will default to:

```
display Vr/* IP Fwd/* ,255.* ,* ,*
```

You can match an expression using = (equal) or != (not equal) as valid operators when specifying attribute values. For example, the following command lists all LPs that are active:

```
list Lp/(usageState = active)
```

and the following command lists all LPs that are not active:

```
list Lp/(usageState != active)
```

You can match an expression by joining up to three attributes using the following operators: AND and OR. For example, the following command lists all the *fruni* components that have a locked open system interconnection (OSI) administrative state or a disabled OSI operational state.

```
list fruni/(adminState = locked OR operationalState = disabled)
```

Attention: The operators = and ! have a higher precedence over the operators AND and OR.

You can also apply both instance filtering and value-based filtering to the same component instance. For example

```
display Laps/2* Sts/*(operationalState=disabled)
```

Command categories

Most Nortel Networks Multiservice Switch system commands fall into one of the following categories as shown in [Command categories \(page 20\)](#).

Each of the following sections briefly explains the category of the command and lists, in alphabetical order, the commands that fall into the category.

Command categories

Category and purpose	Command
Session Session commands allow you to manage your Multiservice Switch session or the sessions of other users.	Cancel command (page 38) Clear Nmis <interface> Session command (page 55) Logout command (page 128) Me command (page 132) Quit command (page 168) Telnet Vr command (page 248)
Common You can use the common verbs with most components to form the common commands. Some components prevent the use of a particular common verb. To determine if a common verb works on a component, use the help command (see Help command (page 100)).	Add command (page 31) Delete command (page 77) Display command (page 80) Find command (page 93) Help command (page 100) List command (page 110) Lock command (page 124) Set command (page 204) Unlock command (page 272)

(1 of 4)

Command categories (continued)

Category and purpose	Command
<p>Provisioning</p> <p>The provisioning commands allow you to reconfigure Multiservice Switch nodes. To execute most of these commands you must be in provisioning mode (see Start Prov command (page 216)).</p>	<p>Activate Prov command (page 25)</p> <p>Apply Prov command (page 34)</p> <p>Check Prov command (page 42)</p> <p>Clear Prov command (page 58)</p> <p>Commit Prov command (page 61)</p> <p>Confirm Prov command (page 64)</p> <p>Continue Prov command (page 66)</p> <p>Copy Prov command (page 72)</p> <p>End Prov command (page 91)</p> <p>Load Prov command (page 121)</p> <p>Save Prov command (page 198)</p> <p>Start Prov command (page 216)</p> <p>Stop Prov command (page 227)</p> <p>Tidy Prov command (page 252)</p>
<p>File system</p> <p>Multiservice Switch file system stores the files necessary to the operation of the node. You can manage the file system and the files stored on it using these commands.</p>	<p>Chdir Fs command (page 40)</p> <p>Copy Fs command (page 68)</p> <p>Format Fs Disk command (page 97)</p> <p>ListFile Fs command (page 117)</p> <p>Lock command (page 124)</p> <p>MakeDirectory Fs command (page 130)</p> <p>Move Fs command (page 134)</p> <p>Protect Fs command (page 160)</p> <p>Remove Fs command (page 176)</p> <p>Synchronize Fs command (page 246)</p> <p>Touch Fs command (page 260)</p> <p>Unlock command (page 272)</p> <p>Unprotect Fs command (page 274)</p> <p>WorkingDir Fs command (page 276)</p>

(2 of 4)

Command categories (continued)

Category and purpose	Command
<p>Software</p> <p>Use the Software commands to download new software applications to a node and to delete old software applications.</p>	<p>Remove Sw Av command (page 179)</p> <p>Start Sw Dld command (page 219)</p> <p>Stop Sw Dld command (page 229)</p> <p>Tidy Sw command (page 257)</p>
<p>Logical processor</p> <p>Use the Logical processor commands to control the logical processors on a node.</p>	<p>Lock command (page 124)</p> <p>ReloadCp Lp command (page 173)</p> <p>Reset <processor> command (page 183)</p> <p>Restart <processor> command (page 190)</p> <p>Switchover Lp command (page 240)</p> <p>Unlock command (page 272)</p>
<p>Line automatic protection switching on Multiservice Switch 7400</p> <p>Use these commands to control the automatic protection switching (APS) links on a node.</p>	<p>Clear Aps command on Multiservice Switch 7400 (page 51)</p> <p>ProtectionLockout Aps command on Multiservice Switch 7400 (page 162)</p> <p>Switch Aps command on Multiservice Switch 7400 (page 231)</p>
<p>Line automatic protection switching on Multiservice Switch 15000 and Multiservice Switch 20000</p> <p>Use these commands to control the line automatic protection switching (LAPS) links on a node.</p>	<p>Clear Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 (page 53)</p> <p>ProtectionLockout Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 (page 165)</p> <p>Switch Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 (page 236)</p>
<p>Testing</p> <p>The Testing commands allow you to perform diagnostic tests on various parts of a node.</p>	<p>Run Shelf Test command (page 196)</p> <p>Start <hardware> Test command (page 212)</p> <p>Stop <hardware> Test command (page 223)</p>
<p>(3 of 4)</p>	

Command categories (continued)

Category and purpose	Command
Routing The Routing commands allow you to clear connections, determine network paths, and to optimize the routing system.	Ping Rtg Dpn <node> command (page 154) Ping <connection> Vc command (page 149) Ping -ip(<address>) <component> command (page 145)
(4 of 4)	

How to get more help

For information on training, problem reporting, and technical support, see the “Nortel Networks support services” section in the *product overview document*.

Command reference

This chapter provides detailed descriptions of all Nortel Networks Multiservice Switch system commands. In the descriptions, some commands have a variable in angle brackets (< >) as part of their name. These commands can be used for multiple Multiservice Switch components.

Creating a valid command

To create a valid command, replace the variable (and its angle brackets) with a specific component name. For example, the `clear Nmis <interface> Session` command works with three different components, including Nmis Telnet Session. The following is a valid `clear Nmis <interface> Session` command:

```
clear Nmis Telnet Session/1
```

The detailed descriptions include the following sections:

- **Properties.** This section lists the operator modes in which you can use the command, and the minimum impact and scope you need to execute the command. It can list other properties of the command as well.
- **Syntax.** This section lists the syntax for the most common uses of the command.
- **Parameters.** This section details all the parameters of the command, including its options.
- **Examples.** This section gives practical examples of how to use the command.
- **Related Information.** This section lists other information in this document related to the command.

Activate Prov command

Use the activate Prov (act Prov) command to bring either the edit view, or a saved view, into service.

Attention: Complete a semantic check of the edit view (using the check Prov command) before issuing the activate Prov command. If you do not complete a semantic check for the view, the system automatically starts the check before the activate process begins.

When you activate a provisioning view, the provisioning system checks that all the software necessary to activate the components in the view is running on the module. If any necessary software is missing, the command fails and the system displays a list of missing software.



CAUTION

If you do not confirm the activate Prov command (see [Confirm Prov command \(page 64\)](#)) within 20 minutes of issuing it, a system restart occurs and the system reactivates the last committed view as the current view (see [Commit Prov command \(page 61\)](#)). A service disruption occurs while the restart is in progress.

Activating a view can delete certain components in the current view. Some components temporarily go out of service if the changes are critical to the provisioned data.

An activation can also result in a CP restart or reload, causing all services on the Nortel Networks Multiservice Switch node to fail. When this happens, wait until the restart or reload is complete and then login again and continue with the confirm Prov command. If an activation results in a CP reset or reload, and the edit view is not saved, the system puts it into a temporary saved view.

For more information on the activate Prov command, see

- [Properties for activate Prov \(page 25\)](#)
- [Syntax for activate Prov \(page 26\)](#)
- [Parameters for activate Prov \(page 26\)](#)
- [Examples for activate Prov \(page 28\)](#)
- [Related information for activate Prov \(page 30\)](#)

Properties for activate Prov

The following table describes the properties of the activate Prov command.

Properties of the activate Prov command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Application	ProvisioningSystem (Prov)

Syntax for activate Prov

The following table describes the syntax for the activate Prov command.

Syntax of the activate Prov command

If you want to...	Use the following syntax:
Activate the edit view, making it the current view	activate Prov
Activate a saved view, making it the current view	activate -file(<view_name>) Prov
Force the activation of an unchecked view	activate -file(<view_name>) -force Prov
Enable the automatic pause of a hitless software upgrade	activate -Pause Prov Attention: This feature is not generally available. Contact Nortel Networks for more information on this feature.
Disable the automatic pause of a hitless software upgrade	activate -noPause Prov
Force the activation when a restore is possible	activate -force Prov

Parameters for activate Prov

There are two types of parameters for the activate Prov command:

- [Activating a saved view parameter for activate Prov \(page 26\)](#)
- [Force override for activate Prov \(page 27\)](#)
- [Disabling the automatic pause parameter in case of faults occurring during a hitless software upgrade \(page 28\)](#)

Activating a saved view parameter for activate Prov

You can activate a saved view instead of the edit view using the file option:

-file(<view_name>)

Enter the name of the saved view using the three-part view filename. For information on the filename syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

If you issue the activate Prov command in operational mode, you must use the file option. You cannot use the activate Prov command with the file option if another operator session is currently in provisioning mode.

Force override for activate Prov Semantic check

You can override the check for the proper software using the force option:

-force

The force option also overrides critical warnings while continuing to activate the view.

When you activate an unchecked provisioning view, the provisioning system runs a semantic check. If there are semantic problems with the view, the system issues errors and warnings. Some warnings are critical. For example, you can receive warnings to restart a specific service, to activate the specified provisioning data change, or to restart the complete system. If a semantic check error or critical warning occurs, then the system aborts the activate Prov command. For critical warnings, you can override this behavior using the force option. You cannot use the force option to override semantic check errors.

Restore possible

If the journaled current view can be restored, then the activate Prov command may cause the journaled current view to be purged, and a restore to no longer be possible. In this case, the -force option is required for the activation to proceed. Note that a restore is only possible if the attribute restorePossible is set to yes.

Enabling saving of journal log files for activate Prov

By default, the saving of journal log files is enabled. By disabling journal log files, the saving of journal log files will be turned off for any subsequent activations. By enabling journal log files, the saving of journal log files will be turned on for any subsequent activations.

Attention: You need to commit the configuration after enabling or disabling journal log file saving.

Enabling the automatic pause parameter for activate Prov when starting a hitless software upgrade

At the start of a hitless software upgrade, you can enable the automatic pause that occurs before migration switchover during a software migration activation:

-Pause

When a hitless software upgrade is activated with the Pause option, the software migration activation pauses before migration switchover occurs.

If faults occur before the pause, the faults will be included in the reason for the pause. If faults occur during the pause, a list of the faults is provided and the continue prov command will fail. If this occurs, you can:

- abort the migration
- fix the condition and continue by issuing the continue prov command
- proceed with the migration by issuing the continue -force prov command

Attention: The -pause and -noPause parameters are mutually exclusive. If you issue the -pause parameter, you cannot issue the -noPause parameter.

Attention: If the migration pauses because of a fault, or if a fault occurs during a pause, you must issue the continue -force prov command if you wish to continue despite the fault condition.

Attention: This feature is not generally available. Contact Nortel Networks for more information on this feature.

Disabling the automatic pause parameter in case of faults occurring during a hitless software upgrade

At the start of a hitless software upgrade, you can disable the automatic pause that occurs before migration switchover during a software migration activation:

-noPause

When a hitless software upgrade is activated with the noPause option, the software migration activation does not pause before migration switchover occurs, regardless of service affecting alarms.

Attention: The -pause and -noPause parameters are mutually exclusive. If you issue the -pause parameter, you cannot issue the -noPause parameter.

Examples for activate Prov

The following examples show how to use the activate Prov command:

- [Activating the edit view in provisioning mode example \(page 29\)](#)
- [Activating a saved view in operational mode example \(page 29\)](#)
- [Activating a saved view and overriding the system check for proper software example \(page 29\)](#)

Activating the edit view in provisioning mode example

You want to activate the edit view in provisioning mode. You enter the following command:

```
activate Prov
```

An alarm warns all operators on the node that an activation has occurred. The following message prompts you to confirm the activation by issuing the confirm Prov command:

```
Prov; <timestamp>
SET warning operator operationalCondition      70000007
ADMIN: unlocked          OPER: enabled        USAGE: busy
AVAIL:                   PROC: initializing  CNTRL:
ALARM:                   STBY: notSet         UNKNW: false
Id: 0D                   Rel: Lp/0
Com: Activation complete. Enter 'confirm prov' to
confirm activation or rollback will occur in 20
minutes.
Int: 0/1/2/16663; casAlarm.cc; 686; p5.0d.19
You have 20 minutes in which to confirm activation.
```

Activating a saved view in operational mode example

You want to activate the saved view DZL_test.full.023 in operational mode. The proper software for the saved view is currently running on the node. You enter the following command:

```
activate -file(DZL_test.full.023) Prov
```

An alarm warns all operators on the node that an activation has occurred. The message prompts you to confirm the activation by issuing the confirm Prov command.

```
Prov
  Invoking Load prov command.
  Prov;
SET warning operator
<timestamp> operationalCondition      70000007
.
.  <text deleted>
.
  Int: 15/1/3/39955; casCPmainEntry.cc;470; p4.0d.26
  Loaded file DZL_test.full.023.
  You have 20 minutes in which to confirm activation.
```

Activating a saved view and overriding the system check for proper software example

You want to activate a saved view DZL_test.full.024, but the node is not currently running the proper software for the saved view. You attempt to activate the view using the following command:

```
activate -file(DZL_test.full.024) Prov
```

You receive a number of error messages ending with the following response:

```
Too many errors loading file DZL_test.full.024.  
command failed
```

The command does not activate the saved view. However, you still want to activate the view regardless of the software. You override the system check for proper software using the following command:

```
activate -file(DZL_test.full.024) -force Prov
```

You receive a number of error messages, ending with the following response:

```
Loaded or applied file DZL_test.full.024.
```

Related information for activate Prov

See the following for information related to the activate Prov command:

- [Activate Prov command \(page 25\)](#)
- [Apply Prov command \(page 34\)](#)
- [Check Prov command \(page 42\)](#)
- [Clear Prov command \(page 58\)](#)
- [Commit Prov command \(page 61\)](#)
- [Confirm Prov command \(page 64\)](#)
- [Continue Prov command \(page 66\)](#)
- [Copy Prov command \(page 72\)](#)
- [End Prov command \(page 91\)](#)
- [Load Prov command \(page 121\)](#)
- [Restore Prov command \(page 194\)](#)
- [Save Prov command \(page 198\)](#)
- [Start Prov command \(page 216\)](#)
- [Stop Prov command \(page 227\)](#)
- [Tidy Prov command \(page 252\)](#)

Add command

The add (a) command lets you create a component (with its default values) in the edit view. You can only use the add command in provisioning mode.

The system adds all mandatory subcomponents, but shows the first six only. If there are more than six subcomponents, a message indicates the number of unseen subcomponents.

To add a component for a new feature or application, the software application version list or feature list must specify that feature or application. For details on specific components, see NN10600-060 *Nortel Networks Multiservice Switch 7400/15000/20000 Component Reference*.

For more information on the add command, see

- [Properties for add \(page 31\)](#)
- [Syntax for add \(page 31\)](#)
- [Parameters for add \(page 32\)](#)
- [Examples for add \(page 32\)](#)
- [Related information for add \(page 33\)](#)

Properties for add

The following table describes the properties of the add command.

Attention: Some components require a higher impact. See NN10600-060 *Nortel Networks Multiservice Switch 7400/15000/20000 Component Reference* for information on specific components or use the help command.

Properties of the add command

Mode	Impact	Scope	Components
Provisioning	Configuration	Depends on component	All provisionable

Syntax for add

The following table describes the syntax for the add command.

Syntax of the add command

If you want to...	Use the following syntax:
Add a new component	add <component_name>
Add a new component and any missing superior components	add -superiors <superior_component_name> <component_name>

Parameters for add

There are two parameter types for the add command:

- [Add a component parameter for add \(page 32\)](#)
- [Add superior components parameter for add \(page 32\)](#)

Add a component parameter for add

You specify which component you want to add to the edit view using the component of the command:

`<component_name>`

Add superior components parameter for add

To create a component, all of its superior component(s) must already exist. If they do not, rather than adding the superior components separately, you can add them automatically using the superiors option:

`-superiors`

You must specify the name of all superior components in the command.

Examples for add

The following examples shows how to use the add command:

- [Adding a component example \(page 32\)](#)
- [Adding a component and all its superior components example \(page 33\)](#)

Adding a component example

You want to create a new *virtualRouter (Vr)* component. You enter the following command:

```
add vr/0
```

You receive the following response:

```
Vr/0
The following components have been created:
Vr/0 Mm
Vr/0 QosP/0
Vr/0
ok
```

Adding a component and all its superior components example

You want to create a new *Ip* component under a new *Vr* component (*Vr/1*), and have the Nortel Networks Multiservice Switch software automatically add the superior *Vr* component. You enter the following command:

```
add -superiors vr/1 Ip
```

You receive the following response:

```
Vr/1 Ip
The following components have been created:
  Vr/1 Mm
  Vr/1 QosP/0
  Vr/1
  Vr/1 Ip Arp
  Vr/1 Ip Icmp
  Vr/1 Ip RelayBC
  and another 3 component(s).
```

Related information for add

See the following for information related to the add command:

- [Clear Prov command \(page 58\)](#)
- [Copy Prov command \(page 72\)](#)
- [Delete command \(page 77\)](#)
- [List command \(page 110\)](#)
- [Start Prov command \(page 216\)](#)
- Components and commands. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for details.

Apply Prov command

Use the apply Prov (app Prov) command to apply the changes in a saved view to the edit view. Use only saved views with a delta format with this command. You can determine the format of all saved views on your node using the following command:

```
display Prov View/* formats
```

Use the apply Prov command only if you have saved the edit view or it is identical to the current view. For information on views, see NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

When you apply a provisioning view, the provisioning system checks to ensure that the software necessary to activate the components in the view is running on the node. If any software is missing, the command fails and the system displays a list of the missing software. If the information in the saved view differs from the edit view, then the edit view prevails and the system displays warning messages. Note any conflicts and resolve them as necessary.

For more information on the apply Prov command, see

- [Syntax for apply Prov \(page 34\)](#)
- [Syntax for apply Prov \(page 34\)](#)
- [Parameters for apply Prov \(page 35\)](#)
- [Examples for apply Prov \(page 35\)](#)
- [Related information for apply Prov \(page 36\)](#)

Properties for apply Prov

The following table describes the properties of the apply Prov command.

Properties of the apply Prov command

Mode	Impact	Scope	Component
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for apply Prov

The following table describes the syntax for the apply Prov command.

Attention: The apply Prov command must always include the file option.

Syntax of the apply Prov command

If you want to...	Use the following syntax:
Apply the changes in a saved view to the edit view	<code>apply -file(<view_name>) Prov</code>
Apply the changes in a saved view to the edit view, and override any system checks for necessary software	<code>apply -force -file(<view_name>) Prov</code>

Parameters for apply Prov

There are two types of parameters for the apply Prov command:

- [Applying a saved view parameter for apply Prov \(page 35\)](#)
- [System check override parameter for apply Prov \(page 35\)](#)

Applying a saved view parameter for apply Prov

You can specify that the provisioning system apply the changes in a saved view to the edit view, using the file option:

-file(<view_name>)

Enter the name of the saved view. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for information on the filename syntax of saved views.

System check override parameter for apply Prov

You can specify that the provisioning system override the system check using the force option:

-force

This option is useful if you know you have all the necessary software, and you want to skip the system check.

The force option overrides the check for proper software, and applies the saved view regardless of the software running on the node. The force option also ensures that the provisioning system continues to process the entire view rather than stopping after five semantic errors.

Examples for apply Prov

The following examples show how to use the apply Prov command:

- [Applying changes in the saved view to the edit view example \(page 36\)](#)
- [Applying changes in a saved view to the edit view and skipping the system check example \(page 36\)](#)

Applying changes in the saved view to the edit view example

You want to apply changes in the saved view AXL_test.full.003 to the edit view. You verify that the saved view has a delta format using the following command:

```
display Prov View/AXL_test.full.003 formats
```

You receive the following response:

```
Prov View/AXL_test.full.003
formats = delta
```

Since the saved view has a delta format, you enter the following command:

```
apply -file(AXL_test.full.003) Prov
```

The system applies the changes from the saved view to the edit view, and resolves or reports conflicts. You receive the following response:

```
Prov
Loaded or applied file AXL_test.full.003.
ok
```

Applying changes in a saved view to the edit view and skipping the system check example

You want to apply changes in a saved view to the edit view, but want to skip the system check for the proper software. In this example, the node is missing some of the proper software. If you try to apply the view without the force option, you receive a number of error messages ending with the following response:

```
Too many errors loading file AXL_test.full.004.
command failed
```

In this situation, the system detects the errors, and aborts the command.

To force the node to ignore the error messages and apply the view, you enter the following command:

```
apply -force -file(AXL_test.full.004) Prov
```

You receive a number of error messages, ending with the following response:

```
Loaded or applied file AXL_test.full.004.
```

Related information for apply Prov

See the following for information related to the apply Prov command:

- [Activate Prov command \(page 25\)](#)
- [Check Prov command \(page 42\)](#)
- [Load Prov command \(page 121\)](#)
- [ReloadCp Lp command \(page 173\)](#)
- [Save Prov command \(page 198\)](#)

- Saved view filename syntax. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for more details.

Cancel command

The cancel command allows you to cancel a wildcarded command and most commands that issue multiple responses or very long responses.

The cancel command works on wildcarded display commands and on all list commands. It only cancels the last command for which you have received part of the response.

You can type out cancel while the command is running, or you can use the keyboard shortcut of Control-C for Local and Telnet.

You can use the cancel command on the Multiservice Data Manager Command Console.

For more information on the cancel command, see

- [Properties for cancel \(page 38\)](#)
- [Syntax for cancel \(page 39\)](#)
- [Canceling a command example \(page 39\)](#)
- [Related information for cancel \(page 39\)](#)

Properties for cancel

The following table describes the properties of the cancel command.

Properties of the cancel command

Mode	Minimum Impact	Component
Operational or Provisioning	Passive	Does not affect components

Syntax for cancel

The following table describes the syntax for the cancel command.

Syntax of the cancel command

If you want to...	Use the following syntax:
Cancel the last wildcarded command you entered	cancel

Canceling a command example

You want to view all the attributes for logical processor 1. When you enter the command, you accidentally type an asterisk for the instance number:

```
display -noTabular Lp/*
```

The long and mostly unwanted command response begins to display:

```
Lp/0
  adminState = unlocked
  operationalState = enabled
  usageState = active
  availabilityStatus =
```

Without waiting for a the command prompt, you enter the cancel command:

```
cancel
```

Alternatively, you press Control-C. The command stops and the following message displays:

```
Command cancelled.
command failed
```

Related information for cancel

See the following for information related to the cancel command:

- [Display command \(page 80\)](#)
- [List command \(page 110\)](#)
- [Command wildcarding \(page 18\)](#)

Chdir Fs command

The chdir Fs (cd Fs) command allows you to change your current working directory in the Nortel Networks Multiservice Switch file system.

If you do not specify a directory, most file system commands assume you want to use your current working directory. You can determine the name of your current working directory using the workingDir Fs command.

For more information on the chdir Fs command, see

- [Properties for chdir Fs \(page 40\)](#)
- [Syntax for chdir Fs \(page 40\)](#)
- [New working directory parameter for chdir Fs \(page 40\)](#)
- [Changing the current working directory example \(page 41\)](#)
- [Related information for chdir Fs \(page 41\)](#)

Properties for chdir Fs

The following table describes the properties of the chdir Fs command.

Properties of the chdir Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Passive	Device	FileSystem (Fs)

Syntax for chdir Fs

The following table describes the syntax for the chdir Fs command.

Syntax of the chdir Fs command

If you want to...	Use the following syntax:
Change to a new working directory	chdir -path(<directorypath>) Fs

New working directory parameter for chdir Fs

You can specify the new working directory using the path option:

-path(<directorypath>)

Enter the absolute or relative path for the new working directory. Enclose the path in double quotation marks. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

You must enter this option.

Changing the current working directory example

Your current working directory is the root directory (/). You want to change it to the provisioning directory. You enter the following command:

```
chdir -path("provisioning") Fs
```

You check your current working directory using the workingDir Fs command:

```
workingDir Fs
```

You receive the following response:

```
Fs  
/provisioning
```

You now want to change your current directory to the /spooled/closed directory using its absolute path. You enter the following command:

```
chdir -path("/spooled/closed") Fs
```

Now you want to change to the opened subdirectory of the spooled directory using a relative pathname. You enter the following command:

```
chdir -path("../opened") Fs
```

Related information for chdir Fs

See the following for information related to the chdir Fs command:

- [ListFile Fs command \(page 117\)](#)
- [WorkingDir Fs command \(page 276\)](#)

Check Prov command

Use the check Prov command to run a semantic check for errors on the provisioning data in the edit view. Use this command before the activate Prov command.

Attention: If you have changed a *Software*, *LogicalProcessor*, *LogicalProcessorType*, or *Card* component, you cannot run the check Prov command while a start Sw DId, tidy Sw, or a remove Sw command is in progress.

During a full semantic check, the system issues a warning for each component that will go out of service because of critical provisioning data changes. When you activate the edit view, these components go out of service and then return to service after the activate is complete. See [Activate Prov command \(page 25\)](#) for more information on view activation.

For more information on the check Prov command, see

- [Properties for check Prov \(page 42\)](#)
- [Syntax for check Prov \(page 42\)](#)
- [Parameters for check Prov \(page 43\)](#)
- [Examples for check Prov \(page 44\)](#)
- [Related information for check Prov \(page 47\)](#)

Properties for check Prov

The following table describes the properties of the check Prov command.

Properties of the check Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for check Prov

The following table describes the syntax for the check Prov command.

Syntax of the check Prov command

If you want to...	Use the following syntax:
Perform a semantic check on the entire edit view	check Prov
Perform a semantic check on only those components in the edit view that are new or changed from the current view	check -changed Prov
Perform a semantic check on a single component and its subcomponents	check -component(<component_name>) Prov
Perform a semantic check on a single component only (and not its subcomponents)	check -component(<component_name>) -nonrecursive Prov
Perform a semantic check but stop it after the system encounters the first error	check -stopOnError Prov

Parameters for check Prov

There are four types of parameters for the check Prov command:

- [Check changed components parameter for check Prov \(page 43\)](#)
- [Check component parameter for check Prov \(page 43\)](#)
- [Nonrecursive parameter for check Prov \(page 44\)](#)
- [Stop check at first error parameter for check Prov \(page 44\)](#)

Check changed components parameter for check Prov

You can specify that the provisioning system check only components in the edit view that are new or changed from the current view using the changed option:

-changed

You cannot use this option in conjunction with the component option.

This option is useful if you wish to save the time involved in performing a full semantic check. However, to activate the edit view, the system must successfully complete a full semantic check.

Check component parameter for check Prov

You can specify that the provisioning system check a specific component and its subcomponents, using the component option:

-component (<component_name>)

This option requests a semantic check of the indicated component and its subcomponents. This option starts a fully recursive check of the component, including all its subcomponents and their attributes. This option does not provide out of service warnings.

You cannot use this option in conjunction with the `changed` option.

This option is useful when changes in a provisioning session affect only a single component. This option is much faster than performing a full semantic check on all components. However, to activate the edit view, the system must successfully complete a full semantic check.

Nonrecursive parameter for check Prov

You can specify that the provisioning system perform a nonrecursive check on a component using the nonrecursive option:

`-nonrecursive`

This option limits a semantic check to a single component. The system does not check subcomponents and their attributes.

You must use this option in conjunction with the `component` option.

This option is useful when changes in a provisioning session affect only the top layer of a single component. This option is much faster than performing a full semantic check. However to activate the edit view, the system must successfully complete a full semantic check.

Stop check at first error parameter for check Prov

You can specify that the provisioning system stop the check when the first error is found, using the `stopOnError` option:

`-stopOnError`

This option stops the semantic check at the first error.

If you do not use this option, the provisioning system attempts to find as many errors as possible, up to a maximum of five. If the system detects five errors, it aborts the semantic check.

Examples for check Prov

The following examples show how to use the `check Prov` command:

- [Checking the provisioning data of a view example \(page 45\)](#)
- [Checking the provisioning data for new or changed components example \(page 45\)](#)
- [Checking the provisioning data of a component and its subcomponents example \(page 46\)](#)

- [Checking a component only example \(page 47\)](#)
- [Stop checking the provisioning data of a view after encountering an error example \(page 47\)](#)

Checking the provisioning data of a view example

You want to start a semantic check with no options. You enter the following command:

```
check Prov
```

You receive the following response:

```
Prov  
ok
```

OR

A warning appears to indicate which components will be taken out of service as a result of the change. In this example, after a critical change to the *FrameRelayUni/2* component, the following message appears:

```
Prov  
Warning: The following components will be taken out  
of service:  
FrUni/2
```

Checking the provisioning data for new or changed components example

For this example, assume that you added two ATM interfaces (*AtmIf/5* and *AtmIf/21*) without assigning them to a logical processor.

You complete a check of any new or changed components using the following command:

```
check -changed Prov
```

You receive the following response:

```
AtmIf/5  
Error:  
  Related Component:  AtmIf/5  
  Related Attribute:  interfaceName  
  Reason:  Unable to retrieve the LP Info from the  
           Interface Name of the atmIf.  
AtmIf/5 ConnMap  
Error:  
  Reason:  Unable to retrieve the LP Info from the  
           Interface Name of the atmIf.  
AtmIf/21  
Error:  
  Related Component:  AtmIf/21  
  Related Attribute:  interfaceName  
  Reason:  Unable to retrieve the LP Info from the
```

```
Interface Name of the atmIf.
AtmIf/21 ConnMap
Error:
Reason: Unable to retrieve the LP Info from the
Interface Name of the atmIf.
Prov
Semantic check failed. This view cannot be
activated.
command failed
```

The check Prov command is unsuccessful in this example because the changed option checks all the attributes and subcomponents of both new components.

Checking the provisioning data of a component and its subcomponents example

For this example, assume that you added two ATM interfaces (AtmIf/5 and AtmIf/21) without assigning them to a logical processor.

To complete a semantic check of the *AtmIf/21* component and all its subcomponents, you enter the following command:

```
check -component (AtmIf/21) Prov
```

You receive following response:

```
AtmIf/21
Error:
Related Component: AtmIf/21
Related Attribute: interfaceName
Reason: Unable to retrieve the LP Info from the
Interface Name of the atmIf.
AtmIf/21 ConnMap
Error:
Reason: Unable to retrieve the LP Info from the
Interface Name of the atmIf.
Prov
Semantic check failed. This view cannot be
activated.
command failed
```

The check Prov command is unsuccessful in this example because the component option used on its own recursively checks all the attributes and subcomponents of the *AtmIf/21* component.

Checking a component only example

You made provisioning changes affecting the *Lp/2* component. However, your changes did not affect any of its many provisioned subcomponents. You have more changes to make before activating the edit view. To save time, you only check the *Lp/2* component (and none of its subcomponents) using the following command:

```
check -component(Lp/2) -nonrecursive Prov
```

You receive the following response:

```
Prov  
ok
```

Stop checking the provisioning data of a view after encountering an error example

To complete a semantic check of all changed components, and stop the check after the first error is encountered, you enter the following command:

```
check -stopOnError Prov
```

You receive the following response:

```
AtmIf/5  
Error:  
  Related Component:  AtmIf/5  
  Related Attribute:  interfaceName  
  Reason:  Unable to retrieve the LP Info from the  
           Interface Name of the atmIf.  
Prov  
  Too many semantic errors found, checking aborted.  
  This view cannot be activated.  
command failed
```

Related information for check Prov

See the following for information related to the check Prov command:

- [Activate Prov command \(page 25\)](#)
- [Commit Prov command \(page 61\)](#)
- [Confirm Prov command \(page 64\)](#)
- [Start Prov command \(page 216\)](#)
- [Stop Prov command \(page 227\)](#)

Clear -notificationId(<id>) -comment(<text>) aaserv command

Use the clear -notificationId(<id>) -comment(<text>) aaserv command to remove an alarm associated with a specific notification ID from the active alarm list (AAList).

For more information on the clear -notificationId(<id>) -comment(<text>) aaserv command, see

- [Properties for clear -notificationId\(<id>\) -comment\(<text>\) aaserv \(page 48\)](#)
- [Syntax for clear -notificationId\(<id>\) -comment\(<text>\) aaserv \(page 48\)](#)
- [Examples of the clear -notificationId\(<id>\) -comment\(<text>\) aaserv command \(page 49\)](#)
- [Related information for clear -notificationId\(<id>\) -comment\(<text>\) aaserv \(page 50\)](#)

Properties for clear -notificationId(<id>) -comment(<text>) aaserv

The following table describes the properties of the clear -notificationId(<id>) -comment(<text>) aaserv command:

Properties of the clear -notificationId(<id>) -comment(<text>) aaserv command

Mode	Impact	Scope	Component
Operational	Service	Device	ActiveAlarmServices

Syntax for clear -notificationId(<id>) -comment(<text>) aaserv

The following table describes the syntax for the clear -notificationId(<id>) -comment(<text>) aaserv command.

Syntax of the clear -notificationId(<id>) -comment(<text>) aaserv command

If you want to...	Use the following syntax:
Remove an active alarm with a specific notification ID from the active alarm list (AAList)	clear -notificationId(id) aaserv
Add an ASCII comment to the specific active alarm that is being removed from the AAList	clear -notificationId (id) -comment (text) aaserv

Examples of the clear -notificationId(<id>) -comment(<text>) aaserv command

You are user “debug”, and have two active alarms with notification IDs 082A and 082B that currently appear on the AAList:

```
Col/log Sp; 2002-06-18 15:42:56.09
SET major operator operationalCondition 00001000
ADMIN: locked OPER: enabled USAGE: idle
AVAIL: PROC: CNTRL:
ALARM: STBY: notSet UNKNW: false
Id: 082A Rel: Lp/0
Com: The component is locked
Int: 0/0/2/7470; osiState.cc; 669; VER4.1.10
Col/alarm Sp; 2002-06-18 15:42:57.33
SET major operator operationalCondition 00001000
ADMIN: locked OPER: enabled USAGE: idle
AVAIL: PROC: CNTRL:
ALARM: STBY: notSet UNKNW: false
Id: 082B Rel: Lp/0
Com: The component is locked
Int: 0/0/2/7468; osiState.cc; 669; VER4.1.10
```

To clear the 082A alarm from the AAList, enter the following command:

```
clear -notificationId(082A) aaserv
```

A response appears, stating that this alarm has been manually cleared by the user “debug”.

```
Col/alarm Sp; 2002-06-19 12:14:22.67
CLR cleared operator operationalCondition 00001000
ADMIN: unlocked OPER: enabled USAGE: active
AVAIL: PROC: CNTRL:
ALARM: STBY: notSet UNKNW: true
Id: 082A Rel: Lp/0
Com: Action by debug. This alarm has been manually
cleared.
The component is locked
Int: 0/0/2/7468; osiState.cc; 669; VER4.1.10
AAServ
ok 2002-06-19 12:14:22.68
```

The alarm is no longer listed in the AAList, and the action of clearing the alarm is logged in the standard operator log stream.

Attention: If a notification ID is not specified or does not exist, an error response is generated.

You can also add a custom comment in addition to the response that appears stating that the alarm is removed. The size of this comment is limited to 100 characters. To clear the same alarm, but this time with a custom comment attached, enter the following command:

```
clear -notificationId(082A) -comment(This is a test.)  
aaserv
```

A response appears, stating that this alarm has been manually cleared by debug. In addition, the comment appears, stating the custom value that was entered (in this case, that this is a test).

```
Col/log Sp; 2002-06-19 12:15:58.46  
CLR cleared operator operationalCondition 00001000  
ADMIN: unlocked OPER: enabled USAGE: active  
AVAIL: PROC: CNTRL:  
ALARM: STBY: notSet UNKNW: true  
Id: 082A Rel: Lp/0  
Com: Action by debug. This alarm has been manually  
cleared. This is a test.  
The component is locked  
Int: 0/0/2/7470; osiState.cc; 669; VER4.1.10  
AAServ  
ok 2002-06-19 12:15:58.47
```

As in the first example, the alarm is no longer listed in the AAList, and the manual clear (with the custom comment) is logged in the standard operator log stream.

Related information for clear -notificationId(<id>) -comment(<text>) aaserv

See the following for information related to the clear -notificationId(<id>)-comment(<text>) aaserv command:

- [Replay aaserv command \(page 181\)](#)

Clear Aps command on Multiservice Switch 7400

Use the clear Aps command to remove manual overrides to the automatic selection of the active line of a link protected by automatic protection switching (APS). This command clears the effects of the protectionLockout Aps and the switch Aps commands.

An APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. When no manual overrides are in effect, the APS system automatically determines the active line.

For more information on the clear Aps command, see

- [Properties for clear Aps \(page 51\)](#)
- [Syntax for clear Aps \(page 51\)](#)
- [Component instance parameter for clear Aps \(page 52\)](#)
- [Clearing APS overrides example \(page 52\)](#)
- [Related information for clear Aps \(page 52\)](#)

Properties for clear Aps

The following table describes the properties of the clear Aps command:

Properties of the clear Aps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	AutomaticProtectionSwitching (Aps)

Syntax for clear Aps

The following table describes the syntax for the clear Aps command.

Syntax of the clear Aps command

If you want to...	Use the following syntax:
Remove all manual overrides on an APS-protected line	clear Aps/<n>

Component instance parameter for clear Aps

An Aps component instance represents a link that is protected by APS. The Aps component manages both the working and protection lines. To remove manual overrides on a particular link, you specify the instance number of the Aps component:

Aps/ <n>

The instance value can be any integer between 0 and 15999.

Clearing APS overrides example

You have manually overridden the automatic selection of the active line on an APS-protected link (represented by Aps/4) using either the protectionLockout Aps command or the switch Aps command. You now want to remove the overrides. You enter the following command:

clear Aps/ <n>

The APS system now automatically selects the active line for the link.

Related information for clear Aps

See the following for information related to the clear Aps command:

- [ProtectionLockout Aps command on Multiservice Switch 7400 \(page 162\)](#)
- [Switch Aps command on Multiservice Switch 7400 \(page 231\)](#)

Clear Laps command on Multiservice Switch 15000 and Multiservice Switch 20000

Use the clear Laps command to remove manual overrides to the automatic selection of the active line of a link protected by line automatic protection switching (Line APS). This command clears the effects of the protectionLockout Laps and the switch Laps commands.

A Line APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. When no manual overrides are in effect, the line APS system automatically determines the active line.

For more information on the clear Laps command, see

- [Properties for clear Laps \(page 53\)](#)
- [Syntax for clear Laps \(page 53\)](#)
- [Component instance parameter for clear Laps \(page 54\)](#)
- [Clearing LAPS overrides example \(page 54\)](#)
- [Related information for clear Laps \(page 54\)](#)

Properties for clear Laps

The following table describes the properties of the clear Laps command:

Properties of the clear Laps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	Line AutomaticProtectionSwitching (Laps)

Syntax for clear Laps

The following table describes the syntax for the clear Aps command.

Syntax of the clear Laps command

If you want to...	Use the following syntax:
Remove all manual overrides on an LAPS-protected line	clear Laps/<n>

Component instance parameter for clear Laps

An Laps component instance represents a link that is protected by line APS. The Laps component manages both the working and protection lines. To remove manual overrides on a particular link, you specify the instance number of the Laps component:

Laps / <n>

The instance value can be any integer between 0 and 15999.

Clearing LAPS overrides example

You have manually overridden the automatic selection of the active line on a LAPS-protected link (represented by Laps/4) using either the protectionLockout Laps command or the switch Laps command. You now want to remove the overrides. You enter the following command:

clear Laps / <n>

The LAPS system now automatically selects the active line for the link.

Related information for clear Laps

See the following for information related to the clear Laps command:

- [ProtectionLockout Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 165\)](#)
- [Switch Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 236\)](#)

Clear Nmis <interface> Session command

The clear Nmis <interface> Session command lets you terminate an individual user session and close its TCP connection. You can terminate user sessions on the telnet, FTP, and FMIP network management interfaces. For information on these interfaces, see NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

If you clear a Telnet session which has an outgoing client connection, the client connection also terminates.

For more information on the clear Nmis <interface> Session command, see

- [Properties for clear Nmis <interface> Session \(page 55\)](#)
- [Syntax for clear Nmis <interface> Session \(page 55\)](#)
- [Session parameters for clear Nmis <interface> Session \(page 56\)](#)
- [Clearing a session example \(page 56\)](#)
- [Related information for clear Nmis <interface> Session \(page 57\)](#)

Properties for clear Nmis <interface> Session

The following table describes the properties of the clear Nmis <interface> Session command.

Properties of the clear Nmis <interface> Session command

Mode	Impact	Scope	Components
Operational or Provisioning	System Administration	Application	NetworkManagementInterfaceSystem Telnet Session (Nmis Telnet Session) NetworkManagementInterfaceSystem Fmip Session (Nmis Fmip Session) NetworkManagementInterfaceSystem Ftp Session (Nmis Ftp Session)

Syntax for clear Nmis <interface> Session

The following table describes the syntax for the clear Nmis <interface> Session command.

Syntax of the clear Nmis <interface> Session command

If you want to...	Use the following syntax:
Terminate a Telnet user session	clear Nmis Telnet Session/<n>
(1 of 2)	

Syntax of the clear Nmis <interface> Session command (continued)

If you want to...	Use the following syntax:
Terminate an FMIP user session	clear Nmis Fmip Session/<n>
Terminate an FTP user session	clear Nmis Ftp Session/<n>
(2 of 2)	

Session parameters for clear Nmis <interface> Session

You specify which user session you want to terminate using the Session subcomponents of the *NetworkManagementInterfaceSystem (Nmis)* component.

An instance of a *Session* component represents each user session. If you display the *Session* subcomponents of a network management interface, you get information on all the current sessions. For example, the following command displays the current FTP sessions:

```
display Nmis Ftp Session/*
```

Session parameters for the clear Nmis <interface> Session command

Component	Description
Nmis	Always enter this component.
Telnet Session/<n>	If you want to clear a Telnet user session, enter the number of the Telnet user session. If the Telnet session has an outgoing client connection, the client connection also terminates.
Fmip Session/<n>	If you want to clear an FMIP user session, enter the number of the FMIP user session.
Ftp Session/<n>	If you want to clear an FTP session, enter the number of the FTP user session.

Clearing a session example

You are the system administrator and you want to terminate a telnet user session. To determine the instance number of the session, you display all current Telnet user sessions using the following command:

```
display Nmis Telnet Session/*
```

You receive the following response:

```
Nmis Telnet Session/*
+-----+-----+-----+-----+
|Session|userid|dataStr  |address  |port  |
|        |      |eams     |         |      |
|        |      |a d l s r|         |      |
|        |      |l e o c t|         |      |
+-----+-----+-----+-----+
```

Command reference

		a b g n s		
1	maryb	*	132.0.1.180	36135
2	stevd	*	132.0.1.181	36136

From this display, you determine that you want to terminate session 2. You enter the following command:

```
clear Nmis Telnet Session/2
```

Related information for clear Nmis <interface> Session

For more information related to the clear Nmis <interface> Session command see the following:

- [Display command \(page 80\)](#)
- [Logout command \(page 128\)](#)
- [Me command \(page 132\)](#)

Clear Prov command

Use the clear Prov command to remove nonpermanent components and their subcomponents from the edit view. This command does not affect permanent components (components that you cannot delete).



CAUTION

Possible loss of provisioning data

The clear Prov command deletes all nonpermanent components from the edit view. If you have not saved your provisioning data in a saved view before using the clear Prov command, you will lose your provisioning data.

For more information on the clear Prov command, see

- [Properties for clear Prov \(page 58\)](#)
- [Syntax for clear Prov \(page 58\)](#)
- [Deleting the components of a removed feature parameter for clear Prov \(page 59\)](#)
- [Examples for clear Prov \(page 59\)](#)
- [Related information for clear Prov \(page 60\)](#)

Properties for clear Prov

The following table describes the properties of the clear Prov command:

Properties of the clear Prov command

Mode	Impact	Scope	Components
Provisioning	System Administration	Application	ProvisioningSystem (Prov)

Syntax for clear Prov

The following table describes the syntax for the clear Prov command.

Syntax of the clear Prov command

If you want to...	Use the following syntax:
Remove all nonpermanent components and their subcomponents from the edit view	clear Prov
Remove all nonpermanent components and their subcomponents associated with a removed feature from the edit view	clear -removedFeature Prov

Deleting the components of a removed feature parameter for clear Prov

You can specify that the provisioning system remove only the components associated with a removed feature using the removedFeature option:

-removedFeature

Use this option when you have removed one or more features from one or more LPTs. It specifies that the system remove from the edit view all components, both permanent and nonpermanent, which have had their associated software unloaded.

Examples for clear Prov

The following examples show how to use the clear Prov command:

- [Clearing all temporary components from the edit view example \(page 59\)](#)
- [Clearing components associated with a removed feature from the edit view example \(page 59\)](#)

Clearing all temporary components from the edit view example

You want to clear all temporary components from the edit view. First, to display all the top-level components, you enter the following command:

list

You receive the following response:

```
FrUni/1
Sw
Shelf
```

To delete the temporary components, enter the following command:

clear Prov

You issue the list command again.

list

You receive the following response:

```
Sw
Shelf
```

Clearing components associated with a removed feature from the edit view example

This example shows how to clear all components for a removed feature. Assume that you have removed the frameRelayUni (FrUni) feature software from the feature list of all LPs.

To display all the top-level components, you enter the following command:

list

You receive the following response:

```
Col/*  
Sw  
Shelf  
Lp/*  
Rtg  
Mod  
Ac  
Npi/*  
FrUni/*
```

To clear the components for a removed feature, you enter the following command:

```
clear -removedFeature Prov
```

To display all the top-level components, you enter the following command:

```
list
```

You receive the following response:

```
Col/*  
Sw  
Shelf  
Lp/*  
Rtg  
Mod  
Ac  
Npi/*
```

Related information for clear Prov

See the following for information related to the clear Prov command:

- [Copy Prov command \(page 72\)](#)
- [Delete command \(page 77\)](#)
- [List command \(page 110\)](#)
- [Start Prov command \(page 216\)](#)

Commit Prov command

Use the commit Prov command to set the current view of the provisioning data as the committed view. This activity can entail saving the current view in portable or commit formats.

The committed view is the configuration to which the node defaults following a CP reset, restart, or switchover. The following conditions must be met before you can commit the current view:

- You must store the current view in a saved view (See [Save Prov command \(page 198\)](#)) prior to committing it. If you have not previously saved the current view with a unique filename, you can both save and commit it by using the file option (See [Specifying a file name parameter for commit Prov \(page 62\)](#)) to specify a filename for the view.
- In a dual-CP node, disks must be synchronized.

In a dual-CP node, the commit Prov command can cause a reload of the standby CP.

Use the commit Prov command after successfully issuing the activate Prov and confirm Prov commands. If you issue the commit Prov command before the confirm Prov command, the system automatically confirms the view before committing the view. If you issue the commit Prov command from operational mode, it fails if another operator session is in provisioning mode.

For more information on the commit Prov command, see

- [Properties for commit Prov \(page 61\)](#)
- [Syntax for commit Prov \(page 62\)](#)
- [Parameters for commit Prov \(page 62\)](#)
- [Examples for commit Prov \(page 62\)](#)
- [Related information for commit Prov \(page 63\)](#)

Properties for commit Prov

The following table describes the properties of the commit Prov command.

Properties of the commit Prov command

Mode	Impact	Scope	Components
Operational or Provisioning	Service	Application	ProvisioningSystem (Prov)

Syntax for commit Prov

The following table describes the syntax for the commit Prov command.

Syntax of the commit Prov command

If you want to...	Use the following syntax:
Make the current view the committed view	commit Prov
Specify a file name for the committed view	commit -file(<view_name>) Prov

Parameters for commit Prov

There are two types of parameters for the commit Prov command: .

- [Force override parameter when restore is possible for commit Prov \(page 62\)](#)
- [Specifying a file name parameter for commit Prov \(page 62\)](#)

Force override parameter when restore is possible for commit Prov

If the journaled current view can be restored, then the commit Prov command will cause the journaled current view to be purged, and a restore will no longer be possible. In this case, the -force option is required for the commit Prov command to proceed. Note that a restore is only possible if the attribute *restorePossible* is set to yes.

Specifying a file name parameter for commit Prov

You can specify a name for the committed view using the file option:

```
-file(<view_name>)
```

Enter a name for the saved version of the current view. For information on filename syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

Examples for commit Prov

The following examples show how to use the commit Prov command:

- [Committing the current view example \(page 62\)](#)
- [Specifying a filename for the committed view example \(page 63\)](#)

Committing the current view example

You want to make the current view of the provisioning data the committed view. For this example, the current view is PPS.full.001. You enter the following:

```
commit Prov
```

You receive the following response:

```
Prov
  Saving the current view into PPS.full.001 (with
  commit,portable formats) ...
Prov
  The committed file is PPS.full.001.
ok
```

Specifying a filename for the committed view example

You want to specify a filename (for this example, `commit1`) to save the committed view. You enter the following:

```
commit -file(commit1) Prov
```

You receive the following response:

```
Prov
  Saving the current view into commit1.full.001 (with
  commit,portable formats)
  ...
Prov
  The committed file is commit1.full.001.
ok
```

Related information for commit Prov

See the following for information related to the `commit Prov` command:

- [Activate Prov command \(page 25\)](#)
- [Confirm Prov command \(page 64\)](#)
- [Save Prov command \(page 198\)](#)

Confirm Prov command

Issue the confirm Prov command after the activate Prov command to activate the edit view. After the confirmation is complete, the current view is the same as the edit view.

You must confirm an the activation of a new view within 20 minutes. After 20 minutes without confirmation, the node restarts using the last committed view. The system generate a warning alarm every five minutes until you enter the confirm Prov command.



CAUTION

If you do not confirm the activate Prov command within 20 minutes of issuing it (see [Activate Prov command \(page 25\)](#)) a system restart occurs and the system reactivates the last committed view (see [Commit Prov command \(page 61\)](#)). A service disruption occurs while the restart is in progress.

You can use the confirm Prov command in either provisioning or operational mode. If you are in operational mode when you issue the confirm Prov command, and another operator is in provisioning mode, the command fails.

For more information on the confirm Prov command, see

- [Properties for confirm Prov \(page 64\)](#)
- [Syntax for confirm Prov \(page 64\)](#)
- [Confirming the activation of a new view into the current view example \(page 65\)](#)
- [Related information for confirm Prov \(page 65\)](#)

Properties for confirm Prov

The following table describes the properties of the confirm Prov command.

Properties of the confirm Prov command

Mode	Impact	Scope	Components
Operational or Provisioning	Service	Application	ProvisioningSystem (Prov)

Syntax for confirm Prov

The following table describes the syntax for the confirm Prov command.

Syntax of the confirm Prov command

If you want to...	Use the following syntax:
Confirm a new provisioning view into the current view, after issuing the activate Prov command	confirm Prov

Confirming the activation of a new view into the current view example

You want to confirm activation of a new provisioning view into the current view. You enter the following command:

```
confirm Prov
```

You receive the following response:

```
Prov; 1998-11-20 14:10:47.49
CLR cleared operator
operationalCondition          70000007
ADMIN: un
ed      OPER: enabled        USAGE: busy
AVAIL:                          PROC: reporting      CNTRL:
ALARM:                          STBY: notSet        UNKNW: false
Id: 0F000021  Rel: Lp/0
Com: Activation confirmed. Rollback will not occur.
Int: 15/1/3/63783;
casResolverVerbProvConfirm.cc;171; p4.0d.27
Prov
```

If you enter the confirm Prov command before the activate Prov command, you receive the following response:

```
Prov
You must activate the edit view first, then confirm.
command failed
```

This message indicates that the confirm Prov command failed because you did not activate the new provisioning view.

Related information for confirm Prov

See the following for information related to the confirm Prov command:

- [Activate Prov command \(page 25\)](#)
- [Commit Prov command \(page 61\)](#)

Continue Prov command

The continue Prov command enables a hitless software upgrade that has been paused to continue. When issued, the continue Prov command causes the migration node to reset and the migration switchover to continue.

For more information on the continue Prov command, see

- [Properties for continue Prov \(page 66\)](#)
- [Syntax for continue Prov \(page 66\)](#)
- [Force parameter for continue Prov \(page 66\)](#)
- [Examples for continue Prov \(page 66\)](#)
- [Related information for continue Prov \(page 67\)](#)

Properties for continue Prov

The following table describes the properties of the continue Prov command.

Properties of the continue Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for continue Prov

The following table describes the syntax for the continue command.

Syntax of the continue command

If you want to...	Use the following syntax:
Restart a paused software migration activation	continue Prov
Force the migration activation to continue by resetting the node	continue -force Prov

Force parameter for continue Prov

You can specify that the hitless software migration activation continues by using the force option. The force option causes the migration node to reset and the migration switchover to continue.

Examples for continue Prov

The following examples illustrate how to use the continue Prov command:

- [Continuing a hitless software upgrade \(page 67\)](#)
- [Forcing a hitless software upgrade to continue \(page 67\)](#)

Continuing a hitless software upgrade

If an application does not behave properly during a migration switchover, then the hitless software upgrade automatically pauses before migration switchover occurs. This pause allows you to review all visible migration alarms before continuing or stopping the hitless software upgrade. To continue the hitless software upgrade, issue the following command:

```
continue Prov
```

Forcing a hitless software upgrade to continue

If you have configured a spare CP but it is unavailable, the migration activation fails. To force the migration activation to continue, reset the node by issuing the following command:

```
continue -force Prov
```

Attention: If the migration pauses because of a fault, or if a fault occurs during a pause, you must issue the `continue -force prov` command if you wish to continue despite the fault condition.

Related information for `continue Prov`

See the following for information related to the `continue Prov` command:

- [Activate Prov command \(page 25\)](#)
- [Apply Prov command \(page 34\)](#)
- [Check Prov command \(page 42\)](#)
- [Clear Prov command \(page 58\)](#)
- [Commit Prov command \(page 61\)](#)
- [Confirm Prov command \(page 64\)](#)
- [Continue Prov command \(page 66\)](#)
- [Copy Prov command \(page 72\)](#)
- [End Prov command \(page 91\)](#)
- [Load Prov command \(page 121\)](#)
- [Save Prov command \(page 198\)](#)
- [Start Prov command \(page 216\)](#)
- [Stop Prov command \(page 227\)](#)
- [Tidy Prov command \(page 252\)](#)

Copy Fs command

The copy Fs (cp Fs) command lets you copy files or directories in the Nortel Networks Multiservice Switch file system. You can copy an individual source file or a source directory and all its subdirectories to a destination in the file system.

The copy Fs command does not overwrite existing files. If you specify an existing file as a destination, the command fails. If you want to overwrite a file, you must first remove it using the remove Fs command.

When you copy a protected file, the new file is not protected.

When you use this command, avoid copying files into the root directory (/). Reserve the root directory for directories only.

For more information on the copy Fs command, see

- [Properties for copy Fs \(page 68\)](#)
- [Syntax for copy Fs \(page 68\)](#)
- [Parameters for copy Fs \(page 69\)](#)
- [Examples for copy Fs \(page 70\)](#)
- [Related information for copy Fs \(page 70\)](#)

Properties for copy Fs

The following table describes the properties of the copy Fs command.

Properties of the copy Fs command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for copy Fs

The following table describes the syntax for the copy command.

Syntax of the copy command

If you want to...	Use the following syntax:
Copy a file	copy -source(<filepath>) -destination(<filepath>) Fs
	(1 of 2)

Syntax of the copy command (continued)

If you want to...	Use the following syntax:
Copy a file into a directory	copy -source(<filepath>) -destination(<directorypath>) Fs
Copy a directory and all its contents (including all subdirectories) into a directory	copy -source(<directorypath>) -destination(<directorypath>) -recursive Fs
(2 of 2)	

Parameters for copy Fs

There are two types of parameters for the copy Fs command:

- [Source and destination parameters for copy Fs \(page 69\)](#)
- [Copy subdirectories parameter for copy Fs \(page 69\)](#)

Source and destination parameters for copy Fs

You can specify which file or directory you want to copy using the source option. You can specify where you want to put the copy using the destination option.

For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

Source and destination options for the copy Fs command

Option	Description
-source (<filepath>) -source (<directorypath>)	Enter the absolute or relative path to the source file or directory. If you specify the path of a directory, the destination must be also be a directory and you must use the recursive option. You must enter this option.
-destination (<filepath>) -destination (<directorypath>)	Enter the absolute or relative path to the destination file or directory. If you are copying a file to directory, the directory must already exist in the file system. You must enter this option.

Copy subdirectories parameter for copy Fs

You can specify that you want to copy all the subdirectories of a directory using the recursive option:

-recursive

When you use the recursive option, the system creates the complete subdirectory hierarchy of the source directory in the destination directory and copies all the files into the destination directory hierarchy.

If the destination directory exists, the system create a directory in it with the same name as the source and copies all the contents of the source directory into that new directory. If the destination directory does not exist, the system creates it and copies all the contents of the source directory into it.

Examples for copy Fs

The following examples illustrate how to use the copy Fs command:

- [Copying a file example \(page 70\)](#)
- [Copying a directory and its subdirectories example \(page 70\)](#)

Copying a file example

Your current working directory is /spooled/closed/account. You want to copy the file account.old in the current working directory into the /tmp directory. You enter the following command:

```
copy -source("account.old") -destination("/tmp") Fs
```

You now want to copy that same file into the /spooled/closed directory, which is one directory above your current working directory. You enter the following command:

```
copy -source("account.old") -destination("../") Fs
```

Copying a directory and its subdirectories example

Your current working directory is /spooled. You want to copy all the contents of the closed directory, including all subdirectories into the /tmp directory. You enter the following command:

```
copy -source("closed") -destination("/tmp") -recursive  
Fs
```

The /tmp directory now has a closed subdirectory with the same contents as the /spooled/closed directory.

You then decide that you want to copy the same closed directory into a new, directory called /closedtmp. You enter the following command:

```
copy -source("closed") -destination("/closedtmp")  
-recursive Fs
```

There is now a new /closedtmp directory with the same contents of the /spooled/closed directory.

Related information for copy Fs

See the following for information related to the copy Fs command:

- [ListFile Fs command \(page 117\)](#)

- [MakeDirectory Fs command \(page 130\)](#)
- [Move Fs command \(page 134\)](#)
- [Remove Fs command \(page 176\)](#)
- [WorkingDir Fs command \(page 276\)](#)

Copy Prov command

Use the copy Prov command to copy the entire current view into the edit view, to copy individual components from the current view into the edit view, or to copy components within the edit view alone.

The following are characteristics of the copy Prov command:

- If you use the command alone with no options, to copy a full view, the system copies all components and related data such that the edit view is identical to the current view.
- If you use the command to copy a component or partial view (edit view to edit view or current view to edit view), the system can change data so that it does not conflict with existing data (for example, DNAs, passwords, and all link attributes). In situations where the system does change data, a warning appears to specify that the system has modified values.

For more information on the copy Prov command, see

- [Properties for copy Prov \(page 72\)](#)
- [Syntax for copy Prov \(page 72\)](#)
- [Parameters for copy Prov \(page 73\)](#)
- [Examples for copy Prov \(page 74\)](#)
- [Related information for copy Prov \(page 76\)](#)

Properties for copy Prov

The following table describes the properties of the copy Prov command.

Properties of the copy Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for copy Prov

Copy Prov allows you to copy entire views or partial views from both the current view and the edit view into the edit view. The view from which you copy is the source view.

The default source view depends on the options you specify:

- If you do not use any options, the default source view is the current view, and the system copies the complete current view into the edit view. This is useful if you have made changes to the edit view but for whatever reason wish to return to the pre-change configuration.

- If you use the source option only, the default source view is the current view.
- If you use both the source and the destination options, the default source view is the edit view. However, you can use the current option to change the default source view to the current view.

The following table describes the syntax for the copy Prov command.

Syntax of the copy Prov command

If you want to...	Use the following syntax:
Copy the current view into the edit view	copy Prov
Copy a component and its subcomponents into the edit view	copy -source(<component_name>) Prov
Copy a component from the edit view and save it under another name, also within the edit view	copy -source(<component_name>) -destination(<component_name>) Prov
Copy a component from the current view and save it under another name in the edit view	copy -source(<component_name>) -current -destination(<component_name>) Prov
Copy a component without its subcomponents from the current view to the edit view	copy -source(<component_name>) -nonrecursive Prov

Parameters for copy Prov

There are four types of parameters for the copy Prov command:

- [Copying a component parameter for copy Prov \(page 73\)](#)
- [Copying and renaming a component parameter for copy Prov \(page 74\)](#)
- [Copying from the current view parameter for copy Prov \(page 74\)](#)
- [Nonrecursive parameter for copy Prov \(page 74\)](#)

Copying a component parameter for copy Prov

You can specify that the provisioning system copy a component into the edit view using the source option:

-source(<component_name>)

The source option causes the system to copy the identified component from either the edit view or the current view, depending on which option or combination of options you use, as follows:

- If you use only the source option, the current view is the source view.

- If you use the destination option in combination with the source option, the edit view is the source view.
- If you use the destination and current options in combination with the source option, the current view is the source view.

If there are any conflicts between component names in the edit view, then the copy fails and no changes occur to the edit view.

Copying and renaming a component parameter for copy Prov

You can specify that the provisioning system copy a component into the edit view and rename it using the destination option:

-destination(<component_name>)

This option is valid only if you use the source option.

Copying from the current view parameter for copy Prov

You can specify that the provisioning system copy from the current view using the current option:

-current

The current option causes the system to change the default source view to the current view when copying a component.

This option is valid only if you use the source and destination options.

Nonrecursive parameter for copy Prov

You can specify that the provisioning system copy into the edit view a component, but not its subcomponents, using the nonrecursive option:

-nonrecursive

This option is valid only if you use the source option.

Examples for copy Prov

The following section contains examples that show how to use the copy Prov command:

- [Copying the current view into the edit view example \(page 75\)](#)
- [Copying a component into the edit view example \(page 75\)](#)
- [Copying and renaming a component within the edit view example \(page 75\)](#)
- [Copying a component from the current view to the edit view, and renaming it in the edit view example \(page 76\)](#)
- [Copying a component but not its subcomponents example \(page 76\)](#)

Copying the current view into the edit view example

You want to copy the current view into the edit view, replacing the edit view. You enter the following command:

```
copy Prov
```

You receive the following response:

```
Prov  
ok
```

Copying a component into the edit view example

The edit view requires a *Vr* component. You want to copy the *Vr/1* component and its subcomponents from the current view into the edit view. You enter the following command:

```
copy -source(Vr/1) Prov
```

You receive the following response:

```
Prov  
ok
```

To list all of the *Vr* components, you enter the following command:

```
list Vr/*
```

You receive following response:

```
Vr/1  
ok
```

Copying and renaming a component within the edit view example

Use the copy Prov command to copy the *Vr/1* component from the edit view to a new component under a different name, also in the edit view. You enter the following command:

```
copy -source(Vr/1) -destination(Vr/2) Prov
```

You receive the following response:

```
Prov  
ok
```

To list all of the *Vr* components, you enter the following command:

```
list Vr/*
```

You receive following response:

```
Vr/1  
Vr/2  
ok
```

You have now created the *Vr/2*, with the identical configuration as *Vr/1*. This procedure is useful if you provision a component in a certain manner and want to duplicate it exactly as another instance of the same component.

Copying a component from the current view to the edit view, and renaming it in the edit view example

Use the copy Prov command to copy the *Vr/1* component from the current view to a new component under a different name, in the edit view. You enter the following command:

```
copy -source(Vr/1) -current -destination(Vr/2) Prov
```

You receive the following response:

```
Prov  
ok
```

To list all of the *Vr* components, you enter the following command:

```
list Vr/*
```

You receive following response:

```
Vr/2  
ok
```

You have now created the *Vr/2* component, with the identical configuration as the *Vr/1* component in the current view.

Copying a component but not its subcomponents example

Use the copy Prov command to copy the *Vr/1* component, but not its subcomponents, from the current view to the edit view. You enter the following command:

```
copy -source(Vr/1) -nonrecursive Prov
```

You receive the following response:

```
Prov  
ok
```

Attention: The system automatically creates the required subcomponents with default provisioning data when you use this option.

Related information for copy Prov

See the following for information related to the copy Prov command:

- [Add command \(page 31\)](#)
- [Clear Prov command \(page 58\)](#)
- [Start Prov command \(page 216\)](#)

Delete command

Use the delete (del) command to remove a component (and its subcomponents) from the edit view. You can only use the delete command in provisioning mode.

The system also removes all provisioned links between the deleted component and any other component.

When you activate the edit view, the system removes the deleted components and subcomponents from the running system. This process terminates the service provided by these components and their subcomponents.

Attention: You can use the copy Prov command to undo an accidental delete. See [Copy Prov command \(page 72\)](#).

For more information on the delete command, see

- [Properties for delete \(page 77\)](#)
- [Syntax for delete \(page 78\)](#)
- [Examples for delete \(page 78\)](#)
- [Related information for delete \(page 78\)](#)

Properties for delete

The following table describes the properties of the delete command.

Properties of the delete command

Mode	Impact	Scope	Components
Provisioning	Configuration	Depends on component	All

Syntax for delete

The following table describes the syntax for the delete command.

Syntax of the delete command

If you want to...	Use the following syntax:
Delete a component and all its associated subcomponents from the edit view	delete <component_name>

Examples for delete

The following examples show how to use the delete command:

- [Deleting a component example \(page 78\)](#)
- [Deleting a permanent component example \(page 78\)](#)

Deleting a component example

You want to delete a *LogicalProcessor* (*Lp*) component (*Lp/2* for this example). You enter the following command:

```
delete Lp/2
```

You receive the following response:

```
Lp/2
A total of 2 components have been deleted.
ok
```

Deleting a permanent component example

You want to delete the permanent *Shelf* component. You enter the following command:

```
delete Shelf
```

You receive the following response:

```
Shelf
The 'Delete' command is not allowed for this component.
commandfailed
```

The command failed because you some required components cannot be removed using the delete command. To remove these components, see [Clear Prov command \(page 58\)](#).

Related information for delete

See the following for information related to the delete command:

- [Add command \(page 31\)](#)
- [Clear Prov command \(page 58\)](#)
- [Copy Prov command \(page 72\)](#)

- [Start Prov command \(page 216\)](#)

Display command

The display (d) command lets you view the attributes of one or more components. You can display the operational and provisionable attributes of both the current and edit view, in either list or tabular format.

When you are in operational mode, the display command assumes you want to view operational attributes in the current view. When you are in provisioning mode, the display command assumes you want to view provisionable attributes in the edit view. The command uses these default associations, which are summarized in [Properties of the set command \(page 205\)](#), whenever possible. You can override the associations using command options.

By default, attributes are displayed in tabular format. If the number of attributes requested does not fit in a table, the system only shows the most useful attributes. To see all the attributes, use the list format of display command.

The display command supports all command wildcarding capabilities. See [Command wildcarding \(page 18\)](#).

For more information on the display command, see

- [Properties for display \(page 80\)](#)
- [Syntax for display \(page 81\)](#)
- [Parameters for display \(page 81\)](#)
- [Examples for display \(page 84\)](#)
- [Related information for display \(page 90\)](#)

Properties for display

The display command works with all components. Some attributes require a higher impact than passive (defined by their read access value) to display. To find specific impact and scope information, see NN10600-060 *Nortel Networks Multiservice Switch 7400/15000/20000 Component Reference* or use the help command.

The following table describes the properties of the display command.

Properties of the display command

Mode	Impact	Scope	Attribute	View
Operational	Passive	Depends on component	Operational	Current
Provisioning	Passive	Depends on component	Provisionable	Edit

Syntax for display

The following table describes the syntax for the display command.

Syntax of the display command

If you want to...	Use the following syntax:
Display provisionable or operational attributes	display <component_name>
Display attribute values type	display <component_name>*
Display all top-level component types	display
Display operational attributes while in provisioning mode	display -operationalData<component_name>
Display provisionable attributes while in operational mode	display -provisionedData <component_name>
Display attribute values in the current view	display -current <component_name>

Parameters for display

The following items are the parameters of the display command:

- [Component parameter for display \(page 81\)](#)
- [Attribute and group parameters for display \(page 82\)](#)
- [Override default parameters for display \(page 83\)](#)
- [Display format parameter for display \(page 83\)](#)
- [Simple attribute value parameters for display \(page 84\)](#)
- [Complex attribute value parameters for display \(page 84\)](#)

Component parameter for display

If you only enter a component as a parameter to the display command, you get all attributes of the type and view associated with the current command mode (see [Properties of the set command \(page 205\)](#) for the associations). If,

however, you specify an operational component while in provisioning mode, you get attributes from the current view. (Operational information does not exist in the edit view.) The system informs you that it is displaying the current view and not the associated edit view.

You can use wildcarding to view attributes from more than one component. With type wildcarding, you can substitute the asterisk (*) wildcard character for the last component type-instance pair to view attributes from all subcomponents. The asterisk must be the last character of the command.

With instance wildcarding, you can substitute a wildcard (*) or a wildcard pattern for an instance value of a component. If you are displaying a component with multiple indexes, you can specify the value for a particular index, or you can wildcard one or more of its index values. Any unspecified index values will default to a wildcard (*).

Components for the display command

Option	Description
<component_name>	Enter the name of the component.
<component_type>/*	Use an asterisk for an instance value to view attributes from all instances of a component type.
<component_name> *	Use an asterisk as the last component type-instance pair to view attributes from all subcomponents of a component. A table displays for each subcomponent.
<component_type>/ <index>, *, ...	Use an asterisk for one or more index values to view attributes from all instances of a multi-indexed component. At least the first index must be specified. Unspecified indices default to *.
<component_type>/* <component_type>/* ...	Use an asterisk for more than one instance value to view attributes from all instances of multiple components in the hierarchy. Only wildcarded instances appear as columns in the table.

Attribute and group parameters for display

You can specify exactly which attribute or group you want to view using the attribute and group parameters. When you specify an attribute or group, it displays even if its type conflicts with the current command mode. You can, for example, specify that you want to view a provisionable attribute while in operational mode. That attribute displays from the current view.

If, however, you specify an operational attribute while in provisioning mode, you get information from the current view since there are no operational attributes in the edit view. In this case, the system informs you that it is displaying information from the current view and not the associated edit view.

You can specify attributes and groups in combination with instance wildcarding only.

Attributes and groups for the display command

Option	Description
<attribute>	Enter the name of the attribute. You can enter a list of attributes or groups, separated by commas (,) to view many attributes.
<group>	Enter the name of the group. You can enter a list of attributes or groups, separated by commas (,) to view many attributes.

Override default parameters for display

You can override the default attribute type and view associations using the `operationalData`, `provisionedData`, and `current` options.

Attribute type options for the display command

Option	Description
<code>-operationalData (-o)</code>	Use this option to view operational attributes while in provisioning mode. Attributes from the current view display since there are no operational attributes in the edit view.
<code>-provisionedData (-p)</code>	Use this option to view provisionable attributes while in operational mode.
<code>-current (-c)</code>	Use this option to view attributes in the current view when in provisioning mode.

Display format parameter for display

When you use wildcards to specify a component, the default format is tabular. The first row of the tabular output labels the components and attributes in the table. The component columns use double horizontal ruling (===) for their label, while attribute columns use single horizontal ruling (---). The remaining rows contain the attribute values for each component instance matched by wildcarding.

The system displays as many attributes as fit within the screen width. If all the attributes do not fit in the table, you can change to list format using the `noTabular` option:

`-noTabular`

You can abbreviate the option as follows:

`-nTabular`

Simple attribute value parameters for display

Simple attribute value parameters consist of an expression that contains an attribute, a relational operator, and a value. A relational operator can be equal (=) or not equal (!=). Parentheses can be used, but are optional. See [Displaying components using simple filtering example \(page 89\)](#) for an example of simple attribute value parameters.

Complex attribute value parameters for display

Complex attribute value parameters are formed when simple attribute value parameters are joined using the following logical operators: AND and OR. A maximum of three simple expressions can be joined. Parentheses can be used, but are optional. See [Displaying components using complex filtering example \(page 89\)](#) for an example of complex attribute value parameters.

Applying both instance and attribute value parameters

You can combine both instance filtering and attribute value parameters to the same component instance. The format is:

`<ComponentClass>/<instance>(attribute value)`

Instance can be a wildcard (*) or a wildcard pattern. See [Displaying components using both instance and attribute value filtering \(page 90\)](#) for an example.

Examples for display

The following examples illustrate how to use the display command:

- [Displaying a component example \(page 85\)](#)
- [Displaying attributes and groups example \(page 85\)](#)
- [Displaying a wildcarded instance example \(page 86\)](#)
- [Displaying a wildcarded type example \(page 87\)](#)
- [Overriding defaults example \(page 87\)](#)
- [Displaying in list format example \(page 88\)](#)
- [Displaying a multi-indexed component example \(page 89\)](#)
- [Displaying components using simple filtering example \(page 89\)](#)
- [Displaying components using complex filtering example \(page 89\)](#)

- [Displaying components using both instance and attribute value filtering \(page 90\)](#)

Displaying a component example

You are currently in operational command mode and you want to view the operational attributes of the node. You enter the following command:

```
display Shelf
```

You receive the following information from the current view:

```
Shelf
  busOperatingMode = dualBus
  hardwareFailures =
  numberOfSlots    = 16
  revertibleTimerCountdown = 0 seconds
```

You are now in provisioning mode and have been provisioning logical processor 4. You want to view the provisionable attributes of this logical processor, so you enter the following command:

```
display Lp/4
```

You receive the following information from the edit view:

```
Lp/4
  mainCard = Shelf Card/4
  spareCard =
  logicalProcessorType = Sw Lpt/ATM
  linkToApplications =
  customerIdentifier = 0
```

Displaying attributes and groups example

You are in operational mode and you want to view the *activeCard* attribute for logical processor 0. You enter the following command:

```
display Lp/0 activeCard
```

You receive the following information from the current view:

```
Lp/0
  activeCard = Shelf Card/0
```

You now want to also see, along with the *activeCard* attribute, all the attributes in the Provisioned group (*mainCard*, *spareCard*, *logicalProcessorType*, and *linkToApplications*). You enter the following command:

```
display Lp/0 activeCard, Provisioned
```

You receive the following information from the current view:

```
Lp/0
  activeCard = Shelf Card/0
  mainCard   = Shelf Card/0
  spareCard  = Shelf Card/15
  logicalProcessorType = Sw Lpt/CP
  linkToApplications =
```

Displaying a wildcarded instance example

You are currently in operational command mode and you want to view the operational attributes of all the collectors, which are represented by instances of the *Collector* component. You enter the following command:

```
display Collector/*
```

You receive the following information from the current view:

```
Col/*
+====+-----+-----+-----+
| Col |currentQue|recordsRx |recordsDis
|     |ueSize   |          |carded
+====+-----+-----+-----+
|acc  |         0|         0|         0
|ala  |         0|        32|         0
|log  |         0|         0|         0
|deb  |         0|         0|         0
|scn  |         0|         0|         0
|trap |         0|         0|         0
|stats|         0|         0|         0
|rts  |         0|         0|         0
```

You now want to view the *recordsRx* attribute of all *Agent* components, which are subcomponents of *Collector*. You enter the following command:

```
display Collector/* Agent/* recordsRx
```

You receive the following information from the current view:

```
Col/* Ag/*
+====+-----+-----+
| Col | Ag |recordsRx |
+====+-----+-----+
|acc  | 0 |         0|
|acc  | 1 |         0|
|ala  | 0 |        32|
|ala  | 1 |         0|
|log  | 0 |         2|
|deb  | 0 |         0|
|deb  | 1 |         0|
|scn  | 0 |         0|
|scn  | 1 |         0|
|trap | 0 |         0|
|trap | 1 |         0|
|stats| 0 |         0|
|stats| 1 |         0|
|rts  | 0 |         0|
|rts  | 1 |         0|
```

Displaying a wildcarded type example

You are in provisioning mode and you want to view the provisionable attributes of all user IDs, which are represented by *Userid* subcomponents of *AccessControl*. You enter the following command:

```
display AccessControl *
```

You receive the following information from the edit view:

```
Ac Userid/*
=====+-----+-----+-----+-----+-----+-----+-----+-----+
| Userid | cid | scope | impact | nmifs |          dir
|         |     |       |         |       |
|         |     |       |         | t     |
|         |     |       |         | l e   |
|         |     |       |         | o l f |
|         |     |       |         | c n m f|
|         |     |       |         | a e i t|
|         |     |       |         | l t p p|
=====+-----+-----+-----+-----+-----+-----+-----+-----+
|ADMIN   | 0 |networ|system|* * * *|/u/admin
|USER1   | 0 |networ|config|* * . *|/u/user1
|USER2   | 0 |networ|config|* * . *|/u/user2
|USER3   | 0 |networ|servic|* * . *|/u/user3
|USER4   | 0 |networ|servic|* * . *|/u/user4
|USER5   | 0 |networ|servic|* * . *|/u/user5
```

Overriding defaults example

You are in provisioning mode and you want to view the operational attributes of the *Shelf* component, which exist only in the current view. You enter the following command:

```
display -operationalData Shelf
```

You receive the following information from the current view:

```
Shelf
  busOperatingMode = dualBus
  hardwareFailures =
  numberOfSlots    = 16
  revertibleTimerCountdown = 0 seconds
```

While still in provisioning mode, you want to view the provisionable attributes of the *Shelf* component in the current view, not the edit view. You enter the following command:

```
display -current Shelf
```

You receive the following information from the current view:

```
Shelf
  commentText = "Lab 2, H16"
```

Now in operational mode, you want to view the provisionable attributes of the *Shelf* component. You enter the following command:

```
display -provisionedData Shelf
```

You receive the following information from the current view:

```
Shelf
  commentText = "Lab 2, H16"
```

Back in provisioning mode, you want to view the operational attribute *busOperatingMode* of *Shelf*, which exists only in the current view. You enter the following command:

```
display Shelf busOperatingMode
```

You receive the following information from the current view:

```
Shelf
  busOperatingMode = dualBus
  All information displayed is from the current view
```

Displaying in list format example

While in provisioning mode, you want to view attributes of all logical processors in a table format. You enter the following command:

```
display Lp/*
```

You receive the following information from the edit view:

```
Lp/*
  Use -noTabular to see hidden attributes: cid
  and linkToApplications
+==+-----+-----+-----+
|Lp|   main   |   spare   |   lpt     |
+==+-----+-----+-----+
| 0|Shelf Card/0 |!          |Sw Lpt/CP  |
| 1|Shelf Card/1 |Shelf Card/2 |Sw Lpt/FP  |
```

You now want to see the same information in list format to see the hidden attributes. You enter the following command:

```
display -noTabular Lp/*
```

You receive the following information from the edit view:

```
Lp/0
  mainCard = Shelf Card/0
  spareCard =
  logicalProcessorType = Sw Lpt/CP
  linkToApplications =
  customerIdentifier = 0
Lp/1
  mainCard = Shelf Card/1
  spareCard = Shelf Card/2
  logicalProcessorType = Sw Lpt/FP
  linkToApplications =
  customerIdentifier = 0
```

Displaying a multi-indexed component example

In provisioning mode, you want to view the *preferredOver* attribute of all *Ip Static Route* components with a subnetwork mask of 255.255.255.0 for virtual router 1. The subnetwork mask is the second index of the *Route* component. You enter the following command:

```
display Vr/1 Ip Static Route/*,255.255.255.0,*  
preferredOver
```

You receive the following information from the edit view:

```
Vr/1 Ip Static Route/*,255.255.255.0,*  
+=====+-----+-----+  
|      addr      |tos| pref  
+=====+-----+-----+  
|27.64.144.0     | 0|extOsp|  
|27.104.160.0    | 0|extOsp|  
|27.187.32.0     | 0|extOsp|  
|27.208.128.0    | 0|extOsp|
```

Displaying components using simple filtering example

You are currently in operational command mode and you want to display the operational components of the cards that are not CPs. You enter the following command:

```
display shelf card/(cardTyp7= CP)
```

You receive the following information from the current view:

```
Shelf Card/*  
Use -noTabular to see the many hidden attributes.  
+==+-----+-----+-----+-----+-----+-----+  
---+-----+  
Card|osiAdmin|osiOper|osiUsage|currentLP|Cause  |self  
   |sc  |  
   |      |      |      |      |      |failure|TestFa  
ult|stat|  
+==+-----+-----+-----+-----+-----+-----+  
---+-----+  
|1  |unlck  |dis   |idle   |wrongC  |none   |notApp  
   |none|
```

Displaying components using complex filtering example

You are currently in operational command mode and you want to display the operational components of the cards that are not CPs and have an enabled operational state. You enter the following command:

```
display shelf card/(cardType != CP AND(operationalState  
= enabled))
```

You receive the following information from the current view:

End Prov command

The end Prov command lets you exit provisioning mode. After exiting provisioning mode, you are working with the current view, not the edit view.

When you exit provisioning view, your provisioning changes are not automatically saved to the filesystem. However, the edit view and the changes you made to it continue to exist in memory. If you enter provisioning mode again using the start Prov command, you will be able to see your changes.

If the node resets, all changes made in the edit view are lost unless you have saved the edit view. For information on saving the edit view, see [Save Prov command \(page 198\)](#).

For more information on the end Prov command, see

- [Properties for end Prov \(page 91\)](#)
- [Syntax for end Prov \(page 91\)](#)
- [Exiting the provisioning mode example \(page 91\)](#)
- [Related information for end Prov \(page 92\)](#)

Properties for end Prov

The following table describes the properties of the end Prov command.

Properties of the end Prov command

Mode	Impact	Scope	Component
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for end Prov

The following table describes the syntax for the end Prov command.

Syntax of the end Prov command

If you want to...	Use the following syntax:
Exit the provisioning mode	end Prov

Exiting the provisioning mode example

You want to exit the provisioning mode. You enter the following command:

```
end Prov
```

You receive the following response:

```
Prov  
ok
```

Attention: After exiting provisioning mode, the system prompt changes from PROV> to > .

Related information for end Prov

See the following for information related to the end Prov command:

- [Save Prov command \(page 198\)](#)
- [Start Prov command \(page 216\)](#)

Find command

The find (f) command lets you return a list of all potentially available components that can be linked to a given component class. This verb is common to every Nortel Networks Multiservice Switch component.

When you are in provisioning mode, the edit view is used. When you are in operational mode, the current view is used.

The find command supports all command wildcarding capabilities. See [Command wildcarding \(page 18\)](#).

For more information on the find command, see

- [Properties for find \(page 93\)](#)
- [Syntax for find \(page 93\)](#)
- [Parameters for find \(page 94\)](#)
- [Examples for find \(page 95\)](#)

Properties for find

The find command works with all components. The following table describes the properties of the find command.

Properties of the find command

Mode	Impact	Scope	Attribute	View
Operational	Passive	Depends on component	Operational	Current
Provisioning	Passive	Depends on component	Provisionable	Edit

Syntax for find

The following table describes the syntax for the find command. The -freelinks option is always required.

Syntax of the find command

If you want to find components that are available to be linked to ...	Use the following syntax:
a given component type	<code>find -freelinks(component_type)</code>
the given component type from the given component name and its subcomponents	<code>find -freelinks(component_type) <component_name></code>
the operational subcomponents	<code>find -freelinks(component_type) -operationalData</code>
the provisioned subcomponents	<code>find -freelinks(component_type) -provisionedData</code>
the given component type in the current view	<code>find -current -freelinks(component_type)</code>
the given component. When a component has more than one link attribute, you need to specify the link attribute	<code>find -freelinks(component_type) -attribute(attribute)</code>
the given component without searching the subtree(s)	<code>find -freelinks(component_type) -nonrecursive</code>

Parameters for find

The following items are the parameters of the find command:

- [Component parameter for find \(page 94\)](#)
- [Override default parameters for find \(page 94\)](#)

Component parameter for find

If you only enter a component as a parameter to the find command, all components are searched. If you enter a component name as a parameter, it acts as a filter. By default the search is recursive, so the target component actually indicates where the search should begin.

You can use wildcarding to search components using the find command. With type wildcarding, you can substitute a wildcard (*) to search all instances of the component.

With instance wildcarding, you can substitute a wildcard (*) for an instance value to search all instances of a component type, or you can substitute a wildcard pattern to search selected instances.

Override default parameters for find

You can override the default attribute type and view associations using the following options.

Options for the find command

Option	Description
-operationalData (-o)	Use this option to search operational components while in provisioning mode.
-provisionedData (-p)	Use this option to search provisioned components while in operational mode.
-current (-c)	Use this option to search in the current view when in provisioning mode.
-freelinks (-f)	Required option with the find command to indicate that the find verb should return those components that are available to be linked to the given component or component class.
-attribute (-a)	Use this option if the component or component class provided by the -freelinks option has more than one link attribute.
-nonrecursive (-n)	Use this option to indicate that the subcomponents should not be recursively searched.

Examples for find

Search and return those components that are available to be linked to the component class *AtmIf*:

```
find -freelinks(AtmIf)
```

You receive the following type of response:

```
Lp/2 Sonet/1 Sts/0  
Lp/3 Sonet/1 Sts/0  
Laps/201 Sts/0  
Lp/4 V35/1  
ok
```

Search and return those components that are available to be linked to *AtmIf* at and under *lp/2*.

```
find -freelinks(AtmIf) lp/2
```

You receive the following type of response:

```
Lp/2 Sonet/1 Sts/0  
ok
```

Search and return those components that are available to be linked to the component class *LogicalProcessor*. You need to specify the link attribute as *LogicalProcessor* has more than one settable link attribute.

```
find -freelinks(LP) -attribute(Lpt)
```

You receive the following type of response:

```
Sw Lpt/CP  
ok
```

Related information for find

See the following for information related to the find command:

- [Display command \(page 80\)](#)
- [List command \(page 110\)](#)
- [Command wildcarding \(page 18\)](#)

Format Fs Disk command

The format Fs Disk command deletes all files and directories on a disk. This command also allows you to specify the volume name of the newly formatted disk.

Only format the standby disk. If you want to format the active disk, use the switchover Lp command to make the active disk the standby disk.

Before formatting a disk you must lock it using the lock command on its *Fs Disk* component. After locking a the disk on a two-disk node, the disks lose synchronization. While you are formatting a disk you cannot test or synchronize the disk.

By default, the format Fs Disk command will format a disk to its maximum physical capacity. To support older control processors with smaller disks, you can format a disk to 256 Mbyte even though it has a larger physical capacity.



CAUTION

Possible loss of important files

The format command erases all files on the disk and resets the disk volume name. All information stored on the disk is lost.

For more information on the format Fs Disk command, see

- [Properties for format Fs Disk \(page 97\)](#)
- [Syntax for format Fs Disk \(page 97\)](#)
- [Parameters for format Fs Disk \(page 98\)](#)
- [Examples for format Fs Disk \(page 99\)](#)
- [Related information for format Fs Disk \(page 99\)](#)

Properties for format Fs Disk

The following table describes the properties of the format Fs Disk command.

Properties of the format Fs Disk command

Mode	Impact	Scope	Component
Operational or Provisioning	Passive	Device	FileSystem (Fs)

Syntax for format Fs Disk

The following table describes the syntax for the format Fs Disk command.

Syntax of the format command

If you want to...	Use the following syntax:
Format a disk	<code>format -volumename(<name>) Fs Disk/<number></code>
Format a disk to be compatible with 256-Mbyte disks	<code>format -volumename(<name>) -backward Fs Disk/<number></code>

Parameters for format Fs Disk

The format Fs Disk command has the following parameters:

- [Disk parameter for format Fs Disk \(page 98\)](#)
- [New volume name parameter for format Fs Disk \(page 98\)](#)
- [Format to smaller size parameter for format Fs Disk \(page 99\)](#)

Disk parameter for format Fs Disk

Specify which disk you want to format using the *Disk* component, which is a subcomponent of *Fs*:

Disk/<number>

Enter the number of the disk you want to format. The disk number corresponds to the slot number of the control processor that holds the disk. You can list the disk numbers using the following command:

list FileSystem Disk/*

You must lock the *Disk* component before formatting the disk.

New volume name parameter for format Fs Disk

Specify the name of the newly formatted disk using the *volumename* option:

-volumename (<name>)

Enter a name for the formatted disk. Enclose the name in quotation marks to prevent the system from misinterpreting its characters. The name, which is case sensitive, can be up to 11 characters long.

If you do not specify a volume name, the command uses the node name (*nodeName* attribute of the *Module* component).

If you want the standby disk to automatically synchronize with the active disk at start-up, use the same name as the active disk. The *volumeName* attribute of the *Fs Disk* component indicates the name of the disk.

Format to smaller size parameter for format Fs Disk

You can format a large disk to 256 Mbyte to maintain compatibility with older control processors using the backward option:

-backward

Examples for format Fs Disk

The following examples illustrate how to use the format Fs Disk command:

- [Formatting a disk to its maximum size example \(page 99\)](#)
- [Formatting a disk to a smaller size example \(page 99\)](#)

Formatting a disk to its maximum size example

You want to format the standby disk on a 5-slot node to its maximum size. The active disk is in slot 0 and the standby disk is in slot 4. You begin by locking the standby disk using the following command:

```
lock Fs Disk/4
```

You then format the disk, giving it the name Node12, using the following command:

```
format -volumename("Node12") Fs Disk/4
```

You then unlock the standby disk and then synchronize it to the active disk.

Formatting a disk to a smaller size example

To maintain backward compatibility, you want to format the standby disk on a 16-slot node to 256 Mbyte even though its maximum size 810 Mbyte. The standby disk is in slot 15. You begin by locking the standby disk using the following command:

```
lock Fs Disk/15
```

You then format the disk, giving it the name Node10, using the following command:

```
format -volumename("Node10") -backward Fs Disk/15
```

You then unlock the standby disk and then synchronize it to the active disk.

Related information for format Fs Disk

See the following for information related to the format Fs Disk command:

- [Lock command \(page 124\)](#)
- [Switchover Lp command \(page 240\)](#)
- [Synchronize Fs command \(page 246\)](#)
- [Unlock command \(page 272\)](#)

Help command

The help (h) command lets you view information about components, groups, attributes, and verbs. The help command also lets you view component hierarchies.

For more information on the help command, see

- [Properties for help \(page 100\)](#)
- [Syntax for help \(page 100\)](#)
- [Parameters for help \(page 101\)](#)
- [Examples for help \(page 103\)](#)
- [Related information for help \(page 106\)](#)

Properties for help

The following table describes the properties of the help command.

Properties of the help command

Mode	Impact	Scope	Components
Operational or Provisioning	Passive	Not applicable	All components regardless of scope

Syntax for help

The following table describes the syntax for the help command.

Syntax of the help command

If you want to...	Use the following syntax:
List all top-level components and verbs that do not require a component	help
Get help on a component	help <component_class>
Get help on a group	help <component_class> <group>
Get help on an attribute	help <component_class> <attribute>
Get help on a verb	help -verb(<verb>) <component_class>
List the complete component hierarchy for the node	help -subcomponents
List a hierarchy for a component	help -subcomponents <component_class>

Parameters for help

The help command has the following parameters:

- [Component parameter for help \(page 101\)](#)
- [Attribute and group parameters for help \(page 102\)](#)
- [Verb parameter for help \(page 103\)](#)
- [Component hierarchy parameter for help \(page 103\)](#)

Component parameter for help

You specify the component for which you need help by using its component class:

`<component_class>`

A component class is a sequence of component types without their instance values. For more information on component class, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

[Help information for a component \(page 101\)](#) describes the information the help command gives you when you request help on a component. If you do not enter a component class, the help command gives you the following information:

- name of the node
- syntax of the help command
- list of top-level components
- list of verbs that do not require components

Help information for a component

Response field	Description
Component	Indicates the full name, abbreviated name (in parentheses), and possible instance values (range or list)
Instantiation	Indicates whether the component is required, optional, dynamic (automatically created based on system conditions), or dynamic-optional (automatically created or manually added)
Scope	Indicates the scope required to access or change the component. Possible values are application, device, or network
Subcomponent Types	Lists all the possible subcomponents of the component
Provisionable Group	Lists the provisionable groups of the component. Following each group is a list of its attributes.
(1 of 2)	

Help information for a component (continued)

Response field	Description
Operational Group	Lists the operational groups of the component. Following each group is a list its attributes.
Verbs	Lists the verbs you can use with the component. The capital letters in the verb indicate the minimum number of characters you must use when abbreviating the verb.
(2 of 2)	

Attribute and group parameters for help

You can get help on particular groups and attributes by specifying the attribute or group name after the component class. You can get help on multiple groups and attributes by entering a list of groups and attributes, separated by commas (,).

When you request help on a group, the help command indicates whether the group is operational or provisionable and lists all its attributes. [Help information for an attribute \(page 102\)](#) describes the information the help command gives you when you request help on an attribute.

Attributes and groups for the help command

Option	Description
<attribute>	Enter the name of the attribute for which you need help.
<group>	Enter the name of the group for which you need help.

Help information for an attribute

Field	Description
Attribute	Indicates the full name and abbreviated name (in parentheses)
Access	Indicates the required impact for reading and writing the attribute value
Criticality	Indicates one of the following consequences of changing the attribute: none, component (component out of service), process (components related to the process out of service), module (node restarts)
Type	Indicates the data type of the attribute
(1 of 2)	

Help information for an attribute (continued)

Field	Description
Values	Indicates the range of possible values for the attribute. Attributes that have a data type of signed integer, decimal number, fixed point decimal, or hexadecimal number can take either a range of numerical values or one or more named values. For example, you are setting a decimal number attribute that defines the maximum number of records held in a queue. You can set the attribute to a numerical value in the range of 1 to 200. Alternatively, you can set the attribute to the named value <i>unlimited</i> , which allows an unlimited number of records in the queue.
Default	Indicates the default value for the attribute. The system automatically sets attributes to their default value.
(2 of 2)	

Verb parameter for help

You can get help on a verb using the verb (v) option:

-verb (<verb>)

Enter the name of the verb. For most verbs you must also enter the component to which the verb applies. For those verbs that do not require components, you can enter the help command with only the verb option.

When you request help on a verb, the help commands indicates the required impact of the verb and its options. If an option takes a value, the help command also indicates its data type and restrictions.

Component hierarchy parameter for help

You can list a component hierarchy using the subcomponent (sub) option:

-subcomponent

If you want to view a hierarchy for all available components associated with the node, enter the help command with only the subcomponent option. If you want to see a hierarchy for a particular component, enter the component after the subcomponent option.

Examples for help

The following examples show how to use the help command:

- [Getting help on help example \(page 104\)](#)
- [Getting help on a component example \(page 104\)](#)
- [Getting help on groups and attributes example \(page 105\)](#)
- [Getting help on a verb example \(page 105\)](#)

- [Displaying a component hierarchy example \(page 105\)](#)

Getting help on help example

You want to display the node name, help command syntax, top-level components, and verbs that do not require components. You enter the following command:

```
help
```

You receive the following response:

```
EM/A567B7
usage: Help [-verb(<verb>)] [-subcomponents]
        [<component class> [<attribute|group>
        [, <attribute|group>]]]
Top-Level Components NetworkManagementInterfaceSystem,
                    AccessControl,
                    Collector,
                    NumberingPlanIndicator,
                    ModuleData,
                    Shelf,
                    LogicalProcessor,
                    Software,
                    FileSystem,
                    Routing,
                    TransportResource,
                    ProvisioningSystem,
                    NetworkSynchronization,
                    VirtualRouter,
                    LanApplication,
                    Trunk,
                    DpnGateway,
                    FrameRelayUni,
                    AtmInterface,
                    AtmCallRouter,
                    AtmRouting
Verbs                CANCEL, LOGOUT, ME, Help, List
```

Getting help on a component example

You want information on the *FileSystem Disk* component. You enter the following command:

```
help FileSystem Disk
```

You receive the following response:

```
Fs Disk
Component           Disk/Decimal([0-15])
Instantiation       dynamic
Scope               device
Subcomponent Types  Test
Operational Group   OsiState
Attributes          adminState, operationalState,
```

	usageState
Operational Group	Operational
Attributes	volumeName, capacity, unformattedCapacity, freeSpace, badBlocksPercentage
Verbs	FORMAT, Display, Help, List, LOCK, Set, Unlock

Getting help on groups and attributes example

You want information on the Provisioned group and the *runningTime* attribute of the *Lp DS1* component. You enter the following command:

```
help Lp DS1 Provisioned, runningTime
```

You receive the following response:

```
Lp DS1
  Group      Provisioned (Prov)
  Properties Provisionable
  Attributes lineType, zeroCoding, clockingSource
             raiAlarmType, lineLength
  Attribute  runningTime
  Access     Read: passive   Write: not allowed
  Criticality none
  Type       Decimal
  Values     [0-4294967295]
  Default    0
```

Getting help on a verb example

You want information on the save verb of the *Prov* component. You enter the following command:

```
help -verb(save) Prov
```

You receive the following response:

```
Prov
  Verb      Save
  Impact    configuration
  Options
  -current,
  -file(Ascii String(1 to 31 ASCII characters)),
  -component{c} (Component name ([<component_type>
  [/<instance_value>]]...)),
  -ascii,
  -portable
```

Displaying a component hierarchy example

You want to view the component hierarchy for the *Software* component. You enter the following command:

```
help -subcomponent Software
```

You receive the following response:

```
Sw
  Download (Dld)
  ApplicationVersion (Av)
    Feature (Feat)
  LogicalProcessorType (Lpt)
```

Related information for help

See the following for information related to the help command:

- [Display command \(page 80\)](#)
- [List command \(page 110\)](#)
- [Me command \(page 132\)](#)

Install command

The install command lets you load another version of firmware onto a Nortel Networks Multiservice Switch 15000 or Multiservice Switch 20000 fabric card's writable bank and activate the new firmware. The active firmware controls the operation of the fabric card.

See NN10600-500 *Nortel Networks Multiservice Switch 6400/7400/15000/20000 Alarms Reference* for a definition of a fabric card's fixed bank and writable bank.

Changing a fabric card's active firmware should not affect node operation. However, it is best to do this procedure when the node is most idle.

All fabric cards in a Multiservice Switch 15000 or Multiservice Switch 20000 node should be operating with the same version of firmware. An alarm is generated when fabric cards are each running a different version of firmware.

To change a fabric card's firmware, follow the instructions in NN10600-272 *Nortel Networks Multiservice Switch 7400/15000/20000 Upgrading Software*.

For more information on the install command, see

- [Properties for install \(page 107\)](#)
- [Syntax for install \(page 107\)](#)
- [Parameters for install \(page 108\)](#)
- [Examples for install \(page 108\)](#)
- [Related information for install \(page 109\)](#)

Properties for install

The following table describes the properties of the install command.

Attention: The install command must always include the file option.

Properties of the install command

Mode	Impact	Scope	Component
Operational	Service	Device	Shelf FabricCard

Syntax for install

The following table describes the syntax for the install command.

Syntax of the install command

If you want to...	Use the following syntax:
Install new firmware for a fabric card	<code>install -file(<firm_version>) Shelf FabricCard/<n></code>

Parameters for install

There are two types of parameters for the install command:

- [Firmware file name parameter for install \(page 108\)](#)
- [Fabric card identifier parameter for install \(page 108\)](#)

Firmware file name parameter for install

You must specify the name of the file containing the new version of firmware with the file option:

```
-file(<firm_version>)
```

Fabric card identifier parameter for install

You must specify the instance of the fabric card component where the new firmware is needed:

```
FabricCard/<n>
```

Examples for install

The following example shows how to use the install command.

You want to upgrade the firmware on both fabric cards in the node. The new firmware is in a file called CA0127A which has already been downloaded from the software distribution site.

You lock the fabric card by entering:

```
lock Shelf FabricCard/x
```

You install the new firmware by entering:

```
install -file(CA0127A) Shelf FabricCard/x
```

You wait a few minutes for the new firmware to be installed.

You verify that the fabric card operates correctly with the new firmware by entering:

```
start Shelf FabricCard/x test
```

The test results show that the fabric card is operating correctly.

You unlock the fabric card by entering:

```
unlock Shelf FabricCard/x
```

You repeat all of the above steps for FabricCard/y.

Related information for install

See the following for information related to the install command:

- [Set command \(page 204\)](#)
- [Start Sw DId command \(page 219\)](#)
- [Stop Sw DId command \(page 229\)](#)
- [Start <hardware> Test command \(page 212\)](#)
- [Lock command \(page 124\)](#)
- [Unlock command \(page 272\)](#)

List command

The list (l) command lets you view the subcomponents associated with a component. You can list both operational and provisionable components in the current and edit views. Operational components only contain operational attributes. Provisionable components can contain both provisionable and operational attributes.

When you are in operational mode, the list command assumes you want to view operational and provisionable components in the current view. When you are in provisioning mode, the list command assumes you want to view provisionable components in the edit view. Unless you specify otherwise, the list command uses these default associations, which are summarized in [Properties of the list command \(page 110\)](#).

The list command supports all command wildcarding capabilities. See [Command wildcarding \(page 18\)](#).

For more information on the list command, see

- [Properties for list \(page 110\)](#)
- [Syntax for list \(page 110\)](#)
- [Parameters for list \(page 111\)](#)
- [Examples for list \(page 113\)](#)
- [Related information for list \(page 116\)](#)

Properties for list

The following table describes the properties of the list command.

Properties of the list command

Mode	Impact	Scope	Component	View
Operational	Passive	Depends on component	All operational and all provisionable	Current
Provisioning	Passive	Depends on component	All provisionable	Edit

Syntax for list

The following table describes the syntax for the list command.

Syntax of the list command

If you want to...	Use the following syntax:
List subcomponent types of a component	list <component_name>
List instances of a component type	list <component_type>/*
List all subcomponents of a component	list <component_name> *
List all top-level component types	list
List operational subcomponents in the current view	list -operationalComponents <component_name>
List provisionable subcomponents	list -provisionedComponents <component_name>
List subcomponents in the current view	list -current <component_name>

Parameters for list

There are four types of parameters for the list command:

- [Component parameter for list \(page 111\)](#)
- [Listing using default overrides example \(page 112\)](#)
- [Simple attribute value parameters for list \(page 112\)](#)
- [Complex attribute value parameters for list \(page 113\)](#)

Component parameter for list

The list command displays components of the type (operational or provisionable) and from the view (current or edit) associated with the current command mode (see [Properties of the list command \(page 110\)](#) for the associations). However, if you specify an operational component while in provisioning mode, you will get operational components from the current view. (Operational information does not exist in the edit view.) The system informs you that it is displaying information from the current view and not the associated edit view.

You can substitute a wildcard (*) or a wildcard pattern to view instances of a component or subcomponent. Substitute a wildcard (*) character for the component type instance to view all subcomponents instances. Use a wildcard for a component instance value or an index value in a multi-indexed component to view instances of a component type. You can view multiple components in the hierarchy by substituting a wildcard for more than one instance value.

Using the list without a component gives you all top-level component types.

Components for the list command

Option	Description
<component_name>	Enter the name of the component.
<component_type>/*	Use an asterisk for an instance value to view all instances of a component type.
<component_name> *	Use an asterisk as the last component type-instance pair to view all subcomponent instances.
<component_type>/ <index>, *, ...	Use an asterisk for one or more index value to view instances of a multi-indexed component.
<component_type>/* <component_type>/* ...	Use an asterisk for more than one instance value to view instances of multiple components in the hierarchy.

Listing using default overrides example

You can override the default associations using the provisionedComponents, operationalComponents, and current options.

Component kind options for the list command

Option	Description
-provisioned Components	Use this option to list provisioned subcomponents.
-operational Components	Use this option to list operational subcomponents in the current view.
-current	Use this option to list subcomponents or component instances from the current view when you are in provisioning mode.

Simple attribute value parameters for list

Simple attribute value parameters consist of an expression that contains an attribute, a relational operator, and a value. A relational operator can be equal (=) or not equal (!=). Parentheses can be used, but are optional. See [Listing components using simple filtering example \(page 115\)](#) for an example of a simple attribute value parameter.

Complex attribute value parameters for list

Complex attribute value parameters are formed when simple attribute value parameters are joined using the following logical operators: AND and OR. A maximum of three simple expressions can be joined. Parentheses can be used, but are optional. See [Listing components using complex filtering example \(page 116\)](#) for an example of a simple attribute value parameter.

Applying both instance and attribute value parameters

You can combine both instance filtering and attribute value parameters to the same component instance. The format is:

```
<ComponentClass>/<instance>(attribute value)
```

Instance can be a wildcard (*) or a wildcard pattern. See [Listing components using both instance and value-based filtering \(page 116\)](#) for an example.

Examples for list

The following examples show how to use the list command:

- [Listing components example \(page 113\)](#)
- [Overriding defaults example \(page 114\)](#)
- [Listing with multiple wildcards example \(page 115\)](#)
- [Listing components using simple filtering example \(page 115\)](#)
- [Listing components using complex filtering example \(page 116\)](#)
- [Listing components using both instance and value-based filtering \(page 116\)](#)

Listing components example

You want to list all logical processors, which are represented by instances of the *Lp* component. You enter the following command:

```
list Lp/*
```

You receive the following response:

```
Lp/0  
Lp/1  
Lp/4  
Lp/5
```

You then want to view the subcomponent types of logical processor 1 (*Lp/1*). You enter the following command:

```
list Lp/1
```

You receive the following response:

```
Lp/1 V35/*  
Lp/1 Eng
```

Now you want to view all the subcomponents of logical processor 1 (*Lp/1*). You enter the following command:

```
list Lp/1 *
```

You receive the following response:

```
Lp/1 V35/0  
Lp/1 V35/1  
Lp/1 V35/2  
Lp/1 V35/3  
Lp/1 V35/4  
Lp/1 V35/5  
Lp/1 V35/6  
Lp/1 V35/7  
Lp/1 Eng
```

Now you want to list all the *View* subcomponents of *Vr/1 Snmp* with an index of 1. You enter the following command:

```
list Vr/1 Snmp View/1,*
```

You receive the following response:

```
Vr/1 Snmp View/1,1  
Vr/1 Snmp View/1,2  
Vr/1 Snmp View/1,3
```

Overriding defaults example

While in operational mode, you want view all top-level provisioned component types. You enter the following command:

```
list -provisionedComponents
```

You receive the following response:

```
Col/*  
Sw  
Shelf  
Lp/*  
Rtg  
Mod  
Ac  
Npi/*
```

Now while in provisioning mode, you want view the provisioned subcomponents of the *AccessControl* component in the current view. You enter the following command:

```
list -current Ac *
```

You receive the following response:

```
Ac Userid/ADMIN  
Ac Userid/USER1  
Ac Userid/USER2  
Ac Userid/USER3
```

```
Ac Userid/USER4
Ac Userid/USER5
```

Still in provisioning mode, you want to view all the top-level operational component types in the current view. You enter the following command:

```
list -operationalComponents
```

You receive the following information from the current view:

```
Nmis
Trm
Prov
Fs
```

Finally, while still in provisioning mode, you want to view the subcomponent types of the *Nmis* component. *Nmis* is an operational component that only exists in the current view. You enter the following command:

```
list Nmis
```

You receive the following information from the current view:

```
Nmis Local
Nmis Telnet
Nmis Fmip
Nmis Ftp
```

All information displayed is from the current view.

Listing with multiple wildcards example

You want to list all V.35 ports provisioned on all logical processors. Instances of the *V35* component represent V.35 ports. You enter the following command:

```
list Lp/* V35/*
```

You receive the following response:

```
Lp/1 V35/0
Lp/1 V35/1
Lp/1 V35/2
Lp/2 V35/0
Lp/2 V35/1
Lp/2 V35/2
Lp/5 V35/6
Lp/6 V35/3
```

Listing components using simple filtering example

You are currently in operational command mode and you want to list the operational components of the cards that are not CPs. You enter the following command:

```
list shelf card/(cardType != CP)
```

You receive the following information from the current view:

```
Shelf Card/1
Shelf Card/2
```

```
Shelf Card/3
Shelf Card/4
```

Listing components using complex filtering example

You are currently in operational command mode and you want to list the operational components of the cards that are not CPs and have an enabled operational state. You enter the following command:

```
list shelf card/(cardType != CP AND (operationalState =
enabled))
```

You receive the following information from the current view:

```
Shelf Card/1
Shelf Card/3
Shelf Card/4
```

Listing components using both instance and value-based filtering

You are currently in operational command mode and you want to list all full provisioning views with a version of CD02A. You enter the following command:

```
List Prov View/*.full.*(version = CD02A)
```

You receive the following information from the current view:

```
Prov View/abc_example.full.001
Prov View/abc_example.full.002
Prov View/abc_example.full.003
```

Related information for list

See the following for information related to the display command:

- [Add command \(page 31\)](#)
- [Cancel command \(page 38\)](#)
- [Delete command \(page 77\)](#)
- [Display command \(page 80\)](#)
- [Start Prov command \(page 216\)](#)
- [Command wildcarding \(page 18\)](#)

ListFile Fs command

The listFile Fs (ls Fs) command lets you list the contents (files and directories) of a directory. You can get information about a directory itself (not its contents), and you can list only those files or directories that are newer than a file or directory you specify.

For each file or directory you list, the listFile Fs command displays the following information:

- type (file or directory)
- protected (yes or no)
- size in bytes
- date and time of the last modification
- name

For more information on the listFile command, see

- [Properties for listFile Fs \(page 117\)](#)
- [Syntax for listFile Fs \(page 117\)](#)
- [Parameters for listFile Fs \(page 118\)](#)
- [Examples for listFile Fs \(page 119\)](#)
- [Related information for listFile Fs \(page 120\)](#)

Properties for listFile Fs

The following table describes the properties of the listFile Fs command.

Properties of the listFile Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Passive	Device	FileSystem (Fs)

Syntax for listFile Fs

The following table describes the syntax for the listFile Fs command.

Syntax of the listFile Fs command

If you want to...	Use the following syntax:
List the contents of the current working directory	listFile Fs
List the contents of a specific directory	listFile -path(<path>) Fs
List information about the current directory itself	listFile -status Fs
List information about a specific directory	listFile -path(<directorypath>) -status Fs
List files and directories that are newer than specific file	listFile -newer(<path>) Fs

Parameters for listFile Fs

There are three parameters for the listFile command:

- [Specific directory or file parameter for listFile Fs \(page 118\)](#)
- [Directory status parameter for listFile Fs \(page 118\)](#)
- [Newer than a file or directory parameter for listFile Fs \(page 118\)](#)

Specific directory or file parameter for listFile Fs

You can list the contents of a specific directory or file using the path option:

-path (<path>)

Enter the absolute or relative path for a directory or a particular file you want to list. Enclose the path in double quotation marks. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

If you do not enter a path option, the listFile command lists the current working directory. If you enter a file, the command only lists information about that file.

Directory status parameter for listFile Fs

Instead of listing the contents of a directory, you can list information about the directory itself using the status option:

-status

Use this option to list information about the current working directory or a specific directory.

Newer than a file or directory parameter for listFile Fs

You can list only those files and directories that are newer than a specific file or directory using the newer option:

-newer (<path>)

Enter the absolute or relative path to a file or directory that you want to use for a newer comparison. The system only lists those files and directories that are newer than the file or directory you specify. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

Examples for listFile Fs

The following examples illustrate how to use the listFile Fs command:

- [Listing the contents of a directory example \(page 119\)](#)
- [Listing information about a directory example \(page 119\)](#)
- [Listing newer files and directories example \(page 120\)](#)

Listing the contents of a directory example

Your current working directory is the root directory (/) and you want to list its contents. You enter the following command:

```
listFile Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
dir  no   0      1998-06-05 09:13:52 tmp
dir  no   0      1998-05-04 09:29:44 system
dir  no   0      1998-05-
05 09:36:36 provisioning
dir  no   0      1998-05-04 09:29:44 software
dir  no   0      1998-05-04 09:34:02 spooled
```

You now want to list the contents of the software directory. You enter the following command:

```
listFile -path("software") Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
dir  no   0      1998-05-04 09:29:44 .
dir  no   0      1998-06-05 09:13:36 ..
dir  no   0      1998-05-04 09:29:44 base
dir  no   0      1998-05-04 09:29:44 trunks
dir  no   0      1998-05-04 09:29:44 frameRelay
dir  no   0      1998-05-04 09:29:44 networking
```

Listing information about a directory example

Your current working directory is the root directory (/) and you want to list information about it and not its contents. You enter the following command:

```
listFile -status Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
dir  no   0      1998-06-05 09:13:36 /
```

Listing newer files and directories example

Your current working directory is /provisioning and you want to list all files and directories in it newer than the file vr.full.001. You enter the following command:

```
listFile -newer("vr.full.001") Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
dir  no   0      1998-05-12 09:35:06 vr.full.003
dir  no   0      1998-05-
29 08:05:42 steve.full.004
```

Related information for listFile Fs

See the following for information related to the listFile Fs command:

- [Chdir Fs command \(page 40\)](#)
- [WorkingDir Fs command \(page 276\)](#)

Load Prov command

Use the load Prov command to load a saved view into the edit view.

When you issue the load Prov command, the system checks if the software required for the saved view is running on the node. If not, the load Prov command fails, and on-screen messages identify which software features you need to load. You can override this behavior using the force option.

For more information on the load Prov command, see

- [Properties for load Prov \(page 121\)](#)
- [Syntax for load Prov \(page 121\)](#)
- [Parameters for load Prov \(page 121\)](#)
- [Examples for load Prov \(page 122\)](#)
- [Related information for load Prov \(page 123\)](#)

Properties for load Prov

The following table describes the properties of the load Prov command.

Properties of the load Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for load Prov

The following table describes the syntax for the load Prov command.

Syntax of the load Prov command

If you want to...	Use the following syntax:
Load a saved view file from the disk to the edit view	load -file(<file_name>) Prov
Load a saved view file from the disk to the edit view, but skip the check for required software	load -force -file(<file_name>) Prov

Parameters for load Prov

There are two types of parameters for the load Prov command:

- [Loading a specific saved view parameter for load Prov \(page 122\)](#)
- [Skipping the check for required software parameter for load Prov \(page 122\)](#)

Loading a specific saved view parameter for load Prov

You can specify that the provisioning system load a specific file into the edit view using the file option:

```
-file(<filename>)
```

The file option loads the specified saved view file from the disk into the edit view. The file option identifies the saved view using the three-part view filename. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for information on saved view names.

Skipping the check for required software parameter for load Prov

You can specify that the provisioning system load the specified saved view file and skip the check for required software using the force option:

```
-force
```

The force option overrides the semantic check for required software. The system loads the saved view regardless of the software running on the node.

The force option also causes the provisioning system to continue to process the entire view rather than stopping after five errors, as would normally occur. (See [Check Prov command \(page 42\)](#) for a detailed description of how the semantic check works.)

Examples for load Prov

The following examples show how to use the load Prov command:

- [Loading a saved view into the edit view example \(page 122\)](#)
- [Loading a saved view into the edit view, but omitting the system check for required software example \(page 123\)](#)

Loading a saved view into the edit view example

You want to load the saved view ABCD1.full.001 into the edit view. The proper software for the saved view is currently running on the node. You enter the following command:

```
load -file(ABCD1.full.001) Prov
```

You receive the following response:

```
Prov  
Loaded or applied file "AB0045.full.001"  
ok
```

If you incorrectly enter the filename, you receive the following response:

```
Prov  
The specified file does not exist.  
command failed
```

Loading a saved view into the edit view, but omitting the system check for required software example

You want to load the saved view `AXL_test.full.004` into the edit view, but you want to omit the system check for the proper software because the node is missing some of the proper software. If you try to load the saved view without the `force` option, you receive a number of error messages ending with the following response:

```
Too many errors loading file AXL_test.full.004.  
command failed
```

In this situation, the system detects the errors, and aborts the command.

To force the node to ignore the error messages and load the view, you enter the following command:

```
apply -force -file(AXL_test.full.004) Prov
```

You receive a number of error messages, ending with the following response:

```
Loaded or applied file AXL_test.full.004.
```

If the required software for particular components is missing, those components will be missing from the edit view when the loading completes.

Related information for load Prov

See the following for information related to the load Prov command:

- [Activate Prov command \(page 25\)](#)
- [Check Prov command \(page 42\)](#)
- [ReloadCp Lp command \(page 173\)](#)
- [Start Prov command \(page 216\)](#)
- [Stop Prov command \(page 227\)](#)

Lock command

The lock command lets you prevent a component from providing service.

The lock command causes a specific component to enter the shutting down OSI administrative state. While shutting down, the component continues to provide services to existing clients, but does not accept any new requests for service. In some cases, locking a component shuts down all its subcomponents. When the component no longer providing service, it enters the locked OSI administrative state.

Some components (like *Bus*) do not enter the shutting down state. They move directly from the unlocked to the locked state. With components that do enter the shutting down state, you can force the component to skip the shutting down state and move immediately to the locked state. When you force a component to lock immediately, all services on the component terminate.

Not all Nortel Networks Multiservice Switch card behave the same way when you force a *Shelf Card* component to lock. For Multiservice Switch 7400 cards, the *lock -force* command causes the card to become locked and disabled, then it is reset, and finally it becomes locked and enabled. For Multiservice Switch 15000 and Multiservice Switch 20000 cards, the *lock -force* command only causes the card to become locked and disabled. Multiservice Switch 15000 and Multiservice Switch 20000 cards do not reset. Instead, the OSI operational state becomes *enabled* only after it is unlocked.

When you lock a *Trunk* component or an *oamEnet* component, it automatically returns to an unlocked state after five minutes of being in a locked state. If necessary, you can permanently lock a *Trunk* component or an *oamEnet* component.

Before you lock a component, you should verify its OSI administrative state by displaying the *adminState* attribute of the component.

For more information on the lock command, see

- [Properties for lock \(page 124\)](#)
- [Syntax for lock \(page 125\)](#)
- [Parameters for lock \(page 125\)](#)
- [Examples for lock \(page 126\)](#)
- [Related information for lock \(page 127\)](#)

Properties for lock

You cannot lock some components. The following table describes the properties of the lock command.

Properties of the lock command

Mode	Impact	Scope	Components
Provisioning	Service	Depends on component	All
Provisioning	Service	Network	Trunk (Trk)

Syntax for lock

The following table describes the syntax for the lock command.

Syntax of the lock command

If you want to...	Use the following syntax:
Lock a component	lock <component_name>
Immediately lock an component, skipping the shuttingDown state	lock -force <component_name>
Lock a trunk until you unlock it	lock -forever Trunk/<n>
Lock the CP's OAM Ethernet port until you unlock it	lock -forever Ip/0 oamEnet/0

Parameters for lock

There are two parameters for the lock command:

- [Immediately locking a component parameter for lock \(page 125\)](#)
- [Locking a trunk permanently parameter for lock \(page 125\)](#)

Immediately locking a component parameter for lock

You can lock immediately by using the force option:

-force

When you use the force option, the component skips the shutting down stage. All service on the component immediately ends and the component moves to the locked state. The abbreviation for the force option is -f.

Locking a trunk permanently parameter for lock

When you lock a *Trunk* or an *oamEnet* component, it automatically unlocks after five minutes. You can lock a *Trunk* component or an *oamEnet* component and have it remained locked using the forever option:

-forever

You can only use the forever option with the *Trunk* component or the *oamEnet* component. When you use this option, the component does not unlock after five minutes. To unlock the *Trunk* component or the *oamEnet* component, use the unlock command.

Examples for lock

The following examples show you how to use the lock command:

- [Locking a component example \(page 126\)](#)
- [Immediately locking a component example for lock \(page 126\)](#)
- [Permanently locking a Trunk component example for lock \(page 127\)](#)
- [Permanently locking an oamEnet component example for lock \(page 127\)](#)

Locking a component example

You want to lock the Lp/1 component. Before locking the component, you check its OSI administrative state using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1
adminState = unlocked
```

Since Lp/1 is unlocked, you lock it using the following command:

```
lock Lp/1
```

The system issues an alarm that indicates Lp/1 is shutting down. The Lp/1 component continues to provide existing service, but it will not accept any new requests for service. You verify the administrative state of Lp/1 using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1
adminState = shuttingDown
```

When all service on Lp/1 ends (for example, when the its associated processor card restarts), its administrative state changes to locked.

Immediately locking a component example for lock

You want to immediately lock the *Lp/1* component, skipping the shutting down administrative state. Before locking the component, you check its OSI administrative state using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1
adminState = unlocked
```

Since Lp/1 is unlocked, you lock it immediately using the following command:

```
lock -force Lp/1
```

The system ends all service on Lp/1 by restarting its associated processor card. Since Lp/1 is locked, the processor card does not load its software. The LED status display on the processor card slowly pulses red. You verify the administrative state of Lp/1 using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1  
adminState = locked
```

Permanently locking a Trunk component example for lock

You want to permanently lock the *Trunk/0* component. You enter the following command:

```
lock -forever Trunk/0
```

The *Trunk* component moves to the shutting down state and then to the locked state. The *Trunk* component remains locked until you unlock it.

Permanently locking an oamEnet component example for lock

You want to permanently lock the *oamEnet* component. You enter the following command:

```
lock -forever lp/0 oamEnet/0
```

The *oamEnet* component moves to the shutting down state and then to the locked state. The *oamEnet* component remains locked until you unlock it.

Related information for lock

See the following for information related to the lock command:

- [Display command \(page 80\)](#)
- [Unlock command \(page 272\)](#)

Logout command

The logout (logoff) command ends your local operator or Telnet session.

If you were in provisioning mode when you entered the logout command, The system automatically sends the end Prov command. It does not modify or save the edit view.

On a local terminal, the login prompt appears after the session ends. With a Telnet session, the logout command terminates the Telnet connection. You have to initiate another Telnet connection to log in to the node again.

The quit command is identical to the logout command. These two commands, along with their abbreviations, give you four ways to end your session:

- logout
- logoff
- quit
- exit

For more information on the logout command, see

- [Properties for logout \(page 128\)](#)
- [Syntax for logout \(page 128\)](#)
- [Ending your session example \(page 129\)](#)
- [Related information for logout \(page 129\)](#)

Properties for logout

The following table describes the properties of the logout command.

Properties of the logout command

Mode	Minimum Impact	Component
Operational or Provisioning	Passive	Does not affect components

Syntax for logout

The following table describes the syntax for the logout command.

Syntax of the logout command

If you want to...	Use the following syntax:
End your local or Telnet session	logout logoff

Ending your session example

You are logged onto a Nortel Networks Multiservice Switch node on the first Telnet session (Nmis Telnet Session/1), and you want to end your session. You enter the following command:

logout

You receive the following response:

```
Userid admin logged out as EM/NODEA Nmis Telnet Session/  
1 at 21:07:33  
Connection closed by foreign host.
```

Related information for logout

See the following for information related to the logout command:

- [Clear Nmis <interface> Session command \(page 55\)](#)
- [Me command \(page 132\)](#)
- [Quit command \(page 168\)](#)
- [Telnet Vr command \(page 248\)](#)

MakeDirectory Fs command

The makeDirectory Fs (mkdir Fs) command lets you create new directories in the Nortel Networks Multiservice Switch file system.

For more information on the makeDirectory Fs command, see

- [Properties for makeDirectory Fs \(page 130\)](#)
- [Syntax for makeDirectory Fs \(page 130\)](#)
- [New directory parameter for makeDirectory Fs \(page 130\)](#)
- [Creating a new directory example \(page 131\)](#)
- [Related information for makeDirectory Fs \(page 131\)](#)

Properties for makeDirectory Fs

The following table describes the properties of the makeDirectory Fs command.

Properties of the makeDirectory Fs command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for makeDirectory Fs

The following table describes the syntax for the makeDirectory Fs command.

Syntax of the makeDirectory Fs command

If you want to...	Use the following syntax:
Make a new directory	makeDirectory -path(<directorypath>) Fs

New directory parameter for makeDirectory Fs

You specify the new directory using the path option:

-path(<directorypath>)

Enter the absolute or relative path for the new directory. Enclose the path in double quotation marks. If the parent directory in the path for the new directory does not exist, the command fails. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

You must enter the path option.

Creating a new directory example

Your current working directory is /provisioning. You want to create a new directory in the /tmp directory called test. You enter the following command:

```
makeDirectory -path("/tmp/test") Fs
```

You check to make sure the directory was created using the following command:

```
listFile -path("/tmp/test") -status Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
dir  no   0      1998-06-09 12:41:28 test
```

Related information for makeDirectory Fs

See the following for information related to the makeDirectory Fs command:

- [Chdir Fs command \(page 40\)](#)
- [Copy Fs command \(page 68\)](#)
- [ListFile Fs command \(page 117\)](#)
- [Remove Fs command \(page 176\)](#)
- [WorkingDir Fs command \(page 276\)](#)

Me command

The me command displays information about your current session and the access capabilities of your user ID.

The session information includes the current node name (represented by the instance value of the *EM* component), network management interface, and session number.

For more information on the me command, see

- [Properties for me \(page 132\)](#)
- [Syntax for me \(page 132\)](#)
- [Displaying information about current session example \(page 132\)](#)
- [Related information for me \(page 133\)](#)

Properties for me

The following table describes the properties of the me command.

Properties of the me command

Mode	Minimum Impact	Component
Operational or Provisioning	Passive	Does not affect components

Syntax for me

The following table describes the syntax for the me command.

Syntax of the me command

If you want to...	Use the following syntax:
Display information about your current session	me

Displaying information about current session example

You are logged in to a Nortel Networks Multiservice Switch node and you want to find out information about your session and the access capabilities of your user ID. You enter the following command:

```
me
```

You receive the following response:

```
EM/NODEA Nmis Local Session/1; userid = operator1  
Impact = configuration; Scope = network; CustomerId = 0  
Mode = oper
```

Related information for me

See the following for information related to the me command:

- [Clear Nmis <interface> Session command \(page 55\)](#)
- [Logout command \(page 128\)](#)

Move Fs command

The move (mv Fs) command lets you move and rename files and directories.

The move Fs command does not overwrite existing files. If you specify an existing file as a destination, the command fails. If you want to overwrite a file, you must first remove it using the remove Fs command.

When using this command, avoid moving files into the root directory (/). Reserve the root directory for directories only.

For more information on the move Fs command, see

- [Properties for move Fs \(page 134\)](#)
- [Source and destination parameters for move Fs \(page 135\)](#)
- [Examples for move Fs \(page 135\)](#)
- [Related information for move Fs \(page 136\)](#)

Properties for move Fs

The following table describes the properties of the move Fs command.

Properties of the move Fs command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for move Fs

The following table describes the syntax for the move Fs command.

Syntax of the move Fs command

If you want to...	Use the following syntax:
Move a file into a new directory	move -source(<filepath>) -destination(<directorypath>) Fs
Rename a file	move -source (<filepath>) - destination(<newfilepath>) Fs
Move a directory into a directory	move -source(<directorypath>) -destination(<directorypath>) Fs
Rename a directory	move -source(<directorypath>) -destination(<newdirectorypath>) Fs

Source and destination parameters for move Fs

Specify which file or directory you want to copy or rename using the source option. Specify where you want to move the file or directory or its new name using the destination option.

If the destination file or directory does not exist, the move Fs command renames the source. You can move and rename a file at the same time by specifying a destination path with a new file name in a different directory.

If the destination is an existing directory, the move Fs command moves the source file or directory into it. If the destination is an existing file, the command fails.

Source and destination options for the move Fs command

Option	Description
-source (<filepath>)	Enter the absolute or relative path to the file or directory you want to move or rename.
-source (<directorypath>)	You must enter this option.
-destination (<filepath>)	Enter the absolute or relative path to the new location or new name of the file or directory.
-destination (<directorypath>)	You must enter this option.

Examples for move Fs

The following examples illustrate how to use the move Fs command:

- [Moving a file and directory example \(page 135\)](#)
- [Renaming a file example \(page 136\)](#)

Moving a file and directory example

Your current working directory is /spooled. You want to move the file account.001 in the current working directory into the /tmp directory. You enter the following command:

```
move -source("account.001") -destination("/tmp") Fs
```

You now want to move the oldaccount directory, which is in your current working directory, into the /tmp directory. You enter the following command:

```
move -source("oldaccount") -destination("/tmp") Fs
```

The oldaccount directory is now a subdirectory of /tmp.

Renaming a file example

You want to rename the file `account.001` in your current working directory to `acc.old`. A file by that name does not exist in your current working directory. You enter the following command:

```
move -source("account.001") -destination("acc.old") Fs
```

You now decide to move the `acc.old` file into the `/tmp` directory while changing its name to `acc.backup`. You enter the following command:

```
move -source("acc.old") -destination("/tmp/acc.backup")  
Fs
```

Related information for move Fs

See the following for information related to the `move Fs` command:

- [Copy Fs command \(page 68\)](#)
- [ListFile Fs command \(page 117\)](#)
- [MakeDirectory Fs command \(page 130\)](#)
- [Remove Fs command \(page 176\)](#)
- [WorkingDir Fs command \(page 276\)](#)

Newfile Col Sp command

The newfile Col Sp command lets you open a new spooling file for data collection.

Spooling files contain data (alarms, accounting, statistics, state change notifications, log, and debug) collected by the data collection system. You can transfer these files from the Nortel Networks Multiservice Switch node for analysis or billing purposes.

The command closes the currently open spooler file (accepting new data records), moves it to the closed directory, and opens a new file. The command fails if you have not turned spooling on for the data type (using the *spooling* attribute of the *Collector Spooler* component).

For more information on the newfile Col Sp command, see

- [Properties for newfile Col Sp \(page 137\)](#)
- [Syntax for newfile Col Sp \(page 137\)](#)
- [Data type parameter for newfile Col Sp \(page 137\)](#)
- [Creating a new spooling file example \(page 138\)](#)

Properties for newfile Col Sp

The following table describes the properties of the newfile Col Sp command:

Properties of the newfile Col Sp command

Mode	Impact	Scope	Components
Operational or Provisioning	Service	Device	Collector Spooler (Col Sp)

Syntax for newfile Col Sp

The following table describes the syntax for the newfile Col Sp command.

Syntax of the newfile Col Sp command

If you want to...	Use the following syntax:
Create a new spooling file	newfile Col/<data_type> Sp

Data type parameter for newfile Col Sp

You specify the data type for which you want to create a new spooling file using the instance value of the *Collector (Col)* component:

Col/<data_type> Sp

Enter one of the following data types:

- accounting (acc)
- alarm (ala)
- debug
- log
- scn
- stats

Attention: The rtstats and traps data types cannot be spooled. Therefore, the rtstats and traps data types do not apply to the Col Sp command.

For more information on these data types, see NN10600-561 *Nortel Networks Multiservice Switch 7400/15000/20000 Data Management*.

Creating a new spooling file example

You want to create a new spooling file for the accounting data type. You enter the following command:

```
newfile Col/accounting Sp
```

The system closes the current spooling file, moves it to the closed directory, and opens a new spooling file.

Optimize command

The optimize command lets you to manually trigger an optimization pass when using the PNNI local and global rerouting feature. The optimize command can be issued at the module (node), interface, or connection level.

Attention: When specified path connections with rerouting capabilities are optimized, the node considers the specified path information to determine the optimal path. The primary path is the only path that is considered optimal for these types of connections. When an optimization results in the connection being re-established on the alternate path or a more preferable automatically computed path, the connection will remain eligible for future optimizations.

If you use the optimize command against the

- *ARtg Pnni Reroute* component
 - you will trigger a module-wide (nodal) optimization pass
- *Atmlf<n> <interface_type> Reroute* component
 - you will trigger a path optimization pass at that ATM interface
- *Atmlf<n> Vpt<m> <interface_type> Reroute* component
 - you will trigger a path optimization pass at a virtual path terminator (VPT)
- *Atmlf<n> vcc<vpi.vci> Source RerouteOverride* component
 - you will trigger a path optimization pass at that ATM vcc connection
- *Atmlf<n> vpc<vpi> Source RerouteOverride* component
 - you will trigger a path optimization pass at that ATM vpc connection
- *Atmlf<n> vpt<m> vcc<vci>Source RerouteOverride* component
 - you will trigger a path optimization pass at that ATM vpt vcc connection

Where:

- <m> is the virtual path terminator number or instance
- <n> is the ATM interface number or instance
- <interface_type> is either Uni, lisp, Aini, or Pnni

The module optimization pass can be cancelled by using the option *-cancel*.

Attention: A path optimization will only move connections from an incumbent route if the new route possesses a better path optimization metric. For more information, see NN10600-702 *Nortel Networks Multiservice Switch 7400/15000/20000 ATM Routing and Signalling Fundamentals*.

Attention: If a local connection recovery occurs in a downstream local rerouting domain, you can issue *optimize artg pnni* (if the component is provisioned) or *optimize atmif/x UNI/IISP/AINI/PNNI reroute* at the local rerouting node. For more information, see NN10600-702 *Nortel Networks Multiservice Switch 7400/15000/20000 ATM Routing and Signalling Fundamentals*.

For more information on the optimize command, see

- [Syntax for optimize \(page 140\)](#)
- [Examples for optimize \(page 141\)](#)
- [Related information for optimize \(page 144\)](#)

Syntax for optimize

The recommended syntax for the optimize command works only with the default settings for the PNNI local and global feature. The following tables describe the syntax for the optimize command:

- [Syntax of the optimize command for the module \(page 140\)](#)
- [Syntax of the optimize command for the interface \(page 141\)](#)
- [Syntax of the optimize command for the connection \(page 141\)](#)

Syntax of the optimize command for the module

If you want to...	Use the following syntax:
Manually trigger the module (nodal) optimization mechanism.	optimize ARtg Pnni Reroute
Manually cancel the module optimization pass.	optimize -cancel ARtg Pnni Reroute

Syntax of the optimize command for the interface

If you want to...	Use the following syntax:
Manually trigger the path optimization mechanism for connections on an interface that has been recovered for path optimization.	optimize AtmIf/<n> <interface_type> Reroute or optimize AtmIf/<n> Vpt/<x> <interface_type> Reroute or optimize FrAtm<n> Reroute or optimize aal1Ges/<n> Reroute where <n> is the interface number <interface_type> is one of the following interface types: Uni, Aini, lisp, or Pnni
Manually trigger the path optimization mechanism for all connections on the interface regardless of whether they are eligible for path optimization or not, including those that have been recovered when the optimize command was last run.	optimize -all AtmIf/<n> <interface_type> Reroute or optimize -all AtmIf/<n> Vpt/<x> <interface_type> Reroute where <n> is the interface number <interface_type> is one of the following interface types: Uni, Aini, lisp, or Pnni

Syntax of the optimize command for the connection

If you want to...	Use the following syntax:
Manually trigger the path optimization mechanism for connections that have been recovered for path optimization.	optimize AtmIf/<n> <connection_type> Src RerouteOv where <connection_type> is vcc/x.y, vpc/y, or vpt/x vcc/y or optimize FrAtm/<n> Dlci/<x> siwf Spvc RerouteOv

Examples for optimize

The following examples illustrate how to use the optimize command:

- [Triggering a module optimization pass \(page 142\)](#)
- [Cancelling a module optimization pass \(page 142\)](#)
- [Optimizing connections that have been recovered on an ATM interface or an FR-ATM interface \(page 142\)](#)
- [Optimizing all connections on an ATM interface \(page 143\)](#)

Triggering a module optimization pass

You want to manually trigger a module (nodal) optimization pass against the *ARtg Pnni Reroute* component. You enter the following command:

```
optimize ARtg Pnni Reroute
```

When the command completes successfully, you receive the following response:

```
Module optimization pass completed.
```

If a module optimization pass is in progress when you use the `optimize` command, you receive the following response:

```
A module optimization pass is already in progress.
```

Cancelling a module optimization pass

You want to cancel the module (nodal) optimization pass that is currently in progress. You enter the following command:

```
optimize -cancel ARtg Pnni Reroute
```

When the command completes successfully, you receive the following response:

```
The current module optimization pass has been cancelled.
```

If there is a cancel command already in progress, you receive the following response:

```
A cancel of the module optimization pass is in progress.
```

If there is no module optimization pass in progress, you receive the following response:

```
There is no module optimization pass currently in progress.
```

Optimizing connections that have been recovered on an ATM interface or an FR-ATM interface

Manually trigger the path optimization mechanism against the *AtmIf <interface_type> Reroute* component or the *FrAtm<interface_type> Reroute* component for connections that have been recovered for path optimization and are eligible for path optimization. These connections are included in the attribute *eligibleRecoveredConnections*.

For an ATM interface, enter the following command:

```
optimize AtmIf/<AtmIf> <interface_type> Reroute
```

For an FR-ATM interface, enter the following command:

```
optimize FrAtm/<FrAtm> Reroute
```

When the command completes successfully, you receive the following response:

```
Interface optimization pass completed.
```

If an optimization pass on the ATM or FR-ATM interface is in progress when you use the optimize command, you receive the following response:

```
An interface optimization pass is already in progress.
```

If a module (nodal) optimization pass is in progress when you use the optimize command, you receive the following response:

```
A module optimization pass is already in progress.
```

Optimizing a specific recovered connection

Manually trigger the path optimization mechanism for connections that have been recovered and are eligible for path optimization. These connections are included in the attribute *eligibleRecoveredConnections*.

For a recovered connection on an ATM interface, enter the following command:

```
optimize AtmIf/<AtmIf> <connection_type> Source  
RerouteOverride
```

For a recovered data link common identifier (DLCI) connection on an FR-ATM interface, enter the following command:

```
optimize FrAtm/<FrAtm> Dlci<Dlci> Siwf Spvc  
RerouteOverride
```

For a recovered Aal1Ces connection, enter the following command:

```
optimize Aal1Ces/<Aal1Ces> Reroute
```

When the command completes successfully, you receive the following response:

```
Path optimization pass completed.
```

Optimizing all connections on an ATM interface

You want to manually trigger the path optimization mechanism against the *AtmIf <interface_type> Reroute* component for all connections on the interface regardless of whether they are eligible for path optimization or not., including those that have been recovered when the optimize command was last run. You enter the following command:

```
optimize -all AtmIf/<AtmIf> [Vpt/Vpi] <interface_type>  
Reroute
```

where:

<interface_type> is Uni, lisp, Aini, or Pnni

When the command completes successfully, you receive the following response:

```
Interface optimization pass completed.
```

If an optimization pass on the ATM interface is in progress when you use the optimize command, you receive the following response:

```
An interface optimization pass is already in progress.
```

If a module (nodal) optimization pass is in progress when you use the optimize command, you receive the following response:

```
A module optimization pass is already in progress.
```

Related information for optimize

See the following for information related to the optimize command:

- [Display command \(page 80\)](#)
- [List command \(page 110\)](#)

Ping -ip(<address>) <component> command

The Ping -ip(<address>) <component> command gives you information about the paths between the end points of a Media Gateway (MG) IP circuit.

The command sends one or more ping packets to the destination node of a specific MG IP circuit. The destination node modifies the ping packet and sends it back to the source node. The Ping -ip(<address>) <component> command uses this response to determine path information. The command waits up to 5 seconds for responses from the ping packets it sends.

The Ping -ip(<address>) <component> command returns the following information to the origination node if the command is successful.

- number of bytes received
- IP address of the responding host
- Internet control message protocol (ICMP) sequence number of the received ping packet
- elapsed time from sending of the ping to receiving of the response

Attention: Only one Ping -ip(<address>) <component> command per component is allowed to be in progress at any one time.

For more information on the Ping -ip(<address>) <component> command, see

- Properties for Ping -ip(<address>) <component> (page 146)
- Syntax for Ping -ip(<address>) <component> (page 146)
- Parameters for Ping -ip(<address>) <component> (page 146)
- Examples for Ping -ip(<address>) <component> (page 147)

Properties for Ping -ip(<address>) <component>

The following table describes the properties of the Ping -ip(<address>) <component> command.

Properties of the Ping -ip(<address>) <component> command

Mode	Impact	Scope	Components
Operational	Passive	Application	NarrowbandServicesTrunkOverAtm VoiceGateway ControlConnection/mg (Nsta Vgs Ctrl/mg) NarrowbandServicesTrunkOverAtm VoiceGateway ControlConnection/sg (Nsta Vgs Ctrl/sg) NarrowbandServicesTrunkOverAtm VoiceGateway IpMediaStreamConnection (Nsta Vgs IpMConn)

Syntax for Ping -ip(<address>) <component>

The following table describes the syntax for the Ping -ip(<address>) <component> command.

Syntax of the Ping -ip(<address>) <component> command

If you want to...	Use the following syntax:
Test the IP network connection from component Nsta Vgs Ctrl/mg on one of voice services processor 2 (VSP2), VSP3, or VSP3-o	Ping -ip(<address>) Nsta/<n> Vgs Ctrl/mg
Test the IP network connection from component Nsta Vgs Ctrl/sg on one of VSP2, VSP3, or VSP3-o	Ping -ip(<address>) Nsta/<n> Vgs Ctrl/sg
Test the IP network connection from component Nsta Vgs IpMConn on one of VSP3 or VSP3-o	Ping -ip(<address>) Nsta/<n> Vgs IpMConn

Parameters for Ping -ip(<address>) <component>

You identify which IP connection you want path information about using the parameters for the Ping -ip(<address>) <component> command.

Parameters of the Ping -ip(<address>) <component> command

Parameter	Notes
-ip	Always enter this option after the Ping verb and before <address>.
<address>	Enter the IP address of the destination node that is to receive the packets. Enter the IP address as follows: <ul style="list-style-type: none">• [0-255].[0-255].[0-255].[0-255]
<component>	Enter the component of the MG that the Ping verb originates from. Enter one of the following components: <ul style="list-style-type: none">• Nsta/<n> Vgs Ctrl/mg• Nsta/<n> Vgs Ctrl/sg• Nsta/<n> Vgs IpMConn where <n> is the instance number of the Nsta component

Examples for Ping -ip(<address>) <component>

The following examples show how to use the Ping -ip<address> <component> command:

- Testing IP connectivity from component Nsta/4 Vgs Ctrl/mg (page 147)
- Testing IP connectivity from component Nsta/4 Vgs Ctrl/sg (page 147)
- Testing IP connectivity from component Nsta/4 Vgs IpMConn (page 148)

Testing IP connectivity from component Nsta/4 Vgs Ctrl/mg

You want to test connectivity (ping) from component Nsta/4 Vgs Ctrl/mg to an address of 48.58.33.51 on the IP network. You enter the following command:

```
Ping -ip(48.58.33.51) Nsta/4 Vgs Ctrl/mg
```

You receive the following response:

```
Ping: Received reply of 1480 bytes from 48.58.33.51:  
icmpSeq=5, time=5ms
```

Testing IP connectivity from component Nsta/4 Vgs Ctrl/sg

You want to test connectivity (ping) from component Nsta/4 Vgs Ctrl/sg to an address of 48.58.33.51 on the IP network. You enter the following command:

```
Ping -ip(48.58.33.51) Nsta/4 Vgs Ctrl/sg
```

You receive the following response:

```
Ping: Received reply of 1480 bytes from 48.58.33.51:  
icmpSeq=6, time=5ms
```

Testing IP connectivity from component Nsta/4 Vgs IpMConn

You want to test connectivity (ping) from component Nsta/4 Vgs IpMConn to an address of 48.58.33.51 on the IP network. You enter the following command:

```
Ping -ip(48.58.33.51) Nsta/4 Vgs IpMConn
```

You receive the following response:

```
Ping: Received reply of 512 bytes from 48.58.33.51:  
icmpSeq=7, time=5ms
```

Ping <connection> Vc command

The ping <connection> Vc command gives you information about the paths between the end points of a frame relay virtual circuit.

The command sends one or more ping packets to the destination node of a specific frame relay virtual circuit. The destination node modifies the ping packet and sends it back to the source node. The ping <connection> Vc command uses this response to determine path information. The command waits up to 15 seconds for responses from the ping packets it sends.

The command returns either a single path to the destination node or the amount of time it takes for a packet to travel to the destination node and back again (round trip delay). You can adjust the size of the ping packet for both the trip to the destination node and the trip back to the source node.

The path taken to the destination node by the ping packet is the same as the path taken by frame relay data packets.

For more information on the ping <connection> Vc command, see

- [Properties for ping <connection> Vc \(page 150\)](#)
- [Syntax for ping <connection> Vc \(page 150\)](#)
- [Parameters for ping <connection> Vc \(page 150\)](#)
- [Examples for ping <connection> Vc \(page 152\)](#)
- [Related information for ping <connection> Vc \(page 153\)](#)

Properties for ping <connection> Vc

The following table describes the properties of the ping <connection> Vc command.

Properties of the ping <connection> Vc command

Mode	Impact	Scope	Components
Operational or Provisioning	Passive	Application	FrameRelayUni DataLinkConnectionIdentifier Vc (FrUni DlcI Vc) FrameRelayNni DataLinkConnectionIdentifier Vc (FrNni DlcI Vc) IpInterfaceOverFrameRelay LogicalChannelNumber Vc (IpiFr Lcn Vc) RemoteServerAgent Connection Vc (Rsa Connection Vc)

Syntax for ping <connection> Vc

The following table describes the syntax for the ping <connection> Vc command.

Syntax of the ping <connection> Vc command

If you want to...	Use the following syntax:
Find a single path to a node	ping <connection> Vc
Determine the round trip delay to a node	ping -roundTripDelay <connection> Vc
Determine the round trip delay using specific packet sizes	ping -roundTripDelay -sendPktDataSize (<size>) -returnPktDataSize (<size>) <connection> Vc

Parameters for ping <connection> Vc

There are two types of parameters for the ping <connection> Vc command:

- [Virtual circuit parameters for ping <connection> Vc \(page 151\)](#)
- [Round trip delay parameters for ping <connection> Vc \(page 151\)](#)

Virtual circuit parameters for ping <connection> Vc

You identify which virtual circuit you want path information about using the components of the ping <connection> Vc.

The command reports the routing identifier (RID), the module identifier (MID), and the process identifier (PID) number of each node on the path between the source and destination node. The PID number only applies to DPN-100 nodes. It indicates the process number of the trunk that received the ping packet. On a Nortel Networks Multiservice Switch node, the PID number is always zero.

Components of the ping <connection> Vc command

Component	Notes
<connection>	Enter the type of connection for the virtual circuit. The following connection types are available: <ul style="list-style-type: none">• FrUni/<n> Dlci/<n>• FrNni/<n> Dlci/<n>• IpiFr Lcn/<n>• Rsa/<n> Connection/<n> where <n> is the instance number of the service and the instance number of the connection
Vc	Always enter this component after the <connection> components.

Round trip delay parameters for ping <connection> Vc

When you use the roundTripDelay option, the command sends five ping packets to the destination node. It records the amount of time it takes to receive a reply back from the destination node for each packet. It then reports the minimum, maximum, and average round trip delay. The command does not report the path the ping packets took to the node.

You can adjust the amount of data the ping packets carry using the sendPktDataSize and returnPktDataSize options. The amount of data the packet carries affects the round trip delay. In most cases, larger packets have longer round trip delay times. Although you can enter zero bytes for both the sendPktDataSize and returnPktDataSize options, the ping packet always uses 12 data bytes to carry ping control information. Since the ping packet contains a 13-byte header, the smallest possible ping packet is 25 bytes.

The default amount of data for both the send and return packets is 128 bytes. If you enter the command using a *FrUni Dlci* or *FrNni Dlci* component and its transfer priority is 11, the default amount of data is 64 bytes.

If you enter a data packet size that exceeds the capacity of a some facility along the path, that facility discards the ping packet.

Round trip delay parameters of the ping <connection> Vc command

Option	Notes
-roundTripDelay -rtd	Use this option to get round trip delay information. The command ignores this option you also select allPaths option.
-sendPktDataSize <size>	Enter the number of bytes of data to send from source to destination node. You can enter a value between 0 and 4095. This option has an effect only if you also specify the roundTripDelay option.
-returnPktDataSize <size>	Enter the number of bytes of data to send from the destination to the source node. You can enter a value between 0 and 4095. This option has an effect only if you also specify the roundTripDelay option.

Examples for ping <connection> Vc

The following examples show how to use the ping <connection> Vc command:

- [Determining a single path example \(page 152\)](#)
- [Determining round trip delay example \(page 152\)](#)

Determining a single path example

You want to find the path to the destination of the virtual circuit on frame relay UNI service 21 with a data link connection identifier of 103. You enter the following command:

```
ping FrUni/21 Dlci/103 Vc
```

You receive the following response:

```
FrUni/21 Dlci/103 Vc
  Destination Rid = 53, Mid = 1121. VC path taken is:
  Rid = 53      Mid = 1121      Pid = 0
```

The destination node is directly connected to your node, so there is only one node in the path.

Determining round trip delay example

You want to determine how long it takes a packet to travel to the destination of a virtual circuit (FrUni/44 Dlci/16 Vc) and back again. You want to send 256 data bytes to the destination node and you want to return 512 bytes back to the source node. You enter the following command:

```
ping -roundTripDelay -sendPktDataSize(256) -
returnPktDataSize(512) FrUni/44 Dlci/16 Vc
```

You receive the following response:

```
FrUni/44 Dlci/16 Vc
  sentPktDataSize = 256 bytes
  returnedPktDataSize = 512 bytes
  pktEmissionPriority = normal
  numRtdPktSent = 5
  numRtdPktReceived = 5
  averageRtd = 6 msec
  minimumRtd = 5 msec
  maximumRtd = 7 msec
```

Related information for ping <connection> Vc

See the following for information related to the ping <connection> Vc command:

- [Ping Rtg Dpn <node> command \(page 154\)](#)

Ping Rtg Dpn <node> command

The ping Rtg Dpn <node> command gives you information about the paths between network nodes that are using the dynamic packet routing system (DPRS).

The command sends one or more ping packets to a node specified using either its routing identifier (RID), its module identifier (MID), or both its RID and MID. The destination node modifies the ping packet and sends it back to the source node. The ping <dpn> command uses this response to determine path information.

The command returns a single path to the destination node, all the paths to the destination node, or the amount of time it takes for a packet to travel to the destination node and back again (round trip delay). You can adjust the path the ping packet selects by setting its sensitivity, reliability, and priority.

For more information on the ping Rtg Dpn <node> command, see

- [Properties for ping Rtg Dpn <node> \(page 155\)](#)
- [Syntax for ping Rtg Dpn <node> \(page 155\)](#)
- [Parameters for ping Rtg Dpn <node> \(page 155\)](#)
- [Examples for ping Rtg Dpn <node> \(page 158\)](#)
- [Related information for ping Rtg Dpn <node> \(page 159\)](#)

Properties for ping Rtg Dpn <node>

The following table describes the properties of the ping Rtg Dpn <node> command.

Properties of the ping Rtg Dpn <node> command

Mode	Impact	Scope	Components
Operational	Passive	Network	Routing DpnAddressPlan ReachableRidInfo (Rtg Dpn Rid) Routing DpnAddressPlan ReachableMidInfo (Rtg Dpn Mid) Routing DpnAddressPlan ReachableRidInfo ReachableMidInfo (Rtg Dpn Rid Mid)

Syntax for ping Rtg Dpn <node>

The following table describes the syntax for the ping Rtg Dpn <node> command.

Syntax of the ping Rtg Dpn <node> command

If you want to...	Use the following syntax:
Find a single path to a node	ping Rtg Dpn Rid/<rid> Mid/<mid>
Find a single path to a node with path selection	ping -sensitivity(delay throughput) -reliability(high normal) -priority(high normal) Rtg Dpn Rid/<rid> Mid/<mid>
Find all paths to a node	ping -allPaths Rtg Dpn Rid/<rid> Mid/<mid>
Find all paths to a node with path selection	ping -sensitivity(delay throughput) -reliability(high normal) -priority(high normal) -allPaths Rtg Dpn Rid/<rid> Mid/<mid>
Determine the round trip delay to a node	ping -roundTripDelay Rtg Dpn Rid/<rid> Mid/<mid>
Determine the round trip delay using specific packet sizes	ping -roundTripDelay -sendPktDataSize (<size>) -returnPktDataSize (<size>) Rtg Dpn Rid/<rid> Mid/<mid>

Parameters for ping Rtg Dpn <node>

There are four types of parameters for the ping Rtg Dpn <node> command:

- [Node identifier parameters for ping Rtg Dpn <node> \(page 156\)](#)
- [Path selection parameters for ping Rtg Dpn <node> \(page 156\)](#)

- [Round trip delay parameters for ping Rtg Dpn <node> \(page 157\)](#)
- [All paths parameter for ping Rtg Dpn <node> \(page 158\)](#)

Node identifier parameters for ping Rtg Dpn <node>

You identify which node you want path information about using the components of the ping Rtg Dpn <node> command. Specify a node by its MID, RID, or both.

With only the node identified, the command sends a single packet carrying 128 bytes of data to the destination node and waits for a reply. If it does not receive a reply in 15 seconds, it will time out. A timeout usually indicates there is a problem with the destination node or congestion on the network.

The command reports the RID, the MID, and the process identifier (PID) number of each node on the path between the source and destination node. The PID number only applies to DPN-100 modules. It indicates the process number of the trunk that received the ping packet. On a Nortel Networks Multiservice Switch node, the PID number is always zero.

Components of the ping Rtg Dpn <node> command

Component	Notes
Rtg Dpn	Always enter these two components.
Rid/<rid> Mid/<mid>	Specify the address of the destination node. Enter the RID, the MID, or both the RID and MID for the node.
Rid/<rid> Mid/<mid>	If you enter only a MID, the command only finds paths within your own RID. If you enter only a RID, the command finds paths to any node within that RID.

Path selection parameters for ping Rtg Dpn <node>

You can adjust how a ping packet selects its path by setting its reliability, sensitivity, and priority. You can use the path section parameters whether you are finding a single path, all paths, or determining the round trip delay.

Path selection parameters of the ping Rtg Dpn <node> command

Option	Notes
-sensitivity(delay throughput)	Enter <i>delay</i> to select the path with the shortest delay time. Enter <i>throughput</i> to select the path with the highest bandwidth. The default is throughput sensitivity.

(1 of 2)

Path selection parameters of the ping Rtg Dpn <node> command (continued)

Option	Notes
-reliability(high normal)	Enter <i>high</i> to select an overflow path if the primary path is congested. Enter <i>normal</i> to discard the ping packet if the path is congested. The default is high reliability.
-priority(high normal)	Enter <i>high</i> to reduce the likelihood of the ping packet being discarded. The default is normal priority.
(2 of 2)	

Round trip delay parameters for ping Rtg Dpn <node>

When you use the roundTripDelay option, the command sends five ping packets to the destination node. It records the amount of time it takes to receive a reply back from the destination node for each packet. It then reports the minimum, maximum, and average round trip delay. The command does not report the path the ping packets took to the node.

You can adjust the amount of data the ping packets carry using the sendPktDataSize and returnPktDataSize options. The amount of data the packet carries will affect the round trip delay. In most cases, larger packets will have longer round trip delay times. Although you can enter zero bytes for both the sendPktDataSize and returnPktDataSize options, the ping packet always uses 12 data bytes to carry ping control information. Since the ping packet contains a 13-byte header, the smallest possible ping packet is 25 bytes.

The default amount of data for both the send and return packets is 128 bytes.

Round trip delay parameters of the ping Rtg Dpn <node> command

Option	Notes
-roundTripDelay -rtd	Use this option to get round trip delay information. The command ignores this option if you also select allPaths option.
-sendPktDataSize <size>	Enter the number of bytes of data to send from source to destination node. You can enter a value between 0 and 4095. This option has an effect only if you also specify the roundTripDelay option.
-returnPktDataSize <size>	Enter the number of bytes of data to send from the destination to the source node. You can enter a value between 0 and 4095. This option has an effect only if you also specify the roundTripDelay option.

All paths parameter for ping Rtg Dpn <node>

You can find many paths to the destination node using the allPaths option:

-allPaths

When you use the allPaths option, the command sends 16 ping packets to the destination node. It reports each unique path and the number of packets that took that path. The command waits up to 15 seconds for responses from all the packets.

Examples for ping Rtg Dpn <node>

The following examples show how to use the ping <dpn> command:

- [Determining a single path example \(page 158\)](#)
- [Determining all paths example \(page 158\)](#)
- [Determining round trip delay example \(page 159\)](#)

Determining a single path example

You want to find the path with the highest throughput to a DPN access module (AM) at RID 4 and MID 478. There are two Nortel Networks Multiservice Switch nodes between the node to which you are logged on (the source node) and the destination node. You enter the following command:

```
ping Rtg Dpn Rid/4 Mid/478
```

You receive the following response:

```
Rtg Dpn Rid/4 Mid/478
Rid = 4      Mid = 1161      Pid = 0
Rid = 4      Mid = 1160      Pid = 0
Rid = 4      Mid = 478       Pid = 659459
```

Pid is the process identifier of the trunk process that received the packet on each RM or AM. This information is not available on Multiservice Switch nodes and is set to 0.

Determining all paths example

You want to find all the paths to a destination node with RID 84 and MID 1103. There are three unique paths between the source node and the destination node. You enter the following command:

```
ping -allPaths Rtg Dpn Rid/84 Mid/1103
```

You receive the following response:

```
Rtg Dpn Rid/84 Mid/1103
16 packets were sent, 16 packets were returned.
Path 1 used 4 time(s):
Rid = 84      Mid = 1115      Pid = 0
Rid = 84      Mid = 1122      Pid = 0
Rid = 84      Mid = 1103      Pid = 0
Path 2 used 4 time(s):
```

```
Rid = 84    Mid = 1115    Pid = 0
Rid = 84    Mid = 1109    Pid = 0
Rid = 84    Mid = 1103    Pid = 0
Path 3 used 8 time(s):
Rid = 84    Mid = 1377    Pid = 0
Rid = 84    Mid = 1109    Pid = 0
Rid = 84    Mid = 1103    Pid = 0
```

Determining round trip delay example

You want to determine how long it takes a packet to travel to a node (RID 84, MID 1103) and back again. You want to send 30 data bytes to the destination node and you want it to return 20 bytes back to the source node. You enter the following command:

```
ping -roundTripDelay -sendPktDataSize(30)
-returnPktDataSize(20) Rtg Dpn Rid/84 Mid/1103
```

You receive the following response:

```
Rtg Dpn Rid/84 Mid/1103
sendPktDataSize      = 30 bytes
returnPktDataSize    = 20 bytes
pktEmissionPriority   = normal
numRTDPktSent        = 5
numRTDPktReceived    = 5
averageRTD            = 11 msec
minimumRTD           = 11 msec
maximumRTD           = 13 msec
```

Related information for ping Rtg Dpn <node>

See the following for information related to the ping Rtg Dpn <node> command:

- [Ping <connection> Vc command \(page 149\)](#)

Protect Fs command

The protect Fs command protects a file from deletion or modification.

When a file is protected, you cannot delete it using the remove Fs command. To delete a protected file, you must first remove its protection using the unprotect Fs command. You can tell if a file is protected or not using the listFile Fs command.

You cannot protect a directory. When you copy a protected file, the new file is not protected.

For more information on the protect Fs command, see

- [Properties for protect Fs \(page 160\)](#)
- [Syntax for protect Fs \(page 160\)](#)
- [File to protect parameter for protect Fs \(page 160\)](#)
- [Protecting a file example \(page 161\)](#)
- [Related information for protect Fs \(page 161\)](#)

Properties for protect Fs

The following table describes the properties of the protect Fs command.

Properties of the protect Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for protect Fs

The following table describes the syntax for the protect Fs command.

Syntax of the protect Fs command

If you want to...	Use the following syntax:
Protect a file from deletion	protect -path(filepath) Fs

File to protect parameter for protect Fs

You specify which file you want to prevent from being deleted or modified using the path option:

-path(<filepath>)

Enter the absolute or relative path for the file you want to prevent from being deleted or modified. Enclose the path in double quotation marks. For information on path syntax, see [Entering commands \(page 15\)](#).

You must enter the path option.

Protecting a file example

You want to prevent the alarm.001 file in the /tmp directory from being deleted or modified. Your current working directory is root (/). You enter the following command:

```
protect -path("/tmp/alarm.001") Fs
```

You use the following listFile Fs commands to verify that the file was protected:

```
listFile -path("/tmp/alarm.001") Fs
```

You receive the following response:

```
Fs
  Type Prot Size   Date       Time       Name
  file yes  9547   1998-05-05 10:12:38  alarm.001
```

The yes in the Prot column indicates that the file is protected.

Related information for protect Fs

See the following for information related to the protect Fs command:

- [ListFile Fs command \(page 117\)](#)
- [Remove Fs command \(page 176\)](#)
- [Unprotect Fs command \(page 274\)](#)

ProtectionLockout Aps command on Multiservice Switch 7400

The protectionLockout Aps (protLock Aps) command forces a link protected by automatic protection switching (APS) to stop using the protection line.

An APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. When no manual overrides are in effect, the APS system automatically determines which line is active.

If the protection line is active when you enter this command, APS switches the data to the working line (making it active), even if the working line is degraded or has failed. If you have set the APS system to bidirectional mode and the far end of the link has already locked the protection line, the protectionLockout Aps command is ignored.

You can release the lock on the protection line using the clear Aps command. You can change the active line between the working and protection line using the switch Aps command.

For more information on the protectionLockout Aps command, see

- [Properties for protectionLockout Aps \(page 162\)](#)
- [Syntax for protectionLockout Aps \(page 162\)](#)
- [Component instance parameter for protectionLockout Aps \(page 163\)](#)
- [Examples for protectionLockout Aps \(page 163\)](#)
- [Related information for protectionLockout Aps \(page 163\)](#)

Properties for protectionLockout Aps

The following table describes the properties of the protectionLockout Aps command.

Properties of the protectionLockout Aps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	AutomaticProtectionSwitching (Aps)

Syntax for protectionLockout Aps

The following table describes the syntax for the protectionLockout Aps command.

Syntax of the protectionLockout Aps command

If you want to...	Use the following syntax:
Prevent APS from using the protection line	protectionLockout Aps/<n>

Component instance parameter for protectionLockout Aps

An Aps component instance represents a link that is protected by APS. The Aps component manages both the working and protection lines. To lock the protection line on a particular link, you specify the instance number of the Aps component:

Aps/ <n>

The instance value can be any integer between 0 and 15999.

Examples for protectionLockout Aps

The following examples show how to use the protectionLockout Aps command:

- [Locking the protection line in unidirectional mode example \(page 163\)](#)
- [Locking the protection line in bidirectional mode example \(page 163\)](#)

Locking the protection line in unidirectional mode example

You have an APS-protected link (represented by Aps/4) that you want to prevent from using the protection line. APS is currently in unidirectional mode. You enter the following command:

```
protectionLockout Aps/4
```

APS stops using the protection line as the active line on the near end of the link. However, the far end of the link, which operates independently in unidirectional mode, can still use its protection line for the active line.

Locking the protection line in bidirectional mode example

You have an APS-protected link (represented by Aps/4) that you want to prevent from using the protection line. APS is currently in bidirectional mode. You enter the following command:

```
protectionLockout Aps/4
```

APS stops using the protection line as the active line on the near end and the far end of the link.

Related information for protectionLockout Aps

See the following for information related to the protectionLockout Aps command:

- [Clear Aps command on Multiservice Switch 7400 \(page 51\)](#)
- [Switch Aps command on Multiservice Switch 7400 \(page 231\)](#)

ProtectionLockout Laps command on Multiservice Switch 15000 and Multiservice Switch 20000

The protectionLockout Laps (protLock Laps) command forces a link protected by line automatic protection switching (Line APS) to stop using the protection line.

An Line APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. When no manual overrides are in effect, the Line APS system automatically determines which line is active.

If the protection line is active when you enter this command, Line APS switches the data to the working line (making it active), even if the working line is degraded or has failed. If you have set the Line APS system to bidirectional mode and the far end of the link has already locked the protection line, the protectionLockout Laps command is ignored.

You can release the lock on the protection line using the clear Laps command. You can change the active line between the working and protection line using the switch Laps command.

For more information on the protectionLockout Laps command, see

- [Properties for protectionLockout Laps \(page 165\)](#)
- [Syntax for protectionLockout Laps \(page 165\)](#)
- [Component instance parameter for protectionLockout Laps \(page 166\)](#)
- [Examples for protectionLockout Laps \(page 166\)](#)
- [Related information for protectionLockout Laps \(page 166\)](#)

Properties for protectionLockout Laps

The following table describes the properties of the protectionLockout Laps command.

Properties of the protectionLockout Laps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	LineAutomaticProtection Switching (Laps)

Syntax for protectionLockout Laps

The following table describes the syntax for the protectionLockout Laps command.

Syntax of the protectionLockout Laps command

If you want to...	Use the following syntax:
Prevent LAPS from using the protection line	protectionLockout Laps/<n>

Component instance parameter for protectionLockout Laps

A Laps component instance represents a link that is protected by LAPS. The Laps component manages both the working and protection lines. To lock the protection line on a particular link, you specify the instance number of the Laps component:

Laps / <n>

The instance value can be any integer between 0 and 15999.

Examples for protectionLockout Laps

The following examples show how to use the protectionLockout Laps command:

- [Locking the protection line in unidirectional mode example \(page 166\)](#)
- [Locking the protection line in bidirectional mode example \(page 166\)](#)

Locking the protection line in unidirectional mode example

You have an LAPS-protected link (represented by Laps/4) that you want to prevent from using the protection line. LAPS is currently in unidirectional mode. You enter the following command:

protectionLockout Laps/4

LAPS stops using the protection line as the active line on the near end of the link. However, the far end of the link, which operates independently in unidirectional mode, can still use its protection line for the active line.

Locking the protection line in bidirectional mode example

You have an LAPS-protected link (represented by Laps/4) that you want to prevent from using the protection line. LAPS is currently in bidirectional mode. You enter the following command:

protectionLockout Laps/4

LAPS stops using the protection line as the active line on the near end and the far end of the link.

Related information for protectionLockout Laps

See the following for information related to the protectionLockout Laps command:

- [Clear Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 53\)](#)

- [Switch Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 236\)](#)

Quit command

The quit (exit) command ends your local or telnet session. It is identical to the logout command.

The logout and quit commands, along with their abbreviations, give you four ways to end your session:

- logout
- logoff
- quit
- exit

See [Logout command \(page 128\)](#) for more information.

Reconnect command

The reconnect command uses break-before-make techniques and will release the current connection and try to re-establish the connection using one of the following parameters:

- The primary path parameter releases the current connection and tries to reconnect using the primary path. This is the default parameter.
- The alternate path parameter releases the current connection and tries to reconnect using the alternate path. If the alternate path has not been provisioned, the reconnect command will fail and the call will be released.
- The automatic route selection parameter releases the current connection and tries to reconnect using automatic route selection, for example, a normal Dijkstra algorithm used for SVC path selection. If the *automaticFallback* attribute is disabled, the reconnect command will fail and the call will be released.

Attention: In the case where the connection is unable to re-establish itself on the desired path, the retry sequence is activated in the following order: primary path, followed by alternate path if provisioned, and ending with a normal retry, if the *automaticFallback* attribute is set.

When a specified path connection is configured with rerouting capabilities, the reconnect command use make-before-break techniques and acts as follows:

- If the reconnect command is issued with either a primary, alternate or automatic option, an attempt is made to establish the call on the path designated by the option. If that attempt is successful, then the connection will be swapped to the new path and the existing connection will be taken down. If the re-establishment attempt fails, the connection will remain on it's original path.
- If the reconnect command is issued with a primary (or alternate) option and the connection is already on the primary (or alternate) path, then no action is taken. Similarly, when using the automatic option, if a connection is on an automatically computed route and a less expensive automatically calculated route cannot be found, no action is taken.
- If a reconnect is issued without specifying an option, the actions taken are similar to those of a Rerouting Optimize command. For more information, refer to [Optimize command \(page 139\)](#). Attempts are made to re-establish the call on a more optimal route in consideration of specified path information. These attempts will be carried out until the connection achieves a more optimal path or it is determined that a more optimal path cannot be found. For example, if a connection of this type were on it's alternate path, issuing a reconnect command with no option would result in an attempt being made to reconnect on the primary path. Should the

attempt fail, then no additional attempts would be carried out. Should the attempt be successful, then the connection would be swapped to the primary path and the existing connection would be taken down.

For more information on the reconnect command, see

- [Properties for reconnect \(page 170\)](#)
- [Syntax for reconnect \(page 170\)](#)
- [Parameters for reconnect \(page 170\)](#)
- [Examples for reconnect \(page 171\)](#)

Properties for reconnect

The following table describes the properties of the reconnect command:

Properties of the reconnect command

Mode	Impact	Scope	Component
Operational and Provisioning	Service	Connection	Manual Designated Transit List (MDTL)

Syntax for reconnect

The following table describes the syntax for the reconnect command.

Syntax of the reconnect command

If you want to...	Use the following syntax:
release the current connection and re-establish the connection	reconnect [-primary/-pri] [-alternate/-alter] [-automatic/-auto]

Parameters for reconnect

The reconnect command has the following options:

- [Primary path for reconnect \(page 170\)](#)
- [Alternate path for reconnect \(page 171\)](#)
- [Automatic route selection for reconnect \(page 171\)](#)

Primary path for reconnect

You specify which connection to release and reconnect with using the primary path option. This is the default behavior:

-primary

Alternate path for reconnect

You specify the alternate path as the reconnect path using the alternate path option:

```
-alternate
```

Automatic route selection for reconnect

You specify the automatic route to perform the reconnect using the automatic option:

```
-automatic
```

Examples for reconnect

The following examples illustrate how to use the reconnect command:

- [Reconnect to primary path example \(page 171\)](#)
- [Reconnect to alternate path example \(page 171\)](#)
- [Reconnect to automatic route selection example \(page 172\)](#)

Reconnect to primary path example

You want to reconnect using the primary path parameter. You enter the following command:

```
reconnect -pri atmif/10 vcc/0.100 src mdt1
```

The following responses are shown for specified path connections with rerouting capabilities.

If the reconnect is successful, you receive the following response:

```
Reconnect command is completed as requested.
```

If the connection is already on the primary path, you receive the following response:

```
Reconnect command not necessary since connection already  
on primary path. No action taken.
```

If the reconnect fails because the primary path is not available, you receive the following response:

```
Reconnect command unable to complete as requested. Check  
the end-to-end availability
```

Reconnect to alternate path example

You want to reconnect using the alternate path parameter. You enter the following command:

```
reconnect -alter atmif/10 vcc/0.100 src mdt1
```

If the specified path connection with rerouting capabilities is already on the alternate path, you receive the following response:

```
Reconnect command not necessary since connection already  
on alternate path. No action taken.
```

Reconnect to automatic route selection example

You want to reconnect using the automatic route selection parameter. You enter the following command:

```
reconnect -auto atmif/10 vcc/0.100 src mdt1
```

ReloadCp Lp command

The reloadCp Lp (reload Lp) command lets you reload the control processor (CP) using a saved provisioning view.

By default, the reloadCp Lp command will only reload the control processor if there is an available standby control processor. To minimize CP down time, the standby CP loads the saved provisioning view and then becomes the active CP. The original active CP then loads the saved provisioning view and becomes the standby CP. If you have only a single control processor, you must use the force option to reload it.

Reloading the CP can cause some or all function processors to reload. Depending on the software to be loaded, standby function processors may be reloaded and become active as the standby CP becomes active.

For more information on the reloadCp Lp command, see

- [Properties for reloadCp Lp \(page 173\)](#)
- [Syntax for reloadCp Lp \(page 173\)](#)
- [Parameters for reloadCp Lp \(page 174\)](#)
- [Reloading with a saved view on a dual-CP node example \(page 174\)](#)
- [Related information for reloadCp Lp \(page 175\)](#)

Properties for reloadCp Lp

The following table describes the properties of the reloadCp Lp command:

Properties of the reloadcp command

Mode	Impact	Scope	Components
Operational and Provisioning	Service	Device	LogicalProcessor (Lp)

Syntax for reloadCp Lp

The following table describes the syntax for the reloadCp Lp command.

Syntax of the reloadCp Lp command

If you want to...	Use the following syntax:
Reload the control processor using a saved provisioning view	reloadCp -file(<viewname>) Lp/0
Reload the control processor when the node has a single CP	reloadcp -file(<viewname>) -force Lp/0

Parameters for reloadCp Lp

The reloadCp Lp command has the following options:

- [Saved view parameter for reloadCp Lp \(page 174\)](#)
- [Single-CP node force parameter for reloadCp Lp \(page 174\)](#)

Saved view parameter for reloadCp Lp

You specify which saved view that you want to reload on the control processor using the file option:

-file(<viewname>)

Enter the name of the saved view in the option. For information on the naming of saved views, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

Single-CP node force parameter for reloadCp Lp

You can force the reloadCp Lp command to work on a single-CP node using the force option:

-force

This option has no effect on a dual-CP node.

Examples for reloadCp Lp

The following examples illustrate how to use the reloadCp Lp command:

- [Reloading with a saved view on a dual-CP node example \(page 174\)](#)
- [Reloading with a saved view on a single-CP node example \(page 175\)](#)

Reloading with a saved view on a dual-CP node example

You want to reload a control processor on a dual-CP node using a saved view. You enter the following command:

```
reloadCp -file(ABCD1.full.001) Lp/0
```

The standby CP loads the new view and becomes the active CP. The active CP then loads the new view and becomes the standby CP.

Reloading with a saved view on a single-CP node example

You want to reload a control processor on a single-CP node using a saved view. You enter the following command:

```
reloadCp -file(ABCD1.full.001) -force Lp/0
```

The CP restarts and loads the saved view. Service on the node is interrupted during the reload.

Related information for reloadCp Lp

See the following for information related to the reloadCp Lp command:

- [Activate Prov command \(page 25\)](#)
- [Apply Prov command \(page 34\)](#)
- [Load Prov command \(page 121\)](#)
- [Reset <processor> command \(page 183\)](#)
- [Restart <processor> command \(page 190\)](#)

Remove Fs command

The remove Fs command lets you delete files and directories. If you remove a directory, you delete all its contents, including all its subdirectories.

If a file is protected from deletion, you have to turn its protection off using the unprotect Fs command before removing it. You can force the remove Fs command to delete protected files using the force option.

	<p>CAUTION Possible system failure</p> <p>Do not remove the directories in the root directory (/). These directories contain necessary system data and software. If you remove the /tmp directory the system fails.</p>
---	---

For more information on the remove Fs command, see

- [Properties for remove Fs \(page 176\)](#)
- [Syntax for remove Fs \(page 176\)](#)
- [Parameters for remove Fs \(page 177\)](#)
- [Examples for remove Fs \(page 178\)](#)
- [Related information for remove Fs \(page 178\)](#)

Properties for remove Fs

The following table describes the properties of the remove Fs command.

Properties of the remove Fs command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for remove Fs

The following table describes the syntax for the remove Fs command.

Syntax of the remove Fs command

If you want to...	Use the following syntax:
Remove a file	remove -path(<filepath>) Fs
Remove a directory and all its contents	remove -path(<directorypath>) -recursive Fs
(1 of 2)	

Syntax of the remove Fs command (continued)

If you want to...	Use the following syntax:
Remove a protected file	remove -path(<filepath>) -force -recursive Fs
Remove a directory and all its contents including protected files	remove -path(<directorypath>) -recursive -force Fs
(2 of 2)	

Parameters for remove Fs

There are three parameters for the remove Fs command:

- [File or directory to remove parameter \(page 177\)](#)
- [Remove subdirectories parameter \(page 177\)](#)
- [Remove protected files parameter \(page 177\)](#)

File or directory to remove parameter

You specify which file or directory you want to remove using the path option:

```
-path(<filepath>)  
-path(<directorypath>)
```

Enter the path to the file or directory you want to remove. If you specify a directory, you must also enter the recursive option. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

If you try to remove a protected file, the command fails. If you remove a directory that contains protected files, the command does not delete the protected files or directories that contain them. It does delete all other files and directories.

You must specify this option.

Remove subdirectories parameter

You can remove the contents of all subdirectories using the recursive option:

```
-recursive
```

To use this option, you must specify a directory in the path option.

Whenever deleting a directory, you must specify this option even if the directory contains no subdirectories.

Remove protected files parameter

You can remove files even if they are protected using the force option:

```
-force
```

Examples for remove Fs

The following examples illustrate how to use the remove Fs command:

- [Removing a file and directory example \(page 178\)](#)
- [Removing a protected file example \(page 178\)](#)

Removing a file and directory example

You want to delete the file account.05051334.010 in your current working directory. You enter the following command:

```
remove -path("account.05051334.010") Fs
```

You now want to remove a copy of the closed subdirectory you created in the /tmp directory. You enter the following command:

```
remove -path("/tmp/closed") Fs
```

The command removes the closed subdirectory along with all its subdirectories.

Removing a protected file example

You have a test directory in the /tmp directory containing the protected file test.info. Your current working directory is /tmp. You want to remove the test.info file. You enter the following command:

```
remove -path("test/test.info") -force Fs
```

You now want to remove the entire test directory. It still contains a number of protected files. You enter the following command:

```
remove -path("test") -recursive -force Fs
```

Related information for remove Fs

See the following for information related to the remove Fs command:

- [Chdir Fs command \(page 40\)](#)
- [ListFile Fs command \(page 117\)](#)
- [Move Fs command \(page 134\)](#)
- [Protect Fs command \(page 160\)](#)
- [Unprotect Fs command \(page 274\)](#)

Remove Sw Av command

The remove Sw Av command lets you remove an unused software application version from the file system. When you remove an application version, you also remove all of its associated patches.

The remove Sw Av command considers a software application version unused if it is not in the application version list (the *avList* attribute of the *Software* component) of any semantically checked view. A semantically checked view can include the current view, the edit view, and saved views. Since all PD files for that particular AV are stored in the SSUP directory, unless they are specific to a patched AV, the remove Sw Av command should not be used to remove an SSUP AV if a patched AV is in use. The patched AV must be removed before the SSUP AV can be removed.

If a semantically checked view uses the application version, the remove Sw Av command fails. The command also fails if a start Sw Dld, tidy Sw, check Prov, or another remove Sw Av command is in progress, or if there is an attempt to remove a SUPP AV directory if a patched AV is in use.

You can remove all unused software applications using the tidy Sw command.

For more information on the remove Sw Av command, see

- [Properties for remove Sw Av \(page 180\)](#)
- [Syntax for remove Sw Av \(page 180\)](#)
- [Application version parameter for remove Sw Av \(page 180\)](#)
- [Removing an unused application version example \(page 180\)](#)
- [Related information for remove Sw Av \(page 180\)](#)

Properties for remove Sw Av

The following table describes the properties of the remove Sw Av command.

Properties of the remove Sw Av command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	Software ApplicationVersion (Sw Av)

Syntax for remove Sw Av

The following table describes the syntax for the remove Sw Av command.

Syntax of the remove Sw Av command

If you want to...	Use the following syntax:
Remove an unused software application version	remove Sw Av/<application_version>

Application version parameter for remove Sw Av

You specify which application version you want to remove using the instance value of the *ApplicationVersion (Av)* component:

Sw Av/<application_version>

Enter the name of the application.

Removing an unused application version example

You want to remove the unused software application, ip_AA08A and all its associated patches. You enter the following command:

remove Sw Av/ip_AA08A

You receive the following response:

```
Sw Av/IP_AA08
The following AV(s) have been removed:
ip_AA008
```

Related information for remove Sw Av

See the following for information related to the remove Sw Av command:

- [Start Sw DId command \(page 219\)](#)
- [Stop Sw DId command \(page 229\)](#)
- [Tidy Sw command \(page 257\)](#)

Replay aaserv command

Use the replay aaserv command to cause all active alarms contained in the active alarm list (AAList) to be delivered to the session (for example, Nmis Fmip Session/<x>) that initiates the replay command.

	<p>CAUTION Multiservice Data Manager applicability only This command is only applicable internally on a Multiservice Data Manager workstation.</p>
---	--

For more information on the replay aaserv command, see

- [Properties for replay aaserv \(page 181\)](#)
- [Syntax for replay aaserv \(page 181\)](#)
- [Related information for replay aaserv \(page 182\)](#)

Properties for replay aaserv

The following table describes the properties of the replay aaserv command:

Properties of the replay aaserv command

Mode	Impact	Scope	Component
Operational	Passive	Device	ActiveAlarmServices

Syntax for replay aaserv

The following table describes the syntax for the replay aaserv command.

Syntax of the replay aaserv command

If you want to...	Use the following syntax:
Forward all alarms from the AAList to your Multiservice Data Manager	replay aaserv
The replay aaserv command is only supported when used with a Multiservice Data Manager. It should not be manually invoked by an operator. Refer to 241-6001-303 <i>Nortel Networks Multiservice Data Manager Customization and Server Administration</i> for details on working with the AAList through Multiservice Data Manager.	

When initiated, the replay aaserv command displays a summary of all active alarms from the AAList, as well as a response stating that all active alarms have been successfully replayed.

Attention: The maximum number of concurrent replay aaserv commands allowed to run on a Nortel Networks Multiservice Switch node is 8. From any given session however, the maximum number of concurrent replay aaserv commands allowed to run is 1.

Related information for replay aaserv

See the following for information related to the replay aaserv command:

- [Clear -notificationId\(<id>\) -comment\(<text>\) aaserv command \(page 48\)](#)

Reset <processor> command

The reset <processor> command resets the hardware, runs the self tests, and reloads the software for one or more processor cards. You can issue the command against a processor card, a logical processor (LP), or the entire node.

When a control processor resets, it reloads the software specified in its committed provisioning view. When a function processor resets, it reloads the software specified for it in the current view. You cannot reset a control processor while a disk synchronization is in progress.



CAUTION

Data loss may occur

When you reset a processor card it is temporarily unable to provide service. During the time the processor is resetting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you reset a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

In some cases, a reset <processor> command causes a switchover from the active processor card to the standby processor card. A switchover can occur for both spared function processors and spared control processors. Special restrictions apply when causing a CP switchover. Before executing the *reset Lp/0* command, the value of the *revertibleTimerCountdown* attribute, under the Shelf component, must be zero. See NN10600-550 *Nortel Networks Multiservice Switch 7400/15000/20000 Common Configuration Procedures* for information.

An alternative to resetting a processor is to restart it using the restart <processor> command. When you restart a processor, the hardware resets but the software only reinitializes. Although the restart <processor> command does not completely reset the processor card, it brings it back into service more quickly. However, data loss can still occur.

For more information on the reset <processor> command, see

- [Properties for reset <processor> \(page 184\)](#)
- [Syntax for reset <processor> \(page 184\)](#)
- [Processor identifier parameters for reset <processor> \(page 185\)](#)

- [Examples for reset <processor> \(page 185\)](#)
- [Related information for reset <processor> \(page 187\)](#)

Properties for reset <processor>

The following table describes the properties of the reset <processor> command.

Properties of the reset <processor> command

Mode	Impact	Scope	Components
Operational and Provisioning	Service	Device	Shelf Shelf Card LogicalProcessor (Lp)

Syntax for reset <processor>

The following table describes the syntax for the reset <processor> command.

	CAUTION Data loss may occur When you reset a processor card it is temporarily unable to provide service. During the time the processor is resetting, data can be lost.
--	--

	CAUTION Loss of stable SVC connections may occur When you reset a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.
---	---

Syntax of the reset <processor> command

If you want to...	Use the following syntax:
Reset a particular processor card	reset Shelf Card/<n>
Reset the active processor card of a logical processor	reset Lp/<n>
Reset all processor cards on the node	reset Shelf

Processor identifier parameters for reset <processor>

You identify which processor or processors you want to reset using the components of the command.

If you issue the command against a *Shelf Card* component, it resets that particular processor card. If you issue the command against a *LogicalProcessor (Lp)* component, it resets the active processor card for that logical processor. The standby processor card for the logical processor (if present) does not reset. In most cases, a reset command causes a switchover from the active to standby processor.

If you issue the reset command against the *Shelf* component, it resets all the processor cards in the node.



CAUTION

Data loss may occur

When you reset a processor card it is temporarily unable to provide service. During the time the processor is resetting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you reset a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

Components for the reset <processor> command

Component	Description
Shelf Card/<n>	To reset a particular processor card, enter the slot number of the card.
Lp/<n>	To reset the active processor card of a logical processor, enter the number of the logical processor.
Node	To reset all the processors on the node, use the <i>Shelf</i> component.

Examples for reset <processor>

The following examples show how to use the reset <processor> command:

- [Resetting a processor card example \(page 186\)](#)
- [Resetting a logical processor example \(page 186\)](#)
- [Resetting all processor cards example \(page 186\)](#)



CAUTION

Data loss may occur

When you reset a processor card it is temporarily unable to provide service. During the time the processor is resetting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you reset a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

Resetting a processor card example

You want to reset the processor card in slot 2. You enter the following command:

```
reset Shelf Card/2
```

The processor card in slot 2 resets.

Resetting a logical processor example

You want to reset logical processor 4. You enter the following command:

```
reset Lp/4
```

The active processor card for the logical processor resets.

Resetting all processor cards example

You want to reset the processor cards in the node. You enter the following command:

```
reset Shelf
```

All processor cards reset.

Related information for reset <processor>

See the following for information related to the reset <processor> command:

- [ReloadCp Lp command \(page 173\)](#)
- [Restart <processor> command \(page 190\)](#)
- [Switchover Lp command \(page 240\)](#)

Restart command

The restart command is only used when operating the Nortel Networks Multiservice Switch Media Gateway application with ATM provisioned switched virtual connections (provisioned SVCs) and switched permanent virtual connections (SPVCs).

The restart command is used to restart the automatic connection procedure. Typically, this is done after the automatic connection procedure has been abandoned after reaching the maximum number of retries allowed. However, the restart command may be used before this maximum is reached.

If the restart command is used on an existing ATM connection, the restart command clears the existing connection and attempts to make a new connection using the current active address.

For more information on the restart command, see

- [Properties for restart \(page 188\)](#)
- [Syntax for restart \(page 188\)](#)
- [Examples for restart \(page 189\)](#)

You can issue the restart command only against the components listed in [Properties for restart \(page 188\)](#).

Properties for restart

The following table describes the properties of the restart command.

Properties of the restart command

Mode	Impact	Scope	Components
Operational	Service	Device	Nsta/<n> Vgs AtmTConn/<m> Aap Nsta/<n> Vgs AtmTConn/<m> SpvcAp Nsta/<n> Vgs IpMConn/<m> Aap Nsta/<n> Vgs IpMConn/<m> SpvcAp Nsta/<n> Vgs Ctrl/<m> Aap Nsta/<n> Vgs Ctrl/<m> SpvcAp Nsta/<n> Vgs Conn/<m> Aap Nsta/<n> Vgs Conn/<m> SpvcAp

Syntax for restart

The following table describes the syntax for the restart command.

Syntax of the restart command

If you want to...	Use the following syntax:
Restart the automatic connection procedure for a trunk using a provisioned SVC active access point.	<code>restart Nsta/<n> Vgs <trunktype>/<m> Aap</code> where <trunktype> can be <code>AtmTConn</code> , <code>IpMConn</code> , <code>Conn</code> , or <code>Ctrl</code>
Restart the automatic connection procedure for a trunk using an SPVC access point.	<code>restart Nsta/<n> Vgs <trunktype>/<m> SpvcAp</code> where <trunktype> can be <code>AtmTConn</code> , <code>IpMConn</code> , <code>Conn</code> , or <code>Ctrl</code>

Examples for restart

The following examples show how to use the restart command:

- [Restarting a trunk with bearer traffic using a provisioned SVC active access point \(page 189\)](#)
- [Restarting a signaling trunk using an SPVC access point \(page 189\)](#)

Restarting a trunk with bearer traffic using a provisioned SVC active access point

An ATM trunk carrying bearer traffic has been using the Media Gateway retry process to re-establish a provisioned switched virtual connection (provisioned SVC) to an ATM address. The maximum number of retries were attempted, but all were unsuccessful. You have corrected the problem in the ATM network that was preventing the provisioned SVC from being established. You want to restart the automatic connection procedure. You enter the following:

```
restart Nsta/<n> Vgs AtmTConn/<m> Aap
```

The provisioned SVC is re-established.

Restarting a signaling trunk using an SPVC access point

An signaling trunk has been using the Media Gateway retry process to re-establish a switched permanent virtual connection (SPVC) to an ATM address. The maximum number of retries were attempted, but all were unsuccessful. You have added the ATM address of a backup node or have corrected the initial problem and want to re-establish the trunk. You want to restart the automatic connection procedure to connect to the backup node. You enter the following:

```
restart Nsta/<n> Vgs Ctrl/<m> SpvcAp
```

The SPVC is re-established with the backup node.

Restart <processor> command

The restart <processor> command resets the hardware (except for memory), runs the self tests, and reinitializes the software of a processor card. You can issue the command against a processor card or a logical processor (LP).

For the restart <processor> command to work on a control processor, the control processor must be running a committed view. If it is running an uncommitted view, the control processor resets instead of restarting. You cannot restart a control processor while a disk synchronization is in progress.



CAUTION

Data loss may occur

When you restart a processor it is temporarily unable to provide service. During the time the processor is restarting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you restart a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

In some cases, a restart <processor> command causes a switchover from the active processor card to the standby processor card. A switchover can occur for both spared function processors and spared control processors. If you cause the switchover of control processors twice within 10 minutes, the system automatically performs a node reset. The system considers a second CP switchover within 10 minutes to be an indication of a more serious fault.

An alternative to restarting a processor is to reset it using the reset <processor> command. When you reset a processor, the hardware resets and the software reloads. The reset <processor> command provides a complete initialization of a processor card, but it takes longer to bring the processor card back into service.

For more information on the restart <processor> command, see

- [Properties for restart <processor> \(page 191\)](#)
- [Syntax for restart <processor> \(page 191\)](#)
- [Processor identifier parameters for restart <processor> \(page 191\)](#)
- [Examples for restart <processor> \(page 192\)](#)
- [Related information for restart <processor> \(page 193\)](#)

Properties for restart <processor>

The following table describes the properties of the restart <processor> command.

Properties of the restart <processor> command

Mode	Impact	Scope	Components
Operational and Provisioning	Service	Device	Shelf Card LogicalProcessor (Lp)

Syntax for restart <processor>

The following table describes the syntax for the restart <processor> command.

	CAUTION Data loss may occur When you restart a processor it is temporarily unable to provide service. During the time the processor is restarting, data can be lost.
---	--

	CAUTION Loss of stable SVC connections may occur When you restart a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.
---	---

Syntax of the restart <processor> command

If you want to...	Use the following syntax:
Restart a processor card	restart Shelf Card/<n>
Restart the active processor card of a logical processor	restart Lp/<n>

Processor identifier parameters for restart <processor>

You identify which processor you want to restart using the components of the command.

If you issue the command against a *Shelf Card* component, it restarts that particular processor card. If you issue the command against a *LogicalProcessor (Lp)* component, it restarts the active processor card for that

logical processor. The standby processor card for the logical processor (if present) does not restart. In most cases, a restart command causes a switchover from the active to standby processor.



CAUTION

Data loss may occur

When you restart a processor it is temporarily unable to provide service. During the time the processor is restarting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you restart a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

Components for the restart <processor> command

Component	Description
Shelf Card Card/<n>	To restart a particular processor card, enter the slot number of the card.
Lp/<n>	To restart the active processor card of an LP, enter the number of the LP.

Examples for restart <processor>

The following examples show how to use the restart <processor> command:

- [Restarting a processor card example \(page 193\)](#)
- [Restarting a logical processor example \(page 193\)](#)



CAUTION

Data loss may occur

When you restart a processor it is temporarily unable to provide service. During the time the processor is restarting, data can be lost.



CAUTION

Loss of stable SVC connections may occur

When you restart a processor card, a loss of SVC connections may occur. Although stable SVC calls should remain active in a redundant processor configuration, exercise caution when issuing this command.

Restarting a processor card example

You want to restart the processor card in slot 1. You enter the following:

```
restart Shelf Card/1
```

The processor card in slot 1 restarts.

Restarting a logical processor example

You want to restart logical processor 4. You enter the following command:

```
restart Lp/4
```

The active processor card for the logical processor restarts.

Related information for restart <processor>

See the following for information related to the restart <processor> command:

- [ReloadCp Lp command \(page 173\)](#)
- [Reset <processor> command \(page 183\)](#)
- [Switchover Lp command \(page 240\)](#)

Restore Prov command

Use the restore Prov command to reactivate the journaled current view if a node resets to the committed view. The attribute *restorePossible* is set to *yes* in the case where the restore Prov command can be issued to restore the journaled current view.



CAUTION

If you do not confirm the restore Prov command (see [Confirm Prov command \(page 64\)](#)) within 20 minutes of issuing it, a system restart occurs and the system reactivates the last committed view as the current view (see [Commit Prov command \(page 61\)](#)). A service disruption occurs while the restart is in progress.

Attention: Restoring a view can delete certain components in the current view. Some components may temporarily go out of service if the changes are critical to the provisioned data.

For more information on the restore Prov command, see

- [Properties for restore Prov \(page 194\)](#)
- [Syntax for restore Prov \(page 194\)](#)
- [Examples for restore Prov \(page 195\)](#)
- [Related information for restore Prov \(page 195\)](#)

Properties for restore Prov

The following table describes the properties of the restore Prov command.

Properties of the restore Prov command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Application	ProvisioningSystem (Prov)

Syntax for restore Prov

The following table describes the syntax for the restore Prov command.

Syntax of the restore Prov command

If you want to...	Use the following syntax:
reactivate the current journal view after a CP- switchover or node reset	restore Prov

Examples for restore Prov

The following examples show how to use the restore Prov command:

- [Attention:Verifying that a restore is possible example \(page 195\)](#)
- [Restoring the current journaled view example \(page 195\)](#)

Attention: Verifying that a restore is possible example

You want to verify that a restore is possible. You enter the following command:

```
display Prov restorePossible
```

You receive the following response:

```
Prov
restorePossible = yes
ok <timestamp>
```

Restoring the current journaled view example

You want to restore the current journaled view, then issue the restore prov command. You enter the following command:

```
restore Prov
```

You receive the following response:

```
Prov
You have 20 minutes in which to confirm the restore.
ok <timestamp>
```

You must perform a confirm Prov after the restore finishes. Refer to the [Confirm Prov command \(page 64\)](#).

Related information for restore Prov

See the following items for information related to the restore Prov command:

- [Activate Prov command \(page 25\)](#)
- [Commit Prov command \(page 61\)](#)
- [Confirm Prov command \(page 64\)](#)

Run Shelf Test command

The run Shelf Test command lets you manually test the bus clock source. The test verifies that all operational processor cards can receive signals from the clock source.



CAUTION **Risk of data loss**

The bus clock source test can cause minor data loss on the bus. Only run this test when bus utilization is low.

The system can automatically test the bus clock source. If you disable automatic bus clock source testing, you should manually test the bus clock source using the run Shelf Test command at least once a month. You can view information on the current status of the bus clock source by displaying the *clockSourceStatus* attribute of the *Shelf Bus* components.

To test the bus clock source, you must set the *type* attribute of the *Shelf Test* component to *busClock*. After performing the test using the run Shelf Test command, you view the test results by displaying the *busClockTestResult* attribute of the *Shelf Test* component.

For more information on the run Shelf Test command, see

- [Properties for run Shelf Test \(page 196\)](#)
- [Syntax for run Shelf Test \(page 196\)](#)
- [Running a bus clock source test example \(page 197\)](#)
- [Related information for run Shelf Test \(page 197\)](#)

Properties for run Shelf Test

The following table describes the properties of the run Shelf Test command.

Properties of the run Shelf Test command

Mode	Impact	Scope	Components
Operational	Service	Device	Shelf Test

Syntax for run Shelf Test

The following table describes the syntax for the run Shelf Test command.

Syntax of the run Shelf Test command

If you want to...	Use the following syntax:
Perform a bus clock source test	run Shelf Test

Running a bus clock source test example

You currently have automatic bus clock source testing disabled. You want to manually test the bus clock source. Before running the test, you ensure that the test type is correctly set using the following command:

```
set Shelf Test type busClock
```

You then run the test using the following command:

```
run Shelf Test
```

After the test stops, you display the results of the test using the following command:

```
display Shelf Test busClockTestResult
```

If all operational processor cards can receive signals from the clock source, you receive the following response:

```
Shelf Test  
busClockTestResult = pass
```

Related information for run Shelf Test

See the following for information related to the run Shelf Test command:

- [Start <hardware> Test command \(page 212\)](#)
- [Stop <hardware> Test command \(page 223\)](#)

Save Prov command

Use the save Prov command to store all or part of either a current view or an edit view in a saved view.

Saved views can be either full or partial:

- A full view contains all the configuration data from an edit view or a current view. The full view is useful if you wish to save a particular view for use at a later date, or if you want to save a particular node configuration and apply it to other nodes.
- A partial view contains only the configuration data for a particular component from an edit view. Partial views are useful for saving component provisioning that you wish to use on other nodes. With the partial view, you only have to provision a component once, save it as a partial view, and then copy that partial view onto as many nodes as you wish.

The provisioning system can also store a saved view in one of several formats.

- The portable format includes all the configuration data necessary to run on a view node.
- The ASCII format allows non-Nortel Networks Multiservice Switch systems to read a saved view.
- The ASCII flat format enables you to save a Multiservice Switch provisioning file on the disk in a format that you can FTP back to a workstation for editing purposes.
- The commit format is a specialized version of the current view that allows for fast activation (see [Commit Prov command \(page 61\)](#)).
- The delta format is a view that includes only the changes made between the edit view and the current view. An edit view in delta format requires that the current view is in portable format.
- The partial format includes all the information about a component.

For more detailed information on full and partial saved views and saved view formats, see NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

The system automatically increments the version number every time you save a version of a view. If you save a view using a new name or type, the system sets the version number to 001.

For more information on the save Prov command, see

- [Properties for save Prov \(page 199\)](#)
- [Syntax for save Prov \(page 199\)](#)

- [Parameters for save Prov \(page 200\)](#)
- [Examples for save Prov \(page 201\)](#)
- [Related information for save Prov \(page 203\)](#)

Properties for save Prov

The following table describes the properties of the save Prov command.

Properties of the save Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for save Prov

The following table describes the syntax for the save Prov command.

Syntax of the save Prov command

If you want to...	Use the following syntax:
Save the provisioning data of the edit view, and have the system assign a default file name	save Prov Using the save Prov command without options causes the system to save the edit view in a delta format. If the current view is not in portable format, the system first saves the current view in portable format then saves the edit view in a delta format.
Save the provisioning data of the current view, and have the system assign a default file name	save -current Prov
Save the provisioning data of the edit view (default) or the current view (using the current option), to a specific file	save -file(<file_name>) Prov save -current -file(<file_name>) Prov
Save the provisioning data of the edit view (default) or the current view (using the current option) in ascii format	save -ascii Prov save -current -ascii Prov
Save the provisioning data of the edit view (default) or the current view (using the current option) in ascii flat format	save -asciiFlat Prov save -current -asciiFlat Prov
(1 of 2)	

Syntax of the save Prov command (continued)

If you want to...	Use the following syntax:
Save from the edit view (default) or the current view (using the current option), to a specific file, the provisioning data of a component	save -file(<file_name>) -component(<component_name>) Prov save -current -file(<file_name>) -component(<component_name>) Prov
Save a complete file to disk	save -file(<file_name>) -portable Prov
(2 of 2)	

Parameters for save Prov

If you don't use any options with the save Prov command, the system saves the edit view using the last loaded, saved, or committed view name, and increments the number by 1.

There are six types of parameters for the save Prov command:

- [Save the current view parameter for save Prov \(page 200\)](#)
- [Save a view with a specific filename parameter for save Prov \(page 200\)](#)
- [Save a view in ASCII format parameter for save Prov \(page 201\)](#)
- [Save the provisioning data for a component parameter for save Prov \(page 201\)](#)
- [Save a view in portable format parameter for save Prov \(page 201\)](#)

Save the current view parameter for save Prov

You can specify that the provisioning system save the provisioning data of the current view using the current option:

-current

If this option is not used, the edit view is saved.

Save a view with a specific filename parameter for save Prov

You can specify that the provisioning system save a view to a specific filename using the file option:

-file(<file_name>)

If the filename you specify already exists, the provisioning system will increment the version number automatically. If the filename you specify does not exist, the provisioning system will create it for you, and give it the version number 001.

The file option identifies the saved view using only the name portion of the three-part filename. For details on filename syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

The name must be between 1 and 31 characters and can only contain letters, numbers, and underscore characters.

Save a view in ASCII format parameter for save Prov

You can specify that the provisioning system save a view in ASCII format using the `ascii` option:

```
-ascii
```

You can use the ASCII format to export a view to a non-Nortel Networks Multiservice Switch application.

Save the provisioning data for a component parameter for save Prov

You can specify that the provisioning system save the provisioning data for a component in a partial saved view using the `component` option:

```
-component (<component_name>)
```

Use the `component` option to store a specific component and its subcomponent hierarchy in a partial saved view.

You must use the `file` option with this option.

Save a view in portable format parameter for save Prov

You can specify that the provisioning system save a view in portable format using the `portable` option:

```
-portable
```

Use this option to create a view that the system on another Nortel Networks Multiservice Switch node can reuse.

Examples for save Prov

The following examples show how to use the `save Prov` command:

- [Saving a view example \(page 201\)](#)
- [Saving a view with a specific filename example \(page 202\)](#)
- [Saving component provisioning data example \(page 202\)](#)
- [Saving a view in ASCII format example \(page 202\)](#)
- [Saving a view in portable format example \(page 203\)](#)

Saving a view example

You want to save the current view and have the system assign a default file name. You enter the following command:

```
save -current Prov
```

You receive the following response:

```
Prov
  The provisioning data is saved in file
  BE0019A.full.008.
```

Saving a view with a specific filename example

You want to save the provisioning data of either the edit view or current view to a specific filename. For this example, the assumption is that you want to save the current view to the file test1. You enter the following command:

```
save -current -file(test1) Prov
```

You receive the following response:

```
Prov
  Saving the current view into test1.full.001 (with
  portable formats) ...
  The provisioning data is saved in file
  test1.full.001.
```

Saving component provisioning data example

You want to store a component into a partial saved view. For this example, the assumption is that you want to save the *FrUni/1* component from the current view to the file FR_test. You enter the following command:

```
save -current -file(FR_test) -component(FrUni/1) Prov
```

You receive the following response:

```
Prov
  Saving the current view into FR_test.part.001 (with
  part formats) ...
  The provisioning data is saved in file
  AXL_test.part.001.
```

Saving a view in ASCII format example

You want to store the current view in ASCII format. For this example, the assumption is that you want to save the current view in ASCII format to the file current1_ascii. You enter the following command:

```
save -current -ascii -file(current_ascii) Prov
```

You receive the following response:

```
Prov
  Saving the current view into current_ascii.full.001
  (with ascii formats) ...
  The provisioning data is saved in file
  current1_ascii.full.001.
```

Saving a view in portable format example

You want to save a complete provisioning view to disk. For this example, the assumption is that you want to save the file BE0019A in a portable format. You enter the following command:

```
save -file(BE0019A) -portable Prov
```

You receive the following response:

```
Prov
Saving the edit view into BE0019A.full.009 (with
portable formats) ...
The provisioning data is saved in file
BE0019A.full.009.
```

Related information for save Prov

See the following for information related to the save Prov command:

- [Activate Prov command \(page 25\)](#)
- [Apply Prov command \(page 34\)](#)
- [Load Prov command \(page 121\)](#)
- [ReloadCp Lp command \(page 173\)](#)
- [Stop Prov command \(page 227\)](#)

Set command

The set (s) command allows you to change the value of an attribute.

You can only set provisionable attributes while you are in provisioning mode. All changes you make within provisioning mode affect the edit view. You cannot set the provisionable attributes of the current view.

You can set some operational attributes, such as test setup attributes. You can set these operational attributes in both operational and provisioning mode. The changes only affect the current view and are lost when the node restarts.

When setting an attribute's value, you need to know the data type of the attribute. A data type specifies the format of the value or values an attribute can assume. For detailed information on data types, see NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

Some attributes can have multiple values. You can add (turn on) and delete (turn off) values for a multiple-value attribute using the set command.

For more information on the set command, see

- [Properties for set \(page 204\)](#)
- [Syntax for set \(page 205\)](#)
- [Parameters for set \(page 205\)](#)
- [Examples for set \(page 209\)](#)
- [Related information for set \(page 210\)](#)

Properties for set

The set command works with all writable attributes (defined by their write access value). Some attributes require a higher impact than service. An attribute's component defines its required scope. To find specific write access, impact, and scope information for an attribute, see NN10600-060 *Nortel Networks Multiservice Switch 7400/15000/20000 Component Reference* or use the help command.

The following table describes the properties of the set command.

Properties of the set command

Mode	Impact	Scope	Attribute	View
Operational	Service	Depends on component	Operational	Current
Provisioning	Service	Depends on component	Provisionable and Operational	Edit and Current

Syntax for set

The following table describes the syntax for the set command.

Syntax of the set command

If you want to...	Use the following syntax:
Set the value of a single-value attribute	set <component> <attribute> <value>
Set values for a multiple-value attribute	set <component> <attribute> <value> [<value>]...
Set the value for more than one attribute of a component	set <component> <attribute> <value> [, <attribute> <values>]...
Delete the value of a single-value attribute	set <component> <attribute> set <component> <attribute> !
Delete (turn off) all values for a multiple-value attribute	set <component> <attribute> !
Delete (turn off) a value for a multiple-value attribute	set <component> <attribute> ~<value>

Parameters for set

The following are the parameters for the set command:

- [Component parameter for set \(page 206\)](#)
- [Data types for set \(page 206\)](#)
- [Attribute and value parameters for set \(page 207\)](#)
- [Delete value parameters for set \(page 208\)](#)

Component parameter for set

You specify which component's attributes you want to set using the component name:

`<component>`

Data types for set

An attribute has a data type. The data type defines the acceptable values for the attribute. There are two kinds of data types: single value and multiple value. Single-value data types accept only one value for the attribute. Multiple-value data types accept more than one value for the attribute.

Multiple-value data types are based on single-value data types. For example, the set of ... multiple-value data type can be based on the decimal, enumeration, or hexadecimal number single-value data types. An attribute with a set of decimal data type accepts a set of decimal values.

[Help information for an attribute \(page 102\)](#) and [Multiple-value data types \(page 207\)](#) describe the possible data types. For more information on data types, see NN10600-060 *Nortel Networks Multiservice Switch 7400/15000/20000 Component Reference*.

The data types of signed integer, decimal number, fixed point decimal, and hexadecimal number take either a range of numerical values or one or more named values.

For example, you are setting a decimal number attribute that defines the maximum number of records held in a queue. You can set the attribute to a numerical value in the range of 1 to 200. Alternatively, you can set the attribute to the named value *unlimited*, which allows an unlimited number of records in the queue.

Single-value data types

Data type	Description	Example
Singed integer	A positive or negative integer	-100, 0, 100
Integer sequence	A sequence of integers separated by periods	63.1023, 65535.255
Decimal number	A positive integer	0, 1, 100
Fixed point decimal	A number with a decimal point	1.2, 4.56
Hexadecimal number	A number in hexadecimal format	00, B6A1
Hexadecimal string	A hexadecimal number stored in a string	00, B6A1

(1 of 2)

Single-value data types (continued)

Data type	Description	Example
Dashed hexadecimal string	A hexadecimal number with dashes between each pair of digits stored in a string	3A, 3A-FC
IP address	An IP address	47.208.133.201
Enumeration	A set of values represented by a symbolic name	E1, DS1
String	An ASCII string	view.full.001, system
Extended string	A string with an escape mechanism for non-ASCII characters	R\le9sum\le9 (Résumé)
BCD	A binary-coded decimal	374984736253
Component name	A component name	Shelf Bus/x
Link	A component name that forms a bi-directional link	Shelf Card/1
Time	A date and time	1998-08-24 15:17:44
(2 of 2)		

Multiple-value data types

Data type	Description	Example
Set of ...	A collection of values from a fixed range	alarm, ~debug, ~log, scn
List of ...	An unrestricted collection of values	base_AA0042, networking_AA042, etc.
Vector of ...	An indexed collection of values	lowPriority 8100 highPriority 65
Array of ...	A double-indexed collection of values	packetSize 16 throughputClass 0 8

Attribute and value parameters for set

In general, you specify an attribute name followed by its value.

If the attribute accepts multiple values, you can specify more than one value after the attributes name. For some multiple-value data types (for example, List of...), setting a value adds it to the attribute. For other data types (for example, Set of...), setting a value turns it on. You can delete or turn off values using the exclamation mark (!) and tilde (~) characters. See [Delete value parameters for set \(page 208\)](#).

You can set multiple attributes of a component by specifying each attribute-value assignment separated by a comma (.). The system attempts all attribute assignments even if some of the assignments fail.

Attribute and value parameters of the set command

Parameter	Notes
<attribute> <value>	Use this parameter to set a single-value attribute.
<attribute> <value> [<value>]...	Use this parameter to set a multiple-value attribute. The system either adds the value to the attribute or turns the value on.
<attribute> <value> [, <attribute> <values>]...	Set multiple attributes of a component by specifying attribute-value assignments separated by commas (.).

Delete value parameters for set

Some attributes data types (for example, Set of ... and List of ...) accept multiple values. Multiple-value attributes support two special characters: exclamation mark (!), and tilde (~). The ! character deletes or turns off (depending on the data type of the attribute) all values for the attribute. The ~ character deletes or turns off (depending on the data type of the attribute) a particular value of a multi-value attribute. The ~ character must immediately precede the value you want to delete.

You can combine the delete characters with other value assignments in a single set command when setting multiple-value attributes.

You can also use the exclamation mark (!) to delete the value of single-value attribute. Alternatively, you can delete the value of a single-value attribute by not including a value in the set command. For example, you can delete the value of the *spareCard* attribute of Lp/1 using the following command:

```
set Lp/1 spareCard
```

Attribute and value parameters of the set command

Parameter	Notes
!	Deletes or turns off all values for a multiple-value attribute. Deletes the value of a single-value attribute.
~<value>	Deletes or turns off a particular value for a multiple-value attribute.

Examples for set

The following example shows how to use the set command:

- [Setting a single-value attribute example \(page 209\)](#)
- [Setting a multiple-value attribute example \(page 209\)](#)
- [Setting multiple attributes example \(page 209\)](#)
- [Deleting an attribute value example \(page 210\)](#)

Setting a single-value attribute example

You want to set the *cardType* attribute of the *Shelf Card/1* component to V35. You enter the following command:

```
set Shelf Card/1 cardType V35
```

You display the attribute using the following command:

```
display Shelf Card/1 cardType
```

You receive the following response:

```
Shelf Card/1
cardType = V35
```

Setting a multiple-value attribute example

You want to add a value to the multiple-value *featureList* attribute of the *Sw Lpt/TRUNK* component. You display its current values using the following command:

```
display Sw Lpt/TRUNK featureList
```

You receive the following response:

```
Sw Lpt/TRUNK
featureList = unackTrunks,porsTrunks
```

You want to add the value *atmTrunks*. You enter the following command:

```
set Sw Lpt/TRUNK featureList atmTrunks
```

You display the new values of the attribute using the following command:

```
display Sw Lpt/TRUNK featureList
```

You receive the following response:

```
Sw Lpt/TRUNK
featureList = unackTrunks,porsTrunks,atmTrunks
```

Setting multiple attributes example

You want to set the *mainCard* and *spareCard* attributes of the *Lp/1* component to *Shelf Card/1* and *Shelf Card/2*, respectively. You enter the following command:

```
set Lp/1 mainCard Shelf Card/1, spareCard Shelf Card/2
```

You display these attributes using the following command:

```
display Lp/1 mainCard, spareCard
```

You receive the following response:

```
Lp/1
  mainCard = Shelf Card/1
  spareCard = Shelf Card/2
```

Deleting an attribute value example

You want to replace all the values for the *avList* attribute (*Sw* component) with *base_AA01*. You enter the following command:

```
set Sw avList ! base_AA01
```

You display the value of the attribute using the following command:

```
display Sw avList
```

You receive the following response:

```
Sw
  avList = base_AA01
```

You now want to turn off the alarm (*ala*) and turn on the log value of the *dataStreams* attribute of the *Nmis Local Session/1* component. You enter the following command to display the current values of the attribute:

```
display Nmis Local Session/1 dataStreams
```

You receive the following response:

```
Nmis Local Session/1
  dataStreams = ala ~deb ~log ~scn ~rts
```

The values preceded by ~ are turned off. You enter the following command to turn off the alarm and turn on the log value:

```
set Nmis Local Session/1 dataStreams ~alarm log
```

You display the attribute again using the following command:

```
display Nmis Local Session/1 dataStreams
```

You receive the following response:

```
Nmis Local Session/1
  dataStreams = ~ala ~deb log ~scn ~rts
```

Because you have removed a spare card for *Lp/3*, you now want to delete the value of the single-value attribute *spareCard*. You enter the following command:

```
set Lp/3 spareCard !
```

Related information for set

See the following for information related to the set command:

- [Add command \(page 31\)](#)

- [Delete command \(page 77\)](#)
- [Display command \(page 80\)](#)
- [Help command \(page 100\)](#)

Start <hardware> Test command

Use the start <hardware> Test command to start a system test (using the *Test* component) on any of the following hardware components:

- a card
- a bus
- a fabric card
- a port/channel
- the Nortel Networks Multiservice Switch filesystem disk

Attention: You must lock a bus, a fabric card, a port/channel, or the Multiservice Switch filesystem disk before testing it (see [Lock command \(page 124\)](#)). You do not need to lock a card before testing it.

You can run a test when you add new hardware or commission new services, as part of a scheduled maintenance program, or to diagnose hardware-related problems.

Before you can run a hardware test, you must define the test by setting a number of attributes of the *Test* component. For details on cards, buses, and disks, see NN10600-550 *Nortel Networks Multiservice Switch 7400/15000/20000 Common Configuration Procedures*. For details on ports and channels, see NN10600-551 *Nortel Networks Multiservice Switch 7400/15000/20000 FP Configuration Reference*.

For more information on the start <hardware> Test command, see

- [Properties for start <hardware> Test \(page 212\)](#)
- [Syntax for start <hardware> Test \(page 213\)](#)
- [Testable hardware components parameter for start <hardware> Test \(page 213\)](#)
- [Starting a hardware test example \(page 214\)](#)
- [Related information for start <hardware> Test \(page 215\)](#)

Properties for start <hardware> Test

The following table describes the properties of the start <hardware> Test command.

Properties of the start <hardware> Test command

Mode	Impact	Scope	Components
Operational or Provisioning	Service	Device	Shelf Card Shelf Bus LogicalProcessor (Lp) AutomaticProtectionSwitching (Aps) LineAutomaticProtection Switching (Laps)
Operational or Provisioning	Configuration	Device	FileSystem (Fs) Disk

Syntax for start <hardware> Test

The following table describes the syntax for the start <hardware> test command.

Syntax of the start <hardware> Test command

If you want to...	Use the following syntax:
Start a test of the specified hardware component	start <hardware> Test Where the <hardware> is the Multiservice Switch component that controls the piece of hardware you wish to test. These components are shown in Testable hardware and components for the start <hardware> Test command (page 213) .

Testable hardware components parameter for start <hardware> Test

The <hardware> parameter identifies the hardware component that you wish to test. The following table describes the <hardware> option for the start <hardware> Test command.

Testable hardware and components for the start <hardware> Test command

Hardware type	Component
Card	Shelf Card/<n>
Bus	Shelf Bus/x or Shelf Bus/y
Fabric card	Shelf FabricCard/x or Shelf FabricCard/y
Ports and channels	Lp/<n> V35/<n>
	Lp/<n> X21/<n>
	Lp/<n> DS1/<n>
(1 of 2)	

Testable hardware and components for the start <hardware> Test command

Hardware type	Component
	Lp/<n> DS1/<n> Chan
	Lp/<n> DS3/<n>
	Lp/<n> DS3/<n> DS1/<n>
	Lp/<n> DS3/<n> DS1/<n> Chan
	Lp/<n> E1/<n>
	Lp/<n> E1/<n> Chan
	Lp/<n> E3/<n>
	Lp/<n> Enet/<n>
	Lp/<n> Sonet/<n>
	Lp/<n> Sdh/<n>
	Lp/<n> JT2/<n>
	Lp/<n> Hssi/0
	Lp/<n> IIsFwdr/<n>
	Lp/<n> Ima/<n>
	Lp/<n> Vsp
	Lp/0 oamEnet/0
	Aps/<n>
	Laps/<n>
Disk	Fs Disk
(2 of 2)	

Starting a hardware test example

You want to test the card in slot 4 (Card/4). You define the test by setting the attributes of the Setup group of the *Test* component. For this example, you want to test card 4 using card 1 as the target card. You review the test setting using the following command:

display Shelf Card/4 Test Setup

You receive the following response:

```
Shelf Card/4 Test
  targetCard           = 1
  frmTypes             = loading verification
  frmPriorities       = lowPriority ~highPriority
  frmSize              = lowPriority : 64 bytes
                     = highPriority : 56 bytes
  frmPatternType      = ccitt32kBitPattern
```

```
customizedPattern = 55555555 Hex
duration           = 1 minutes
```

You now want to start the test. You enter the following command:

```
start Shelf Card/4 Test
```

You receive the following response:

```
Shelf Card/4 Test
Test started.
```

After the duration of the test, you receive the following response:

```
Shelf Card/4 Test
Test stopped.
```

You now want to view the results of the test. You enter the following command:

```
display Shelf Card/4 Test Results
```

You receive the following response:

```
Shelf Card/4 Test
elapsedTime = 1 minutes
timeRemaining = 0 minutes
causeOfTermination = testTimeExpired
loadingFrmData      =                priority
                    results| low high
                    -----+ --- ----
                    framesSent| 612   0
                    framesLost|   0   0
verificationFrmData =                priority
                    results| low high
                    -----+ --- ----
                    framesTested| 203   0
                    framesBad|   0   0
```

Related information for start <hardware> Test

See the following for information related to the start <hardware> Test command:

- [Lock command \(page 124\)](#)
- [Stop <hardware> Test command \(page 223\)](#)

Start Prov command

Use the start Prov (st Prov) command to enter provisioning mode.

Only one operator can be in provisioning mode at any given time for a particular node. The system rejects a start Prov command if another operator attempts to enter provisioning mode. However, an operator with systemAdministration impact can force another operator out of provisioning mode by issuing the start Prov command with the force option.

For more information on the start Prov command, see

- [Properties for start Prov \(page 216\)](#)
- [Syntax for start Prov \(page 216\)](#)
- [Remove another operator from provisioning mode parameter for start Prov \(page 216\)](#)
- [Examples for start Prov \(page 217\)](#)
- [Related information for start Prov \(page 218\)](#)

Properties for start Prov

The following table describes the properties of the start Prov command.

Properties of the start Prov command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for start Prov

The following table describes the syntax for the start Prov command.

Syntax of the start Prov command

If you want to...	Use the following syntax:
Enter provisioning mode	start Prov
Force another operator out of provisioning mode	start -force Prov

Remove another operator from provisioning mode parameter for start Prov

You can specify that the provisioning system remove another operator from a provisioning session, using the force option.

A system administrator uses the force option to take over another operator's provisioning session. The contents of the edit view are preserved, and any outstanding commands issued by the previous operator run to completion (that is, in progress commands are not aborted).

The system generates an alarm to inform the other operator that he or she has been forced out.

Examples for start Prov

The following examples show how to use the start Prov command:

- [Starting a provisioning session example \(page 217\)](#)
- [Taking over another operator's provisioning session example \(page 217\)](#)

Starting a provisioning session example

You want to enter provisioning mode. You enter the following command:

```
start Prov
```

You receive one of the following responses:

```
Prov
  The edit view is identical to the current view.
```

OR

```
Prov
  The edit view differs from the current view.
  Changed xx provisioning attribute(s) in the edit
  view.
```

Attention: When entering provisioning mode, the system prompt changes from > to PROV>.

Taking over another operator's provisioning session example

You are the system administrator and you want to enter a provisioning session currently in use by another operator. You enter the following command:

```
start -force Prov
```

You receive one of the following responses:

```
Prov
  The edit view is identical to the current view.
```

OR

```
Prov
  The edit view differs from the current view.
  Changed xx provisioning attribute(s) in the edit
  view.
```

You and the other operator receive the following alarm to indicate that you have forced the provisioning operator out of the provisioning mode:

```
Prov;
MSG warning operator operationalCondition      70000012
ADMIN: unlocked          OPER: enabled        USAGE: busy
AVAIL:                   PROC: reporting     CNTRL:
ALARM:                   STBY: notSet        UNKNW: false
Id: 0F000022  Rel:
Com: The provisioning operator has been forced off
      by the System Administrator.
Int: 15/1/3/63507;casResolverVerbProvStart.cc;195;
      p4.0d.27
Prov
```

Related information for start Prov

See the following for information related to the start Prov command:

- [End Prov command \(page 91\)](#)

Start Sw Dld command

The start Sw Dld command lets you begin downloading software applications from the software distribution site (SDS) to your Nortel Networks Multiservice Switch node. It will also let you download patches to a software application.

The SDS is a UNIX workstation that stores the complete set of Multiservice Switch software. The command connects to the SDS using file transfer protocol (FTP) and downloads software applications you have specified onto the file system. Note that secure FTP communications should be used for downloading software. Please refer to the Multiservice Data Manager 241-6001-040 *Preside MDM Security User Guide* for details. To start a download you must know the IP address and have a user ID and a password for the SDS.

Before running the start Sw Dld command, you must set the *avListToDownload (dldList)* attribute of the *Sw Dld* component to the software application versions you want to download. You should also set the processor types for the application using the *processorTargets* attribute. You can specify i960, PowerPC (ppc), or both. Downloading files to support a processor type that you are not using on the node wastes disk space.

Attention: You cannot download files to support the PowerPC (ppc) processor type on nodes that have only a 256-Mbyte disk on their control processors.

With the patch auto-application, the scheduling of the patch download is controlled by the MDM. At the scheduled time, the MDM triggers the switch to download the latest version of the Patch Av. In order to view patches on-switch, the Patch Av must be downloaded from the Passport SDS site.

You cannot start the software download process if a remove Sw, tidy Sw, or check Prov command is currently running on the node, or if there is an attempt to remove a SUPP AV directory and a patched AV is in use. Once you have started downloading, you can stop the process using the stop Sw Dld command. You can monitor the progress of the download by displaying the attributes of the *Sw Dld* component.

For more information on the start Sw Dld command, see

- [Properties for start Sw Dld \(page 220\)](#)
- [Syntax for start Sw Dld \(page 220\)](#)
- [Starting an application version download example \(page 221\)](#)
- [Related information for start Sw Dld \(page 222\)](#)

Properties for start Sw DId

The following table describes the properties of the start Sw DId command.

Properties of the start Sw DId command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	Software Download (Sw DId)

Syntax for start Sw DId

The following table describes the syntax for the start Sw DId command.

Syntax of the start Sw DId command

If you want to...	Use the following syntax:
Start a software download	start -host(<IPaddress>) -userId(<userID>) -password (<password>) Sw DId

Parameters for start Sw DId

There are two types of parameters for the start Sw DId command:

- [SDS IP address parameter \(page 220\)](#)
- [Log on parameters \(page 220\)](#)

SDS IP address parameter

You must identify the software distribution site by its IP address using the host option:

-host (<IPaddress>)

You must enter the host option.

Log on parameters

To access the SDS site you must provide a valid user ID and password using the userID and password options. The user ID must be allowed FTP access to the site with read permission on all software files.

Options for the start Prov command

Option	Description
-user(<userID>) -u(<userID>)	Enter a user ID for the software distribution site.
-password <password> -p(<password>)	Enter the password for the user ID you entered in the userID option.

Examples for start Sw Dld

The following examples show how to use the start Sw Dld command:

- [Starting an application version download example \(page 221\)](#)
- [Starting a patch download example \(page 222\)](#)

Starting an application version download example

You want to download the application versions `frameRelay_AQ0123A` and `trunks_AQ0123A` to your node. You set the `avListToDownload` attribute using the following command:

```
set Sw Dld avListToDownload ! frameRelay_AQ0123A
trunks_AQ0123A
```

Your node only has i960 processors on its function processors, so you set the `processorTargets` attribute using the following command:

```
set Sw Dld processorTargets i960 ~ppc
```

For auto patch application, download the Patch Av:

```
start -host(10.236.0.21) -user(admin) -password(yu5u67)
Sw Dld
```

Your software distribution site has an IP address of 10.236.0.21. You can access the site using the user ID `admin` with a password of `yu5u67`. You enter the following command to begin the software download process:

```
start -host(10.236.0.21) -user(admin) -password(yu5u67)
Sw Dld
```

The system begins to download the application versions and patches to those application versions stored on the SDS. To monitor the progress of the download, you display the attributes of the `Sw Dld` component using the following command:

```
display Sw Dld
```

You receive the following response:

```
Sw Dld
avBeingDownloaded = trunks_AQ0123A
status            = inProgress
```

```
filesToTransfer      = 1
processorTargets     = i960
avListToDownload    = trunks_AQ0123A
downloadedAvList    = frameRelay_AQ0123A
```

Starting a patch download example

You want to download any new patches to the application version `base_AQ0123A` available on the SDS. You set the `avListToDownload` attribute using the following command:

```
set Sw Dld avListToDownload base_AQ0123A
```

Your node only has i960 processors on its function processors, so you set the `processorTargets` attribute using the following command:

```
set Sw Dld processorTargets i960 ~ppc
```

Your software distribution site has an IP address of 10.236.0.21. You can access the site using the user ID `admin` with a password of `yu5u67`. You enter the following command to begin the software download process:

```
start -host(10.236.0.21) -user(admin) -password(yu5u67)
Sw Dld
```

The system begins to download new patches to the `base_AQ0123A` application version. When the download is complete, you list all the patches now available for the `base_AQ0123A` application version using the following command:

```
list Sw Av/base_AQ0123A Patch/*
```

You receive the following response:

```
Sw Av/BASE_AQ0123A Patch/BASE001A
Sw Av/BASE_AQ0123A Patch/BASE002A
```

Related information for start Sw Dld

See the following for information related to the `start Sw` command:

- [Display command \(page 80\)](#)
- [Remove Sw Av command \(page 179\)](#)
- [Set command \(page 204\)](#)
- [Stop Sw Dld command \(page 229\)](#)
- [Tidy Sw command \(page 257\)](#)

Stop <hardware> Test command

Use the stop <hardware> Test command to stop a system test (see [Start <hardware> Test command \(page 212\)](#)) on any of the following hardware components:

- a card
- a bus
- a fabric card
- a port/channel
- the Nortel Networks Multiservice Switch filesystem disk

Attention: You must lock a bus, a fabric card, a port/channel, or the Multiservice Switch filesystem disk before testing it (see [Lock command \(page 124\)](#)). You do not need to lock a card before testing it.

Before you can run a hardware test, you must define the test by setting a number of attributes of the *Test* component. See [Start <hardware> Test command \(page 212\)](#).

For more information on the stop <hardware> Test command, see

- [Properties for stop <hardware> Test \(page 223\)](#)
- [Syntax for stop <hardware> Test \(page 224\)](#)
- [Testable hardware components parameter for stop <hardware> Test \(page 224\)](#)
- [Stopping a hardware test example \(page 225\)](#)
- [Related information for stop <hardware> Test \(page 225\)](#)

Properties for stop <hardware> Test

The following table describes the properties of the stop <hardware> Test command.

Properties of the stop <hardware> Test command

Mode	Impact	Scope	Components
Operational or Provisioning	Service	Device	Shelf Card Shelf Bus LogicalProcessor (Lp) AutomaticProtectionSwitching (Aps) LineAutomaticProtection Switching (Laps)
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for stop <hardware> Test

The following table describes the syntax for the stop <hardware> Test command.

Syntax of the stop <hardware> Test command

If you want to...	Use the following syntax:
Stop a test of the specified hardware component	stop <hardware> Test where <hardware> is the Multiservice Switch component that controls the piece of hardware on which you are currently running a test. These components are shown in Testable hardware and components for the stop <hardware> Test command (page 224) .

Testable hardware components parameter for stop <hardware> Test

The <hardware> parameter identifies the hardware component that the system is currently testing. The following table describes the <hardware> option for the stop <hardware> Test command.

Testable hardware and components for the stop <hardware> Test command

Hardware type	Component
Card	Shelf Card/<n>
Bus	Shelf Bus/x or Shelf Bus/y
Fabric Card	Shelf FabricCard/x or Shelf FabricCard/y
Ports and channels	Lp/<n> V35/<n> Lp/<n> X21/<n>
	(1 of 2)

Testable hardware and components for the stop <hardware> Test command

Hardware type	Component
	Lp/<n> DS1/<n>
	Lp/<n> DS1/<n> Chan
	Lp/<n> DS3/<n>
	Lp/<n> DS3/<n> DS1/<n>
	Lp/<n> DS3/<n> DS1/<n> Chan
	Lp/<n> E1/<n>
	Lp/<n> E1/<n> Chan
	Lp/<n> E3/<n>
	Lp/<n> Tr/<n>
	Lp/<n> Enet/<n>
	Lp/<n> Sonet/<n>
	Lp/<n> Sdh/<n>
	Lp/<n> JT2/<n>
	Lp/<n> Hssi/0
	Lp/<n> IIsFwdr/<n>
	Lp/<n> Ima/<n>
	Lp/<n> Vsp
	Aps/<n>
	Laps/<n>
Disk	Fs Disk
(2 of 2)	

Stopping a hardware test example

You want to stop a test that is in progress on Card/4. You enter the following command:

```
stop Shelf Card/4 Test
```

You receive the following response:

```
Shelf Card/4 Test  
Test stopped.
```

Related information for stop <hardware> Test

See the following for information related to the stop <hardware> Test command:

- [Lock command \(page 124\)](#)

- [Start <hardware> Test command \(page 212\)](#)

Stop Prov command

Use the stop Prov command to abort a provisioning command of the following types:

- activate Prov
- apply Prov
- check Prov
- load Prov
- save Prov

The stop Prov command is useful if you wish to abort a long-running provisioning command.

For more information on the stop Prov command, see

- [Properties for stop Prov \(page 227\)](#)
- [Syntax for stop Prov \(page 227\)](#)
- [Stopping a provisioning system command example \(page 227\)](#)
- [Related information for stop Prov \(page 228\)](#)

Properties for stop Prov

The following table describes the properties of the stop Prov command.

Properties of the stop Prov command

Mode	Impact	Scope	Components
Provisioning	Configuration	Application	ProvisioningSystem(Prov)

Syntax for stop Prov

The following table describes the syntax for the stop Prov command.

Syntax of the stop Prov command

If you want to...	Use the following syntax:
Abort a provisioning system command	stop Prov

Stopping a provisioning system command example

You want to stop a long-running provisioning system command. You enter the following command:

```
stop Prov
```

You receive the following response:

```
Prov  
ok
```

Attention: The system finishes the phase being executed by the in-progress command before it aborts the command. This means that the in-progress command can still take a few seconds to terminate after you issue stop Prov.

When the in-progress command terminates, you receive the following response:

```
command cancelled
```

Related information for stop Prov

See the following for information related to the stop Prov command:

- [Apply Prov command \(page 34\)](#)
- [Check Prov command \(page 42\)](#)
- [Load Prov command \(page 121\)](#)
- [Save Prov command \(page 198\)](#)

Stop Sw Dld command

The stop Sw Dld command lets you stop downloading software applications and patches from the software distribution site (SDS) to a Nortel Networks Multiservice Switch node.

The stop Sw Dld stops the running download without completing the application or patch it is currently downloading. You cannot use a partially downloaded application or patch. If you restart the download, the system continues downloading where it left off.

After stopping a software download, you cannot immediately start another download. You have to wait for the node to fully disconnect from the software distribution site.

You can monitor the progress of a download by displaying the attributes of the *Sw Dld* component. While the node is disconnecting from the SDS, the *status* attribute has a value of stopping.

For more information on the stop Sw Dld command, see

- [Properties for stop Sw Dld \(page 229\)](#)
- [Syntax for stop Sw Dld \(page 229\)](#)
- [Stopping a software download example \(page 230\)](#)
- [Related information for stop Sw Dld \(page 230\)](#)

Properties for stop Sw Dld

The following table describes the properties of the stop Sw Dld command.

Properties of the stop Sw Dld command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	Software Download (Sw Dld)

Syntax for stop Sw Dld

The following table describes the syntax for the stop Sw Dld command.

Syntax of the stop Sw Dld command

If you want to...	Use the following syntax:
Stop a software download	stop Sw Dld

Stopping a software download example

You have started downloading software applications and patches. To check the progress of the download, you display the attributes of the *Sw Dld* component using the following command:

```
display Sw Dld
```

You receive the following response:

```
Sw Dld
avBeingDownloaded = trunks_AQ0123A
status             = inProgress
filesToTransfer   = 1
processorTargets  = i960
avListToDownload  = trunks_AQ0123A
downloadedAvList  = frameRelay_AQ0123A
```

You decide to stop the download using the following command:

```
stop Sw Dld
```

You immediately check the status of the download using the following command:

```
display Sw Dld status
```

You receive the following response:

```
Sw Dld
status = stopping
```

Related information for stop Sw Dld

See the following for information related to the stop Sw command:

- [Display command \(page 80\)](#)
- [Remove Sw Av command \(page 179\)](#)
- [Start Sw Dld command \(page 219\)](#)
- [Tidy Sw command \(page 257\)](#)

Switch Aps command on Multiservice Switch 7400

The switch Aps command allows you to manually change between the working and protection line on an APS-protected link.

An APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. Unless manually overridden, the APS system automatically determines the active line.

APS can ignore the switch Aps command depending on the state (request) of the near and far end of the link and the mode (unidirectional or bidirectional). You can determine the state of the link by displaying the following attributes of the Aps component:

- nearEndRequest
- nearEndRequestChannel
- farEndRequest
- farEndRequestChannel

The manual change request created by the switch Aps command remains in effect until it is removed using the clear Aps command or it is overridden by a signal degradation, signal failure, or a lock to the protection line using the protectionLockout Aps command.

For more information on the switch Aps command, see

- [Properties for switch Aps \(page 231\)](#)
- [Syntax for switch Aps \(page 232\)](#)
- [Parameters for switch Aps \(page 232\)](#)
- [Examples for switch Aps \(page 233\)](#)
- [Related information for switch Aps \(page 235\)](#)

Properties for switch Aps

The following table describes the properties of the switch Aps command.

Properties of the switch Aps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	AutomaticProtectionSwitching (Aps)

Syntax for switch Aps

The following table describes the syntax for the switch Aps command.

Syntax of the switch Aps command

If you want to...	Use the following syntax:
Change from the working to the protection line	switch -workingToProtection Aps/<n>
Change from the protection to the working line	switch -protectionToWorking Aps/<n>
Force a change from working to protection line even if the protection line has a degraded or failed signal	switch -force -workingToProtection Aps/<n>
Force a change from protection to working line even if the working line has a degraded or failed signal	switch -force -protectionToWorking Aps/<n>

Parameters for switch Aps

The following are the parameters for the switch Aps command:

- [Component instance parameter for switch Aps \(page 232\)](#)
- [Working to protection parameter for switch Aps \(page 232\)](#)
- [Protection to working for switch Aps \(page 233\)](#)
- [Force parameter for switch Aps \(page 233\)](#)

Component instance parameter for switch Aps

An Aps component instance represents a link that is protected by APS. The Aps component manages both the working and protection lines. To change between the lines, you specify the instance number of the Aps component:

Aps / <n>

The instance value can be any integer between 0 and 15999.

Working to protection parameter for switch Aps

To change from the working line to the protection line, use the workingToProtection option:

-workingToProtection

APS ignores a switch Aps command using this option in the following situations:

- the protection line is locked at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)

- the protection line is experiencing signal degradation or failure at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)

You can force the change to occur when the protection line is experiencing signal degradation using the force option.

Protection to working for switch Aps

To change from the protection line to the working line, use the protectionToWorking option:

-protectionToWorking

APS ignores a switch Aps command using this option in the following situation:

- the working line is experiencing signal degradation or failure at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)

You can force the change to occur when the working line is experiencing signal degradation or signal failure using the force option.

Force parameter for switch Aps

You can force a change to the working or protection line using the force option:

-force

You can force a change to the working line when it is experiencing signal degradation or signal failure. You can only force a change to the protection line when it has signal degradation, not when it has signal failure. You cannot force a change to the protection line when it has been locked using the protectionLockout Aps command.

Examples for switch Aps

The following example shows how to use the switch Aps command:

- [Switching from working to protection line example \(page 233\)](#)
- [Switching from protection to working line example \(page 234\)](#)
- [Forcing a switch example \(page 235\)](#)

Switching from working to protection line example

You want to change the active line from the working to the protection line on an APS-protected link (represented by Aps/1). You check the state of the link using the following command:

```
display Aps/1 nearEndRequest, nearEndRequestChannel,  
farEndRequest, farEndRequestChannel
```

You receive the following response:

```
Aps/1
  nearEndRequest      = noRequest
  nearEndRequestChannel = working
  farEndRequest       = noRequest
  farEndRequestChannel = working
```

Since there are no outstanding requests on neither the near or far end of the link, you enter the following command:

```
switch -workingToProtection Aps/1
```

The protection line becomes the active line at both ends of the link. You again check the state of the link using the following command:

```
display Aps/1 nearEndRequest, nearEndRequestChannel,
farEndRequest, farEndRequestChannel
```

You receive the following response:

```
Aps/1
  nearEndRequest      = manualSwitch
  nearEndRequestChannel = protection
  farEndRequest       = reverseRequest
  farEndRequestChannel = protection
```

Switching from protection to working line example

You previously switched to the protection line on a link protected by APS (represented by Aps/1) in bidirectional mode. You now want to change back to the working line. You enter the following command:

```
switch -protectionToWorking Aps/1
```

The working line becomes the active line at both ends of the link. You check the state of the link using the following command:

```
display Aps/1 mode, nearEndRequest,
nearEndRequestChannel, farEndRequest,
farEndRequestChannel
```

You receive the following response:

```
Lp/1
  mode                = bidirectional
  nearEndRequest      = manualSwitch
  nearEndRequestChannel = working
  farEndRequest       = reverseRequest
  farEndRequestChannel = working
```

Forcing a switch example

An APS-protected link (represented by Aps/1) in bidirectional mode has automatically switched from the working to the protection line because it has detected signal degradation on the working line. However, you want to change back to the working line. Since the working line is experiencing signal degradation, you must force the change using the following command:

```
switch -force -workingToProtection Aps/4
```

The working line becomes the active line at both ends of the link. You check the state of the link using the following command:

```
display Aps/1 mode, nearEndRequest,  
nearEndRequestChannel, farEndRequest,  
farEndRequestChannel
```

You receive the following response:

```
Lp/1  
mode = bidirectional  
nearEndRequest = forcedSwitch  
nearEndRequestChannel = working  
farEndRequest = reverseRequest  
farEndRequestChannel = working
```

Related information for switch Aps

See the following for information related to the switch Aps command:

- [Clear Aps command on Multiservice Switch 7400 \(page 51\)](#)
- [ProtectionLockout Aps command on Multiservice Switch 7400 \(page 162\)](#)

Switch Laps command on Multiservice Switch 15000 and Multiservice Switch 20000

The switch Laps command allows you to manually change between the working and protection line on an line APS-protected link.

A line APS-protected link has two lines: working and protection. The working line normally carries the data. The protection line acts as a backup to the working line. The line that is currently carrying the data is called the active line. Unless manually overridden, the line APS system automatically determines the active line.

Line APS can ignore the switch Laps command depending on the state (request) of the near and far end of the link and the mode (unidirectional or bidirectional). You can determine the state of the link by displaying the following attributes of the Laps component:

- nearEndRequest
- nearEndRequestChannel
- farEndRequest
- farEndRequestChannel

The manual change request created by the switch Laps command remains in effect until it is removed using the clear Laps command or it is overridden by a signal degradation, signal failure, or a lock to the protection line using the protectionLockout Laps command.

For more information on the switch Laps command, see

- [Properties for switch Laps \(page 236\)](#)
- [Syntax for switch Laps \(page 237\)](#)
- [Parameters for switch Laps \(page 237\)](#)
- [Examples for switch Laps \(page 238\)](#)
- [Related information for switch Laps \(page 240\)](#)

Properties for switch Laps

The following table describes the properties of the switch Laps command.

Properties of the switch Laps command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	LineAutomaticProtectionSwitching (Laps)

Syntax for switch Laps

The following table describes the syntax for the switch Laps command.

Syntax of the switch Laps command

If you want to...	Use the following syntax:
Change from the working to the protection line	switch -workingToProtection Laps/<n>
Change from the protection to the working line	switch -protectionToWorking Laps/<n>
Force a change from working to protection line even if the protection line has a degraded or failed signal	switch -force -workingToProtection Laps/<n>
Force a change from protection to working line even if the working line has a degraded or failed signal	switch -force -protectionToWorking Laps/<n>

Parameters for switch Laps

The following are the parameters for the switch Laps command:

- [Component instance parameter for switch Laps \(page 237\)](#)
- [Working to protection parameter for switch Laps \(page 237\)](#)
- [Protection to working for switch Laps \(page 238\)](#)
- [Force parameter for switch Laps \(page 238\)](#)

Component instance parameter for switch Laps

An Laps component instance represents a link that is protected by Line APS. The Laps component manages both the working and protection lines. To change between the lines, you specify the instance number of the Laps component:

Laps/ <n>

The instance value can be any integer between 0 and 15999.

Working to protection parameter for switch Laps

To change from the working line to the protection line, use the workingToProtection option:

-workingToProtection

LAPS ignores a switch Laps command using this option in the following situations:

- the protection line is locked at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)
- the protection line is experiencing signal degradation or failure at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)

You can force the change to occur when the protection line is experiencing signal degradation using the force option.

Protection to working for switch Laps

To change from the protection line to the working line, use the protectionToWorking option:

-protectionToWorking

Line APS ignores a switch Laps command using this option in the following situation:

- the working line is experiencing signal degradation or failure at the near end of the link (unidirectional and bidirectional mode) or the far end of the link (bidirectional mode only)

You can force the change to occur when the working line is experiencing signal degradation or signal failure using the force option.

Force parameter for switch Laps

You can force a change to the working or protection line using the force option:

-force

You can force a change to the working line when it is experiencing signal degradation or signal failure. You can only force a change to the protection line when it has signal degradation, not when it has signal failure. You cannot force a change to the protection line when it has been locked using the protectionLockout Laps command.

Examples for switch Laps

The following example shows how to use the switch Laps command:

- [Switching from working to protection line example \(page 239\)](#)
- [Switching from protection to working line example \(page 239\)](#)
- [Forcing a switch example \(page 240\)](#)

Switching from working to protection line example

You want to change the active line from the working line to the protection line on a line APS-protected link (represented by Laps/1). You check the state of the link using the following command:

```
display Laps/1 nearEndRequest, nearEndRequestChannel,  
farEndRequest, farEndRequestChannel
```

You receive the following response:

```
Laps/1  
  nearEndRequest           = noRequest  
  nearEndRequestChannel    = working  
  farEndRequest            = noRequest  
  farEndRequestChannel     = working
```

Since there are no outstanding requests on neither the near or far end of the link, you enter the following command:

```
switch -workingToProtection Laps/1
```

The protection line becomes the active line at both ends of the link. You again check the state of the link using the following command:

```
display Laps/1 nearEndRequest, nearEndRequestChannel,  
farEndRequest, farEndRequestChannel
```

You receive the following response:

```
Laps/1  
  nearEndRequest           = manualSwitch  
  nearEndRequestChannel    = protection  
  farEndRequest            = reverseRequest  
  farEndRequestChannel     = protection
```

Switching from protection to working line example

You previously switched to the protection line on a link protected by line APS (represented by Laps/1) in bidirectional mode. You now want to change back to the working line. You enter the following command:

```
switch -protectionToWorking Laps/1
```

The working line becomes the active line at both ends of the link. You check the state of the link using the following command:

```
display Laps/1 mode, nearEndRequest,  
nearEndRequestChannel, farEndRequest,  
farEndRequestChannel
```

You receive the following response:

```
Lp/1  
  mode                     = bidirectional  
  nearEndRequest           = manualSwitch  
  nearEndRequestChannel    = working  
  farEndRequest            = reverseRequest  
  farEndRequestChannel     = working
```

Forcing a switch example

A line APS-protected link (represented by Laps/1) in bidirectional mode has automatically switched from the working to the protection line because it has detected signal degradation on the working line. However, you want to change back to the working line. Since the working line is experiencing signal degradation, you must for the change using the following command:

```
switch -force -workingToProtection Laps/4
```

The working line becomes the active line at both ends of the link. You check the state of the link using the following command:

```
display Laps/1 mode, nearEndRequest,  
nearEndRequestChannel, farEndRequest,  
farEndRequestChannel
```

You receive the following response:

```
Lp/1  
mode = bidirectional  
nearEndRequest = forcedSwitch  
nearEndRequestChannel = working  
farEndRequest = reverseRequest  
farEndRequestChannel = working
```

Related information for switch Laps

See the following for information related to the switch Laps command:

- [Clear Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 53\)](#)
- [ProtectionLockout Laps command on Multiservice Switch 15000 and Multiservice Switch 20000 \(page 165\)](#)

Switchover Lp command

The switchover Lp command allows you to manually change control between the active and standby processor cards of an LP.

You can schedule the switchover to occur at a future time. You can also cancel a scheduled switchover. You cannot schedule a switchover for the control processor (Lp/0).

If you have switched control from a main to the spare card to replace a defective main card, you should change back to the main card once you have replaced the defective hardware. Switching back is particularly important when you are using one-for-*n* sparing. In this configuration, a single spare card protects multiple main cards. When the spare card is providing service for one of the main cards, all other main cards are unprotected.

Switching from the active to the standby control processor can cause the system to restart the function processors of the node. If you have hot standby enabled, some function processors continue running (and providing service) during a control processor switchover. For more information on switching between active and standby control processors, see NN10600-500 *Nortel Networks Multiservice Switch 6400/7400/15000/20000 Alarms Reference*.

Attention: Do not perform a control processor switchover more than once every 10 minutes. The system considers a second CP switchover within 10 minutes to be an indication of a more serious fault and will perform a shelf reset. Before executing the *switchover Lp* command, the value of the *reversibleTimerCountdown* attribute, under the Shelf component, must be zero.

You cannot manually change control from the active to standby control processor if any of the following conditions are true:

- The disks on the two control processors are not synchronized.
- A software upgrade is in progress.
- The standby control processor is in the process of loading the committed view.

You can change control from the active to the standby control process, or when the current view is not the committed view, if you use the *-force* option.

For more information on the *switchover Lp* command, see

- [Properties for switchover Lp \(page 241\)](#)
- [Syntax for switchover Lp \(page 242\)](#)
- [Parameters for switchover Lp \(page 242\)](#)
- [Examples for switchover Lp \(page 243\)](#)
- [Related information for switchover Lp \(page 245\)](#)

Properties for switchover Lp

The following table describes the properties of the *switchover Lp* command.

Properties of the switchover Lp command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	LogicalProcessor (Lp)

Syntax for switchover Lp

The following table describes the syntax for the switchover Lp command.

Syntax of the switchover Lp command

If you want to...	Use the following syntax:
Immediately change from the active to standby processor card	switchover Lp/<n>
Force a function processor switchover when the standby is not ready, or force a control processor switchover if the current view is not the committed view	switchover -force Lp/<n>
Schedule a future switchover from the active to standby processor card	switchover -time(<date_time>) Lp/<n>
Cancel a scheduled switchover	switchover -cancel Lp/<n>

Parameters for switchover Lp

The following are the parameters for the switchover Lp command:

- [Logical processor parameter for switchover Lp \(page 242\)](#)
- [Force parameter for switchover Lp \(page 242\)](#)
- [Scheduled time parameter for switchover Lp \(page 243\)](#)
- [Cancel scheduled time parameter for switchover Lp \(page 243\)](#)

Logical processor parameter for switchover Lp

You specify which logical processor you want to switchover using the instance of the *LogicalProcessor (Lp)* component:

Lp/<n>

Enter the number of the logical processor you want to switchover.

Force parameter for switchover Lp

You can force a logical processor switchover using the -force option:

-force

The -force option works differently depending on whether it is used on a function processor or a control processor.

Normally, you cannot use the switchover Lp command to change from an active to a standby function processor if the standby is not ready to take over. A standby function processor is not ready to take over when it is in a degraded state. (For example, a function processor is degraded when there are software errors on the card, or the connections on the active card are not properly duplicated on the standby.) You can use the -force option to cause a change

to the standby even if the standby is not ready. If the degradation on the standby function processor is severe enough, failure can occur after the switchover.

Normally, you cannot use the switchover Lp command to change from an active to a standby control processor if the current provisioning view is not the committed view. However, you can use the -force option to force a change to the standby control processor under these conditions. After the switchover, the system reverts to the committed provisioning view. All FPs that are not running the committed provisioning view are restarted. Therefore, it is possible that service outages may occur after a forced switchover.

Scheduled time parameter for switchover Lp

You can schedule the switchover for a future time using the time option:

```
-time(<date_time>)
```

Enter the date and time for the scheduled switchover using the following format:

```
yyyy-mm-dd hh:mm
```

You can view the current time by displaying the *moduleTime* attribute of the *Time* component. You can view the scheduled time of a switchover by displaying the *scheduledSwitchover* attribute of an *Lp* component. If this attribute has a value of 0000-00-00 00:00, there is no scheduled switchover.

If you have scheduled a switchover and a switchover occurs (either manual or automatic) before the scheduled time, the system cancels the scheduled switchover.

You can force scheduled switchover to begin immediately by entering the switchover Lp command with no options. To change a scheduled switchover, you must cancel it and then set a new a new date and time.

You cannot schedule a switchover between the active and standby control processor (Lp/0).

Cancel scheduled time parameter for switchover Lp

You can cancel a scheduled switchover using the cancel option:

```
-cancel
```

Examples for switchover Lp

The following example shows how to use the switchover command:

- [Immediately switching between active and standby function processor example \(page 244\)](#)
- [Immediately switching between active and standby control processor example \(page 244\)](#)

- [Forcing a switchover between active and standby function processor example \(page 244\)](#)
- [Forcing a switchover between active and standby control processor example \(page 245\)](#)
- [Scheduling a switchover example \(page 245\)](#)
- [Canceling a scheduled switchover example \(page 245\)](#)

Immediately switching between active and standby function processor example

You want to change control from the active to the standby processor card for logical processor 1 (Lp/1). You enter the following command:

```
switchover Lp/1
```

The standby processor card becomes the active card. The active processor card restarts and becomes the standby processor card.

Immediately switching between active and standby control processor example

You want to change control from the active control processor to the standby control processor. Since the control processor is always Lp/0, you enter the following command:

```
switchover Lp/0
```

The standby control processor becomes active. The active control processor restarts and becomes the standby processor card.

If you have hot standby enabled, function processors that support hot standby continue running uninterrupted during the switchover. Multiservice Data Manager connections to the node are unavailable during the time it takes to complete the switchover.

If you have hot standby disabled, all function processors restart during a control processor switchover. Multiservice Data Manager connections are unavailable during the time it takes to complete the switchover.

Forcing a switchover between active and standby function processor example

You want to force a switchover from the active to the standby processor card for logical processor 1 (Lp/1), which is in a degraded state due to software errors. You enter the following command:

```
switchover -force Lp/1
```

The standby processor card becomes the active card. The active processor card restarts and becomes the standby processor card.

Forcing a switchover between active and standby control processor example

You want to force a switchover from the active control processor to the standby control processor when the current provisioning view is not the committed view. Since the control processor is always Lp/0, you enter the following command:

```
switchover -force Lp/0
```

The standby control processor becomes the active control processor. The active processor card restarts and becomes the standby processor card. The system retains the current view.

Scheduling a switchover example

You want to schedule a switchover for logical processor 1 (Lp/1). You enter the following command in operational mode:

```
switchover -time(1998-10-03 00:00) Lp/1
```

When the node time (*moduleTime* attribute of the *Time* component) reaches the scheduled time, the active and standby processor cards of the logical processor switchover.

Canceling a scheduled switchover example

You want to cancel a scheduled switchover for logical processor 1 (Lp/1). You enter the following command:

```
switchover -cancel Lp/1
```

Related information for switchover Lp

See the following for information related to the switchover Lp command:

- [ReloadCp Lp command \(page 173\)](#)
- [Reset <processor> command \(page 183\)](#)
- [Restart <processor> command \(page 190\)](#)
- [Synchronize Fs command \(page 246\)](#)

Synchronize Fs command

The synchronize Fs command lets you manually synchronize the standby disk to the active disk. At start-up time, The system automatically synchronizes the active and standby disks if they both have the same volume name.

While the disks are synchronizing, you cannot format or test either the active or standby disk. You also cannot switchover the active and standby control processors. If the capacity of the standby disk is smaller than the space used on the active disk, the command fails.

After synchronization is complete, the active and the standby disks are identical: they contain the same files and directories and have the same volume name. Once synchronized, the system automatically mirrors changes made on the active disk to the standby disk.

The *syncStatus* attribute of the *FileSystem* component indicates if the disks are synchronized, not synchronized, or in the process of synchronization. The *syncProgress* attribute (also of the *FileSystem* component) indicates the percentage of the standby disk synchronized to the active disk.

Depending on the amount of data stored on the active disk and the difference between the two disks, the synchronization process can take several hours. The system will not synchronize a full disk (a disk with no free space).

For more information on the synchronize Fs command, see

- [Properties for synchronize Fs \(page 246\)](#)
- [Syntax for synchronize Fs \(page 246\)](#)
- [Synchronizing disks example \(page 247\)](#)
- [Related information for synchronize Fs \(page 247\)](#)

Properties for synchronize Fs

The following table describes the properties of the synchronize Fs command.

Properties of the synchronize Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for synchronize Fs

The following table describes the syntax for the synchronize Fs command.

Syntax of the synchronize Fs command

If you want to...	Use the following syntax:
Synchronize the standby disk to the active disk	synchronize Fs

Synchronizing disks example

At start-up the disks did not automatically synchronize. You now want to manually synchronize the standby disk to the active disk. You enter the following command:

```
synchronize Fs
```

The synchronization process begins. You check its progress using the following command:

```
display Fs syncProgress
```

You receive the following response:

```
Fs
syncProgress = 72 %
```

Related information for synchronize Fs

See the following for information related to the synchronize Fs command:

- [Format Fs Disk command \(page 97\)](#)
- [Switchover Lp command \(page 240\)](#)

Telnet Vr command

The telnet Vr command lets you connect to another Nortel Networks Multiservice Switch node so you can manage that node remotely. The remote node must be accessible through a virtual router. The telnet Vr command also lets you connect to any accessible device that complies with the basic Telnet protocol specification (RFC 854).

You can only use the telnet Vr command if you are logged in to a node using the Telnet network management interface. You cannot use the telnet Vr command from the local terminal or the Multiservice Data Manager Command Console.

When you connect to another Multiservice Switch node, the connection is transparent. All command responses and alarms appear as if you had directly connected to the node. You can use the me command to determine the name of the node to which you are currently connected.

The telnet Vr command includes a telnet command mode where you can enter commands to display and set information about the Telnet connection.

You can end a Telnet connection to another Multiservice Switch node using the logout or quit commands or their abbreviations of logoff or exit. You can end a Telnet connection to a device supporting the basic Telnet protocol specification using the quit or exit command.

For more information on the telnet Vr command, see

- [Properties for telnet Vr \(page 248\)](#)
- [Syntax for telnet Vr \(page 249\)](#)
- [Parameters for telnet Vr \(page 249\)](#)
- [Telnet command mode \(page 249\)](#)
- [Examples for telnet Vr \(page 250\)](#)
- [Related information for telnet Vr \(page 251\)](#)

Properties for telnet Vr

Along with the normal impact and scope restrictions, your user ID must also have permission for outgoing Telnet access.

The following table describes the properties of the telnet Vr command.

Properties of the telnet Vr command

Mode	Impact	Scope	Components
Operational	Service	Application	VirtualRouter (Vr)

Syntax for telnet Vr

The following table describes the syntax for the telnet Vr command.

Syntax of the telnet Vr command

If you want to...	Use the following syntax:
Connect to a Multiservice Switch node through a virtual router	telnet -ipAddress(<address>) Vr/<n>

Parameters for telnet Vr

The following are the parameters for the telnet Vr command:

- [Virtual router parameter for telnet Vr \(page 249\)](#)
- [IP address parameter for telnet Vr \(page 249\)](#)

Virtual router parameter for telnet Vr

To establish a Telnet connection to a remote device, that device must be accessible through (within the address space of) a management or customer virtual router on your node. You specify the virtual router using the instance value of a *VirtualRouter (Vr)* component:

Vr/<n>

IP address parameter for telnet Vr

You specify the IP address of the remote device you want to connect to using the ipAddress option:

-ipAddress(<address>)

Enter the IP address using decimal dot notation. The IP address must be within the address space of the management or virtual router you specify using the Vr component.

Telnet command mode

The telnet Vr command supports a command mode where you can enter a number of commands to display information about your telnet connection.

You enter into command mode by pressing the escape character after having established a Telnet connection. By default, the escape character is Control-].

When you are in command mode, the command prompt changes to the node name followed by `:telnet>`. For example, if you are currently logged in to the node named NODEA and you press the escape character, the command prompt changes to the following:

```
NODEA:telnet>
```

You exit command mode by successfully entering a command, or by pressing the Enter key.

The following table describes the commands available in Telnet command mode.

Commands available in Telnet command mode

Command	Description
?	Displays help information, including a list of all commands.
close	Closes the Telnet connection and exits.
display	Displays operating parameters of the connection, including character mappings.
quit, exit, logout, logoff	Closes the Telnet connection and exits.
set	Sets operating parameters of the connection. You can see a list of parameters you can set by following the set command with a question mark (?): set ? You can set the escape character using the following syntax: set escape <char> where: <char> is the escape character.
status	Displays the status of the connection, including the IP address of the remote device and the current escape character.

Examples for telnet Vr

You are currently logged in to a Nortel Networks Multiservice Switch node using the Telnet network management interface. You want to connect to another Multiservice Switch node accessible through the management virtual router (Vr/1). The IP address of the node is 10.12.142.8. You enter the following command:

```
telnet -ipAddress(10.12.142.8) Vr/1
```

You receive the following response:

```
Trying 10.12.142.8...  
Connected to 10.12.142.8.  
Escape character is '^]'
```

```
Enter login:
```

You can now log in to the node.

Related information for telnet Vr

See the following for information related to the telnet Vr command:

- [Clear Nmis <interface> Session command \(page 55\)](#)
- [Logout command \(page 128\)](#)
- [Me command \(page 132\)](#)
- [Quit command \(page 168\)](#)

Tidy Prov command

Use the tidy Prov command to remove saved provisioning views from the system disk.

Do not use tidy Prov to remove old views immediately after performing a software upgrade. If problems arise as a result of the upgrade, you will need an old view so you can downgrade to the previous software version.

When the provisioning system encounters a file system error, it cancels the tidy Prov command and provides details on the nature of the error.

The provisioning system has built-in safeguards to prevent you from accidentally removing any of the following views:

- the committed view
- the most recent full view used by one of the activate Prov, commit Prov, load Prov, or save Prov commands
- the current view, if it exists as a saved view (that is, the saved view containing the data in the current view)
- saved views that are read-only
- non-provisioning files or directories that do not have the standard <name>.<type>.<number> format
- saved views in portable format that support dependent saved views in delta format (that is, any view that is a base for another view)

For more information on the tidy Prov command, see

- [Properties for tidy Prov \(page 253\)](#)
- [Syntax for tidy Prov \(page 253\)](#)
- [Parameters for tidy Prov \(page 253\)](#)
- [Examples for tidy Prov \(page 254\)](#)
- [Related information for tidy Prov \(page 256\)](#)

Properties for tidy Prov

The following table describes the properties of the tidy Prov command.

Properties of the tidy Prov command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Application	ProvisioningSystem (Prov)

Syntax for tidy Prov

You must use at least one option when issuing the tidy Prov command.

The following table describes the syntax for the tidy Prov command.

Syntax of the tidy Prov command

If you want to...	Use the following syntax:
Remove all views	tidy -all Prov
Remove all but the listed view(s)	tidy -keep(<file_name> <file_name>... <file_name>) Prov
Remove only the listed view(s)	tidy -remove(<file_name> <file_name>... <file_name>) Prov
Remove all views that match a filename, except for the listed view(s)	tidy -remove(<file_name> -keep(<file_name> <file_name>... <file_name>) Prov
Remove all views created during a specified period of time	tidy -fromDate(<date>) -toDate(<date>) Prov The format for <date> must be yyyy-mm-dd.

Parameters for tidy Prov

There are five types of parameters for the tidy Prov command:

- [Remove all saved views parameter for tidy Prov \(page 253\)](#)
- [Remove saved views by date parameter for tidy Prov \(page 254\)](#)
- [Remove all but certain saved views parameter for tidy Prov \(page 254\)](#)
- [Remove only certain saved views parameter for tidy Prov \(page 254\)](#)

Remove all saved views parameter for tidy Prov

You can specify that the provisioning system remove all saved views from the disk using the all option:

-a11

The all option removes all saved views (except those views that cannot be removed).

You cannot use the all option with the remove and date options.

Remove saved views by date parameter for tidy Prov

You can specify that the provisioning system remove all saved views that fall within a range of dates using the fromDate and toDate options:

```
-fromDate(<date>)  
-toDate(<date>)
```

The option value <date> must be in the form yyyy-mm-dd (for example, 1998-06-23).

Remove all but certain saved views parameter for tidy Prov

You can specify that the provisioning system remove all saved views but those you wish to keep using the keep option:

```
-keep(<file_name>)
```

The keep option removes all saved views except those specified in the keep list. The keep option takes precedence over all other tidy options.

If you specify the keep option alone, then the provisioning system removes all views except those specified in the keep list.

If you specify either the remove or the date options with the keep option, then the system removes only those views that are not on the keep list and that the remove or date options specify.

The <file_name> option value identifies the saved view using the three-part view filename. When you specify more than one view, separate each filename by a space. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for information on filename format.

Remove only certain saved views parameter for tidy Prov

You can specify that the provisioning system remove only the saved views that you specify, using the remove option:

```
-remove(<file_name>)
```

The <file_name> value identifies the saved view using the three-part view filename. Where you specify more than one view, separate each filename by a space. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for information on filename format.

Examples for tidy Prov

The following examples show how to use the tidy Prov command:

- [Removing all saved views example \(page 255\)](#)

- [Removing saved views from a specific period example \(page 255\)](#)
- [Removing all but the specified saved views example \(page 255\)](#)
- [Removing all provisioning views that match a specific filename example \(page 256\)](#)
- [Removing a single saved view example \(page 256\)](#)

Removing all saved views example

You want to remove all saved views. You enter the following command:

```
tidy -all Prov
```

You receive a response similar to the following:

```
Prov
  Non-provisioning file cloneprov will be kept.
  Committed file BE0019A.full.008 will be kept.
  Base file BE0019A.full.006 will be kept.
  34 file(s) deleted.
```

Removing saved views from a specific period example

You want to remove saved views with date stamps that fall within a defined period of time. You enter the following command:

```
tidy -fromDate(199x-06-01) -toDate(199x-06-31) Prov
```

You receive a response similar to the following:

```
Prov
  Last used file BE0019A.full.010 will be kept.
  Non-provisioning file cloneprov will be kept.
  5 file(s) deleted.
```

Removing all but the specified saved views example

You want to remove all saved views except for those views specified in the keep list. You enter the following command:

```
tidy -keep(TEST1.full.009 TEST1.full.004) Prov
```

You receive a response similar to the following:

```
Prov
  Current view file test3.full.001 will be kept.
  Last used file test3.full.010 will be kept.
  Committed file BE0019A.full.008 will be kept.
  Base file BE0019A.full.006 will be kept.
  7 file(s) deleted.
```

Removing all provisioning views that match a specific filename example

You want to remove all provisioning views that match a specific filename, except specified saved views (in this example, TEST2.full.012 and TEST2.full.020). You enter the following command:

```
tidy -remove(TEST2) -keep(TEST2.full.012  
TEST2.full.020) Prov
```

You receive a response similar to the following:

```
Prov  
Last used file test2.full.022 will be kept.  
Base file test2.full.001 will be kept.  
5 file(s) deleted.
```

In this example, the last view used (test2.full.022) is part of the set defined by the -remove option. Since it is the last file, you cannot delete it. Also, test2.full.001 is the base for another view, and so you cannot delete it.

Removing a single saved view example

You want to remove a single saved view. Use the remove option and specify the view using a complete filename. You enter the following command:

```
tidy -remove(AB05sn.full.049) Prov
```

You receive a response similar to the following:

```
Prov  
1 file(s) deleted
```

Related information for tidy Prov

See the following for information related to the tidy Prov command:

- [Save Prov command \(page 198\)](#)
- [Start Prov command \(page 216\)](#)

Tidy Sw command

The tidy Sw command lets you remove all unused software application versions and patches from the file system. Before removing any software, you can have the tidy Sw command list the applications that it will remove.

The tidy Sw command considers a software application version unused if it is not in the application version list (the *avList* attribute of the *Software* component) of any semantically checked view, including the current view, the edit view, and saved views. Whenever the tidy Sw command removes an application version, it also removes all patches associated with that application version. Since all PD all PD files for that particular AV are stored in the SSUP directory, unless they are specific to a patched AV, the tidy Sw Av command should not be used to remove an SSUP AV if a patched AV is in use. The patched AV must be removed before the SSUP AV can be removed.

The command fails if a start Sw DId, remove Sw Av, check Prov, or another tidy Sw command is in progress, or if there is an attempt to remove the SSUP AV directory while a patched AV is in use.

You can remove a particular unused software application using the remove Sw Av command. You can remove unused provisioning files using the tidy Prov command.

For more information on the tidy Sw command, see

- [Properties for tidy Sw \(page 258\)](#)
- [Properties for tidy Sw \(page 258\)](#)
- [Applications to remove query parameter \(page 258\)](#)
- [Deleting all unused software example \(page 258\)](#)
- [Related information for tidy Sw \(page 259\)](#)

Properties for tidy Sw

The following table describes the properties of the tidy Sw command:

Properties of the tidy Sw command

Mode	Impact	Scope	Components
Operational or Provisioning	Configuration	Device	Software (Sw)

Syntax for tidy Sw

The following table describes the syntax for the tidy Sw command:

Syntax of the tidy Sw command

If you want to...	Use the following syntax:
Determine which application versions the tidy Sw command will remove	tidy -query Sw
Remove all unused software application versions	tidy Sw

Applications to remove query parameter

You can list the unused software application versions on the node using the query option:

-query

The application versions listed using the query option are the ones the tidy Sw command will remove when you issue the command without any options. When you use the query option, the tidy Sw command does not remove any software.

You should always using the tidy Sw command with the query option before issuing it with no options. This practice allows you to verify the application versions the command will delete before it deletes them.

Deleting all unused software example

You want to remove all unused application versions and their associated patches. You list the unused application versions using the following command:

tidy -query Sw

You receive the following response:

```
Sw
  The following AV(s) would be removed if the Tidy
  command was issued without the query option:
  ip_AA008      vns_AA008
```

You want all the application versions on the list deleted, so you enter the following command:

```
tidy Sw
```

You receive the following response:

```
Sw
  The following AV(s) have been removed:
  ip_AA008      vns_AA008
```

Related information for tidy Sw

See the following for information related to the tidy Sw command:

- [Remove Sw Av command \(page 179\)](#)
- [Start Sw Dld command \(page 219\)](#)
- [Stop Sw Dld command \(page 229\)](#)

Touch Fs command

The touch Fs command lets you set the modification date and time of a file or directory. You can set the modification date and time to the current date and time or to a specific date and time.

If the specified file or directory does not exist, the command creates a new empty file (0 bytes).

For more information on the touch command, see

- [Properties for touch Fs \(page 260\)](#)
- [Syntax for touch Fs \(page 260\)](#)
- [Parameters for touch Fs \(page 260\)](#)
- [Examples for touch \(page 261\)](#)
- [Related information for touch Fs \(page 262\)](#)

Properties for touch Fs

The following table describes the properties of the touch command.

Properties of the touch Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for touch Fs

The following table describes the syntax for the touch Fs command.

Syntax of the touch Fs command

If you want to...	Use the following syntax:
Set the modification date and time of a file or directory to the current date and time	<code>touch -path(<path>) Fs</code>
Set the modification date and time of a file or directory to a specific date and time	<code>touch -path(<path>) -date(<datetime>) Fs</code>

Parameters for touch Fs

There are two parameters for the touch Fs command:

- [File or directory to update parameter for touch Fs \(page 261\)](#)

- [Date and time parameter for touch Fs \(page 261\)](#)

File or directory to update parameter for touch Fs

You specify which file or directory for which you want to set the modification date and time using the path option:

```
-path(<path>)
```

Enter the absolute or relative path for the file or directory for which you want to update the modification date and time. Enclose the path in double quotation marks. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

You must enter this option.

Date and time parameter for touch Fs

You can specify a modification date and time for the file or directory using the date option:

```
-date(<datetime>)
```

Enter the new modification date and time using the format yyyy-mm-dd hh:mm:ss.

If you do not enter a date option, the modification date and time is set to the current node date and time.

Examples for touch

The following examples illustrate how to use the touch command:

- [Setting to current date and time example \(page 261\)](#)
- [Setting to specific date and time example \(page 261\)](#)

Setting to current date and time example

You want to set the modification date and time of the info.txt file in your current working directory to the current date and time. You enter the following command:

```
touch -path("info.txt") Fs
```

You check the modification date and time using the listFile Fs command.

Setting to specific date and time example

You want to set the modification date and time of the info.txt file in your current working directory to exactly 9:00 PM on January 1, 2001. You enter the following command:

```
touch -path("info.txt") -date(2001-01-01 09:00:00) Fs
```

You check the modification date and time using the following listFile Fs command:

```
listFile -path("info.txt") Fs
```

You receive the following response:

```
Fs
Type Prot Size      Date      Time      Name
file no  0      2001-01-01 09:00:00 info.txt
```

Related information for touch Fs

See the following for information related to the workingDir Fs command:

- [ListFile Fs command \(page 117\)](#)
- File and directory syntax. Refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview* for details.

Trace command

The trace command is used to initiate a path or connection trace. The path trace traces new point-to-point connections in the process of being established. The connection trace collects information on existing point-to-point connections that have already been established.

You need to set up the parameters for the path trace test connection that are listed in the NN10600-715 *Nortel Networks Multiservice Switch 7400/15000/20000 ATM Fault and Performance Management* prior to performing the trace command.

For more information on the trace command, see

- [Path trace test connection \(page 263\)](#)
- [Path trace filters \(page 265\)](#)
- [Connection trace command \(page 269\)](#)

Path trace test connection

Path trace test connections can be initiated at the trace source node towards a called party number. A test connection will setup an SPVC from the trace source to the trace destination and will always be released once it reaches the trace destination.

For more information on path trace test connections, see

- [Properties for path trace test connection \(page 263\)](#)
- [Syntax for path trace test connection \(page 263\)](#)
- [Parameters for path trace test connection \(page 264\)](#)
- [Example for path trace test connection \(page 264\)](#)

Properties for path trace test connection

The following table displays the properties of the trace command for the path trace test connection.

Properties of the trace command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	PathTraceTest Connection

Syntax for path trace test connection

The following table describes the syntax for the path trace test connection.

Syntax of the path trace test connection

If you want to...	Use the following syntax:
trace a path	trace atmif/* uni/iisp/aini/pnni pathTraceTestConnection
set the path trace test connection destination address	set atmif/* uni/iisp/aini/pnni pathTraceTestConnection testCalledAddress <40 hex digits>
set the path trace test connection vpi.vci	set atmif/* uni/iisp/aini/pnni pathTraceTestConnection testCalledVpiVci <[0-4095],[0-65535]>
set other path trace test connection attributes	set atmif/* uni/iisp/aini/pnni pathTraceTestConnection <operational_attributes> <operational_attribute_value> where: <operational_attributes> can be traceCrankback, txTrafficDescType, txTrafficDescParm, rxTrafficDescType, rxTrafficDescParm, atmServiceCategory, fwdQosClass, fwdQosParameters, bwdQosClass, bwdQosParameters, bearerClassBbc, transferCapabilityBbc, clippingBbc, bestEffort
trace a path trace test connection	trace atmif/* uni/iisp/aini/pnni pathTraceTestConnection

Parameters for path trace test connection

For the path trace, there are no options that need to be specified.

Example for path trace test connection

The verb trace is used to initiate the path trace. For the path trace, there are no options that need to be specified. For a successful path trace test connection, the response will be displayed on the operator console:

```
trace atmif/20 uni PathTraceTestConnection

AtmIf/20 Uni Ptt
Released with :
causeCode = 31
diagCode = ""
Trace status = Completed normally
Src port Id = 1310721
Src port name = EM/PARIS Atmif/20

Node Id = 60A03912345678912345678912440100201B124C0060
Node name = PARIS
```

```
Port Id = 1376257
Port name = EM/PARIS Atmif/21
Node Id = 60A0391234567891234567891255010090CF42E80060
Node name = TOKYO
Port Id = 655361
Port name = EM/TOKYO Atmif/10
ok                2001-11-05 15:11:30.29
```

A failed path trace test connection will display the cause code as follows:

```
> trace atmif/20 uni PathTraceTestConnection
AtmIf/20 Uni Ptt
Connection failed or not enough resources.
Cause code= 3
command failed 2001-11-05 08:56:16.88
```

Only one path test connection query is supported per signaling interface at a time. If the trace verb is issued before the previous trace command has responded, the following response will be returned to the later trace command:

```
Trace Command is in progress.
```

If the trace verb is issued and no reply is returned before the timer expires as predefined in the signaling specification, the following response is displayed:

```
The Trace Command has timed out.
```

If the path trace test connection cannot be routed to the called party, the following response is displayed:

```
No route found.
```

Path trace filters

Path trace filters on certain interfaces are configured at the trace source node and are used to define the criteria for which a connection will be traced. The filter criteria includes: called party number, calling party number, and connection type. When a filter is provisioned on a certain interface, all connections going through that interface, which satisfy all defined filtering criteria, will be traced. This is used for connections that will remain up.

For more information on path trace test connections, see

- [Properties for path trace filter \(page 265\)](#)
- [Syntax for path trace filter \(page 266\)](#)
- [Example for path trace filter \(page 267\)](#)
- [Records for path trace filter \(page 268\)](#)

Properties for path trace filter

The following table displays the properties of the trace command for the path trace filter:

Properties of the trace command for path trace filter

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	PathTraceFilter
Provisioning	must be added to set the maxTrace-Records	Device	Ov
Provisioning	Must be set to a number between 1 and 200 to ensure the path trace will work properly	Device	maxTraceRecords

Syntax for path trace filter

The following table describes the syntax for the path trace filter:

Syntax of the trace command for path trace filter

If you want to...	Use the following syntax:
Set the maximum trace records used by the filter	add Lp/n Eng atmpathTrace Ov set Lp/n Eng atmpathTrace Ov MaxTraceRecords >1 to 200
Add a path trace filter	add atmif/* uni/iisp/aini/pnni ptf
Set the parameters for the path trace filter	set atmif/* uni/iisp/aini/pnni ptf connectionType <svc spvc svp spvp> set atmif/20 uni/iisp/aini/pnni ptf connectionConfiguration <ptp ptmp> set atmif/20 uni/iisp/aini/pnni ptf serviceCategory <cbv rtVbr nrtVbr ubr> set atmif/20 uni/iisp/aini/pnni ptf traceTimeout <1-70560> set atmif/20 uni/iisp/aini/pnni ptf maxTraceRecords <1-200>
Start the path trace filter	start atmif/* uni/iisp/aini/pnni ptf
Stop the path trace filter	stop atmif/* uni/iisp/aini/pnni ptf
(1 of 2)	

Syntax of the trace command for path trace filter (continued)

If you want to...	Use the following syntax:
Clear the path trace filter	clear atmif/* uni/iisp/aini/pnni ptf
Display the records for successful calls being established	display atmif/* vcc/* PathTraceRecord
Display the record for the successful call at each hop	display atmif/* vcc/* PathTraceRecord hop/*
Display the records for unsuccessful calls being established	display atmif/* uni/iisp/aini/pnni ptf PathTraceRecord
Display the record for the unsuccessful call at each hop	display atmif/* uni/iisp/aini/pnni ptf PathTraceRecord hop/*
(2 of 2)	

Example for path trace filter

Before a filter can be started, the user must first add the *Lp/n Eng atmPathTrace Ov* component and then set the *MaxTraceRecords* to a value other than zero (the maximum value of 10 is selected in this example) as follows:

```
> add lp/2 eng atmPathTrace Ov

Lp/2 Eng PTrace Ov
The following components have been created:
Lp/2 Eng PTrace
Lp/2 Eng PTrace Ov
ok                2001-11-04 17:18:49.47

> set Lp/2 Eng PTrace Ov maxTraceRecords 10
Lp/2 Eng PTrace Ov
ok                2001-11-04 17:19:33.69
```

In order to use the path trace filter command, the user must first add it under the uni/iisp/aini/pnni interface. The filter and its attributes can then be modified using operational commands.

```
> add atmif/20 uni ptf
AtmIf/20 Uni Ptf
The following components have been created:
AtmIf/20 Uni Ptf
ok                2001-11-04 17:22:02.50
```

Several verbs are provided for this component allowing the user to START, STOP and CLEAR the records of a filter. The verb START starts the *traceTimeout* timer associated with the filter. If the verb START is run successfully, a response with the amount of records available is provided to the user as follows:

```
> start atmif/20 uni ptf

AtmIf/20 Uni Ptf
There are 10 records available for storage.
ok                2001-11-04 17:22:26.36
```

The verb STOP stops the *traceTimeout* timer associated with the filter. The records associated with the filter are not removed.

```
> stop atmif/20 uni ptf
AtmIf/20 Uni Ptf
ok                2001-11-04 17:24:07.21
```

The verb CLEAR removes all records associated with a stopped filter.

```
> clear atmif/20 uni ptf
AtmIf/20 Uni Ptf
ok                2001-11-04 17:24:14.77
```

The user is not allowed to change the criteria of a running filter. In order to make changes, the filter must first be stopped. The following command is used to display the path trace filter components that can be set:

```
> d -o atmif/20 uni ptf

AtmIf/20 Uni Ptf
traceInfo = crankBack connId callRef
calledPartyPrefix = ""
callingPartyPrefix = ""
connectionType = svc spvc svp spvp
connectionConfiguration = ptp ptmp
serviceCategory = cbr rtVbr nrtVbr ubr
traceTimeout = 60 minutes
maxTraceRecords = 2
state = active
recordCount = 0
matchedConnections = 0
elapsedTime = 0 minutes
timeRemaining = 60 minutes
ok                2001-11-04 17:23:20.75
```

Records for path trace filter

The trace information for a successful connection is stored under the *atmif/m vpc/*, *atmif/n vcc/x.y* or *atmif/m vpt/x vcc/y* component. The last unsuccessful trace connection is stored under the *atmif/n UNI/IISP/AINI/PNNI PTraceFilter* component.

The number of records that can be stored on a per card basis can be overridden, from its default value by changing the provisionable attribute *maxRecords* under the *lp/m eng atmpathTrace Ov* component. When the maximum number of records has been reached, each filter will overwrite its oldest record if it needs to store a newer record.

In the case where multiple filters are provisioned on the same Lp, each filter has a *maxRecords* attribute associated with the filter. This will allow the operator to manage the number of records allocated to each filter. But if the sum of the filter *maxRecords* attribute is greater than the *maxRecords* attribute of the *Lp Eng atmpathTrace* component, then each filter may not get the requested number of records.

The maximum number of concurrent requests that can be handled can be overridden from its default value by changing the provisionable attribute *maxConcurrentRequests* under the *lp/m eng atmpathTrace ov* component.

Connection trace command

The connection trace collects information on existing point-to-point connections that have already been established. For more information on the connection trace command, see the following sections:

- [Properties for connection trace \(page 269\)](#)
- [Syntax for connection trace \(page 269\)](#)
- [Parameters for connection trace \(page 270\)](#)
- [Examples for connection trace \(page 271\)](#)

Properties for connection trace

The following table [Properties of the trace command \(page 263\)](#) describes the properties of the trace command:

Properties of the trace command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	atmif/m vcc/x.y
			atmif/m vpc/x
			atmif/m vpt/x vcc/y

Syntax for connection trace

The following table [Syntax of the connection trace command \(page 270\)](#) describes the syntax for the connection trace command:

Syntax of the connection trace command

If you want to...	Use the following syntax:
trace a connection	trace [-s -v -a]

Parameters for connection trace

For the connection trace, there are several options outlined in the following list:

- [Indicates usage of the new trace command \(page 270\)](#)
- [Indicates inclusion of vpi and vci values \(page 270\)](#)
- [Indicates inclusion of call reference values \(page 270\)](#)

Indicates usage of the new trace command

You can specify that the new trace procedure be used instead of the Nortel Networks Multiservice Switch proprietary OAM based trace procedure by using the -s option:

-s

Attention: The -s option must be present for connection trace, otherwise, the trace defaults to the OAM-based trace.

Indicates inclusion of vpi and vci values

You can specify whether the trace includes VPI and VCI values using the -v option:

-v

Attention: The -s option must be present if either one of the -v and/or -a options are present. Otherwise, the trace defaults to the OAM-based trace.

Indicates inclusion of call reference values

You can specify whether the trace includes call reference values using the -a option:

-a

Attention: The -s option must be present if either one of the -v and/or -a options are present. Otherwise, the trace defaults to the OAM-based trace.

Examples for connection trace

For a successful connection test, you receive the following response:

```
trace -s -v -a atmif/20 vcc/0.100

AtmIf/20 Vcc/0.100
Switch side trace result:
Trace status = Completed normally
Src port Id = 1310721
Src port name = EM/LUCIELUCIE Atmif/20

Vpi.Vci = 0.100
Call reference = 7FFFFFFF
Node Id = 60A03912345678912345678912440100201B124C0060
Node name = LUCIELUCIE
Port Id = 1441793
Port name = EM/LUCIELUCIE Atmif/22
Vpi.Vci = 0.560
Call reference = 01
Node Id = 60A0391234567891234567891255010090CF42E80060
Node name = QUIGONQUIGON
Port Id = 655361
Port name = EM/QUIGONQUIGON Atmif/10
Destination vpi.vci= 0.100
Destination call reference = 7FFFFFFF
ok                2001-11-04 18:20:27.68
```

Only one connection trace query is supported per signaling component at a time. If the trace verb is issued before the previous trace command has responded, the following response will be returned to the later trace command:

```
Trace Command is in progress.
```

If the trace verb is issued and no reply is returned before the timer has expired, the following response is displayed:

```
The Trace Command has timed out.
```

If the trace verb is issued to a *vpc/x*, *vcc/x.y*, or a *vpt/x vcc/y* component that is not active or was not created by signaling, the following response is displayed:

```
Connection is not active, or trace is not applicable.
```

Related information for path filter trace

See the following for information related to the path filter trace command:

- [Start Prov command \(page 216\)](#)
- [Stop Prov command \(page 227\)](#)
- [Clear Prov command \(page 58\)](#)

Unlock command

The unlock command lets you unlock a component you have previously locked using the lock command. By locking a component, you prevent it from providing service. By unlocking a locked component, you allow the component to provide service again.

Before you unlock a component, you should verify its OSI administrative state by displaying the *adminState* attribute of the component.

For more information on the unlock command, see

- [Properties for unlock \(page 272\)](#)
- [Syntax for unlock \(page 272\)](#)
- [Unlocking a locked component example \(page 272\)](#)
- [Related information for unlock \(page 273\)](#)

Properties for unlock

The following table describes the properties of the unlock command.

Properties of the unlock command

Mode	Impact	Scope	Components
Provisioning	Service	Device	Many

Syntax for unlock

The following table describes the syntax for the unlock command.

Syntax of the unlock command

If you want to...	Use the following syntax:
Unlock a component	unlock <component_name>

Unlocking a locked component example

You want to unlock the *Lp/1* component. Before unlocking the component, you check its OSI administrative state using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1
adminState = locked
```

Since Lp/1 is locked, you unlock it using the following command:

```
unlock Lp/1
```

The system issues an alarm that indicates Lp/1 is now unlocked. You verify the administrative state of Lp/1 using the following command:

```
display Lp/1 adminState
```

You receive the following response:

```
Lp/1  
adminState = unlocked
```

Related information for unlock

See the following for information related to the unlock command:

- [Lock command \(page 124\)](#)

Unprotect Fs command

The unprotect Fs command removes the deletion and modification protection from a file.

When a file is protected, you cannot delete it using the remove Fs command. To delete a protected file, you must first remove its protection using the unprotect Fs command. You can tell if a file is protected or not using the listFile Fs command.

You cannot protect or unprotect a directory.

For more information on the unprotect Fs command, see

- [Properties for unprotect Fs \(page 274\)](#)
- [Syntax for unprotect Fs \(page 274\)](#)
- [File to unprotect parameter for unprotect Fs \(page 274\)](#)
- [Unprotecting a file example \(page 275\)](#)
- [Related information for unprotect Fs \(page 275\)](#)

Properties for unprotect Fs

The following table describes the properties of the unprotect Fs command:

Properties of the unprotect Fs command

Mode	Impact	Scope	Component
Operational or Provisioning	Configuration	Device	FileSystem (Fs)

Syntax for unprotect Fs

The following table describes the syntax for the unprotect Fs command.

Syntax of the unprotect Fs command

If you want to...	Use the following syntax:
Remove deletion protection a file	unprotect -path(filepath) Fs

File to unprotect parameter for unprotect Fs

You specify the file for which you want to remove deletion and modification protection using the path option:

-path(<filepath>)

Enter the absolute or relative path for the file for which you want to remove deletion and modification protection. Enclose the path in double quotation marks. For information on path syntax, refer to NN10600-030 *Nortel Networks Multiservice Switch 7400/15000/20000 Overview*.

You must enter the path option.

Unprotecting a file example

There is a protected file in the /tmp directory called alarm.001 that you want to delete. Before deleting it, you must remove its deletion and modification protection. Your current working directory is root (/). You enter the following command:

```
unprotect -path("/tmp/alarm.001") Fs
```

You use the following listFile Fs commands to verify that the file was unprotected:

```
listFile -path("/tmp/alarm.001") Fs
```

You receive the following response:

```
Fs
  Type Prot Size      Date      Time      Name
  file no 9547    1998-05-05 10:12:38 alarm.001
```

The *no* in the Prot column indicates that the file is unprotected.

Related information for unprotect Fs

See the following for information related to the unprotect Fs command:

- [ListFile Fs command \(page 117\)](#)
- [Protect Fs command \(page 160\)](#)
- [Remove Fs command \(page 176\)](#)

WorkingDir Fs command

The workingDir Fs (pwd Fs) command displays your current working directory.

For more information on the workingDir Fs command, see

- [Properties for workingDir Fs \(page 276\)](#)
- [Syntax for workingDir Fs \(page 276\)](#)
- [Displaying the current working directory example \(page 276\)](#)
- [Related information for workingDir Fs \(page 276\)](#)

Properties for workingDir Fs

The following table describes the properties of the workingDir command.

Properties of the workingDir command

Mode	Impact	Scope	Component
Operational or Provisioning	Passive	Device	FileSystem (Fs)

Syntax for workingDir Fs

The following table describes the syntax for the workingDir Fs command.

Syntax of the workingDir Fs command

If you want to...	Use the following syntax:
Display your current working directory	workingDir Fs

Displaying the current working directory example

Your current working directory is /spooled/closed. You enter the following command:

```
workingDir Fs
```

You receive the following response:

```
Fs  
/spooled/closed
```

Related information for workingDir Fs

See the following for information related to the workingDir Fs command:

- [Chdir Fs command \(page 40\)](#)
- [ListFile Fs command \(page 117\)](#)

Zero Nsta/n Vgs Digit Collection/n command

The Zero Nsta/n Vgs Digit Collection/n command reinitializes statistical operational attributes.

Attention: Zero does not reset all operational statistical attributes. Only attributes which indicate 'extreme' values may be reset in this way.

For more information on the Zero Nsta/n Vgs Digit Collection/n command, see

- [Properties for Zero Nsta/n Vgs Digit Collection/n \(page 277\)](#)
- [Syntax for Zero Nsta/n Vgs Digit Collection/n \(page 277\)](#)

Properties for Zero Nsta/n Vgs Digit Collection/n

The following table describes the properties of the Zero Nsta/n Vgs Digit Collection/n command.

Properties of the Zero Nsta/n Vgs Digit Collection/n command

Mode	Impact	Scope	Component
Operational or Provisioning	Service	Device	NstaVgsDigitCollection

Syntax for Zero Nsta/n Vgs Digit Collection/n

The following table describes the syntax for the Zero Nsta/n Vgs Digit Collection/n command.

Syntax of the Zero Nsta/n Vgs Digit Collection/n command

If you want to...	Use the following syntax:
Reset extreme operational statistical attributes for the <i>DigitCollection</i> component using the Zero verb via CAS:	zero nsta/1 vgs DigitCollection

Nortel Networks Multiservice Switch 7400/15000/20000

Commands Reference

Copyright © 2005 Nortel Networks.
All Rights Reserved.

Publication: NN10600-050
Document status: Standard
Document issue: sPCR6.1S1
Document date: February 2005
Product release: sPCR6.1
Job function: Basics
Type: NTP
Language type: U.S. English

NORTEL, NORTEL NETWORKS, the globemark design, and the NORTEL NETWORKS corporate logo are trademarks of Nortel Networks.

