



ISDN Primary Rate Interface Installation and Commissioning Avaya Communication Server 1000

7.5
NN43001-301, 05.08
February 2012

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Preventing Toll Fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud Intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support Web site: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

Contents

| | |
|--|----|
| Chapter 1: New in this release | 11 |
| Other changes..... | 11 |
| Revision History..... | 11 |
| Chapter 2: Customer service | 13 |
| Navigation..... | 13 |
| Getting technical documentation..... | 13 |
| Getting product training..... | 13 |
| Getting help from a distributor or reseller..... | 13 |
| Getting technical support from the Avaya Web site..... | 14 |
| Chapter 3: Introduction | 15 |
| Legacy products and releases..... | 15 |
| Applicable systems..... | 15 |
| System migration..... | 15 |
| Intended audience..... | 16 |
| Related information..... | 16 |
| Technical Documents..... | 16 |
| Online..... | 16 |
| Chapter 4: ISDN Primary Rate Interface equipment overview | 17 |
| Contents..... | 17 |
| Introduction..... | 19 |
| Primary Rate Interface (PRI) hardware requirements..... | 19 |
| ISDN Signaling Link (ISL) hardware..... | 21 |
| 64 Kbit/s Clear Data Hardware..... | 22 |
| D-Channel Handler description..... | 23 |
| NT6D11 DCH..... | 23 |
| Power requirements..... | 23 |
| DCH/PRI interface..... | 23 |
| DCH faceplate..... | 23 |
| QPC757 DCH..... | 24 |
| Power requirements..... | 24 |
| DCH/PRI interface..... | 25 |
| QPC757 faceplate..... | 25 |
| NT6D80 MSDL..... | 26 |
| Power requirements..... | 26 |
| MSDL/PRI interface..... | 27 |
| MSDL faceplate..... | 27 |
| NTBK51 Downloadable D-Channel Daughterboard..... | 28 |
| Standard PRI cards..... | 28 |
| NT8D72 PRI2..... | 29 |
| Power requirements..... | 29 |
| NT8D72 faceplate..... | 29 |
| Cable requirements..... | 31 |
| Carrier interface..... | 32 |
| Echo canceller interface..... | 32 |

| | |
|---|-----------|
| QMT21 High Speed Data Module..... | 32 |
| QPC720 PRI for 1.5/2.0 Mb gateway..... | 32 |
| Clock operation for the NT8D72..... | 32 |
| QPC720 PRI..... | 35 |
| Power requirements..... | 35 |
| QPC720 faceplate..... | 35 |
| QPC720 Cable requirements..... | 37 |
| Carrier interface..... | 37 |
| Echo Canceller interface..... | 37 |
| 64 T-link version 2 protocol..... | 38 |
| Disk drive hardware..... | 39 |
| NT5D97 Dual-port DTI2/PRI2 card..... | 39 |
| External D-Channel Interface DCH or MSDL..... | 39 |
| NT5D97 faceplate..... | 40 |
| System capacity and performance..... | 45 |
| Testability and diagnostics..... | 46 |
| Cable requirements..... | 46 |
| Cable diagrams..... | 52 |
| Clock for the NT5D97..... | 54 |
| NT5D12 Dual-port DTI/PRI..... | 62 |
| D-Channel and MSDL interface..... | 63 |
| NT5D12 faceplate..... | 63 |
| System capacity and performance..... | 68 |
| Power requirements..... | 69 |
| Testability and diagnostics..... | 70 |
| NT5D12 Cable requirements..... | 70 |
| Trunk Tip/Ring cables..... | 71 |
| Reference clock cables..... | 77 |
| MSDL/DCHI cables..... | 78 |
| Cable diagrams..... | 79 |
| Clock..... | 80 |
| Reference clock errors..... | 81 |
| Automatic clock recovery..... | 82 |
| Automatic clock switching..... | 82 |
| Clock configurations..... | 82 |
| UDT E1/T1- Universal Digital Trunk card..... | 88 |
| UDT E1/T1 software transparency..... | 89 |
| UDT E1/T1 applicable systems..... | 89 |
| UDT E1/T1 limitations..... | 89 |
| Chapter 5: DCH installation..... | 91 |
| Contents..... | 91 |
| Install the NT6D11AB, NT6D11AE, NT6D11AF DCH..... | 91 |
| Set up the NT6D11AB, NT6D11AE, NT6D11AF DCHI..... | 92 |
| DIP switch settings..... | 92 |
| Protocol selection..... | 93 |
| Valid switch combinations..... | 93 |
| Jumper settings..... | 94 |

| | |
|---|------------|
| Port addressing modes..... | 95 |
| Port address switch settings..... | 96 |
| Install the NT6D11AB, NT6D11AE, NT6D11AF DCHI..... | 97 |
| Remove the NT6D11AB, NT6D11AE, NT6D11AF DCH..... | 98 |
| Install the QPC757 DCH..... | 99 |
| Port address switch settings..... | 101 |
| D-channel parameter downloading..... | 101 |
| Remove the QPC757 DCHI..... | 101 |
| Chapter 6: NTBK51 DDCH installation and removal..... | 103 |
| Contents..... | 103 |
| Introduction..... | 103 |
| Install NTBK51 DDCH on NT5D97 dual-port DTI2/PRI2 card..... | 104 |
| Remove NTBK51 DDCH from NT5D97 dual-port DTI2/PRI2 card..... | 104 |
| Install NTBK51 DDCH on NT5D12 dual-port DTI/PRI..... | 105 |
| Remove NTBK51 DDCH from NT5D12 dual-port DTI/PRI..... | 105 |
| Chapter 7: Universal Digital Trunk card installation..... | 107 |
| Contents..... | 107 |
| Installation guidelines - default mode..... | 107 |
| Installation guidelines - non default mode..... | 108 |
| UDT Clock Controller daughter board installation..... | 109 |
| Physical installation of the UDT card..... | 110 |
| UDT E1/T1 Configuration guidelines - PRI2 (E1)..... | 113 |
| UDT E1/T1 Configuration guidelines - DTI2 (E1)..... | 113 |
| UDT E1/T1 Configuration guidelines - DTI (T1)..... | 114 |
| UDT E1/T1 Configuration guidelines- DPNSS/DASS (E1)..... | 114 |
| Chapter 8: Universal Digital Trunk card firmware upgrade..... | 117 |
| Contents..... | 117 |
| Firmware upgrade..... | 117 |
| Feature interactions..... | 117 |
| Firmware download duration..... | 118 |
| Security..... | 118 |
| Loadware patch..... | 118 |
| Firmware download guidelines..... | 119 |
| Loadware Configuration Procedures..... | 119 |
| LD 60 Check the existing firmware version of UDT cards..... | 120 |
| LD 22 Print the existing peripheral software download version (PSDL)..... | 121 |
| LD 143 Execute the UDT card upgrade for the required UDT cards..... | 122 |
| UDT E1/T1 secure firmware download..... | 123 |
| UDT E1/T1 secure firmware download guidelines..... | 124 |
| Chapter 9: MSDL installation for all systems..... | 125 |
| Contents..... | 125 |
| Install the MSDL..... | 125 |
| Replace the MSDL..... | 127 |
| Chapter 10: NT8D72 and QPC720 PRI card installation..... | 129 |
| Contents..... | 129 |
| Introduction..... | 129 |
| PRI circuit pack locations..... | 129 |

| | |
|---|------------|
| Cable requirements..... | 130 |
| Switch settings..... | 148 |
| Install NT8D72 and QPC720 PRI cards on Large Systems..... | 150 |
| Remove NT8D72 and QPC720 PRI cards from Large Systems..... | 152 |
| Install an additional network shelf..... | 152 |
| Chapter 11: NT5D97 Dual-port DTI2/PRI2 installation and removal..... | 155 |
| Contents..... | 155 |
| Introduction..... | 155 |
| NT5D97 circuit card locations..... | 156 |
| Port definitions..... | 156 |
| Case Scenarios for replacing a digital trunk NT8D72BA, QPC536E, or NTCK43 by a DDP2 card..... | 157 |
| NT5D97AA/AB DIP switch settings..... | 157 |
| Trunk interface switches for NT5D97AA/AB..... | 160 |
| DCH Address select switch for NTBK51AA/NTBK51CA daughter board for NT5D97AA/AB | 161 |
| NT5D97AD DIP switch settings..... | 163 |
| Trunk interface switches for NT5D97AD..... | 165 |
| DCH Address select switch for NTBK51AA/NTBK51CA daughter board for NT5D97AD | 166 |
| MSDL external card..... | 167 |
| Install the NT5D97 DDP2..... | 168 |
| Remove the NT5D97 DDP2..... | 169 |
| Configure the NT5D97 DDP2..... | 170 |
| Chapter 12: NT5D12 Dual-port DTI/PRI card installation..... | 171 |
| Contents..... | 171 |
| Introduction..... | 171 |
| NT5D12 circuit card locations..... | 172 |
| Port definitions..... | 172 |
| Scenarios for replacement of a digital trunk card (QPC720/QPC472) by a DDP card..... | 172 |
| NT5D12 switch settings..... | 173 |
| General Purpose Switches..... | 173 |
| Trunk interface switches..... | 174 |
| Ring ground switches..... | 175 |
| DCH mode and address select switches..... | 175 |
| Install the NT5D12 DDP..... | 178 |
| Remove the NT5D12 DDP..... | 180 |
| Configure the NT5D12 DDP..... | 180 |
| Chapter 13: Clock Controller description and installation..... | 183 |
| Contents..... | 183 |
| Introduction..... | 184 |
| Description..... | 184 |
| Need for synchronization..... | 184 |
| Supported Clock Controllers..... | 185 |
| Synchronization methods..... | 186 |
| Hierarchical synchronization..... | 187 |
| Stratum levels..... | 188 |
| Frame slip..... | 189 |
| Guidelines..... | 190 |
| Modes of operation..... | 196 |

| | |
|---|------------|
| Small System Clock Controller daughterboard..... | 197 |
| Installation procedures..... | 197 |
| Determine slots and shelves..... | 198 |
| Set switches..... | 198 |
| Start the Clock Controller..... | 200 |
| Clock Controller commands..... | 200 |
| LD 39 commands with the NTRB53 Clock Controller..... | 200 |
| Install or replace a Clock Controller on a Half Group and Single Group system..... | 200 |
| Install or replace a Clock Controller on a Single Group and Multi Group System..... | 202 |
| Upgrade to an NTRB53 Clock Controller on a Single Group and Multi Group System..... | 203 |
| Chapter 14: ISL installation..... | 209 |
| Contents..... | 209 |
| ISL configurations..... | 209 |
| Shared mode..... | 209 |
| DCHI switch settings..... | 210 |
| MSDL switch settings..... | 211 |
| Shared mode..... | 212 |
| Dedicated mode using leased line..... | 213 |
| Dedicated mode using dialup modem..... | 214 |
| Install a modem for ISL applications..... | 214 |
| Dedicated mode using PRI/DTI trunks..... | 216 |
| QMT11 switch settings..... | 217 |
| QMT8 switch settings..... | 218 |
| QMT21C switch settings..... | 218 |
| ISL installation..... | 219 |
| Install ISL in dedicated mode (digital and analog)..... | 219 |
| Install ISL in shared mode..... | 219 |
| Chapter 15: Echo canceller installation..... | 221 |
| Contents..... | 221 |
| Introduction..... | 221 |
| Echo canceller operating parameters..... | 221 |
| Echo canceller initialization procedures..... | 222 |
| PRI to Echo canceller pin assignments..... | 222 |
| Electromagnetic Interference..... | 223 |
| Chapter 16: Universal Digital Trunk card commissioning..... | 225 |
| Contents..... | 225 |
| UDT card configuration as 2.0 Mb PRI2 (E1)..... | 226 |
| Task summary list..... | 226 |
| LD 17 configure PRI loop and D-channel interface..... | 226 |
| LD 15 configure PRI customer..... | 227 |
| LD 16 configure ISDN service route..... | 227 |
| LD 14 configure service channels and PRI trunks..... | 228 |
| LD 73 configure system timers and clock controller..... | 229 |
| UDT card configuration as 2.0 Mb DTI (E1)..... | 229 |
| Task summary list..... | 229 |
| LD 17 configure DTI loop..... | 230 |
| LD 73 configure 2.0 Mb DTI ABCD signaling bit tables and system timers..... | 230 |

| | |
|---|------------|
| LD 16 configure 2.0 Mb DTI trunk route..... | 231 |
| LD 14 configure service channels and 2.0 Mb DTI trunks..... | 232 |
| UDT card configuration as DPNSS/DASS (E1)..... | 232 |
| Task summary list..... | 232 |
| LD 17 configure DPNSS/DASS loop and D-channel..... | 233 |
| LD 74 configure DDSL block for DPNSS/DASS2..... | 234 |
| LD 16 configure route data block..... | 234 |
| LD 14 configure DPNSS/DASS2 trunks..... | 235 |
| UDT card configuration as 1.5 Mb PRI (T1)..... | 236 |
| Task summary list..... | 236 |
| LD 17 configure PRI loop and D-channel interface..... | 236 |
| LD 15 configure PRI customer..... | 237 |
| LD 16 configure ISDN service route..... | 238 |
| LD 14 configure service channels and PRI trunks..... | 238 |
| LD 73 configure system timers and clock controller..... | 239 |
| UDT card configuration as 1.5 Mb DTI (T1)..... | 240 |
| Task summary list..... | 240 |
| LD 17 configure DTI loop..... | 240 |
| LD 16 configure 1.5 Mb DTI trunk route..... | 241 |
| LD 14 configure service channels and 1.5 Mb DTI trunks..... | 241 |
| LD 73 configure clock reference..... | 242 |
| Chapter 17: 1.5 Mb PRI implementation..... | 245 |
| Contents..... | 245 |
| Overview..... | 245 |
| Hardware requirements..... | 246 |
| Circuit cards..... | 246 |
| Cables..... | 246 |
| Channel Service Units (CSU)..... | 246 |
| Hardware description..... | 247 |
| Media Gateway/Media Gateway Expansion..... | 247 |
| NTRB21 TMDI card..... | 248 |
| NTAK09 DTI/PRI circuit card..... | 249 |
| NTAK20 Clock Controller (CC) daughterboard..... | 250 |
| Clock controller LED states..... | 252 |
| Shelf slot assignments for NTRB21, NTAK09 and NTAK20..... | 253 |
| NTAK93 D-channel Handler Interface (DCHI) daughterboard..... | 253 |
| NTBK51BA Downloadable D-channel (DDCH) daughterboard..... | 254 |
| Install PRI hardware..... | 254 |
| Install/remove daughterboard on the NTRB21 TMDI card..... | 254 |
| Insert/remove the NTRB21 TMDI card..... | 255 |
| Install/remove daughterboards on the NTAK09 DTI/PRI card..... | 257 |
| Set switches on NTAK09 DTI/PRI card..... | 258 |
| Installing the NTAK09..... | 259 |
| Chapter 18: 1.5 Mb DTI implementation..... | 267 |
| Contents..... | 267 |
| Overview..... | 267 |
| Hardware requirements..... | 267 |

| | |
|--|------------|
| Cables..... | 268 |
| Channel Service Units (CSU)..... | 268 |
| Hardware description..... | 268 |
| Install DTI hardware..... | 269 |
| Set the switches..... | 269 |
| Connect the cables..... | 269 |
| Software enable the DTI/PRI cards..... | 270 |
| Chapter 19: 1.5 Mb ISL implementation..... | 275 |
| Contents..... | 275 |
| Overview..... | 275 |
| Hardware requirements..... | 275 |
| Shared mode..... | 276 |
| Dedicated mode..... | 276 |
| ISL hardware installation (dedicated mode)..... | 277 |
| Basic ISL implementation..... | 279 |
| Implement dedicated mode..... | 279 |
| Implement shared mode..... | 284 |
| Chapter 20: 2.0 Mb DTI implementation..... | 285 |
| Contents..... | 285 |
| Overview..... | 285 |
| Hardware requirements..... | 285 |
| NTAK10 2.0 Mb DTI card..... | 286 |
| Install DTI hardware..... | 286 |
| Inspect the NTAK10 circuit card..... | 287 |
| Set the switches..... | 287 |
| Switch S1 - Clock Controller (CC) configuration..... | 287 |
| Switch S2 - Carrier impedance configuration..... | 287 |
| Switch S3 - Mode of operation..... | 288 |
| Switch S4 - Carrier shield grounding..... | 288 |
| Insert the NTAK10..... | 289 |
| NTBK05DA pinouts..... | 289 |
| NTBK05CA pinouts..... | 289 |
| DTI software implementation..... | 290 |
| Task summary list..... | 290 |
| Chapter 21: 2.0 Mb PRI implementation..... | 305 |
| Contents..... | 305 |
| Overview..... | 305 |
| Hardware requirements..... | 305 |
| Circuit cards..... | 305 |
| Cables..... | 306 |
| Hardware description..... | 306 |
| 2.0 Mb PRI cards..... | 306 |
| NTAK20 Clock Controller (CC) daughterboard..... | 308 |
| NTAK93 D-Channel Handler Interface (DCHI) daughterboard..... | 308 |
| NTBK51 Downloadable D-Channel (DDCH) daughterboard..... | 309 |
| Install the NTAK79 PRI card..... | 309 |
| Inspect the NTAK79 circuit card..... | 310 |

| | |
|---|------------|
| Set the switches on the NTAK79..... | 310 |
| Insert the NTAK79..... | 312 |
| Install the NTBK50 PRI card..... | 313 |
| Set the switches on the NTBK50..... | 314 |
| Mount the daughterboards on the NTBK50..... | 316 |
| Insert the NTBK50..... | 318 |
| Connect the cables..... | 318 |
| PRI software implementation..... | 319 |
| Task summary..... | 320 |
| Configure DPNSS1 with IP expansion cabinets/Media Gateway systems..... | 328 |
| Configure ISDN BRI trunking with IP expansion cabinets/Media Gateway systems..... | 328 |
| Chapter 22: 2.0 Mb ISL implementation..... | 331 |
| Contents..... | 331 |
| Overview..... | 331 |
| ISL hardware requirements..... | 331 |
| ISL in shared mode..... | 332 |
| ISL in dedicated mode using leased line..... | 332 |
| ISL in dedicated mode using dialup modem..... | 333 |
| ISL hardware installation..... | 334 |
| Shared mode..... | 334 |
| Dedicated mode..... | 334 |
| ISL software implementation..... | 336 |
| Shared mode..... | 336 |
| Dedicated mode..... | 337 |
| Chapter 23: Nonstandard cables..... | 341 |
| Contents..... | 341 |
| Introduction..... | 342 |
| NT5K40AA, NT5K41AA, NT5K86AA..... | 342 |
| NT8D7206, NT8D7207..... | 343 |
| QCAD128..... | 343 |
| QCAD129..... | 344 |
| QCAD133..... | 345 |
| NT8D7205..... | 346 |
| QCAD328..... | 346 |
| NT8D74 Clock Controller to InterGroup cable..... | 347 |
| NT8D75 Clock Controller to Clock Controller cable..... | 347 |
| NT8D79 PRI/DTI to Clock Controller cable..... | 348 |
| NT8D83 PRI/DTI to I/O cable..... | 348 |
| NT8D85 Network to IPE cable..... | 348 |
| NT8D86 Network to I/O cable..... | 349 |
| NT8D97AX PRI/DTI I/O to MDF cable..... | 349 |
| NT9J93AD PRI/DTI Echo Canceller to I/O cable..... | 350 |
| NTND26 PRI to MSDL cables..... | 350 |
| NTND27 MSDL to I/O panel cables..... | 350 |
| NTND98 PRI to I/O panel cables..... | 350 |
| Index..... | 351 |

Chapter 1: New in this release

There are no updates to the feature descriptions in this document for Avaya Communication Server 1000 Release 7.5.

Other changes

There are no other changes.

Revision History

| | |
|---------------|---|
| February 2012 | Standard 05.08. This document is up-issued for changes in Physical installation of the UDT card on page 110. |
| December 2011 | Standard 05.07. This document is up-issued for changes in Physical installation of the UDT card on page 110. |
| December 2011 | Standard 05.06. This document is up-issued to include new information about UDT configuration. |
| November 2011 | Standard 05.05. This document is up-issued to remove legacy feature and hardware content that is no longer applicable to or supported by Communication Server 1000 systems. |
| August 2011 | Standard 05.04. This document is up-issued for changes in technical content. Information about commissioning a UDT card as 1.5 Mb PRI or as 1.5 Mb DTI has been added. |
| March 2011 | Standard 05.03. This document is up-issued to replace the NT5D16AA 100W cable with the NTBK66AAE5 T1 interface cable. |
| November 2010 | Standard 05.02. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. |
| February 2012 | Standard 04.04. This document is up-issued for changes in Physical installation of the UDT card on page 110. |
| December 2011 | Standard 04.03. This document is up-issued for changes in Physical installation of the UDT card on page 110. |

New in this release

| | |
|----------------|--|
| August 2011 | Standard 04.02. This document is up-issued for changes in technical content. Information about commissioning a UDT card as 1.5 Mb PRI or as 1.5 Mb DTI has been added. |
| June 2010 | Standard 04.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.0. |
| May 2009 | Standard 03.01. This document is up-issued to support Communication Server 1000 Release 6.0. |
| December 2007 | Standard 02.03. This document is up-issued to support Communication Server Release 5.5. |
| August 2007 | Standard 01.03. This document is up-issued to support CR Q01732521. |
| June 2007 | Standard 01.02. This document is up-issued to remove the Confidential statement. |
| May 2007 | Standard 01.01. This document is issued to support Communication Server 1000 Release 5.0. This document contains information previously contained in the following legacy document, now retired: <i>ISDN Primary Rate Interface Installation and Commissioning, NN43001-301</i> . No new content is added for Communication Server 1000 Release 5.0. All references to Communication Server 1000 Release 4.5 are applicable to Communication Server 1000 Release 5.0. |
| August 2005 | Standard 3.00. This document is up-issued to support Communication Server 1000 Release 4.5. |
| September 2004 | Standard 2.00. This document is up-issued for Communication Server 1000 Release 4.0. |
| October 2003 | Standard 1.00. This document is a new technical document for Succession 3.0. It was created to support a restructuring of the Documentation Library, which resulted in the merging of multiple legacy technical documents. This new document consolidates information previously contained in the following legacy documents, now retired: <ul style="list-style-type: none">• <i>ISDN Primary Rate Interface: Installation (553-2901-201)</i>• <i>1.5Mb DTI/PRI: Description, Installation and Maintenance (553-3011-310)</i> (Content from <i>1.5Mb DTI/PRI: Description, Installation and Maintenance (553-3011-310)</i> also appears in <i>Avaya ISDN Primary Rate Interface Maintenance, NN43001-717</i>.)• <i>2.0Mb DTI/PRI: Description, Installation and Maintenance (553-3011-315)</i> (Content from <i>2.0Mb DTI/PRI: Description, Installation and Maintenance (553-3011-315)</i> also appears in <i>Avaya ISDN Primary Rate Interface Maintenance, NN43001-717</i>.) |

Chapter 2: Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to www.avaya.com or go to one of the pages listed in the following sections.

Navigation

- [Getting technical documentation](#) on page 13
- [Getting product training](#) on page 13
- [Getting help from a distributor or reseller](#) on page 13
- [Getting technical support from the Avaya Web site](#) on page 14

Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet, go to www.avaya.com/support.

Getting product training

Ongoing product training is available. For more information or to register, go to www.avaya.com/support. From this Web site, locate the Training link on the left-hand navigation pane.

Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at www.avaya.com/support.

Chapter 3: Introduction

This document is a global document. Contact your system supplier or your Avaya representative to verify that the hardware and software described are supported in your area.

Legacy products and releases

This technical document contains information about systems, components, and features that are compatible with Avaya Communication Server 1000 software. For more information about legacy products and releases, click the **Documentation** link under **Support** on the Avaya home page:

www.avaya.com

Applicable systems

This document applies to the following systems:

- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Communication Server 1000E (CS 1000E)

System migration

When you upgrade a Meridian 1 system to run Avaya CS 1000 software and configure it to include a Signaling Server, it becomes an Avaya CS 1000 system. [Table 1: Meridian 1 systems to CS 1000 systems](#) on page 15 lists each Meridian 1 system that supports an upgrade path to a CS 1000 system.

Table 1: Meridian 1 systems to CS 1000 systems

| This Meridian 1 system | Maps to this CS 1000 system |
|----------------------------|-----------------------------|
| Meridian 1 PBX 11C Chassis | CS 1000E |
| Meridian 1 PBX 11C Cabinet | CS 1000E |
| Meridian 1 PBX 61C | CS 1000M Single Group |

| This Meridian 1 system | Maps to this CS 1000 system |
|------------------------|-----------------------------|
| Meridian 1 PBX 81C | CS 1000M Multi Group |

For more information, see one or more of the following documents:

- *Avaya CS 1000M and Meridian 1 Large System Upgrades Overview, NN43021-458*
- *Avaya Communication Server 1000E Upgrades, NN43041-458*
- *Avaya Communication Server 1000E Upgrade — Hardware Upgrade Procedures, NN43041-464*

Intended audience

This document is intended for individuals responsible for installing and configuring ISDN PRI.

Related information

This section lists information sources that relate to this document.

Technical Documents

The following technical publications are referenced in this document:

- *Avaya Features and Services Fundamentals, NN43001-106*
- *Avaya Software Input Output Administration, NN43001-611*
- *Avaya Software Input Output Reference — Maintenance, NN43001-711*

Online

To access Avaya documentation online, click the **Documentation** link under **Support** on the Avaya home page: www.avaya.com

Chapter 4: ISDN Primary Rate Interface equipment overview

Contents

The section contains information about the following topics:

[Introduction](#) on page 19

[Primary Rate Interface \(PRI\) hardware requirements](#) on page 19

[ISDN Signaling Link \(ISL\) hardware](#) on page 21

[64 Kbit/s Clear Data Hardware](#) on page 22

[D-Channel Handler description](#) on page 23

[NT6D11 DCH](#) on page 23

[Power requirements](#) on page 23

[DCH/PRI interface](#) on page 23

[DCH faceplate](#) on page 23

[QPC757 DCH](#) on page 24

[Power requirements](#) on page 24

[DCH/PRI interface](#) on page 25

[QPC757 faceplate](#) on page 25

[NT6D80 MSDL](#) on page 26

[Power requirements](#) on page 26

[MSDL/PRI interface](#) on page 27

[MSDL faceplate](#) on page 27

[NTBK51 Downloadable D-Channel Daughterboard](#) on page 28

[Standard PRI cards](#) on page 28

[NT8D72 PRI2](#) on page 29

[Power requirements](#) on page 29

[NT8D72 faceplate](#) on page 29

[Cable requirements](#) on page 31

[Carrier interface](#) on page 32

[Echo canceller interface](#) on page 32

[QMT21 High Speed Data Module](#) on page 32

[QPC720 PRI for 1.5/2.0 Mb gateway](#) on page 32

[Clock operation for the NT8D72](#) on page 32

[QPC720 PRI](#) on page 35

[Power requirements](#) on page 35

[QPC720 faceplate](#) on page 35

[QPC720 Cable requirements](#) on page 37

[Carrier interface](#) on page 37

[Echo Canceller interface](#) on page 37

[64 T-link version 2 protocol](#) on page 38

[Disk drive hardware](#) on page 39

[NT5D97 Dual-port DTI2/PRI2 card](#) on page 39

[External D-Channel Interface DCH or MSDL](#) on page 39

[NT5D97 faceplate](#) on page 40

[System capacity and performance](#) on page 45

[Testability and diagnostics](#) on page 46

[Cable requirements](#) on page 46

[Cable diagrams](#) on page 52

[Clock for the NT5D97](#) on page 54

[NT5D12 Dual-port DTI/PRI](#) on page 62

[D-Channel and MSDL interface](#) on page 63

[NT5D12 faceplate](#) on page 63

[System capacity and performance](#) on page 68

[Power requirements](#) on page 69

[Testability and diagnostics](#) on page 70

[NT5D12 Cable requirements](#) on page 70

[Trunk Tip/Ring cables](#) on page 71

[Reference clock cables](#) on page 77

[MSDL/DCHI cables](#) on page 78

[Cable diagrams](#) on page 79

[Clock](#) on page 80

[Reference clock errors](#) on page 81

[Automatic clock recovery](#) on page 82

[Automatic clock switching](#) on page 82

[Clock configurations](#) on page 82

[UDT E1/T1- Universal Digital Trunk card](#) on page 88

[UDT E1/T1 software transparency](#) on page 89

[UDT E1/T1 applicable systems](#) on page 89

[UDT E1/T1 limitations](#) on page 89

Introduction

This chapter describes the basic hardware needed to equip ISDN PRI on Avaya Communication Server 1000 (Avaya CS 1000) and Meridian 1 systems.

Primary Rate Interface (PRI) hardware requirements

The following hardware is required to equip ISDN PRI on a Large System:

- NT6D11(AB/AE/AF) D-Channel Interface (DCH) card (for 2.0 Mb PRI)
- QPC757 D-channel Interface (DCH) for (1.5 Mb PRI)
- NT6D80 Multipurpose Serial Data Link (MSDL) card
- NTBK51 Downloadable D-Channel Daughterboard (DDCH), the NT5D97 dual-port DTI2/PRI2 card, or the NT5D12 dual-port 1.5 Mb DTI/PRI card
- NT8D72 (AB/BA) PRI2 card
- NT5D97 dual-port DTI2/PRI2 card
- QPC720 1.5 Mb PRI card
- NT5D12 dual-port 1.5 DTI/PRI card
- QPC775 or NTRB53 Clock Controller

 **Note:**

The NTRB53 Clock Controller cannot be combined with a QPC775 or a QPC471 card in one system

Additional hardware is also required for PRI capability and applications. Installation instructions are given in other Avaya publications, or supplied by the manufacturer. This additional hardware includes:

- QPC414 Network card
- Channel Service Unit (CSU)
- Echo canceller
- ROM circuit card requirements:
 - the QPC939A for a CS 1000M HG
 - the QPC939A for CS 1000M SG

 **Note:**

CS 1000M MGROM requirements are fulfilled by the NT6D66 Call Processor (CP) card.

- QMT8 Asynchronous Data Module (ADM)

See [Figure 1: PRI hardware \(shown without downloadable PRI and DCH cards\)](#) on page 21 for a representation of the basic PRI system hardware.

 **Note:**

Figure 1 shows a basic configuration, not the dual-port NT5D12 DTI/PRI card, nor the associated dual-port NTBK51AA/NTBK51CA Downloadable D-Channel daughterboard.




Figure 1: PRI hardware (shown without downloadable PRI and DCH cards)

ISDN Signaling Link (ISL) hardware

The following hardware is required for ISDN Signaling Link (ISL) capability and applications.

Equipment required for shared mode capability:

- NT6D11(AB/AE/AF) D-Channel (DCH) card (for 2.0 Mb PRI)
- QPC757 D-channel (DCH) for (1.5 Mb PRI)
- NT6D80 Multipurpose Serial Data Link (MSDL) card
- NTBK51 Downloadable D-Channel Daughterboard (DDCH), the NT5D97 dual-port DTI2/PRI2 card, or the NT5D12 dual-port 1.5 Mb DTI/PRI card
- NT8D72 (AB/BA) PRI2 card
- NT5D97 dual-port DTI2/PRI2 card
- QPC720 1.5 Mb PRI card
- NT5D12 dual-port 1.5 DTI/PRI card
- QPC775 Clock Controller or NTRB53

Equipment required for dedicated mode using leased lines:

- NT6D11(AB/AE/AF) D-Channel (DCH) card (for 2.0 Mb PRI)
- QPC757 D-channel (DCH) for (1.5 Mb PRI)

- NT6D80 Multipurpose Serial Data Link (MSDL) card
- NTBK51 Downloadable D-Channel Daughterboard (DDCH), used as an option to the NT6D80 MSDL
- modem set in synchronous mode

Equipment required for dedicated mode using a dialup modem:

- NT6D11(AB/AE/AF) D-Channel (DCH) card (for 2.0 Mb PRI)
- QPC757 D-channel (DCH) for (1.5 Mb PRI)
- NT6D80 Multipurpose Serial Data Link (MSDL) card
- NTBK51 Downloadable D-Channel Daughterboard (DDCH), used as an option to the NT6D80 MSDL
- modem with autodial capability

 **Note:**

This configuration is the least reliable due to lockup problems inherent in Smart Modems from power spikes and noisy lines. To increase the reliability on this configuration, use a constant power source when powering the modems. Also, verify that TIE lines meet data grade specifications. Avaya takes no responsibility for ISL D-Channel outages due to modem lockup.

- 500 set line card
- QPC71 2W TIE, or QPC237 4W TIE E&M

Equipment required for dedicated mode using a DTI/DTI2 trunk:

- NT6D11(AB/AE/AF) D-Channel (DCH) card (for 2.0 Mb PRI)
- QPC757 D-channel (DCH) for (1.5 Mb PRI)
- NT6D80 Multipurpose Serial Data Link (MSDL) card
- NTBK51 Downloadable D-Channel Daughterboard (DDCH), used as an option to the NT6D80 MSDL
- NT5D97 dual-port DTI2/PRI2 card
- QPC472 1.5 Mb DTI card or NT5D12 dual-port 1.5 DTI/PRI card
- QMT8 Asynchronous Data Module (ADM), QMT11 Asynchronous/Synchronous Interface Module (ASIM) or QMT21 High Speed Data Module (HSDM)
- Data line card

64 Kbit/s Clear Data Hardware

The QMT21 High Speed Data Module (HSDM) is required in the clear-data pathway to support the 64Kbit/s clear-data function. One module is required at each system end of any connection.

D-Channel Handler description

This section provides descriptions of the D-Channel (DCH) cards, the MSDL card, and the Downloadable D-Channel Daughterboard.

NT6D11 DCH

Power requirements

The power requirements for the NT6D11AB/11AE/AF DCH are:

- +5 volts at 3 amperes
- +12 volts at 75 milliamperes
- -12 volts at 75 milliamperes

DCH/PRI interface

The NT6D11AB/AE/AF DCHs connect to the PRI2 cards by means of a special RS422 cable, the QCAD328A, which is a special RS422 cable; refer to [QCAD328](#) on page 346 of the Cabling chapter for more details.

DCH faceplate

NT6D11AB/AE/AF DCHs have one Light Emitting Diode (LED), to indicate an active or inactive state, and two external connectors:

- Port J1 is a standard asynchronous port providing an interface for non-PRI applications.

 **Note:**

This connection does not support an Add-on Data Module (ADM) terminal.

- Port J2 is the D-Channel Interface port.

[Figure 2: NT6D11 DCH faceplate layout](#) on page 24 shows the faceplate layout.




Figure 2: NT6D11 DCH faceplate layout

QPC757 DCH

Power requirements

The power requirements for the QPC757 DCH are:

- +5 volts at 3 amperes
- +12 volts at 50 milliamperes
- -12 volts at 50 milliamperes

DCH/PRI interface

The QPC757 DCH connects to the QPC720 PRI via a RS-422 cable. The following signals are transmitted across the interface:

- RCV DATA
- RCV CLOCK
- XMIT CLOCK
- XMIT READY
- PRI READY
- DCH READY

PRI READY and DCH READY are handshake signals.

QPC757 faceplate

The QPC757 DCH, as shown in [Figure 3: QPC757 DCH faceplate layout](#) on page 26 has one LED to indicate an active or inactive state and two external connectors as follows:

- Port J1 is a standard asynchronous port in LD 48


 **Note:**

This connection does not support an Add-on Data Module (ADM) terminal.

- Port J2 is the D-Channel Interface port.

 **Note:**

A QPC757 vintage C is required if the ISL Revert to Conventional Signaling feature is configured. The QPC757 vintage D is recommended for combination ISL/PRI networks using NACD or Network Message Services and ISL networks using modems.



553-1373

Figure 3: QPC757 DCH faceplate layout

NT6D80 MSDL

The NT6D80 MSDL card can be used in conjunction with, or independent of, the QPC757, or NT6D11AB/AE/AF DCH.

Power requirements

The NT6D80 MSDL power requirements are:

| Voltage (VAC) | Current (Amps) | Power (Watts) | Heat (BTUs) |
|---------------|----------------|---------------|-------------|
| +5 | 3.20 | 16.00 | 55.36 |
| +12 | 0.10 | 1.20 | 4.15 |

| Voltage (VAC) | Current (Amps) | Power (Watts) | Heat (BTUs) |
|---------------|----------------|---------------|-------------|
| -12 | 0.10 | 1.20 | 4.15 |

MSDL/PRI interface

MSDL can connect to PRI trunks through RS-422 or RS-232 interfaces. The interfaces are switch configured.

MSDL faceplate

The NT6D80 MSDL has one LED to indicate an active or inactive state and four external connectors. Each port can be RS-422 or RS-232 connectors, with either DCE or DTE interfaces. Refer to [Figure 4: NT6D80 MSDL faceplate layout](#) on page 27.




Figure 4: NT6D80 MSDL faceplate layout

NTBK51 Downloadable D-Channel Daughterboard

The NTBK51 is a two port Downloadable D-Channel Daughterboard (DDCH) that is introduced as an option to the NT6D80 MSDL, the NT5D97 dual-port DTI2/PRI2 card, or the NT5D12 dual-port 1.5 Mb DTI/PRI card.

The NTBK51 supports all the features of the existing 4 port MSDL (NT6D80), and eliminates the need for an external DCH card and associated cables for MSDL applications. The NTBK51 can support a maximum of 32 (16*2) MSDL type D-Channels per system, unlike the MSDL which can support a maximum of 64.

 **Note:**

NTBK51AA/CA can be used with the NT5D97 or the NT5D12. The NTBK51BA version has only 30+30 pin connectors (instead of 40+30 pins in the AA version). The missing 10 pins in the BA version prohibits the use of port 0 on the NT5D97, or NT5D12 card.

 **Note:**

The software allocation for NTBK51AA/NTBK51CA DDCH is similar to the MSDL. It is both physical and logical, and supports D-Channel functionality only.

 **Note:**

Port 0 has to be an even loop on the DDP2, and Port 1 has to be an odd loop. Port 2 and Port 3 should not be configured.

The connection between the dual-port cards and the DDCH daughterboard is made using two headers: one 30 pin and one 40 pin connector.

Standard PRI cards

This section provides a description of the standard ISDN PRI cards, namely the NT8D72 (AB/BA) PRI2 card, and the QPC720 1.5 Mb PRI card.

NT8D72 PRI2

Power requirements

The NT8D72AB and NT8D72BA PRI use power and ground connections from the backplane. Power requirements are:


+5 volts at 4 amperes

+12 volts at 50 milliamperes

-12 volts at 50 milliamperes

NT8D72 faceplate

The NT8D72 contains five LEDs and six external connectors. [Figure 5: NT8D72 PRI faceplate layout](#) on page 30 shows the faceplate layout.



553-7336

Figure 5: NT8D72 PRI faceplate layout

[Table 2: NT8D72 PRI External connectors](#) on page 30 gives information about the external connectors located on the NT8D72 PRI2 faceplate.

Table 2: NT8D72 PRI External connectors

| Faceplate Destination | Type | Description |
|-----------------------|----------------------------|---------------------------------|
| J1 | 9-pin female, D-connector | Reference Clock 0 interface |
| J2 | 9-pin female, D-connector | Reference Clock 1 interface |
| J3 | 36-pin connector | Loop interface |
| J4 | 15-pin male, D-connector | External digital trunk |
| J5 | 15-pin male, D-connector | D-Channel interface |
| J6 | 15-pin female, D-connector | Echo Canceller/RS-232 interface |
| RCV MON | Miniature bantam jack | Monitor DSI from network |

| Faceplate Destination | Type | Description |
|-----------------------|-----------------------|----------------------|
| XMT MON | Miniature bantam jack | Monitor DSI from PRI |

Cable requirements

[Table 3: NT8D72AB and NT8D72BA PRI: Cables and cable lengths](#) on page 31 lists the types of cable used and the lengths required for internal and external NT8D72 PRI2 connections.

 **Note:**

No additional cabling is required for nB+D configurations. Multiple PRIs and the D-Channel are associated at the PRI prompt in LD 17.

Table 3: NT8D72AB and NT8D72BA PRI: Cables and cable lengths

| Cable Type | From | To | Maximum length (meters) |
|------------|------------------|-------------------------|-------------------------|
| NT8D79AA | PRI card | Clock controller (CC-0) | 2.13 |
| NT8D79AA | PRI card | Clock controller (CC-1) | 2.13 |
| QCAD328A | PRI card | DCH card | 1.8 |
| QCAD328B | PRI card | DCH card | 5.5 |
| QCAD328C | PRI card | DCH card | 10.67 |
| QCAD328D | PRI card | DCH card | 15.24 |
| NTND26AA | PRI card | MSDL | 1.8 |
| NTND26AB | PRI card | MSDL | 5.5 |
| NTND26AC | PRI card | MSDL | 10.67 |
| NTND26AD | PRI card | MSDL | 15.24 |
| NT8D85AB | PRI card Network | Network Card | 15.24 |
| RS-232 | PRI card | Echo canceller | 15.24 |
| NT8D7207 | PRI card | I/O panel | 3.05 |
| NT8D7205 | I/O panel | crossconnect | 15.24 |

Carrier interface

The NT8D72 PRI2 provides an interface to the 2Mb external digital line either directly or through an office repeater, echo canceller or line terminating unit (LTU).

Echo canceller interface

Echo cancellers are required only on satellite transmission circuits. The echo canceller detects the length of the loop, and then cancels out reflected transmission. (Callers do not hear echoes of their own voices reflecting back to them from the far end of the call.)

The echo canceller's control protocol must conform with that of the Tellabs Model 251. Both the echo canceller and the PRI circuit card act as Data Terminal Equipment (DTE).

QMT21 High Speed Data Module

The QMT21 High Speed Data Module supports the 64K Clear Data feature. (It allows data terminating equipment (DTE) to send and receive 64-Kb/s clear data.) The QMT21B is required for Large System to Large System configurations.

QPC720 PRI for 1.5/2.0 Mb gateway

Systems which are being used as a 1.5/2.0 Mb Gateway, need one or more QPC720 (1.5 Mb) Primary Rate Interface circuit cards.

 **Note:**

Older vintages of the QPC720 PRI cannot be used for Gateway applications. The 1.5/2.0 Mb Gateway feature requires the use of a QPC720 circuit card with firmware updated to provide modified PAD values.

Clock operation for the NT8D72

There are two types of clock operation—tracking mode and free-run mode.

Tracking mode

In tracking mode, the PRI loop supplies an external clock reference to a clock controller. Two PRI loops can operate in tracking mode, with one defined as the primary reference source for

clock synchronization, the other defined as the secondary reference source. The secondary reference acts as a back-up to the primary reference.

As shown in [Figure 6: Clock controller primary and secondary tracking](#) on page 33, a system with dual CPUs can have two clock controllers (CC-0 and CC-1). One clock controller acts as a back-up to the other. The clock controllers should be completely locked to the reference clock.




Figure 6: Clock controller primary and secondary tracking

Free run (non-tracking) mode

The clock synchronization of the system can operate in free-run mode if:

- no loop is defined as the primary or secondary clock reference,
- the primary and secondary references are disabled, or
- the primary and secondary references are in local alarm

Reference clock errors

The system software checks at intervals of 1 to 15 minutes to see if a clock controller or reference-clock error is occurred. (The interval of this check can be configured in LD 73.)

In tracking mode, at any one time, there is one active clock controller which is tracking on one reference clock. If a clock-controller error is detected, the system switches to the back-up clock controller, without affecting which reference clock is being tracked.

A reference-clock error occurs when there is a problem with the clock driver or with the reference clock at the far end. If the clock controller detects a reference-clock error, the reference clocks are switched.

Automatic clock recovery

A command for automatic clock recovery can be selected in LD 60 with the command EREF.

A PRI loop is disabled when it enters a local-alarm condition. If the local alarm is cleared, the loop is enabled automatically. When the loop is enabled, clock tracking is restored in the following conditions:

1. If the loop is assigned as the primary reference clock but the clock controller is tracking on the secondary reference or in free-run mode, it is restored to tracking on primary.
2. If the loop is assigned as the secondary reference clock but the clock controller is in free-run mode, it is restored to tracking on secondary.

If the clock check indicates the switch is in free-run mode:

1. Tracking is restored to the primary reference clock if defined.
2. If the primary reference is disabled or in local alarm, tracking is restored to the secondary reference clock if defined.

Note:

If the switch is put into free-run mode by the craftsperson, it resumes tracking on a reference clock unless the clock-switching option is disabled (LD 60, command MREF), or the reference clock is "undefined" in the database.

Automatic clock switching

If the EREF command is selected in LD 60, tracking on the primary or secondary reference clock is automatically switched in the following manner:

1. If software is unable to track on the assigned primary reference clock, it switches to the secondary reference clock and sends appropriate DTC maintenance messages.
2. If software is unable to track on the assigned secondary reference clock, it switches to free run.

QPC720 PRI

The QPC720 PRI card is required for PRI operation in all machine types.


Power requirements

The QPC720 PRI uses power and ground from the backplane. This card does not require an intelligent bus. Power requirements are:

- +5 volts at 6 amperes
- +12 volts at 50 milliamperes
- -12 volts at 50 milliamperes

QPC720 faceplate

QPC720 PRI contains five LEDs and six external connectors. [Figure 7: QPC720 PRI faceplate layout](#) on page 36 shows the QPC720 PRI faceplate layout. [Table 4: QPC720 PRI external connectors](#) on page 36 gives information about the external connectors located on the QPC720 PRI faceplate.



553-AAA0084

Figure 7: QPC720 PRI faceplate layout

Table 4: QPC720 PRI external connectors

| Faceplate destination | Type |
|-----------------------|----------------------------|
| J1 | 9-pin female, D-connector |
| J2 | 9-pin female, D-connector |
| J3 | 36-pin connector |
| J4 | 15-pin male, D-connector |
| J5 | 15-pin male, D-connector |
| J6 | 15-pin female, D-connector |
| RCV MON | Miniature bantam jack |
| XMT MON | Miniature bantam jack |

QPC720 Cable requirements

[Table 5: QPC720 PRI cables and cable lengths](#) on page 38 lists the types of cable used and the lengths required for external QPC720 PRI connections.

 **Note:**

No additional cabling is required for nB+D configurations. Multiple PRIs and the D-channel are associated through software in LD 17, prompt PRI.

Carrier interface

The QPC720 PRI provides an interface to the DS-1 Channel either directly, through an office repeater, or through an Echo Cancellor.

The T1 Channel Service Units listed below are compatible with the QPC720 PRI card and the 64K Clear Data feature as well as with PRI connection parameters such as the Superframe format, the Extended superframe format, and the B7 and B8ZS Alternate Mark Inversion (AMI) line coding.

- Digital Link 551A
- Digital Link 551C
- Digital Link 551E
- Tellabs Model 441
- Verilink Model 551V ST

In the U.S.A., FCC Part 68 regulations require Network Channel Terminating Equipment (for example, the NT QRY551 Channel Service Unit) installed at of the point of connection between a system and a registered common carrier trunk.

Echo Cancellor interface

Echo Cancellers are required only with satellite transmission. The Echo Cancellor detects the length of the loop, then cancels the reflected transmission (callers do not hear their own voices echoed).

The QPC720 PRI provides both a T1 line interface and a control interface to link to a signal format compatible with EIA standard RS-232-C. Both the PRI and the Echo Cancellor act as Data Terminal Equipment (DTE). The Echo Cancellor's control protocol must conform to that of the Tellabs Model 251.

64 T-link version 2 protocol

The QPC720 card supports the 64 T-link version 2 protocol. The QPC720 together with the QMT21 High Speed Data Module supports the 64K Clear Data feature. The QPC720 card provides a trunk that ties two switches together. This trunk allows 64K eClear Data to pass from the system to an outside network. The QMT21 module allows Data Terminal Equipment (DTE) to send and receive 64K Clear Data. See *Meridian Link ISDN/AP General Guide (553-2901-100)* for more information about the 64K Clear Data feature.

Table 5: QPC720 PRI cables and cable lengths

| Cable type | From | To | Maximum length (feet) | Maximum length (meters) |
|------------|----------------|----------------------|-----------------------|-------------------------|
| QCAD130 | QPC720 | QPC471/QPC775 (CC-0) | 7 | 2.13 |
| QCAD130 | QPC720 | QPC471/QPC775 (CC-1) | 7 | 2.13 |
| QCAD328A | QPC720 | QPC757 DCHI | 6 | 1.8 |
| QCAD328B | QPC720 | QPC757 DCHI | 18 | 5.5 |
| QCAD328C | QPC720 | QPC757 DCHI | 35 | 10.67 |
| QCAD328D | QPC720 | QPC757 DCHI | 50 | 15.24 |
| QCAD124 | QPC720 | QPC414 Network | 50 | 15.24 |
| QCAD128 | QPC720 | Bulkhead I/O panel | 25 | 7.62 |
| RS-232 | QPC720 | Echo Canceller | 50 | 15.24 |
| NTND26AA | QPC720 | NT6D80 MSDL | 6 | 1.8 |
| NTND26AB | QPC720 | NT6D80 MSDL | 18 | 5.5 |
| NTND26AC | QPC720 | NT6D80 MSDL | 35 | 10.67 |
| NTND26AD | QPC720 | NT6D80 MSDL | 50 | 15.24 |
| NTND98 | QPC720 | Input/output panel | 6 | 1.8 |
| 22AWG ABAM | Echo Canceller | DSX-1 | 655 | 199.64 |

 **Note:**

The QPC775 Clock Controller is not available in the U.S.A. There can be no mixing of QPC775 and QPC471 in one system.

Disk drive hardware

The following hardware is required for Large System upgrades:

- 3.5-inch disk drive unit
- disk drive controller for above
- cable for above

NT5D97 Dual-port DTI2/PRI2 card

The NT5D97 is a dual-port 2.0 Mb DTI2/PRI2 card (the DDP2 firmware functions in DTI2 or PRI2 mode, depending on DIP switch settings) that integrates the functionality of two NT8D72BA PRI2 cards, and one QPC414 ENET card into a single CE card. The NT5D97 occupies a single slot in the Network shelf and provides two DTI2/PRI2 network connections: an interface to an external D-Channel Handler (the NT6D11AF) or the NT6D80 Multipurpose Serial Data Link card, and an optional plug-on NTBK51AA/NTBK51CA Downloadable D-Channel daughterboard (DDCH) with two DCH interface ports.

The NT5D97 DDP2 card can be mixed in the same machine with PRI2 NT8D72BA cards.

The NT5D97 DDP2 card hardware design uses a B57 ASIC E1/T1 framer. The carrier specifications comply with the ANSI T1.403 specification. The NT5D97 provides an interface to the 2.048 Mbps external digital line either directly or through an office repeater, Network Channel Terminating Equipment (NCTE), or Line Terminating Unit (LTU).



Voltage:

DANGER OF ELECTRIC SHOCK

The NT5D97 DDP2 card is not designed to be connected directly to the Public Switched Network, or other exposed plant networks. Such a connection should only be done using an isolating-type networking terminating device that provides voltage surge protection, such as a Line Terminating Unit (LTU), Network Channel Terminating Equipment (NCTE), or Network Termination 1 (NT1), as certified by your local, regional, or national safety agency and telecommunications authority.

External D-Channel Interface DCH or MSDL

The connection between the DDP2 card and the external DCH or MSDL is through a 26 pin female D type connector. The data signals conform to the electrical characteristics of the EIA standard RS-422.

Two control signals are used to communicate the D-channel link status to the DCH or MSDL. These are:

- Receiver Ready (RR), originating at the DDP2 card, to indicate to the DCH or MSDL that the D-channel link is operational.
- Transmitter Ready (TR), originating at the DCH or MSDL, to indicate to the DDP2 card that the DCH are ready to use the D-channel link.

[Table 6: DCH/MSDL Receiver Ready control signals](#) on page 40 indicates how the RR control signal operates with regard to the DDP2 status.

Table 6: DCH/MSDL Receiver Ready control signals

| RR State | Condition |
|----------|---|
| ON | D-Channel data rate selected at 64 Kbps and PRI2 loop is enabled and PRI2 link is not in OOS or Local Alarm mode state and PRI2 link is not transmitting a Remote Alarm pattern and PRI2 link is not receiving a Remote Alarm Indication from a remote facility |
| OFF | All other conditions |

NT5D97 faceplate

[Figure 8: NT5D97 faceplate](#) on page 41 illustrates the faceplate layout for the NT5D97 DDP card. The faceplate contains an enable/disable switch; a DDCH status LED; 6 x 2 trunk port status LEDs; and six external connectors. [Table 7: External connectors and LEDs](#) on page 41 shows the name of each connector, its designation with respect to the faceplate and the name and description of the card it is connected to. Also shown are the names of the LEDs.




Figure 8: NT5D97 faceplate

Table 7: External connectors and LEDs

| Function | Faceplate Designator | Type | Description |
|------------|----------------------|------------------------|---|
| Switch | ENB/DIS | Plastic, ESD protected | Card Enable/disable switch |
| Connectors | Unit 0 Clock 0 | RJ11 Connector | Connects reference clock 0 to Clock Controller card 0 |

| Function | Faceplate Designator | Type | Description |
|----------|----------------------|---------------------------|---|
| | Unit 0 Clock 1 | RJ11 Connector | Connects reference clock 0 to Clock Controller card 1 |
| | Unit 1 Clock 0 | RJ11 Connector | Connects reference clock 1 to Clock Controller card 0 |
| | Unit 1 Clock 1 | RJ11 Connector | Connects reference clock 1 to Clock Controller card 1 |
| | J5 TRK | 9 Pin Female D Connector | Two external E1 Trunk 0 and Trunk 1 |
| | J6 DCH | 26 Pin Female D Connector | Connects to external DCH or MSDL |
| LEDs | ENET | 2 Red LEDs | ENET 0 or ENET 1 is disabled |
| | DIS | 2 Red LEDs | Trunk 0 or Trunk 1 is disabled |
| | OOS | 2 Yellow LEDs | Trunk is out of service |
| | NEA | 2 Yellow LEDs | Local (Near End) Alarm |
| | FEA | 2 Yellow LEDs | Far End Alarm |
| | LBK | 2 Yellow LEDs | Loop Back test being performed on Trunk 0 or Trunk 1 |
| | DCH | Bicolor Red/Green LED | NTBK51AA/ NTBK51CA status |

The following is a brief description of each element on the faceplate.

Enable/Disable Switch

This switch is used to disable the card prior to insertion or removal from the network shelf. While this switch is in disable position, the card does not respond to the system CPU.

ENET LEDs

Two red LEDs indicate if the "ENET0" and "ENET1" portions of the card are disabled. These LEDs are lit in the following cases:

- When the enable/disable switch is in disabled state (lit by hardware).
- After power-up, before the card is enabled.
- When the ENET port on the card is disabled by software.

Trunk Disable (DIS) LEDs

Two red LEDs indicate if the "trunk port 0" or "trunk port 1" portions of the card are disabled. These LEDs are lit in the following cases:

- upon reception of the "disable loop" message from the software
- after power-up

OOS LEDs

Two yellow LEDs indicate if the "trunk port 0" and "trunk port 1" portions of the card are out-of-service.

NEA LEDs

Two yellow LEDs indicate if the near end detects absence of incoming signal or loss of synchronization in "trunk port 0" or "trunk port 1" respectively. The Near End Alarm causes a Far End Alarm signal to be transmitted to the far end.

FEA LEDs

Two yellow LEDs indicate if a Far End Alarm is reported by the far end (usually in response to a Near End Alarm condition at the far end) on "trunk port 0" or "trunk port 1".

LBK LEDs

Two yellow LEDs indicate if a remote loopback test is being performed on trunk port 0 or trunk port 1. The loopback indication is active when the digital trunk is in remote loopback mode. Normal call processing is inhibited during the remote loopback test.

DCH LED

When the dual colored LED is red, it indicates the onboard DDCH is present but disabled.
When the dual colored LED is green, it indicates the onboard DDCH is present and enabled.
If a DDCH is not configured on the DDP2 card, this lamp is not lit.

Unit 0 Clk Connectors

Two RJ11 connectors for connecting:

- Digital trunk unit 0 recovered clock to primary or secondary reference source on clock controller card 0.
- Digital trunk unit 0 recovered clock to primary or secondary reference source on clock controller card 1.

Unit 1 Clk Connectors

Two RJ11 connectors for connecting:

- Digital trunk unit 1 recovered clock to primary or secondary reference source on clock controller card 0.
- Digital trunk unit 1 recovered clock to primary or secondary reference source on clock controller card 1.

Connector J5 (TRK)

A 9 pin D-Type connector used to connect:

- Digital trunk unit 0 receive and transmit Tip / Ring pairs
- Digital trunk unit 1 receive and transmit Tip / Ring pairs

Connector J6 (DCH)

A 26-pin D-type connector is used to connect the DDP2 card to the external MSDL or D-channel handler.

System capacity and performance

Physical capacity

Each NT5D97 DDP2 card occupies one slot on the network shelf. Each card supports two digital trunk circuits and two network loops. The total number of DDP2 cards per system is limited by the number of network loops, physical capacity of the shelf, number of DTI2/PRI2 interfaces allowed by the software and the range of DCH addresses.

D-Channel capacity

The software configuration for the NTBK51AA/NTBK51CA DDCH is similar to the MSDL and only supports D-channel functionality.

The system has a total capacity of 16 addresses (Device Addresses or DNUM) that can be reserved for DCH card, MSDL card or DDCH card. One exception is DNUM 0 which is commonly assigned to the TTY terminal.

No two different D-Channel providers can share the same DNUM. Hence, the combined maximum number of DCH, MSDL and DDCH cards in the system is 16.

The DCH has one D-Channel unit, the DDCH has two D-Channel units, and the MSDL has a maximum of four units. Therefore, the total number of D-Channel is derived by the following formula:

$$\text{Total_Num_DCH-Units} = \text{Num_DCHx1} + \text{Num_DDCHx2} + \text{Num_MSDLx4}$$

Therefore, Total_Num_DCH-Units in any given system is between 0-63.

CPU capacity

Using a NT5D97 DDP2 card instead of DTI2/PRI2 cards does not increase the load on the system CPU. The DDP2 replaces an ENET card and two DTI2/PRI2 cards. Emulating the ENET card and the overall CPU capacity is not impacted by using a DDP2 card instead of a DTI2/PRI2 card.

Power requirements

[Table 8: NT5D97 DDP2 power requirements](#) on page 46 lists the power requirements for the NT5D97 DDP2 card.

Table 8: NT5D97 DDP2 power requirements

| Voltage | Source | Current | |
|-----------------------|-----------|----------------------------------|-------------------------------|
| | | DDP2 (without NTBK51AA/NTBK51CA) | DDP2 (with NTBK51AA/NTBK51CA) |
| +5V | Backplane | 3A | 3.8A |
| +12V | Backplane | 25mA | 75mA |
| -12V | Backplane | 25mA | 75mA |
| Total Power (Maximum) | | 15.6W | 20.8W |

Testability and diagnostics

The DDP2 card supports testing and maintenance functions through the following procedures:

- Self test upon power up or reset
- Signalling test performed in the LD 30
- Loopback tests, self tests, and continuity tests performed by LD 60 and LD 45
- The D-Channel (DCH, MSDL, DDCH) maintenance is supported by LD 96.

 **Note:**

The MSDL selftest is not applicable to the NTBK51AA/NTBK51CA D-Channel daughterboard.

Cable requirements

This section lists the types of cable used and the lengths required for internal and external NT5D97 DDP2 connections.

 **Note:**

No additional cabling is required for nB+D configurations. Multiple DDP2 cards and the D-channel are associated through software in LD 17.

DDP2 cable assemblies include:

- E1 carrier cables
 - NTCK45AA (A0407956)
 - NT8D7217 (A0617192)
 - NTCK78AA (A0618294)

- NTCK79AA (A0618296)
- DDP2 to QPC471/QPC775 Clock Controller Cables
 - NTCG03AA
 - NTCG03AB
 - NTCG03AC
 - NTCG03AD
- DDP2 to DCH cables
 - NTCK46AA
 - NTCK46AB
 - NTCK46AC
 - NTCK46AD
- DDP2 to MSDL cables
 - NTCK80AA
 - NTCK80AB
 - NTCK80AC
 - NTCK80AD

A description of each type of DDP2 cable follows.

E1 carrier cables

NTCK45AA (A0407956)

The NTCK45AA (8 ft.) is an 120W cable for systems equipped with an I/O filter panel, connecting the TRK port (P1, D-type 9 pin male) on the DDP2 faceplate to the I/O filter (P2, P3 D-type 9 pin males).




Figure 9: NTCK45AA

[Table 9: NTCK45AA cable pins](#) on page 48 lists the pin attributes for the NTCK45AA cable.

Table 9: NTCK45AA cable pins

| Cable | Name | Description | Color | DDP2 pins | I/O Panel pins |
|-------|----------|-----------------------|-------|-----------|----------------|
| 0 | T-PRI0TX | Trunk 0 Transmit Tip | Black | P1-1 | P2-6 |
| 0 | R-PRI0TX | Trunk 0 Transmit Ring | Red | P2-2 | P2-7 |
| 0 | T-PRI0RX | Trunk 0 Receive Tip | Black | P1-3 | P2-2 |
| 0 | R-PRI0RX | Trunk 0 Receive Ring | White | P1-4 | P2-3 |
| 0 | | GND Shield Wire | Bare | N/C | Case P2 |
| 0 | | GND Shield Wire | Bare | N/C | Case P2 |
| 0 | | Standard Wire (3") | Bare | Case P2 | P2-5 |
| 0 | | Standard Wire (3") | Bare | Case P2 | P2-9 |
| 1 | T-PRI1TX | Trunk 1 Transmit Tip | Black | P1-5 | P3-6 |
| 1 | R-PRI1TX | Trunk 1 Transmit Ring | Red | P1-6 | P3-7 |
| 1 | T-PRI1RX | Trunk 1 Receive Tip | Black | P1-7 | P3-2 |
| 1 | R-PRI1RX | Trunk 1 Receive Ring | White | P1-8 | P3-3 |
| 1 | | GND Shield Wire | Bare | N/C | Case P3 |
| 1 | | GND Shield Wire | Bare | N/C | Case P3 |
| 1 | | Standard Wire (3") | Bare | Case P3 | P3-5 |
| 1 | | Standard Wire (3") | Bare | Case P3 | P3-9 |

NT8D7217 (A0617192)

The NT8D7217 (50 ft.) is a 120W cable for systems equipped with an I/O filter panel, connecting the 9 pin I/O filter connector to the 9 pin NCTE connector.



Figure 10: NT8D7217

[Table 10: NT8D7217 cable pins](#) on page 48 which follows lists the pin attributes for the NT8D7217 cable.

Table 10: NT8D7217 cable pins

| Cable | Name | Description | Color | DDP2 pins | I/O Panel pins |
|-------|----------|----------------------|-------|-----------|----------------|
| 0 | T-PRI0TX | Trunk 0 Transmit Tip | Black | P1-6 | P2-6 |

| Cable | Name | Description | Color | DDP2 pins | I/O Panel pins |
|-------|----------|-----------------------|-------|-----------|----------------|
| 0 | R-PRI0TX | Trunk 0 Transmit Ring | White | P1-7 | P2-7 |
| 0 | T-PRI0RX | Trunk 0 Receive Tip | Black | P1-2 | P2-2 |
| 0 | R-PRI0RX | Trunk 0 Receive Ring | Red | P1-3 | P2-3 |
| 0 | | GND Shield Wire | Bare | P1-5 | N/C |
| 0 | | GND Shield Wire | Bare | P1-9 | N/C |
| 1 | T-PRI1TX | Trunk 1 Transmit Tip | Black | P1-6 | P2-6 |
| 1 | R-PRI1TX | Trunk 1 Transmit Ring | White | P1-7 | P2-7 |
| 1 | T-PRI1RX | Trunk 1 Receive Tip | Black | P1-2 | P2-2 |
| 1 | R-PRI1RX | Trunk 1 Receive Ring | Red | P1-3 | P2-3 |
| 1 | | GND Shield Wire | Bare | P1-5 | N/C |
| 1 | | GND Shield Wire | Bare | P1-9 | N/C |

NTCK78AA (A0618294)

The NTCK78AA (50 ft.) is a 120W cable for connecting the TRK port on the DDP2 faceplate (P1, D-type 9 pin male) to the Main Distribution Frame (MDF) (P2, P3 D-type 15-pin males). The NTCK78AA is used for systems not equipped with an I/O filter panel.




Figure 11: NTCK78AA

[Table 11: NTCK78AA cable pins](#) on page 49 lists the pin attributes for the NTCK78AA cable.


Table 11: NTCK78AA cable pins

| Cable | Name | Description | Color | DDP2 pins | NCTE pins |
|-------|----------|-----------------------|-------|-----------|-----------|
| 0 | T-PRI0TX | Trunk 0 Transmit Tip | Black | P1-1 | P2-1 |
| 0 | R-PRI0TX | Trunk 0 Transmit Ring | Red | P1-2 | P2-9 |
| 0 | T-PRI0RX | Trunk 0 Receive Tip | Black | P1-3 | P2-3 |
| 0 | R-PRI0RX | Trunk 0 Receive Ring | White | P1-4 | P2-11 |
| 0 | | GND Shield Wire | Bare | P1 Case | P2-2 |
| 0 | | GND Shield Wire | Bare | P1 Case | P2-4 |

| Cable | Name | Description | Color | DDP2 pins | NCTE pins |
|-------|----------|-----------------------|-------|-----------|-----------|
| 1 | T-PRI1TX | Trunk 1 Transmit Tip | Black | P1-5 | P3-1 |
| 1 | R-PRI1TX | Trunk 1 Transmit Ring | Red | P1-6 | P3-9 |
| 1 | T-PRI1RX | Trunk 1 Receive Tip | Black | P1-7 | P3-3 |
| 1 | R-PRI1RX | Trunk 1 Receive Ring | White | P1-8 | P3-11 |
| 1 | | GND Shield Wire | Bare | P1 Case | P3-2 |
| 1 | | GND Shield Wire | Bare | P1 Case | P3-4 |

NTCK79AA (A0618296)

The NTCK79AA (40 ft) is a 75W coaxial cable for connecting the TRK port on the DDP2 faceplate (P1, D-type 9 pin male) to the Line Terminating Unit (LTU) (P2, P3, P4, P5 BNC males).



553-7388

Figure 12: NTCK79AA

[Table 12: NTCK79AA cable pins](#) on page 50 lists the pin attributes for the NTCK79AA cable.


Table 12: NTCK79AA cable pins

| Cable | Name | Description | Color | DDP2 pins | NCTE pins |
|-------|----------|-----------------------|-------|-----------|--------------------|
| 0 | T-PRI0TX | Trunk 0 Transmit Tip | Red | P1-1 | P2 inner conductor |
| 0 | R-PRI0TX | Trunk 0 Transmit Ring | Red | P1-2 | P2 shield |
| 0 | T-PRI0RX | Trunk 0 Receive Tip | Green | P1-3 | P3 inner conductor |
| 0 | R-PRI0RX | Trunk 0 Receive Ring | Green | P1-4 | P3 shield |
| 1 | T-PRI1TX | Trunk 1 Transmit Tip | Red | P1-5 | P4 inner conductor |
| 1 | R-PRI1TX | Trunk 1 Transmit Ring | Red | P1-6 | P4 shield |
| 1 | T-PRI1RX | Trunk 1 Receive Tip | Green | P1-7 | P5 inner conductor |
| 1 | R-PRI1RX | Trunk 1 Receive Ring | Green | P1-8 | P5 shield |

| Cable | Name | Description | Color | DDP2 pins | NCTE pins |
|-------|------|----------------------------|-------|-----------|-----------|
| 1 | | Outer metalized PVC shield | Bare | N/C | P1 Case |
| 1 | | 3 stranded wire | Bare | N/C | P1 Case |

Reference clock cables

The NTCG03AA (14 ft), NTCG03AB (2.8 ft), NTCG03AC (4.0 ft), or NTCG03AD (7 ft), is a DDP2 card to Clock Controller cable, connecting each of the CLK0 or CLK1 ports on the DDP2 faceplate to the primary or secondary source ports on Clock Controller card 0 or 1.



Connector P1 - 4 pin, male, RJ11 (DDP2 faceplate)
 Connector P2 - 9 pin, male, D-type (Clock Controller)

Note: Includes a 9 pin D-type adaptor.

553-7384

Figure 13: NTCG03AA/AB/AC/AD

MSDL/DCH cables

External DCH cable

The NTCK46 cable connects the DDP2 card to the NT6D11AF/NT5K75AA/NT5K35AA D-Channel Handler card. The cable is available in four different sizes:

- NTCK46AA (6 ft.) - DDP2 to DCH cable
- NTCK46AB (18 ft.) - DDP2 to DCH cable
- NTCK46AC (35 ft.) - DDP2 to DCH cable
- NTCK46AD (50 ft.) - DDP2 to DCH cable




Figure 14: NTCK46AA/AB/AC/AD

External MSDL cable

The NTCK80 cable connects the DDP2 card to the NT6D80 MSDL card. The cable is available in four different sizes:

- NTCK80AA (6 ft) - DDP2 to MSDL cable
- NTCK80AB (18 ft) - DDP2 to MSDL cable
- NTCK80AC (35 ft) - DDP2 to MSDL cable
- NTCK80AD (50 ft) - DDP2 to MSDL cable




Figure 15: NTCK80AA/AB/AC/AD

Cable diagrams


[Figure 16: DDP2 cable for systems with an I/O panel](#) on page 53 and [Figure 17: DDP2 cable for systems without an I/O panel](#) on page 54 provide examples of typical cabling configurations for the DDP2.

[Figure 16: DDP2 cable for systems with an I/O panel](#) on page 53 shows a typical DDP2 cabling for a system with an I/O panel, with the connection between the I/O panel and a Network Channel Terminating Equipment (NCTE).

[Figure 17: DDP2 cable for systems without an I/O panel](#) on page 54 shows cabling for a system without an I/O panel. Here, the DDP2 faceplate is cabled directly to the NCTE.


 **Note:**

Because there exists several clock cabling options, none is represented in the diagrams. Refer to [Clock configurations](#) on page 57 for a description on each available option.



553-AAA1104

Figure 16: DDP2 cable for systems with an I/O panel



553-7400

Figure 17: DDP2 cable for systems without an I/O panel

Clock for the NT5D97

Clock operation

There are two types of clock operation — tracking mode and free-run mode.

Tracking mode

In tracking mode, the DDP2 loop supplies an external clock reference to a clock controller. Two DDP2 loops can operate in tracking mode, with one defined as the primary reference source for clock synchronization, the other defined as the secondary reference source. The secondary reference acts as a back-up to the primary reference.

As shown in [Figure 18: Clock Controller primary and secondary tracking](#) on page 55, a system with dual CPUs can have two clock controllers (CC-0 and CC-1). One clock controller acts as a back-up to the other. The clock controllers should be completely locked to the reference clock.




Figure 18: Clock Controller primary and secondary tracking

Free run (non-tracking) mode

The clock synchronization of the system can operate in free-run mode if:

- no loop is defined as the primary or secondary clock reference,
- the primary and secondary references are disabled, or
- the primary and secondary references are in local (near end) alarm

Reference clock errors

The system software checks at intervals of 1 to 15 minutes to see if a clock controller or reference-clock error is occurred. (The interval of this check can be configured in LD 73).

In tracking mode, at any one time, there is one active clock controller which is tracking on one reference clock. If a clock controller error is detected, the system switches to the back-up clock controller, without affecting which reference clock is being tracked.

A reference-clock error occurs when there is a problem with the clock driver or with the reference clock at the far end. If the clock controller detects a reference-clock error, the reference clocks are switched.

Automatic clock recovery

A command for automatic clock recovery can be selected in LD 60 with the command EREF.

A DDP2 loop is disabled when it enters a local-alarm condition. If the local alarm is cleared, the loop is enabled automatically. When the loop is enabled, clock tracking is restored in the following conditions:

- If the loop is assigned as the primary reference clock but the clock controller is tracking on the secondary reference or in free-run mode, it is restored to tracking on primary.
- If the loop is assigned as the secondary reference clock but the clock controller is in free-run mode, it is restored to tracking on secondary.
- If the clock check indicates the switch is in free-run mode:
 - Tracking is restored to the primary reference clock if defined.
 - If the primary reference is disabled or in local alarm, tracking is restored to the secondary reference clock if defined.

Note:

If the system is put into free-run mode by the craftsperson, it resumes tracking on a reference clock unless the clock-switching option is disabled (LD 60, command MREF), or the reference clock is "undefined" in the database.

Automatic clock switching

If the EREF command is selected in LD 60, tracking on the primary or secondary reference clock is automatically switched in the following manner:

- If software is unable to track on the assigned primary reference clock, it switches to the secondary reference clock and sends appropriate DTC maintenance messages.
- If software is unable to track on the assigned secondary reference clock, it switches to free run.

Clock configurations

Clock Controllers can be used in a single or a dual CPU system.

A single CPU system has one Clock Controller card. This card can receive reference clocks from two sources referred to as the primary and secondary sources. These two sources can originate from a PRI2, DTI2, etc. PRI2 cards such as the NT8D72BA are capable of supplying two references of the same clock source. These are known as Ref1 (available at J1) and Ref2 (available at J2) on the NT8D72BA.

The NT5D12 card is capable of supplying two references from each clock source, i.e., four references in total. NT5D12 can supply Clk0 and Clk1 from Unit 0 and Clk0 and Clk1 from Unit 1. Either Unit 0 or Unit 1 can originate primary source, as shown in [Figure 19: Clock Controller - Option 1](#) on page 59 through [Figure 22: Clock Controller - Option 4](#) on page 62 on pages [Figure 18: Clock Controller primary and secondary tracking](#) on page 55 to [Figure 22: Clock Controller - Option 4](#) on page 62.

There is one Clock Controller cable required for the DDP2 card, which is available in four sizes; this is the NTCG03AA/AB/AC/AD. Refer to [Reference clock cables](#) on page 51 for more information.

[Table 13: Clock Controller options - summary](#) on page 57 summarizes the clocking options. [Table 14: Clock Controller options - description](#) on page 58 explains the options in more detail.


Table 13: Clock Controller options - summary

| CC Option | CPU Type | Notes |
|-----------|----------|--|
| Option 1 | Single | Ref from P0 on Clk0 Ref from P1 on Clk0 |
| Option 2 | Dual | Ref from P0 on Clk0 Ref from P0 on Clk1 |
| Option 3 | Dual | Ref from P1 on Clk0 Ref from P1 on Clk1 |
| Option 4 | Dual | Ref from P0 on Clk0 |

| CC Option | CPU Type | Notes |
|-----------|----------|---|
| | | Ref from P0 on Clk1 Ref from P1 on Clk0 Ref from P1 on Clk1 |

Table 14: Clock Controller options - description

| Clock Option | Notes |
|--------------|---|
| Option 1 | This option provides a single CPU system with 2 clock sources derived from the 2 ports of the DDP2. Connector Clk0 provides a clock source from Unit 0. Connector Clk1 provides a clock source from Unit 1. Refer to Figure 19: Clock Controller - Option 1 on page 59. |
| Option 2 | This option provides a Dual CPU system with 2 references of a clock source derived from port 0 of the DDP2. Connector Clk0 provides a Ref 1 clock source from Unit 0. Connector Clk1 provides a Ref 2 clock source from Unit 0. Refer to Figure 20: Clock Controller - Option 2 on page 60 |
| Option 3 | This option provides a Dual CPU system with 2 references of a clock source derived from port 1 of the DDP2. Connector Clk0 provides a Ref 1 clock source from Unit 1. Connector Clk1 provides a Ref 2 clock source from Unit 1. Refer to Figure 21: Clock Controller - Option 3 on page 61 |
| Option 4 | This option provides a Dual CPU system with 2 references from each clock source derived from the DDP2. Connector Clk0 provides a Ref 1 clock source from Unit 0. Connector Clk1 provides a Ref 2 clock source from Unit 0. Connector Clk0 provides a Ref 1 clock source from Unit 1. Connector Clk1 provides a Ref 2 clock source from Unit 1. Refer to Figure 22: Clock Controller - Option 4 on page 62. |



553-7401

Figure 19: Clock Controller - Option 1




Figure 20: Clock Controller - Option 2




Figure 21: Clock Controller - Option 3




Figure 22: Clock Controller - Option 4

NT5D12 Dual-port DTI/PRI

The NT5D12 is a dual-port 1.5 DTI/PRI card (the DDP firmware functions in DTI or PRI mode) integrating the functionality of two QPC472 DTI/DDP2 PRI cards and one QPC414 ENET into one card. The NT5D12 occupies a single Network shelf slot and provides two DTI/PRI network connections, an optional connection to an external D-Channel Handler, the QPC757 D-Channel Handler Interface (DCHI) or NT6D80 Multipurpose Serial Data Link (MSDL), and an optional plug-on NTBK51AA/NTBK51CA Downloadable D-Channel daughterboard (DDCH.)

The NT5D12 DDP card supports all features (except the echo canceller and protocol conversion) of the QPC720. In addition, it maintains the backward compatibility of QPC720.

The NT5D12 DDP card hardware design uses a B57 ASIC E1/T1 framer. The carrier specifications comply with the ANSI T1.403 specification. The NT5D12 provides an interface to the 1.5 Mb external digital line either directly or through an office repeater, Line Terminating Unit (LTU), or Channel Service Unit (CSU).

D-Channel and MSDL interface

The connection between the DDP card and the DCHI or MSDL is via a 26 pin female D type connector. The data signals conform to the electrical characteristics of the EIA standard RS-422.

Two control signals are used to communicate the D-Channel link status to the DCHI or MSDL. These are:

- Receiver Ready (RR), originating at the DDP card, to indicate to the DCHI or MSDL that the D-channel link is operational.
- Transmitter Ready (TR), originating at the DCHI or MSDL, to indicate to the DDP card that the DCHI or MSDL are ready to use the D-Channel link.

[Table 15: DCHI/MSDL Receiver Ready control signals](#) on page 63 indicates how the RR control signal operates with regard to the DDP status.

Table 15: DCHI/MSDL Receiver Ready control signals

| RR State | Condition |
|----------|--|
| ON | D-Channel data rate selected at 64 Kbps or 56 Kbps or 64 Kbps inverted and PRI loop is enabled and PRI link is not in RED alarm mode state and PRI link is not transmitting a yellow alarm pattern and PRI link is not receiving a Remote Alarm Indication from the remote facility and PRI link is not in FA3 mode and Transmitter Ready (TR) control signal from the DCHI/MSDL is ON |
| OFF | All other conditions |

NT5D12 faceplate

[Figure 23: NT5D12 faceplate - general view](#) on page 64 and [Figure 24: DDP faceplate - detailed view](#) on page 65 illustrate the faceplate layout for the NT5D12 DDP card. The faceplate contains an enable/disable switch; a DDCH status LED; 6 x 2 trunk port status LEDs; and six external connectors. [Table 7: External connectors and LEDs](#) on page 41 shows the name of each connector, its designation with respect to the faceplate and the name and description of the card it is connected to. Also shown are the names of the LEDs.




Figure 23: NT5D12 faceplate - general view




Figure 24: DDP faceplate - detailed view

Table 16: External connectors and LEDs

| Function | Faceplate Designator | Type | Description |
|------------|----------------------|------------------------|---|
| Switch | ENB/DIS | Plastic, ESD protected | Card Enable/disable switch |
| Connectors | Port 0 Clock 0 | RJ11 Connector | Connects reference clock to Clock Controller card |

| Function | Faceplate Designator | Type | Description |
|----------|----------------------|---------------------------|--|
| | Port 0 Clock 1 | RJ11 Connector | Connects reference clock to Clock Controller card |
| | Port 1 Clock 0 | RJ11 Connector | Connects reference clock to Clock Controller card |
| | Port 1 Clock 1 | RJ11 Connector | Connects reference clock to Clock Controller card |
| | J5 TRK | 9 Pin Female D Connector | Two external DS-1 Trunk 0 and Trunk 1 |
| | J6 DCH | 26 Pin Female D Connector | Connects to DCHI or MSDL |
| | OOS | 2 Red LEDs | ENET 0 or ENET 1 disabled |
| | DIS | 2 Red LEDs | Trunk 0 or Trunk 1 disabled |
| | ACT | 2 Green LEDs | Trunk 0 or Trunk 1 lines active |
| | RED | 2 Red LEDs | Red Alarm on Trunk 0 or Trunk 1 |
| LEDs | YEL | 2 Yellow LEDs | Yellow Alarm on Trunk 0 or Trunk 1 |
| | LBK | 2 Green LEDs | Loop Back test being performed on Trunk 0 or Trunk 1 |
| | DCH | Bicolor Red/Green LED | NTBK51AA/NTBK51CA status |

The following is a brief description of each element on the faceplate:

Enable/Disable Switch

This switch is used to disable the card prior to insertion or removal from the network shelf; while this switch is in disable position, the card does not respond to system CPU.

Port Out of Service LEDs

Two red LEDs indicate if the "ENET0" and "ENET1" portion of the card are disabled. These LEDs are lit in the following cases:

- When the enable/disable switch is in state disable (lit by hardware)
- After power-up, before the card is enabled
- When the ENET port on the card is disabled by software.

Trunk Port Disable LEDs

Two red LEDs indicate if the "trunk port 0" and "trunk port 1" portion of the card are disabled. These LEDs are turned on in the following cases:

- When the enable/disable switch is in state disable (lit by hardware).
- After power-up, before the card is enabled.
- When digital trunk interface on the card is deactivated by software.

ACT LEDs

Two green LEDs indicate if the "trunk port 0" and "trunk port 1" portion of the card is active.

RED LEDs

Two red LEDs indicate if the near end detects absence of incoming signal or loss of synchronization in "trunk port 0" or "trunk port 1" respectively. The Near End Alarm causes a Far End Alarm signal to be transmitted to the far end.

YEL LEDs

Two yellow LEDs indicate if a Far End Alarm is reported by the far end (usually in response to a Near End Alarm condition at the far end) on "trunk port 0" or "trunk port 1".

LBK LEDs

Two green LEDs indicate the remote loopback test is being performed on trunk port 0 or trunk port 1. The loopback indication is active when the digital trunk is in remote loopback mode (T1 signals received from the far end are regenerated and transmitted to the far end.) Normal call processing is inhibited during remote loopback test.

DCH LED

A dual color red/green LED indicates that the onboard DDCH is present but disabled (red), or is present and enabled (green). If a DDCH is not configured on the DDP card, this lamp is not lit.

Port 0 Clk Connectors

Two RJ11 connectors for connecting:

- Digital trunk port 0 recovered clock to primary or secondary reference source on clock controller card 0.
- Digital trunk port 0 recovered clock to primary or secondary reference source on clock controller card 1.

Port 1 Clk Connectors

Two RJ11 connectors for connecting:

- Digital trunk port 1 recovered clock to primary or secondary reference source on clock controller card 0.
- Digital trunk port 1 recovered clock to primary or secondary reference source on clock controller card 1.

Connector J5 (TRK)

A 9 pin D-Type connector used to connect:

- Digital trunk port 0 receive and transmit Tip / Ring pairs.
- Digital trunk port 1 receive and transmit Tip / Ring pairs.

Connector J6 (DCH)

A 26 pin D-type connector, used to connect the DDP card to MSDL or QPC757 external D-channel handlers.

System capacity and performance

Physical capacity

Each DDP card occupies one slot on the network shelf. It supports two digital trunk circuits and two network loops. The total number of DDP cards per system is limited by the number of network loops, physical capacity of the shelf, number of DTI/PRI interfaces allowed by the software and the range of DCH addresses.

D-Channel capacity

The software configuration for the NTBK51AA/NTBK51CA DDCH is similar to the MSDL. It is both physical and logical, and supports D-Channel functionality only.

The system has a total capacity of 16 addresses (Device Addresses or DNUM) that can be reserved for DCHI card, MSDL card or DDCH card. One exception is DNUM 0 which is commonly assigned to the System Monitor.

No two different D-Channel providers can share the same DNUM. Hence, the combined maximum number of DCHI, MSDL and DDCH cards in the system is 16.

The DCHI and DDCH have two D-Channel units, the MSDL has four. Therefore the total number of D-Channels is derived by the following formula:

$$\text{Total_Num_DCH-Units} = \text{Num_DCHI} \times 2 + \text{Num_DDCH} \times 2 + \text{Num_MSDL} \times 4$$

Therefore, Total_Num_DCH-Units in any given system is between 0-63.

CPU capacity

Using a NT512 DDP card instead of DTI/PRI cards does not increase the load on the system CPU. The DDP replaces an ENET card and two DTI/PRI cards, it emulates the ENET card and the overall CPU capacity is not impacted by usage of DDP card instead of a DTI/PRI card.

Power requirements

[Table 17: DDP power requirements](#) on page 69 lists the power requirements for the DDP card.

Table 17: DDP power requirements

| Voltage | Source | Current | |
|-----------------------|-----------|---------------------------------|------------------------------|
| | | DDP (without NTBK51AA/NTBK51CA) | DDP (with NTBK51AA/NTBK51CA) |
| +5V | Backplane | 3A | 3.8A |
| +12V | Backplane | 25mA | 75mA |
| -12V | Backplane | 25mA | 75mA |
| Total Power (Maximum) | | 15.6W | 20.8W |

Testability and diagnostics

The DDP card supports all current QPC720 testing and maintenance functions through the following procedures:

- Self test upon power up or reset;
- Signaling test performed in the LD 30;
- Loopback tests, self tests, and continuity tests performed by LD 60 and LD 45;
- The D-Channel (MSDL, DCHI, DDCH) maintenance is supported by LD 96.

NT5D12 Cable requirements

This section lists the types of cable used and the lengths required for internal and external NT5D12 DDP connections.

 **Note:**

No additional cabling is required for nB+D configurations. Multiple DDPs and the D-channel are associated through software in LD 17.

 **Note:**

A detailed discussion of each type of DDP cable listed below follows.

New DDP cable assemblies include:

- System Trunk Tip/Ring Cables
 - – NTBK66AAE5
- DDP to QPC471/QPC775 Clock Controller Cables
 - NTCG03AA
 - NTCG03AB
 - NTCG03AC
 - NTCG03AD
- DDP to DCHI cables
 - NTCK46AA
 - NTCK46AB
 - NTCK46AC

- NTCK46AD
- DDP to MSDL cables
 - NTCK80AA
 - NTCK80AB
 - NTCK80AC
 - NTCK80AD

Trunk Tip/Ring cables

NTBK66AAE5

The NTBK66AAE5 T1 Interface Cable is a replacement to the NT5D16. The NTBK66AAE5 interfaces to the J5 connector on the front of the NT5D12 Dual Port DTI/PRI DDP Card and mounts securely to the backplane of the Network module. Although the NTBK66AAE5 has been designed as a single board/single cable assembly, it functions as a dual T1 interface.

 **Note:**

On the I/O panel side, this cable is equipped with two monitor bantam plugs and two RJ45/48 connectors mounted on a small PCB. There are no bantam plugs on the DDP faceplate.




Figure 25: NTBK66AAE5 Cable assembly

NTBK66AAE5 Cable Assembly installation:

Figure 26: Connection of NTBK66AAE5 cable assembly on DDP pack



Figure 27: Connection of NTB66AAE5 cable assembly on shelf rear panel — Step 1



Position the cable assembly behind slots J22 and J23 as shown in the figure above.

Figure 28: Connection of NTB66AAE5 cable assembly on shelf rear panel — Step 2



Insert the assembly connector clip through the shelf rear panel as shown in the figure above.




Figure 29: Connection of NTBK66AAE5 cable assembly on shelf rear panel — Step 3

Ensure that the cable assembly is seated as shown in the figure above.





Figure 30: Connection of NTBK66AAE5 cable assembly on shelf rear panel — Back view

Reference clock cables

The NTCG03AA (14 ft.), NTCG03AB (2.8 ft.), NTCG03AC (4.0 ft.), or NTCG03AD (7 ft.) is a DDP card to Clock Controller cable, connecting each of the CLK0 or CLK1 ports on the DDP faceplate to the primary or secondary source ports on Clock Controller card 0 or 1.



Connector P1 - 4 pin, male, RJ11 (DDP faceplate)
Connector P2 - 9 pin, male, D-type (Clock Controller)

Note:
Includes an RJ11<-->9 pin D-type adaptor.


Figure 31: NTCG03AA, NTCG03AB, NTCG03AC, or NTCG03AD

MSDL/DCHI cables

External DCHI cable

The NTCK46 cable connects the DDP card to the QPC757 DCHI D-Channel Handler card. The cable is available in four different sizes:

- NTCK46AA (6 ft.) - DDP to DCHI cable
- NTCK46AB (18 ft.) - DDP to DCHI cable
- NTCK46AC (35 ft.) - DDP to DCHI cable
- NTCK46AD (50 ft.) - DDP to DCHI cable




Connector P1 - 26 pin, male, D-type (DDP faceplate)
Connector P2 - 25 pin, male, D-type (DCHI port 0)
Connector P3 - 25 pin, male, D-type (DCHI port 1)

Figure 32: NTCK46AA, NTCK46AB, NTCK46AC, NTCK46AD

External MSDL cable

The NTCK80 cable connects the DDP card to the NT6D80 MSDL card. The cable is available in four different sizes:

- NTCK80AA (6 ft.) - DDP to MSDL cable
- NTCK80AB (18 ft.) - DDP to MSDL cable
- NTCK80AC (35 ft.) - DDP to MSDL cable
- NTCK80AD (50 ft.) - DDP to MSDL cable



Connector P1 - 26 pin, male, D-type (DDP faceplate)
 Connector P2 - 26 pin, SCSI (MSDL port 0)
 Connector P3 - 26 pin, SCSI (MSDL port 1)

Figure 33: NTCK80AA, NTCK80AB, NTCK80AC, NTCK80AD

Cable diagrams

[Figure 34: DDP cable for systems with an I/O panel](#) on page 80 provides an example of a typical cabling configuration for the DDP. Please note that these figures are representational only, and are not intended to show the relational card slot position of the various cards.

[Figure 34: DDP cable for systems with an I/O panel](#) on page 80 shows a typical DDP cabling for a system Option with an I/O panel, with the connection between the I/O panel and a Network Channel Terminating Equipment (NCTE).

*** Note:**

Because there exists several clock cabling options, none is represented in the diagram. Please refer to [Clock configurations](#) on page 82 for a description on each available option.




Figure 34: DDP cable for systems with an I/O panel

Clock

There are two types of clock operation - tracking mode and free-run mode.

Tracking mode

In tracking mode, the DDP loop supplies an external clock reference to a clock controller. Two DDP loops can operate in tracking mode, with one defined as the primary reference source for clock synchronization, the other defined as the secondary reference source. The secondary reference acts as a back-up to the primary reference.

As shown in [Figure 35: Clock Controller primary and secondary tracking](#) on page 81, a system with dual CPUs can have two clock controllers (CC-0 and CC-1). One clock controller acts as a back-up to the other. Lock the clock controllers to the reference clock.




Figure 35: Clock Controller primary and secondary tracking

Free run (non-tracking) mode

The clock synchronization of the system can operate in free-run mode if:

- no loop is defined as the primary or secondary clock reference,
- the primary and secondary references are disabled, or
- the primary and secondary references are in local (near end) alarm.

Reference clock errors

The system software checks at intervals of 1 to 15 minutes to see if a clock controller or reference-clock error is occurred. (The interval of this check can be configured in LD 73.)

In tracking mode, at any one time, there is one active clock controller which is tracking on one reference clock. If a clock controller error is detected, the system switches to the back-up clock controller, without affecting which reference clock is being tracked.

A reference-clock error occurs when there is a problem with the clock driver or with the reference clock at the far end. If the clock controller detects a reference-clock error, the reference clocks are switched.

Automatic clock recovery

A command for automatic clock recovery can be selected in LD 60 with the command EREF.

A DDP loop is disabled when it enters a local-alarm condition. If the local alarm is cleared, the loop is enabled automatically. When the loop is enabled, clock tracking is restored in the following conditions:

- If the loop is assigned as the primary reference clock but the clock controller is tracking on the secondary reference or in free-run mode, it is restored to tracking on primary.
- If the loop is assigned as the secondary reference clock but the clock controller is in free-run mode, it is restored to tracking on secondary.
- If the clock check indicates the switch is in free-run mode:
 - Tracking is restored to the primary reference clock if defined.
 - If the primary reference is disabled or in local alarm, tracking is restored to the secondary reference clock if defined.

 **Note:**

If the system is put into free-run mode by the craftsperson, it resumes tracking on a reference clock unless the clock-switching option is disabled (LD 60, command MREF), or the reference clock is "undefined" in the database.

Automatic clock switching

If the EREF command is selected in LD 60, tracking on the primary or secondary reference clock is automatically switched in the following manner:

- If software is unable to track on the assigned primary reference clock, it switches to the secondary reference clock and sends appropriate DTC maintenance messages.
- If software is unable to track on the assigned secondary reference clock, it switches to free run.

Clock configurations

Clock Controllers can be used in a single or a dual CPU system.

A single CPU system has one Clock Controller card. This card can receive reference clocks from two sources referred to as the primary and secondary sources. These two sources can

originate from a PRI, DTI, etc. PRI cards such as the QPC720 are capable of supplying two references of the same clock source. These are known as Ref1 (available at J1) and Ref2 (available at J2) on the QPC720.

The NT5D12 card is capable of supplying two references from each clock source, i.e., four references in total. NT5D12 can thus supply Clk0 and Clk1 from Port 0 and Clk0 and Clk1 from Port 1. Either Port 0 or Port 1 can originate the primary source, as shown in [Figure 36: Clock Controller - Option 1](#) on page 85 through [Figure 39: Clock Controller - Option 4](#) on page 88 to [Figure 39: Clock Controller - Option 4](#) on page 88.

There is one new Clock Controller cable required for the new DDP card, which is available in four sizes; this is the NTCG03AA/AB/AC/AD. Refer to [Reference clock cables](#) on page 77 for more information.

[Reference clock cables](#) on page 51 summarizes the clock options. [Table 19: Clock Controller options - description](#) on page 83 explains the options in more detail.


Table 18: Clock Controller options- summary

| CC Option | CPU Type | Notes |
|-----------|----------|--|
| Option 1 | Single | Ref from P0 on Clk0 Ref from P1 on Clk0 |
| Option 2 | Dual | Ref from P0 on Clk0 Ref from P0 on Clk1 |
| Option 3 | Dual | Ref from P1 on Clk0 Ref from P1 on Clk1 |
| Option 4 | Dual | Ref from P0 on Clk0 Ref from P0 on Clk1 Ref from P1 on Clk0 Ref from P1 on Clk1 |

Table 19: Clock Controller options - description

| Clock Option | Notes |
|--------------|--|
| Option 1 | This option provides a single CPU system with 2 clock sources derived from the 2 ports of the DDP. Connector Clk0 provides a clock source from Port 0. Connector Clk1 provides a clock source from Port 1. Refer to Figure 36: Clock Controller - Option 1 on page 85 |
| Option 2 | This option provides a Dual CPU system with 2 references of a clock source derived from port 0 of the DDP. Connector Clk0 provides a Ref 1 clock source from Port 0. Connector Clk1 provides a Ref 2 clock source from Port 0. Refer to Figure 37: Clock Controller - Option 2 on page 86 |
| Option 3 | This option provides a Dual CPU system with 2 references of a clock source derived from port 1 of the DDP. |

| Clock Option | Notes |
|--------------|---|
| | Connector Clk0 provides a Ref 1 clock source from Port 1. Connector Clk1 provides a Ref 2 clock source from Port 1. Refer to Figure 38: Clock Controller - Option 3 on page 87 |
| Option 4 | This option provides a Dual CPU system with 2 references from each clock source derived from the DDP. Connector Clk0 provides a Ref 1 clock source from Port 0. Connector Clk1 provides a Ref 2 clock source from Port 0. Connector Clk0 provides a Ref 1 clock source from Port 1. Connector Clk1 provides a Ref 2 clock source from Port 1. Refer to Figure 39: Clock Controller - Option 4 on page 88 |



553-AAA0079

Figure 36: Clock Controller - Option 1





Figure 37: Clock Controller - Option 2



553-AAA0081

Figure 38: Clock Controller - Option 3




Figure 39: Clock Controller - Option 4

UDT E1/T1- Universal Digital Trunk card

The UDT provides a TDM single E1/T1 pack for the Communication Server 1000E. The UDT E1/T1 card provides the following features:

- Contains all existing DTI/DTI2, PRI/PRI2, DPNSS1/DASS2 and B-channels functionality.
- Replaces, and allows the retirement of, the NTAk79, NTAk09, NTAk10, NTBk50, and NTRB21
- Includes the functionality of the NTAk20, NTAk93, and NTBk51 daughterboards.
- Software transparency; you can use UDT E1/T1 NTDW79AAE5 in the installed base for repairs and upgrades.
- Provides enhanced trouble shooting using a CLI interface.
- Restriction of Hazardous Substances (RoHS) and Chinese Restriction of Hazardous Substances (CRoHS) compliance.
- Meets Stratum 3 and 4 requirements for clocking reference.

UDT E1/T1 software transparency

The UDT E1/T1 card provides software transparency; the characteristics are as follows:

- Provides all DTI, DTI2, PRI, PRI2, DPNSS1, DASS2 functionality.
- Uses a universal CC DB (NTDW12AAE5).
- On board DDCH/DCHI functionality.
- Standards compliance.
- Highly secure (no Telnet, HTTP, or FTP servers).
- Secure and simple UDT E1/T1 firmware upgrade process from the Call Server (PSDL).

UDT E1/T1 applicable systems

The UDT E1/T1 card information contained in this book applies to Communication Server 1000 systems running X21 software (Release 5.5 or later).

UDT E1/T1 limitations

Limitations of the UDT NTDW79AAE5 are shown in the following list:

- The UDT CC daughter board (NTDW12AAE5) works only with the UDT E1/T1 pack (NTDW79AAE5).
- The UDT E1/T1 pack does not work with the NTAK20 CC DB.
- 75ohm BNC connectors are not used for E1. You can use 75ohm impedance by converting the UDT E1/T1 120ohm impedance using a proper converter (for example, Balun).

Chapter 5: DCH installation

Contents

The section contains information about the following topics:

[Install the NT6D11AB, NT6D11AE, NT6D11AF DCH](#) on page 91

[Install the NT6D11AB, NT6D11AE, NT6D11AF DCH](#) on page 91

[Set up the NT6D11AB, NT6D11AE, NT6D11AF DCHI](#) on page 92

[DIP switch settings](#) on page 92

[Protocol selection](#) on page 93

[Valid switch combinations](#) on page 93

[Jumper settings](#) on page 94

[Port addressing modes](#) on page 95

[Port address switch settings](#) on page 96

[Install the NT6D11AB, NT6D11AE, NT6D11AF DCHI](#) on page 97

[Remove the NT6D11AB, NT6D11AE, NT6D11AF DCH](#) on page 98

[Install the QPC757 DCH](#) on page 99

[Port address switch settings](#) on page 101

[D-channel parameter downloading](#) on page 101

[Remove the QPC757 DCHI](#) on page 101

Install the NT6D11AB, NT6D11AE, NT6D11AF DCH

Installation procedures for the NT6D11AB, NT6D11AE, and NT6D11AE DCHI cards are the same for all Large Systems. These instructions apply to hardware both for primary and backup D-channels. D-channel lines must be conditioned for 64K before D-channels can be brought up.

*** Note:**


To configure J1, the asynchronous port on the DCHI card, refer to the documentation of the application being interfaced, and to *Avaya Circuit Card Reference, NN43001-311*. J1 configuration is not described in this technical document.

Set up the NT6D11AB, NT6D11AE, NT6D11AF DCHI

DIP switch settings

The NT6D11AB/AE/AF has three sets of DIP switches. Each port has its own bank of 10 DIP switches (SW1 & SW2) to select the port address (8 bits) and mode of operation (2 bits). SW1 is used for port 0 settings, SW2 is used for port 1 settings. SW3 is used to select the D-channel protocol. Port 0 is used to select whether the asynchronous ESDI port is be disabled or not. Port 1 is used to select the standard or expanded D-channel addressing mode on the NT6D11AB/AE/AF.

The DIP switches are located as shown by [Figure 40: NT6D11 DIP switches](#) on page 92.



553-7349

Figure 40: NT6D11 DIP switches

Protocol selection

SW3 is used to select the D-channel protocol, as shown by [Table 20: Protocol selection switch settings](#) on page 93.

 **Note:**

The setting must be 1 for ISDN applications.

Table 20: Protocol selection switch settings

| Protocol | Switch Setting | |
|----------|----------------|-------|
| | SW3.1 | SW3.2 |
| DPNSS1 | 0 | 0 |
| ISDN | 1 | 1 |

Valid switch combinations

The following are the only allowable switch setting combinations (not including address switch settings).

Port 0

Port 0 can be configured as asynchronous ESDI, or disabled. If the port is configured as disabled, it is not visible to the system CPU. Refer to [Table 21: Port 0 settings](#) on page 93.

Table 21: Port 0 settings

| Mode | Switch setting | | | |
|-------------------|----------------|-------|-------|-------|
| | SW1.1 | SW1.2 | SW3.1 | SW3.2 |
| Asynchronous ESDI | 1 | 0 | 0 | 0 |
| Asynchronous ESDI | 1 | 0 | 1 | 1 |
| Port disabled | 1 | 1 | - | - |

Port 1

The following are the only valid emulation mode combinations. If the port is configured as disabled, it is not visible to the system CPU. Refer to [Table 22: Port 1 settings](#) on page 94.



Note:


The ISDN emulation must be selected.

Table 22: Port 1 settings

| Mode | Emulates | Switch setting | | | |
|-----------------|----------|----------------|-------|-------|-------|
| | | SW2.1 | SW2.2 | SW3.1 | SW3.2 |
| DPNSS1 | NT5K35 | 0 | 0 | 0 | 0 |
| ISDN | NT6D11 | 0 | 0 | 1 | 1 |
| Expanded DPNSS1 | NT5K75 | 0 | 1 | 0 | 0 |
| Port disabled | | 1 | 1 | - | - |


Jumper settings

The NT6D11AB/AE/AF has two banks of option straps, one for each port. These select between DCE and DTE operation and whether the signalling interface is RS232 or RS422. Refer to [Figure 41: NT6D11 DCH with ISL high-speed programming jumper settings](#) on page 94 and [Figure 42: NT6D11 DCH with ISL low-speed programming jumper settings](#) on page 95.



553-7350

Figure 41: NT6D11 DCH with ISL high-speed programming jumper settings



553-7351

Figure 42: NT6D11 DCH with ISL low-speed programming jumper settings

Port addressing modes

Port 0 Mode selection

Port 0 is used to select whether the asynchronous ESDI port is to be disabled or not. Refer to [Table 23: Port 0 mode selection](#) on page 95.

*** Note:**

The asynchronous ESDI port must be set to "disabled".

Table 23: Port 0 mode selection

| Port Mode | Switch Setting | |
|-------------------|----------------|-------|
| | SW1.1 | SW1.2 |
| Not used | 0 | - |
| Asynchronous ESDI | 1 | 0 |
| Port disabled | 1 | 1 |

Port 1 mode selection

Port 1 is used to select the standard or expanded D-channel addressing mode on the NT6D11AB/AE/AF. Refer to [Table 24: Port 1 mode selection](#) on page 96.

Table 24: Port 1 mode selection

| Port Mode | Switch Setting | |
|--|----------------|-------|
| | SW2.1 | SW2.2 |
| Synchronous, D-channel, standard addressing  Note: THIS SELECTION MUST BE MADE FOR ISDN. | 0 | 0 |
| Synchronous, D-channel, expanded addressing | 0 | 1 |
| Not used | 1 | 0 |
| Port disabled | 1 | 1 |

Port address switch settings

Port address switch settings in the standard mode, for ISDN

[Table 25: Port address switch settings for ISDN](#) on page 96 depicts the port address switch settings that apply to SW1 or SW2, the D-channel port, for ISDN mode.

Table 25: Port address switch settings for ISDN

| Port Address | Switch Setting | | | | | | | |
|--------------|----------------|----|----|------------|----|----|----|-----|
| | Half Group No. | | | Device No. | | | | |
| | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | x |
| 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | x |
| 2 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | x |
| 3 | 0 | 0 | 0 | 0 | 0 | 1 | 1 | x |
| 4 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | x |
| 5 | 0 | 0 | 0 | 0 | 1 | 0 | 1 | x |

| Port Address | Switch Setting | | | | | | | |
|--------------|----------------|----|----|------------|----|----|----|-----|
| | Half Group No. | | | Device No. | | | | |
| | S3 | S4 | S5 | S6 | S7 | S8 | S9 | S10 |
| 6 | 0 | 0 | 0 | 0 | 1 | 1 | 0 | x |
| 7 | 0 | 0 | 0 | 0 | 1 | 1 | 1 | x |
| 8 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | x |
| 9 | 0 | 0 | 0 | 1 | 0 | 0 | 1 | x |
| 10 | 0 | 0 | 0 | 1 | 0 | 1 | 0 | x |
| 11 | 0 | 0 | 0 | 1 | 0 | 1 | 1 | x |
| 12 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | x |
| 13 | 0 | 0 | 0 | 1 | 1 | 0 | 1 | x |
| 14 | 0 | 0 | 0 | 1 | 1 | 1 | 0 | x |
| 15 | 0 | 0 | 1 | | | | | |
| 16-31 | 0 | 0 | 1 | | | | | |
| 32-47 | 0 | 1 | 0 | | | | | |
| 48-63 | 0 | 1 | 1 | | | | | |
| 64-79 | 1 | 0 | 0 | | | | | |
| 80-95 | 1 | 0 | 1 | | | | | |
| 96-111 | 1 | 1 | 0 | | | | | |
| 112-127 | 1 | 1 | 1 | | | | | |

Install the NT6D11AB, NT6D11AE, NT6D11AF DCHI

Follow [Install the NT6D11AB, NT6D11AE, NT6D11AF DCH](#) on page 97 to install the NT6D11 DCH on the Large System.

Install the NT6D11AB, NT6D11AE, NT6D11AF DCH

1. Determine the cabinet and shelf location for the circuit pack being installed.

The NT6D11AB, NT6D11AE, or NT6D11AF DCHI card can be installed in any slot appropriate for an I/O port card on a Network shelf. (The NT6D11 DCHI card can be located on the Common Equipment shelf only on single-CPU switches.)

2. Unpack and inspect the card.
3. Set the option switches on the DCHI card. For PRA capability, set port J2 to odd. For ISL capability, set port J2 for high speed or low speed operation (See [Figure](#)

[41: NT6D11 DCH with ISL high-speed programming jumper settings](#) on page 94, [Figure 42: NT6D11 DCH with ISL low-speed programming jumper settings](#) on page 95, and [Table 25: Port address switch settings for ISDN](#) on page 96 starting on [Figure 41: NT6D11 DCH with ISL high-speed programming jumper settings](#) on page 94).

4. Set faceplate toggle switch to DISABLE.
5. Install the DCHI card into the assigned shelf and slot.
6. Connect DCHI port J2 to the NT8D72AB or NT8D72BA PRI port J5 with a QCAD328A cable.
7. Set faceplate toggle switch to ENABLE.
8. Coordinate the start-up and verification of the DCHI with the start-up of the PRI.
9. Enable the DCHI card using LD 96, command `ENL DCHI N`.

Remove the NT6D11AB, NT6D11AE, NT6D11AF DCH

Use [Remove the NT6D11AB, NT6D11AE, NT6D11AF DCH](#) on page 98 to remove the NT6D11AB, NT6D11AE, NT6D11AF DCH from a Large System.

 **Caution:**

The NT6D11AB, NT6D11AE, NT6D11AF DCH must be software disabled before it is hardware disabled, or initialization occurs.

Remove the NT6D11AB, NT6D11AE, NT6D11AF DCH

1. Disable the NT6D11AB, NT6D11AE, NT6D11AF DCHI using LD 96, command `DIS DCHI N`.
2. If asynchronous port J1 is enabled, it must also be software disabled, using LD 37, or initialization occurs.
3. If the circuit pack is being completely removed, not replaced, remove data from memory.
4. Determine the cabinet and shelf location of the card to be removed.
5. Set faceplate toggle switch to DISABLE.
6. Disconnect NT6D11AB, NT6D11AE, NT6D11AF DCHI cables.
7. Remove NT6D11AB, NT6D11AE, NT6D11AF DCHI card.
8. Pack and store the card.

Install the QPC757 DCH

Installation procedures for the QPC757 DCHI card are the same for all Large Systems. These procedures apply to both primary and backup D-channels. See [Figure 43: QPC757 option and PRI/ISL high-speed programming switch settings](#) on page 100 on page 115, [Figure 44: QPC757 option and PRI/ISL low-speed programming switch settings](#) on page 100 and [Table 26: D-channel port address switch settings for PRI](#) on page 101, for option switch settings per port number of the DCHI card, in Primary Rate Interface mode.

Use [Install the QPC757 DCHI](#) on page 99 to install the QPC757 DCHI card on Large Systems.

Install the QPC757 DCHI

1. Determine the cabinet and shelf location of the circuit card to be installed.

The QPC757 DCHI card can be installed in any slot appropriate for an I/O port card on a network shelf. For single CPU systems only, the QPC757 DCHI card can be located on the Common Equipment (CE) shelf.
2. Unpack and inspect the card.
3. Set option switches and jumper plugs on the DCHI card. For PRI capability, set port J2 to odd. For ISL capability, set port J2 for high-speed or low-speed programming.
4. Set faceplate toggle switch to DISABLE.
5. Install DCHI card into the assigned shelf or module and slot.
6. Run and connect DCHI cables: connect QPC757 J2 to QPC720 PRI J5 with a QCAD328A cable.
7. Set faceplate toggle switch to ENABLE.
8. Enable the loop in LD 60.
9. Coordinate start-up and verification of the DCHI with the start-up of the PRI.
10. Enable the DCHI card using LD 96, command `ENL DCH x`.




Figure 43: QPC757 option and PRI/ISL high-speed programming switch settings




Figure 44: QPC757 option and PRI/ISL low-speed programming switch settings

Port address switch settings

[Table 26: D-channel port address switch settings for PRI](#) on page 101 shows the port address switch settings that apply to SW1, SW2 (the D-channel port), SW3, and SW4.

Table 26: D-channel port address switch settings for PRI

| Port Number | | Port Address Switch Settings | | | |
|-------------|----|------------------------------|-----|-----|-----|
| J1 | J2 | SW1 | SW2 | SW3 | SW4 |
| 0 | 1 | Off | Off | Off | Off |
| 2 | 2 | Off | Off | On | Off |
| 4 | 5 | Off | On | Off | Off |
| 6 | 7 | Off | On | On | Off |
| 8 | 9 | On | Off | Off | Off |
| 10 | 11 | On | Off | On | Off |
| 12 | 13 | On | On | Off | Off |
| 14 | 15 | On | On | On | Off |

D-channel parameter downloading

The system software automatically downloads new parameters to each D-channel Interface (DCHI) circuit card upon SYSLOAD. When this occurs, the D-channel is temporarily disabled and then automatically reenabled.

Three situations require manual disabling and enabling of each DCHI to ensure parameter downloading:

- Performing a parallel load and switching over to the second CPU
- Following an alarm condition for the T1 loop carrying the D-channel (but the D-channel is still operational)
- Following SYSLOAD when using ISDN Signaling Link (ISL)

Remove the QPC757 DCHI

Use [Remove the QPC757 DCH](#) on page 102 to remove the QPC757 DCHI card from Large Systems.



The QPC757 DCH must be software disabled before it is hardware disabled to prevent initialization

Remove the QPC757 DCH

1. Disable the QPC757 DCHI using LD 96, command `DIS DCH x`.
2. Disable asynchronous port J1 in LD 48 to prevent initialization.
3. Disable loop in LD 60.
4. If the circuit card is being removed, not replaced, remove data from memory.
5. Determine the cabinet and shelf location of the card to be removed.
6. Set faceplate toggle switch to DISABLE.
7. Disconnect QPC757 DCHI cables.
8. Remove QPC757 DCHI card.
9. Pack and store circuit card.

Chapter 6: NTBK51 DDCH installation and removal

Contents

This section contains information about the following topics:

[Introduction](#) on page 103

[Install NTBK51 DDCH on NT5D97 dual-port DTI2/PRI2 card](#) on page 104

[Remove NTBK51 DDCH from NT5D12 dual-port DTI/PRI](#) on page 105

Introduction

This chapter provides installation and removal procedures for the NTBK51 Downloadable D-channel Daughterboard, the NT5D97 dual-port DTI2/PRI2 card, and the NT5D12 dual-port 1.5 Mb DTI/PRI card on all Large Systems.



Note:

NTBK51AA/CA can be used with NT5D97 or the NT5D12 in Large Systems. Vintage NTBK51BA cannot be used, due to a different pin configuration (the NTBK51BA is used on Small Systems.)

Before beginning an installation:

- Consult *Avaya Spares Planning, NN43001-253*, and follow the instructions.
- Bring spares of all cables and boards.
- Remember that test procedures require a 24-hour minimum bit error-rate testing before being used.
- Remember that either the DDCH, the MSDL, or NT5D97, or NT5D12 card can be installed first. However, NT5D97 PRI2 loops, and NT5D12 PRI loops, must be configured in software before defining DCH links.

Install NTBK51 DDCH on NT5D97 dual-port DTI2/PRI2 card

Installation procedures for the NTBK51 DDCH are the same for all Large Systems. Use [Install the NTBK51 on the NT5D97 dual-port DTI2/PRI2 card](#) on page 104 below.

The DDCH can be mounted on any NT5D97 DDP2 card. Set the address for the DDCH (see the switch settings section to set the address). If a DDCH is present on a DDP2 card then an external D-channel should not be connected to J6. If a DDCH is present the LED "DDCH" lights up.

 **Caution:**

The static discharge bracelet located inside the cabinet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

Install the NTBK51 on the NT5D97 dual-port DTI2/PRI2 card

1. Unpack and inspect the DDCH daughterboard.

The DDCH comes with four standoffs so that it can be mounted onto the NT5D97. These are easily pushed into four corresponding mounting holes on the DDP2.

2. Mount the DDCH so that it mates with P1 and P2 on the NT5D97 motherboard.

 **Note:**

P 1 and P 2 contain (40+30) sockets as the NTBK51AA/NTBK51CA respective pins (40+30), which enables the technician to "mate" them. This is applicable for the NT5D97AA/AB. The NT5D97AD has 44+34 sockets. In order to place the NTBK51AA/NTBK51CA (40+30 pins), place the NTBK51AA/NTBK51CA inside P1 and P2. Start from their lower edge. (The remaining "free" sockets (4+4) in P1 and P2 are in their upper edge.)

3. Set the DDP2 ENB/DIS faceplate switch to Enable (ON). The DDCH LED then flashes three times.

Remove NTBK51 DDCH from NT5D97 dual-port DTI2/PRI2 card

Removal procedures for the NTBK51 DDCH are the same for all Large Systems.

 **Caution:**

A static discharge bracelet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

The NTBK51 can only be removed when it is disabled in software. Both ports of the associated DDP2 card must be disabled. Follow the steps in [Remove the NTBK51 from the NT5D97 dual-](#)

[port DTI2/PRI2 card](#) on page 105 to remove the NTBK51 from the NT5D97 dual-port DTI2/PRI2 card.

Remove the NTBK51 from the NT5D97 dual-port DTI2/PRI2 card

1. Set the DDP2 ENB/DIS faceplate switch to Disable (OFF).
2. Remove the DDP2 and the DDCH.

Install NTBK51 DDCH on NT5D12 dual-port DTI/PRI

Installation procedures for the NTBK51 DDCH are the same for all Large Systems.

Set the address for the DDCH (see the switch settings section to set the address). If a DDCH is present on a DDP card then an external D-channel should not be connected to J6. If a DDCH is present, the LED "DCH" lights up.



Caution:

Service Interruption

A static discharge bracelet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

The DDCH can be mounted on any DDP card. Follow the steps in [Install the NTBK51 DDCH on the NT5D12 dual-port DTI/PRI](#) on page 105 to install the NTBK51 on the NT5D12 dual-port DTI/PRI card.

Install the NTBK51 DDCH on the NT5D12 dual-port DTI/PRI

1. Unpack and inspect the DDCH daughterboard.
The DDCH comes with four standoffs so that it can be mounted onto the DDP. These are easily pushed into four corresponding mounting holes on the DDP.
2. Mount the NTBK51 DDCH so that it mates correctly with P1 and P2 on the NT5D12 DDP motherboard.

Remove NTBK51 DDCH from NT5D12 dual-port DTI/PRI

Removal procedures for the NTBK51 DDCH are the same for all Large Systems.



Caution:

A static discharge bracelet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

The DDCH can only be removed when it is disabled in software. Both ports of the associated DDP card must be disabled. Follow the steps in [Remove the NTBK51 from the NT5D12 dual-](#)

[port DTI/PRI card](#) on page 106 to remove the NTBK51 from the NT5D12 dual-port DTI/PRI card.

Remove the NTBK51 from the NT5D12 dual-port DTI/PRI card

1. Disable the faceplate switch on the DDP.
2. Remove the DDP and DDCH.

Chapter 7: Universal Digital Trunk card installation

Contents

The section contains information about the following topics:

- [Installation guidelines - default mode](#) on page 107
- [Installation guidelines - non default mode](#) on page 108
- [UDT Clock Controller daughter board installation](#) on page 109
- [Physical installation of the UDT card](#) on page 110
- [UDT E1/T1 Configuration guidelines - PRI2 \(E1\)](#) on page 113
- [UDT E1/T1 Configuration guidelines - DTI2 \(E1\)](#) on page 113
- [UDT E1/T1 Configuration guidelines - DTI \(T1\)](#) on page 114
- [UDT E1/T1 Configuration guidelines- DPNSS/DASS \(E1\)](#) on page 114

Installation guidelines - default mode

- Mount the UDT Clock Controller (CC) daughter board on the UDT card, if required. See [UDT Clock Controller daughter board installation](#) on page 109.
- Set the DIP switch settings:
 - Set switch number 1
 - ON - E1
 - OFF - T1
- Default setup of E1/T1 parameters for E1 mode:
 - Usage - PRI2
 - CRC4 - NO

- Default setup E1/T1 parameters for T1 mode:
 - Usage - PRI
 - Frame Mode - ESF;
 - Line Code - B8ZS
 - Yellow Alarm - FDL
 - LBO - 0-133 FT
- Insert the UDT card and connect the carrier cable (E1/T1 link). See [Physical installation of the UDT card](#) on page 110.



Note:

RS232 port connectivity is not required when installing the UDT card in default mode.

- X21 configuration:
 - LD 17 (CEQU, ADAN)
 - LD 15 (NET data)
 - LD 16 (RDB)
 - LD 14 (trunks)
 - LD 73 (System timers and CC configuration)
- Enable/activate the card X21 commands:
 - LD 60
 - LD 75
 - LD 96


Installation guidelines - non default mode

- Mount the UDT CC daughter board on the UDT card, if required. See [UDT Clock Controller daughter board installation](#) on page 109.
- Set the DIP switch settings:
 - Set switch number 1
 - ON - E1
 - OFF - T1
- Insert the UDT card and connect the RS232 port and the carrier cable (E1/T1 link). See [Physical installation of the UDT card](#) on page 110.

- UDT card configuration is required for non default mode setup.
- X21 configuration:
 - LD 17 (CEQU, ADAN)
 - LD 15 (NET data)
 - LD 16 (RDB)
 - LD 14 (trunks)
 - LD 73 (System timers and CC configuration)
- Enable/activate the card X21 commands:
 - LD 60
 - LD 75
 - LD 96

UDT Clock Controller daughter board installation

Mount the UDT CC daughter board on the UDT card, if required. Work on a flat surface when mounting or removing daughter boards.




1. Visually inspect the connector pins on the underside of the daughter board. Straighten and realign any bent pins prior to mounting.
2. Place the UDT card down flat on an antistatic pad.
3. From an overhead view, with the daughter board parallel above the UDT card and the connector pins aligned over the connector sockets, line up the mounting holes on the daughter board with the tops of the standoffs on the UDT card.
4. Slowly lower the daughter board towards the UDT card, keeping the standoffs in line with all four holes, until the holes are resting on the tops of the four standoffs. If more than a very slight amount of pressure is required at this point, the connector

pins cannot be aligned with the connector socket. If so, lift the daughter board off the UDT card and return to step 2.

5. Ensure the daughter board is securely attached to UDT card (using the four supplied screws and standoffs).

Physical installation of the UDT card

The UDT card can be installed in any CE-MUX slot of an Avaya Communication Server 1000E cabinet.



1. Remove the cabinet module cover.
2. Determine the cabinet and slot location of the UDT card to be installed.
3. Unpack and inspect the card.
4. Attach the antistatic wrist strap to your wrist, or discharge static electricity on the cabinet bare metal surface.
5. Set the E1/T1 mode DIP switch.
6. Flip the UDT top locking latch up and the bottom-locking latch down.
7. Insert the UDT card into the card-aligning guides in the card cage.
8. Gently push the UDT card into the slot until you feel resistance.
9. Lock the UDT card in the card cage by simultaneously pushing ends of the locking latches against the faceplate.
10. If the cabinet is turned on, the UDT card conducts a self-test. After the self-test, the EN/DIS LED remains red until the card is software-enabled in LD 60.
11. Connect the RS232 port to a terminal using a DB9 to DB25 cable. This connection is used to set the E1/T1 parameters (in case that they have values different from the default).

 **Note:**

RS232 port connectivity is not required when installing the UDT card in default mode.

The D-type Debug connector pin out is as follows:

| Pin | Function |
|-----|----------|
| 1 | |
| 2 | TXD |
| 3 | RXD |
| 4 | |
| 5 | GND |
| 6 | |
| 7 | |
| 8 | |
| 9 | |

12. Configure the terminal or terminal emulation program settings:

- 9600 baud
- 8 data bits
- 1 stop bit
- No parity

13. Connect the carrier cable to the 50-pin Amphenol connector associated with the slot in which the UDT card is installed and terminate it as required.

The NTBK65AAE5 adapter provides break out to a standard RJ48C connection for use with Cat5/Cat5e cable.

 **Note:**

Avaya does not supply cables. It is the responsibility of the distributor to supply the required cables:

- RS-232 serial port (D-type 9) cable
- Bantam jacks
- RJ45 Ethernet shielded cable

The NTBK65AAE5 adapter has the following pin out:

| 50-pin | RJ45 | Function |
|--------|------|--------------|
| 24 | 1 | RX RING |
| 49 | 2 | RX TIP |
| | 3 | N/C RESERVED |
| 23 | 4 | TX RING |
| 48 | 5 | TX TIP |
| | 6 | N/C RESERVED |
| | 7 | N/C |
| | 8 | N/C |

 **Note:**

Transmit/Receive direction is with respect to the UDT card; for example, TX is UDT output.



Figure 45: NTBK65AAE5 adapter

UDT E1/T1 Configuration guidelines - PRI2 (E1)

- Configure the DIP switch settings:
 - Configure switch number 1: ON - E1
- UDT E1/T1 configuration (CLI)- Only if changing default values
 - Required configuration:
 - Protocol: Europe (E1)
 - Usage: PRI2
 - CRC4: NO/YES
 - Configuration location in CLI: /udtadmin/E1T1Settings
- X21 configuration for existing packs:
 - Overlay 17 (CEQU, ADAN)
 - Overlay 15 (NET data)
 - Overlay 16 (RDB)
 - Overlay 14 (PRI2 trunks)
 - Overlay 73 (System timers and CC configuration)

UDT E1/T1 Configuration guidelines - DTI2 (E1)

- Configure the DIP switch settings:
 - Configure switch number 1: ON - E1
- UDT E1/T1 configuration (CLI)
 - Required configuration:
 - Protocol: Europe (E1)
 - Usage: DTI2
 - CRC4: NO/YES
 - AIS in TS16 (NO/YES)

- Configuration location in CLI: /udtadmin/E1T1Settings
- X21 configuration for existing packs:
 - Overlay 17 (CEQU, ADAN)
 - Overlay 73 (ABCD signaling, system timers and CC configuration)
 - Overlay 16 (RDB)
 - Overlay 14 (DTI2 trunks)

UDT E1/T1 Configuration guidelines - DTI (T1)

- Configure the DIP switch settings:
 - Configure switch number 1: OFF - T1
- UDT E1/T1 configuration (CLI)
 - Required configuration:
 - Protocol: North America (T1)
 - Usage: DTI (Frame mode, Line Code, Yellow Alarm, and LBO)
 - Configuration location in CLI: /udtadmin/E1T1Settings
- X21 configuration for existing packs:
 - Overlay 17 (CEQU)
 - Overlay 16 (RDB)
 - Overlay 14 (DTI trunks)
 - Overlay 73 (Digital Data Block and CC configuration)

UDT E1/T1 Configuration guidelines- DPNSS/DASS (E1)

- Configure the DIP switch settings:
 - Configure switch number 1: ON - E1
- UDT E1/T1 configuration (CLI)
 - Required configuration:
 - Protocol: Europe (E1)
 - Usage: DDCS

- CRC4: NO/YES
- Configuration location in CLI: /udtadmin/E1T1Settings
- X21 configuration for existing packs:
 - Overlay 17 (CEQU, ADAN)
 - Overlay 74 (DDSL)
 - Overlay 16 (RDB)
 - Overlay 14 (RDC/VDC)
 - Overlay 73 System timers and CC configuration)

Chapter 8: Universal Digital Trunk card firmware upgrade

Contents

The section contains information about the following topics:

[Firmware upgrade](#) on page 117

[Loadware Configuration Procedures](#) on page 119

[LD 60 Check the existing firmware version of UDT cards](#) on page 120

[LD 22 Print the existing peripheral software download version \(PSDL\)](#) on page 121

[LD 143 Execute the UDT card upgrade for the required UDT cards](#) on page 122

[UDT E1/T1 secure firmware download](#) on page 123

[UDT E1/T1 secure firmware download guidelines](#) on page 124

Firmware upgrade

The UDT card firmware can be upgraded by downloading a new file from the Call Server. The download for each UDT card in the system can be performed and managed through the Call Server. No additional physical connection need be made to the UDT card.

If the firmware download fails, the UDT card will always be able to come up with a working firmware, which was not affected by the downloading process.

The firmware upgrade requires a card reboot.

Feature interactions

Firmware download is implemented as a patch.

Firmware download from the Call Server is applicable only for configurations of a UDT card placed in a Media Gateway Controller shelf.

Only manual and sequential download is supported. This feature does not include any automatic upgrading.

Firmware download is not supported by Element Manager. All provisioning must be done through the TTY by running the required LD programs.

During the UDT firmware download, the Media Gateway Controller is prevented from sending any messages to the UDT other than the messages that are related with the UDT firmware download. An attempt to send messages to the Multi-purpose Serial Data Link through the UDT will be rejected. Hence, a scheduled download to the Multi-purpose Serial Data Link will fail as long as the UDT firmware download is in process.

Firmware download duration

The duration of the download process is expected to be around three minutes.

Security

The initiation of the UDT firmware download can be made only from the Call Server, so all the existing security mechanisms are applicable to the UDT firmware download process. The loadware file is located on the mass storage device of the Call Server, and it is passed to the Media Gateway Controller via the Secure IP messaging system, which includes its own security mechanism. The Media Gateway Controller in turn, sends the loadware to the UDT via the CEMUX bus. Hence the UDT is not subject to security threats over the Ethernet network.

Loadware patch

The management of the loadware file for the UDT is the same as the loadware file of the Media Gateway Controller. The format of the UDT loadware patch name is UDTCAAnn.LW, where 'nn' is a pair of digits denoting the version number.

There is a standard file which by default is used when downloading the UDT firmware. A loadware patch can be introduced in order to use another UDT loadware file. When the UDT loadware patch is active, the UDT downloading will use the patch file rather than using the standard file. When putting the patch out of service, the standard file will be used again for the UDT downloads.

To install and activate loadware patches, see [Loadware Configuration Procedures](#) on page 119.

Firmware download guidelines

- Secure firmware download process from the Call Server using the existing Avaya Communication Server 1000 Peripheral Software download (PSDL) mechanism.
- Supported from X21 Release 5.5 and later.
- X21 Call Server commands are introduced or changed to support the UDT card firmware upgrade process (LD 143, 60, 22). Implemented in X21 Releases 5.5 and 6.0 by an X21 software patch.
- UDT card firmware file is part of the Call server PSDL software. Implemented in X21 Releases 5.5 and 6.0 by an X21 loadware patch.
- Media Gateway Controller firmware changes are introduced to support the UDT secure firmware download process.
- Ensure that required X21 CS software/loadware patches (X21 Release 5.5/6.0) and Media Gateway Controller loadware patch (X21 RLS 5.5/6.0) are in service.
- Check the existing firmware version of UDT cards (LD 60).
- Print the existing peripheral software download version (PSDL) list (LD 22). Query the existing UDT card PSDL version (a desired new UDT loadware file can be loaded as a new Call Server loadware patch).
- Execute the UDT card upgrade for the required UDT cards (LD 143).

Loadware Configuration Procedures

Loadware patch for the UDT

The UDT loadware is provided to the Call Server as a loadware patch. The UDT loadware patch file should be placed in the Call Server mass storage device directory `/u/loadware`. Once the loadware patch file is in the `/u/loadware` directory, a loadware patch must be created and installed.

To create and install a loadware patch:

```
pdt> lwload udtcaa15.lw
```

A loadware patch handle number is provided by the Call Server.

Put the loadware patch in service:

```
pdt> lwinst 0
```

If that is the first time that a UDT loadware patch is introduced to the Call Server then the following message will be displayed:

```
UDTCAA15 was installed as the UDT permanent loadware.
```

The loadware file will be copied to the loadware permanent directory /p/sl1/loadware and saved as a loadware file (not a loadware patch file) with the standard file name format UDTCaaxx.LD. If a UDT loadware was already introduced to the Call Server in the past, this is regarded as a request to patch the existing loadware and the following prompt is issued:

```
Loadware "UDTCAAxX" will be replaced by "UDTCAAYY+"  
Do you wish to continue (y/n)? [y].
```

If the answer is 'Y' then the following message appears:

```
UDT Loadware patch have been put into service.
```

Otherwise, the following message will appear:

```
UDT Loadware patch not installed. Exiting.
```

To remove the loadware patch (so that the patch can be replaced with another UDT loadware patch):

```
pdt> lwout 0  
Patch 0 will be removed.  
Do you wish to continue (y/n)? [y]  
Loadware patch 0 has been removed successfully.
```

Loadware patch for the Media Gateway Controller

A patch to the Media Gateway Controller must be activated prior to downloading the UDT patch.

If the Media Gateway Controller is not patched, and an attempt is made to invoke UDT download, the Media Gateway Controller will fail to properly respond to the Download Start request from the Call Server, which will cause the Call Server to abort the download. No other functionality problem should occur by this situation.

LD 60 Check the existing firmware version of UDT cards

VER command

If the VER <UDT Digital Loop Number> command is issued, a new Special-SSD message will be sent to the MGC, asking it to query the UDT firmware version. The MGC will make an IO read to the digital loop. This specific IO read does not affect any non-UDT loop, but in case it is a UDT, this read will retrieve the UDT firmware version. The MGC will send another new Special-SSD message to the Call Server containing the retrieved version, or a zero in case

the read failed. The Call Server will store the retrieved version number in the unprotected data block of the digital loop, and when LD 60 gets a timeslice it will search for this version number. If found then it will print it out, and if not found before a certain amount of time elapses, it will print an error message stating that the loop in question failed to provide a UDT firmware version.

The format of the UDT firmware version is UDT VER <AAnn>.

ENLL command

When requested to enable a disabled loop, the ENLL command will check whether it is a UDT. If it is a UDT, it will check whether the UDT is in the middle of a download process. If the UDT is in the middle of a download process, then the enabling request will be rejected and an appropriate error message will be issued.

LD 22 Print the existing peripheral software download version (PSDL)

PSWV command

The existing PRT PSWV command is enhanced so that it also prints the version of the UDT loadware file that is present on the Call Server mass storage device.

If the UDT loadware file is present, the PRT PSWV command produces the following output:

```
UDT
VERSION NUMBER: AA01
```

If the loadware file was replaced by a loadware patch, the output will look like:

```
UDT
VERSION NUMBER: AAnn+
```

There is no change to the existing output of the PRT PSWV command if the loadware file of the UDT card is not present.

When inserting the UDT loadware patch for the first time, the loadware will be taken and treated as the permanent UDT loadware, not as a patched loadware. The output of the PRT PSWV command will not include the '+' sign. Also, the ISSP command will show no UDT loadware patch.

When it is required to change the UDT loadware, a second request to load a loadware patch will be issued. Then the UDT loadware will be regarded as patched, and the output of the PRT PSWV command will show the patched UDT version with the '+' sign.

When asking to take off the loadware patch, the UDT loadware that was used the first time will become active, and the UDT loadware will be treated as unpatched loadware.

To install and manage loadware patches, see [Loadware Configuration Procedures](#) on page 119.

ISSP command

The ISSP command shows the UDT active loadware patch. When the UDT loadware patch is activated for the first time, the loadware file will be used as the permanent UDT loadware, and a request to show the loadware patches in the system will show no UDT loadware patch. When activating a UDT loadware patch next time, it will be regarded as a loadware patch and will be shown by the ISSP command.

Following is an example of activating the UDT loadware patch for the first time while a Media Gateway Controller loadware patch exists in the system:

```
pdt> lwload udtcaa15.lw
pdt> lwinst 1
UDTCAA15 was installed as the UDT permanent loadware.
pdt> sllinput
> LD 22
REQ ISSP
INSTALLED LOADWARE PEPS : 1
PAT# PRS/CR PATCH REF # NAME DATE FILENAME
01 Q2424242 ISS1:1OF1 p222222_2 06/11/08 mgcczz99.lw
```

Following is an example of output when there is an active Media Gateway Controller loadware patch and an active UDT loadware patch:

```
pdt> lwload udtcaa16.lw
pdt> lwinst 1
Loadware "UDTCAA15" will be replaced by "UDTCAA16+"
Do you wish to continue (y/n)? [y].
UDT Loadware patch have been put into service.
pdt> sllinput
> LD 22
REQ ISSP
INSTALLED LOADWARE PEPS : 2
PAT# PRS/CR PATCH REF # NAME DATE FILENAME
01 Q2424242 ISS1:1OF1 p222222_2 06/11/08 mgcczz99.lw
02 Q1234567 ISS1:1OF1 p123456_1 06/11/08 udtcaa16.lw
```

LD 143 Execute the UDT card upgrade for the required UDT cards

Start upgrade command

```
upgudt <supl shelf card>
```

If the UDT can not be reached then the following message will be printed:

```
UDT[LLL S CC]: Not available. Upgrade command ignored.
```

If an UDT upgrade is already in progress then the following message will be printed:

```
UDT[LLL s CC]: Doing Upgrade already. Upgrade command ignored.
```

```
upgudtabort
```

If the abort request was made after the UDT has erased its old firmware then terminating the upgrade will cause the UDT to be left without any upgraded code, and it will have to come up with its fixed factory firmware. When this is the case, to confirm the abort request the Call Server will print the following message:

```
UDT[LLL S CC] is undergoing an upgrade. Do you want to abort the upgrade?
ENTER Y(ES) TO CONFIRM ABORT UPGRADE, N(O) TO IGNORE COMMAND.
```

If confirmed, an abort message will be sent to the UDT.

UDT download status query

```
upgudt stat
```

The upgudt stat command reports the current UDT upgrade state and the TN of the UDT card that is currently downloaded.

If no upgrade is currently taking place, the reply will be:

```
Udt Upgrade is idle
```

If an upgrade process does exist, then the reply format will be:

```
UDT Upgrade is [idle / checking / starting / active / aborting]. Loop <L> [LLL S CC]
```

UDT E1/T1 secure firmware download

This section provides information about UDT E1/T1 secure firmware downloads.

- The existing CS 1000 peripheral software download (PSDL) mechanism is used to perform secure firmware downloads from the Call Server to the UDT card.
- You do not require CLI and Ethernet connectivity to perform the UDT E1/T1 firmware upgrade.
- UDT E1/T1 secure firmware download is supported only for CS 1000E and MG 1000B systems (MGC based only).
- UDT E1/T1 secure firmware download is supported for X21 Releases 5.5 and greater.
- X21 Call Server commands support the UDT E1/T1 upgrade process (overlays 143, 60, and 22).
- The UDT E1/T1 loadware file is part of Call Server PSDL software.
- MGC firmware supports the UDT E1/T1 secure download process.

UDT E1/T1 secure firmware download guidelines

Use the following guidelines when you perform a UDT E1/T1 secure firmware download.

- Ensure the necessary X21 CS software/loadware patches (X21 RLS 5.5/6.0) and MGC loadware patch (X21 RLS 5.5) are in-service.
- Generate and print the system card inventory (overlay 117 command).
- Check the existing firmware version of UDT E1/T1 cards (overlay 60 command).
- Print the existing peripheral software download version (PSDL) list (overlay 22 command) and query the existing UDT E1/T1 PSDL version. If you have an older version, download the latest UDT loadware file as a new Call Server loadware patch.
- Execute the UDT E1/T1 upgrade for the required UDT E1/T1 cards (overlay 143 command).

Chapter 9: MSDL installation for all systems

Contents

The section contains information about the following topics:

[Install the MSDL](#) on page 125

[Replace the MSDL](#) on page 127

Install the MSDL

Installation procedures for the MSDL card are the same for Large Systems. Use [Install the MSDL card](#) on page 125 below. See [Figure 46: MSDL card layout](#) on page 126, and [Table 27: MSDL switch settings](#) on page 126 for the port and interface switch settings.

The MSDL card goes into the following slots:

| | |
|-----------------------------|---------------------------------|
| Half Group, Single Group | CPU/Network Module slot 1–8, 13 |
| Multi Group | Network Module slot 5–14 |

See *Avaya Software Input Output Reference — System Messages, NN43001-712* and *Avaya Circuit Card Reference, NN43001-311* for more information.

Install the MSDL card

1. Determine module and slot location for the MSDL card. Unpack and inspect the MSDL card.
2. Set the MSDL switch settings to correspond to [Table 27: MSDL switch settings](#) on page 126, and [Figure 46: MSDL card layout](#) on page 126.
3. Insert the MSDL card into the selected card slot of the module following the card guides.
4. Observe the red LED on the MSDL faceplate. If it turns on, flashes three times, and stays on continuously, the MSDL is operating correctly but is not yet enabled.

If the LED turns on and stays on continuously without flashing three times, the card can be defective. Go to step 8.

5. Connect the appropriate cable between the NT6D80 and the PRI card MSDL interface.
6. Enable the MSDL card in LD96.
7. Unplug the MSDL card and reinsert it. If the red LED still does not flash three times, leave the card installed for approximately 10 minutes to allow the card to be initialized.
8. After 10 minutes unplug the card, reinsert it and if the card still does not flash three times, the card is defective and must be replaced.




Figure 46: MSDL card layout

Table 27: MSDL switch settings

| | Port 0—SW4 | | | | | | | | Port 0—SW8 | | | | | | | | |
|----------|------------|----|----|----|----|----|----|----|------------|----|----|----|----|----|----|----|----|
| RS-232-D | o | o | o | o | o | o | o | o | o | o | o | o | o | o | o | o | o |
| | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff | ff |

| | | |
|--------------|--|--|
| RS-422-A DTE | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o n n n n n n n n n n |
| RS-422-A DCE | o o o o o o o o n n n n n n n n n n | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| | Port 1—SW3 | Port 1—SW7 |
| RS-232-D | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| RS-422-A DTE | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o n n n n n n n n n n |
| RS-422-A DCE | o o o o o o o o n n n n n n n n n n | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| | Port 2—SW2 | Port 2—SW6 |
| RS-232-D | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| RS-422-A DTE | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o n n n n n n n n n n |
| RS-422-A DCE | o o o o o o o o n n n n n n n n n n | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| | Port 3—SW1 | Port 3—SW5 |
| RS-232-D | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |
| RS-422-A DTE | o o o o o o o o ff ff ff ff ff ff ff ff | o o o o o o o o o o n n n n n n n n n n |
| RS-422-A DCE | o o o o o o o o n n n n n n n n n n | o o o o o o o o o o ff ff ff ff ff ff ff ff ff ff |

Replace the MSDL

Replacement procedures for the MSDL card are the same for all Large Systems. Use [Replace the MSDL card](#) on page 127 below.

Replace the MSDL card

1. Disable the MSDL card in LD 96.
2. Disconnect MSDL to PRI cables.
3. Remove the faulty MSDL card.
4. Unpack and inspect the new MSDL card.

5. Set the MSDL switch settings to correspond to [Table 27: MSDL switch settings](#) on page 126 and [Figure 46: MSDL card layout](#) on page 126.
6. Insert the new MSDL card into the selected card slot of the module following the card guides.
7. Observe the red LED on the MSDL faceplate. If it turns on, flashes three times, and stays on continuously, the MSDL is operating correctly but is not yet enabled.

If the LED turns on and stays on continuously without flashing three times, the card can be defective. Go to step 11.
8. Connect the appropriate cable between the NT6D80 and the PRI card MSDL interface.
9. Enable the MSDL card in LD 96.
10. Unplug the MSDL card and reinsert it. If the red LED still does not flash three times, leave the card installed for approximately 10 minutes to allow the card to be initialized.
11. After 10 minutes unplug the card and reinsert it. If the red LED does not flash three times, the card is defective and must be replaced.

Chapter 10: NT8D72 and QPC720 PRI card installation

Contents

The section contains information about the following topics:

[Introduction](#) on page 129

[PRI circuit pack locations](#) on page 129

[Cable requirements](#) on page 130

[Switch settings](#) on page 148

[Install NT8D72 and QPC720 PRI cards on Large Systems](#) on page 150

[Remove NT8D72 and QPC720 PRI cards from Large Systems](#) on page 152

[Install an additional network shelf](#) on page 152

Introduction

This chapter contains information about how to install the 2.0 Mb NT8D72 and the 1.5 Mb QPC720 PRI cards on all Large Systems.

Information about how to install the dual-port cards NT5D97 and NT5D12 is contained in this document.

PRI circuit pack locations

The PRI circuit pack occupies two adjacent slots on a shelf. As many as five circuit packs can be plugged into an empty Network shelf, along with a Power Converter circuit pack. Specific locations depends on available space.

 **Note:**

Due to physical width, Bus Terminating Units (BTUs) and PRIs cannot fit next to each other on a shelf.

 **Note:**

This chapter includes instructions for installing an additional network shelf on a system (when no vacant Network slots are available to install PRI packs, additional network shelves can replace Intelligent Peripheral Equipment shelves located on the rear of the Common Equipment or Disk shelves). Refer to [Install an additional network shelf](#) on page 152.

Cable requirements

Shielded 22 AWG (0.644 mm) cables are recommended for connecting the PRI to the crossconnect point. This cable consists of two twisted-pair conductors.

The transmit and the receive pairs must be enclosed in a polyvinyl jacket. This type of cable is commonly referred to as "6-conductor" cable. The cable should be grounded at the crossconnect point.


In addition to twisted-pair conductors, 75-ohm coaxial cable can also be used to provide connection to the office repeater or line terminating unit (LTU).

For manufacture cables of lengths different than those of the standard cables provided, see "Nonstandard cables" on [Nonstandard cables](#) on page 341 of this practice.

For the 2.0 Mb NT8D72 PRI card, see [Figure 47: NT8D72\(Half Group cabling\) on Half and Single Group systems without an echo canceller](#) on page 131, [Figure 48: NT8D72 \(Half Group cabling\) for Half and Single Group systems, with an echo canceller](#) on page 132, [Figure 49: NT8D72 \(Single Group cabling\) for Half and Single Group systems, without an echo canceller](#) on page 133, and [Figure 50: NT8D72 \(Single Group cabling\) for Half and Single Group systems, with an echo canceller](#) on page 134 for Half Group and Single Group cabling arrangements applying to the system; also, refer to [Table 51: NTBK51AA/NTBK51CA DCH switches for NT5D97AD](#) on page 167. For the 2.0 NT8D72 on a Multi Group arrangement, see [Figure 51: NT8D72 \(Multi Group cabling\) for Multi Group systems without an echo canceller](#) on page 135 and [Figure 52: NT8D72 \(Multi Group cabling\) for Multi Group systems with an echo canceller](#) on page 136; also refer to [Table 29: Cable for the NT8D72 PRI card for Multi Group systems](#) on page 144.

For the 1.5 Mb QPC720 PRI card on Half Group and Single Group systems, see [Figure 53: QPC720 \(Half Group cabling\) for Multi Group systems without an echo canceller](#) on page 137, [Figure 54: QPC720 \(Half Group cabling\) for Multi Group systems with an echo canceller](#) on page 138, [Figure 55: QPC720 \(Single Group cabling\) for Multi Group systems without an echo canceller](#) on page 139, also, refer to [Table 30: Cable for the QPC720 PRI card for Half and Multi Group systems](#) on page 145. For the QPC720 on Multi Group systems, see [Figure 57: QPC720 Multi Group cabling without an echo canceller](#) on page 141 and [Figure 58: QPC720](#)

[Multi Group cabling with an echo canceller](#) on page 142; also refer to [Table 31: Cable for the QPC720 PRI card on Multi Group systems](#) on page 146.




Note 1: Maximum cable distance from PRI card to cross connect is 200 m (655 ft) .

Note 2: Maximum cable distance from PRI card to repeater is 229 m (750 ft).


553-1389

Figure 47: NT8D72(Half Group cabling) on Half and Single Group systems without an echo canceller



- Note 1:** Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).
 - Note 2:** Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).
 - Note 3:** QPC720 does not interface with NT8D04 Superloop Network Card.
- 553-7366

Figure 48: NT8D72 (Half Group cabling) for Half and Single Group systems, with an echo canceller




Note 1: Maximum cable distance from PRI card to cross connect is 200 m (655 ft) .

Note 2: Maximum cable distance from PRI card to repeater is 229 m (750 ft).

553-1391

Figure 49: NT8D72 (Single Group cabling) for Half and Single Group systems, without an echo canceller




Note 1: Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).

Note 2: Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-1392

Figure 50: NT8D72 (Single Group cabling) for Half and Single Group systems, with an echo canceller




Note 1: Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).

Note 2: Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.


553-7366

Figure 51: NT8D72 (Multi Group cabling) for Multi Group systems without an echo canceller



- Note 1:** Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).
- Note 2:** Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).
- Note 3:** QPC720 does not interface with NT8D04 Superloop Network Card. 553-7367

Figure 52: NT8D72 (Multi Group cabling) for Multi Group systems with an echo canceller




Note 1: Maximum cable distance from PRI card to cross connect is 200 m (655 ft) .

Note 2: Maximum cable distance from PRI card to repeater is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-1389.1

Figure 53: QPC720 (Half Group cabling) for Multi Group systems without an echo canceller




Note 1: Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).

Note 2: Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-1390.1

Figure 54: QPC720 (Half Group cabling) for Multi Group systems with an echo canceller




Note 1: Maximum cable distance from PRI card to cross connect is 200 m (655 ft) .

Note 2: Maximum cable distance from PRI card to repeater is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-1391.1

Figure 55: QPC720 (Single Group cabling) for Multi Group systems without an echo canceller




Note 1: Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).

Note 2: Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-1392

Figure 56: QPC720 (Single Group cabling) for Multi Group systems with an echo canceller




Note 1: Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).

Note 2: Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).

Note 3: QPC720 does not interface with NT8D04 Superloop Network Card.

553-7366.1

Figure 57: QPC720 Multi Group cabling without an echo canceller



- Note 1:** Maximum cable distance from PRI card to DS-1 cross connect is 200 m (655 ft).
- Note 2:** Maximum cable distance from PRI card to LD-1 is 229 m (750 ft).
- Note 3:** QPC720 does not interface with NT8D04 Superloop Network Card. 553-7367.1

Figure 58: QPC720 Multi Group cabling with an echo canceller

Table 28: Cable for the NT8D72 PRI card for Half and Single Group systems

| Cable | From | Des | Con | To | Des | Con | To |
|----------|----------|-----|-----|------------------|------|-----|---------------------------------|
| NTND26 | PRI card | | J5 | MSDL | | | |
| NT8D79AA | PRI card | | J1 | Clock controller | CC-0 | J2 | Only when primary clock source. |

| Cable | From | Des | Con | To | Des | Con | To |
|-----------------------|------------------|------|-----|------------------|------|-----|---|
| NT8D79AA | PRI card | | J1 | Clock controller | CC-0 | J1 | Only when secondary clock source. |
| For single-group only | | | | | | | |
| NT8D79AA | PRI card | | J2 | Clock controller | CC-1 | J2 | Only when primary clock source. |
| NT8D79AA | PRI card | | J2 | Clock controller | CC-1 | J1 | Only when secondary clock source. |
| QCAD125 | Clock controller | CC-0 | J3 | Clock controller | CC-1 | J3 | Clock Controller back-up. |
| NT8D85AB | PRI card | | J3 | Network | | | Run directly to Network pack. |
| QCAD328A | PRI card | | J2 | DCHI | | J2 | Run directly to DCHI card. |
| NTND26 | PRI card | | J5 | MSDL | | | |
| NT8D7207 | PRI card | | J4 | I/O Panel | | | |
| RS-232 | I/O Panel | | | Echo canceller | | | |
| RS-232 | PRI card | | J6 | Echo canceller | | | |
| NT8D7205 | I/O Panel | | | cross connect | | | Run via cabinet I/O panel to crossconnect terminal from switch. |

 **Note:**

No additional cabling is required for multiple PRIs. The D-channel is associated through software in LD 17 (prompt PRI).

Table 29: Cable for the NT8D72 PRI card for Multi Group systems

| Cable | From | Des. | Con. | To | Des. | Con. | Notes |
|----------|------------------|------|------|----------------|------------------|------|-------|
| QCAD130 | PRI card | | | J1 | Clock controller | CC-0 | 1 |
| QCAD130 | PRI card | | | J1 | Clock controller | CC-0 | 2 |
| QCAD130 | PRI card | | | J2 | Clock controller | CC-1 | 1 |
| QCAD130 | PRI card | | | J2 | Clock controller | CC-1 | 2 |
| QCAD110 | Clock controller | CC-0 | J3 | Junctor board | JCTR | J11 | 3 |
| QCAD110 | Clock controller | CC-1 | J3 | Junctor board | JCTR | J12 | |
| QCAD124 | PRI card | | J3 | Network | | | 4 |
| QCAD328A | PRI card | | J5 | DCHI card | | J2 | 5 |
| NTND26 | PRI card | J5 | | MSDL | | | |
| QCAD128 | PRI card | | J4 | I/O Panel | | | 6 |
| QCAD133 | I/O Panel | | | Patch Panel | | | 6 |
| QCAD129 | PRI card | | J6 | I/O Panel | | | 6 |
| RS-232 | I/O Panel | | | Echo Canceller | | | |
| RS-232 | PRI card | | J6 | Echo Canceller | | | 7 |
| QCAD133 | PRI card | | J4 | Patch Panel | | | 7 |
| RS-232 | PRI card | | J6 | Echo Canceller | | | 7 |

 **Note:**
Only when primary clock source.

 **Note:**
Only when secondary clock source.

 **Note:**
multigroup junctor board connection.

| Cable | From | Des. | Con. | To | Des. | Con. | Notes |
|---|------|------|------|----|------|------|-------|
| <p> Note: Run to connector on network pack.</p> <p> Note: Run directly to DCHI card.</p> <p> Note: Run by means of cabinet I/O panel to CSU, echo canceller, or cross connect terminal.</p> <p> Note: Run by means of cabinet I/O panel to crossconnect terminal or echo canceller from non shielded system.</p> <p> Note: No additional cabling is required for multiple PRIs. The D-channel is associated through software in LD17, prompt PRI.</p> | | | | | | | |

Table 30: Cable for the QPC720 PRI card for Half and Multi Group systems

| Cable | From | Des. | Con. | To | Des. | Con. | Comments |
|-----------------------|-----------------------|------|------|-------------------|------|------|-----------------------------------|
| For half group only | | | | | | | |
| QCAD130 NT8D79xx | QPC720 | | J1 | QPC471/ QPC775 | CC-0 | J2 | Only when primary clock source. |
| QCAD130 NT8D79xx | QPC720 | | J1 | QPC471/ QPC775 | CC-0 | J1 | Only when secondary clock source. |
| NTND26 | QPC720 | | J5 | NT6D80 | | | |
| For single group only | | | | | | | |
| QCAD130 NT8D79xx | QPC720 | | J2 | QPC471/ QPC775 | CC-1 | J2 | Only when primary clock source. |
| QCAD130 NT8D79xx | QPC720 | | J2 | QPC471/ QPC775 | CC-1 | J1 | Only when secondary clock source. |
| QCAD125 NT8D75xx | QPC471 / QPC775 | CC-0 | J3 | QPC471/ QPC775 | CC-1 | J3 | Clock controller back-up. |
| QCAD124 NT8D85xx | QPC720 | | J3 | Network | | | Run directly to network card. |

| Cable | From | Des. | Con. | To | Des. | Con. | Comments |
|---------------------|-----------|------|------|----------------|------|------|--|
| QCAD328A | QPC720 | | J5 | QPC757 | | J2 | Run directly to DCHI card. |
| NTND26 | QPC720 | | J5 | NT6D80 | | | |
| QCAD133 | I/O Panel | | | Patch panel | | | Run via cabinet I/O panel to CSU, Echo Cancellor, or cross connect terminal. |
| QCAD129 | QPC720 | | J6 | I/O Panel | | | |
| RS-232 | I/O Panel | | | Echo Cancellor | | | |
| RS-232 | QPC720 | | J6 | Echo Cancellor | | | |
| QCAD133 NT8D83xx | QPC720 | | J4 | Patch panel | | | Run via cabinet I/O panel to crossconnect terminal or Echo Cancellor from non-shielded system. |

Table 31: Cable for the QPC720 PRI card on Multi Group systems

| Cable | From | Des. | Con. | To | Des. | Con. | Notes |
|---------------------|--------|------|------|----|--------------------------|------|----------------------------------|
| QCAD130 NT8D79xx | QPC720 | | | J1 | QPC4 71 QCP7 75 | CC-0 | Only when primary clock source |
| QCAD130 NT8D79xx | QPC720 | | | J1 | QPC4 71 QCP7 75 | CC-0 | Only when secondary clock source |
| QCAD130 NT8D79xx | QPC720 | | | J2 | QPC4 71 QCP7 75 | CC-1 | Only when primary clock source |
| QCAD130 NT8D79xx | QPC720 | | | J2 | QPC4 71 | CC-1 | Only when secondary clock source |

| Cable | From | Des. | Con. | To | Des. | Con. | Notes |
|---------------------|------------------|------|------|-------------------|--------|------|--|
| | | | | | QCP775 | | |
| QCAD110 NT8D74xx | QPC471 QCP775 | CC-0 | J3 | QPC417 | JCTR | J11 | multigroup junctor board connection |
| QCAD110 NT8D74xx | QPC471 QCP775 | CC-1 | J3 | QPC417 | JCTR | J12 | |
| QCAD124 NT8D85xx | QPC720 | | J3 | Network | | | Run to connector on network pack |
| QCAD328 | QPC720 | | J5 | QPC757 | | J2 | Run directly to DCHI card |
| NTND26 | QPC720 | | J5 | NT6D80 | | | |
| QCAD128 NT8D83xx | QPC720 | | J4 | I/O Panel | | | Run via cabinet I/O panel to CSU, Echo Canceller, or crossconnect terminal |
| QCAD133 NT8D83xx | I/O Panel | | | Patch Panel | | | Run via cabinet I/O panel to CSU, Echo Canceller, or crossconnect terminal |
| QCAD129 NT9J93xx | QPC720 | | J6 | I/O Panel | | | Run via cabinet I/O panel to CSU, Echo Canceller, or crossconnect terminal |
| RS-232 | I/O Panel | | | Echo Canceller | | | |
| RS-232 | QPC720 | | J6 | Echo Canceller | | | Run via cabinet I/O panel to Echo Canceller or crossconnect terminal from non-shielded system |


| Cable | From | Des. | Con. | To | Des. | Con. | Notes |
|---------------------|--------|------|------|-------------------|------|------|---|
| QCAD133 NT8D83xx | QPC720 | | J4 | Patch Panel | | | Run via cabinet I/O panel to Echo Cancellor or crossconnect terminal from non-shielded system |
| RS-232 | QPC720 | | J6 | Echo Cancellor | | | Run via cabinet I/O panel to Echo Cancellor or crossconnect terminal from non-shielded system |

Switch settings


[Figure 59: NT8D72AA, NT8D72AB, NT8D72BA PRI DIP switch settings for Large Systems](#) on page 149 shows the NT8D72AA, NT8D72AB, and NT8D72BA PRI DIP switch settings for Large Systems. [Figure 60: QPC720 switch settings for Half and Single Group systems](#) on page 150 shows the QPC720 PRI switch settings for Large Systems.

[Table 32: NT8D72 and QPC720 PRI transmission equalization switch settings for Large Systems](#) on page 150 indicates the Transmission equalization switch settings for the NT8D72 and QPC720 PRI cards for Large Systems.

NT8D72AA, NT8D72AB



NT8D72BA




553-7533

Figure 59: NT8D72AA, NT8D72AB, NT8D72BA PRI DIP switch settings for Large Systems

**Note:**

For EuroISDN applications, use the default setting (120 ohms).



553-1503

Figure 60: QPC720 switch settings for Half and Single Group systems

Table 32: NT8D72 and QPC720 PRI transmission equalization switch settings for Large Systems

| Switch S2 settings | To repeater facility | To crossconnect point |
|---|----------------------------|----------------------------|
| 5 on | 0 - 45 m (0 - 150 ft) | 0 - 30 m (0 - 100 ft) |
| 2, 4, 6 on | 46 - 135 m (151 - 450 ft) | 31 - 100 m (101 - 355 ft) |
| 1, 3, 7 on | 136 - 225 m (451 - 750 ft) | 101 - 200 m (356 - 655 ft) |
| Switch 3 options for PRI with ESF | | |
| SW3-1 on = extended superframe format (ESF) off = superframe format (SF) | | |
| <p> Note: All positions on S2 (location B22) are OFF except as shown under the column labeled "Switch S2 settings." The 8-pole SW3 (location E37) positions are OFF except for SW3-1 as shown for "Switch 3 option for DTI with ESF."</p> <p> Note: For D2, D3, or D4 framing formats (superframe formats), set all SW3 options to OFF.</p> | | |

Install NT8D72 and QPC720 PRI cards on Large Systems

Use [Install the NT8D72 and QPC720 PRI on Large Systems](#) on page 151 to install the NT8D72 and QPC720 PRI cards on Large Systems.

Install the NT8D72 and QPC720 PRI on Large Systems

1. Determine the cabinet and shelf location of the circuit card to be installed. The following slots can be used if they are not required for other cards.

Table 33: Shelf and slot location of NT8D72 and QPC720 for Half Group and Single Group systems

| System | Shelf | Slot |
|--------------------------|---------------------|------------------------|
| Half Group, Single Group | NT6D39 CPU/NET | 3–8 Note 1 18 Note 3 |
| | NT8D35 DTI Exp Cube | 2–3 Note 1 5–14 Note 1 |
| Multi Group | Core | 0-3 |
| | Network Module | 5–10, 13–14 |



Note:

DTI/PRI packs require two slots. The slot indicated is the maximum slot that the pack resides in. For example, the slot 14 pack uses slots 13 and 14.



Note:

The DTI/PRI pack cannot be installed in slot 11. The pack would come in contact with the BTU installed between slots 11 and 12.



Note:

Slot 18 is only available on CPU shelf, which has no MDU/FDU.



Note:

DTI/PRI pack could reside in slots 10 and 11, but cannot reside in slots 11 and 12 because of powering restrictions.

2. Unpack and inspect the PRI cards.
3. Set the option switches on the PRI circuit cards.
4. Install the PRI circuit card in the assigned shelf and slot.
5. Install the network circuit card (if no network loop connection is available).
6. If required, install I/O adapters in the I/O panel.
7. Run and connect the PRI cables.
8. If required, install connecting blocks at MDF or wall-mounted crossconnect terminal.
9. If required, designate connecting blocks at MDF or wall-mounted crossconnect terminal.
10. If required, install CSU or Echo Cancellor.
11. Crossconnect PRI circuits.

12. Add related office data into system memory. Refer to the work order.
13. Run PRI verification tests.

Remove NT8D72 and QPC720 PRI cards from Large Systems

To remove the NT8D72 and QPC720 PRI cards from Large Systems:

1. Disable the D-channel in LD 96.
2. Disable Network Loop using LD 60. The command is `DISL x`.
3. Remove the data from memory if the circuit card is being completely removed, not replaced.
4. Determine the location of the circuit cards to be removed.
5. Remove cross connections at MDF to wall-mounted crossconnect terminal.
6. Disconnect PRI cables at Echo Cancellor and at carrier interface (for example, Office Repeater and NCTE equipment).
7. Tag and disconnect cables from card. Rearrange Clock Controller card cables if required. This affects call processing on DTI/PRI loops.
8. Remove PRI and network circuit cards. If the other circuit of a dual network card is in use, DO NOT remove the network card.
9. Pack and store circuit card.

Install an additional network shelf

Use [Install an additional network shelf on Half Group and Single Group systems](#) on page 152 to install an additional network shelf, when additional shelf space is required for PRI cards on Half Group and Single Group systems. A QUD15 cooling unit is required for each additional shelf installed.

 **Caution:**

Do not place the circuit packs in the shelf until Step 7 is completed.

Install an additional network shelf on Half Group and Single Group systems

1. Determine the cabinet and shelf location of the Network shelf to be installed.
2. Unpack and inspect the shelf.

3. Remove the existing left or right rear Intelligent Peripheral Equipment (IPE) shelf (if required).
4. Install the additional Network shelf in the IPE (Step 3) location.
5. Install a QUD15 cooling unit directly below the Network shelf and secure with four mounting screws.
6. Install and connect the QCAD172A power cable to the added QUD15 cooling unit as follows:
 - If the added QUD15 is located below the left Network shelf, unplug the C11 connector from the QCAD111 power harness that connects to the existing left side QUD15.
 - If the added QUD15 is located below the right Network shelf, unplug the C21 connector from the QCAD111 power harness instead of the C11.
7. Plug the C11 or C21 connector into the single-ended connector of the QCAD172A power cable.
8. Plug one of the two connectors at the other end of the C11 or C21 connector that was removed.
9. Plug the remaining connector of the QCAD172A power cable into the added QUD15.
10. Adjust the QCAD111 power wiring harness, untie and then connect:
 - the C17 power connection cable to the right rear Network shelf
 - the C19 power connection cable to the left rear Network shelf
11. Install PRI trunks and enter related shelf and PRI office data into switch memory.

Chapter 11: NT5D97 Dual-port DTI2/PRI2 installation and removal

Contents

The section contains information about the following topics:

[Introduction](#) on page 155

[NT5D97 circuit card locations](#) on page 156

[Port definitions](#) on page 156

[Case Scenarios for replacing a digital trunk NT8D72BA, QPC536E, or NTCK43 by a DDP2 card](#) on page 157

[NT5D97AA/AB DIP switch settings](#) on page 157

[Install the NT5D97 DDP2](#) on page 168

[Remove the NT5D97 DDP2](#) on page 169

[Configure the NT5D97 DDP2](#) on page 170

Introduction

This section contains information required to install the NT5D97 Dual-port DTI2/PRI2 (DDP2) card on Large Systems.

For installation and removal procedures for the NTBK51AA/NTBK51CA Downloadable D-channel daughterboard, refer to the section [NTBK51 DDCH installation and removal](#) on page 103.

NT5D97 circuit card locations

Each NT5D97 card requires one slot on a shelf. NT5D97 cards can be placed in any card slot in the network bus.

Port definitions

Because of the NT5D97 card is a dual-card, it equips two ports; these ports can be defined in the following combinations:

Table 34: NT5D97AA/AB loops configuration

| Loop 0 | | | | |
|--------|----------------|----------------|------|------|
| Loop 1 | | not configured | DTI2 | PRI2 |
| | not configured | V | V | V |
| | DTI2 | V | V | V |
| | PRI2 | V | V | V |

Table 35: NT5D97AD loops configuration

| Loop 0 | | | | | |
|--------|----------------|----------------|------|------|------|
| Loop 1 | | not configured | DTI2 | PRI2 | DDCS |
| | not configured | V | V | V | V |
| | DTI2 | V | V | V | V |
| | PRI2 | V | V | V | X |
| | DDCS | V | V | X | V |

 **Note:**

Each loop DPNSS can be defined in Normal or Extended addressing mode.

Case Scenarios for replacing a digital trunk NT8D72BA, QPC536E, or NTCK43 by a DDP2 card

The following discussion describes possible scenarios when replacing a digital trunk NT8D72BA PRI2 card or QPC536E DTI2 card or NTCK43 Dual PRI card configuration with a NT5D97 DDP2 card configuration.

Case 1 - The two ports of a QPC414 network card are connected to two digital trunks.

In this case, the QPC414 and the two digital trunks are replaced by a single DDP2 card, which is plugged into the network shelf in the QPC414 slot.

Case 2 - One port of the QPC414 card is connected to a digital trunk, and the second is connected to a peripheral buffer. Both cards are in a network loop location.

In this case, the QPC414 should not be removed. The digital trunk is removed and the DDP2 card is plugged into one of the two empty slots.

Case 3 - The network shelf is full, one port of a QPC414 network card is connected to a digital trunk, and the second is connected to a peripheral buffer. This arrangement is repeated for another QPC414. The digital trunks are located in a shelf that provides only power.

In this case, the peripheral buffers need to be reassigned, so that each pair of buffers uses both ports of the same QPC414 card. The other QPC414 card can then be replaced by the NT5D97 DDP2.

Note:

If an NT8D72BA/NTCK43 card is being replaced by a DDP2 card, the D-channel Handler can be reconnected to the DDP2 card, or removed if an onboard NTBK51DDCH card is used. Also, DIP Switches in the NT5D97 must be set properly before insertion. NT5D97 has a different DIP Switch setting from NTCK43AB. Refer to [NT5D97AA/AB DIP switch settings](#) on page 157 for DIP switch setting).


NT5D97AA/AB DIP switch settings

The NT5D97 DDP2 card is equipped with 6x2 sets of DIP switches for trunk parameters settings for port0 and port1 respectively. Additionally, the DDP2 card is equipped with one set of four DIP switches for the Ring Ground setting. The NT5D97AA/AB has one set of eight DIP switches and NT5D97AD has two sets of ten DIP switches for the D-channel Handler parameters setting.

The DIP switches are used for the setting of default values of certain parameters. Firmware reads the general purpose switches, which sets the default values accordingly.

Table 36: DIP switch settings for NT5D97AA/AB

| | Card | Trunks 0 and 1 | Port 0 | Port 1 | Trunk 0 | Trunk 1 |
|-----------------------------------|------|-------------------|--------|--------|---------|---------|
| ENB/DSB mounted on the face plate | S1 | | | | | |
| Ring Ground | | S2 | | | | |
| MSDL | | | S3 | | | |
| Tx Mode | | | | | S4 | S10 |
| LBO Setting | | | | | S5 | S11 |
| | | | | | S6 | S12 |
| | | | | | S7 | S13 |
| Receiver Interface | | | | | S8 | S14 |
| General Purpose | | | | | S9 | S15 |



553-7405

Figure 61: DIP switches for NT5D97AA/AB

The following parameters are set by DIP switches. The boldface font shows the factory setup.

Trunk interface switches for NT5D97AA/AB

Impedance level and unit mode

The S9/S15 switch selects the impedance level and loop operation mode on DEI2 OR PRI2. Refer to [Table 37: Impedance level and loop mode switch settings](#) on page 160.

Table 37: Impedance level and loop mode switch settings

| Switch | Description | S9/S15 Switch Setting |
|--------|-----------------|--|
| 1 | Impedance level | OFF - 120 ohm ON - 75 ohm |
| 2 | Spare | X |
| 3 | Spare | X |
| 4 | Unit mode | OFF - Loop operates in the DTI2 mode ON - Loop operates in the PRI2 mode |

Transmission mode

A per-trunk switch (S4/S10) provides a selection of the digital trunk interface type. Refer to [Table 38: Impedance level and loop mode switch settings](#) on page 160.

Table 38: Impedance level and loop mode switch settings

| Description | S4/S10 switch settings |
|-------------|------------------------|
| E1 | OFF |
| Not used | |

Line build out

A per-trunk set of three switches (S5/S11, S6/S12 and S7/S13) provides the dB value for the line build out. Refer to [Table 39: Trunk interface line build out switch settings](#) on page 161.



Note:

Do not change this setup.

Table 39: Trunk interface line build out switch settings

| Description | Switch setting | | |
|-------------|----------------|--------|--------|
| | S5/S11 | S6/S12 | S7/S13 |
| 0dB | OFF | OFF | OFF |

Receiver impedance

A per-trunk set of four DIP switches (S8/S14 provides selection between 75 or 120 ohm values. Refer to [Table 40: Trunk interface impedance switch settings](#) on page 161.

Table 40: Trunk interface impedance switch settings

| Description | S8/S14 switch setting | | | |
|-------------|-----------------------|-----|-----|----|
| | 75 ohm | OFF | OFF | ON |
| 120 ohm | OFF | OFF | OFF | ON |

Ring ground switches for NT5D97AA/AB

A set of four DIP switches (S2) selects which Ring lines are connected to the ground. Refer to [Table 47: LBO switches for NT5D97AD](#) on page 165.

Table 41: Ring ground switch settings

| Switch | Description | S2 switch settings |
|--------|------------------|---|
| 1 | Trunk 0 Transit | OFF-Ring line is not grounded ON- Ring line is grounded |
| 2 | Trunk 0 Receive | OFF-Ring line is not grounded ON- Ring line is grounded |
| 3 | Trunk 1 Transmit | OFF-Ring line is not grounded ON- Ring line is grounded |
| 4 | Trunk 1 Receive | OFF-Ring line is not grounded ON- Ring line is grounded |

DCH Address select switch for NTBK51AA/NTBK51CA daughter board for NT5D97AA/AB

In case of an onboard NTBK51AA/NTBK51CAD-channel daughterboard, a set of four switches (S3) provide the daughterboard address. Refer to [Table 49: Trunk 1 switches](#) on page 166.

 **Note:**

Switch 8 of S3 (S3-8) does not require a switch setting to select between the onboard NTBK51AA/NTBK51CA D-channel daughterboard and an external DCHI/MSDL. The NT5D97 detects when the onboard NTBK51AA/NTBK51CA D-channel daughterboard is used.

Table 42: DCH mode and address switch settings

| Switch | Description | S3 switch setting |
|--------|---------------------------------|-------------------|
| 1-4 | D-channel daughterboard address | See table |
| 5-8 | For future use | OFF |

[Table 50: Ring ground switch for NT5D97AD](#) on page 166 shows the possible selections of the NTBK51AA/NTBK51CA D-channel.

Table 43: NTBK51AA/NTBK51CA daughterboard addressselect switch settings

| Device Address | Switch Setting | | | |
|----------------|----------------|-----|-----|-----|
| 0 | OFF | OFF | OFF | OFF |
| 1 | ON | OFF | OFF | OFF |
| 2 | OFF | ON | OFF | OFF |
| 3 | ON | ON | OFF | OFF |
| 4 | OFF | OFF | ON | OFF |
| 5 | ON | OFF | ON | OFF |
| 6 | OFF | ON | ON | OFF |
| 7 | ON | ON | ON | OFF |
| 8 | OFF | OFF | OFF | ON |
| 9 | ON | OFF | OFF | ON |
| 10 | OFF | ON | OFF | ON |
| 11 | ON | ON | OFF | ON |
| 12 | OFF | OFF | ON | ON |
| 13 | ON | OFF | ON | ON |
| 14 | OFF | ON | ON | ON |
| 15 | ON | ON | ON | ON |

 **Note:**

The system contains a maximum number of 16 DCHI, MSDL, and DDCH devices. The Device Addresses are equivalent to the MSDL DNUM designations.

| Device Address | Switch Setting |
|--|---|
|  Note: | Device address 0 is commonly assigned to the System TTYD Monitor. |

NT5D97AD DIP switch settings


The NT5D97 DDP2 card is equipped with 6x2 sets of DIP switches for trunk parameters settings for port 0 and port 1 respectively. Additionally, the DDP2 card is equipped with one set of four DIP switches for the Ring Ground setting. The NT5D97AA/AB has one set of eight DIP switches and NT5D97AD has two sets of ten DIP switches for the D-channel Handler parameters setting.

The DIP switches are used for the setting of default values of certain parameters. Firmware reads the general purpose switches, which sets the default values accordingly

Table 44: DIP switch settings for NT5D97AD

| | Card | Trunks 0 and 1 | Port 0 | Port 1 | Trunk 0 | Trunk 1 |
|-----------------------------------|------|-------------------|--------|--------|---------|---------|
| ENB/DSB mounted on the face plate | S1 | | | | | |
| Ring Ground | | S16 | | | | |
| DPNSS | | | S8 | S9 | | |
| MSDL | | | S9 | | | |
| TX Mode | | | | | S2 | S10 |
| LBO Setting | | | | | S3 | S13 |
| | | | | | S4 | S14 |
| | | | | | S5 | S15 |
| Receiver Interface | | | | | S6 | S11 |
| General Purpose | | | | | S12 | S7 |

Refer to DIP switch locations in [Figure 62: Dip switches locations for NT5D97AD](#) on page 164.



553-AAA0367

Figure 62: Dip switches locations for NT5D97AD

The following parameters are set by DIP switches. The boldface font shows the factory setup.

Trunk interface switches for NT5D97AD

Trunk 0 switches

Switch S12 gives the MPU information about its environment as shown in [Table 45: General purpose switches for NT5D97AD](#) on page 165.

Table 45: General purpose switches for NT5D97AD

| Switch | Description | S9/S15 Switch Setting |
|--------|-----------------|--|
| S12_1 | Impedance level | OFF - 120 ohm ON - 75 ohm |
| S12_2 | Spare | For future use |
| S12_3 | Spare | For future use |
| S12_4 | Unit mode | OFF - Unit operates in the DTI2 mode ON - Unit operates in the PRI2 mode |

Switch S2 selects the Transmission mode as shown in [Table 46: TX mode switches for NT5D97AD](#) on page 165.

Table 46: TX mode switches for NT5D97AD

| TX mode | S2 |
|----------|-----|
| E1 | OFF |
| Not used | ON |

Switch S3, S4, and S5 select LBO function as is [Table 47: LBO switches for NT5D97AD](#) on page 165.

Table 47: LBO switches for NT5D97AD

| LBO setting | S3 | S4 | S5 |
|-------------|-----|-----|-----|
| 0dB | OFF | OFF | OFF |
| 7.5dB | ON | ON | OFF |
| 15dB | ON | OFF | ON |

Switch S6 selects the Receiver interface as in [Table 48: Receiver interface switches for NT5D97AD](#) on page 166.

Table 48: Receiver interface switches for NT5D97AD

| Impedance | S6-1 | S6-2 | S6-3 | S6-4 |
|-----------|------|------|------|------|
| 75 ohm | OFF | OFF | ON | OFF |
| 120 ohm | OFF | OFF | OFF | ON |

Trunk 1 switches for NT5D97AD

Table 49: Trunk 1 switches

| Switch | Function |
|----------------|---|
| S7 | General Purpose...See Table 45: General purpose switches for NT5D97AD on page 165 |
| S10 | TX Mode...See Table 46: TX mode switches for NT5D97AD on page 165 |
| S13, S14 & S15 | LBO...See Table 47: LBO switches for NT5D97AD on page 165 |
| S11 | RX Impedance...See Table 48: Receiver interface switches for NT5D97AD on page 166 |

Ring ground switches for NT5D97AD

Switch S16 selects which ring lines connect to ground. When set to ON, the ring line is grounded as shown in [Table 50: Ring ground switch for NT5D97AD](#) on page 166.

Table 50: Ring ground switch for NT5D97AD

| Switch | Line |
|--------|------------------|
| S16_1 | Trunk 0 Transmit |
| S16_2 | Trunk 0 Receive |
| S16_3 | Trunk 1 Transmit |
| S16_4 | Trunk 1 Receive |

DCH Address select switch for NTBK51AA/NTBK51CA daughter board for NT5D97AD

Switch S9 selects the NTBK51AA/NTBK51CA DCH daughterboard address.

Switch S8 is not used when the NTBK51AA/NTBK51CA daughterboard is used. S8_1-10 can be set to OFF position as in [Table 51: NTBK51AA/NTBK51CA DCH switches for NT5D97AD](#) on page 167.

Table 51: NTBK51AA/NTBK51CA DCH switches for NT5D97AD

| Switch number | Function |
|---------------|------------------------------------|
| S9_1-4 | DCH daughter card address |
| S9_5-8 | Set to OFF |
| S9_9 | Set to ON (NTBK51AA/NTBK51CA Mode) |
| S9_10 | Set to ON (NTBK51AA/NTBK51CA Mode) |

MSDL external card

[Table 52: Switch settings for MSDL external card](#) on page 167 lists the switch numbers assigned for future use on the MSDL external card.

Table 52: Switch settings for MSDL external card

| Switch number | Function |
|---------------|----------------|
| S9_1-10 | For future use |
| S8_1-10 | For future use |

Use [Table 53: Switch setting for MSDL external card](#) on page 167 to set the card address.

Table 53: Switch setting for MSDL external card

| DNUM (LD 17) | Switch Setting | | | |
|--------------|----------------|-----|-----|-----|
| | 1 | 2 | 3 | 4 |
| 0 | OFF | OFF | OFF | OFF |
| 1 | ON | OFF | OFF | OFF |
| 2 | OFF | ON | OFF | OFF |
| 3 | ON | ON | OFF | OFF |
| 4 | OFF | OFF | ON | OFF |
| 5 | ON | OFF | ON | OFF |
| 6 | OFF | ON | ON | OFF |
| 7 | ON | ON | ON | OFF |
| 8 | OFF | OFF | OFF | ON |

| DNUM (LD 17) | Switch Setting | | | |
|--------------|----------------|-----|-----|----|
| | 1 | 2 | 3 | 4 |
| 9 | ON | OFF | OFF | ON |
| 10 | OFF | ON | OFF | ON |
| 11 | ON | ON | OFF | ON |
| 12 | OFF | OFF | ON | ON |
| 13 | ON | OFF | ON | ON |
| 14 | OFF | ON | ON | ON |
| 15 | ON | ON | ON | ON |

Install the NT5D97 DDP2

Use [Install the NT5D97 on Large Systems](#) on page 168 to install the NT5D97 on Large Systems.

 **Caution:**

The static discharge bracelet located inside the cabinet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

Install the NT5D97 on Large Systems

1. Determine the cabinet and shelf location where the NT5D97 is to be installed. The NT5D97 can be installed in any card slot in the Network bus.
2. Unpack and inspect the NT5D97 and cables.
3. If a DDCH is installed, see the section [NTBK51 DDCH installation and removal](#) on page 103.
4. Set the option switches on the NT5D97 card before installation. Refer to [NT5D97AA/AB DIP switch settings](#) on page 157.

The ENB/DIS (enable/disable faceplate switch) must be OFF (DIS) when installing the NT5D97, otherwise a system initialize can occur. The ENB/DIS on the NT5D97 corresponds to the faceplate switch on the QPC414 Network card.

5. Install NT5D97 card in the assigned shelf and slot.
6. Set the ENB/DIS faceplate switch to ON.

If the DDCH is installed, the DDCH LED should flash three times.

7. If required, install the I/O adapters in the I/O panel.
8. Run and connect the NT5D97 cables

 **Caution:**

Clock Controller cables connecting the Clock Controller and NT5D97 card must NOT be routed through the center of the cabinet past the power harness. Instead they should be routed around the outside of the equipment shelves.

9. If required, install connecting blocks at the MDF or wall mounted crossconnect terminal.
10. If required, designate connecting blocks at the MDF or wall mounted crossconnect terminal.
11. If required, install a Network Channel Terminating Equipment (NCTE). or Line Terminating Unit (LTU).
12. Add related office data into switch memory.
13. Enable faceplate switch S1. This is the "Loop Enable" switch.
The faceplate LEDs should go on for 4 seconds then go off and the OOS, DIS and ACT LEDs should go on again and stay on.
If DDCH is installed, the DCH LED should flash 3 times.
14. Run the PRI/DTI Verification Test.
15. Run the PRI status check.

Remove the NT5D97 DDP2

Use [Remove the NT5D97 from Large Systems](#) on page 169 to remove the NT5D97 from Large Systems

 **Caution:**

The static discharge bracelet located inside the cabinet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

Remove the NT5D97 from Large Systems

1. Determine the cabinet and shelf location of the NT5D97 card to be removed.
2. Disable the Network Loop using the LD 60 command `DISL "loop number"`.
The associated DCHI must be disabled first; do not disable the faceplate switch ENB/DIS until both PRI2/DTI2 loops are disabled.
3. Remove data from memory, if the NT5D97 card is being completely removed, not replaced.
4. Remove cross connections at the MDF to wall-mounted crossconnect terminal.
5. Tag and disconnect cables from the card.
6. Rearrange Clock Controller cables if required.

 **Caution:**

Clock Controller cables connecting the Clock Controller and DDP2 card must NOT be routed through the center of the cabinet past the power harness. Instead, they should be routed around the outside of the equipment shelves.

7. Remove the DDP2 card only if both loops are disabled. If the other circuit of a DDP2 card is in use, DO NOT remove the card. The Faceplate switch ENB/DIS must be in the OFF (DIS) position before the card is removed, otherwise the system initializes.
8. Pack and store the NT5D97 card and circuit card.

Configure the NT5D97 DDP2

After the NT5D97 DDP2 is installed, configure the system using the same procedures as the standard NT8D72BA PRI2.

Consider the following when configuring the NT5D97 DDP2 card:

- The system software allows four ports to be defined for the NT6D80 MSDL. The DDCH (NTBK51AA/NTBK51CA) card has only two ports, 0 and 1; therefore, ports 2 and 3 must not be defined when using the NTBK51AA/NTBK51CA.
- Port 0 of the NTBK51AA/NTBK51CA can only be defined to work with Loop 0 of the NT5D97 DDP2 card, and Port 1 of the NTBK51AA/NTBK51CA can only be defined to work with Loop 1 of the NT5D97. This relationship must be reflected when configuring a new DCH in LD 17 (in response to the DCHL prompt, enter either 0 or 1 when specifying the loop number used by the DCH).
- You cannot define one of the DDP2 loops for the NTBK51AA/NTBK51CA DDCH, and the other loop for the NT6D11AF, NT5K75AA, and NT5K35AA DCH card or the NT6D80 MSDL.
- When configuring the NT5D97 DDP2 in DTI2 outgoing dial pulse mode, a Digit Outpulsing patch is required.

Chapter 12: NT5D12 Dual-port DTI/PRI card installation

Contents

The section contains information about the following topics:

[Introduction](#) on page 171

[NT5D12 circuit card locations](#) on page 172

[Port definitions](#) on page 172

[Scenarios for replacement of a digital trunk card \(QPC720/QPC472\) by a DDP card](#) on page 172

[NT5D12 switch settings](#) on page 173

[General Purpose Switches](#) on page 173

[Trunk interface switches](#) on page 174

[Ring ground switches](#) on page 175

[DCH mode and address select switches](#) on page 175

[Install the NT5D12 DDP](#) on page 178

[Remove the NT5D12 DDP](#) on page 180

[Configure the NT5D12 DDP](#) on page 180

Introduction

This section contains information required to install the NT5D12 1.5 Mb DTI/PRI Dual-port (DDP) card on Large Systems.

For installation and removal procedures for the NTBK51AA/NTBK51CA Downloadable D-channel daughterboard, see the section [NTBK51 DDCH installation and removal](#) on page 103.

NT5D12 circuit card locations

Each NT5D12 circuit card requires one slot on a shelf. NT5D12 cards can be placed in any card slot in the network bus, subject to the cautionary note below.

Port definitions

Because of the NT5D12 card is dual-card, it equips two ports. These ports are defined in the following combinations:

| Port 0 | Port 1 |
|----------------|----------------|
| DTI | DTI |
| DTI | PRI |
| PRI | DTI |
| PRI | PRI |
| DTI | Not configured |
| PRI | Not configured |
| Not configured | PRI |
| Not configured | DTI |

Scenarios for replacement of a digital trunk card (QPC720/QPC472) by a DDP card

The following discussion describes possible scenarios when replacing a digital trunk QPC720 PRI card or QPC472 DTI card configuration with a NT5D12 DDP card configuration.

Case 1 - The two ports of a QPC414 network card are connected to two digital trunks.

In this case, the QPC414 and the two digital trunks are replaced by a single DDP card, which is plugged into the CE shelf in the QPC414 slot.

Case 2 - One port of the QPC414 card is connected to a digital trunk, and the second is connected to a peripheral buffer. Both cards are in the network loop location.

In this case, the QPC414 should not be removed. The digital trunk is removed and the DDP card is plugged into one of the two empty slots.

Case 3 - The CE shelf is full, one port of a QPC414 network card is connected to a digital trunk, and the second is connected to a peripheral buffer. This arrangement is repeated for another QPC414. The digital trunks are located in a shelf that provides only power.

In this case, the peripheral buffers need to be reassigned, so that each pair of buffers can use both ports of the same QPC414 card. The other QPC414 card can then be replaced by the NT5D12 DDP.

Note in all cases - If a QPC720 card is being replaced by a DDP card, the D-channel Handler or MSDL can be either reconnected to the DDP card, or removed if an onboard NTBK51AA/NTBK51CA DDCH card is used.

NT5D12 switch settings

The NT5D12 card is equipped with 6x2 sets of DIP switches for trunk parameters settings for port0 and port1 respectively. Additionally, the NT5D12 card is equipped with one set of four DIP switches for the Ring Ground setting and one set of eight DIP switches for the D-channel Handler parameters setting.

The DIP switches are used for setting of default values of certain parameters. The general purpose switches are read by the firmware which sets the default values accordingly.

The following parameters are being set by the DIP switches. Factory setups are shown in bold.

General Purpose Switches

A per-trunk set of four DIP switches provides the default setting for operational modes. Switch set S9 is used for Trunk 0. Switch set S15 is used for Trunk 1. Refer to [Table 54: General purpose switch settings](#) on page 173'.

Table 54: General purpose switch settings

| Switch | Description | S9/S15 Switch Setting |
|--------|----------------------------|--------------------------|
| 1 | Framing Mode | OFF - ESF ON - SF |
| 2 | Yellow Alarm Method | OFF - FDL ON - Digit2 |
| 3 | Zero Code Suppression Mode | OFF - B8ZS ON - AMI |
| 4 | Unused | OFF |

Trunk interface switches

Transmission Mode

A per-trunk switch provides selection for T1 transmission. See [Table 55: Trunk interface transmission mode switch settings](#) on page 174.

Table 55: Trunk interface transmission mode switch settings

| Description | S4/S10 Switch Setting |
|-----------------|-----------------------|
| For future use. | OFF |
| T1 | ON |

Line Build Out

A per-trunk set of three switches provides a selection between 0, 7.5 or 15 dB values. See [Table 56: Trunk interface line build out switch settings](#) on page 174.

Table 56: Trunk interface line build out switch settings

| Description | Switch Setting | | |
|-------------|----------------|--------|--------|
| | S5/S11 | S6/S12 | S7/S13 |
| 0 dB | OFF | OFF | OFF |
| 7.5 dB | ON | ON | OFF |
| 15 dB | ON | OFF | ON |

Receiver Impedance

A per trunk set of four DIP switches provides a selection between 75, 100 or 120 Ω values. See [Table 57: Trunk interface receiver impedance switch settings](#) on page 174.

Table 57: Trunk interface receiver impedance switch settings

| Description | S8/S14 Switch Setting | | | |
|--------------|-----------------------|-----|-----|-----|
| 75 Ω | OFF | OFF | ON | OFF |
| 100 Ω | ON | OFF | OFF | ON |
| 120 Ω | OFF | OFF | OFF | ON |

Ring ground switches

A set of four DIP switches selects which Ring lines are connected to the ground. See [Table 58: Ring ground switch settings](#) on page 175.

Table 58: Ring ground switch settings

| Switch | Description | S2 Switch Setting |
|--------|------------------|---|
| 1 | Trunk 0 Transmit | OFF - Ring line is not grounded ON - Ring line is grounded |
| 2 | Trunk 0 Receive | OFF - Ring line is not grounded ON - Ring line is grounded |
| 3 | Trunk 1 Transmit | OFF - Ring line is not grounded ON - Ring line is grounded |
| 4 | Trunk 1 Receive | OFF - Ring line is not grounded ON - Ring line is grounded |

DCH mode and address select switches

A set of eight DIP switches selects between an onboard NTBK51AA/NTBK51CA D-channel daughterboard and an external MSDL/DCHI card. In the case of an onboard NTBK51AA/NTBK51CA D-channel daughterboard, four of the switches provide the daughterboard address. See [Table 59: DCH mode and address select switch settings](#) on page 175.

Table 59: DCH mode and address select switch settings

| Switch | Description | S3 Switch Setting |
|--------|---------------------------------|--|
| 1-4 | D-channel daughterboard Address | See Table 60: NTBK51AA/NTBK51CA daughterboard address select switch settings on page 175 |
| 5-7 | For future use. | OFF |
| 8 | External DCH or Onboard DDCH | OFF - MSDL or DCHI card ON - Onboard DDCH daughterboard |

Table 60: NTBK51AA/NTBK51CA daughterboard address select switch settings

| Device Address ¹ | Switch Setting | | | |
|-----------------------------|----------------|-----|-----|-----|
| 0 ² | OFF | OFF | OFF | OFF |
| 1 | ON | OFF | OFF | OFF |

| Device Address ¹ | Switch Setting | | | |
|--|----------------|-----|-----|-----|
| 2 | OFF | ON | OFF | OFF |
| 3 | ON | ON | OFF | OFF |
| 4 | OFF | OFF | ON | OFF |
| 5 | ON | OFF | ON | OFF |
| 6 | OFF | ON | ON | OFF |
| 7 | ON | ON | ON | OFF |
| 8 | OFF | OFF | OFF | ON |
| 9 | ON | OFF | OFF | ON |
| 10 | OFF | ON | OFF | ON |
| 11 | ON | ON | OFF | ON |
| 12 | OFF | OFF | ON | ON |
| 13 | ON | OFF | ON | ON |
| 14 | OFF | ON | ON | ON |
| 15 | ON | ON | ON | ON |
| <p>Note 1: The maximum number of DCHI, MSDL, and DDCH devices in the system is 16. Note 1: The Device Addresses are equivalent to the MSDL DNUM designations. Note 2: Device address 0 is commonly assigned to the System Monitor.</p> | | | | |




Figure 63: Switch functional areas on the NT5D12




Figure 64: NT5D12 switch default settings

Install the NT5D12 DDP

Use [Install the NT5D12 on Large Systems](#) on page 179 to install the NT5D12 on Large Systems.

⚠ Caution:

The static discharge bracelet located inside the cabinet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

Install the NT5D12 on Large Systems

1. Determine the cabinet and shelf location where the NT5D12 card is to be installed. The NT5D12 can be installed in any card slot in the Network bus, subject to the cautionary note below.

 **Caution:**

Some installed-based systems can have a Bus Terminating Unit (BTU) already installed. This can interfere with a selected NT5D12 card location. In such cases, the NT5D12 should be installed in an alternate network bus card slot location.

2. Unpack and inspect circuit cards and cables.
3. If a DDCH is to be installed, refer to [NTBK51 DDCH installation and removal](#) on page 103.
4. Set the option switches on the NT5D12 circuit card before installation. Refer to [NTBK51 DDCH installation and removal](#) on page 103.
S1 (faceplate switch) must be OFF (DIS) when installing the NT5D12. S1 on the NT5D12 corresponds to the faceplate switch on the QPC414 Network card.
5. Install the NT5D12 circuit card in the assigned shelf and slot.
6. Add related office administration data into the system memory.
7. If required, install the I/O adapters in the I/O panel.
8. Run and connect the NT5D12 cables.

 **Caution:**

Clock Controller cables connecting the Clock Controller and NT5D12 card must NOT be routed through the center of the cabinet past the power harness. Instead, route them around the outside of the equipment shelves.

9. If required, install connecting blocks at the MDF or wall mounted crossconnect terminal.
10. If required, designate connecting blocks at the MDF or wall mounted crossconnect terminal.
11. If required, install Network Channel Terminating Equipment (NCTE).
12. Enable faceplate switch S1. This is the "Loop Enable" switch.

The faceplate LEDs should go on for 4 seconds then go off and the OOS, DIS and ACT LEDs should go on again and stay on.

IF DDCH is installed, the DCH LED should flash 3 times.

13. Run PRI/DTI Verification Test.
14. Run PRI status check.

Remove the NT5D12 DDP

Use [Remove the NT5D12 DDP](#) on page 180 to remove the NT5D12 from Large Systems.

 **Caution:**

A static discharge bracelet must be worn before handling circuit cards. Failure to wear the bracelet can result in damage to the circuit cards.

Remove the NT5D12 DDP

1. Determine the cabinet and shelf location of the NT5D12 card to be removed.
2. Disable Network Loop using the LD 60 command `DISL loop number`.
The associated DCHI must be disabled first; do not disable the faceplate switch S1 until both PRI loops are disabled.
3. Remove data from memory, if the NT5D12 card is being completely removed, not replaced.
4. Remove cross connections at the MDF to wall-mounted crossconnect terminal.
5. Tag and disconnect cables from card.
6. Rearrange Clock Controller cables if required.

 **Caution:**

Clock Controller cables connecting the Clock Controller and NT5D12 card must NOT be routed through the center of the cabinet past the power harness. Instead they should be routed around the outside of the equipment shelves.

7. Determine if the other circuit of a NT5D12 card is in use. DO NOT remove the card if in use.
8. Remove the NT5D12 card only if both loops are disabled. Switch S1 (faceplate switch) must be in the OFF (DIS) position before the card is removed.
9. Pack and store the NT5D12 card and circuit card.

Configure the NT5D12 DDP

After the NT5D12 DDP is installed, it can be configured using the same procedures as for the standard QPC720 PRI card.

Consider the following when configuring the NT5D12 DDP card:

- The system software allows four ports to be defined for the NT6D80 MSDL. The DDCH (NTBK51AA/NTBK51CA) card has only two ports, 0 and 1; therefore, ports 2 and 3 must not be defined when using the NTBK51AA/NTBK51CA.
- Port 0 of the NTBK51AA/NTBK51CA can only be defined to work with Loop 0 of the NT5D12 DDP card, and Port 1 of the NTBK51AA/NTBK51CA can only be defined to work with Loop 1 of the NT5D12. This relationship must be reflected when configuring a new DCH in LD 17 (in response to the DCHL prompt, enter either 0 or 1 when specifying the loop number used by the DCH).
- You cannot define one of the NT5D12 loops for the NTBK51AA/NTBK51CA DDCH, and the other loop for the QPC757 DCHI or the NT6D80 MSDL.

Chapter 13: Clock Controller description and installation

Contents

The section contains information about the following topics:

[Introduction](#) on page 184

[Description](#) on page 184

[Need for synchronization](#) on page 184

[Supported Clock Controllers](#) on page 185

[Synchronization methods](#) on page 186

[Hierarchical synchronization](#) on page 187

[Stratum levels](#) on page 188

[Frame slip](#) on page 189

[Guidelines](#) on page 190

[Modes of operation](#) on page 196

[Small System Clock Controller daughterboard](#) on page 197

[Installation procedures](#) on page 197

[Determine slots and shelves](#) on page 198

[Set switches](#) on page 198

[Start the Clock Controller](#) on page 200

[Clock Controller commands](#) on page 200

[Install or replace a Clock Controller on a Half Group and Single Group system](#) on page 200

[Install or replace a Clock Controller on a Single Group and Multi Group System](#) on page 202

[Upgrade to an NTRB53 Clock Controller on a Single Group and Multi Group System](#) on page 203

Introduction

This chapter introduces the NTRB53 Clock Controller, and provides procedures on how to install this clock controller on Large Systems.

The NTRB53 Clock Controller replaces the QPC471H and QPC775F in new systems. QPC471H and QPC775F Clock Controllers continue to be supported.

 **Note:**

The NTRB53 Clock Controller cannot be combined with a QPC775 or a QPC471 card in one system

The illustrations used in the description section depict a Small System. However, the system can also be representative of a Large System.

Description

This section provides an overview on the use of clock controllers. For Large Systems, the following clock controllers are supported:

- NTRB53
- QPC471
- QPC775

 **Note:**

Clock controllers cannot be mixed in one system.

The NTRB53 Clock Controller is available for all markets. The QPC471 Clock Controller is available for U.S. markets. Vintages A through G of the QPC471 Clock Controller can be used in one system; vintage H of QPC471 Clock Controllers cannot be mixed with clock controllers of other vintages.

The QPC775E Clock Controller card is available for only Canadian and International markets.

Need for synchronization

Digital trunking requires synchronized clocking so that a shift in one clock source results in an equivalent shift of the same size and direction in all parts of the network.

When digital signals are being transported over a communication link, the receiving end must operate at the same frequency (data rate) as the originating end to prevent loss of information.

This is referred to as link synchronization. If both ends of a communication link are not in synchronization, data bit slips occur and therefore a loss of data results. In general, accurate timing is very important, but more importantly synchronized timing is a must for reliable data transfer.

When only two switches are interconnected, synchronization can be achieved by operating the two systems in a master/slave mode whereby one system derives its timing from the other. However, in a network of digital systems, slips can be better prevented by forcing all digital systems to use a common reference clock (see [Figure 65: Hierarchical Synchronization](#) on page 188).

Supported Clock Controllers

For Large Systems, the following clock controllers are supported:

- NTRB53
- QPC471
- QPC775

NTRB53 Clock Controller

The NTRB53 Clock Controller is a replacement for the QPC471 and QPC775 Clock Controllers. The NTRB53 clock controller retains existing functionality.

Software configuration of the clock remains unchanged. A PSDL object allows field upgrades of the clock's firmware. Overlay changes allow for force download and status checking. Support for the IDC command and hardware inventory are also included.

System Initialization

During system initialization, the system software verifies if the clock controllers equipped in the system are the downloadable clock controllers (NTRB53) or not. If the clock controllers are identified as the downloadable clock controller cards, then both downloadable clock controller cards is checked for the software version number they are running with. This is compared with the version number of the PSDL file stored in the system software database.

If there is a mismatch between the two version numbers and the system database has the higher version number, the card is put in the PSDL downloading tree. Once the entry is added in the PSDL tree, the preprocess step is done. The next step is for the system to initiate the downloading in the background, using the PSDL tree. As soon as the download complete message is received from the card, the CPU sends a message to reset the clock controller card so that it boots with the new software. Once a self-test is complete the core sends an enable base message to enable the card.

Maintenance Overlays

Downloading can be initiated from LD 60 for the inactive clock controller card as part of the enabling sequence of the card. A download can be forced by specifying the optional parameter FDL (Force Download) when enabling the card. At the prompt, enter:

ENL CC x FDL Enable Clock in side x with the force download option

If the optional parameter is not specified, then downloading is conditional. This means that the version number of the loadware on the clock controller card is checked against the version number stored on the system disk. If a mismatch is found and the version number in the system software database is higher, then downloading is initiated for that card. The entry for the card is not added to the PSDL tree at this time. Instead, downloading is initiated on a single card and only that card is allowed to perform the force download option.

QPC471 and QPC775 Clock Controllers

Clock Controllers QPC471 and QPC775 continues to function with the following Avaya Communication Server 1000 (Avaya CS 1000) systems:

- CS 1000M HGsystems
- CS 1000M SGsystems
- CS 1000M MGsystems



Note:

[Description](#) on page 184 for market and application availability information.

Synchronization methods

There are two common methods of operation for maintaining timing coordination between switching systems, Plesiosynchronous and Mesosynchronous.

Plesiosynchronous operation

In a Plesiosynchronous operation, nodal clocks run independently (free run) at the same nominal frequency. There are frequency differences between clocks resulting in frame slips (see [Frame slip](#) on page 189.) The magnitude of frame slips are directly proportional to the frequency difference. Slips are inevitable but can be minimized by using very stable clocks and elastic stores or buffers. These buffers are capable of absorbing a certain number of data bits to compensate for slight variances in clock frequencies.

Mesosynchronous operation

In a Mesosynchronous operation, nodal clocks are continuously and automatically locked to an external reference clock. With this method, frame slips can be eliminated if elastic stores are large enough to compensate for transmission variances. Mesosynchronous operation is virtually slip free.


Whenever possible the system uses the Mesosynchronous mode of operation by using the clock controller circuit cards to lock onto an external reference source (such as the Central

Office, another PBX, and so on). This statement is true unless the system is used as a Master in an independent/private network (no digital links to a higher Node Category).

In an isolated private network, the clock controller can operate in free run mode and act as a master clock to be tracked by other PBX systems in the private network.

Hierarchical synchronization

[Figure 65: Hierarchical Synchronization](#) on page 188 provides a general view of the Digital Network Clock Synchronization including the four stratum level Node Categories. Stratum 1 being the most accurate and Stratum 4 being the least accurate. System clocking meets Node Category E Stratum 4 requirements. Also shown are ways of providing a Secondary Clock Source while preventing timing loops.



553-7560.EPS

Figure 65: Hierarchical Synchronization

Stratum levels

In a digital network, nodes are synchronized using a priority master/slave method. Digital nodes are ranked in Stratum levels 1 to 5. Each node is synchronized to the highest ranking node in its neighborhood with which it has a direct link. Refer to [Table 61: Node categories and stratum levels](#) on page 188.

Table 61: Node categories and stratum levels

| | Stratum 2 | Stratum 3 | Stratum 4 |
|----------|-------------------------------|-------------------------------|-------------------------------|
| Accuracy | +/- 1.6 * 10 ⁻⁸ Hz | +/- 4.6 * 10 ⁻⁶ Hz | +/- 3.2 * 10 ⁻⁵ Hz |

| | Stratum 2 | Stratum 3 | Stratum 4 |
|---------------------------|---|---|-------------------------|
| Holdover | $1 * 10^{-10}$ per day | ≤ 255 frame slips in 1st 24 hours | Not Required |
| Hardware Duplication | Required | Required (Note 1) | Not Required |
| MTIE During Rearrangement | MTIE ≤ 1 usec Phase Change Slope: ≤ 81 ns in any 1.326 msec | MTIE ≤ 1 usec Phase Change Slope: ≤ 81 ns in any 1.326 msec | No Requirement (Note 2) |
| Pull-in Range | $\pm 1.6 * 10^{-8}$ Hz | $\pm 4.6 * 10^{-6}$ Hz | $\pm 3.2 * 10^{-5}$ Hz |
| Dedicated Timing Required | Required | Required | Not required |

*** Note:**

Non-duplicated clock hardware that meets all other stratum 3 requirements is referred to as stratum 3ND.

*** Note:**

Stratum 4 clock hardware that meets MTIE requirements during rearrangements is referred to as 4E.

Frame slip

Digital signals must have accurate clock synchronization for data to be interleaved into or extracted from the appropriate timeslot during multiplexing and demultiplexing operations. A Frame Slip is defined (for 2 Mbyte links) as the repetition of, or deletion of the 256 data bits of a CEPT frame due to a sufficiently large discrepancy in the read and write rates at the buffer (clocks are not operating at exactly the same speed).

When data bits are written into (added to) a buffer at a slightly higher rate than that at which they are being read (emptied), sooner or later the buffer overflows. This is a slip-frame deletion.

In the opposite situation, when data bits are written (added) into a buffer at slightly lower rate than that at which they are being read (emptied), eventually the buffer runs dry or underflows. This is also a slip-frame repetition.

A 1.5 Mbyte PRI contains a buffer large enough to hold about 2 full DS-1 frames ($193 * 2 = 386$). A 2 Mbyte PRI contains a buffer large enough to contain 2 full frames ($256 * 2 = 512$ bits). The buffer is normally kept half full (1 frame).

Slippage has impact on the data being transferred, as is shown in [Table 62: Performance impact of one slip on service type](#) on page 190. All of the degradations shown in the table can be controlled or avoided with proper clock synchronization.

Table 62: Performance impact of one slip on service type

| Service | Potential Impact |
|-----------------|--|
| Encrypted Text | Encryption key must be resent. |
| Video | Freeze frame for several seconds. Loud pop on audio. |
| Digital Data | Deletion or repetition of data. Possible misframe. |
| Facsimile | Deletion of 4 to 8 scan lines. Dropped call. |
| Voice Band Data | Transmission Errors for 0.01 to 2 s. Dropped call. |
| Voice | Possible click. |

Guidelines

Some key points to keep in mind when designing Network Synchronization:

- Where possible, the Master Clock Source should always be from a Node Category/Stratum with higher clock accuracy, that is, a PBX connected to the Central Office (CO.) The CO is the Master and the PBX is the Slave.
- The source should not be in free-run itself (providing its own clock) unless it is operating in a fully independent network where the source acts as a Master (see [Plesiosynchronous operation](#) on page 186.)
- When connecting two PBXs together (no CO connections), the most reliable PBX should be the Master. Reliability here refers to Dual CPU/Dual Clock, battery back-up or stratum level of the clock controller.
- Avoid timing loops. A timing loop occurs when a clock using as its reference frequency a signal that it itself traceable to the output of that clock. The formation of such a closed timing loop leads to frequency instability and is not permitted. Timing loops are sometimes unavoidable on the secondary clock reference source.
- Ensure all CO/PBX links used as clock references have a traceable path back to the same stratum 1 clock source.

While it is beyond the scope of this discussion to provide detailed Network Synchronization, the following examples illustrate some of the basic concepts to achieve stable clocking.




Figure 66: Example 1, Isolated Private Network

In this example, there is no digital connection to the Central Office.




Figure 67: Example 2, Isolated Private Network with Secondary Reference Clock

In this example, there is no digital connection to the Central Office. For tie lines between PBXs facilitated by a central office, clocking is derived from the PBX, not the CO. When a second Digital loop is available, it can be used as a Secondary Clock source in case the Primary Source fails.




Figure 68: Example 3, Clocking Hierarchy referenced to a Public Network Master Clock

This is an example of a "STAR" arrangement— one Hub PBX is linked to the Central Office and all other PBXs are connected as slaves. When a second Digital loop from the system which forms the hub of this network becomes available, it can be used as a Secondary Clock Source in case the Primary Source fails.




Figure 69: Example 4, Alternate Clocking from the same CO

In this case, a digital connection to the Central Office can exist (i.e. Loops X and Y). When a second Digital loop from the CO or Master M-1 becomes available, it can be used as a Secondary Clock Source in case the Primary Source fails.

To avoid timing loops, in example 4-4 the most reliable slave system should not have a Secondary Clock Source (SREF= <cr>). In this example, this is illustrated by the node which supports loops X and Z.




Figure 70: Example 5, digital connection to the CO

In this example, digital connections to the Central Office do exist. When a second Digital loop from the CO becomes available, it can be used as a Secondary Clock Source in case the Primary Source fails.

Slaves can track on each other as a secondary source because the chances of both links to the Central Offices going down at the same time are minimal.

All Central Offices must have a path back to the same stratum 1 source.




Figure 71: Example 6, Complex Isolated Private Network

Digital connections to the Central Office do not exist in this example. If it does, the PBX connected to it tracks off the CO and in turn is used as a clock source to other nodes.

When a second Digital loop from the Master system becomes available, it can be used as a Secondary Clock Source in case the Primary Source fails.




Figure 72: Example 7, Network Clocking with MUX

In this example, the direct connection to the CO (without a MUX) should be used as a primary clock reference because this is where the least amount of hardware is involved. The MUX must pass the clock and not generate its own clock; in other words, it must be a slave (not Free Run). Synchronized clocking is required.

Modes of operation

There are two modes of operation, tracking mode and free run (non-tracking) mode.

Tracking mode

In tracking mode, the Primary Rate Interface (PRI) or Digital Trunk Interface (DTI) loop supplies an external clock reference to the onboard clock controller. Two PRI or DTI packs can operate in tracking mode, with one defined as the primary reference source for clock synchronization, the other defined as a secondary reference source. The secondary reference acts as a back-up to the primary reference.

Free run (non-tracking) mode

The clock synchronization for a PRI loop can operate in free-run mode if:

- the loop is not defined as the primary or secondary clock reference
- the primary and secondary references are disabled
- the primary and secondary references are in a local alarm state

Small System Clock Controller daughterboard

The Small System supports a single onboard clock controller daughterboard, the NTAk20, located on either:

- the NTRB21 1.5 Mbyte DTI/PRI card
- the NTAk09 1.5 DTI/PRI card
- the NTAk10 2 Mbyte DTI card
- the NTAk79 2 Mbyte PRI card
- the NTBk50 2 Mbyte PRI card

The clock controller circuitry synchronizes to an external reference clock and generates and distributes the clock to the system. This enables the system to function either as a slave to an external clock or as a clocking master.

 **Note:**

When configuring ISL over analog trunks, clock controllers are not required.

Installation procedures

This section provides procedures on how to install a clock controller on Large Systems.

 **Caution:**

Do not deviate from the procedures described in this section. Call processing can stop if procedural steps are not followed properly.

Determine slots and shelves

[Table 63: Clock Controller shelves and slots](#) on page 198 shows the systems, the shelves and available slots.

Table 63: Clock Controller shelves and slots

| System | Shelf | Slot(s) |
|--------------------------|-----------------------|---------|
| Half Group, Single Group | NT6D39 CPU/NET | 9 |
| Multi Group | NTDA35 Network Module | 13 |

Set switches

Before installing a clock controller, set the switches as shown in [Table 64: Clock Controller switch settings for QPC471 vintage H](#) on page 198, [Table 65: Clock Controller switch settings for QPC775](#) on page 199, and [Table 66: Clock Controller switch settings for NTRB53](#) on page 199. [Table 64: Clock Controller switch settings for QPC471 vintage H](#) on page 198 displays the settings for different vintages of the QPC471. [Table 65: Clock Controller switch settings for QPC775](#) on page 199 shows the settings for the QPC775. [Table 66: Clock Controller switch settings for NTRB53](#) on page 199 shows settings for the NTRB53.

Table 64: Clock Controller switch settings for QPC471 vintage H

| System | SW1 | | | | SW2 | | | | SW4 | | | |
|---|-----|-----|-----|-----|--|-----|-----|-----|-----|----|-----|---|
| | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 |
| Half Group, Single Group | on | on | on | on | off | off | off | off | off | on | * | * |
| Option 81 | off | off | off | off | off | off | off | off | off | on | * | * |
| Multi Group (with the exception of Option 81) | on | off | off | off | off | off | off | off | ** | on | * | * |
| Multi Group with Fiber Network | on | off | off | off | off | off | off | off | ** | on | * | * |
| | | | | | *Cable length between the J3 faceplate connectors: | | | | | | | |
| | | | | | 0–4.3 m (0–14 ft) | | | | off | | off | |
| | | | | | 4.6–6.1 m (15–20 ft) | | | | off | | on | |
| | | | | | 6.4–10.1 m (21–33 ft) | | | | on | | off | |
| | | | | | 10.4–15.2 m (34–50 ft) | | | | on | | on | |

| System | SW1 | | | | SW2 | | | | SW4 | | | |
|---|-----|---|---|---|-----|---|---|---|-----|---|---|---|
| | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 | 1 | 2 | 3 | 4 |
| <p>* If there is only one clock controller card in the system, set to OFF. If there are two clock controller cards, determine the total cable length between the J3 connectors (no single cable can exceed 25 ft.) and set these two switch positions for this cable length, as shown above. The maximum total (combined) length is 50 ft. Set the switches on both cards to the same settings.</p> | | | | | | | | | | | | |
| <p>** Set to ON for clock controller 0. Set to OFF for clock controller 1.</p> | | | | | | | | | | | | |
| <p> Note: FNF based-systems the total clock path length is equal to the length of the NTRC49 cable used to connect between the two clock controller cards.</p> | | | | | | | | | | | | |

Table 65: Clock Controller switch settings for QPC775

| System | SW2 | SW3 | SW4 |
|--------------------------|-----|-----|-----|
| Half Group, Single Group | ON | OFF | ON |
| Multi Group | OFF | OFF | ON |

Table 66: Clock Controller switch settings for NTRB53

| Multigroup/ Single group | Machine Type # 1 | Faceplate Cable Length (CC to CC) | | | Side Number | Machine Type #2 |
|---------------------------------------|-------------------------------------|---|-----|----------|-----------------------------|---|
| | | 3 | 4 | | | |
| 1 | 2 | 3 | 4 | | 5 | 6 |
| Multigroup = Off Single group = On | 61, 51C, 61C 71, 81, 81C = On | Off | Off | 0-14 ft | Side 0 = On Side 1 = Off | 81 = Off 51, 51C 61, 61C, 81C = On |
| | | Off | On | 15-20 ft | | |
| | | On | Off | 21-33 ft | | |
| | | On | On | 34-50 ft | | |

 **Note:**
Switches 7 and 8 are not used.

Start the Clock Controller

The clock controller, when first enabled, is in free run mode. It stays in this mode for several minutes before being switched to tracking mode. Manual mode setting is possible using LD 60.

All clock controllers begin tracking within approximately 15 minutes.

Clock Controller commands

During the installation procedure you use some of the clock controller commands available in LD 39 and LD 60. See *Avaya Software Input Output Reference — Maintenance, NN43001-711*.

LD 39 commands with the NTRB53 Clock Controller

| Command | Description |
|------------|---|
| DIS SCG x | Disable SCG card x (0 or 1). Not applicable for NTRB53 Clock Controller. Use LD 60 instead. |
| ENL SCG x | Enable SCG x (0 or 1). Not applicable for NTRB53 Clock Controller. Use LD 60 instead. |
| SCLK | Switch clock to other SCG. Functions with NTRB53 Clock Controller |
| STAT SCG x | Print status of SCG x (0 or 1). Prints normal status of NTRB53 (not full status) |

Install or replace a Clock Controller on a Half Group and Single Group system

[Install a clock controller for Half Group and Single Group Systems](#), on page 200 outlines the steps to install a clock controller on Half Group and Single Group systems.

Install a clock controller for Half Group and Single Group Systems.

1. Unpack and inspect the circuit card.
2. Determine the cabinet and shelf location. Refer to [Table 63: Clock Controller shelves and slots](#) on page 198.
3. Set the clock controller switch. Refer to [Table 64: Clock Controller switch settings for QPC471 vintage H](#) on page 198, [Table 65: Clock Controller switch settings for](#)

[QPC775](#) on page 199, or [Table 66: Clock Controller switch settings for NTRB53](#) on page 199.

4. Set the ENL/DIS toggle switch to DIS (disable).
5. Replacing a clock controller, do the following:
 - Perform a status check on the clock with the `SSCK` command in LD 60. The new controller should have the same status.

 **Note:**

ERR20 messages can be generated. These can usually be ignored. However, excessive clock switching should be avoided, especially when counters are near the maintenance or out-of-service thresholds. Excessive switching could generate threshold-exceeded messages or cause the PRI to be automatically disabled. Check the counters in LD 60. If necessary, reset the counters using the `RCNT` command.

- a. Set the old card's faceplate ENL/DIS switch to DIS.
 - b. Disconnect the cables from the old clock controller card and remove the card from the shelf.
6. Adjust the 3PE switches to recognize the clock controller card.
 7. Set faceplate ENL/DIS switch to DIS.
 8. Install the clock controller in the selected slot.
 9. Run and connect cables
 - a. Connect the primary reference to J2.
 - b. If available, connect the secondary reference to J1.
 - c. Connect the cable between the two clocks to J3 on each controller card.
 10. Set the faceplate ENL/DIS switch to ENL.

 **Note:**

Verify that the faceplate LED flashes three times to ensure the clock controller self test passed.

11. Enable the clock controller by entering `ENL CC x` in LD 60.
12. Set the error detection thresholds and clock synchronization controls in LD 73. (Optional with card replacement; required with new installation.)
13. Track on a primary or secondary reference clock, use LD 60. Use the following command:

| | | |
|------|------|-----------------|
| TRCK | PCK | (for primary) |
| | SCLK | (for secondary) |

| | | |
|--|------|----------------|
| | FRUN | (for free-run) |
|--|------|----------------|

14. Issue the status check command, `SSCK`.

 **Note:**

In order for the clock enhancement feature in the clock controller (NTRB53) to be fully functional, the user must issue a manual `INI` to activate the clock enhancement feature.

Install or replace a Clock Controller on a Single Group and Multi Group System

[Install a Clock Controller on a Single Group and Multi Group System](#) on page 202 outlines the steps to install a clock controller on Single Group and Multi Group systems.

Install a Clock Controller on a Single Group and Multi Group System

1. Unpack and inspect the circuit card.
2. Determine the cabinet and shelf location. Refer to [Table 63: Clock Controller shelves and slots](#) on page 198.
3. Set the clock controller switch. Refer to [Table 64: Clock Controller switch settings for QPC471 vintage H](#) on page 198, [Table 65: Clock Controller switch settings for QPC775](#) on page 199, or on [Table 64: Clock Controller switch settings for QPC471 vintage H](#) on page 198.
4. Set the ENL/DIS toggle switch to DIS (disable).
5. If replacing a clock controller, do the following:
 - Perform a status check on the clock with the `SSCK` command in LD 60. The new controller should have the same status.
 - Use LD 135 to `STAT` the CPU and switch if necessary
 - Disable the old card using LD 60.

 **Note:**

Do not disable an active clock or a clock associated with an active CPU.

 **Note:**

ERR20 messages can be generated. These can usually be ignored. However, excessive clock switching should be avoided, especially when counters are near the maintenance or out-of-service thresholds. Excessive switching could generate threshold-exceeded messages or cause the PRI to be automatically disabled. Check the counters in LD 60. If necessary, reset the counters using the `RCNT` command.

- a. Set the old card's faceplate ENL/DIS switch to DIS.

- b. Disconnect the cables from the old clock controller card and remove it from the shelf.
6. Install the new clock controller in the selected slot.
7. Run and connect the cables
 - a. Connect the primary reference to J2.
 - b. Connect the secondary reference to J, if available.
 - c. Connect the cable from J3 on each controller card to the junctor group connector.
8. Set the faceplate ENL/DIS switch to ENL.
9. Execute the `ENL CC x` command in LD 60. The faceplate LED should go to the OFF state.
10. Set the error detection thresholds and clock synchronization controls in LD 73. (Optional if replacing card; required with new installation.)
11. Track on a primary or secondary reference clock, use LD 60. The command follows:

| | | |
|------|------|-----------------|
| TRCK | PCK | (for primary) |
| | SCLK | (for secondary) |
| | FRUN | (for free-run) |

12. Issue the status check command, `SSCK`.
13. (Optional) Wait two minutes before activating the newly installed clock controller with the LD 60 `SWCK` command.

 **Note:**

This allows a smooth transition of the clock controller upgrade.

14. Repeat for the second clock controller, if necessary.

Upgrade to an NTRB53 Clock Controller on a Single Group and Multi Group System

Follow these procedures to replace the existing clock controller with the NTRB53 Clock Controller on Large Systems.

 **Note:**

The NTRB53 Clock Controller cannot be combined with a QPC775 or a QPC471 card in one system.

Remove old equipment

1. Ensure the clock controller card being removed for dual core systems is on the inactive core. If you need to switch cores go to LD 135 and enter:

```
LD 135
SCPU          Switch cores
****         Exit the overlay
```

2. Disable the QPC775 or QPC471 Clock Controller card. At the prompt, enter:

```
LD 60         Load the program
SSCK x        Get status of system clock where x = 0 or 1
```

Switch clocks if the clock is active at the prompt, enter:

```
SWCK          Switch system clock from active to standby
SSCK x        Get status of system clock where x = 0 or 1
```

Ensure the other clock controller is active and in the free run mode. At the prompt, enter:

```
SSCK x        Get status of system clock where x = 0 or 1
TRCK FRUN     Set clock controller tracking to free run
```

3. Disable the clock controller card you are removing. At the prompt, enter:

```
DIS CC x      Disable system clock controller where x = 0 or 1
```

4. Set the ENL/DIS switch to DIS on the card you are removing.
5. Tag and disconnect the cables to the card you are removing.
6. Unhook the locking devices on the card and pull it out of the card cage.

Follow these procedures to install new equipment with Clock Controller on Large Systems.

Installing new equipment

1. Set the ENB/DIS switch to DIS on the replacement card.
2. Set the option switches on the replacement card (NTRB53). Refer to [Table 66: Clock Controller switch settings for NTRB53](#) on page 199.
3. Insert the replacement card into the vacated slot and hook the locking devices.
4. Connect the reference cables (J1 and J2) to the replacement card.

 **Caution:**

Clock-to-Clock cable J3 should never be connected between the old clock (QPC471 or QPC775) and the new clock (NTRB53).

5. Set the ENB/DIS switch to ENB on the replacement card.
6. Software enable the card. At the prompt, enter

```
LD 60
ENL CC x    Enable clock controller card, where x = 0 or 1
```

7. Verify that the card is active. At the prompt, enter:

```
SSCK x      Get status of system clock where x = 0 or 1
****       Exit the overlay
```

8. Switch to the core with the new clock. At the prompt, enter:

```
LD 135
SCPU        Switch CPU
```

 **Note:**

Wait two minutes before proceeding to the next step.

 **Caution:**

The following procedure to faceplate disable the active clock controller could impact service.

9. Disable the faceplate of the active clock controller to force the newly installed clock controller to activate.
10. Disconnect the Clock-to-Clock faceplate cable to J3 of the new clock controller card in the active CPU side

 **Caution:**

Active calls experiences noise over local and trunk calls

11. Verify that the clock controller is active. At the prompt, enter

```
LD 60
SSCK        Get status of the new system clock, where x = 0 or 1
TRCK PCK    Track primary clock, where x = 0 or 1
RCNT        Resets all alarm counters of all digital cards
```

**** Exit the overlay



Note:

Replacing the clock controller generates errors on the network equipment. It is recommended that all counters be reset.

12. Replace the remaining QPC775 or QPC471 clock controller card, tag and disconnect the cables to the card you are removing.
13. Unhook the locking devices on the card and pull it out of the card cage.
14. Set the ENB/DIS switch to DIS on the replacement card.
15. Set the option switches on the replacement card (NTRB53). Refer to [Table 66: Clock Controller switch settings for NTRB53](#) on page 199.
16. Insert the replacement card into the selected slot and hook the locking devices.
17. Connect the reference cables (J1 and J2) and the clock-to-clock cable (J3) to the replacement card.
18. Set the ENB/DIS switch to ENB on the replacement card.
19. Disable the software and enable the card. At the prompt, enter:

LD 60

DID CC x Disable clock controller card, where x=0 or 1

ENL CC x Enable clock controller card, where x=0 or 1

20. Verify that the card is active. At the prompt, enter:

SSCK x Get status of system clock, where x=0 or 1

**** Exit the overlay



Note:

Wait two minutes before proceeding to next step.

21. Activate the new card and verify that it is active. At the prompt enter:

LD60

SWCK Switch system clock from active to standby

SSCK x Get status of system clock, where x = 0 or 1

TRCK PCK Track primary clock, where x = 0 or 1

RCNT Reset alarm counters of all digital cards

**** Exit the overlay

22. Set the clock source to the status it was in before the replacement procedure.
23. Verify clock switchover and tracking. At the prompt, enter:

| | |
|--------|--|
| SWCK | Switch system clock from active to standby |
| SSCK x | Get status of system clock, where x = 0 or 1 |
| **** | Exit the overlay |

Chapter 14: ISL installation

Contents

The section contains information about the following topics:

- [ISL configurations](#) on page 209
- [DCHI switch settings](#) on page 210
- [MSDL switch settings](#) on page 211
- [Shared mode](#) on page 209
- [Dedicated mode using leased line](#) on page 213
- [Dedicated mode using dialup modem](#) on page 214
 - [Install a modem for ISL applications](#) on page 214
 - [Dedicated mode using PRI/DTI trunks](#) on page 216
- [QMT11 switch settings](#) on page 217
- [QMT8 switch settings](#) on page 218
- [QMT21C switch settings](#) on page 218
- [ISL installation](#) on page 219
 - [Install ISL in dedicated mode \(digital and analog\)](#) on page 219
 - [Install ISL in shared mode](#) on page 219

ISL configurations

The ISDN Signaling Link (ISL) is used on PRI/DTI connections. The ISL feature operates in two modes, shared and dedicated.

Shared mode

The DCHI supports ISDN PRI signaling for both PRI and ISL trunks.

Dedicated mode

In this mode, the DCHI supports ISL trunks using ISDN PRI signaling. The D-channel communicates with the far end using a dedicated leased line, dialup modem, or DTI trunk.

DCHI switch settings

For ISL functions, use the following switch settings for the J2 port:

- RS-232 for 19.2 Kbps and below
- HS (RS-422) for speeds above 19.2 Kbps
- External clock (in LD 17) provided by modem, ADM, or ASIM, otherwise DCHI runs at 64 Kbps
- DTE device configuration

[Figure 73: NT6D11AB, NT6D11AD DCHI with ISL high-speed programming jumper settings](#) on page 210 shows the ISL high-speed programming jumper settings for the NT6D11AB, NT6D11AE DCHI, and [Figure 74: NT6D11AB, NT6D11AD DCHI with ISL low-speed programming jumper settings](#) on page 211 shows the ISL low-speed programming jumper settings for the NT6D11AB, NT6D11AE/AF DCHI.




Figure 73: NT6D11AB, NT6D11AD DCHI with ISL high-speed programming jumper settings




Figure 74: NT6D11AB, NT6D11AD DCHI with ISL low-speed programming jumper settings

MSDL switch settings

For ISL functions, use the following switch settings.

- DTE for high speed programming;
- RS-232 for 19.2 Kbps and below;
- External clock (in LD17) provided by modem, ADM, or ASIM, HSDM: otherwise, DCH runs at 64 Kbps. Refer to [Figure 75: MSDL/ISL settings](#) on page 212.




Figure 75: MSDL/ISL settings

Shared mode

In shared mode, the D-channel is provided by the DCHI or MSDL card and PRI. The hardware configuration is basically the same as the ISDN PRI D-channel. See [Figure 76: ISL in shared mode](#) on page 213.

Shared mode is established through service change in LD17, prompt USR, with the response SHA.

In the shared mode, the DCH can share signaling for no more than 382 (T1) or 480 (E1) trunks, including digital and analog.




Figure 76: ISL in shared mode

Dedicated mode using leased line

In this configuration, the D-channel connects the DCHI or MSDL to a modem which communicates with a far-end modem over a dedicated leased line. See [Figure 77: ISL dedicated mode, using leased line](#) on page 213. A 2400 baud D-channel can support signaling for approximately 382 (T1) or 480 (E1) trunks without non-call associated messages.

Both modems should be set in the synchronous mode.




Figure 77: ISL dedicated mode, using leased line

Dedicated mode using dialup modem

In this configuration, the DCHI or MSDL is connected to a modem which is connected to a 500 set line card. See [Figure 79: ISL dedicated mode, using dialup Hayes Smartmodem 2400](#) on page 216. The call is connected to the far end through the analog (500/2500 type set) -to-TIE trunk path.

To set up the D-channel, program the modem at one end in the autodial mode, so it automatically initiates a call to the other end at power up. The autodial DN must be coordinated with personnel at the far end switch.

Install a modem for ISL applications

The modem software and hardware must be installed sequentially. The modem software must be defined before the hardware connection between the modem and the system can be made. Within the software installation, either the autodial or the auto-answer software can be set up first. [Figure 78: ISL dedicated mode: using dialup Hayes Smartmodem 2400](#) on page 214 shows the hardware configuration between two PBXs and their corresponding modems.




Figure 78: ISL dedicated mode: using dialup Hayes Smartmodem 2400

Examples of parameters used for actual auto-answer and autodial sites are shown in the following tables (note that the Hayes Smartmodem is used.) [Table 67: Active and stored profiles of the autodial or originating modem](#) on page 215 shows the active and stored profiles of the autodial site (or the originating modem). [Table 68: Active and stored profiles of the auto answer or terminating modem](#) on page 215 shows the active and stored profiles of the auto-answer site (or the terminating modem). The Hayes Smartmodem User Guide contains explanations of the parameters used in [Table 67: Active and stored profiles of the autodial or originating modem](#) on page 215 and [Table 68: Active and stored profiles of the auto answer or terminating modem](#) on page 215.

After the software parameters are set up, the JP1 jumpers behind the front faceplate of the Hayes Smartmodem must be dumb strapped on both modems. Next, see the Hayes Smartmodem Getting Started Guide to set up the hardware between the system and the modem.

Table 67: Active and stored profiles of the autodial or originating modem

| |
|--|
| Active profile: |
| B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D0 &G0 &J0 &L0 &P0 &Q2 &R0 &S0 &X0 &Y0 S00:000 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:030 S08:002 S09:006 S10:014 S12:050 S14:ACH S16:00H S18:000 S21:20H S22:76H S23:15H S25:005 S26:001 S27:42H |
| Stored profile 0: |
| B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D0 &G0 &J0 &L0 &P0 &Q2 &R0 &S0 &X0 S00:000 S14:ACH S18:000 S21:20H S22:76H S23:17H S25:005 S26:001 S27:42H |
| Stored profile 1: |
| B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0 S00:00 S14:AAH S18:000 S21:00H S22:76H S23:17H S25:005 S26:001 S27:40H |
| Telephone numbers: |
| &Z0=ATDT7414011 &Z1= &Z2= &Z3= |

Table 68: Active and stored profiles of the auto answer or terminating modem

| |
|--|
| Active profile: |
| B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q1 &R0 &S1 &X2 &Y0 S00:001 S01:000 S02:043 S03:013 S04:010 S05:008 S06:002 S07:030 S08:002 S09:006 S10:014 S12:050 S14:ACH S16:00H S18:000 S21:70H S22:76H S23:15H S25:005 S26:001 S27:61H |
| Stored profile 0: |
| B1 E0 L2 M1 Q1 V1 X4 Y0 &C1 &D2 &G0 &J0 &L0 &P0 &Q1 &R0 &S1 &X2 S00:001 S14:ACH S18:000 S21:70H S22:76H S23:17H S25:005 S26:001 S27:61H |
| Stored profile 1: |
| B1 E1 L2 M1 Q0 V1 X4 Y0 &C0 &D0 &G0 &J0 &L0 &P0 &Q0 &R0 &S0 &X0 S00:000 S14:AAH S18:000 S21:00H S22:76H S23:17H S25:005 S26:001 S27:40H |
| Telephone numbers: |
| &Z0= &Z1= &Z2= &Z3= |




Figure 79: ISL dedicated mode, using dialup Hayes Smartmodem 2400

Dedicated mode using PRI/DTI trunks

In this configuration, the DCHI or MSDL is connected to a High Speed Data Module (HSDM) or Asynchronous/Synchronous Interface Module (ASIM). See [Figure 80: ISL dedicated mode: using PRI/DTI trunk](#) on page 217. The HSDM or ASIM is connected to a Data Line Card (DLC). The call is then connected to the far end through the DLC to DTI trunk path.

To establish the D-channel in this configuration, set up the HSDM or ASIM at one end in hot line mode. The hot line DN must be coordinated with personnel at the far end, then programmed in LD11. The preprogrammed hot line DN is dialed by the system. If the call cannot be established, the system continues to dial the hot line number continuously until the call is connected.

Set the HSDM or ASIM must be in synchronous mode. A data rate of 9.6 Kbps is recommended because it provides internal error detection and correction. The following data rates are also supported: 1.2 Kbps, 2.4 Kbps, 3.6 Kbps, 4.8 Kbps, 7.2 Kbps, 14.4 Kbps, 19.2 Kbps, 38.4 Kbps, and 56 Kbps for ASIM. The High Speed Data Module (HSDM) supports 64 Kbps.

*** Note:**

This configuration is the least reliable due to the lockup problems inherent in Smart Modems from power splices and noisy lines. To increase the reliability on this configuration, a constant power source can be used when powering the modems. Also ensure that the TIE lines meet data grade specifications.

*** Note:**

Avaya takes no responsibility for ISL D-channel outages due to modem lockup.




Figure 80: ISL dedicated mode: using PRI/DTI trunk

QMT11 switch settings

If using the QMT11 ASIM, set the DIP switches, located on top of the unit under the flip-up, as follows:

- Hotline, On; See Note 1.
- Forced DTR, On; See Note 2.
- FDX (full duplex), On
- SYNC, On
- INTernal CLK, On
- Modem/Network, Modem
- Auto Answer, On
- Loopback, Off

*** Note:**

Set only one side of the interface to originate the hot line.

*** Note:**

Forced Data Terminal Ready (DTR) automatically reinitiates a dropped hot line call.

QMT8 switch settings

If the QMT8 Asynchronous Data Module (ADM) is used, set the switches as follows:

| Switch 1: | Switch 3: | Switch 4: |
|------------------------|---|--|
| set to zeros (no VFDN) | <ol style="list-style-type: none"> 1. not used 2. not used 3. FDX (full duplex) 4. modem 5. internal clock 6. no echo 7. auto answer 8. off (no loopback) | <ol style="list-style-type: none"> 1. on 2. on (hot line*) 3. off (DTR-data terminal ready-required) 4. on (synchronous) U5 and U7 must be jumpered <p>* Only one side of the interface should be set to originate the hot line.</p> |

QMT21C switch settings

If using the QMT21 HSDM, set the dip switches, located on top of the unit under the flip-up, as follows.

- Hotline, On; See Note 1.
- Forced DTR, On; See Note 2.
- FDX (full duplex), On
- SYNC, On
- INTernal CLK, On
- Modem/Network, Modem
- Auto Answer, On
- Loopback, Off



Note:

Set only one side of the interface to originate the hot line.



Note:

Forced Data Terminal Ready (DTR) automatically reinitiates a dropped hot line call.

ISL installation

Use [Install ISL in dedicated mode](#) on page 219 to install ISL in dedicated mode. Use [Install ISL in shared mode](#) on page 219 to install ISL in shared mode.

Modem paths must have individual configurations: route data blocks, trunks, and routes.

Install ISL in dedicated mode (digital and analog)

DTI or PRI should already be up and running.

Install ISL in dedicated mode

1. In LD17, configure ISL for dedicated mode. $USR = ISLD \text{ ISLM} = \text{Number of trunks handled by this D-channel (1-382)}$
2. In LD16, configure the Route Data Block to map out the software parameters for these trunks.
3. Install the modem with leased line functionality.
4. In LD14, reassign old trunks to the routes just built in LD16.
5. In LD16, out the old DTI route. A separate Route Data Block should be built for Leased Line, or to accommodate the dialing plan for a dedicated modem.

Install ISL in shared mode

DTI or PRI should already be up and running.

Install ISL in shared mode

1. In LD14, remove the PRI trunks.
2. In LD17, configure ISL for dedicated mode. $USR = SHA \text{ ISLM} = \text{Number of trunks handled by this D-channel (1-382)}$
3. In LD16, build a PRI route data block. This is the same route you just removed in step 1. $ISDN = YES$
4. In LD16 build another route data block to correspond to the IAS routes.
5. In LD14, assign trunks to the newly configured routes.

Chapter 15: Echo canceller installation

Contents

The section contains information about the following topics:

[Introduction](#) on page 221

[Echo canceller operating parameters](#) on page 221

[Echo canceller initialization procedures](#) on page 222

[PRI to Echo canceller pin assignments](#) on page 222

[Electromagnetic Interference](#) on page 223

Introduction

Echo cancellers are required only in cases where satellite transmission is being used. The echo canceller detects the length of the loop, and cancels out transmission reflections (which result in audible echoes of voices on satellite-carried calls).

Echo canceller operating parameters

The operational parameters of the echo canceller must be:

- Data transfer rate: 4800 baud
- System unit number: 1
- Display timeout: active
- Failures before alarm: 3

Echo canceller initialization procedures

Each of the 24 channels on the echo canceller must be initialized as shown here:

- Bypass: OFF
- Off-hook: ON
- Cancellor only: OFF
- H reset: OFF
- H hold: OFF

PRI to Echo canceller pin assignments

The echo canceller is controlled by an RS-232 port on the PRI circuit pack. The following tables give the echo canceller pin assignments, operating parameters and initialization procedures.

See [Table 69: PRI-to-Echo canceller - pin assignments](#) on page 222 for PRI-to-Echo canceller pin assignments; refer to [Figure 81: PRI to echo canceller cabling](#) on page 223 for a PRI-to-Echo-canceller cabling schematic.

Table 69: PRI-to-Echo canceller - pin assignments

| Signal | PRI pin | Echo canceller pin | EIA RS-232-C circuit designator |
|-------------------------------------|---------|--------------------|---------------------------------|
| TXD (Transmitted Data) | 5 | 2 | BA |
| RXD (Received Data) | 2 | 3 | BB |
| RTS (Request to Send) | — | 4 | CC |
| CTS (Clear to Send) | — | 5 | CB |
| Common Return (signal ground) | 10 | 7 | AB |
| DCD (received line signal detector) | 1 | 8 | CF |
| DTR (data terminal ready) | 4 | 20 | CD |

Electromagnetic Interference

The Electromagnetic Interference (EMI) filter assembly for PRI is PO643763. The system meets FCC Part 15, Subpart J, Class A requirements regarding EMI. In order to accomplish this, the SDI cables must exit the cabinet through EMI filters on the I/O panel. This procedure depends on the system cabinet type.




Figure 81: PRI to echo canceller cabling

Chapter 16: Universal Digital Trunk card commissioning

Contents

This section contains information about the following topics:

[UDT card configuration as 2.0 Mb PRI2 \(E1\)](#) on page 226

[UDT card configuration as 2.0 Mb DTI \(E1\)](#) on page 229

[UDT card configuration as DPNSS/DASS \(E1\)](#) on page 232

[UDT card configuration as 1.5 Mb PRI \(T1\)](#) on page 236

[UDT card configuration as 1.5 Mb DTI \(T1\)](#) on page 240

Configure the Universal Digital Trunk (UDT) card using the UDT card Command Line Interface (CLI). The RS232 port must be connected to a terminal. For more information about the UDT card CLI, see *Avaya Software Input Output Reference — Maintenance, NN43001-711*.

The NTDW79AAE5 UDT card is a single slot size TDM card. The NTDW12AAE5 Universal Clock Controller (UDT CC) daughter board may be mounted on the NTDW79AAE5 UDT card.

The NTDW79AAE5 UDT card and daughterboard replace NTAk79, NTAk10, NTBK50, NTRB21, NTAk20, NTAk93, NTAk09 and include onboard DDCH/DCHI functionality.

You can use the NTDW79AAE5 UDT card in Avaya Communication Server 1000 (Avaya CS 1000) small systems as well as in Avaya CS 1000E systems, positioned on CE-MUX slots.

For more information about the NTDW79AAE5 UDT card, see *Circuit Card Reference, NN43001-311*.

UDT card configuration as 2.0 Mb PRI2 (E1)

Task summary list

- [LD 17 configure PRI loop and D-channel interface](#) on page 226
- [LD 15 configure PRI customer](#) on page 227
- [LD 16 configure ISDN service route](#) on page 227
- [LD 14 configure service channels and PRI trunks](#) on page 228
- [LD 73 configure system timers and clock controller](#) on page 229

LD 17 configure PRI loop and D-channel interface

Table 70: PRI Loop configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|--|
| REQ | CHG | Change existing data. |
| TYPE | CEQU | Common Equipment |
| CEQU | YES | Changes to Common Equipment |
| ... | ... | |
| PRI2 | xx | The PRI2 digital loop |
| MG_CARD | supl sh card | The physical card for the PRI2 loop in the associated IPMG |
| ... | ... | |

Table 71: DCH configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|------------|--|
| REQ | CHG | Change existing data |
| TYPE | ADAN | Action Device And Number |
| ADAN | NEW DCH xx | Add a primary D-channel |
| CTYP | MSDL | D-Channel configuration on MSDL card (UDT E1/T1 includes on board DCH functionality) |

| | | |
|---------|--------------|-------------------------------------|
| MG_CARD | supl sh card | In format superloop, shelf, card |
| PORT | 1 | Port must be set to 1 |
| USR | PRI | D-channel is used for ISDN PRI only |
| IFC | xx | Interface type for D-channel |
| DCHL | xx | PRI loop number |
| ... | ... | |
| SIDE | (USR) NET | The system is network/user side |

LD 15 configure PRI customer

Table 72: PRI customer configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|------------------------------------|
| REQ | NEW CHG | Add new data Change existing data. |
| TYPE | NET | Networking data |
| CUST | xx | Customer number |
| ... | ... | |
| ISDN | YES | Customer is equipped with ISDN |
| ... | ... | |

LD 16 configure ISDN service route

Table 73: ISDN service route configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---------------------|
| REQ | NEW | Add new data |
| TYPE | RDB | Route Data Block |
| CUST | xx | Customer number |
| ROUT | xx | Route number |
| ... | ... | |
| TKTP | xxx | Trunk type |
| DTRK | YES | Digital trunk route |

| | | |
|------|------|-------------------------|
| DGTP | PRI2 | 2.0 Mb PRI |
| IFC | xxx | Interface type |
| ... | ... | |
| ISDN | YES | ISDN option |
| MODE | PRA | Route used for PRA only |
| ... | ... | |

LD 14 configure service channels and PRI trunks

Table 74: Service channels and PRI trunks configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|--------------|--|
| REQ | NEW | Add new data When assigning several members at once use the multiple create command NEW XX |
| TYPE | xxx | Trunk type |
| TN | l ch | Loop and channel for digital trunks |
| DES | xxx | Designator field for trunk |
| PDCA | (1) - 16 | PAD category table number |
| PCML | A MU | Pulse Code Modulation Law A = A-law MU = u-law |
| ... | ... | |
| RTMB | rt mm | Route number and Member number |
| ... | ... | |
| TGAR | 0 – (1) - 31 | Trunk Group Access Restriction |
| ... | ... | |
| CLS | aaaa | Class of Service |
| ... | ... | |

LD 73 configure system timers and clock controller

Table 75: System timers and clock controller configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---|
| REQ | NEW CHG | Add new data Change existing data |
| TYPE | PRI2 | 2.0 Mb PRI |
| FEAT | SYTI | System timers |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI2 providing the Primary Clock Reference |
| PREF | card | Card number of the PRI2 providing the Primary Clock Reference |
| SREF | card | Card number of the PRI2 providing the Secondary Clock Reference |
| ... | ... | The system can include up to 50 MG 1000E (for each MG 1000E including digital trunks, Clock Reference must be configured) |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI2 providing the Primary Clock Reference |
| PREF | card | Card number of the PRI2 providing the Primary Clock Reference |
| SREF | card | Card number of the PRI2 providing the Secondary Clock Reference |
| ... | ... | |

UDT card configuration as 2.0 Mb DTI (E1)

Task summary list

- [LD 17 configure DTI loop](#) on page 230
- [LD 73 configure 2.0 Mb DTI ABCD signaling bit tables and system timers](#) on page 230

- [LD 16 configure 2.0 Mb DTI trunk route](#) on page 231
- [LD 14 configure service channels and 2.0 Mb DTI trunks](#) on page 232

LD 17 configure DTI loop

Table 76: DTI Loop configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|--|
| REQ | CHG | Change existing data. |
| TYPE | CEQU | Common Equipment |
| CEQU | YES | Changes to Common Equipment |
| ... | ... | |
| DTI2 | xx | The DTI2 digital loop |
| MG_CARD | supl sh card | The physical card for the DTI2 loop in the associated IPMG |
| ... | ... | |

LD 73 configure 2.0 Mb DTI ABCD signaling bit tables and system timers

Table 77: 2.0 Mb DTI ABCD signaling bit tables configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|--|
| REQ | NEW CHG | Add or Change Digital Trunk Interface data |
| TYPE | DTI2 | 2.0 Mb/s DTI data block |
| FEAT | ABCD | ABCD bit signaling category |
| SICA | 2-16 | Signaling category |
| ... | ... | |

Table 78: 2.0 Mb DTI system timers configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|-----------------------------------|
| REQ | NEW CHG | Add new data Change existing data |
| TYPE | DTI2 | 2.0 Mb DTI |

| | | |
|-------|--------|---|
| FEAT | SYTI | System timers |
| MGCLK | sl s c | Superloop, shelf and card number of the DTI2 providing the Primary Clock Reference |
| PREF | card | Card number of the DTI2 providing the Primary Clock Reference |
| SREF | card | Card number of the DTI2 providing the Secondary Clock Reference |
| ... | ... | The system can include up to 50 MG 1000E (for each MG 1000E including digital trunks, Clock Reference must be configured) |
| MGCLK | sl s c | Superloop, shelf and card number of the DTI2 providing the Primary Clock Reference |
| PREF | card | Card number of the DTI2 providing the Primary Clock Reference |
| SREF | card | Card number of the DTI2 providing the Secondary Clock Reference |
| ... | ... | |

LD 16 configure 2.0 Mb DTI trunk route

Table 79: 2.0 Mb DTI trunk route configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---------------------|
| REQ | NEW | Add new data |
| TYPE | RDB | Route Data Block |
| CUST | xx | Customer number |
| ROUT | xx | Route number |
| ... | ... | |
| TKTP | xxx | Trunk type |
| DTRK | YES | Digital trunk route |
| DGTP | DTI2 | 2.0 Mb DTI |
| ... | ... | |

LD 14 configure service channels and 2.0 Mb DTI trunks

Table 80: Service channels and 2.0 Mb DTI trunks configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|------------------|--|
| REQ | NEW | Add new data When assigning several members at once use the multiple create command NEW XX |
| TYPE | xxx | Trunk type |
| TN | l ch | Loop and channel for digital trunks |
| DES | xxx | Designator field for trunk |
| SICA | (1) -16 | Signaling Category table number |
| PDCA | (1) - 16 | PAD category table number |
| PCML | A MU | Pulse Code Modulation Law A = A-law MU = u-law |
| ... | ... | |
| RTMB | rt mm | Route number and Member number |
| ... | ... | |
| TGAR | 0 – (1) - 31 | Trunk Group Access Restriction |
| ... | ... | |
| CLS | DIP DIPF DTN MFC | Dial pulse Dial pulse digit collection Digitone Multi Frequency Compelled |
| ... | ... | |

UDT card configuration as DPNSS/DASS (E1)

Task summary list

- [LD 17 configure DPNSS/DASS loop and D-channel](#) on page 233
- [LD 74 configure DDSL block for DPNSS/DASS2](#) on page 234

- [LD 16 configure route data block](#) on page 234
- [LD 14 configure DPNSS/DASS2 trunks](#) on page 235

LD 17 configure DPNSS/DASS loop and D-channel

Table 81: DPNSS/DASSI Loop configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|---|
| REQ | CHG | Change existing data. |
| TYPE | CEQU | Common Equipment |
| CEQU | YES | Changes to Common Equipment |
| ... | ... | |
| DDCS | loop | The loop number for the new DPNSS/DASS2 link. |
| MG_CARD | supl sh card | The physical card for the DPNSS/DASS2 loop association to the IPMG is required. |
| ... | ... | |

Table 82: DCH configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|--|
| REQ | CHG | Change existing data |
| TYPE | ADAN | Action Device And Number |
| ADAN | NEW DCH xx | Add a D-channel |
| CTYP | DCHI | On board DCHI functionality |
| MG_CARD | supl sh card | The physical card for the digital loop associated with the MG 1000E. |
| PORT | 1 | Port must be set to 1 |
| ... | ... | |
| DES | aaa...a | Designator (up to 16 alphanumeric characters) |
| DPNS | YES | Digital Private Network Signaling |
| ... | ... | |

LD 74 configure DDSL block for DPNSS/DASS2

Table 83: DDSL block configuration for DPNSS/DASS2

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---|
| REQ | NEW | New data |
| TYPE | DDSL | Digital Signaling Link |
| S2 | 0 | Normal addressing mode |
| DDSL | xx | The D-Channel logical port number, entered in LD 17 |
| SIGL | DA | DPNSS/DASS2 digital signaling |
| DDCS | xx | Loop number used for the PRI link (Reference to DDCS in LD 17) |
| PRIV | YES/NO | Yes - DPNSS link No - DASS2 link |
| SIDE | AET/BNT | The AET/BNT end of DPNSS/DASS2 link |
| DPNS | AET/BNT | Digital Private Network Signaling System (DPNSS) or Digital Access Signaling System (DASS2) |
| ... | ... | |

LD 16 configure route data block

Table 84: Route data block configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---|
| REQ | aaa | Request (aaa = CHG, NEW) |
| TYPE | RDB | Route Data Block |
| CUST | xx | Customer number, as defined in LD 15 |
| ROUT | xx | Route number |
| DES | aaa.a | Designator (up to 16 alphanumeric characters) |
| ... | ... | |
| TKTP | IDA | Trunk Type- Integrated digital access trunks |
| SIGL | DPN/DAS | Signaling interface: DPN – for DPNSS signaling DAS – for DASS signaling |

| | | |
|------|-----------|---|
| ... | ... | |
| ICOG | aaa | Incoming, outgoing or both way trunks |
| SRCH | (LIN) RRB | Search method for outgoing trunk member |
| ACOD | xxx..x | One-seven-digit access code for the trunk route |
| TARG | 0-(1)-31 | Trunk Access Restriction Group Number |
| ... | ... | |

LD 14 configure DPNSS/DASS2 trunks

For DPNSS, both RDC (real) and VDC (virtual) channels must be configured.

For DASS2, only RDC (real) channels configuration is required.

Table 85: Trunk data block configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|--------------|--|
| REQ | NEW CHG | Request (aaa = CHG, NEW) |
| TYPE | RDC/VDC | Real/Virtual digital channel |
| TN | l ch | Terminal Number for digital trunks Where l = loop, ch = channel. Loop and channel for digital trunks |
| DES | aa...a | Designator field for trunk |
| ... | ... | |
| DDSL | xx | DASS2/DPNSS D-channel logical port number, entered in LD 74 |
| SIGL | DPN/DAS | Signaling interface: DPN – for DPNSS signaling DAS – for DASS signaling |
| CUST | xx | Customer number, as defined in LD 15 |
| NCOS | (0) - 99 | Network Class of Service group |
| ... | ... | |
| RTMB | rt mm | Route number and Member Number |
| ... | ... | |
| TGAR | 0 – (1) - 31 | Trunk Group Access Restriction The default of 1 automatically blocks direct access. |
| ... | ... | |
| CLS | aaaa | Class of Service |

| | | |
|-----|-----|--|
| ... | ... | |
|-----|-----|--|

UDT card configuration as 1.5 Mb PRI (T1)

Task summary list

- [LD 17 configure PRI loop and D-channel interface](#) on page 236
- [LD 15 configure PRI customer](#) on page 237
- [LD 16 configure ISDN service route](#) on page 238
- [LD 14 configure service channels and PRI trunks](#) on page 238
- [LD 73 configure system timers and clock controller](#) on page 239

LD 17 configure PRI loop and D-channel interface

Table 86: PRI Loop configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|---|
| REQ | CHG | Change existing data. |
| TYPE | CEQU | Common Equipment |
| CEQU | YES | Changes to Common Equipment |
| ... | ... | |
| DLOP | xx | The PRI digital loop |
| MG_CARD | supl sh card | The physical card for the PRI loop in the associated IPMG |
| ... | ... | |
| MODE | PRI | Mode of operation |
| TMDI | NO | Must be configured as NO |
| ... | ... | |
| YALM | xxx | Yellow alarm method |
| TRSH | 0 - 15 | Threshold |
| ... | ... | |

Table 87: DCH configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|--------------------------------------|
| REQ | CHG | Change existing data |
| TYPE | ADAN | Action Device And Number |
| ADAN | NEW DCH xx | Add a primary D-channel |
| CTYP | MSDL | D-Channel configuration on MSDL card |
| MG_CARD | supl sh card | In format superloop, shelf, card |
| PORT | 1 | Port must be set to 1 |
| USR | PRI | D-channel is used for ISDN PRI only |
| IFC | xx | Interface type for D-channel |
| DCHL | xx | PRI loop number |
| ... | ... | |
| SIDE | (USR) NET | The system is network/user side |
| ... | ... | |

LD 15 configure PRI customer

Table 88: PRI customer configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---------------------------------------|
| REQ | NEW CHG | Add new data Change existing data. |
| TYPE | NET | Networking data |
| CUST | xx | Customer number |
| ... | ... | |
| ISDN | YES | Customer is equipped with ISDN |
| ... | ... | |

LD 16 configure ISDN service route

Table 89: ISDN service route configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|-------------------------|
| REQ | NEW | Add new data |
| TYPE | RDB | Route Data Block |
| CUST | xx | Customer number |
| ROUT | xx | Route number |
| ... | ... | |
| TKTP | xxx | Trunk type |
| DTRK | YES | Digital trunk route |
| DGTP | PRI | 1.5 Mb PRI |
| IFC | xxx | Interface type |
| ... | ... | |
| ISDN | YES | ISDN option |
| MODE | PRA | Route used for PRA only |
| ... | ... | |

LD 14 configure service channels and PRI trunks

Table 90: Service channels and PRI trunks configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|--|
| REQ | NEW | Add new data When assigning several members at once use the multiple create command NEW XX |
| TYPE | xxx | Trunk type |
| TN | l ch | Loop and channel for digital trunks |
| DES | xxx | Designator field for trunk |
| PDCA | (1) - 16 | PAD category table number |
| PCML | A MU | Pulse Code Modulation Law A = A-law |

| | | |
|------|--------------|--------------------------------|
| | | MU = u-law |
| ... | ... | |
| RTMB | rt mm | Route number and Member number |
| ... | ... | |
| TGAR | 0 - (1) - 31 | Trunk Group Access Restriction |
| ... | ... | |
| CLS | aaaa | Class of Service |
| ... | ... | |

LD 73 configure system timers and clock controller

Table 91: System timers and clock controller configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|--------------|---|
| REQ | NEW CHG | Add new data Change existing data |
| TYPE | DDB | Digital Data Block |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI providing the Primary Clock Reference |
| PREF | card | Card number of the PRI providing the Primary Clock Reference |
| SREF | card | Card number of the PRI providing the Secondary Clock Reference |
| ... | ... | |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI providing the Primary Clock Reference |
| PREF | card | Card number of the PRI providing the Primary Clock Reference |
| SREF | card | Card number of the PRI providing the Secondary Clock Reference |
| ... | ... | |
| TRSH | 0 - 15 | Set the PRI threshold (configure the threshold in LD 17 upon configuring the PRI loop) |
| RALM | 1- (3) - 128 | Yellow (remote) alarm 24 hours threshold (for example, the number of remote alarm clear signals received in 24 hours) |

| | | |
|-----|-----|--|
| ... | ... | |
|-----|-----|--|

UDT card configuration as 1.5 Mb DTI (T1)

Task summary list

- [LD 17 configure DTI loop](#) on page 240
- [LD 16 configure 1.5 Mb DTI trunk route](#) on page 241
- [LD 14 configure service channels and 1.5 Mb DTI trunks](#) on page 241
- [LD 73 configure clock reference](#) on page 242

LD 17 configure DTI loop

Table 92: DTI Loop configuration

| PROMPT | RESPONSE | DESCRIPTION |
|---------|--------------|---|
| REQ | CHG | Change existing data. |
| TYPE | CEQU | Common Equipment |
| CEQU | YES | Changes to Common Equipment |
| ... | ... | |
| DLOP | xx | The DTI digital loop |
| MG_CARD | supl sh card | The physical card for the DTI loop in the associated IPMG |
| ... | ... | |
| MODE | TRK | Mode of operation |
| TMDI | NO | Must be configured as NO |
| ... | ... | |
| YALM | xxx | Yellow alarm method |
| TRSH | 0 - 15 | Threshold |
| ... | ... | |

LD 16 configure 1.5 Mb DTI trunk route

Table 93: 1.5 Mb DTI trunk route configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|---------------------|
| REQ | NEW | Add new data |
| TYPE | RDB | Route Data Block |
| CUST | xx | Customer number |
| ROUT | xx | Route number |
| ... | ... | |
| TKTP | xxx | Trunk type |
| DTRK | YES | Digital trunk route |
| DGTP | DTI | 1.5 Mb DTI |
| ... | ... | |

LD 14 configure service channels and 1.5 Mb DTI trunks

Table 94: Service channels and 1.5 Mb DTI trunks configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|--|
| REQ | NEW | Add new data When assigning several members at once use the multiple create command NEW XX |
| TYPE | xxx | Trunk type |
| TN | l ch | Loop and channel for digital trunks |
| DES | xxx | Designator field for trunk |
| PDCA | (1) - 16 | PAD category table number |
| PCML | A MU | Pulse Code Modulation Law A = A-law MU = u-law |
| ... | ... | |
| RTMB | rt mm | Route number and Member number |
| ... | ... | |

| | | |
|------|---------------------------|--|
| TGAR | 0 - (1) - 31 | Trunk Group Access Restriction |
| SIGL | xxx | Level 3 signaling |
| STRI | xxx | Start arrangement incoming |
| STRO | xxx | Start arrangement outgoing |
| SUPN | (NO) YES | Answer and disconnect supervision required |
| ... | ... | |
| CLS | DIP DIPF DTN MFC | Dial pulse Dial pulse digit collection Digitone Multi Frequency Compelled |
| ... | ... | |

LD 73 configure clock reference

Table 95: Clock reference configuration

| PROMPT | RESPONSE | DESCRIPTION |
|--------|----------|--|
| REQ | NEW CHG | Add new data Change existing data |
| TYPE | DDB | Digital Data Block |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI providing the Primary Clock Reference |
| PREF | card | Card number of the PRI providing the Primary Clock Reference |
| SREF | card | Card number of the PRI providing the Secondary Clock Reference |
| ... | ... | |
| MGCLK | sl s c | Superloop, shelf and card number of the PRI providing the Primary Clock Reference |
| PREF | card | Card number of the PRI providing the Primary Clock Reference |
| SREF | card | Card number of the PRI providing the Secondary Clock Reference |
| ... | ... | |
| TRSH | 0 - 15 | Set the PRI threshold (configure the threshold in LD 17 upon configuring the PRI loop) |

| | | |
|------|--------------|---|
| RALM | 1- (3) - 128 | Yellow (remote) alarm 24 hours threshold (for example, the number of remote alarm clear signals received in 24 hours) |
| ... | ... | |

Chapter 17: 1.5 Mb PRI implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 245

[Hardware requirements](#) on page 246

[Hardware description](#) on page 247

[Install PRI hardware](#) on page 254

Overview

Digital trunks are supported in the Small System cabinet, the IP expansion cabinet, and the Media Gateway.

This chapter provides the following information required to install PRI on a system:

- hardware and software installation
- implementation procedures for basic call service

While either the hardware or software can be installed first, the PRI cannot be enabled and tested until both are completed.

Hardware requirements

Circuit cards

To implement PRI on the system, the hardware shown in [Table 96: Required circuit cards](#) on page 246 is required.

Table 96: Required circuit cards

| Circuit card | Description |
|--------------|--|
| NTRB21 | DTI/PRI TMDI card. |
| NTAK09 | DTI/PRI circuit card. |
| NTAK20 | Clock-controller daughterboard. Small Systems supports only one active clock controller per system or IP expansion cabinet.  Note: Every cabinet/Media Gateway that contains a digital trunk must contain a clock controller. |
| NTAK93 | D-channel-handler (DCH) interface daughterboard. |
| NTBK51BA | Downloadable D-channel daughterboard (DDCH). Connects to the NTAK09 DTI/PRI card. |

Cables

The following cables are required for PRI connections:

- PRI to external T1 cable
- NTBK04 carrier cable
- NT8D97 50-foot extension (if needed)

Channel Service Units (CSU)

When connecting the DTI/PRI to the public network, CSUs are required by most operating companies. One CSU is required per PRI. Suitable CSUs which support 64 Kbps clear and

Bipolar 8 Zero Substitution (B8ZS) are available from vendors such as Verilink, Digitalink, Kentrox, and Tellabs.



Note:

Contact your Avaya Sales representative for specific local CSU requirements.

Hardware description

Media Gateway/Media Gateway Expansion

The Media Gateway and Media Gateway Expansion contain physical card slots, numbered 1 to 10. When configuring the system, the physical card slot numbers must be transposed to logical card slot numbers. For example, to configure a card physically located in slot two of the Media Gateway one, use logical slot 12. To configure a card physically located in slot two of the Media Gateway two, use logical Slot 22.

[Table 97: Media Gateway and Media Gateway Expansion slot assignments](#) on page 247 maps physical card slot numbers to logical card numbers for the Media Gateway and Media Gateway Expansion and reflects added support for the Media Gateway and Media Gateway Expansion physical card slot 4.

Table 97: Media Gateway and Media Gateway Expansion slot assignments

| | Media Gateway/Media Gateway Expansion | | | | | | | |
|-------------------------|---------------------------------------|-------------------|--------------------|-------------------|--------------------|-------------------|--------------------|-------------------|
| | First | | Second | | Third | | Fourth | |
| | Physical card slot | Logical card slot | Physical card slot | Logical card slot | Physical card slot | Logical card slot | Physical card slot | Logical card slot |
| Media Gateway | 1 | 11 | 1 | 21 | 1 | 31 | 1 | 41 |
| | 2 | 12 | 2 | 22 | 2 | 32 | 2 | 42 |
| | 3 | 13 | 3 | 23 | 3 | 33 | 3 | 43 |
| | 4 | 14 | 4 | 24 | 4 | 34 | 4 | 44 |
| | 5 | * | 5 | * | 5 | * | 5 | * |
| | 6 | * | 6 | * | 6 | * | 6 | * |
| Media Gateway Expansion | 7 | 17 | 7 | 27 | 7 | 37 | 7 | 47 |
| | 8 | 18 | 8 | 28 | 8 | 38 | 8 | 48 |
| | 9 | 19 | 9 | 29 | 9 | 39 | 9 | 49 |

| | Media Gateway/Media Gateway Expansion | | | | | | | |
|-------------------------|---------------------------------------|----|--------|----|-------|----|--------|----|
| | First | | Second | | Third | | Fourth | |
| | 10 | 20 | 10 | 30 | 10 | 40 | 10 | 50 |
| Legend * Not supported. | | | | | | | | |

NTRB21 TMDI card

The NTRB21 TMDI card provides 1.5 MBit/s Digital Trunk Interface or Primary Rate Interface functionality on the system. The NTRB21 has a built-in, downloadable D-channel.

The NTRB21 can be equipped with the NTA09 DTI/PRI card (with the NTB51 downloadable D-channel daughterboard) and the NTA93 DCHI daughterboard.

 **Note:**

A TMDI D-channel programmed as a backup D-channel against a non-TMDI primary D-channel is not supported. Backup D-channels are supported only when programmed against TMDI primary D-channels.

[Figure 82: NTRB21 TMDI card faceplate](#) on page 249 shows a faceplate of the NTRB21 TMDI card.

Shelf slot assignments

For Small Systems, the NTRB21 can be placed in main and expansion cabinets in any single card slot given in [Table 99: Shelf slot assignments for NTRB21, NTA09, and NTA20](#) on page 253.

The Media Gateway Expansion does not support digital trunks (DTI/PRI).




Figure 82: NTRB21 TMDI card faceplate

NTAK09 DTI/PRI circuit card

The NTA09 Digital Trunk Interface/Primary Rate Interface (DTI/PRI) card provides the physical interface for the DS-1 facility T-1 carrier on the system. It is required for PRI and DTI operation and is also used for ISL shared-mode applications.

[Figure 83: NTA09 DTI/PRI circuit card](#) on page 250 shows the faceplate layout, the location of the switch and the position of the daughterboards and connectors.

Shelf slot assignments

For cabinet systems, the NTA09 DTI/PRI card can be placed in main and expansion cabinets in any single card slot given in [Table 99: Shelf slot assignments for NTRB21, NTA09, and NTA20](#) on page 253.

Digital trunk cards are not supported in the Media Gateway Expansion.




Figure 83: NTA09 DTI/PRI circuit card

NTA20 Clock Controller (CC) daughterboard

Digital Trunking requires synchronized clocking so a shift in one clock source results in an equivalent shift of the same size and direction in all parts of the network. Synchronization is accomplished with the NTA20 clock controller circuit card in each Main and IP expansion cabinet/Media Gateway.

! **Important:**
IMPORTANT!

Every Small System cabinet or Media Gateway that contains a digital trunk must contain a clock controller.

If a Small System is equipped with digital trunks, it is recommended that at least one digital trunk be placed in the main cabinet.

 **Note:**

Clocking slips can occur between systems that are clocked from different COs, if the COs are not synchronized. The slips can degrade voice quality.

The Clock Controller circuitry synchronizes the system to an external reference clock, and generates and distributes the clock to the system. A Small System can function either as a slave to an external clock or as a clocking master.

The NTAK20AA version of the clock controller meets AT&T Stratum 3 and Bell Canada Node Category D specifications. The NTAK20BA version meets CCITT stratum 4 specifications.

Clocking modes

The system supports a single clock controller that can operate in one of two modes - tracking or non-tracking (also known as free-run).

Tracking mode

In tracking mode, one or possibly two DTI/PRI cards supply a clock reference to a clock controller daughterboard. One DTI/PRI is defined as the primary reference source for clock synchronization, while the other is defined as the secondary reference source (PREF and SREF in LD 73).

There are two stages to clock controller tracking, as follows:

- tracking a reference
- locked onto a reference

When tracking a reference, the clock controller uses an algorithm to match its frequency to the frequency of the incoming clock. When the frequencies are very nearly matched, the clock controller locks onto the reference. The clock controller makes small adjustments to its own frequency until incoming and system frequencies correspond.

If the incoming clock reference is stable, the internal clock controller tracks it, locks onto it, and matches frequencies exactly. Occasionally, however, environmental circumstances cause the external or internal clocks to drift. When this happens, the internal clock controller briefly enters the tracking stage. The green LED flashes momentarily until the clock controller locks onto the reference once again.

If the incoming reference is unstable, the internal clock controller is continuously in the tracking stage, with the LED flashing green all the time. This condition does not present a problem, instead it shows that the clock controller is continually attempting to lock onto the signal. However, if slips are occurring, there is a problem with the clock controller or the incoming line.

Free-run (non-tracking)

In free-run mode, the clock controller does not synchronize on any source, it provides its own internal clock to the system. This mode can be used when the system is used as a master clock source for other systems in the network. Free-run mode is undesirable if the system is

intended to be a slave. It can occur, however, when both the primary and secondary clock sources are lost due to hardware faults, or when invoked by using software commands.

Shelf slot assignment

For cabinet systems, the NTAK09 DTI/PRI card can be placed in main and expansion cabinets in any single card slot given in [Table 99: Shelf slot assignments for NTRB21, NTAK09, and NTAK20](#) on page 253.

Note:

For CISPR B group cabinets, the active Clock Controller (NTAK20) can only occupy slots 1-3, 11-13, 21-23, 31-33, or 41-43 in an Option 11C cabinet. For FCC and/or CISPR A group cabinets, this limitation does not exist.

On non-CISPR B system cabinets, the NTAK20 can be placed in slots 1-9 of the Option 11C main cabinet. On cabinets NTAK11Dx and NTAK11Fx, the active NTAK20 must be placed in slots 1-3 (slots 4-10 cannot be used.)

On non-CISPR B IP expansion cabinets, the NTAK20 can be placed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

Clock controller LED states

The clock controller LED, on the NTAK09 or NTRB21 faceplates, is in various states depending on the status of the clock controller.

Table 98: Clock controller LEDs

| LED | Clock controller |
|------------------|---|
| On (Red) | NTAK20 is equipped and disabled. |
| On (Green) | NTAK20 is equipped and is either locked to a reference or in free run mode. |
| Flashing (Green) | NTAK20 is equipped and attempting to lock (tracking mode) to a reference. If the LED flashes continuously over an extended period of time, check the CC STAT in LD 60. If the CC is tracking this can be an acceptable state. Check for slips and related clock controller error conditions. If none exist, then this state is acceptable, and the flashing is identifying jitter on the reference. |
| Off | NTAK20 is not equipped. |

Shelf slot assignments for NTRB21, NTAK09 and NTAK20

[Table 99: Shelf slot assignments for NTRB21, NTAK09, and NTAK20](#) on page 253 provides the shelf slot assignments for the NTRB21 TMDI card, NTAK09 DTI/PRI card, and NTAK20 Clock Controller daughterboard in Small Systems. The NTAK 93 DCH and NTBK51BA DDCH daughterboards are not included in this table because they are mounted on the NTAK09 DTI/PRI circuit card and not on a shelf.

Table 99: Shelf slot assignments for NTRB21, NTAK09, and NTAK20

| | | NTRB21 TMDI card | NTAK09 DTI/ PRI circuit card | NTAK20 Clock controller daughterboard | |
|--------------|-------------|---------------------|------------------------------------|--|--------------------------|
| | | | | CISPR B cabinets | Non- CISPR B cabinets |
| Small System | Main | 1 – 9 | 1 – 9 | 1 – 3 | 1 – 9 (see Note 2) |
| | Expansion 1 | 11 – 19 | 11 – 19 | 11 – 13 | 11 – 19 |
| | Expansion 2 | 21 – 29 | 21 – 29 | 21 – 23 | 21 – 29 |
| | Expansion 3 | 31 – 39 | 31 – 39 | 31 – 33 | 31 – 39 |
| | Expansion 4 | 41 – 49 | 41 – 49 | 41 – 43 | 41 – 49 |

 **Note:**

On cabinets NTAK11Dx and NTAK11Fx, the active card must be placed in slots 1 – 3 (slots 4 to 10 cannot be used).

NTAK93 D-channel Handler Interface (DCHI) daughterboard

The NTAK93 DCHI daughterboard interfaces with the system Central Processing Unit (CPU) and mounts on the NTAK09 DTI/PRI circuit card for PRI or ISL shared mode applications. The DCHI is responsible for performing the Q.921 layer 2 protocol information. It transfers layer 3 signaling information between two adjacent network switches.

The NTAK93 DCH daughterboard, when installed on the NTAK09 circuit card, is addressed in the same slot as the NTAK09. The NTAK93 can use SDI I/O addresses 0 to 79 and port 1.

 **Note:**

I/O addresses 0, 1, 2, 8 and 9 are preconfigured on the Small System and must not conflict with the I/O addresses on the NTAK93 card.

A minimum of one NTAK93 is required for each PRI link. If more than one PRI link connects to the same end location, a single DCHI circuit card can support up to a maximum of sixteen PRI connections for the Small System. This allows a total of 382 B-channels or PRI trunks to

be supported if a backup D-channel is also used. A total of 383 B-channels or PRI trunks are supported if a backup channel is not used.

NTBK51BA Downloadable D-channel (DDCH) daughterboard

The NTBK51BA DDCH daughterboard interfaces with the Small System Central Processing Unit (CPU) and mounts on the NTAK09 DTI/PRI circuit card for PRI D-channel applications. The DDCH is equivalent to the MSDL card used on a Large System, but it only supports D-channel applications (no SDI or ESDI).

The NTBK51BA DDCH daughterboard, when installed on the NTAK09 circuit card, is addressed in the same slot as the NTAK09.

A minimum of one NTBK51BA is required for each PRI link. If more than one PRI link connects to the same end location, a single DDCH circuit card can support up to a maximum of sixteen PRI connections for the Small Systems. This allows a total of 382 B-channels or PRI trunks to be supported if a backup D-channel is also used. A total of 383 B-channels or PRI trunks are supported if a backup channel is not used.

For more information about expansion daughterboards, see *Avaya Communication Server 1000M and Meridian 1 Small System Planning and Engineering, NN43011-220*.

Install PRI hardware

Install/remove daughterboard on the NTRB21 TMDI card

Work on a flat surface when mounting or removing daughterboards.

Mounting the NTAK20 daughterboard on the NTRB21

1. Visually inspect the connector pins on the underside of the daughterboard. Straighten and realign any bent pins prior to mounting.
2. Place the NTRB21 down flat on an antistatic pad.
3. From an overhead view, with the daughterboard parallel above the NTRB21 and the connector pins aligned over the connector sockets, line up the mounting holes on the daughterboard ([Figure 84: NTAK20 daughterboard installation on the NTRB21](#) on page 255) with the tops of the standoffs on the NTRB21.
4. Slowly lower the daughterboard towards the NTRB21, keeping the standoffs in line with all four holes, until the holes are resting on the tops of the four standoffs.

If more than a very slight amount of pressure is required at this point, the connector pins cannot be aligned with the connector socket. If so, lift the daughterboard off the NTRB21 and return to step 2.

5. Gently apply pressure along the edge of the board where the connector is located until the standoffs at the two corners adjacent to the connector snap into a locked position. Then press down on the two corners on the opposite side until they also lock into place.




Figure 84: NTA20 daughterboard installation on the NTRB21

Insert/remove the NTRB21 TMDI card

Refer to [Table 99: Shelf slot assignments for NTRB21, NTA09, and NTA20](#) on page 253 to determine the slot assignment for the NTRB21 TMDI circuit card appropriate to the system.

The NTRB21 card is installed only in the Media Gateway. It is not supported in the Media Gateway Expansion.

Inserting the NTRB21 TMDI card

1. Check for available card slots in the base cabinet and print the configuration record to determine which slots can be used. To do this, enter the following command in LD 22:

```
REQ: PRT  
TYPE: CFN
```

2. If in PRI mode, enter the following command in LD 96 to software disable the D-channel:

```
DIS DCH x
```

where x is the DCH port number that was assigned in LD 17.

3. If the Clock Controller is enabled, enter the following command in LD 60 to software disable it:

```
DIS CC 0
```

4. Hold the NTRB21 by the lock latch, unlock the latch, and slide the card into the cabinet.



Note:

Refer to [Table 99: Shelf slot assignments for NTRB21, NTA09, and NTA20](#) on page 253 to determine the correct slot in which to insert the card.

5. Enter the following command in LD 96 to enable the TMDI card:

```
ENL TMDI x ALL
```

where x is the NTRB21 TMDI card number (DLOP). The card number associated with an NTRB21 TMDI card is based on the slot in which the card is installed.

6. Within about 30 seconds, the D-channel layer 3 should be established. To confirm, enter the following command in LD 96 to request the current status of the D-channel:

```
STAT DCH (N)
```

The system response is:

```
DCH N EST OPER
```

This means that the D-channel is established and operational.

Removing the NTRB21 TMDI card

1. If in PRI mode, enter the following command in LD 96 to software disable the D-channel:

```
DIS DCH x
```

where x is the DCH port number that was assigned in LD 17.

2. If the Clock Controller is enabled, enter the following command in LD 60 to software disable it:

```
DIS CC 0
```

3. Enter the following command in LD 96 to disable the NTRB21 TMDI card:

```
DIS TMDI x All
```

where x is the NTRB21 TMDI card number (DLOP). The card number associated with a NTRB21 TMDI card is based on the slot in which the card is installed.

4. Hold the NTRB21 by the lock latch, unlock the latch, and slide the card out from the cabinet.

Install/remove daughterboards on the NTAK09 DTI/PRI card

Use these guidelines to mount the NTAK20 CC and the NTAK93 DCHI or NTB51 DDCH daughterboards on the NTAK09 DTI/PRI card. Because of the physical layout of the mother and daughterboards, the NTAK93 or NTB51 should be mounted before the NTAK20. Work on a flat surface when mounting or removing daughterboards.

Mounting the daughterboards on the NTAK09

1. Visually inspect the connector pins on the underside of the daughterboard. Straighten and realign any bent pins prior to mounting.
2. Place the NTAK09 down flat on an antistatic pad.
3. From an overhead view, with the daughterboard parallel above the NTAK09 and the connector pins aligned over the connector sockets, align the mounting holes on the daughterboard ([Figure 85: Daughterboard installation on the NTAK09](#) on page 258) with the tops of the standoffs on the NTAK09.
4. Slowly lower the daughterboard toward the NTAK09, keeping the standoffs in line with all four holes, until the holes rest on top of the four standoffs.



Note:

If more than a very slight amount of pressure is required at this point, the connector pins are not aligned with the connector socket. If so, lift the daughterboard off the NTAK09 and return to step 2.

5. Gently apply pressure along the edge of the board where the connector is located until the standoffs at the two corners adjacent to the connector snap into a locked position. Then press down on the two corners on the opposite side until they also are locked into place.

Use these guidelines to remove the NTAK20 Clock Controller (CC) and the NTAK93 DCHI or NTB51 DDCH daughterboards from the NTAK09 DTI/PRI card. Because of the physical layout of the mother and daughterboards, the NTAK20 should be removed before the NTAK93 or NTB51.

Removing the daughterboards from the NTAK09

1. Starting at the two corners opposite the connector, gently lift each corner out of the locking groove of the standoff.
2. At the two corners adjacent to the connector, gently lift the entire side until the mounting holes are clear of the locking groove of the standoff.
3. To remove the connector pins, grasp the edge of the board adjacent to the connector and lift gently.

If more than one NTAK09 card is installed, the additional cards might not carry daughterboards, depending on the system configuration. At least one NTAK20 (per system) is always required.




Figure 85: Daughterboard installation on the NTAK09

Set switches on NTAK09 DTI/PRI card

Set the switches on the NTAK09 DTI/PRI card according to [Table 100: NTAK09 switch settings](#) on page 258.

Table 100: NTAK09 switch settings

| Distance to digital cross connect | 1 DCH F/W | 2 (LEN 0) | 3 (LEN 1) | 4 (LEN 2) |
|-----------------------------------|-----------|-----------|-----------|-----------|
| 0 - 133 feet | Off | Off | Off | On |
| 133 - 266 feet | Off | On | On | Off |
| 266 - 399 feet | Off | Off | On | Off |
| 399 - 533 feet | Off | On | Off | Off |
| 533 - 655 feet | Off | Off | Off | Off |

Installing the NTAK09

Refer to [Table 99: Shelf slot assignments for NTRB21, NTAK09, and NTAK20](#) on page 253 to determine the slot assignment for the NTAK09 DTI/PRI circuit card appropriate to the system.

The NTAK09 DTI/PRI card is installed only in the Media Gateway. It is not supported in the Media Gateway Expansion.

Installing the NTAK09

1. Check for available card slots in the base and expansion cabinets, and Media Gateway systems and print the configuration record to determine which slots can be used. To do this, enter the following command in LD 22:

```
PRT CFN
```

2. Hold the NTAK09 by the lock latch, unlock the latch, and slide the card into the cabinet.

 **Note:**

Refer to [Table 99: Shelf slot assignments for NTRB21, NTAK09, and NTAK20](#) on page 253 to determine the correct slot in which to insert the card.

The only cable required to support the NTAK09 DTI/PRI circuit card is the NTBK04 cable. The cable is twenty feet long. If additional distance is required, the NT8D97AX fifty-foot extension is available up to a 600 foot maximum. [Table 101: DS-1 line interface pinout for NTBK04 cable](#) on page 259 gives pinout information for the NTBK04.

Connecting the cables

1. Connect the NTBK04 cable to a 50-pin Amphenol connector on the cabinet.
For a Small System, the Amphenol connector is located below the card slot in which the NTAK09 circuit card is installed.
2. Connect the other end of the cable to the CSU or DSX-1 cross connect.

Table 101: DS-1 line interface pinout for NTBK04 cable

| From 50-pin MDF connector | To DB-15 | Signal name | Description |
|---------------------------|----------|-------------|---------------------------|
| pin 48 | pin 1 | T | transmit tip to network |
| pin 23 | pin 9 | R | transmit ring to network |
| pin 25 | pin 2 | FGND | frame ground |
| pin 49 | pin 3 | T1 | receive tip from network |
| pin 24 | pin 11 | R1 | receive ring from network |

Enabling the NTRB21 TMDI card

1. Enter the following command in LD 96 to enable the NTRB21 TMDI card:

```
ENL TMDI x ALL
```

where x is the NTRB21 TMDI card number (DLOP). The card number associated with a NTRB21 TMDI card is based on the slot in which the card is installed.

2. If in PRI mode, enter the following command in LD 96 to software enable the D-channel:

```
ENL DCH y
```

where y is the DCH port number that was assigned in LD 17.

3. Within about 30 seconds, the D-channel layer 3 should be established. To confirm, enter the following command in LD 60 to request the current status of the D-channel:

```
STAT DCH (N)
```

The system response is:

```
DCH N EST OPER
```

This means that the D-channel is established and operational.

Enabling the NTAK09 DTI/PRI card

The DCHI and PRI cards must be configured prior to software enabling the NTAK09. Refer to the procedure [Implementing basic PRI](#) on page 261 for further information.

1. Enter the following command in LD 60 to software enable all NTAK09 DTI/PRI cards:

```
ENLL C
```

where C is the DTI/PRI card number (DLOP). The card number associated with a DTI/PRI card is based on the slot in which the card is installed.

Under normal conditions, this step enables the clock controller and D-channel interface. If enable fails, enter the following command in LD 60 to software enable clock tracking on the primary digital card:

```
ENL CC 0
```

2. Enter the following command in LD 96 to software enable the NTAK93 (DCHI) daughterboard:

```
ENL DCHI N
```

where N is the DCHI I/O address.

3. Within about 30 seconds, the D-channel layer 3 should be established. To confirm, enter the following command in LD 60 to request the current status of the D-channel:

```
STAT DCH (N)
```

The system response is:

```
DCH N EST OPER
```

This means that the D-channel is established and operational.

Use this procedure to configure the PRI cards, DCHI interface, DCH link and ISDN trunk route and trunks (B-channels) that are required to implement PRI between systems. No feature applications other than Basic Call Service are included in the implementation.

PRI cards must be configured before defining the DCH links or PRI applications.

Prompts which do not show a response can be left as default. For more information about any of these prompts, see *Avaya Software Input Output Administration, NN43001-611*.

Before installing PRI cards in an IP expansion cabinet/Media Gateway, first configure the expansion cabinet/Media Gateway for IP connectivity. Refer to LD 117 in the *Avaya Software Input Output Reference — Maintenance, NN43001-711* for further information.

To implement PRI on the system:

Implementing basic PRI

1. Add a PRI card. step [6](#) on page 261
2. Add a DCHI card. [Table 102: LD 17 - Adding a PRI card](#) on page 261
3. Define a PRI customer. [Table 104: LD 15 - Defining a PRI customer](#) on page 263
4. Define a PRI service route. [Table 105: LD 16 - Configuring an ISDN service route](#) on page 264
5. Define service channels (B-channels) and PRI trunks. [Table 106: LD 14 - Defining service channels and PRI trunks](#) on page 265
6. Define clock synchronization. [Table 107: LD 73 - Defining system timers and clock controller parameters](#) on page 266

Table 102: LD 17 - Adding a PRI card

| Prompt | Response | Description |
|--------|------------------|---|
| REQ | CHG | Change existing data. |
| TYPE | CFN | Configuration data block. |
| CEQU | YES | Changes to common equipment. |
| PRI | loop x card x | For Large Systems and Small Systems |
| TMDI | (Yes) No | TMDI Card (Mode set to PRI OR TRK) Option 11C Cabinet Other card |

Table 103: LD 17 - Adding a D-channel interface

| Prompt | Response | Description |
|----------|--|--|
| REQ | CHG | Change existing data. |
| TYPE | ADAN | Action Device And Number. |
| - ADAN | NEW DCH xx CHG DCH xx OUT DCH xx | Add a primary D-channel (any unused SDI port.) Change a primary D-channel. Remove the primary D-channel, where: xx =0-79. |
| - CTYP | DCHI MSDL TMDI | DCHI = D-channel configuration for the NTAK09 card or NTAK93. MSDL = NTBK51 Downloadable D-channel daughterboard. TMDI = D-channel configuration on TMDI (NTRB21) card. |
| - CDNO | 1-50 | Card slot number to be used as the primary DDCH/ DCHI. Card slots 10, 20, 30, 40, and 50 are only applicable for D-channel configuration of ISL or VNS. |
| - PORT | 1 | PORT must be set to 1. |
| - DES | <CR> | Designator. |
| - USR | PRI | D-channel is for ISDN PRI only. |
| - IFC | xx | Interface type. |
| - - DCHL | xx | PRI loop number. |
| - OTBF | 1-(16)-127 | Number of output request buffers.  Note: For a single PRI link, leave this prompt at default (16). Add 5 output request buffers per additional link. |
| - DRAT | 64KC | D-channel transmission rate. |
| - SIDE | NET (USR) | Prompted only if IFC is set to SL1. NET = network, the controlling switch. USR = slave to the controller. |
| - RLS | xx | Release ID of the switch at the far-end of the D-channel. |
| - RCAP | ND2 | Remote capability. |
| - OVLR | YES (NO) | Allow or disallow overlap receiving on a D-channel. Default is NO. Enter carriage return if settings are to be left at default. |
| - LAPD | YES (NO) | Change LAPD parameters. Enter carriage return if timers are to be left at default. The following timers are |

| Prompt | Response | Description |
|---------|-----------|---|
| -- T23 | 1-(20)-31 | prompted only if LAPD is YES. (They can all be left at default during initial setup.) Interface guard timer checks how long the interface takes to respond. In units of 0.5 seconds (default 20 = 10 seconds). |
| -- T200 | 2-(3)-40 | Retransmission timer in units of 0.5 seconds (default 3 = 1.5 seconds). |
| -- N200 | 1-(3)-8 | Maximum number of retransmissions. |
| -- N201 | 4(260) | Maximum number of octets in information field. |
| -- K | 1-(7)-32 | Maximum number of outstanding unacknowledged frames (NAKS). |

Table 104: LD 15 - Defining a PRI customer

| Prompt | Response | Description |
|--------|-------------------------|--|
| REQ: | NEW CHG | Add new data. Change existing data. |
| TYPE: | NET | Networking Data. |
| CUST | 0-99 | Customer number Range for Large System, Call Server 1000E, and Media Gateway 1000E |
| | 0-31 | Range for Small System, Media Gateway 1000B |
| LDN0 | xxxx | Listed Directory number 0 must be defined for ISDN PRI DID service. The length of LDN0 determines the number of trailing digits translated as the dialed DN on PRI DID routes. Up to seven digits can be entered if DNXP option 150 is equipped. Otherwise, up to four digits can be entered. |
| AC2 | | ESN Access Code 2. Enter incoming ISDN call types (NARS network translation types) for which AC2 must be inserted when INAC = YES in LD 16. Multiple responses are allowed. Prompted only if NARS is equipped. If a NARS call type is not entered here, it is defaulted to AC1. |
| | NPA NXX INTL SPN LOC | E.164 National. E.164 Subscriber. International. Special Number. Location Code |
| ISDN | YES | Customer is equipped with ISDN. |
| - PNI | (0) 1-32700 | Private Network Identifier. Each customer data block must have a unique PNI when multi-customer option is equipped. PNI = 1 is typical for CUST = 0. It must be matched by the PNI in the far-end RDB. |

| Prompt | Response | Description |
|----------|----------------|---|
| - HNPA | NPA | <p> Note: Using the default value of PNI = 0 prevents operation of features like NRAG, NACD and NMS.</p> <p>Telephone area code for this system. Sent as part of setup message as calling line identification.</p> <p>Telephone local exchange code for this system. Sent as part of setup message as calling line identification.</p> <p>Home location code (NARS), prompted when PRA = YES.</p> <p>One to four digit Local Steering Code, if required in the Coordinated Dialing Plan (CDP). LSCs are required only if the CDP DNs are longer than the local PDNs. The CLID sent for a CDP call is composed of the LSC defined in LD 15 plus the PDN of the calling set. Various ISDN network features depend on the CLID as the "return address" for sending feature control messages. Multiple LSCs can be defined in LD 87 for CDP, but only one LSC can be defined here for CLID.</p> |
| - HNXX | NXX | |
| - - HLOC | XXX | |
| - - LSC | 1-9999table 81 | |

Table 105: LD 16 - Configuring an ISDN service route

| Prompt | Response | Description |
|---------|-------------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | RDB | Route data block. |
| TKTP | xxx | Trunk type. |
| DTRK | YES | Digital trunk route. |
| - DGTP | PRI | 1.5 Mb PRI. Prompted only if PRA = YES in LD15. |
| ISDN | YES | ISDN option. |
| - MODE | PRA | Route used for PRA only. |
| - - PNI | (0) 1-32700 | <p>Private Network Identifier. Each customer data block must have a unique PNI when multi-customer option is equipped. PNI = 1 is typical for CUST = 0. It must be matched by the PNI in the far-end RDB.</p> <p> Note: Using the default value of PNI = 0, prevents operation of features like NRAG, NACD and NMS.</p> |
| IFC | xx | |

| Prompt | Response | Description |
|--------|--------------|---|
| - CHTY | BCH | Signalling type - prompted if DTRK is YES. D-channel signalling for B-channels. |
| - CTYP | <CR> | Call Type. Enter the call type to be associated with the outgoing route for direct dialing using the trunk access code (instead of NARS access code). See the <i>Avaya Software Input Output Administration, NN43001-611</i> for a listing of possible responses. |
| - INAC | YES | Insert ESN Access Code based on NARS/BARS call type for incoming calls on TIE routes only. If NARS is equipped, this feature inserts AC1 or AC2, depending on the responses to AC2 in LD 15 Customer Data Block. For NARS/BARS call types, INAC bypasses incoming digit insertion specified by INST in LD 16 Route Data Block. Unknown call types, including CDP steering codes, are not affected by INAC, and do not bypass digit insertion specified by INST. INAC must be Yes to support features such as Network ACD and Network Message Services, which depend on non-call associated TCAP facility messages. |
| PII | YES | Enable the Privacy Indicator Ignore (PII) feature |
| | NO (default) | Disable the PII feature. |
| | [CR] | Leave the feature setting as it is. |
| AUXP | YES | Enable the Auxiliary processor application (AUXP) feature. |
| | NO | Disable the AUXP feature. |
| | [CR] | Leave the feature setting as it is. Note: The AUXP prompt is automatically Yes when the PII prompt is Yes, and can be modified only when PII is No. |

Table 106: LD 14 - Defining service channels and PRI trunks

| Prompt | Response | Description |
|--------|-------------|---|
| REQ | NEW CHG | Add new data. Change existing data. When assigning several members at once use the multiple create command NEW XX. |
| TYPE | TIE | TIE Trunk only, allowed between MSL-1. |
| TN | l ch | Loop and channel for digital trunks |
| RTMB | 0-511 1-510 | Route number and Member number Range for Large System and CS 1000E system. |

| Prompt | Response | Description |
|--------|--------------|---|
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B. |

Table 107: LD 73 - Defining system timers and clock controller parameters

| Prompt | Response | Description |
|----------|----------|---|
| REQ | CHG | Change existing data. |
| TYPE | PRI | 1.5 Mb PRI. |
| FEAT | SYTI | System timers. |
| CCO | xx | Card slot number for Clock Controller 0. |
| PREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| SREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| CC1 | xx | Card number for Clock Controller 1. |
| PREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| SREF CC1 | xx | Secondary Reference DTI/PRI loop for Clock controller one. |
| CC2 | xx | Card number for Clock Controller 2. |
| PREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC3 | xx | Card number for Clock Controller 3. |
| PREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC4 | xx | Card number for Clock Controller 4. |
| PREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CCAR | 0-(15) | Clock Controller Audit Rate. Enter the time (in minutes) between normal CC audits. |

Chapter 18: 1.5 Mb DTI implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 267

[Hardware requirements](#) on page 267

[Hardware description](#) on page 247

[Install DTI hardware](#) on page 269

[Software enable the DTI/PRI cards](#) on page 270

Overview

This chapter provides the information required to install DTI on a system, including:

- hardware and software installation
- implementation procedures for basic call service

This chapter covers the most common type of Avaya DTI installation – a 24-channel Digital Trunk Interface (DTI) installation between two systems, or between a system and a central office.

Digital trunks are supported in Small System IP expansion cabinets.

Hardware requirements

To implement DTI on the system, the hardware listed in [Table 108: DTI hardware](#) on page 268 is required:

Table 108: DTI hardware

| Item | Description |
|--------|---|
| NTRB21 | DTI/PRI TMDI card |
| NTAK09 | DTI/PRI Circuit card |
| NTAK20 | Clock Controller Daughter board. Option 11C Cabinet support only one active Clock Controller per IP Expansion cabinet. |
| NTBK04 | Carrier Cable |

Cables

The following cables are required for DTI connections:

- DTI to external T1 cable
- NTBK04 carrier cable
- NT8D97 50-foot extension (if needed)

Channel Service Units (CSU)

When connecting the DTI/PRI to the public network, Channel Service Units (CSUs) are required by most operating companies. One CSU is required per DTI. Suitable CSUs which support 64 Kbps clear and Bipolar 8 Zero Substitution (B8ZS) are available from vendors such as Verilink, Digitalink, Kentrox and Tellabs.

Contact your Avaya Sales representative for specific local CSU requirements.

Hardware description

Refer to [Hardware description](#) on page 247.

Install DTI hardware

Refer to "[Install PRI hardware](#) on page 254" for information about installing DTI hardware. Specifically:

- To install the NTRB21 DTI/PRI card, see [Insert/remove the NTRB21 TMDI card](#) on page 255.
- To install the NTAK09 DTI/PRI card, see [Installing the NTAK09](#) on page 259.
- To install the NTAK20 Clock Controller, see [Install/remove daughterboards on the NTAK09 DTI/PRI card](#) on page 257.

Set the switches

Set the switches on the NTAK09 DTI/PRI card according to [Table 109: NTAK09 switch settings](#) on page 269.

Table 109: NTAK09 switch settings

| Distance to digital crossconnect | 1 DCH F/W | 2 (LEN 0) | 3 (LEN 1) | 4 (LEN 2) |
|----------------------------------|-----------|-----------|-----------|-----------|
| 0 - 133 feet | Off | Off | Off | On |
| 133 - 266 feet | Off | On | On | Off |
| 266 - 399 feet | Off | Off | On | Off |
| 399 - 533 feet | Off | On | Off | Off |
| 533 - 655 feet | Off | Off | Off | Off |

Connect the cables

For Small Systems, connect the NTBK04 cable to the 50-pin amphenol connector below the card slot in which the NTAK09 circuit card is installed. Connect the other end of the cable to the CSU or DSX-1 cross connect.

The NTBK04 is twenty feet long. If additional distance is required, the NT8D97AX 50-foot extension is available up to a 600-foot maximum. The only cable required to support the NTAK09 circuit card is the NTBK04.

Pinout information about the NTBK04 cable is given in [Table 110: DS-1 line interface pinout for NTBK04 cable](#) on page 270.

Table 110: DS-1 line interface pinout for NTBK04 cable

| From 50-pin MDF connector | to DB-15 | Signal name | Description |
|---------------------------|----------|-------------|---------------------------|
| pin 48 | pin 1 | T | transmit tip to network |
| pin 23 | pin 9 | R | transmit ring to network |
| pin 25 | pin 2 | FGND | frame ground |
| pin 49 | pin 3 | T1 | receive tip from network |
| pin 24 | pin 11 | R1 | receive ring from network |

Software enable the DTI/PRI cards

Enabling the NTRB21 TMDI card

1. Enter the following command in LD 96 to enable the NTRB21 TMDI card:

```
ENL TMDI X ALL
```

2. If in DTI mode, enter the following command in LD 96 to software enable the D-channel:

```
ENL DCH y
```

- where y is the DCH port number that was assigned in LD 17.

3. Within about 30 seconds, the D-channel layer 3 should be established. To confirm, enter the following command in LD 60 to request the current status of the D-channel:

```
STAT DCH (N)
```

The system response is:

```
DCH N EST OPER
```

This means that the D-channel is established and operational.

The DCHI and DTI cards must be implemented prior to software enabling the NTAK09. Refer to the section [Implementing basic PRI](#) on page 261 for further information.

Enabling the NTAK09 card

1. Enter the following command in LD 60 to software enable all NTAK09 DTI/PRI cards:

```
ENLL C
```

Under normal conditions, this step enables the clock controller and D-channel interface. If enable fails, go to step 2.

- Optional: Enter the following command in LD 60 to enable clock tracking on the primary digital card:

```
ENL CC 0
```

- Enter the following command in LD 96 to software enable the NTAK93 (DCHI) daughterboard:

```
ENL DCHI N
```

- where *N* is the DCHI I/O address.

- Within about 30 seconds, the D-channel layer 3 should be established. To confirm, enter the following command in LD 60 to request the current status of the D-channel:

```
STAT DCH (N)
```

The system response is:

```
DCH N EST OPER
```

This means that the D-channel is established and operational.

Use this procedure to implement the DTI software interface between systems or between a system and a central office.

Implementing DTI

- Add a DTI card. See [Table 111: LD 17 - Adding a DTI card](#) on page 271.
- Configure a DTI trunk route. See [Table 112: LD 16 - Configuring a DTI trunk route](#) on page 272.
- Configure the trunks. See [Table 113: LD 14 - Configuring the trunks](#) on page 272.
- Assign clock's reference source. See [Table 114: LD 73 - Assigning a clock reference source](#) on page 272.

Table 111: LD 17 - Adding a DTI card

| Prompt | Response | Description |
|--------|----------|------------------------------------|
| REQ | CHG | Change existing data. |
| TYPE | CFN | Configuration data block. |
| ... | | |
| PARM | YES | |
| ... | | |
| PCML | (MU) A | System PCM law. Default is MU law. |
| ... | | |

| Prompt | Response | Description |
|--------|-----------|--|
| CEQU | YES | Changes to common equipment. |
| MODE | TRK | Select Digital Trunk Interface mode. |
| TMDI | (YES) NO | Whether the card is a TMDI card. |
| YALM | DG2 (FDL) | Yellow alarm method — prompted only if the frame format is ESF — Must match the far end. Use FDL with ESF and use DG2 with non-ESF. If not prompted then DG2 is set automatically. |
| TRSH | 0-15 | The maintenance and threshold table to be used for this DTI card, as configured in LD 73. |
| T1TE | 0 1 2 | T1 Transmit Equalization (0=0-200 ft., 1=200-400 ft, 2=400-700 ft). Only for TMDI = YES. |

Table 112: LD 16 - Configuring a DTI trunk route

| Prompt | Response | Description |
|--------|------------------------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | RDB | Route data block. |
| TKTP | | Create a trunk route. |
| | COT WAT DID TIE FEX | Central Office Trunk data block WATS Trunk data block Direct Inward Dial Trunk data block TIE Trunk data block Foreign Exchange |
| DTRK | YES | Digital trunk route. |

Table 113: LD 14 - Configuring the trunks

| Prompt | Response | Description |
|--------|--------------|--|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | xxx | Trunk type |
| TN | l ch | Loop and channel for digital trunks |
| RTMB | 0-511 1-4000 | Route number and Member number Range for Large System and CS 1000E system. |
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B. |

Table 114: LD 73 - Assigning a clock reference source

| Prompt | Response | Description |
|--------|----------|-----------------------|
| REQ | CHG | Change existing data. |

| Prompt | Response | Description |
|----------|----------|---|
| TYPE | DDB | Digital Data Block. |
| CC0 | xx | Card slot number for Clock Controller 0. |
| PREF CC0 | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| SREF CC0 | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| CC1 | xx | Card number for Clock Controller 1. |
| PREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| SREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| CC2 | xx | Card number for Clock Controller 2. |
| PREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC3 | xx | Card number for Clock Controller 3. |
| PREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC4 | xx | Card number for Clock Controller 4. |
| PREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |

1.5 Mb DTI implementation

Chapter 19: 1.5 Mb ISL implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 275

[Hardware requirements](#) on page 275

[Basic ISL implementation](#) on page 279

Overview

This chapter contains the information required to implement ISL on the system. It describes:

- hardware and software installation
- hardware and software configuration for basic call service

Two modes of ISL are available: shared and dedicated. This chapter covers the most common type of Avaya ISL installation, an ISDN Signaling Link (ISL) installation in dedicated mode using dedicated and leased lines.

Hardware requirements

To implement ISL regardless of operation mode, analog or digital TIE lines are used as B-channels:

- NT8D15 or NT8D14 Analog TIE Trunk cards
- NTAK09 Digital trunk cards (for shared mode)
- NTAK02 SDI/DCH card (for dedicated mode)

Shared mode

In shared mode, PRI hardware plus the existing TIE line interface card is required.

Dedicated mode

Dedicated mode requires modems. See [Figure 86: ISL in dedicated mode using leased line](#) on page 276 and [Figure 87: ISL in dedicated mode using dialup modem](#) on page 277 for details.

The requirements for using a leased line are

Table 115: Leased line requirements

| Hardware | Comments |
|----------|---|
| NTAK02 | D-channel Handler Interface (DCHI) Card for ISL mode. |
| Modem | Modem capable of the following: (such as Ventel 2400-33 or 2400 Plus II) <ul style="list-style-type: none"> • minimum of 2400 baud • synchronous operation • must support leased line (also known as private line or point-to-point) operation |
| NTAK19BA | Four port break out cable. |




Figure 86: ISL in dedicated mode using leased line

Using dialup modems

The requirements for using a dialup modem are:

Table 116: Dial-up modem requirements

| Hardware | Comments |
|----------|--|
| NT8D09 | 500 set line card. |
| NTAK02 | D-channel Handler Interface (DCHI) Card (for ISL mode). |
| Modem | Modem capable of the following: (such as Ventel 2400-33 or 2400 Plus II) <ul style="list-style-type: none"> • minimum of 2400 baud • synchronous operation • modems are programmed such that one modem originates the call while the other auto-answers • auto dial capability |
| NTAK19BA | Four port break out cable. |




Figure 87: ISL in dedicated mode using dialup modem

ISL hardware installation (dedicated mode)

Use [Installing ISL hardware](#) on page 278 to install hardware for an ISDN Signaling Link (ISL) in dedicated mode using dedicated leased lines. For shared mode, hardware installation is identical to the PRI installation found in [1.5 Mb PRI implementation](#) on page 245, with the addition of analog or digital TIE Trunks or both.

The NTAK02 connects to a modem via the NTAK19BA four-port cable. Only ports 1 and 3 are available for use as DCHIs.

Installing ISL hardware

1. Set option switches/jumpers on the NTAK02 card as shown in [Table 117: NTAK02 switch setting](#) on page 278 and [Table 118: NTAK02 jumper settings](#) on page 278 for mode of operation (RS232 or RS422 and DTE or DCE.)

Table 117: NTAK02 switch setting

| Port 0 | Port 1 | SW 1-1 | SW 1-2 |
|--------|--------|--------|--------|
| SDI | DCH | OFF | OFF |
| SDI | DPNSS | OFF | ON |
| — | ESDI | ON | ON |

| Port 2 | Port 3 | SW 1-3 | SW 1-4 |
|--------|--------|--------|--------|
| SDI | DCH | OFF | OFF |
| SDI | DPNSS | OFF | ON |
| — | ESDI | ON | ON |

Table 118: NTAK02 jumper settings

| Unit | Jumper location | Strap for DTE | Strap for DCE |
|--------|-----------------|---------------|---------------|
| Unit 0 | J10 | C - B | B - A |
| Unit 1 | J7 J6 | C - B C - B | B - A B - A |
| Unit 2 | J5 | C - B | B - A |
| Unit 3 | J4 J3 | C - B C - B | B - A B - A |

| Unit | Jumper location | RS422 | RS232 |
|--------|-----------------|-------------|-------------|
| Unit 0 | — | — | — |
| Unit 1 | J9 J8 | C - B C - B | B - A B - A |
| Unit 2 | — | — | — |
| Unit 3 | J2 J1 | C - B C - B | B - A B - A |

2. Install the NTAK02 in any available slot 1-10 of the Option 11C Cabinet or slot 11-14 of Media Gateway 1.
3. Install the NTAK19BA four-port cable on the 50-pin Amphenol connector associated with the slot the NTAK02 is installed in.
4. If the installation is a dedicated mode using leased line modem configuration, the D-channel connects the DCHI with the far-end modem over a dedicated leased line.

The modems must have a minimum transmission rate of 2400 baud and must support leased line capability and synchronous mode, 2-wire or 4-wire operation.

Modems such as Ventel 2400 Plus II can be used. You must specify 4-wire operation when ordering. Otherwise, the modem is factory shipped for 2-wire operation.

 **Note:**

The Hayes Smart modem 2400 cannot be used on leased lines.

5. If the installation is a dedicated mode using dialup modem (such as Hayes 2400, Ventel 2400 or Gandalf 2400) configuration, the DCHI is connected to a modem that is connected to a 500 set line card. The call is connected to the far-end via the 500 set-to-TIE Trunk path.

 **Note:**

Dedicated mode using leased line modems is the preferred method.

6. Set up the D-channel. Configure the modem at one end in the autodial mode so it automatically initiates a call to the other end at power-up. The autodial number must be coordinated with the far-end switch. The originating modem must have this autodial number stored internally as part of the modem configuration routine. The far-end modem must be configured for auto-answer.

Basic ISL implementation

Implement dedicated mode

Use [Implementing dedicated mode](#) on page 280 to configure basic ISL capability. It applies to analog TIE Trunks that are used as B-channels. When DTI/PRI trunks are also used, LD 73 (digital data block-DDB) must also be configured with the appropriate clocking and threshold settings.

The DCHI in this case uses the NTAK02 circuit card and does not support ISDN PRI signaling. The DCHI is reserved for ISL use only. The D-channel can communicate with the far-end by means of a dedicated leased line modem or dialup modem.

For ISL dedicated mode using a dialup modem, a 500 set, TIE Trunk route and member have to be configured (used for D-channel).

Configuring dedicated mode involves four major steps:

Implementing dedicated mode

1. Configure the D-channel for ISL (LD 17).
2. Enable ISDN option (LD 15).
3. Enable the ISL option on a per route basis, assigning a D-channel for each route (LD 16).
4. Assign a channel identification to each trunk with the ISL option (LD 17).

Table 119: LD 17 - Configuring the D-channel for ISL

| Prompt | Response | Description |
|--------|--------------------------------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | CFN | Configuration data block. |
| ADAN | NEW DCH 0-79 | Add primary D-channel. |
| CTYP | DCHI | D-channel card type. |
| CDNO | 1-9 11-19 21-29 31-39 41-49 | Card slot in which the card supporting the DCHI resides. |
| PORT | 1 | Must be set to 1. |
| USR | PRI | D-channel for ISDN PRI only. |
| IFC | SL1 | Interface type. |
| DCHL | 1-9 | PRI card number (Must match entry for CDNO). |
| SIDE | NET (USR) | Net: network, the controlling switch. User: slave to controller. |
| RLS | XX | Software release of far-end. This is the current software release of the far-end. If the far-end has an incompatible release of software, it prevents the sending of application messages, for example, Network Ring Again. |
| CLOK | | D-channel clock type for signaling. |
| | EXT | Source of D-channel clock is external to DCHI card (in this case, the DTI/PRI circuit card). Normally, EXT is used for PRI/ISL. Do not confuse this clock with the E1 span Clock Controller found on the NTAK10/79. This clock is in reference to the DCHI synchronous mode of operation. Note: If directly connecting two DCHI ports without modems, set "CLOK" to "EXT" on one side and "INT" on the other. |

| Prompt | Response | Description |
|--------|-----------|--|
| LAPD | YES (NO) | Change LAPD parameters. Enter <cr> to leave timers at default value. The following timers are prompted only if LAPD is YES. The following can all be left at default during initial setup. |
| T23 | 1-(20)-31 | Interface guard timer checks how long the interface takes to respond. In units of 0.5 seconds (default 20 = 10 seconds). |
| T200 | 2-(3)-40 | Retransmission timer in units of 0.5 seconds (default 3 = 1.5 seconds). |
| N200 | 1-(3)-8 | Maximum number of retransmissions. |
| N201 | 4(260) | Maximum number of octets in information field. |
| K | 1-(7)-32 | Maximum number of outstanding unacknowledged frames (NAKS). |

Table 120: LD 73 - Configuring the D-channel for ISL

| Prompt | Response | Description |
|--------|----------------------------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | DDB | Digital data block. |
| TRSH | 0-15 | Assign a threshold set or table. |
| RALM | 1-(3)-128 | Yellow alarm 24-hour threshold. |
| BIPC | 1-(2)-128 | 24-hour bit rate violation threshold. |
| LFAC | 1-(3)-128 | 24-hour loss of frame alignment threshold. |
| BIPV | 1-(3)-4 1-(2)-4 | Bit rate (bipolar violation and CRC) monitoring limits for maintenance and out-of-service thresholds. |
| SRTK | 1-(5)-24 1-(30)-3600 | Frame slip-tracking-monitoring limits (in hours). |
| SRNT | 1-(15)1024 1-(3)-1024 | Non-tracking slip-rate monitoring maintenance and out-of-service thresholds. |
| LFAL | 1-(17)-10240 1-(511)-10240 | Loss of frame alignment monitoring limits. |
| SRIM | (1)-127 | Slip rate improvement timer. |
| SRMM | 1-(2)-127 | Maximum number of times the slip rate exceeds the maintenance limit. |

Table 121: LD 15 - Enabling ISDN option

| Prompt | Response | Description |
|--------|----------|---|
| REQ: | NEW CHG | Add new data. Change existing data. |
| TYPE: | NET | Networking data. |
| CUST | 0-99 | Customer number Range for Large System, Call Server 1000E, and Media Gateway 1000E |
| | 0-31 | Range for Small System, Media Gateway 1000B |
| ISDN | YES | Customer is equipped with ISDN. |
| PNI | 1-32700 | Customer private network identifier. This number MUST be unique to this customer in the private network. It is used to as part of the setup message for feature operation such as Network Ring Again and Network ACD. |
| HNPA | NPA | Telephone area code for this system. Sent as part of setup message as calling line identification. |
| HNXX | NXX | Telephone local exchange code for this system. Sent as part of setup message as calling line identification. |
| HLOC | XXX | Home location code (NARS). |
| LSC | 1-9999 | One to four digit Local Steering Code established in the Coordinated Dialing Plan (CDP). The LSC prompt is required for Calling Line I.D. and Network ACD. |
| AC2 | | Access Code 2. Enter call types (type of number) that use access code 2. Multiple responses are permitted. This prompt only appears on NARS equipped systems. If a call type is not entered here, it is automatically defaulted to access code 1. |
| | NPA | E.164 National. |
| | NXX | E.164 Subscriber. |
| | INTL | International. |
| | SPN | Special Number. |
| | LOC | Location Code. |

Table 122: LD 16 - Enabling ISL option on a per-route basis, assigning a D-channel for each route

| Prompt | Response | Description |
|--------|----------|-------------------------------------|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | RDB | Route data block. |

| Prompt | Response | Description |
|--------|----------|--|
| CUST | xx | Customer number as defined in LD 15. |
| ROUT | 0-511 | Route number Range for Large System and CS 1000E system. |
| | 0-127 | Range for Meridian 1 Small System, Media Gateway 1000B |
| TKTP | TIE | TIE Trunk route. |
| DTRK | YES/NO | Enter YES if this is a Digital Trunk Interface (DTI or PRI). |
| ISDN | YES | ISDN option. |
| MODE | ISLD | Route for ISL application. |
| DCHI | XX | DCHI port number in CFN which carries the D-channel for this TIE Trunk route. |
| PNI | 1-32700 | Customer private network identifier. Must be the same as the CDB PNI at the far-end. |
| IFC | | Interface type. |
| | SL1 | Interface type |
| CTYP | <CR> | Call Type. Enter the call type to be associated with the outgoing route for direct dialing using the trunk access code (instead of NARS access code). See the <i>Avaya Software Input Output Reference System Messages, NN43001-712</i> , for a list of valid responses. |
| INAC | YES | Insert Access Code. Permits the NARS AC1 or AC2 access code to be reinserted automatically on an incoming ESN call. |

Table 123: LD 14 - Assigning a channel identification to each trunk with the ISL option

| Prompt | Response | Description |
|--------|--------------|--|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | TIE | TIE Trunk type. |
| TN | l ch | Loop and channel for digital trunks |
| RTMB | 0-511 1-4000 | Route number and Member number Range for Large System and CS 1000E system. |
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B. |
| CHID | 1-192 | Channel identifier for ISL channels (remove with Xnn) must be coordinated with far-end (no default value). |

Implement shared mode

The same DTI/PRI software implementation sequence can be used as for Dedicated mode with the following exceptions:

Table 124: LD 17

| Prompt | Response | Description |
|--------|----------|--|
| USR | SHA | D-channel for ISL in "shared" mode, used for both ISDN PRI and ISL. |
| ISLM | 1-192 | Number of ISL B-channel (trunks) controlled by the D-channel (no default value). |

Table 125: LD 16

| Prompt | Response | Description |
|--------|----------|---|
| IFC | SL1 | Interface type must be SL1 (this is the only type supported for ISL). |
| MODE | ISLD | TIE route used for ISL members. |
| DCHI | 0-15 | DCHI port number. |

Table 126: LD 14

| Prompt | Response | Description |
|--------|----------|--|
| CHID | 1-192 | Channel identifier for ISL channels. Must be coordinated with the far-end. |

Chapter 20: 2.0 Mb DTI implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 285

[Hardware requirements](#) on page 285

[NTAK10 2.0 Mb DTI card](#) on page 286

[Install DTI hardware](#) on page 286

[DTI software implementation](#) on page 290

Overview


This chapter provides the information required to install the 2.0 Mb Digital Trunk Interface (DTI) card in a system. It includes information for:

- hardware installation
- software implementation

Hardware requirements

Hardware requirements for 2.0 Mb DTI are as follows:

- 2.0 Mb DTI Circuit card - NTAK10
(a Clock Controller is incorporated into the circuit card)
- CEPT Cable – NTBK05DA (120 $\frac{3}{4}$ twisted pair – 6.15 m length)



553-AAA1071

Figure 88: 2.0 Mb DTI cabling

NTAK10 2.0 Mb DTI card

The 2.0 Mb DTI card provides the physical interface for the digital E-1 carrier on the system. The card includes an onboard clock controller and is installed in slots 1 through 9 in the Option 11C Cabinet. On IP Expansion cabinets, it is placed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

The NTAK10 2.0 Mb DTI card is also used for ISL shared mode applications.

For information about the NTAK10 faceplate LEDs, see *Avaya ISDN Primary Rate Interface Maintenance, NN43001-717*.

Install DTI hardware

The NTAK10 circuit card is installed in card slot 1-9 in the Option 11C Cabinet. On IP Expansion cabinets, it is installed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

It is not supported in the Media Gateway Expansion. Up to four digital trunk cards are supported in each Media Gateway. The NTAK10 card is installed in Slots 1, 2, 3 and 4 of the Media Gateway.

! Important:
IMPORTANT!

Each Media Gateway that has a digital trunk must have a clock controller set to an external reference clock.

Inspect the NTAK10 circuit card

Inspect the circuit card before installing it in the Option 11C Cabinet or Media Gateway:

- Locate the NTAK10 2.0 Mb circuit card and carefully remove it from its packaging.
- Inspect the circuit card for any visible damage that occurred during shipping.

Set the switches

The NTAK10 incorporates four surface mounted dip switches. The following tables provide information about the various settings and related functions of these switches.

 **Note:**

The ON position for all the switches is toward the bottom of the card. This is indicated by a white dot printed on the board adjacent to the bottom left corner of each individual switch.

Set the switches on the circuit card according to the requirements of your installation.

Switch S1 - Clock Controller (CC) configuration

This switch enables and disables the onboard Clock Controller (CC).

Table 127: Switch S1

| Switch | Off (Up) | On (Down) |
|--------|--------------------------|---------------------------|
| S1-1 | Spare | Spare |
| S1-2 | Clock Controller Enabled | Clock Controller Disabled |

Switch S2 - Carrier impedance configuration

This switch sets the carrier impedance to 120 Ω . Twisted pair cable is usually associated with 120 Ω .

Table 128: Switch S2

| Switch | Off (Up) |
|--------|---------------------------------|
| S2-1 | 120 ³ / ₄ |

Switch S3 - Mode of operation

This switch selects the operational mode for the NTAK10. The NTAK10 supports firmware that allows it to operate in the standard CEPT format mode or the modified CEPT format used in France.

Table 129: Switch S3

| Switch | Off (Up) | On (Down) |
|--------|---------------------|-----------------|
| S3-1 | Non-French Firmware | French Firmware |
| S3-2 | Spare | Spare |

Switch S4 - Carrier shield grounding

This switch supports selective shield grounding of the Tx and/or Rx pairs of the carrier cable. The Tx and Rx pairs are referenced with respect to the 2.0 Mb DTI card that is, Rx is carrier received from the far-end device. The switches are needed to be kept in off (up) position and leave unconnected.

Table 130: Switch S4

| Switch | Off (Up) |
|--------|-----------------------------|
| S4-1 | Receive Shield Unconnected |
| S4-2 | Transmit Shield Unconnected |

 **Note:**

The usual method is to ground the outer conductor of the receive coax signal.

Insert the NTAK10

Install the circuit card in slots 1-9 in the Option 11C Cabinet, or in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth IP expansion cabinets, respectively.

Secure the circuit card in the cabinet or Media Gateway by locking the lock latch assemblies.

Connecting the cables

1. In the cabling area, located directly below the card cage, remove the retaining bar that secures the MDF cables. Connect the NTBK05DA interface cable to the 50-pin Amphenol connector below the card slot holding the NTAK10 2.0 Mb DTI circuit card. Reinstall the retaining bar to secure the cable(s).
2. Terminate the NTBK05DA carrier cable as required.

NTBK05DA pinouts

The pinouts for the NTBK05DA cable are as follows:

Table 131: NTBK05DA pinouts

| | | Color | Signal |
|--------|-------|-------|------------|
| pin 23 | pin 6 | Black | R0 |
| pin 48 | pin 7 | White | T0 |
| pin 50 | pin 9 | Bare | R0/T0 FGND |
| pin 24 | pin 2 | Black | R1 |
| pin 49 | pin 3 | Red | T1 |
| pin 25 | pin 5 | Bare | R1/T1 FGND |

NTBK05CA pinouts

The pinouts for the NTBK05CA cable are as follows:

Table 132: NTB05CA pinouts

| From: 50-pin MDF connector | To: Transmit coax connector | To: Receive coax connector | To: 50-pin MDF connector |
|----------------------------|-----------------------------|----------------------------|--------------------------|
| pin 23 | Inner conductor | — | — |
| pin 48 | outer conductor | — | — |
| pin 24 | — | Inner conductor | — |
| pin 49 | — | outer conductor | — |
| pin 21 | — | — | pin 49 |
| pin 46 | — | — | pin 48 |

DTI software implementation

The following procedure describes the process required to program basic 2.0 Mb DTI on the system main and IP expansion cabinets or Media Gateway.

Task summary list

The following is a summary of the tasks in this section:

1. [Table 133: LD 17 - Adding a 2.0 Mb DTI card](#) on page 290
2. [Table 134: LD 73 - Defining the 2.0 Mb DTI ABCD signaling bit tables](#) on page 291
3. [Table 135: LD 73 - Defining the 2.0 Mb DTI pad tables](#) on page 295
4. [Table 137: LD 73 - Defining the 2.0 Mb DTI timers](#) on page 298
5. [Table 139: LD 73 - Defining the 2.0 Mb DTI system timers](#) on page 300
6. [Table 140: LD 16 - Configuring the service routes](#) on page 302

Table 133: LD 17 - Adding a 2.0 Mb DTI card

| Prompt | Response | Description |
|--------|----------|--|
| REQ | CHG | Change. |
| TYPE | CEQU | Common equipment. |
| ... | | |
| DTI2 | xx | Enter a card slot number for 2.0 Mb DTI. |

Table 134: LD 73 - Defining the 2.0 Mb DTI ABCD signaling bit tables

| Prompt | Response | Description |
|--------------------------|--------------|--|
| REQ | NEW CHG | Add or change Digital Trunk Interface data block. |
| TYPE | DTI2 | 2.0 Mb/s DTI data block. |
| FEAT | ABCD | ABCD bit signaling category. |
| SICA | 2-16 | Signaling category. |
| ... | | |
| DFLT | (1)-16 | Default signaling category used for default values JDMI defaults to 16 with <CR> ³ . |
| Incoming/Outgoing Calls: | | |
| IDLE(S) | abcd | (Send) idle signal bits. |
| IDLE(R) | abcd | (Receive) idle signal bits. |
| FALT(S) | abcd | (Send) bits. 2.0 Mb DTI out-of-service. |
| | N | If FALT (send) signal not required. |
| FALT(R) | abcd | (Receive) bits. 2.0 Mb DTI out-of-service. |
| | N | If FALT (receive) signal not required. |
| Incoming Calls: | | |
| SEZ(R) | abcd | Seize signal (send or receive) for voice or data calls from or to a non-SL-1. |
| SEZD(R) | abcd | Seize signal (send or receive) for data calls between SL-1s. |
| | N | If SEZD(R) signal not required. |
| SEZV(R) | abcd | Seize signal (send or receive) for voice calls. |
| | N | If SEZV(R) signals not required. |
| P CALL(R) | abcd | (Receive) signal sent during seize by an incoming CO trunk. |
| TIME | ON OFF | Length of pulse time on, and time off. (default 2 seconds on, 8 seconds off) |
| SEZA(S) | abcd | Seize signal acknowledgment (send). |
| | N | If SEZA(S) signal not required. |
| P WNKS(S) | abcd | Wink start (corresponds to a pulsed seize acknowledgment). Prompted when SEZA(S) not required. |
| | N | If WNKS(S) signal not required. |
| TIME | 10-(220)-630 | Time for WNKS(S) signal in milliseconds. |

| Prompt | Response | Description |
|-----------|--------------|--|
| P DIGT(R) | abcd | (Receive) decadic pulses. |
| | N | If DIGT(R) not required. |
| NRCV(S) | abcd | Number received signal (send). |
| | N | If NRCV(S) signal not required. |
| P EOSF(S) | abcd | End of selection free (send). |
| | N | If EOSF(S) not required. |
| TIME | (100)-150 | Time for EOSF(S) in milliseconds. |
| P EOSB(S) | abcd | End of selection busy (send). |
| | N | If EOSB(S) not required. |
| TIME | (100)-150 | Time for EOSB(S) in milliseconds. |
| P OPCA(R) | abcd | Operator calling time (receive) signal. |
| | N | If OPCA(R) not required. |
| TIME | 64-(128)-192 | Time of OPCA(R) pulse in milliseconds. |
| REPT | (1)-5 | Number of OPCA(R) pulses. |
| CONN(S) | abcd | Connect send. |
| CONN(R) | abcd | Connect receive. |
| P RRC(S) | abcd | Register recall (send) signal. Activated by Malicious Call Trace. |
| | N | If RRC(S) not required. |
| TIME | 10-(100)-150 | Time of RRC(S) signal in milliseconds. |
| P BURS(S) | abcd | Bring up receiver (send). Uses switchhook flash timer for timer. |
| | N | If BURS(S) not required. |
| P BURS(R) | abcd | Bring up receiver (receive). Uses switchhook flash timer for timer. |
| | N | If BURS(R) not required. |
| TIME | 64-(128)-192 | Length of BURS(R) pulse in milliseconds. |
| P CAS(S) | abcd | CAS Flash. Same timing as analogue trunks.  Note: Prompted for JDMI only. Operational only if CASM package equipped. |
| | N | If CAS(S) not required. |
| CLRB(S) | abcd | Clearback (send) signal. |

| Prompt | Response | Description |
|-----------------|---------------|--|
| | N | If CLRB(S) not required (IDLE signal is used). |
| P RCTL(S) | abcd | Release control (send) signal. |
| | N | If RCTL(S) not required.  Note: Prompted only when CLRB is unused or is defined the same as IDLE. |
| TIME | 100-(150)-300 | Time value is stored in multiples of 10 milliseconds. |
| R RCOD(S) | abcd | Release Control Originating party Disconnect. This signal is another pulsed SL-1 signal sent on incoming trunks when the originating party disconnects first. |
| | N | If RCOD(S) not required. |
| TIME | 150 | Timer value in milliseconds is fixed. |
| P OPRS(R) | abcd | Operator (receive) manual recall signal. |
| | N | If OPRS(R) not required. |
| TIME | xxx yyy | Minimum and maximum time range for OPRS(R) in milliseconds. xxx = 8-(48)-2040 yyy = xxx-(128)-2040 |
| P NXFR(S) | abcd | Network transfer signal (send) pulse. Pulse time not variable. |
| | N | If NXFR(S) not required. |
| P ESNW(S) | abcd | ESN wink signal (send) pulse. Pulse time not variable. |
| | N | If ESNW(S) not required. |
| P CAS(S) | abcd | Centralized Attendant signal (send) pulse. Pulse time not variable.  Note: Prompted for 2.0 Mb DTI only. |
| | N | If CAS(S) not required. |
| CLRF(R) | abcd | Clear forward (receive). |
| | N | If CLRF(R) not required. |
| SOSI | abcd (N) | Special operator signal defined. Undefined. Prompted when OPRC = N. |
| Outgoing Calls: | | |
| SEZA(S) | abcd | Seize acknowledgement |
| SEZD(S) | abcd | Seize acknowledgement and (send) data signal. |

| Prompt | Response | Description |
|-----------|-------------------------------|---|
| | N | If SEZD(S) not required. |
| SEZV(S) | abcd | Seize acknowledgement and (send) voice signal. Only recommended for Meridian to M-1 applications. |
| TIME | xxx yyy | Minimum and maximum time range for OPRS(R) in milliseconds. xxx = 8-(48)-2040 yyy = xxx-(128)-2040 |
| | N | If SEZV(S) not required. |
| SEZA(R) | abcd | Seize acknowledgement (receive) signal. |
| | N | If SEZA(R) not required. |
| P WNKS(R) | abcd | Wink start pulsed seize acknowledgement (receive) signal. |
| | N | If P WNKS(R) not required. |
| TIME | 20-(140)-500, 20-(290)-500 | Minimum and maximum length of WNKS(R) pulse in milliseconds. |
| P EOS(R) | abcd | End of selection (receive) signal. |
| | N | If EOS(R) not required. |
| TIME | (64)-320 64- (256)-320 | Length of EOS(R) pulse stored in multiples of 8 milliseconds. |
| CONN(S) | abcd | Connect send. |
| CONN(R) | abcd | Connect receive. |
| P OPRC(R) | abcd | Operator recall signal for special services. minimum three pulses of 160 milliseconds each. |
| | N | If OPRC(R) not required. |
| P BURS(S) | abcd | Bring up receiver (send) for L1 networking. |
| | N | If BURS(S) not required. |
| P BURS(R) | abcd | Bring up receiver (receive) for L1 networking. |
| | N | If BURS(R) not required. |
| TIME | 64-(128)-192 | Length of BURS(R) pulse in milliseconds. |
| | N | If SEZV(S) not required. |
| P CAS(R) | abcd | CAS Flash. Same timing as analogue trunks. Prompted for JDMI only. Operational only if CASR package equipped. |
| | N | If CAS(R) not required. |
| CLRB(R) | abcd | Clear back. |
| | N | If CLRB(R) not required, when IDLE is used. |

| Prompt | Response | Description |
|-----------|------------------------------|---|
| P RCTL(R) | abcd | Release control. Prompted only when CLRБ is unused or is defined the same as IDLE. |
| | N | If RCTL(R) not required. |
| TIME | 96-(128)-320 96-(256)-320 | Time value stored in multiples of 8 milliseconds. |
| P NXFR(R) | abcd | Network transfer. |
| | N | If not required. |
| P ESNW(R) | abcd | ESN wink signal. |
| | N | If ESNW(R) not required. |
| P CAS(R) | abcd | Centralized attendant service signal. 2.0 Mb DTI only ³ . |
| | N | If CAS(R) not required. |
| CLRF(S) | abcd | Clear forward (send). |
| | N | If CLRF(S) not required. |
| TIME | (0) | 800 milliseconds. * Note: Prompted when the abcd bits entered in response to the CLRF(S) prompt are different from the abcd bits of the IDLE signal. |
| SOSO | abcd (N) | Special operator signal defined (undefined). * Note: Prompted when OPRC = N. |

Table 135: LD 73 - Defining the 2.0 Mb DTI pad tables

| Prompt | Response | Description |
|--------|----------|--|
| REQ | NEW CHG | Add or change Digital Trunk Interface data block. |
| TYPE | DTI2 | 2.0 Mb DTI. |
| FEAT | PAD | Request the digital pad feature. |
| PDCA | 1-16 | PAD Category table. If one channel is using the specified table, then the command is aborted. Cannot modify or delete Table 1. |
| TNLS | YES (NO) | TN List. This is for the print command only. A YES response means that a list of the trunk TNs using the requested PAD category tables are printed after the table. |

| Prompt | Response | Description |
|--|----------|--|
| DFLT | (1)-16 | For NEW only. The table is used for default values. |
| <p>The following prompts define the pad levels. The receiving pad code is r and the transmission pad code is t. These entries have the range 0-15. The pad values (in decibels) relating to these codes are shown after this table.</p> | | |
| ONP | r t | On-premises extension. |
| OPX | r t | Off-premises extension. |
| DTT | r t | Digital TIE trunks. |
| SDTT | r t | Digital Satellite TIE trunks. |
| NTC | r t | Nontransmission compensated. |
| TRC | r t | Transmission compensated. |
| DCO | r t | Digital COT, FEX, WAT, and DID trunks. |
| VNL | r t | Via Net Loss. |
| DTO | r t | 2.0 Mb DTI digital TOLL office trunks. |
| ACO | r t | AnalogCO or WATS trunks. |
| AFX | r t | Analog FEX trunks. |
| ADD | r t | Analog DID trunks. |
| SATT | r t | Analog satellite TIE trunks. |
| TNLS | YES (NO) | TN List. This is for the print command only. A YES response means that a list of the trunk TNs using the requested PAD category tables are printed after the table. |
| DFLT | (1)-16 | For NEW only. The table is used for default values. |
| <p>The following prompts define the pad levels. The receiving pad code is r and the transmission pad code is t. These entries have the range 0-15. The pad values (in decibels) relating to these codes are shown after this table.</p> | | |
| ONP | r t | On-premises extension. |
| OPX | r t | Off-premises extension. |
| TNLS | YES (NO) | TN List. This is for the print command only. A YES response means that a list of the trunk TNs using the requested PAD category tables are printed after the table. |
| DFLT | (1)-16 | For NEW only. The table is used for default values. |
| <p>The following prompts define the pad levels. The receiving pad code is r and the transmission pad code is t. These entries have the range 0-15. The pad values (in decibels) relating to these codes are shown after this table.</p> | | |
| ONP | r t | On-premises extension. |

| Prompt | Response | Description |
|--------|----------|---|
| OPX | r t | Off-premises extension. |
| DTT | r t | Digital TIE trunks. |
| SDTT | r t | Digital Satellite TIE trunks. |
| NTC | r t | Nontransmission compensated. |
| TRC | r t | Transmission compensated. |
| DCO | r t | digital COT, FEX, WAT, and DID trunks. |
| VNL | r t | Via Net Loss. |
| DTO | r t | 2.0 Mb DTI digital TOLL office trunks. |
| ACO | r t | Analog CO or WATS trunks. |
| AFX | r t | Analog FEX trunks. |
| ADD | r t | Analog DID trunks. |
| SATT | r t | Analog satellite TIE trunks. |
| ATO | r t | Analog TOLL office trunks. |
| DTI2 | r t | 2.0 Mb DTI trunk (Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=DTI2). |
| XUT | r t | Analog CO trunk (Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=DTI2). |
| XEM | r t | Analog TIE trunk (Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=DTI2). |

The following pads are available for the 2.0 Mb DTI card. Their respective codes are also given. Positive dB represents loss and negative dB represents gain.

Table 136: 2.0 Mb DTI pads

| | | | | | | | | |
|------------|------|------|-------|-------|-------|-------|-------|------|
| code | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| value (dB) | 0.0 | +1.0 | +2.0 | +3.0 | +4.0 | +5.0 | +6.0 | +7.0 |
| code | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| value (dB) | +8.0 | +9.0 | +10.0 | +11.0 | +12.0 | +13.0 | +14.0 | -1 |
| code | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 |
| value (dB) | -2 | -3 | -4 | -5 | -6 | -7 | -8 | -9 |
| code | 24 | 25 | 26 | | | | | |
| value (dB) | -10 | idle | +0.6 | | | | | |

Table 137: LD 73 - Defining the 2.0 Mb DTI timers

| Prompt | Response | Description |
|------------|---------------|--|
| REQ | NEW CHG | Add or Change Digital Trunk Interface data block |
| TYPE | DTI2 | 2.0 Mb DTI |
| FEAT | LPTI | Set the timers used for a 2.0 Mb DTI |
| LOOP | xx | 2.0 Mb DTI card slot number. xx = 1-9 in Main Cabinet. xx = 11-19, 21-29, 31-39, 41-49 in IP expansion cabinets 1-4, respectively. xx = 11-14, 21-24, 31-34, 41-44 of the first, second, third and fourth Media Gateway, respectively. |
| P DIGT (S) | abcd | Digit pulse timing from TDS (Bits P, X or U are selectable) |
| | N | If DIGT(S) signal not required |
| P METR(R) | abcd | Metering (receive). Bits P, X or U. Only two P bits allowed. COT and DID trunks only. * Note: PPM package must be enabled. |
| | N | If METR(R) signal not required |
| EDGE | 0 1 | PPM bit counted when changed from 1 to 0. PPM bit counted when changed from 0 to 1. |
| TIME | 40-(240)-480 | Maximum time METR signal is in milliseconds. |
| SASU | 0-(1920)-8064 | Seize acknowledge supervision period in milliseconds. 2.0 Mb DTI default = 1920 |
| MFAO | YES (NO) <CR> | DTI card will or will not set bit 3 of timeslot 0 if loss of Multiframe Alignment Signal (MFAS) occurs. 2.0 Mb DTI default = NO <cr> = no change is required |
| SZNI | YES (NO) | PSTN incoming seizure during lockout of MFAS and far-end fault states allowed (denied) |
| MFF | CRC (AFF) | Multiframe format - Cyclic Redundancy Check (CRC 4) Alternative Frame Format * Note: Prompted for Small Systems. |

The following prompts and associated responses define the grade of service timers for the DTI card. Group I problems are treated individually. They are bipolar violations, bit error rate (frame alignment) slips, and CRC-4 errors.

Group II problems are treated as a group. They are bit 3 of TS0 (far-end out of service), bit 6 of TS16 (far-end lost multiframe alignment), AIS (alarm indication signal), loss of frame alignment, and loss of multiframe alignment.

Responses are interpreted as follows:

- mt = Maintenance threshold time.
- ct = New call suppression (hardware service removal) threshold time.
- ot = Out of service threshold time.
- dt = No new data calls suppression threshold time.

Each of the response times are expressed as follows:

- nnnY = time in milliseconds where nnnn = 20-5000 (input to nearest 20 milliseconds.)
- nnnS = time in seconds where nnn = 1-240
- nnnM = time in minutes where nnn = 1-240
- nnH = time in hours where nn = 1-24

Table 138: LD 73 - Defining the grade of service timers for the DTI card

| Prompt | Response | Description |
|--------|----------------|---|
| CRC | NC mt dt ct ot | <p>Cyclic redundancy check error counts. NC = Error count values are in the range 1-255. mt = Maintenance threshold time (MNT). dt = No new data calls threshold time (NNDC). ct = No new calls threshold time (NNC). ot = Out of service threshold time (OOS).</p> <p> Note: The following requirements must be met for input. mt = Maintenance threshold is equal to or greater than dt. dt = Data calls threshold is equal to or greater than ct. ct = Calls threshold is equal to or greater than ot.</p> |
| BPV | NB mt dt ct ot | <p>Bipolar violation error counts. NB = Error count values are in the range 1-255. mt = Maintenance threshold time (MNT). dt = No new data calls threshold time (NNDC). ct = No new calls threshold time (NNC). ot = Out of service threshold time (OOS).</p> <p> Note: The following requirements must be met for this input: mt = >dt = >ct = >ot.</p> |
| FAP | NF mt dt ct ot | <p>Frame alignment problem thresholds. NF = Error count values are in the range 1-255. mt = Maintenance threshold time (MNT). dt = No new data calls threshold time (NNDC). ct = No new calls threshold time (NNC). ot = Out of service threshold time</p> |

| Prompt | Response | Description |
|--------|----------------|---|
| SLP | NS mt dt ct ot | <p> Note: The following requirements must be met for this input: mt = >dt = >ct = >ot.</p> <p>Maintenance threshold slip count. NS = Error count values are in the range 1-255. mt = Maintenance threshold time (MNT). dt = No new data calls threshold time (NNDC). ct = No new calls threshold time (NNC). ot = Out of service threshold time (OOS).</p> |
| GP2 | T2 mt dt ct ot | <p>Group 2 error thresholds. This is the maximum amount of time that can occur before software checks the associated thresholds of 120 to 32640 msec and rounds it to the closest multiple of 128 msec. T2 error count values are in the range 1-(20)-255. NC = Error count values are in the range 1-255. mt = Maintenance threshold time (MNT). dt = No new data calls threshold time (NNDC). ct = No new calls threshold time (NNC). ot = Out of service threshold time (OOS).</p> <p> Note: The following requirements must be met for this input: mt = >dt = >ct = >ot.</p> |
| FRFW | YES (NO) | This 2.0 Mb DTI card is (is not) equipped with special Firmware for France. |

Table 139: LD 73 - Defining the 2.0 Mb DTI system timers

| Prompt | Response | Description |
|--------|-----------------------|--|
| REQ | NEW CHG | Add or Change Digital Trunk Interface data block. |
| TYPE | DTI2 | 2.0 Mb DTI. |
| FEAT | SYTI | Change the switch timers and counters for 2.0 Mb DTI. There is only one such block per switch. |
| MAND | 0-(15)-1440 | Maintenance guard time in minutes. |
| NCSD | 0-(15)-1440 1S-59S | New call suppression guard time in minutes and seconds. |
| OSGD | 0-(15)-1440 | Out-of-service guard time in minutes. |
| OOSC | 0-(5)-127 | Out-of-service occurrences since midnight (DTI disabled). |
| PERS | 0-(100)-254 | Persistence timer in milliseconds for far-end problems. |
| DBNC | (10)-32 | Debounce timer in milliseconds. |
| CCO | xx | Card slot number for Clock Controller 0. |
| | <CR> | No change for defaults. |

| Prompt | Response | Description |
|----------|-------------|--|
| | X | To remove clock controller data. |
| PREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| SREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| CC1 | xx | Card number for Clock Controller 1. |
| PREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| SREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| CC2 | xx | Card number for Clock Controller 2. |
| PREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC3 | xx | Card number for Clock Controller 3. |
| PREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC4 | xx | Card number for Clock Controller 4. |
| PREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CCGD | 0-(15)-1440 | Clock controller free run guard time in minutes. |
| CCAR | 0-(15) | Clock controller audit rate. The time, in minutes, between normal CC audits. Only programmable on units equipped with 2-Mb DTI. |
| | | <p> Note: The clock controller prompts only appear for clocks which are valid for the machine type being configured. The prompts only appear if the system is in a valid state for the definition of the 2.0 Mb DTI clock controller data that is, the DTI clock references must be unused or in a free-run mode.</p> <p> Note: Before programming clock controller references, the QPC775 clock controller card(s) must be plugged in, and the switches on the system's QPC441 3 Port Extender must be appropriately set. Otherwise, the PREF and SREF prompts are not given.</p> |

Table 140: LD 16 - Configuring the service routes

| Prompt | Response | Description |
|--------|------------------|--|
| REQ | NEW CHG | Add or Change Route data block. |
| TYPE | RDB | Route data block. |
| CUST | xx | Customer number, as defined in LD 15 |
| ROUT | 0-511 | Route number Range for Large System and CS 1000E system. |
| | 0-127 | Range for Meridian 1 Small System, Media Gateway 1000B. |
| TKTP | | Service routes allowed with ISDN. |
| | TIE COT DID | TIE trunk route. Central office trunk. Direct Inward Dial trunk. |
| RCLS | (EXT) INT | Class marked route as Internal or External. |
| DTRK | (NO) YES | Digital trunk route. Analog. Digital. |
| DGTP | DTI2 | Select a digital trunk type of 2.0 Mb DTI. |
| ... | | |
| NCNA | YES (NO) | Network Call Name is (is not) allowed. |
| NCRD | YES (NO) | Network Call Redirection. Allows network call redirection messages to be sent (or blocks messages if NCRD=no). |
| PTYP | | Port type at far-end: |
| | (ATT) AST AOT | Analog TIE trunk routes: Analog TIE trunk. Analogue satellite system TIE trunk or ESN satellite Meridian SL-1 TIE trunk. Analogue TIE trunk, used instead of ATT whenever the system has one or more digital satellite trunk routes (DST) to any digital satellite system which includes OPX sets. |
| | DTT DCT DST | Digital TIE trunk routes: Digital TIE trunk. Combination digital TIE trunk. Digital satellite system TIE trunk. |
| AUTO | YES (NO) | Auto-terminate must be NO if response to DSEL is VOD. |
| ICOG | IAO ICT OGT | Incoming and outgoing trunk. Incoming trunk. Outgoing trunk. |
| SRCH | (LIN) RRB | Linear search, or round-robin search, used for outgoing trunks. |
| ACOD | xxxx | Trunk route access code. |
| TARG | 1-15 | Trunk access restriction group for routes. |
| OABS | 0-9 | Outgoing digit(s) to be absorbed. |
| INST | (0)-999 | Digits to be inserted. |

| Prompt | Response | Description |
|--------|----------|---|
| CNTL | (NO) YES | Changes to controls or timers. |
| NEDC | | Near-end disconnect control. |
| | ETH | Either end control. |
| | ORG | Originating end control. Default for TIE, ATVN, DID, and CCSA trunk types. |
| FEDC | | Far-end disconnect control. |
| | ETH | Either end. |
| | FEC | Far-end. |
| | JNT | Joint. |
| | (ORG) | Originating end. |
| DLTN | YES (NO) | Dial tone on originating calls. |
| TIMER | (30)-240 | Network Ring Again duration timer time is in minutes. |
| | |  Note: Package 148, Advanced ISDN Features, is required. |

Table 141: LD 14 - Defining the associated list of service trunks

| Prompt | Response | Description |
|--------|-------------|---|
| REQ | NEW CHG | Add or Change Trunk data block. |
| TYPE | TIE COT DID | TIE trunk route. Central Office trunk data block. Direct Inward Dial trunk data block. |
| CHID | 1-382 | Channel ID for this trunk. |
| TN | l ch | Loop and channel for digital trunks |
| TOTN | s c | New card slot and channel, where: <ul style="list-style-type: none"> • s = 1-9 DTI2 card slot number (Option 11C main cabinet) s = 11-19 DTI2 card slot number (IP expansion cabinet 1) s = 21-29 DTI2 card slot number (IP expansion cabinet 2) s = 31-39 DTI2 card slot number (IP expansion cabinet 3) s = 41-49 DTI2 card slot number (IP expansion cabinet 4) • c = 1-30, 2.0 Mb DTI channel |
| PDCA | (1) - 16 | Pad Category Number. This prompt is given if the card is a 2.0 Mb DTI card, or if the card is a 2.0 Mb DTI card and the 1.5/2.0 Mb Gateway feature is equipped. For 2 to 16, the pad category used must already be defined in LD 73. |
| PCML | (MU) A | System PCM law. |

| Prompt | Response | Description |
|--------|--------------|---|
| | | Prompted if the card is 2.0 Mb DTI, or if the card is a 2.0 Mb DTI card and the 2.0 Mb Gateway feature is equipped. MU, the default, was entered in the PCML prompt in LD 17. |
| CUST | xx | Customer number, as defined LD 15 |
| NCOS | 0-3 0-7 0-15 | Network class-of-service group number: CDP BARS/ NFCR NARS |
| RTMB | 0-511 1-4000 | Route number and Member number Range for Large System and CS 1000E system. |
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B. |
| NITE | xxxx | Night-service directory number. |
| TGAR | (0)-15 | Trunk group access restriction. |
| CLS | | Class-of-service restrictions. |
| | |  Note: If DIP option is selected, a new SLCA table must be defined in LD 73. |

Chapter 21: 2.0 Mb PRI implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 305

[Hardware requirements](#) on page 305

[Hardware description](#) on page 306

[Install the NTA79 PRI card](#) on page 309

[Install the NTB50 PRI card](#) on page 313

[PRI software implementation](#) on page 319

Overview

This chapter provides the information required to install 2.0 Mb PRI on a system. It includes information about hardware installation and software implementation.

Hardware requirements

Circuit cards

To implement 2.0 Mb PRI, an NTA79 or an NTB50 PRI card plus associated daughterboards is required.

Table 142: 2.0 Mb PRI hardware requirement

| Circuit card | Description |
|--------------|--|
| NTBK50 | 2.0 Mb PRI circuit card. Supports the NTAK20 clock controller daughterboard and a D-channel handler interface daughterboard (NTAK93 DCHI or NTBK51 DDCH). |
| NTAK79 | 2.0 Mb PRI circuit card. Supports an onboard clock controller and an onboard D-channel handler interface. |
| NTAK20 | Clock-controller daughterboard. The system supports only one active clock controller per system or IP expansion cabinet.  Note: Every cabinet or Media Gateway that contains a digital trunk must contain a clock controller. Connects to the NTBK50 PRI card. |
| NTAK93 | D-channel-handler interface (DCHI) daughterboard. Connects to the NTBK50 PRI card. |
| NTBK51 | Downloadable D-channel daughterboard (DDCH). Connects to the NTBK50 PRI card. |

Cables

One of the following cables is required for a PRI connection:

- CEPT Cable - NTBK05DA (120 ½ twisted pair—6.15 m length), or
- CEPT Cable - NTBK05CA (75 ½ twisted pair—6.15 m length)

Hardware description

2.0 Mb PRI cards

Two PRI cards are available on the system:

- NTAK79 2.0 Mb PRI card
- NTBK50 2.0 Mb PRI card

The difference between the two PRI cards is that the NTBK50, when equipped with the NTBK51 D-channel daughterboard, can download software onto the card. This feature is based on the

MSDL platform and essentially replaces the D-channel circuit on the NTAK79 PRI card. (The NTAK79 PRI card does not support the NTB51 Downloadable D-channel handler daughterboard.)

A second difference between the NTAK79 and NTB50 2.0 Mb PRI cards is that the NTAK79 has an onboard clock controller while the NTB50 supports the NTAK20 clock controller daughterboard.

 **Note:**

If the NTAK93 D-channel daughterboard is attached to the NTB50 PRI card instead of the NTB51 Downloadable D-channel daughterboard, the NTB50 PRI card functions in the same manner as the NTAK79 PRI card.

NTAK79 2.0 Mb PRI circuit card

The 2.0 Mb Primary Rate Interface card provides the physical interface for the digital E-1 carrier on the system. The card includes an onboard clock controller and onboard D-channel handler. It is installed in slots 1-9 in the main cabinet. On IP Expansion cabinets, it is installed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

For information about the NTAK79 faceplate LEDs, see *Avaya ISDN Primary Rate Interface Maintenance, NN43001-717*.

NTBK50 2.0 Mb PRI circuit card

The 2.0 Mb Primary Rate Interface card provides the physical interface for the digital E-1 carrier on the system. The card is installed in slots 1-9 in the main cabinet or Media Gateway. On IP Expansion cabinets, it is installed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

 **Important:**

IMPORTANT!

Each Media Gateway that has a digital trunk must have a clock controller set to an external reference clock.

 **Note:**

Clocking slips can occur between Media Gateway systems that are clocked from different COs, if the COs are not synchronized. The slips can degrade voice quality.

The NTB50 supports the following clock controller and D-channel handler daughterboards:

- NTAK20 clock controller daughterboard
- NTAK93 D-channel handler daughterboard, or NTB51 Downloadable D-channel daughterboard.

If the NTA93 D-channel daughterboard is attached, the NTB50 PRI card functions in the same manner as the NTA79 PRI card. If the NTB51 D-channel daughterboard is attached, software is downloaded to the card instead of residing in a D-channel circuit.

For information about the NTB50 faceplate LEDs, see *Avaya ISDN Primary Rate Interface Maintenance, NN43001-717*.

NTAK20 Clock Controller (CC) daughterboard

The NTA20 Clock Controller daughterboard is used with the NTB50 2.0 Mb PRI card. The NTA79 PRI card has an onboard clock controller.

Digital Trunking requires synchronized clocking so that a shift in one clock source results in an equivalent shift of the same size and direction in all parts of the network. On systems, synchronization is accomplished with the NTA20 clock controller circuit card.

 **Important:**
IMPORTANT!

Every Small System cabinet or Media Gateway that contains a digital trunk must contain a clock controller. If a Small System is equipped with digital trunks, Avaya recommends that at least one digital trunk is placed in the Small System main cabinet.

The Clock Controller circuitry synchronizes the system to an external reference clock, and generates and distributes the clock to the system. The system can function either as a slave to an external clock or as a clocking master. The NTA20AB version of the clock controller meets AT&T Stratum 3 and Bell Canada Node Category D specifications. The NTA20BB version meets CCITT stratum 4 specifications.

Shelf slot assignment

On non-CISPR B system cabinets, the NTA20 is placed in slots 1-9. On cabinets NTA11Dx and NTA11Fx, the active NTA20 is placed in slots 1-3 (slots 4-10 cannot be used.) On IP Expansion cabinets, the NTA20 is placed in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth expansion cabinets, respectively.

NTAK93 D-Channel Handler Interface (DCHI) daughterboard

The NTA93 DCHI daughterboard interfaces with the system Central Processing Unit (CPU) and mounts on the NTB50 PRI card for PRI (but not ISL) applications. The equivalent circuit resides onboard the NTA79 2.0 Mb PRI card. The DTI/PRI digital trunk card is installed in the Media Gateway. Digital trunk cards are not supported in Media Gateway Expansions.

The DCHI is responsible for performing the Q.921 layer 2 protocol information. It transfers layer 3 signaling information between two adjacent network switches.

The NTAK93 DCH daughterboard, when installed on the NTB50 circuit card, is addressed in the same slot as the NTB50.

A minimum of one NTAK93 is required for each PRI link. If more than one PRI link connects to the same end location, a single DCH circuit card can support up to a maximum of sixteen PRI connections for the system. This allows for the support of 495 B-Channels or PRI trunks.

NTBK51 Downloadable D-Channel (DDCH) daughterboard

The NTB51 DDCH daughterboard interfaces with the system Central Processing Unit (CPU) and mounts on the NTB50 2.0 Mb PRI circuit card for PRI D-Channel applications.

Digital trunk cards are not supported in Media Gateway Expansions.

The DDCH is equivalent to the MSDL card on larger systems, but it only supports D-channel applications (no SDI or ESDI).

The NTB51 DDCH daughterboard, when installed on the NTB50 circuit card, is addressed in the same slot as the NTB50.

A minimum of one NTB51 is required for each PRI link. If more than one PRI link connects to the same end location, a single DDCH circuit card can support up to a maximum of 16 PRI connections for the system. This enables support for 495 B-channels or PRI trunks.

Install the NTAK79 PRI card

The steps required to install PRI are as follows:

Installing the NTAK79 PRI card

1. Inspect the PRI card.
2. Set the switches on the PRI card.
3. Insert the PRI card in slots 1-9 of the Small System main cabinet, or in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth Expansion cabinets, respectively.
4. Connect the cables.

Each step is described in the pages that follow. The PRI hardware installation procedure is the same regardless of the type of system at the far-end that is, another system such as the AXE-10, or SYS-12.

Inspect the NTA79 circuit card

- Locate the NTA79 2.0 Mb circuit card and carefully remove it from its packaging.
- Inspect the circuit card for any visible damage that occurred during shipping.

Set the switches on the NTA79

The NTA79 incorporates four onboard dip switches. The tables that follow provide information about the various settings and related functions of these switches.

*** Note:**

The ON position for all the switches is positioned toward the bottom of the card. This is indicated by a white dot printed on the board adjacent to the bottom left corner of each individual switch.




Figure 89: NTA79 with switch locations

Set the switches on the circuit card according to the requirements of your specific installation:

Switch SW1 - DCHI configuration

This switch enables and disables the onboard DCHI and sets the operating mode of the DCHI.

For the U.K., use DPNSS1 mode. For all other countries, use Q.931 mode.

Table 143: Switch SW1

| Switch | Down (On) | Up (Off) |
|--------|--------------|--------------|
| SW 1-1 | enable DCHI | disable DCHI |
| SW 1-2 | DPNSS1/DASS2 | Q.931 |

Switch SW2 - Carrier impedance configuration

This switch sets the carrier impedance to either 120½ or 75½. Twisted pair cable is usually associated with 120½. Coaxial cable is usually associated with the 75½ setting.

Table 144: Switch SW2

| Cable Type | SW 2-1 | SW 2-2 |
|------------|-----------|-----------|
| 75½ | Up (Off) | Down (On) |
| 120½ | Down (On) | Up (Off) |

Switch SW3 - Clock controller configuration

This switch enables and hardware disables the onboard Clock Controller. SW 3-2 should be disabled if the onboard clock controller is not in use.

Table 145: Switch SW3

| Switch | Down (On) | Up (Off) | Note |
|--------|-----------|----------|-------|
| SW 3-1 | — | — | Spare |
| SW 3-2 | Disabled | Enabled | |

Switch SW4 - Carrier shield grounding

This switch allows for the selective grounding of the Tx/Rx pairs of the carrier cable. Closing the switch (down position) applies Frame Ground (FGND) to the coaxial carrier cable shield, creating a 75½ unbalanced configuration. This applies only to the NTBK05CA cable.

Table 146: Switch SW4

| Switch | Down (On) | Up (Off) |
|--------|-----------|----------|
| SW 4-1 | Rx—FGND | Rx—OPEN |
| SW 4-2 | Tx—FGND | Tx—OPEN |

*** Note:**

The usual method is to ground the outer conductor of the receive coax signal.

Insert the NTAK79


Slide the circuit card into card slot 1-9 in the Small System main cabinet, or in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth IP Expansion cabinets, respectively.

Secure the circuit card in the cabinet by locking the lock latch assemblies. The card number associated with a 2.0 Mb PRI card is based on the slot in which the card is installed.

Follow the instructions below to connect cables to the NTAK79 PRI card. Also refer to [Figure 90: NTAK79 cabling](#) on page 312.

Connecting the cables

1. In the cabling area, located directly below the card cage, remove the retaining bar that secures the MDF cables. Connect the NTBKO5DA/CA interface cable to the 50-pin Amphenol connector below the slot in which the NTAK79 is installed. reinstall the retaining bar to secure the cable(s) in place.
2. Terminate the NTBKO5DA/CA carrier cable as required.



553-AAA1985

Figure 90: NTAK79 cabling

NTBK05DA pinouts

The pinouts for the NTB05DA cable are as follows:

Table 147: NTB05DA pinouts

| From: 50-pin MDF connector | To: 9-pin connector | color | Signal |
|----------------------------|---------------------|-------|------------|
| pin 23 | pin 6 | Black | R0 |
| pin 48 | pin 7 | White | T0 |
| pin 50 | pin 9 | Bare | R0/T0 FGND |
| pin 24 | pin 2 | Black | R1 |
| pin 49 | pin 3 | Red | T1 |
| pin 25 | pin 5 | Bare | R1/T1 FGND |

NTBK05CA pinouts

The pinouts for the NTB05CA cable are as follows:

Table 148: NTB05CA pinouts

| From: 50-pin MDF connector | To: Transmit coax connector | To: Receive coax connector | To: 50-pin MDF connector |
|----------------------------|-----------------------------|----------------------------|--------------------------|
| pin 23 | Inner conductor | — | — |
| pin 48 | outer conductor | — | — |
| pin 24 | — | Inner conductor | — |
| pin 49 | — | outer conductor | — |
| pin 21 | — | — | pin 49 |
| pin 46 | — | — | pin 48 |

Install the NTB50 PRI card

The NTB50 serves as a motherboard to the NTAK20 clock controller, and either the NTB51 Downloadable D-channel handler or the NTAK93 D-channel handler.

The steps required to install PRI are as follows:

Installing the NTBK50 PRI card

1. Inspect the PRI card and daughterboards.
2. Set the switches on the PRI card.
3. Mount the daughterboard(s) on the PRI card.
4. Insert the PRI card in the Small System main cabinet or Media Gateway and any IP expansion cabinets.
5. Connect the cables.

Each step is described in the pages that follow. The PRI hardware installation procedure is the same regardless of the type of system at the far-end.

Inspecting the NTBK50 circuit card

1. Locate the NTBK50 2.0 Mb circuit card plus associated daughterboard(s) and carefully remove them from their packaging.
2. Inspect the circuit cards for any visible damage that occurred during shipping.

Set the switches on the NTBK50

The NTBK50 incorporates three onboard dip switches. The following tables provide information about the various settings and related functions of these switches.

 **Note:**

The ON position for all the switches is positioned toward the bottom of the card. This is indicated by a white dot printed on the board adjacent to the bottom left corner of each switch.




Figure 91: NTBK50 with switch locations

Set the switches on the circuit card according to the requirements of your installation.

Switch SW1 - DCHI configuration (NTAK93 only)

This switch enables and disables the DCHI and sets the operating mode of the DCHI. It is only used if an NTAK93 D-channel handler daughterboard is being used. It has no effect when using the NTBK51 DDCH daughterboard.

For the U.K., use DPNSS1 mode. For all other countries, use Q.931 mode.

Table 149: Switch SW1

| Switch | Down (On) | Up (Off) |
|--------|--------------|----------|
| SW 1-1 | — | — |
| SW 1-2 | DPNSS1/DASS2 | Q.931 |

Switch SW2 - Carrier impedance configuration

This switch sets the carrier impedance to either 120½ or 75½. Twisted pair cable is usually associated with 120½. Coaxial cable is usually associated with the 75½ setting.

Table 150: Switch SW2

| Cable type | SW 2-1 |
|------------|-----------|
| 75% | Down (On) |
| 120% | Up (Off) |

Switch SW4 - Carrier shield grounding

This switch supports the selective grounding of Tx and Rx pairs of carrier cable. Closing the switch (down position) applies Frame Ground (FGND) to the coaxial carrier cable shield, creating a 75½ unbalanced configuration. This applies only to the NTBK05CA cable.

Table 151: Switch SW3

| Switch | Down (On) | Up (Off) |
|--------|-----------|----------|
| SW 4-1 | Rx—FGND | Rx—OPEN |
| SW 4-2 | Tx—FGND | Tx—OPEN |

 **Note:**

The usual method is to ground the outer conductor of the receive coax signal.

Mount the daughterboards on the NTBK50

Use the following procedure to mount and remove the NTAk20 CC and the NTBk51 DDCH or NTAk93 DCHI daughterboards onto the NTBk50 PRI.

Install the NTAk93 or NTBk51 daughterboard before the NTAk20 daughterboard. Work on a flat surface when mounting or removing daughterboards.

1. Visually inspect the connector pins on the underside of the daughterboard. Realign any bent pins prior to mounting.
2. Place the NTBk50 down flat on an antistatic pad.
3. From an overhead view, with the daughterboard parallel above the NTBk50 and the connector pins aligned over the connector sockets, align the mounting holes on the daughterboard with the tops of the standoffs on the NTBk50 (see [Figure 92: Daughterboard installation](#) on page 317).
4. Slowly lower the daughterboard toward the NTBk50, keeping the standoffs in line with all four holes, until the holes rest atop the four standoffs.

If more than slight pressure is required at this point, the connector pins might not be aligned with the connector socket. If so, lift the daughterboard off the NTB50 and return to step 2.

5. Gently apply pressure along the edge of the board where the connector is located until the standoffs at the two corners adjacent to the connector snap into a locked position. Then press down on the two corners on the opposite side until they lock into place.




Figure 92: Daughterboard installation

Remove the daughterboards from the NTB50

Use these guidelines to remove the NTA20 and NTB51 or NTA93 from the NTB50 PRI card. Because of the physical layout of the mother and daughterboards, the NTA20 should be removed before the NTA93 or NTB51.

1. Starting at the two corners opposite the connector, gently lift each corner out of the locking groove of the standoff.
2. At the two corners adjacent to the connector, gently lift the entire side until the mounting holes are clear of the locking groove of the standoff.
3. To remove the connector pins, grasp the edge of the board adjacent to the connector and lift gently.

If more than one NTB50 card is installed, the additional cards may not carry daughterboards, depending on system configuration. At least one NTA20 (per system) is always required.

Insert the NTB50


Slide the circuit card into card slot 1-9 in the Small System main cabinet, or in slots 11-19, 21-29, 31-39, 41-49 of the first, second, third, and fourth IP expansion cabinets, respectively.

Secure the circuit card in the cabinet by locking the lock latch assemblies. The card number associated with a 2.0 Mb PRI card is based on the slot in which the card is installed.

Connect the cables

Follow the instructions below to connect cables to the NTB50 PRI card. Also refer to [Figure 93: NTB50 cabling](#) on page 318.

- In the cabling area, located directly below the card cage, remove the retaining bar that secures the MDF cables. Connect the NTB05DA/CA interface cable to the 50-pin Amphenol connector below the slot in which the NTB50 is installed. reinstall the retaining bar to secure the cable(s) in place.
- Terminate the NTB05DA/CA carrier cable as required.



553-AAA1073

Figure 93: NTB50 cabling

NTBK05DA pinouts

The pinouts for the NTBK05DA cable are as follows:

Table 152: NTBK05DA pinouts

| From: 50-pin MDF connector | To: 9-pin connector | color | Signal |
|----------------------------|---------------------|-------|------------|
| pin 23 | pin 6 | Black | R0 |
| pin 48 | pin 7 | White | T0 |
| pin 50 | pin 9 | Bare | R0/T0 FGND |
| pin 24 | pin 2 | Black | R1 |
| pin 49 | pin 3 | Red | T1 |
| pin 25 | pin 5 | Bare | R1/T1 FGND |

NTBK05CA pinouts

The pinouts for the NTBK05CA cable are as follows:

Table 153: NTBK05CA pinouts

| From: 50-pin MDF connector | To: Transmit coax connector | To: Receive coax connector | To: 50-pin MDF connector |
|----------------------------|-----------------------------|----------------------------|--------------------------|
| pin 23 | Inner conductor | — | — |
| pin 48 | outer conductor | — | — |
| pin 24 | — | Inner conductor | — |
| pin 49 | — | outer conductor | — |
| pin 21 | — | — | pin 49 |
| pin 46 | — | — | pin 48 |

PRI software implementation

The following information describes the process required to program basic 2.0 Mb PRI on the system.

PRI cards must be configured before defining the DCH links or PRI applications.

Prompts which do not show a response are left as default. For more information about any of these prompts, see *Avaya Software Input Output Administration, NN43001-611*.

Task summary

Note:

Before installing PRI cards in IP expansion cabinets or Media Gateway systems, configure them for IP connectivity. Refer to LD 117 in the *Software Input Output Reference — Maintenance* for further information.

The following is a summary of the tasks in this section:

1. [Table 154: LD 17 - Adding a PRI card](#) on page 320
2. [Table 155: LD 17 - Adding a DCHI or DDCH](#) on page 320
3. [Table 156: LD 15 - Defining a PRI customer](#) on page 322
4. [Table 157: LD 16 - Defining a PRI service route](#) on page 323
5. [Table 158: LD 14 - Defining service channels and PRI trunks](#) on page 324
6. [Table 159: LD 73 - Defining system timers and clock controller parameters](#) on page 324
7. [Table 160: LD 73 - Defining PRI parameters and thresholds](#) on page 325
8. [Table 161: LD 73 - Changing trunk pad category values](#) on page 327

Table 154: LD 17 - Adding a PRI card

| Prompt | Response | Description |
|--------|----------|---|
| REQ | CHG | Change data. |
| TYPE | CFN | Configuration data block. |
| CEQU | YES | Changes to common equipment. |
| PRI2 | xx | The PRI2 digital card number, where: xx = 1-9 (Option 11C main cabinet), 11-19 (IP expansion cabinet 1), 21-29 (IP expansion cabinet 2), 31-39 (IP expansion cabinet 3), 41-49 (IP expansion cabinet 4.) xx = 11-14, 21-24, 31-34, 41-44 of the first, second, third and fourth Media Gateway, respectively. |

Table 155: LD 17 - Adding a DCHI or DDCH

| Prompt | Response | Description |
|--------|----------|---------------------------|
| REQ | CHG | Change data. |
| TYPE | CFN | Configuration data block. |

| Prompt | Response | Description |
|--------|--|---|
| ADAN | NEW DCH xx CHG DCH xx OUT DCH xx | Add a primary D-channel (any unused SDI port.) Change a primary D-channel. Out the primary D-channel, where: xx = 1-9 for Option 11C main cabinet, 11-19 for IP expansion cabinet 1, 21-29 for IP expansion cabinet 2, 31-39 for IP expansion cabinet 3, and 41-49 for IP expansion cabinet 4. xx = 11-14, 21-24, 31-34, 41-44 of the first, second, third and fourth Media Gateway, respectively. |
| CTYP | MSDL TMDI | Card type where: MSDL = The NTBK51BA Downloadable D-Channel Daughterboard. TMDI = TMDI (NTRB21) card. |
| CDNO | 1-50 | Card slot number used as the primary DDCH/DCHI. Card slots 10, 20, 30, 40, and 50 are only applicable for D-channel configuration of ISL or VNS. |
| PORT | 1 | PORT set to "1". |
| USR | PRI | D-channel is for ISDN PRI only.  Note: 2.0 Mb only supports PRI or SHA user mode. |
| IFC | xx | Interface type. |
| DCHL | xx | PRI card number carries the D-channel. Must match entry made for the "CDNO" associated with the "DCHI" prompt above. Where: xx = 1-9 for Option 11C main cabinet, 11-19 for IP expansion cabinet 1, 21-29 for IP expansion cabinet 2, 31-39 for IP expansion cabinet 3, and 41-49 for IP expansion cabinet 4. xx = 11-14, 21-24, 31-34, 41-44 of the first, second, third and fourth Media Gateway, respectively. |
| PRI2 | <CR> | Additional PRI Loops controlled by this DCHI. Remember one DCHI can control up to 16 PRI loops going to the same destination. For the system, the maximum limit is eight loops. |
| OTBF | 1-(16)-127 | Number of output request buffers. Note: for a single PRI link, leave this prompt at default (16). Add 5 output request buffers per additional link. |
| SIDE | NET (USR) | Prompted only if IFC is set to SL1. NET = network, the controlling switch USR = slave to the controller |
| RLS | XX | Software release of far-end. This is the current software release of the far-end. If the far-end has an incompatible release of software, it prevents the sending of application messages, for example, 'Network Ring Again. |
| RCAP | MSL | MSDL RCAP capability. |

| Prompt | Response | Description |
|--------|-----------|--|
| OVLR | <CR> | Allow or disallow overlap receiving on a D-channel. Default is NO. |
| LAPD | YES (NO) | Change LAPD parameters. Enter carriage return if timers are left at default. The following timers are prompted only if LAPD is YES. They are all left at default during initial setup. |
| - T23 | 1-(20)-31 | Interface guard timer checks how long the interface takes to respond. In units of 0.5 seconds (default 20 = 10 seconds). |
| T200 | 2-(3)-40 | Retransmission timer in units of 0.5 seconds (default 3 = 1.5 seconds). |
| - N200 | 1-(3)-8 | Maximum number of retransmissions. |
| - N201 | 4(260) | Maximum number of octets in information field. |
| - K | 1-(7)-32 | Maximum number of outstanding unacknowledged frames (NAKS). |

Table 156: LD 15 - Defining a PRI customer

| Prompt | Response | Description |
|--------|----------|---|
| REQ: | NEW CHG | Add new data. Change existing data. |
| TYPE: | NET | Networking data. |
| CUST | 0-99 | Customer number Range for Large System, Call Server 1000E, and Media Gateway 1000E |
| | 0-31 | Range for Small System, Media Gateway 1000B |
| LDN | XXXX | Enter the customer's Listed Directory Number. |
| AC2 | | Access Code 2. Enter call types (type of number) that use access code 2. Multiple responses are permitted. This prompt only appears on NARS equipped systems. If a call type is not entered here, it automatically defaults to access code 1. |
| | NPA | E.164 National. |
| | NXX | E.164 Subscriber. |
| | INTL | International. |
| | SPN | Special Number. |
| | LOC | Location Code. |
| ISDN | YES | Customer is equipped with ISDN. |
| PNI | 1-32700 | Customer private network identifier. This number is unique to this customer in the private network. For example, it is |

| Prompt | Response | Description |
|--------|----------|---|
| HNPA | NPA | used as part of the setup message for feature operation such as Network Ring Again and Network ACD. Note that if PNI is set to zero (0), NRAG and NACD does not work. Telephone area code for this system. Sent in the setup message as calling line identification. |
| HNXX | NXX | Telephone local exchange code for this system. Sent in the setup message as calling line identification. |
| HLOC | XXX | Home location code (NARS) |
| LSC | 1-9999 | One to four digit Local Steering Code established in the Coordinated Dialing Plan (CDP). The LSC prompt is required for Calling Line ID and Network ACD. |

Table 157: LD 16 - Defining a PRI service route

| Prompt | Response | Description |
|--------|----------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | RDB | Route data block. |
| TKTP | xxx | Trunk type. |
| DTRK | YES | Digital trunk route. |
| DGPT | PRI2 | 2.0 Mb PRI. Prompted only if PRA = YES in LD15. |
| ISDN | YES | ISDN option. |
| MODE | PRI | Route used for PRI only. |
| PNI | 1-32700 | Customer private network identifier. Is the same as the CDB PNI at far-end. |
| IFC | xx | Interface type. |
| CHTY | BCH | Signaling type. Prompted if DTRK is YES. D-channel signaling for B-channels. |
| CTYP | aaa <CR> | Call Type. Enter the call type to associate with the outgoing route for direct dialing using the trunk access code (instead of NARS access code). |
| INAC | YES | Insert Access Code. Permits the NARSAC1 or AC2 access code to be reinserted automatically on an incoming ESN call. This prompt only appears on a TIE route and is "YES" for features such as Network ACD to function. On an existing ESN network, setting this prompt to "YES" may also require modifying the Digit Manipulation Index (DMI) associated with this route at the far-end (so the Access Code is not reinserted twice). The INSERT prompt (INST) is bypassed if INAC = YES. |

| Prompt | Response | Description |
|--------|--------------|---|
| PII | YES | Enable the Privacy Indicator Ignore (PII) feature. |
| | NO (default) | Disable the PII feature. |
| | [CR] | Leave the feature setting as it is. |
| AUXP | YES | Enable the Auxiliary processor application (AUXP) feature. |
| | NO (default) | Disable the AUXP feature. |
| | [CR] | Leave the feature setting as it is. |
| | |  Note: The AUXP prompt is automatically YES when the PII prompt is YES, and can be modified only when PII is NO. |

Table 158: LD 14 - Defining service channels and PRI trunks

| Prompt | Response | Description |
|--------|--------------|--|
| REQ | NEW CHG | Add new data. Change existing data. |
| | |  Note: When assigning several members at once use the multiple create command NEW XX. |
| TYPE | TIE | TIE trunk only, allowed between MSL-1. |
| TN | l ch | Loop and channel for digital trunks |
| RTMB | 0-511 1-4000 | Route number and Member number Range for Large System and CS 1000E system. |
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B, |
| ... | | |

Table 159: LD 73 - Defining system timers and clock controller parameters

| Prompt | Response | Description |
|----------|----------|---|
| REQ | CHG | Change data. |
| TYPE | PRI2 | 2.0 Mb PRI. |
| FEAT | SYTI | System timers. |
| CCO | xx | Card slot number for Clock Controller 0. |
| PREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |

| Prompt | Response | Description |
|----------|----------|---|
| SREF CCO | xx | Card number of PRI/DTI/SILC containing the primary clock reference for the main cabinet |
| CC1 | xx | Card number for Clock Controller 1. |
| PREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| SREF CC1 | xx | Primary Reference DTI/PRI loop for Clock controller one. |
| CC2 | xx | Card number for Clock Controller 2. |
| PREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC2 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC3 | xx | Card number for Clock Controller 3. |
| PREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC3 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CC4 | xx | Card number for Clock Controller 4. |
| PREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| SREF CC4 | xx | Card number of PRI/DTI/SILC or DTI2/PRI2/SILC containing the primary clock reference. |
| CCAR | 0-(15) | Clock Controller Audit Rate. Enter the time (in minutes) between normal CC audits. |

Table 160: LD 73 - Defining PRI parameters and thresholds

| Prompt | Response | Description |
|--------|-------------|--|
| REQ | CHG | Change data. |
| TYPE | PRI2 | 2.0 Mb PRI. |
| FEAT | LPTI | Loop timers. |
| LOOP | X | X is the slot number of the 2.0 Mb PRI card. |
| MFF | AFF (CRC) | Alternate mode or CRC multiframe mode. |
| ALRM | (REG) ALT | Default or alternate alarms selected. |
| G10S | | |
| SLP | mc mt oc ot | Slip error count. <ul style="list-style-type: none"> • mc = Maintenance threshold slip count, 1- (5)-255. • mt = Maintenance threshold time, default 24 hours. |

| Prompt | Response | Description |
|--------|----------------|--|
| BPV | n1 n2 | <ul style="list-style-type: none"> • oc = Out-of-service threshold slip count, 1-(30)-255. • ot = Out-of-service threshold time, default 1 hour. <p>Bipolar violation error count. Range is 1-(128)-255 for n1, 1-(122)-255 for n2.</p> <ul style="list-style-type: none"> • n1 is multiplied by 16 to obtain the actual count, giving an actual count range of 16-4080. |
| CRC | n1 n2 | <p>Cyclic redundancy check error count. Range is 1-(201)-255 for n1, 1-(97)-255 for n2.</p> <ul style="list-style-type: none"> • n1 is multiplied by 4 to obtain the actual count, giving an actual count range of 4-1020. |
| FAP | n1 n2 | <p>Frame alignment problem error count. Range is 1-(28)-255 for n1, (1)-255 for n2.</p> |
| RATS | 1-(10)-15 | <p>Number of seconds firmware has to check BPV/CRC/FAP for excessive error rate.</p> |
| GP2 | T2 mt dt ct ot | <p>Group 2 error thresholds. This is the maximum amount of time that can elapse before software checks the associated thresholds of 120 to 32,640 msec and rounds it to the closest multiple of 128 msec.</p> <ul style="list-style-type: none"> • T2 = Error count values are in the range 1-(20)-255. • mt = Maintenance threshold time (MNT)(default =100S). • dt = No new data calls threshold time (NNDC)(default =12S). • ct = No new calls threshold time (NNC)(default =12S). • ot = Out of service threshold time (OOS)(default =4S). <p> Note: The following requirements must be met for input mt = >dt = >ct = >ot.</p> <p> Note: Threshold times are one of the following: nnnnT, nnnS, nnnM, or nnH, where nnnn is an integer and T,S,M, or H show the increments of use. The values are as follows: -nnnnT is the time in 20 millisecond increments (nnnn = 20-5000) - nnnS is the time in 1 second increments (nnn= 1-240) - nnnM is the time in 1 minute increments (nnn= 1-240) -nnH is the time in 1 hour increments (nn= 1-24)</p> |
| MNG1 | nnnM | Maintenance Guard time Group 1, default = 15M. |
| NCG1 | nnnM | No New Calls Guard time Group 1, default = 15M. |

| Prompt | Response | Description |
|--------|----------|--|
| OSG1 | nnnM | Out Of Service Guard time Group 1, default = 15M. |
| MNG2 | nnnS | Maintenance Guard time Group 2, default = 15S. |
| NCG2 | nnnS | No New Calls Guard time Group 2, default = 15S. |
| OSG2 | nnnS | Out Of Service Guard time Group 2, default = 15S. |
| PERS | ttt | Persistence Timer for Group II problems. Enter 0-256 msec in increments of 2 msec. Default is 50 (=100ms). |
| CLRS | ttt | Clearance Timer for Group II problems. Enter 0 - 256 msec in increments of 2 msec. Default is 50 (=100ms). |
| OOSC | nnn | Out-of-Service Counter. Range for nnn of 0-255 with a default of 5. |

Table 161: LD 73 - Changing trunk pad category values

| Prompt | Response | Description |
|--|----------|--|
| REQ | CHG | Change data. |
| TYPE | PRI2 | 2.0 Mb PRI. |
| FEAT | PADS | |
| PDCA | # | PAD table-0 is default and is hard coded. |
| <p>The following prompts define the pad levels. The receiving pad code is r and the transmission pad code is t. These entries have the range 0-15. The pad values (in decibels) relating to these codes are shown after this table.</p> | | |
| ONP | r t | On-premises extension. |
| DSET | r t | Meridian Digital set. Prompted only if the 2.0 Mb Gateway feature is equipped. |
| OPX | r t | Off-premises extension. |
| DTT | r t | Digital TIE trunks. |
| SDTT | r t | Digital Satellite TIE trunks. |
| NTC | r t | Nontransmission compensated. |
| TRC | r t | Transmission compensated. |
| DCO | r t | Digital COT, FEX, WAT, and DID trunks. |
| VNL | r t | Via Net Loss. |
| DTO | r t | 2.0 Mb PRI2 digital TOLL office trunks. |
| ACO | r t | Analog CO or WATS trunks. |
| AFX | r t | Analog FEX trunks. |
| ADD | r t | Analog DID trunks. |

| Prompt | Response | Description |
|--------|----------|--|
| SATT | r t | Analog satellite TIE trunks. |
| ATO | r t | Analog TOLL office trunks. |
| PRI2 | r t | 2.0 Mb PRI trunk. Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=2.0 Mb PRI. |
| XUT | r t | Analog CO trunk. Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=PRI2. |
| XEM | r t | Analog TIE trunk. Prompted only if the 1.5/2.0 Mb Gateway feature is equipped and TYPE=PRI2. |

[Table 162: Pad values](#) on page 328 shows the pads available to 2.0 Mb PRI. Positive dB represents loss and negative dB represents gain.

Table 162: Pad values

| | | | | | | | | |
|------------|------|------|-------|-------|-------|-------|-------|------|
| code | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| value (dB) | 0.0 | +1.0 | +2.0 | +3.0 | +4.0 | +5.0 | +6.0 | +7.0 |
| code | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| value (dB) | +8.0 | +9.0 | +10.0 | +11.0 | +12.0 | +13.0 | +14.0 | -1 |
| code | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 |
| value (dB) | -2 | -3 | -4 | -5 | -6 | -7 | -8 | -9 |
| code | 24 | 25 | 26 | | | | | |
| value (dB) | -10 | idle | +0.6 | | | | | |

Configure DPNSS1 with IP expansion cabinets/Media Gateway systems

For Small Systems, when configuring a PRI2 card slot number for DPNSS1, the response to the DDCS prompt in LD 17 is: 1-9 (Option 11C Cabinet), 11-19 (IP expansion cabinet 1), 21-29 (IP expansion cabinet 2), 31-39 (IP expansion cabinet 3), 41-49 (IP expansion cabinet 4).

Configure ISDN BRI trunking with IP expansion cabinets/Media Gateway systems

For Small Systems, when configuring the MISP card slot number for ISDN BRI trunking in LD 27, the response to the LOOP prompt is: 1-9 (Option 11C Cabinet), 11-19 (IP expansion cabinet

1), 21-29 (IP expansion cabinet 2), 31-39 (IP expansion cabinet 3), 41-49 (IP expansion cabinet 4).

For Small Systems, when configuring the DSL for ISDN BRI trunking in LD 27, the response to the MISIP prompt is: 1-9 (Option 11C Cabinet), 11-19 (IP expansion cabinet 1), 21-29 (IP expansion cabinet 2), 31-39 (IP expansion cabinet 3), 41-49 (IP expansion cabinet 4).

Chapter 22: 2.0 Mb ISL implementation

Contents

This section contains information on the following topics for Avaya Communication Server 1000 (Avaya CS 1000):

[Overview](#) on page 331

[ISL hardware requirements](#) on page 331

[ISL hardware installation](#) on page 334

[ISL software implementation](#) on page 336

Overview

This chapter provides the information required to implement ISL on the system including:

- hardware and software installation
- implementation of components needed to provide basic call service

ISDN features are treated separately in the chapter devoted to ISDN feature implementation.

This chapter assumes that ESN implementation is already in place. It also assumes that the reader has a basic understanding of NARS and CDP.

Two modes of ISL are available: shared and dedicated. This chapter covers ISL installation in dedicated mode using dedicated and leased lines. Shared mode installations are done according to the instructions supplied for PRI, with the noted exceptions.

ISL hardware requirements

ISL, regardless of the operation mode, uses analog or digital TIE lines as B-channels.

ISL in shared mode

In shared mode, PRI hardware is required in addition to the existing TIE lines interface cards.

- NT8D15 Analog trunk card(s)
- NTAK02 SDI/DCH, NTAK10 2.0 Mb DTI, NTAK79 2.0 Mb PRI, or NTBK50 2.0 Mb PRI card(s)





Figure 94: ISL in shared mode

ISL in dedicated mode using leased line

The following hardware is required:

- NTAK02 SDI/DCH D-channel handler interface
- A modem capable of the following: (such as Ventel 2400-33 or 2400 Plus II)
 - minimum of 2400 baud
 - synchronous operation
 - must support leased line (also known as private line or point-to-point) operation



553-AAA1075

Figure 95: ISL in dedicated mode using leased line

ISL in dedicated mode using dialup modem

The requirements are as follows:

- NTAK02 SDI/DCH D-channel handler interface.
- Modems such as the Ventel 2400, Hayes 2400 (the Hayes Smartmodem 2400 cannot be used on leased lines) or Gandalf 2400 that can support 2 or 4-wire leased line operation. 4-wire operation must be specified when ordering. Otherwise, modems are factory shipped for 2-wire operation. Modems capable of the following:
 - autodial capability
 - minimum of 2400 baud
 - synchronous operation
 - programmable so that one modem originates the call while the other auto-answers
- NT8D09 500 set line card.




Figure 96: ISL in dedicated mode using dialup modem

ISL hardware installation

Shared mode

The hardware installation is identical to the PRI installation, with the addition of analogue or digital TIE trunks (or both).

Dedicated mode

The NTAk02 connects to the modem through the NTAk19BA 4-port cable. Only ports 1 and 3 are available for use as DCHIs.

Installing the NTAk02

1. Set option switches/jumpers on the DCHI card, as shown in [Table 163: NTAk02 switch settings](#) on page 335 and [Table 164: NTAk02 jumper settings](#) on page 335, for mode of operation that is, RS232 or RS422 and DTE or DCE.
2. Install the NTAk02 in any spare slot 1-9 of the Main Cabinet or slots 11-14 of the Media Gateway.
3. Install the NTAk19BA four port cable on the 50-pin Amphenol connector associated with the slot holding the NTAk02.

Table 163: NTA02 switch settings

| Port 0 | Port 1 | SW1-1 | SW1-2 |
|--------|--------|-------|-------|
| SDI | DCH | OFF | OFF |
| SDI | DPNSS1 | OFF | ON |
| — | ESDI | ON | ON |

| Port 2 | Port 3 | SW1-3 | SW1-4 |
|--------|--------|-------|-------|
| SDI | DCH | OFF | OFF |
| SDI | DPNSS1 | OFF | ON |
| — | ESDI | ON | ON |

Table 164: NTA02 jumper settings

| Unit | Jumper location | Strap for DTE | Strap for DCE | Jumper location | RS422 | RS232 |
|--------|-----------------|---------------|---------------|-----------------|-------------|-------------|
| Unit 0 | J10 | C - B | B - A | | | |
| Unit 1 | J7 J6 | C - B C - B | B - A B - A | J9 J8 | C - B C - B | B - A B - A |
| Unit 2 | J5 | C - B | B - A | | | |
| Unit 3 | J4 J3 | C - B C - B | B - A B - A | J2 J1 | C - B C - B | B - A B - A |

Setting up the D-channel

1. If this is a dedicated mode installation using leased line modems, the D-channel connects the DCHI with the far-end modem over a dedicated leased line. Synchronous modems with a minimum 2400 baud data rate must be configured. Modems must support leased line capability and synchronous mode. The Hayes Smartmodem 2400 cannot be used on leased lines.

If this a dedicated mode using dialup modems, modems such as Hayes 2400, Ventel 2400 or Gandalf 2400 can be used. In this configuration, the DCHI connects to a modem which is connected to a 500 set line card. The call connects to the far-end through the 500 set-to-TIE trunk path.

Program the modem at one end in the autodial mode, so it automatically initiates a call to the other end at power up. The autodial number must be coordinated with the far-end switch. The originating modem has this autodial number stored internally as part of the modem configuration routine.

The far-end modem need only be setup for auto-answer.

ISL software implementation

There are two modes of ISDN Signaling Link (ISL) operation, shared mode and dedicated mode.

Shared mode

The NTA79 onboard DCHI supports ISDN PRI signaling and ISL trunks. The configuration is basically the same as the PRI D-channel, with the D-channel also supporting ISL trunks.

The DTI/PRI software implementation sequence can be used (refer to the appropriate chapters for more information) with the following exceptions.

Table 165: LD 17 - Shared mode

| Prompt | Response | Description |
|--------|----------|--|
| USR | SHA | D-channel for ISL in "shared" mode, used for both ISDN PRI and ISL. |
| ISLM | 1-240 | Number of ISL B-channel (trunks) controlled by the D-channel (no default value). |

Table 166: LD 16 - Interface type

| Prompt | Response | Description |
|--------|----------|---|
| IFC | SL1 | Interface type must be SL1 (this is the only type supported for ISL). |
| MODE | ISLD | TIE route used for ISL members. |

Table 167: LD 14 - Channel identifier

| Prompt | Response | Description |
|--------|----------|--|
| CHID | 1-240 | Channel identifier for ISL channels. Must be coordinated with the far-end. |

Dedicated mode

The DCHI uses the NTA02 circuit card and does not support ISDN PRI signaling. The DCHI is reserved for ISL use only. The D-channel can communicate with the far-end by means of a dedicated leased line modem or dialup modem.

Note that the following implementation relates to analogue TIE trunks being used as B-channels. In the case where DTI/PRI trunks are also used, then LD 17 digital loop (2.0 Mb PRI) and LD73 (2.0 Mb PRI/SYTI) must also be configured with the appropriate clocking and threshold settings.

For ISL dedicated mode using a dialup modem, a 500 set, TIE trunk route and member must be programmed (used for D-channel). [Table 168: Configuring basic ISL capability](#) on page 337 summarizes the required steps.

Table 168: Configuring basic ISL capability

| Step | LD | Action |
|------|----|--|
| 1 | 17 | Configure the D-channel for ISL use. |
| 2 | 15 | Enable ISDN option. |
| 3 | 16 | Enable the ISL option on a per route basis, assign a D-channel for each route. |
| 4 | 14 | Assign a channel identification to each trunk with the ISL option. |

Table 169: LD 17 - Configure the D-channel for ISL

| Prompt | Response | Description |
|--------|---|--|
| REQ | CHG | Change existing data |
| TYPE | CFN | Configuration data block. |
| ADAN | NEW DCH 0-79 | Add primary D-channel. |
| CTYP | DCHI | D-channel card type. |
| CDNO | 0-15 1-9 11-19 21-29, 31-39 41-49 1-50 | Serial Data Interface (SDI) Card number. Number the SDI cards logically with the system. MSDL application small system Card number DCHI small system Card number |
| PORT | 1 | Must be set to 1. |
| USR | PRI | D-channel for ISDN PRI only. |
| IFC | SL1 | Interface type. |

| Prompt | Response | Description |
|--------|-----------|--|
| DCHL | 1-9 | PRI2 card number. (Must match entry for CDNO). |
| SIDE | NET (USR) | Net: network, the controlling switch. User: slave to controller. |
| RLS | XX | Software release of far-end. This is the current software release of the far-end. If the far-end has an incompatible release of software, it prevents the sending of application messages. For example, for Network Ring Again. |
| CLOK | | D-channel clock type for signaling. |
| | EXT | Source of D-channel clock is external to DCHI card (in this case the DTI/PRI circuit card). Normally, EXT is used for PRI/ISL.  Note: Do not confuse this clock with the E1 span Clock Controller found on the NTAK10/79. This clock is in reference to the DCHI synchronous mode of operation.  Note: If directly connecting two DCHI ports with out the use of modems, set "CLOK" to "EXT" on one side and "INT" on the other. |
| LAPD | YES,(NO) | Change LAPD parameters. Simply carriage return if timers are to be left at default value. The following timers are prompted only if LAPD is YES. The following can all be left at default during initial setup. |
| T23 | 1-(20)-31 | Interface guard timer checks how long the interface takes to respond. In units of 0.5 seconds (default 20 = 10 seconds). |
| T200 | 2-(3)-40 | Retransmission timer in units of 0.5 seconds (default 3 = 1.5 seconds). |
| N200 | 1-(3)-8 | Maximum number of retransmissions. |
| N201 | 4(260) | Maximum number of octets in information field. |
| K | 1-(7)-32 | Maximum number of outstanding unacknowledged frames (NAKS). |

Table 170: LD 15 - Enable the ISDN option

| Prompt | Response | Description |
|--------|----------|---|
| REQ: | NEW CHG | Add new data. Change existing data. |
| TYPE: | NET | Networking data. |
| CUST | 0-99 | Customer number Range for Large System, Call Server 1000E, and Media Gateway 1000E |
| | 0-31 | Range for Small System, Media Gateway 1000B, |
| ISDN | YES | Customer is equipped with ISDN. |
| PNI | 1-32700 | Customer private network identifier. MUST be unique to this customer in the private network. Used as part of the setup message for feature operation such as Network Ring Again and Network ACD. |
| HNPA | NPA | Telephone area code for this system. Sent as part of setup message as CLID. |
| HNXX | NXX | Telephone local exchange code for this system. Sent as part of setup message for calling line identification. |
| HLOC | XXX | Home location code (NARS). |
| LSC | 1-9999 | One to four digit Local Steering Code established in the Coordinated Dialing Plan (CDP). The LSC prompt is required for Calling Line ID and Network ACD. |
| AC2 | | Access Code 2. Enter call types (type of number) that use access code 2. Multiple responses are permitted. This prompt only appears on NARS equipped systems. If a call type is not entered here, it is automatically defaulted to access code 1. |
| | NPA | E.164 National. |
| | NXX | E.164 Subscriber. |
| | INTL | International. |
| | SPN | Special Number. |
| | LOC | Location Code. |

Table 171: LD 16 - Enable the ISL option

| Prompt | Response | Description |
|--------|----------|--------------------------------------|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | RDB | Route data block. |
| CUST | xx | Customer number, as defined in LD 15 |

| Prompt | Response | Description |
|--------|----------------|---|
| ROUT | 0-511 0-127 | Route number Range for Large System and CS 1000E system. Range for Meridian 1 Small System, Media Gateway 1000B. |
| TKTP | TIE | TIE trunk route. |
| DTRK | YES NO | Enter YES if this is a Digital Trunk Interface (DTI or PRI). |
| ISDN | YES | ISDN option. |
| MODE | ISLD | Route for ISL application. |
| DCHI | XX | DCHI port number in CFN to carry the D-channel for this TIE trunk route. |
| PNI | 1-32700 | Customer private network identifier. Must be the same as the CDB PNI at the fa- end. |
| IFC | | Interface type. |
| | SLI | System to system. |
| CTYP | aaa <CR> | Call Type. Enter the call type to be associated with the outgoing route for direct dialing using the trunk access code (instead of NARS access code). |
| INAC | YES | Insert Access Code. Permits the NARS AC1 or AC2 access code to be reinserted automatically on an incoming ESN call. |

Table 172: LD 14 - Assign a channel identifier

| Prompt | Response | Description |
|--------|--------------|---|
| REQ | NEW CHG | Add new data. Change existing data. |
| TYPE | TIE | TIE trunk type. |
| TN | l s c u | Terminal Number Format for Large System and CS 1000E system, where l = loop, s = shelf, c = card, u = unit. |
| | c u | Format for Meridian 1 Small System, Media Gateway 1000B where c = card and u = unit. |
| RTMB | 0-511 1-4000 | Route number and Member number Range for Large System and CS 1000E system. |
| | 0-127 1-4000 | Range for Meridian 1 Small System, Media Gateway 1000B. |
| CHID | 1-240 | Channel identifier for ISL channels (remove with Xnn). Must be coordinated with far-end (no default value). |

Chapter 23: Nonstandard cables

Contents

The section contains information about the following topics:

[Introduction](#) on page 342

[NT5K40AA, NT5K41AA, NT5K86AA](#) on page 342

[NT8D7206, NT8D7207](#) on page 343

[QCAD128](#) on page 343

[QCAD129](#) on page 344

[QCAD133](#) on page 345

[NT8D7205](#) on page 346

[QCAD328](#) on page 346

[NT8D74 Clock Controller to InterGroup cable](#) on page 347

[NT8D75 Clock Controller to Clock Controller cable](#) on page 347

[NT8D79 PRI/DTI to Clock Controller cable](#) on page 348

[NT8D83 PRI/DTI to I/O cable](#) on page 348

[NT8D85 Network to IPE cable](#) on page 348

[NT8D86 Network to I/O cable](#) on page 349

[NT8D97AX PRI/DTI I/O to MDF cable](#) on page 349

[NT9J93AD PRI/DTI Echo Canceller to I/O cable](#) on page 350

[NTND26 PRI to MSDL cables](#) on page 350

[NTND27 MSDL to I/O panel cables](#) on page 350

[NTND98 PRI to I/O panel cables](#) on page 350

Introduction

This section provides information required to build systems cables of nonstandard lengths for ISDN PRI applications.

NT5K40AA, NT5K41AA, NT5K86AA

These cables are used to transport the 2Mb digital signal from the faceplate connector on the PRI card to the Line Terminating Equipment interface.

- Standard lengths:
 - NT5K40AA - 4 m (13 ft.)
 - NT5K41AA - 8 m (26 ft.)
 - NT5K86AA - 12m (39 ft.)
- Construction - 75 ohm dual co-axial type with solid inner conductor and braided shield.
- J1 Connector - 15-pin, male, subminiature D with jackscrews
- J2 Connector - 75 ohm BNC crimp plug
- J3 Connector - 75 ohm BNC crimp plug

Table 173: NT5K40AA, NT5K41AA, NT5K86AA wire list

| From (pack end) | To (I/O end) | Signal |
|-----------------|--------------------|------------------|
| J1-1 | J2 Inner Conductor | XTIP (transmit) |
| J1-9 | J2 Shield | XRING (transmit) |
| J1-3 | J3 Inner Conductor | RTIP (receive) |
| J1-11 | J3 Shield | RRING (receive) |
| J1-9 | J3 Shield | FRAME GROUND |

NT8D7206, NT8D7207

This cable is used to transport the 2Mb/s digital signal from the PRI pack to the I/O assembly located at the cabinet bulkhead.

- Standard length - 3.05 m (10 ft.) for Half Group systems and Single group systems
- Construction - 24 AWG, stranded foil-shielded twisted pairs
- P1 Connector (Pack end) - 9-pin, male, subminiature D, with jackscrews
- P2 Connector (I/O Panel end) - 9-pin, male, subminiature D, with jackscrews

Table 174: NT8D7206, NT8D7207 wire list

| Color | From (pack end) | To (I/O end) | Signal |
|--------------|-----------------|--------------|------------------|
| White | P1-1 | P2-6 | XTIP (transmit) |
| Black | P1-9 | P2-7 | XRING (transmit) |
| Green Shield | nc | P2-CASE P2-9 | GROUND |
| Red | P1-3 | P2-2 | RTIP (receive) |
| Black | P1-11 | P2-3 | RRING (receive) |
| Red Shield | nc | P2-CASE P2-5 | GROUND |

QCAD128

This cable transports the T1 signal from the PRI pack to the I/O panel.

- Standard length - 10 ft. (3.05 m)
- Construction - 15-conductor ribbon, 28 AWG (0.321 mm), stranded
- P1 Connector - 15-pin, male, subminiature D, with jackscrews
- P2 Connector - 15-pin, male, subminiature D, with jackscrews

See Table [Table 175: QCAD128 wire list](#) on page 343.

Table 175: QCAD128 wire list

| From | To | Signal |
|------|------|--|
| P1-1 | P2-1 | XTIP (transmit tip) to telephone company |

| From | To | Signal |
|-------|-------|---|
| P1-2 | P2-2 | GND (ground) |
| P1-3 | P2-3 | RTIP (receive tip) from telephone company |
| P1-4 | P2-4 | GND (ground) |
| P1-5 | P2-5 | |
| P1-6 | P2-6 | |
| P1-7 | P2-7 | |
| P1-8 | P2-8 | |
| P1-9 | P2-9 | XRING (transmit ring) to telephone company |
| P1-10 | P2-10 | |
| P1-11 | P2-11 | RRING (receive ring) from telephone company |
| P1-12 | P2-12 | |
| P1-13 | P2-13 | |
| P1-14 | P2-14 | |
| P1-15 | P2-15 | |

QCAD129

This cable is used to connect the RS-232-C interface between an echo canceller and the PRI pack.

- Standard length - 2.1 m (7 ft.)
- Construction - 22 AWG (0.644 mm), stranded
- P1 Connector - 15-pin, male, subminiature D, with jackscrews
- P2 connector - 25-pin, male, subminiature D, with jackscrews

Table 176: QCAD129 wire list

| PRI Signal | From | To | Echo Canceller Signal |
|------------|------|-------|-----------------------|
| DCD | P1-1 | P2-20 | DTR |
| RXD | P1-2 | P2-2 | TXD |
| DTR | P1-4 | P2-8 | DCD |
| TXD | P1-5 | P2-3 | RXD |

| PRI Signal | From | To | Echo Canceller Signal |
|------------------------------|-------|------|-----------------------|
| GND | P1-10 | P2-7 | GND |
| RTS | P1-12 | P2-4 | |
| CTS | P1-9 | P2-5 | |
| TPENB (Test Port Enable Bar) | P1-15 | nc | |

QCAD133

For cabinets with an I/O filter assembly, this cable transports the T1 signal from the I/O filter to the Network Channel Terminating Equipment (NCTE) telephone company interface. See [Table 177: QCAD133 wire list](#) on page 345.

For cabinets without an I/O filter assembly, this cable transports the T1 signal from the QPC720 PRI pack to the NCTE telephone company interface.

- Standard length - 50 ft (15.3 m)
- Construction - Individually foil-shielded, twisted pairs, 24 AWG (0.511 mm), stranded
- P1 Connector - 15-pin, female, subminiature D with jackscrews
- P2 Connector - 15-pin, male, subminiature D, with slide-latch (optional spring-latch loose-packed with cable assembly)

Table 177: QCAD133 wire list

| Color | From | To | PRI signal |
|----------|-------|-------|---|
| WHITE | P1-1 | P2-1 | XTIP (transmit tip) to telephone company |
| BLACK | P1-9 | P2-9 | XRING (transmit ring) to telephone company |
| GRN SHLD | P1-2 | nc | GND (ground) |
| RED | P1-3 | P2-3 | RTIP (receive tip) from telephone company |
| BLACK | P1-11 | P2-11 | RRING (receive ring) from telephone company |
| RED SHLD | P1-4 | nc | GND (ground) |

NT8D7205

This cable is used to transport the 2Mb digital signal from the I/O panel at the cabinet bulkhead to the Network Channel Terminating Equipment (NCTE) telephone company interface.

- Standard length - 15.3 m (50 ft.)
- Construction - Individually foil-shielded, twisted pairs, 24 AWG (0.511 mm), stranded
- P1 Connector - 9-pin, female, subminiature D with jackscrews
- P2 Connector - 9-pin, male, subminiature D, with jack screws

Table 178: NT8D7205 wire list

| Color | From (pack end) | To (I/O end) | Signal |
|--------------|-----------------|--------------|------------------|
| White | P1-6 | P2-6 | XTIP (transmit) |
| Black | P1-7 | P2-7 | XRING (transmit) |
| Green Shield | P1-9 | nc | GROUND |
| Red | P1-2 | P2-2 | RTIP (receive) |
| Black | P1-3 | P2-3 | RRING (receive) |
| Red Shield | P1-5 | nc | GROUND |

QCAD328

This cable is used to connect the PRI pack to the D-channel interface card, either the QPC757 or NT6D11AB DCHI. There are two types of QCAD328 cables: QCAD328A and QCAD328B.

- QCAD328A - 1.8 m (6 ft)
- QCAD328B - 5.5 m (18 ft)
- QCAD328C - 10.67 m (35 ft)
- QCAD328D - 15.24 m (50 ft)
- Construction - 24 AWG (0.511 mm), stranded
- P1 Connector - 25-pin male, subminiature D
- P2 Connector - 15-pin male, subminiature D

Table 179: QCAD328 wire list

| From | To | Signal |
|-------|-------|--------|
| P1-2 | P2-2 | SDA+ |
| P1-13 | P2-10 | SDB- |
| P1-20 | P2-15 | TR |
| P1-15 | P2-9 | STA+ |
| P1-14 | P2-11 | STB- |
| P1-3 | P2-4 | RDA+ |
| P1-16 | P2-12 | RDB- |
| P1-17 | P2-5 | RTA+ |
| P1-12 | P2-13 | RTB- |
| P1-8 | P2-8 | RR |
| P1-5 | P1-8 | CS |
| P1-7 | P1-1 | SG |
| P1-1 | P2-1 | GND |

NT8D74 Clock Controller to InterGroup cable

This cable connects the QPC471 Clock Controller card to the NT8D36 InterGroup Module.

This cable is available in the following lengths:

- NT8D74AC 1.2 m (4 ft)
- NT8D74AD 1.8 m (6 ft)
- NT8D74AE 2.4 m (8 ft)
- NT8D74AF (QCAD110B) 3 m (10 ft)
- NT8D74AJ 4.8 m (16 ft)

NT8D75 Clock Controller to Clock Controller cable

This cable interconnects QPC471 Clock Controller cards.

This cable is available in the following lengths:

- NT8D75AC 1.2 m (4 ft)
- NT8D75AD 1.8 m (6 ft)
- QCAD125 3 m (10 ft)

NT8D79 PRI/DTI to Clock Controller cable

This cable connects the PRI/DTI card to the QPC471 Clock Controller card.

This cable is available in the following lengths:

- NT8D79AB 0.6 m (2 ft)
- NT8D79AC 1.2 m (4 ft)
- NT8D79AD 1.8 m (6 ft)
- NT8D79AE 2.4 m (8 ft)
- NT8D79AF (QCAD130) 3 m (10 ft)

NT8D83 PRI/DTI to I/O cable

This cable connects the PRI/DTI card (T1 port) to the I/O connector panel.

This cable is available in the following lengths:

- NT8D83AC 1.2 m (4 ft)
- NT8D83AD 1.8 m (6 ft)

NT8D85 Network to IPE cable

This cable connects the following:

- QPC581 CMA card to QPC581 CMA card in dual CPU configuration
- QPC414 Network card to PRI/DTI card

- QPC414 Network card to QPC659 Dual Loop Peripheral Buffer card (for internal cabling only)
- QPC659 Dual Loop Peripheral Buffer card to QPC659 Dual Loop Peripheral Buffer card when connecting two NT8D13 IPE Modules together

This cable is available in the following lengths:

- NT8D85AB 0.6 m (2 ft)
- NT8D85AC 1.2 m (4 ft)
- NT8D85AZ 1.5 m (5 ft)
- NT8D85AD 1.8 m (6 ft)
- NT8D85AE 2.4 m (8 ft)
- NT8D85AF 3 m (10 ft)
- NT8D85AJ 4.8 m (16 ft)
- NT8D85AL 6 m (20 ft)
- NT8D85AP 7.6 m (25 ft)
- NT8D85AV 13.7 m (45 ft)

NT8D86 Network to I/O cable

This cable connects the following to the I/O connector panel:

- QPC414 Network card
- PRI/DTI card
- QPC659 Dual Loop Peripheral Buffer card

This cable is available in the following lengths:

- NT8D86AC 1.5 m (5 ft)
- NT8D86AD 1.8 m (6 ft)

NT8D97AX PRI/DTI I/O to MDF cable

This cable connects the PRI/DTI card to the MDF through the I/O connector panel. It is 15.2 m (50 ft) long.

NT9J93AD PRI/DTI Echo Cancellor to I/O cable

This cable connects the PRI/DTI Echo Cancellor port to the I/O connector panel. It is 1.8 m (6 ft) long.

NTND26 PRI to MSDL cables

These cables connect the MSDL card to the PRI cards.

- NTND26AA 6 feet
- NTND26AB 18 feet
- NTND26AC 35 feet
- NTND26AD 50 feet

NTND27 MSDL to I/O panel cables

These cables connect the MSDL card to the I/O panel.

- NTND27 6 ft

NTND98 PRI to I/O panel cables

These cables connect the PRI card to the I/O panel.

- NTND98 6 ft

Index

Numerics

| | |
|------------------------------------|---|
| 0-127 1-510 | 290 , 320 |
| 0-31 | 320 , 337 |
| 64 T-link version 2 protocol | 38 |
| 64K Clear Data feature | 37 , 38 |

A

| | |
|--|--------------------|
| AMI (Alternate Mark Inversion) line coding | 37 |
|--|--------------------|

C

| | |
|-----------------------------------|---|
| cable requirements | 38 |
| cables | 347 , 348 |
| NT8D74 | 347 |
| NT8D75 | 347 |
| NT8D79 | 348 |
| NT8D83 | 348 |
| NT8D85 | 348 |
| Clock Controllers | 183 , 347 , 348 |
| cable for | 347 , 348 |
| CSU (Channel Service Units) | 37 |
| Customer number | 320 |
| Customer number. | 337 |

D

| | |
|-------------------------------------|--|
| D-channel | 101 |
| parameter downloading | 101 |
| DCHI | 99 , 101 |
| installing | 99 |
| removing | 101 |
| DS-1 Channel | 37 |
| DTE (Data Terminal Equipment) | 37 , 38 |

E

| | |
|----------------------------------|---|
| Echo Cancellor | 37 |
| ERR20 messages | 200 , 202 |
| Extended superframe format | 37 |

H

| | |
|-------------------------------------|--------------------|
| HSDM (High Speed Data Module) | 38 |
|-------------------------------------|--------------------|

I

| | |
|--|---------------------|
| I/O connector panels, cables for | 348 |
| InterGroup Module, cable for | 347 |

L

| | |
|-------------------------|---------------------|
| LD 60 | 200 |
| Clock Controllers | 200 |

M

| | |
|---|--|
| main c | 290 , 334 |
| main cabinet | 277 , 286 |
| Media Gateway | 246–248 , 250 , 277 , 286 , 287 , 289 , 290 , 320 , 334 |
| Meridian 1 | 185–187 |
| Meridian 1 PBX | 186 |
| Meridian 1 system Options 51C, 61C, and 81C | 19 |

N

| | |
|---|---------------------|
| NCTE (Network Channel Terminating Equipment) | 37 |
| Network cards, cable for | 348 |
| NT8D36 InterGroup Module | 347 |
| cable for | 347 |
| NT8D74 cables | 347 |
| NT8D75 cables | 347 |
| NT8D79 cables | 348 |
| NT8D83 cables | 348 |
| NT8D85 cables | 348 |

O

| | |
|-------------------------|---|
| Option 11C main c | 287 , 289 |
|-------------------------|---|

Q

| | |
|---|---|
| QMT21 HSDM (High Speed Data Module) | 38 |
| QPC471 Clock Controller | 347 , 348 |
| cable for | 347 , 348 |
| QPC720 PRI card | 38 |
| 64 T-link version 2 protocol | 38 |

| | | | |
|---|-------------------------|-------------------------|--------------------------|
| cables for | 38 | RRR MMM | 270, 279 |
| QPC757 DCHI | 99, 101 | | |
| D-channel parameter downloading | 101 | | |
| installing | 99 | | |
| removing | 101 | | |
| <hr/> | | <hr/> | |
| R | | S | |
| removing QPC757 DCHI | 101 | Superframe format | 37 |
| RRR is the route created in step 3 (?). MMM is the member number. | 270 | SYSLOAD command | 101 |
| | | <hr/> | |
| | | T | |
| | | Tellabs Model 251 | 37 |