



Linux Platform Base and Applications Installation and Commissioning Avaya Communication Server 1000

7.5
NN43001-315, 05.21
April 2012

Notice

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

Documentation disclaimer

"Documentation" means information published by Avaya in varying mediums which may include product information, operating instructions and performance specifications that Avaya generally makes available to users of its products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of documentation unless such modifications, additions, or deletions were performed by Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

Link disclaimer

Avaya is not responsible for the contents or reliability of any linked Web sites referenced within this site or documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

Warranty

Avaya provides a limited warranty on its Hardware and Software ("Product(s)"). Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this Product while under warranty is available to Avaya customers and other parties through the Avaya Support Web site: <http://support.avaya.com>. Please note that if you acquired the Product(s) from an authorized Avaya reseller outside of the United States and Canada, the warranty is provided to you by said Avaya reseller and not by Avaya.

Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, [HTTP://SUPPORT.AVAYA.COM/LICENSEINFO/](http://support.avaya.com/licenseinfo/) ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AUTHORIZED AVAYA RESELLER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AUTHORIZED AVAYA RESELLER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING, AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA AUTHORIZED RESELLER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, or Hardware provided by Avaya. All content on this site, the documentation and the Product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

Third-party components

Certain software programs or portions thereof included in the Product may contain software distributed under third party agreements ("Third Party Components"), which may contain terms that expand or limit rights to use certain portions of the Product ("Third Party Terms"). Information regarding distributed Linux OS source code (for those Products that have distributed the Linux OS source code), and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply to them is available on the Avaya Support Web site: <http://support.avaya.com/Copyright>.

Preventing Toll Fraud

"Toll fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services.

Avaya Toll Fraud Intervention

If you suspect that you are being victimized by Toll Fraud and you need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support Web site: <http://support.avaya.com>. Suspected security vulnerabilities with Avaya products should be reported to Avaya by sending mail to: securityalerts@avaya.com.

Trademarks

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation and Product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation and Product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners, and "Linux" is a registered trademark of Linus Torvalds.

Downloading Documentation

For the most current versions of Documentation, see the Avaya Support Web site: <http://support.avaya.com>.

Contact Avaya Support

Avaya provides a telephone number for you to use to report problems or to ask questions about your Product. The support telephone number is 1-800-242-2121 in the United States. For additional support telephone numbers, see the Avaya Web site: <http://support.avaya.com>.

Contents

Chapter 1: New in this Release	7
Features.....	7
Navigation.....	7
HP DL360 G7 server.....	7
Other changes.....	7
Administrator UserID change.....	7
Revision history.....	8
Chapter 2: Customer service	13
Navigation.....	13
Getting technical documentation.....	13
Getting product training.....	13
Getting help from a distributor or reseller.....	13
Getting technical support from the Avaya Web site.....	14
Chapter 3: Introduction	15
Navigation.....	15
Conventions.....	16
Supported hardware platforms.....	17
Linux Base applications installation and commissioning task flow.....	18
Communication Server 1000 task flow.....	20
Upgrade path.....	22
Release 5.0 or 5.5 to Release 7.5.....	22
Release 6.0 or 7.0 to Release 7.5.....	22
Chapter 4: Fundamentals	25
Navigation.....	25
Linux platform overview.....	25
Linux Base key features.....	25
Linux Operating System and Distribution.....	26
Co-resident Call Server and Signaling Server.....	26
Security server configuration.....	28
Network and firewall.....	28
Syslog and log rotation.....	29
Software reliability.....	30
Linux security hardening.....	31
Patching.....	32
Centralized authentication.....	32
User accounts and access control.....	32
SNMP.....	34
Disaster recovery.....	34
Avaya UCM overview.....	36
Description.....	36
Deployment Manager.....	41
Deployment View.....	42
Internet Explorer.....	44
Software loads.....	45

Supported configurations.....	46
Backup and restore application data.....	47
6.0 Deployment Targets.....	49
System upgrade.....	49
NFS/system upgrade versus a local installation.....	49
Element Manager.....	49
Chapter 5: New Linux Base installation.....	51
Navigation.....	51
Prerequisites.....	51
Installing a new Linux Base.....	54
Chapter 6: Deployment Manager—New system installation and commissioning.....	69
Navigation.....	69
Installation workflow.....	69
Primary security server configuration.....	70
Configuring the primary security server.....	71
Deployment Manager—Server preconfiguration.....	75
Preconfiguring process using Deployment View.....	75
Logging on to Unified Communications Management.....	78
Accessing Deployment Manager.....	78
Software loads.....	79
Deployment View.....	83
Deployment Actions.....	107
Backups.....	111
6.0 Deployment Targets.....	112
Prerequisites.....	112
Deploy.....	112
Deploying application software to a Call Server.....	112
Undeploying application software.....	114
Backing up existing system data files.....	114
Restoring system data.....	116
NFS based new installation.....	117
Installation workflow using NFS.....	117
NFS based remote installation topology.....	118
Prerequisites.....	119
Installing the servers (NFS-based new installation).....	120
Chapter 7: Upgrade Linux Base.....	123
Navigation.....	123
Prerequisites to upgrading Linux Base.....	123
Upgrading Linux Base.....	123
Chapter 8: Upgrade Avaya Communication Server 1000 system Linux installation....	129
Navigation.....	129
Upgrading a backup or member server from Release 6.0 or later.....	130
Accessing the Local Deployment Manager.....	133
Chapter 9: Base Manager.....	137
Navigation.....	137
Accessing Base Manager through UCM.....	138
Accessing Base Manager through local logon.....	140

Deploying software in local login mode.....	142
Undeploying software in local login mode.....	142
Rebooting the server.....	143
Base system configuration using Base Manager.....	144
Editing network identity for a Member server.....	144
DNS and Hosts.....	147
Adding a route entry.....	151
Deleting a route entry.....	153
Configuring Explicit Congestion Notification.....	155
Date and time configuration.....	156
Configuring NTP transfer mode.....	161
Configuring the clock source for a primary server.....	162
Configuring the clock source for a secondary server.....	164
Configuring a server that is not a clock server.....	166
Regenerating SSH Keys for a UCM Member server.....	167
Software maintenance using Base Manager.....	169
Managing application status.....	170
View and export logs using Base Manager.....	171
Viewing application logs.....	171
Exporting application logs.....	173
Chapter 10: Disaster recovery.....	177
Navigation.....	177
Prerequisites.....	177
Performing disaster recovery for Avaya Linux Base.....	177
UCM considerations for disaster recovery.....	181
Changing Linux Base passwords.....	182
Appendix A: Hardware platforms.....	185
Navigation.....	185
Configuring the privilege level for Windows Vista or Windows 7.....	185
Creating a bootable RMD for Linux Base installations.....	186
Hardware installation checklist.....	191
CP PM card.....	192
Determining CP PM disk size.....	193
Determining CP PM memory size.....	194
BIOS methods.....	195
CP PM Signaling Server.....	199
Connecting a CP PM Signaling Server.....	201
Changing the baud rate on a CP PM Signaling Server.....	202
Installation in a CS 1000E system.....	203
Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000E system.....	203
Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000M system.....	204
CP DC card.....	205
CP MG card.....	205
Dell R300 server.....	205
Configuring the COM1 serial port on a Dell R300 server.....	207
Setting the BIOS password for the Dell R300 server.....	209
Configuring RAID settings.....	213

HP DL320 G4 server.....	213
HP DL320 G4 BIOS settings.....	215
Connecting an HP DL320 G4 Signaling Server.....	220
HP DL360 G7 server.....	221
Front panel components.....	222
Back panel components.....	223
ROM-Based setup utility interface.....	223
Connecting an HP DL360 G7 Signaling Server.....	225
IBM x306m server.....	226
IBM x306m BIOS settings.....	228
Connecting an IBM X306m server.....	232
Changing the baud rate on an IBM X306m Signaling Server.....	234
IBM x3350 server.....	236
Configuring COM port settings for the IBM x3350 server.....	238
Setting the BIOS password for the IBM x3350 server.....	241
Appendix B: Installation times.....	245
Average installation times by media type.....	245
Linux Base and application deployment—average installation time.....	246
Appendix C: Media Application Server.....	247
Checklist for adding a new maintenance release for MAS.....	247
Checklist for upgrading a standalone MAS.....	248
Appendix D: Avaya Linux Base CLI commands.....	249
Appendix E: Troubleshooting.....	257
Deployment errors.....	257
Linux Base installation errors.....	266
Log file.....	267
Backup security server configuration error.....	268
Appendix F: Network configuration for Secure File Transfer Protocol (SFTP) data backup.....	269
Network configuration.....	269
SFTP logon.....	269
SFTP network configuration requirements.....	270
Appendix G: Passthrough end user license agreement.....	271

Chapter 1: New in this Release

The following sections detail what is new in the *Linux Platform Base and Applications Installation and Commissioning, NN43001-315* for Avaya Communication Server 1000 Release 7.5.

- [Features](#) on page 7
- [Other changes](#) on page 7

Features

See the following sections for information about feature changes

Navigation

- [HP DL360 G7 server](#) on page 7

HP DL360 G7 server

CS 1000 Release 7.5 introduces a new hardware platform. The Avaya Common Server supports the Co-resident Call Server and Signaling Server (Co-res CS and SS) configuration. For more information, see [HP DL360 G7 server](#) on page 221.

Other changes

See the following section for information about changes that are not feature-related.

Administrator UserID change

The default administrator User ID has changed for Avaya CS 1000 Release 7.5. The administrator User ID is admin2

Revision history

April 2012	Standard 05.21. This document is up-issued for changes to the Deployment Manager and Linux Base applications and commissioning task flow sections.
April 2012	Standard 05.20. This document is up-issued to support the removal of Gryphon tool content.
February 2012	Standard 05.19. This document is up-issued for changes in technical content; a note is added to the section Deleting a Network Service on page 95.
January 2012	Standard 05.18. This document is up-issued for changes to the section Editing network identity for a Member server on page 144.
January 2012	Standard 05.17. This document is up-issued to provide information about UCM and disaster recovery.
December 2011	Standard 05.16. This document is up-issued to include a list of supported platforms in the Upgrade Linux Base section.
November 2011	Standard 05.15. This document is up-issued to reflect changes in technical content to the Base Manager section.
October 2011	Standard 05.14. This document is up-issued to support the removal of content for outdated features, hardware, and system types.
September 2011	Standard 05.13. This document is up-issued to reflect changes in technical content for product codes for CP PM components.
September 2011	Standard 05.12. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. Added a note to the Editing network identity procedure.
August 2011	Standard 05.11. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. Changes made to provide clarification on using Deployment Manager on the Primary Security server rather than logging on to the local server.
August 2011	Standard 05.10. This document is up-issued to support Avaya Communication Server 1000 Release 7.5.
August 2011	Standard 05.09. This document is up-issued to support Avaya Communication Server 1000 Release 7.5.

	Changes were made to add document references, and examples.
June 2011	Standard 05.08. This document is up-issued to include updates to the Troubleshooting section.
June 2011	Standard 05.07. This document is up-issued to update references to Avaya Common Server (HP DL360–G7).
May 2011	Standard 05.06. This document is up-issued to support Avaya Communication Server 1000 Release 7.5.
February 2011	Standard 05.05. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. Updated the COTS3 HP DL360 G7 server content.
February 2011	Standard 05.04. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. Added the COTS3 HP DL360 G7 server.
January 2011	Standard 05.03. This document is up-issued to support Avaya Communication Server 1000 Release 7.5. Added a prerequisite on avoiding a session timeout when adding a software load from a client machine in the Deployment Manager section for new installation and commissioning. References to pre-loaded CP PM configurations have been removed. Changes to keycode validation.
November 2010	Standard 05.02. This document is published to support Avaya Communication Server 1000 Release 7.5.
November 2010	Standard 05.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.5.
September 2010	Standard 04.03. This document is up-issued to support Communication Server 1000 Release 7.0. Updated Deployment View and Deployment Actions content. Changed title of New CS 1000 system installation and commissioning to Deployment Manager—New system installation and commissioning and moved the Deployment Manager chapter to a subsection of the Preconfiguring (staging) deployment targets section.
June 2010	Standard 04.02. This document is up-issued to support Avaya Communication Server 1000 Release 7.0. Changes made to the media types for adding a software load and NFS prerequisites.
June 2010	Standard 04.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.0.
July 2009	Standard 03.08. This document is up-issued to include revised information for Disaster recovery on page 177.

New in this Release

July 2009	Standard 03.07. This document is up-issued to support Communication Server 1000 Release 6.0.
June 2009	Standard 03.06. This document is up-issued to support Communication Server 1000 Release 6.0.
June 2009	Standard 03.05. This document is up-issued to support Communication Server 1000 Release 6.0.
May 2009	Standard 03.04. This document is up-issued to support Communication Server 1000 Release 6.0.
May 2009	Standard 03.03. This document is up-issued to support Communication Server 1000 Release 6.0.
May 2009	Standard 03.02. This document is up-issued to support Communication Server 1000 Release 6.0.
April 2009	Standard 03.01. This document is up-issued to support Communication Server 1000 Release 6.0.
May 2008	Standard 02.08. This document is up-issued to update information in the Upgrading Linux base procedures.
April 2008	Standard 02.07. This document is up-issued to add information to the procedure Installing the Primary Security Service and Network Routing Service and added UCM Upgrade Procedures 5.00 GA to 5.50.12 to Task Flow chapter.
April 2008	Standard 02.06. This document is up-issued to add lab trial information.
February 2008	Standard 02.05. This document is up-issued to include references to host configuration scripts found in <i>Unified Communications Management Common Services Fundamentals</i> , NN43001-116.
February 2008	Standard 02.04. This document is up-issued to support changes in technical content, including the addition of task flow diagrams for the installation and upgrade of the Linux base and applications.
January 15, 2008	Standard 02.03. This document is up-issued for changes in technical content. New screen captures have been included and an installation and upgrade task flow section has been added.
December 2007	Standard 02.02. This document is up-issued for changes in technical content.
December 2007	Standard 02.01. This document is up-issued to support Communication Server 1000 Release 5.5. This document contains new information on CLI commands, an upgrade procedure, firewall ports, and alarms. Screen captures for the Linux base installation procedure are updated.

November 2007	Standard 01.04. This document is up-issued for changes in technical content.
September 2007	Standard 01.03. This document is up-issued to address changes in technical content for Release 5.0.
June 2007	Standard 01.02. This document is up-issued to remove the Confidential statement.
May 2007	Standard 01.01. This document is issued to support Communication Server 1000 Release 5.0.

New in this Release

Chapter 2: Customer service

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to www.avaya.com or go to one of the pages listed in the following sections.

Navigation

- [Getting technical documentation](#) on page 13
- [Getting product training](#) on page 13
- [Getting help from a distributor or reseller](#) on page 13
- [Getting technical support from the Avaya Web site](#) on page 14

Getting technical documentation

To download and print selected technical publications and release notes directly from the Internet, go to www.avaya.com/support.

Getting product training

Ongoing product training is available. For more information or to register, go to www.avaya.com/support. From this Web site, locate the Training link on the left-hand navigation pane.

Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at www.avaya.com/support.

Chapter 3: Introduction

This document is intended to guide you through the various stages of planning your network and upgrading your servers using Deployment Manager on the Primary security server (Deployment Server) for an end-to-end installation and configuration of Linux Base and applications to your target servers. The preconfiguration capability of Deployment Manager allows you to stage the deployment (or upgrade) of your telephony solution and perform the actual installation and deployment to the target servers on your own time line. Deployment Manager can also enable remote Linux Base installation and upgrades for Release 6.0 and later systems, thereby reducing the need for physical access to your target servers.

The following are the various stages.

- Planning process: identify the network configuration requirements of your target servers
- Identify your Primary security server: perform a fresh Linux Base installation or upgrade
- Preconfiguration process: stage your servers for a logical deployment or upgrade
- Identify pre-Release 6.0 systems for a physical upgrade
- Committing your servers: your servers have now been upgraded with the latest Linux Base and applications are deployed.

After you have read the Introduction and Fundamentals chapters, install or upgrade Linux Base on your Primary Security server [Upgrade Linux Base](#) on page 123 or [New Linux Base installation](#) on page 51 and then proceed to [Deployment Manager—New system installation and commissioning](#) on page 69.

Navigation

- [Fundamentals](#) on page 25
- [New Linux Base installation](#) on page 51
- [Deployment Manager—New system installation and commissioning](#) on page 69
- [Upgrade Linux Base](#) on page 123
- [Upgrade Avaya Communication Server 1000 system Linux installation](#) on page 129
- [Base Manager](#) on page 137
- [Disaster recovery](#) on page 177
- [Hardware platforms](#) on page 185
- [Installation times](#) on page 245
- [Media Application Server](#) on page 247

- [Avaya Linux Base CLI commands](#) on page 249
- [Troubleshooting](#) on page 257
- [Network configuration for Secure File Transfer Protocol \(SFTP\) data backup](#) on page 269
- [Passthrough end user license agreement](#) on page 271

Conventions

In this document, the term System refers generically to the following:

- Avaya Communication Server 1000E (Avaya CS 1000E)
- Avaya Communication Server 1000M (Avaya CS 1000M)
- Meridian 1

In this document, the term Server refers generically to the following hardware platforms:

- Call Processor Pentium IV (CP PIV) card
- Common Processor Pentium Mobile (CP PM) card
- Common Processor Media Gateway (CP MG) card
- Common Processor Dual Core (CP DC) card
- Commercial off-the-shelf (COTS) servers
 - IBM x360m server (COTS1)
 - HP DL320 G4 server (COTS1)
 - IBM x3350 server (COTS2)
 - Dell R300 server (COTS2)
 - HP DL360 G7 server (Avaya Common Server)

In this document, the term COTS refers generically to all COTS servers. The terms COTS1, COTS2, and Common Server refer to the specific servers in the previous list.

In this document, the term Media Controller refers generically to the following cards:

- Media Gateway Controller (MGC) card (NTDW60 and NTDW98)
- Media Gateway Extended Peripheral Equipment Controller (MG XPEC) card (NTDW20)
- Common Processor Media Gateway (CP MG) card (NTDW56 and NTDW59)

In this document, the term Media Gateway refers generically to the following cards:

- Option 11C Mini Chassis (NTDK91) and Expander chassis (NTDK92) - legacy hardware
- Option 11C Cabinet (NTAK11) - legacy hardware

- Expander chassis (NTDK92) - legacy hardware
- MG 1000E Chassis (NTDU14) and Expander chassis (NTDU15)
- MG 1010 Chassis (NTC310)
- IPE module (NT8D37) with MG XPEC card (NTDW20)

Supported hardware platforms

The following table shows the supported roles for common hardware platforms.

Table 1: Hardware platform supported roles

Hardware Platform	VxWorks Server	Linux Server	Co-res CS and SS	Gateway Controller
CP PIV	yes (see Note 2.)	no	no	no
CP PM	yes	yes	yes	no
CP DC	no	yes	yes	no
CP MG	no	no (see Note 1.)	yes (see Note 1.)	yes (see Note 1.)
MGC	no	no	no	yes
MG XPEC	no	no	no	yes
COTS1	no	yes	no	no
COTS2	no	yes	yes	no
Common Server	no	yes	yes	no

Note 1: The CP MG card functions as the Co-res CS and SS and the Gateway Controller while occupying slot 0 in a Media Gateway.
 Note 2: HS supports the CP PIV for only the VxWorks Call Servers for HA groups.

Linux Platform Base and Applications can run on the following hardware platforms:

- CP PM card
- CP DC card
- CP MG card
- COTS Servers
 - IBM x306m
 - HP DL320 G4
 - IBM x3350

- Dell R300
- Common Server
- HP DL360 G7

The Avaya CS 1000 Linux Base system provides a Linux server platform for applications on a Server. The platform supports Session Initiation Protocol Network Redirect Server (SIP NRS), Avaya Unified Communications Management (UCM), traditional Signaling Server applications, SIP Line Gateway Applications, and deployment of the Co-resident Call Server and Signaling Server applications.

Call Server hardware platforms that support the CS 1000E High Availability configuration are supported in the CS 1000 High Scalability configuration. This includes the CP PM for the Call Server software running under the VxWorks operating system and the CP PM and COTS servers that support the Signaling Server applications, including the NRS.

Linux Base applications installation and commissioning task flow

The following task flow provides a high-level task flow for the installation and commissioning of Linux Base and applications on a Server. The task flow depicts the recommended sequence of events and provides a reference to the relevant technical document for each event.

Each box in the task flow represents a stage in the Linux Base installation and commissioning process. The stages are as follows:

- Plan your system
- Identify (gather) parameters for all Servers
- Install and commission the Primary security server (Deployment Server)
- Install and deploy target servers
- Configure and provision applications (for example, Subscriber Manager and SIP Trunk Bridge Manager)




Figure 1: High-level task flow

The following technical documents are referenced in the preceding task flow diagram:

- *Avaya Communication Server 1000E Planning and Engineering, NN43041-220*
- *Avaya Communication Server 1000E High Scalability Planning and Engineering, NN43041-221*
- *Avaya Linux Platform Base and Applications Installation and Commissioning, NN43001-315*

- *Avaya Subscriber Manager Fundamentals, NN43001-120*
- *Avaya Signaling Server IP Line Applications Fundamentals, NN43001-125*
- *Avaya Network Routing Service Fundamentals, NN43001-130*
- *Avaya Media Application Server Commissioning, NN44471-301*
- *Avaya Element Manager System Reference - Administration, NN43001-632*
- *Avaya Security Management Fundamentals, NN43001-604*
- *Avaya SIP Trunk Bridge Fundamentals, NN43001-143*
- *Avaya Communication Server 1000E Installation and Commissioning, NN43041-310*

Communication Server 1000 task flow

The following figure provides a high-level task flow for the installation or upgrade of a Communication Server 1000 system. The task flow indicates the recommended sequence of events to follow when configuring a system and provides the technical document number that contains the detailed procedures required for the task.




Figure 2: Communication Server 1000 task flow

Note:

For the purposes of this diagram, Linux patching is considered to be part of the Configure Call Server box in the CS 1000 task flow. For more information about Linux patching, see *Avaya Patching Fundamentals, NN43001-407*

Upgrade path

There are two supported upgrade paths.

- Release 5.0 or 5.5 to Release 7.5
- Release 6.0 or 7.0 to Release 7.5

Release 5.0 or 5.5 to Release 7.5

The flow to upgrade from Release 5.0 or 5.5 to Release 7.5 requires the following high level steps:

- Backup existing customer data, for example, NRS.
- Perform a CS 1000 Linux base installation or upgrade.
 - If it is a new Linux base installation, see [New Linux Base installation](#) on page 51.
 - If it is an upgrade, see [Upgrade Linux Base](#) on page 123.
- Restore the customer data for the corresponding Management systems, for example, NRSM for NRS. For more information, see *Network Routing Service Fundamentals, NN43001–130*.

For VxWorks Call Server upgrades, see *Avaya Communication Server 1000E Software Upgrades, NN43041–458*.

Release 6.0 or 7.0 to Release 7.5

The flow to upgrade from Release 6.0 or later to Release 7.5 requires the following high level steps:

1. Patch all Release 6.0 or later targets to the latest Service Pack (the latest patch contains the migration patch).

Note:

If upgrading from Release 6.0 to 7.5, the MPLR30019 patch is required to be loaded prior to upgrading to Release 7.0 or 7.5.

2. Backup the Release 6.0 or later data, for example, NRS
3. Upgrade the Primary Security server to Release 7.5
4. Patch the Release 7.5 Primary Security server to the latest Release 7.5 SP (if applicable)

5. Populate the Release 7.5 Deployment View. For more information, see [Deployment View](#) on page 42.
6. Run **System Upgrade** from Deployment Manager to automatically upgrade the Linux Servers (Primary Server is not included as it is already upgraded).

Chapter 4: Fundamentals

This chapter provides an overview about basic information and concepts necessary to successfully install and configure the Linux Base.

Navigation

- [Linux platform overview](#) on page 25
- [Avaya UCM overview](#) on page 36
- [Deployment Manager](#) on page 41
- [Software loads](#) on page 45
- [Supported configurations](#) on page 46
- [Backup and restore application data](#) on page 47
- [6.0 Deployment Targets](#) on page 49
- [NFS/system upgrade versus a local installation](#) on page 49
- [Element Manager](#) on page 49

Linux platform overview

This section provides an overview about basic information and concepts necessary to successfully install and configure the Linux Base.

Linux Base key features

The following are the Linux Base features:

- Linux operating system and distribution
- Firewall
- Software reliability
- Linux security hardening

- Patching
- User accounts and access control
- Software installation and delivery
- System upgrades
- Debugging
- Logging
- Disaster recovery
- Network Time Protocol (NTP)

Linux Operating System and Distribution

The selected distribution is Red Hat Linux 5. This distribution is built on a 2.6.18 kernel, and supports many Open Source Development Lab (OSDL) Carrier Grade Linux (CGL) features.

Red Hat Linux 5 (update 1) supports Linux kernel version 2.6.18 and the following applications:

- Avaya Unified Communications Management (UCM)
- Simple Network Management Protocol (SNMP)
- Deployment Manager (DM)
- Signaling Server (SS)
- Network Routing Service (NRS)
- Call Server (CS)
- Session Initiation Protocol Line (SIPL)
- Element Manager (EM)
- Subscriber Manager (SubM)

Co-resident Call Server and Signaling Server

The Avaya Communication Server 1000 (Avaya CS 1000) Linux Base Co-resident Call Server and Signaling Server (Co-res CS and SS) can run the Call Server software, the Signaling Server software, and the System Management software on the same hardware platform. The Co-res CS and SS can run on various hardware platforms. For more information, see [Supported hardware platforms](#) on page 17.

The Signaling Server software on the Co-res CS and SS refers to a suite of CS 1000 software applications which includes:

- Line Telephony Proxy Server (LTPS)
- Virtual Trunk (VTRK) includes H.323 Gateway or SIP Gateway
- NRS includes SIP Proxy Server (SPS), SIP Redirect Server (SRS), H.323 Gatekeeper, Network Connect Server (NCS), Network Routing Service Manager
- Personal Directory (PD) includes RL, CL, and Unicode Name Directory
- UCM Common Services
 - Security Server
 - Element Manager (EM), including Cluster Manager/IP Telephony node
 - Deployment Manager
 - Base Manager
 - Patching Manager
 - Subscriber Manager
 - SIP Line

You need not deploy all the preceding software applications on the Server. For example, you can install and configure a Co-res CS and SS to run only the Call Server, LTPS, VTRK, UCM Security Server, and EM software. However, the Co-res CS and SS must have the Call Server and at least one Signaling Server application installed. A stand alone Call Server is not supported on the Linux based Servers.

Note:

A Server running Signaling Server and/or UCM applications without a Call Server is not referred to as a Co-res CS and SS.

Upgrade paths

The following upgrade paths are supported for CS 1000 systems:

- CS 1000 Release 6.0 or earlier CP PM based CS 1000E Standard Availability (SA) Call Server to a CS 1000 Release 7.5 Co-resident Call Server and Signaling Server
- CS 1000 Release 6.0 or earlier CS 1000E Signaling Server to CS 1000 Release 7.5 Co-resident Call Server and Signaling Server
- Option 11C, CS 1000M, or CS 1000S Call Server to CS 1000 Release 7.5 Co-resident Call Server and Signaling Server
- Option 11C, CS 1000M, or CS 1000S Call Server to CS 1000 Release 7.5 Co-resident Call Server and Signaling Server

- Option 11C Call Server to CS 1000 Release 7.5 CS 1000E TDM system.
- CS 1000M Call Server to CS 1000 Release 7.5 Co-resident Call Server and Signaling Server

Note:

The minimum CS 1000 Release for Small System migration to a Co-resident Call Server and Signaling Server is Release 23.10.

Note:

If you upgrade from a non-CP PM based CS 1000E Call Server, you must replace your old Call Server hardware with a supported Server and upgrade the software.

For more information about the CS 1000 Co-res CS and SS, see *Avaya Co-resident Call Server and Signaling Server Fundamentals*, NN43001-509.

Security server configuration

A Linux Base server can be assigned one of three security roles: Primary, Backup, or Member.

A network requires one primary security server. The backup security service is optional. One backup security server and one or more member servers can exist for each UCM security domain.

The primary security server must be configured; it provides basic security features such as user administration including password changes, the ability to configure different authorization levels, and the enforcement of security policies.

The backup security server is an optional server that you can configure to perform authentication and authorization when the primary security server is unavailable.

For a more details about UCM configuration of primary, backup, and member servers, see *Avaya Unified Communications Management Common Services Fundamentals*, NN43001-116. For more information about security management, see *Avaya Security Management Fundamentals*, NN43001-604.

Network and firewall

All applications operate behind a network firewall. The firewall starts on system boot, which invokes the Linux iptables facility to load the firewall configuration.

Each Linux server supports at least two Ethernet ports; one for ELAN subnet connectivity and another for TLAN subnet connectivity. By convention, the TLAN is open to the network, while the ELAN is reachable only within the subnet. The Linux application selects the Ethernet port to use. The firewall protects both ports. For a list of Linux Base open firewall ports see [Table](#)

[2: Linux Base open firewall ports](#) on page 29. For a definition of ELAN and TLAN, see [Network configuration](#) on page 269.

Use the command line interface (CLI) command `basefirewallconfig` to configure the network firewall. For a list of Avaya Linux Base CLI commands see [Avaya Linux Base CLI commands](#) on page 249.

Table 2: Linux Base open firewall ports

Protocol	Port number or range
TCP	22
UDP	22
UDP	53 (to configured DNS servers only)
UDP	123
UDP	500
UDP	514
TCP	2100
UDP	33434—33524
RPC	111

Note:

The port numbers in [Table 2: Linux Base open firewall ports](#) on page 29 apply only to the Linux Base. Linux applications can require different ports. For a list of ports opened for the application, see the appropriate application document.

Syslog and log rotation

Syslog

Syslog provides application logging. The log files are stored in the `/var/log/avaya` directory. The log file partition is 10 percent of your hard drive disk space. To increase the performance, the SYNC option is turned off for all application logs. Log files must be readable and writable when logged on using the admin2 account.

Log rotation

The log rotation mechanism is enabled for all application log files. Use log rotation to ease the administration of systems that generate large numbers of log files and provide automatic rotation, compression, removal, and mailing of log files. The log files can be configured for

rotation on a daily, weekly, or monthly basis or when the log file reaches a predefined limit. For more information, see the logrotate MAN pages on your Linux Base.

Software reliability

Software monitoring

Avaya uses a third-party application package to monitor the important daemon services automatically initiated at startup. If a malfunction occurs, you can see actions such as, alert, start, stop, and restart.

The following system parameters are monitored: memory, CPU, and device space usage. If a parameter exceeds a warning threshold a message appears and an SNMP trap is generated. [Table 3: Warning and Critical thresholds](#) on page 30 shows the warning and critical thresholds.

Table 3: Warning and Critical thresholds

System Resource	Warning Clear	Warning Set	Critical Clear	Critical Set
Memory usage	—	—	90%	95%
CPU usage	—	—	90%	95%
/boot (/dev/sda1) Size: 100 MB. Critical.	70%	75%	80%	85%
admin (/dev/sda2) Size: 4 GB.	80%	85%	85%	90%
/ (/dev/sda6) Size: 4 GB.	80%	85%	85%	90%
/opt (/dev/sda7) Size: 8 GB. Not critical.	80%	85%	90%	95%
/home (/dev/sda8) Size: 4 GB. Not critical.	80%	85%	90%	95%
/tmp (/dev/sda9) Size: 20 GB. Critical.	80%	85%	85%	90%
/var (/dev/sda10) Size: 30 GB. Critical.	80%	85%	85%	90%

[Figure 3: Critical Set alarm example](#) on page 31 shows an example of a Critical Set alarm. [Figure 4: Critical Clear alarm example](#) on page 31 shows an example of a Critical Clear alarm message.

Note:

If critical alarms persist, contact your Avaya technical support.

```
Message from syslogd@ibm2-t at Wed Oct 17 14:23:22 2007 ...
ibm2-t Base: EMERG: alarm(788): CRITICAL SET: CPU utilization has
passed the 95% utilization threshold.
```

Figure 3: Critical Set alarm example

```
Message from syslogd@ibm2-t at Wed Oct 17 14:33:26 2007 ...
ibm2-t Base: EMERG: alarm(788): CRITICAL CLEAR: CPU utilization has
dropped below the 90% utilization threshold.
```

Figure 4: Critical Clear alarm example

Hardware watchdog

Servers running Linux Base offer a hardware watchdog. The watchdog is a hardware component of each server which includes a count-down timer that is programmed during the server startup. If the timer reaches zero, the watchdog unconditionally restarts the server (reboots the Linux operating system). The watchdog timer duration is five minutes. A program running as part of the Linux Base continually resets the timer on a periodic basis. The software program and hardware timer work together to effect a systematic recovery of the server in the unlikely event it enters a halted or suspended state (also known as: hung, frozen, or dead). In this case, the software component also halts, and ceases to reset the hardware timer, resulting in an inevitable restart of the server. A server halt can only be the result of an anomalous hardware or software event.

Linux security hardening

Linux security hardening is divided into two categories: basic hardening and enhanced hardening. During the Linux Base installation, the generic Linux Base components are installed, then the basic and enhanced hardening items are applied. The enhanced hardening items are set to default values when they are applied during the installation process.

Basic hardening:

Basic Linux security hardening includes all hardening items that do not affect the performance of Avaya applications. Basic hardening items are on by default and they are not configurable.

Enhanced hardening:

Enhanced hardening items include all hardening items that can affect the performance of Avaya applications, or hardening items that require configuration. Enhanced hardening items

that do not affect Avaya applications performance are on by default, enhanced hardening items that affect performance are turned off by default.

For details about Avaya Linux security hardening, see *Avaya Security Management Fundamentals, NN43001-604*.

Patching

Avaya Linux Base uses Patching Manager to perform patching tasks. You can use Patching Manager on the primary security server to remotely deploy patches from a central location to other Linux servers in the same security domain using the Central Patching Manager. You can also install patches locally. You can access Local patching from the Base Manager of each element, using the Local Patching Manager.

For more information about Avaya Linux patching, see *Avaya Patching Fundamentals* , *NN43001-407*.

Centralized authentication

UCM provides a centralized, GUI-based interface for individual account administration for the CS 1000 network. When a user logs on to a Linux server CLI they receive a prompt for user name and password. First, the user name and password are authenticated locally. If authentication fails, the user name and password is encrypted and sent to the centralized UCM security server through the RADIUS protocol for verification. UCM acts as a RADIUS server to provide authentication for RADIUS clients. If the user is defined in the UCM database then access is granted to the proper Linux shell with the roles defined in the UCM database. For more information about UCM role creation, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*.

User accounts and access control

User accounts and access control methods are managed by native Linux user account management (root and admin2) and tools such as RADIUS and PAM for the UCM managed accounts.

Linux Base includes the following accounts:

- root (as Linux default)

Note:

Avaya does not recommend logging on using the root account unless you are explicitly directed to do so. All base maintenance and debug actions must be performed using the admin2 account.

Note:

You can log on directly as root through the COM1 console, or through a keyboard and video monitor (KVM).

⚠ Caution:

Do not change your KVM terminal. If you switch the KVM terminal, logon can fail if you log on directly as root.

Important:

If you log on to the COM1 port, make sure you turn off **Caps Lock** before you log on.

- **admin2:** The user account for the basic Linux Base operations as well as for base manager. For a list of CLI commands that can be invoked by admin2, see [Avaya Linux Base CLI commands](#) on page 249.
- **System UCM accounts:** These accounts are governed by UCM policies; for information about UCM password policies, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*.

Note:

If you log in and your account remains inactive for 15 minutes, you are automatically logged out.

Note:

System Linux Base accounts that make three successive incorrect logon attempts are locked for one hour. System UCM accounts making successive incorrect logins are locked based on the policy settings defined in UCM.

Passwords

The following regulations govern the use of passwords:

Password policy

The password for the root account expires after three months, but the root account does not expire.

Note:

A warning that the password will expire is given by the system when logging into the server during last seven days before it expires. After the password for the account has expired, the password must be changed the next time the account is used to log into the server. The password for the admin2 account never expires, but it is still recommended that the password be changed at a regular schedule, based on your security requirements.

- A new password must differ from the previous three passwords.

UCM password rules for Admin are different than the System UCM accounts. For more information, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*.

Password creation guidelines

Passwords must meet the following criteria:

- Passwords must contain both uppercase letters, lowercase letters, numeric characters, and special characters.
- In addition to letters, passwords must use digits (0 to 9) and special characters (@#\$%^*()_+|~-=-\`{}[]:~;'&<>?,./!).
- The password must contain at least eight alphanumeric characters.
- The password cannot be a word in the English language as defined in the Linux Pluggable Authentication Module (PAM) module.
- Passwords cannot use discernible character patterns such as abcdef or 123123.
- Passwords cannot use the backward spelling of a word.
- Passwords cannot be an English language word (as defined in the Linux PAM module) preceded or followed by a digit. For example, 1secret or secret1.
- You can change your password by using the `passwd` CLI command.

For more information about changing lost or forgotten passwords, see [Changing Linux Base passwords](#) on page 182.

SNMP

Linux Base supports standard server type Management Information Base (MIB) II MIBs. For information about the configuration of SNMP on Linux Base, see *Avaya Communication Server 1000 Fault Management — SNMP, NN43001-719*.

Disaster recovery

Important:

If you are attempting to recover a server that has been upgraded from Communication Server 1000 Release 6.0 or later and does not have the latest backup data (either USB or SFTP), perform a backup data restore during the Linux Base installation. Performing a restore ensures a graceful reregistration to the UCM Security Domain and UCM Deployment Manager. For more information, see [Performing disaster recovery for Avaya Linux Base](#) on page 177.

Hardware faults can occur that require disaster recovery. Recovery occurs in two steps. First, restore the Linux Base (including operating system and Base applications), and then restore the Avaya applications.

A file backup and restore option supports the base disaster recovery.

During a system backup, information for the following applications (if installed) is backed up and is restorable when the applications are reinstalled:

Note:

The list of backed up Base and Avaya applications is comprised of applications successfully installed prior to the backup. This list contains common applications; your installation can contain applications not listed here.

- Base configuration data
- UCM

UCM backs up the following data:

- Data pertaining to Element Registry
- Certificate Authority (if the server is the primary UCM server); certificates and jboss keystore.
- User and Emergency accounts. If Subscriber Manager is installed, subscriber accounts are also backed up.
- Configuration files
- SSH keys

- SNMP
- DM
- SS
- NRS
- CS
 - Data from the last EDD is backed up.
- SIPL
- EM
- SubM
- Intrasystem Signaling Security Solution (ISSS)

Disaster recovery does not back up Avaya logs; however, UCM backs up security logs.

Application-configured system data:

You can configure values for routes using [Adding a route entry](#) on page 151. You can add or delete host records using [DNS and Hosts](#) on page 147, and firewall rules using the CLI commands `routeconfig`, `hostconfig`, and `basefirewallconfig`. These values are application-configured system data. Application-configured system data is backed up as part of the system data backup.

For more information about disaster recovery prerequisites and procedures, see [Disaster recovery](#) on page 177.

Avaya UCM overview

The following section contains an overview and references about Avaya Unified Communications Management (Avaya UCM) security configuration.

Description

UCM is a collection of system management tools. UCM provides a consistent methodology and interface to perform system management tasks. System management tools are Web-based system management solutions supported by the UCM framework.

Installed on every Avaya Linux Base operating system is a Web server with extended security features that forms the basis for UCM and provides the following key features:

- Central element registry for all elements
- Authorization and authentication functionality
- Single sign on across application and hardware platforms
- PKI management
- RADIUS support
- External authentication support

Note:

Support terminals not connected to the DNS domain must modify their local host files to gain initial access to UCM. For more information about managing local host files, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*.

The following overview shows UCM on an Avaya Linux Base system.



Figure 5: UCM overview

You can configure UCM in one of the following ways:

- Primary security server
- Backup security server
- Member security server

Every security domain must have one primary security server. The security domain can have one or no backup servers; additional servers are member servers.




Figure 6: UCM server configurations

UCM framework is installed and runs on all CS 1000 Linux platforms (CP PM and COTS). Management applications are packaged as Web Archive (WAR) files and loaded into the UCM framework.

CS 1000 management applications are auto-deployed, other applications are deployed as required.

- Auto-deployed to the UCM server
 - Base Manager: Provides local Web management for Linux Base. Supports IPv6.
 - Deployment Manager: Provides a one-step Linux Base and application installation or upgrade across all preconfigured servers. Deployment Manager is installed on the Primary security server. Deployment Manager is accessible locally on the target server.
 - Patching Manager: Provides Web-based patch delivery. Patching Manager is centrally accessible from the primary security server or locally on the target server.
 - IPsec Manager: Provides centralized Web-based IPsec management.

- SNMP: Provides centralized Web-based fault management.
- User deployed
 - Element Manager: Provides traditional CS 1000 Web-based management, including Call Server overlay support. Support IPv6.
 - Network Routing Service Manager
 - Subscriber Manager
 - Signaling Server (virtual trunks, Terminal Proxy Server)
 - SIP Line

The following figure shows application deployment on UCM servers.




Figure 7: UCM application deployment

The following figure provides an example of system management components deployed in a typical installation. Network and engineering analysis determines the location of the UCM primary and backup servers. Typically EM is deployed physically close to the Call Server it manages.




Figure 8: Physical deployment of UCM

The UCM Graphical User Interface (GUI) is shown in the following figure.




Figure 9: UCM graphical view

The following figure illustrates the three levels of UCM management.

UCM - Network, System and Element View

This view shows the three levels of UCM managers. Some managers have a scope only at the hardware or element layer. Some managers have a scope that spans multiple hardware layers, but are restricted to a single CS 1000 system. The network level is the only level that spans multiple CS 1000 systems.




Figure 10: UCM management levels

For detailed information about the components, features, and benefits of Unified Communications Management, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*.

Deployment Manager

Use Deployment Manager on the Primary security server for an end-to-end installation and configuration of Linux Base and applications. Deployment Manager provides a simplified and unified solution that enables network installation of Linux Base on target servers. The Primary security server is the Deployment Server.

Install the Linux Base on the Primary security server (Deployment Server) using a local Linux Base installation media. Upgrade Linux Base on the Member and Backup servers over the network using Network File System (NFS). For more information, see [NFS/system upgrade versus a local installation](#) on page 49.

Use UCM Deployment Manager to select groups for predeployed applications prior to joining the domain. After preconfiguration, commit predeployed applications for deployment. You can then deploy application groups to Servers. If the Server is not running Release 6.0, you can physically deploy using the bootable media. For more information about the end-to-end installation and configuration procedures, see [Deployment Manager—Server preconfiguration](#) on page 75. For more information about upgrading existing servers, see [Upgrade Avaya Communication Server 1000 system Linux installation](#) on page 129.

After installation and configuration is complete:

- Linux Base is installed
- Base applications are installed during the first restart of the computer
- UCM is deployed and security configuration is complete
- The application combination is determined and deployed
- Applications are active

There are two different types of Linux Base deployments.

- Linux Base operating system is already installed
- Linux Base operating system is not installed

For more information about the different deployment procedures, see [Deployment View](#) on page 83.

Important:

You must install and configure VxWorks elements manually. Deployment Manager cannot be used to perform installation and configuration of VxWorks elements.

From UCM, you can click Software Deployment to reach the UCM Deployment Manager. The following links are available.

- [Deployment View](#) on page 42
- [Software loads](#) on page 45

- [Backup and restore application data](#) on page 47
- [6.0 Deployment Targets](#) on page 49

Deployment View

The Deployment View page has three view screens. Click the View list to select the required view. The View options are:

- Servers
- Network Services
- CS 1000 System

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Deployment View Print | Refresh

Linux Server Deployment Actions View: Servers

Host Name	Address	Type	Status	Predeployed Applications	Base Version
<input type="radio"/> 192.168.209.115(Active)	192.168.209.115	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.116(Active)	192.168.209.116	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.117 (Inactive)	192.168.209.117	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.55.118(Active)	192.168.55.118	VxCS	Preconfigured	N/A	
<input type="radio"/> hpss7.us.avaya.com (member)	192.168.55.150	Linux	Committed	CS1000HS-EM	
<input type="radio"/> ibmss10.us.avaya.com (primary)	192.168.55.178	Linux	Committed	SubM, NRS, EM, SS	7.50.07
<input type="radio"/> test1.us.avaya.com (member)	192.168.55.190	Linux	Committed	EM, SS, NRS	
<input type="radio"/> test2.us.avaya.com (member)	192.168.55.211	Linux	Preconfigured	None	

NFS status: enabled

Servers that are already deployed with specified applications, and need to be configured into systems.
 Servers which have only Linux base applications installed.

Note: All servers have to be in the committed state for further deployment operations.
 Undeploy option will only be available for servers that are not part of any network services or CS1000 systems.

Figure 11: Deployment View

Important:

On the Deployment View page, a server that appears in blue cannot be committed. You must add the server to a group before you can Commit.

Deployment View screens:

Servers:

The Servers view is the default page as shown in the preceding figure. The following items appear on the Deployment View page in table format:

- Hostname
- Address
- Type (Linux or VxWorks Call Server)
- Status (Preconfigured, Predeployed, Committed, or Configured)
 - Preconfigured: the status when the server is first added in Deployment Manager
 - Predeployed: the status to identify the applications that Deployment Manager deems necessary to be deployed to the server
 - Committed: the status when the server is ready for NFS installation, deployment, or removal from Deployment Manager
 - Configured: the status when the server is registered to UCM but no applications are installed.
- Predeployed Applications: The applications that are to be deployed on the server. (for example, NRS, CS, EM, SS, or CS1000 HS)
- Base Version: The Linux Base version on the server. The server must be registered in UCM for the updated version to appear.
- Server Status: The current application deployment status of the server. Can be Deployed or Undeployed.
- Current Operation: Informs you of any current operations being performed on the server. Does not report the current operations for NFS installations.
- Deployed Applications: Shows the actual applications that are deployed on the server. The Server Status shows deployed.
- Last Operation: The last operation that was performed on this server.

Network Services:

The Network Services view shows a tree view of the following network types for viewing, adding, or deleting:

- MAS
- NRS
- SIP Trunk Bridge
- Subscriber Manager

CS1000 Systems:

The CS1000 Systems view shows tree view groupings of **CS1000** or **CS1000 HS** for viewing, adding, or deleting.

The following table shows the application that is deployed for a particular group.

Table 4: Deployed applications by group

Group	Deployed application
NRS	NRS
MAS	MAS
Call Server (CS1000 system — Call Server)	CS
Element Manager (CS1000 — Element Manager)	EM
Signaling Server (CS1000 — Signaling Servers, CS1000 HS — HA system — Signaling Servers)	SS
CS1000 Element Manager HS (CS1000 HS — Element Manager HS)	CS1000HS-EM
SIP Trunk Bridge	SIP Trunk Bridge
Subscriber Manager	SubM

Deployment Actions:

The **Deployment Actions** list is context-sensitive so only the actions that are available to be selected appear in the list. The following is a complete list of the Deployment Actions:

- Deploy
- Undeploy
- Backup
- Restore
- System Upgrade

For more information about using Deployment Actions, see [Deployment Actions](#) on page 107

Internet Explorer

Deployment Manager supports Internet Explorer 6.02600 or later. However, if you use the tree view structure in Deployment Manager with Internet Explorer 8.0, you must configure the compatibility view setting from Internet Explorer. Go to the **Tools** menu and select **Compatibility View Settings**. On the Compatibility View Settings page, select **Display all websites in Compatibility View**. Click **Close**.

Software loads

There are two load types for CS 1000 Linux applications.

- CS 1000 load: avaya-cs1000-linux-700xx-pyyy-mzz.nai
- MAS load: avaya-cs1000-linux-mas-700xx-pyyy-mzz.nai

The naming convention for the .nai file is avaya-cs1000-linux-version and release number-loadware number-deplist.nai

- 700xx is the version and release number
- pyyy is the preinstallation loadware number that is part of the nai distribution
- mzz is the deplist number that is part of the nai distribution
- nai is the extension name (Avaya Application Image)

Downloading the nai file:

Download the nai file for the CS 1000 or the MAS software load.

1. Go to the Avaya Web site <http://www.avaya.com>.
2. Navigate to **Support > Downloads**.
3. Select the Release number from the list, and click the required software load zip file for the server platform, for example **Communication Server 1000 Software Downloads – Release x.x**.

Note:

The default release is 7.5.x.

4. Click the **Downloads** tab.
5. Click the software load zip file, for example, avaya-cs1000-linux-700xx-pyyy-mzz.nai.

You can download the application load files directly to the hard drive of the client PC, or you can copy the application load file to a CD, DVD, compact flash (CF), or USB device and then attach the storage medium to the client PC and upload the application load file. Deployment Manager provides the functionality to transfer the application load file from the client PC to the server hard disk.

For central deployment, you must upload the application load file to Deployment Manager, which deploys the software to other servers in the security domain. Local deployment requires that you upload the software load to each target server. The primary security server can then deploy the software applications to other servers in the same security domain.

For more information about installing the load files, see [Adding a software load from the Deployment Server](#) on page 79.

Supported configurations

The following list shows the possible application options supported in Deployment Manager:

Predeployed applications	Supported configurations
SS	SS
EM	EM
NRS	NRS
SubM	SubM
CS	CS
CS 1000HS-EM	CS 1000-EM
BRIDGE	BRIDGE
SS, EM	SS_EM
SS, NRS	NRS+SS
SS, SubM	SS_SubM
SS, CS	CS+SS
EM, SubM	SS_EM_SubM
EM, NRS	NRS+SS_EM
EM, CS	CS+SS+EM
NRS, SubM	NRS+SS_SubM
NRS, CS	CS+SS_NRS
SubM, CS	CS+SS_SubM
SS, EM, NRS	NRS+SS_EM
SS, EM, SubM	SS_EM_SubM
SS, EM, CS	CS+SS+EM
SS, NRS, SubM	NRS+SS_SubM
SS, NRS, CS	CS+SS_NRS
SS, SubM, CS	CS+SS_SubM
EM, NRS, SubM	NRS+SS_EM_SubM
EM, NRS, CS	CS+SS+NRS+EM
EM, SubM, CS	CS+SS+EM_SubM

Predeployed applications	Supported configurations
NRS, SubM, CS	CS+SS_NRS_SubM
SS, EM, NRS, SubM	NRS+SS_EM_SubM
SS, EM, NRS, CS	SS+SS+NRS+EM
SS, EM, SubM, CS	CS+SS+EM_SubM
SS, NRS, SubM, CS	CS+SS_NRS_SubM
EM, NRS, SubM, CS	CS+SS+NRS+EM_SubM
SS, EM, NRS, SubM, CS	CS+SS+NRS+EM_SubM

The preceding list shows the applications that are supported in standalone mode. All other applications, such as SIP Trunk Bridge and MAS, are supported as standalone only.

Backup and restore application data

In order to retain application data values, you must perform a data backup prior to an installation or upgrade. The type of data backed up is dependent on the applications/manager running on the server. For example:

- UCM data backup always includes Linux Base system settings and parameters.
- If the server is a primary security server, the backup includes UCM data.
- If the MAS application is deployed on the server, the backup (MAS uses Element Manager to backup MAS data) includes MAS data.

Note:

For information about data backup using MAS Element Manager, see the MAS documentation *Media Server Administration and Security, NN44471-600*.

Other backups can include NRS, Subscriber Manager, CS 1000, CS 1000 HS, Signaling Server/PD, and SIP Trunk Bridge.

After the application installation or upgrade is complete, you can restore application data from the backup you created.

The following actions are performed during a system restore:

- All applications are stopped (including Web applications).
- Configuration and provisioning data for pre-installed applications and for previously deployed applications is restored.
- All applications are restarted except for Base Operating System configuration (such as IP addresses and DNS).

Figure 12: Application data backup and restore on page 48 provides a high-level overview of application data backup and restore processes.




Figure 12: Application data backup and restore

6.0 Deployment Targets

6.0 Deployment Targets can be reached from the UCM Deployment Manager navigation tree. It is available for sites that are supporting a mixed release environment and for those sites that are using a phased approach for upgrading to a later software release. For CS 1000 systems running Release 6.0, you can continue to access the 6.0 Deployment Targets link to manage and deploy application software and for system data backup and restore. For more information, see [6.0 Deployment Targets](#) on page 112.

System upgrade

A system upgrade includes a reinstallation of Linux Base and applications with your system data restored. For more information, see [Upgrading a backup or member server from Release 6.0 or later](#) on page 130.

NFS/system upgrade versus a local installation

In scenarios where there is not enough network bandwidth, such as a slow WAN connection between the Deployment Manager server and the desired target server, the recommended approach is to perform a local installation. For procedures on performing a local installation, see [Installing a new Linux Base](#) on page 54.

Element Manager

When configuring your Communication Server 1000 High Scalability (HS) system in Deployment Manager, there are two lists for Element Manager. The first list includes all the Linux servers that can be selected for deployment with the CS 1000HS-EM application. The second list (for Alternate Element Manager) contains a default value of Not Configured and shows the Linux servers from the first list except for the server that was selected in the first list.

Upon finishing the configuration for Element Manager and Alternate Element Manager, the configured servers (or just Element Manager if that is the only one configured) become members of a UCM group with the type xemGroup. The main Element Manager server is made the leader for this group. This group is made a member to the multicore cluster group.

A file is created with the IP addresses of the main Element Manager server and the Alternate Element Manager server which includes whether it is configured as standalone or redundant mode. This file is transferred to the Target Server during the deployment and is read by the monitoring process.

There are one or two CS 1000 elements created in UCM depending on the number of servers. For example, if the Element Manager server has FQDN1 and the Alternate Element Manager server has FQDN2, then the managementURL field for the two links is https://FQDN1/.../xemWeb/index.jsp and https://FQDN2/.../xemWeb/index.jsp.

The monitoring process internally changes the managementURL to point to the active server. In this example, the managementURL of the second server is also changed to https://FQDN1/.../xemWeb/index.jsp. If for any reason the main element management server changes from the first server to the other then the management URL of both servers is changed to https://FQDN2/.../xemWeb/index.jsp. The following figure shows the CS 1000HS-EM screen from the UCM elements page.

For more information about Element Manager for HS, see *Avaya CS 1000E High Scalability Installation and Commissioning*, NN43041-312. For more information about configuring a CS 1000 High Scalability system, see [Defining a new CS 1000 High Scalability system](#) on page 101.

Host Name: **ibmss9.ca.avaya.com** Software Version: 02.10.0012.01(3404) User Name admin

Elements

New elements are registered into the security framework, or may be added as simple hyperlinks. Click an element name to launch its management service. You can optionally filter the list by entering a search term.

<input type="checkbox"/>	Element Name	Element Type ▲	Release	Address	Description ▲
<input type="checkbox"/>	CS1000HS-EM on ibmss9	CS1000	6.5	1.2.3.4	New element.
<input type="checkbox"/>	192.168.55.134	Call Server	6.0	192.168.55.134	New element.
<input type="checkbox"/>	CallServer105	Call Server	6.0	192.168.209.105	New element.
<input type="checkbox"/>	CallServer119	Call Server	6.0	192.168.209.119	New element.
<input type="checkbox"/>	ibmss9.ca.avaya.com (primary)	Linux Base	6.0	192.168.55.183	Base OS element.

Figure 13: CS 1000HS-EM screen

Chapter 5: New Linux Base installation

The chapter includes a new Linux Base installation. You can install the Linux Base using a local Linux Base installation media or over the network. The following procedures are recommended for a Primary security server installation and, if necessary, you can also use the procedures for an offline installation of the Member and Backup servers. However, the recommended approach for installing Linux Base on the Member and Backup servers is using NFS, see [Installing the servers \(NFS-based new installation\)](#) on page 120.

Navigation

- [Prerequisites](#) on page 51
- [Installing a new Linux Base](#) on page 54

Prerequisites

The server must meet the following requirements:

- The hard drive size must be at least 40 GB.
 - If you are installing Linux Base on an existing VxWorks CP PM Signaling Server, use the command `disksize show` to check the hard drive size. For information about upgrading the CP PM hard drive, see procedure for Replacing the hard drive on a CP PM Signaling Server in *Avaya Circuit Card Reference, NN43001-311*.
- The CP PM card BIOS must be Release 18 or higher to support Linux Base on a CP PM version 1 card. Linux Base is required for Co-resident Call Server and Signaling Server (Co-res CS and SS) applications.
- The compact flash card must have a capacity of at least 2 GB for CP PM servers. For CP MG and CP DC, USB 2.0 is the only media supported. CP PM supports Compact Flash and COTS supports only CD/DVD-ROM. USB 1.0 and 1.1 flash devices are not supported.

Note:

The N0220961 USB memory stick is supported for Avaya Communication Server 1000. Not all USB memory sticks are supported.

- If you are installing Linux Base on an existing VxWorks CP PM Signaling Server, use the command `memsize show` to check the memory size. For information about

upgrading the memory capacity of a CP PM Signaling Server, see procedure for Upgrading the CP PM memory in *Avaya Circuit Card Reference, NN43001-311*

- You must create a bootable media device using the mkbootrmd.bat tool every time a bootable software load is copied to the media. For information about creating a bootable media device, see [Creating a bootable RMD for Linux Base installations](#) on page 186.

Before you install the Linux Base, you must gather the following customer information:

- ELAN IP address
- ELAN gateway IP address
- ELAN netmask
- The host name associated with the TLAN

Note:

Supported Host Name length — The maximum length for the Host Name is 32 characters. The minimum length is 1 character. The first character of the host name must not be a digit.

Supported Host Name characters — The host name you enter must conform to the following:

- A valid host name consists of a text string that can include the alphabetic characters 'a' to 'z', the digits '0' to '9'.
 - The period (.) is not permitted in the host name because it is reserved for use as a delimiter between domain names.
 - No space or tab characters are permitted.
 - The first character of the Host Name must be an alphabetic character (a to z).
- The domain name

Note:

A Fully Qualified Domain Name (FQDN) consists of a host name, a domain name, and a top-level domain name. For example, the FQDN, kwei.ca.avaya.com, the host name is kwei, the domain name is ca.avaya, and the top-level domain name is .com. The FQDN must contain at least three fields separated by dots. The host name cannot contain dots.

Note:

If you are using a DNS server to resolve the FQDN to an IP address, ensure that you can resolve the FQDN to the expected IP address prior to the installation of the Linux server. For example, attempt to ping the FQDN from a PC that uses the external DNS server, and it should resolve to the expected IP address.

- TLAN IP address
- TLAN gateway IP address
- TLAN netmask

- Timezone
- IP address of the Primary Domain Name Service (DNS) server
- Default system gateway associated with the network interface is TLAN.

Note:

TLAN as the default gateway can be influenced by your deployment decisions about how applications are to be deployed in accordance to your network topology. For a definition of ELAN and TLAN, see [Network configuration](#) on page 269.

Note:

The ELAN and TLAN ports on the Co-res CS and SS can be cabled through the Gateway Controller. Even though the ELAN and the TLAN ports can be connected directly to an external Layer 2 switch, it is recommended that the ports be connected to the Gateway Controller to provide ease of cabling and to take advantage of the dual-homing feature provided by the Gateway Controller.

Note:

The CLI command `routeconfig` can be used to add routing entries. The choice of routing entries will depend upon the network topology and application deployment. For a list of Avaya Linux Base CLI commands, see [Avaya Linux Base CLI commands](#) on page 249.

⚠ Warning:

If you are installing Linux Base on a CP PM card and the CP PM card is currently running Signaling Server software from VxWorks, you must either press the faceplate reset button or reseat the card before you begin the Linux Base installation. Failure to do so results in a watchdog reset during installation. This scenario occurs when you issue a `reboot -1` from the `pdt` shell and then proceed directly to the Linux Base installation. Reset the card using the faceplate button to disable the hardware watchdog and allow the installation to complete.

Additional equipment:

You may require the following additional equipment, depending on the installation options that you select.

- PC—you can use a client PC for the following installation tasks:
 - Run a program such as Putty to connect to the Linux server COM1 port. Use of the COM1 port is mandatory for installations on a CP PM server, and optional for installations on a COTS server.
 - Configure UCM primary (Deployment Server), backup, and member servers.
 - Create a bootable media for local installation on a Server (for the Primary (Deployment Server) and on Release 5.5 or earlier systems).
 - Launch Deployment Manager using a Web browser to deploy software.
- Keyboard, video card, and monitor (KVM)—KVM can be used for COTS server Linux Base installation and password recovery.

Note:

KVM is no longer mandatory for password recovery; Linux Base also supports COM port password recovery. You can use a USB Keyboard, USB mouse, and a VGA monitor for CP DC card Linux Base installation and password recovery. The CP DC card has a USB and a VGA port on the faceplate.

Note:

If you connect to the IBM x3350 server with a terminal for setup, the server does not function with the serial cable that was previously shipped with the ISP 1100 or other COTS platforms. The IBM x3350 server requires the new NTRX26NPE6 9 pin female to 9 pin female null modem cable. For a picture of the null modem cable, see [Figure 180: NTRX26NPE6 9 pin female to 9 pin female null modem cable](#) on page 237.

- Ensure the USB security dongle adapter is hidden from plain view.
 - For a Dell R300 server: insert the USB security dongle adapter into an internal USB port (recommended).
 - For an IBM x3350 server: insert the USB security dongle adapter into a rear USB port.
 - For COTS2 and Common Servers: insert the USB security dongle adapter with security dongle into a USB port.
 - Restart the server to ensure the dongle is recognized.

The following figure shows a USB security dongle and a USB security dongle adapter.



Figure 14: USB Security dongle and adapter

Installing a new Linux Base

Install Linux Base.

⚠ Warning:

If you access the Linux server through the COM port of a client PC, it is possible that garbled characters (such as uuuuuu) can appear during a system restart during the installation. This appearance can make the system seem to hang.

You can resolve the problem by reestablishing the COM port connection from the client PC or work station to the Linux server.

Do not manually restart the system during the upgrade or installation. This can result in hard drive corruption, and forces you to reinstall the system.

1. Insert the Linux Base installation media.

⚠ Warning:

The Linux Base DVD should only be inserted in the DVD drive during the Linux Base installation on a COTS server (this does not apply to CP PM servers). Normally the DVD auto-ejects after the Linux Base installation is complete. If the Linux Base DVD is accidentally left in the DVD drive after installation and a system restart occurs, the system will boot into the installation program. This can be interpreted as a hung system. If this occurs, manually eject the DVD and restart the system.

2. Restart the server.

Important:

The boot prompt appears only briefly. You have about eight seconds to respond before it defaults to COM1.

3. For COTS: Watch for the boot prompt during the restart process and proceed to [4](#) on page 56 in this procedure.

OR

For CP DC and CP MG servers, press the F key immediately after the server begins rebooting and proceed to [4](#) on page 56 in this procedure.

OR

For a CP PM server, at the Linux Base installer screen, you see ..., at this point press the F key to force the board to boot from the faceplate drive, as shown in the following figure, and proceed to [4](#) on page 56 in this procedure.




Figure 15: Force board to boot screen

4. Type `com1` to install using a serial console on COM1.

OR

Type `kvm` to install using an attached keyboard and video monitor.

Note:

Kvm is not a valid option for CP PM servers.

Important:

If you log on to the COM1 port, make sure that **Caps Lock** is turned off before you log on.

The CS 1000 Linux Base system installer confirmation screen appears.

5. Type `Y` and press `Enter`, as shown in the following figure.

```

PreInstall script started. mntDir=/mnt/source ethif=eth0

Checking for previous installation...
#####
#####

Installation of New Linux base Operating System
Existing Linux base release:
System Release:      cs1000-linuxbase-7.50.07.00
Build Timestamp:    Wed Sep 22 15:44:49 EDT 2010

New Linux base release:
System Release:      cs1000-linuxbase-7.50.07.00
Build Timestamp:    Wed Sep 22 15:44:49 EDT 2010

This is a RE-INSTALLATION, NOT UPGRADE of Linux Base.
If there is backup data available on an USB or
SFTP server, it can be recovered at the subsequent
"Base Configuration Data Selection" stage.
If this was meant to be an upgrade operation,
abort this installation and invoke upgrade CLI.

#####
#####

Do you wish to proceed with installation (Y/N) [Y]? █

```

Figure 16: CS 1000 Linux Base system installer confirmation screen

The Format all partitions screen appears.

6. Press **Enter** to continue, as shown in the following figure.

```

#####
#####

ALL PARTITIONS WILL BE ERASED AND FORMATTED.

THIS DATA CANNOT BE RESTORED ONCE FORMATTED
BY THIS INSTALLATION PROGRAM.

PRESS THE ENTER KEY TO CONTINUE...

#####
#####

```

Figure 17: Format all partitions screen

The Base Configuration Data Selection screen appears.

7. Because this is a new installation, type **1** and press **Enter**, as shown in the following figure.

Note:

If you select option 2 or 3, the remainder of the process is the same as the upgrade procedure. Proceed to [9](#) on page 126 in [Upgrading Linux Base](#) on page 123.



Figure 18: Base Configuration Data Selection screen

The System configuration window appears.

8. Press **Enter** to begin network configuration, as shown in the following figure.




Figure 19: System configuration screen

9. You are prompted to type the following, as shown in the following figure.

- **ELAN IP Address**
- **ELAN Netmask**
- **ELAN Gateway IP Address**

- **Hostname**

At the prompt, Do you wish to configure a Domain Name (Y/N), type Y as this is a mandatory requirement.

- **TLAN port Domain Name**

- **TLAN IP Address**

- **TLAN Netmask**

- **TLAN Gateway**

At the prompt, Do you wish to configure TLAN with IPv6 Addr (Y/N) [N], type Y to configure TLAN with an IPv6 Address. Default is No.

Press Enter to continue.

```

Network Configuration
-----
Enter ELAN IP Address: 10.2.115.101
Enter ELAN Netmask: 255.255.255.0
Enter ELAN Gateway IP Address: 10.2.115.1
FQDN (Fully Qualified Domain Name) = Hostname + Domain Name
Enter Hostname: sys219
Do you wish to configure a Domain Name (Y/N) [Y]?
Enter TLAN port Domain Name: canada.com
Enter TLAN IP Address : 10.2.110.201
Enter TLAN Netmask: 255.255.255.0
Enter TLAN Gateway IP Address: 10.2.110.1
Do you wish to configure Tlan with IPv6 Addr (Y/N) [N]?

The Default Gateway will be set to the TLAN Gateway.
Press ENTER to continue.

```

Figure 20: Network Configuration screen

10. On the TimeZone Configuration screen, type the number corresponding to the GMT offset you want to choose, as shown in the following figure.

```

TimeZone Configuration
-----
GMT Offset Selection
 1) +00:00          2) +01:00          3) +02:00
 4) +03:00          5) +03:30          6) +04:00
 7) +04:30          8) +05:00          9) +05:30
10) +05:45         11) +06:00         12) +06:30
13) +07:00         14) +08:00         15) +09:00
16) +09:30         17) +10:00        18) +11:00
19) +12:00         20) +13:00        21) -01:00
22) -02:00         23) -03:00        24) -03:30
25) -04:00         26) -04:30        27) -05:00
28) -06:00         29) -07:00        30) -08:00
31) -09:00         32) -10:00        33) -11:00
34) -12:00
Enter GMT Offset (1-34): 27
Select (0,1-3):2
    
```

Figure 21: TimeZone Configuration screen

For example, to select a time in the United States Eastern time zone, type 28. The time zone and the corresponding Greenwich Mean Time (GMT) offsets, are shown in the following table.

Table 5: Time zone offsets

Name	Description	Relative to GMT
GMT	Greenwich Mean Time	GMT
UTC	Universal Coordinated Time	GMT
ECT	European Central Time	GMT+1:00
EET	Eastern European Time	GMT+2:00
ART	(Arabic) Egypt Standard Time	GMT+2:00
EAT	Eastern African Time	GMT+3:00
MET	Middle East Time	GMT+3:30
NET	Near East Time	GMT+4:00
PLT	Pakistan Lahore Time	GMT+5:00
IST	India Standard Time	GMT+5:30
BST	Bangladesh Standard Time	GMT+6:00
VST	Vietnam Standard Time	GMT+7:00
CTT	China Taiwan Time	GMT+8:00
JST	Japan Standard Time	GMT+9:00
ACT	Australia Central Time	GMT+9:30
AET	Australia Eastern Time	GMT+10:00
SST	Solomon Standard Time	GMT+11:00

Name	Description	Relative to GMT
NST	New Zealand Standard Time	GMT+12:00
MIT	Midway Islands Time	GMT-11:00
HST	Hawaii Standard Time	GMT-10:00
AST	Alaska Standard Time	GMT-9:00
PST	Pacific Standard Time	GMT-8:00
PNT	Phoenix Standard Time	GMT-7:00
MST	Mountain Standard Time	GMT-7:00
CST	Central Standard Time	GMT-6:00
EST	Eastern Standard Time	GMT-5:00
IET	Indiana Eastern Standard Time	GMT-5:00
PRT	Puerto Rico and US Virgin Islands Time	GMT-4:00
CNT	Canada Newfoundland Time	GMT-3:30
AGT	Argentina Standard Time	GMT-3:00
BET	Brazil Eastern Time	GMT-3:00
CAT	Central African Time	GMT-1:00

- On the DST Selection screen, type the number that corresponds to the Daylight Saving Time (DST) value that you want to choose and press `Enter`, as shown in the following figure.

```
DST Selection
1) [DST=YES] (GMT-04:00) Atlantic Time (Canada)
2) [DST=NO] (GMT-04:00) Georgetown, La Paz, San Juan
3) [DST=YES] (GMT-04:00) Manaus
4) [DST=YES] (GMT-04:00) Santiago
Select (0,1-4):1
```

Figure 22: DST Selection screen

- Review the configuration information on the Network Configuration Validation screen. Type `Y` to confirm the data, and press `Enter`.

OR

Type `N` and press `Enter` to reenter the configuration information, as shown in the following figure.

```
Network Configuration Validation
-----
      ELAN IP Address: 10.2.115.101
      ELAN Gateway IP Address: 10.2.115.1
      ELAN Netmask: 255.255.255.0

      Hostname: sys219
      Fully Qualified Domain Name: sys219.canada.com

      TLAN IP Address : 10.2.110.201
      TLAN Gateway IP Address: 10.2.110.1
      TLAN Netmask: 255.255.255.0

      Enable Tlan IPv6: 0

      Default Gateway: 10.2.110.1

      Timezone: [DST=YES] (GMT-04:00) Atlantic Time (Canada)

Is this information correct (Y/N) [Y]?
```

Figure 23: Configuration Validation screen

13. On the Network Time Protocol (NTP) Configuration screen, press `Enter`, as shown in the following figure.

```
Network Time Protocol (NTP) Configuration
-----
NTP settings will be automatically set to default:
Clock Source: Primary
Clock Type: Internal

NTP settings can later be changed using "ntpconfig"
Press "Enter" to continue!
```

Figure 24: Network Time Protocol (NTP) Configuration screen

Note:

NTP settings can be changed after the installation is complete. To change NTP settings, see [Adding a Linux server](#) on page 84. You can also configure NTP settings using the CLI command `ntpconfig`.

14. On the, DNS Server configuration screen, type `N` and press `Enter` as you do not want to configure the Primary DNS server IP address if there are no active DNS servers present, as shown in the following figure.

```

DNS Server Configuration
-----
Do you wish to configure the Primary DNS Server IP Address (Y/N) [N]?

```

Figure 25: DNS Server Configuration screen

⚠ Warning:

Do not configure the DNS IP addresses when no active DNS server is present on the network as you can experience delays in the GUI operations. Use Base Manager to add at a later time.

15. On the DNS Configuration Validation screen, type `Y` and press `Enter` to confirm the configuration.

OR

Type `N` and press `Enter` if the configuration information is not correct.

```

DNS Configuration Validation
-----
Primary DNS Server IP Address: not configured
Secondary DNS Server IP Address: not configured
Is this information correct (Y/N) [Y]?

```

Figure 26: DNS Configuration Validation screen

16. On the Date and Time Configuration screen, type `Y` and press `Enter` to confirm the date and time.

OR

Type `N` and press `Enter` if the configuration information is not correct.

```

Date and Time Configuration
-----
Current Date and Time: 12:30:18 2/20/2008
Do you want to keep this date and time (Y/N) [Y]? _

```

Figure 27: Date and Time Configuration screen

17. On the Password Configuration screen for the local server account, type a root password and retype the root password, as shown in the following figure.

```
Password Configuration
-----
For security reasons, password entry keystrokes will not be shown as they
are typed. Please ensure you type the correct password and remember it for
future reference. Once the installation is started, you will not be prompted
for the password again.

Please note that a valid password must contain at least 8 characters,
6 of which are UNIQUE from all 4 character classes (lowercase, uppercase,
digits, other characters) to be considered valid.
Your password should not contain words from any dictionary in any
language or jargon, and should not be based on any personal
or login information.

Press ENTER to continue...

Changing password for user root.

You can now choose the new password.

A valid password should be a mix of upper and lower case letters,
digits, and other characters. You can use an 8 character long
password with characters from all of these classes. An upper
case letter that begins the password and a digit that ends it do
not count towards the number of character classes used.

Enter new password:
Re-type new password:
```

Figure 28: root Password Configuration screen

Note:

For information about passwords, see [Password creation guidelines](#) on page 34.

18. On the admin2 Password Configuration screen, type the admin2 password and retype the admin2 password, as shown in the following figure.

```

Password Configuration
-----
For security reasons, password entry keystrokes will not be shown as they
are typed. Please ensure you type the correct password and remember it for
future reference. Once the installation is started, you will not be prompted
for the password again.

Please note that a valid password must contain at least 8 characters,
6 of which are UNIQUE from all 4 character classes (lowercase, uppercase,
digits, other characters) to be considered valid.
Your password should not contain words from any dictionary in any
language or jargon, and should not be based on any personal
or login information.

Press ENTER to continue...

Changing password for user admin2.

You can now choose the new password.

A valid password should be a mix of upper and lower case letters,
digits, and other characters. You can use an 8 character long
password with characters from all of these classes. An upper
case letter that begins the password and a digit that ends it do
not count towards the number of character classes used.

Enter new password:
Re-type new password:

```

Figure 29: Password Configuration screen

19. On the Deployment Server screen, type `Y` if you wish to configure this system as the Deployment Server (Primary security server)

OR

Type `N` for Member and Backup servers, as shown in the following figure. Press Enter.

Continue to the next step to confirm that the Deployment Server is the Primary security server.

20. If you select `Y` in the previous step, you are prompted to type `Y` at the Continue configuration as the Deployment Server (Y/N) [N] prompt, as shown in the following figure.

```

Deployment Server
-----
Do you wish to configure this system as the Deployment Server (Y/N) [N]? y
As a Deployment Server, it must be configured as a Primary Security Server.
Continue configuration as the Deployment Server (Y/N) [N]? y_

```

Figure 30: Deployment Server screen

A pre-installation status screen appears, as shown in the following figure.

```
*****
* The final phase to complete the CS 1000 Linux Base System *
* pre-installation is now in progress. *
*****
Pre Installation in progress ... (May take a few minutes!)
Please wait .....
```

Figure 31: Pre-installation status screen

```
#####
# Post System Configuration #
#####

Post system installation configuration is now being performed.

The machine will reboot once this process has completed.
Do not remove the installation media until after the system reboots.

Copying Deployment Manager image ... (May take a few minutes!)
Please wait .._
```

Figure 32: Post System Configuration screen

The Linux Hardening status displays, as shown in the following figure. This indicates that the Linux Base installation is finished.

```
Post-Installation Final Phase Started... Please wait...

#####
# Status of Linux Hardening items #
#####
audit : The Linux Audit daemon is disabled.
banners : The pre-login banners are enabled.
coredumps : The ability to create core files is permitted.
dba : Use of DBA SFTP account is forbidden.
ftp : Use of FTP service is permitted.
nettools : Network Analysis Tools are forbidden.
nfs : NFS service is not accessible.
passwd_days : Password lifetime parameters are configured.
ssh_filter : Host-based SSH filtration is disabled.
telnet : Use of Telnet service is forbidden.
tftp : Use of TFTP service is permitted.
Welcome to Red Hat Enterprise Linux Server
```

Figure 33: Post Installation Final Phase screen

The system restarts, as shown in the following figure.

```

/tmp/hda3
unmounting filesystems...
/mnt/runtime done
disabling /dev/loop1
/proc/bus/usb done
/proc done
/dev/pts done
/sys done
/tmp/ramfs done
/tmp/cf done
/mnt/sysimage/home done
/mnt/sysimage/opt done
/mnt/sysimage/admin done
/mnt/sysimage/tmp done
/mnt/sysimage/var/coredump done
/mnt/sysimage/var/log done
/mnt/sysimage/var done
/mnt/sysimage/boot done
/mnt/sysimage/sys done
/mnt/sysimage/proc done
/mnt/sysimage/dev done
/mnt/sysimage done
rebooting system
-

```

Figure 34: System restart screen

⚠ Warning:

For COTS servers, make sure that the installation DVD ejects. If the installation DVD does not eject automatically, eject the DVD manually.

21. Remove installation media and insert backup media.
22. For CP PM server cards, do not press F when prompted, as shown in the following figure.

⚠ Caution:

Do not press F at this step; otherwise, you are taken back to the installation menu and must perform the procedures again.

```

+-----+
|                System BIOS Configuration, (C) 2005 General Software, Inc.                |
+-----+
| System CPU       : Pentium M      | Low Memory       : 632KB      |
| Coprocessor     : Enabled        | Extended Memory  : 2035MB     |
| Ide 0 Type      : 3              | Serial Ports 1-2 : 03F8 02F8    |
| Ide 1 Type      : 3              | ROM Shadowing    : Enabled    |
| Ide 2 Type      : 3              | BIOS Version     : NTDU74AA 18 |
+-----+
| Press F to force board to boot from faceplate drive.                               |
|....._|

```

Figure 35: CP PM screen

23. On the Avaya Linux Base screen, type the admin2 userid at the login prompt, and type the admin2 password, as shown in the following figure. This can take several minutes before you can proceed to the next step.

```
Avaya Inc. Linux Base 7.50
The software and data stored on this system are the property of,
or licensed to, Avaya Inc. and are lawfully available only
to authorized users for approved purposes. Unauthorized access
to any software or data on this system is strictly prohibited and
punishable under appropriate laws. If you are not an authorized
user then do not try to login. This system may be monitored for
operational purposes at any time.

cores2.ca .avaya .com login: admin2
Password:
```

Figure 36: Avaya Linux Base screen

24. Start a Web browser to configure the primary security server. For more information about configuring a primary security server, see [Configuring the primary security server](#) on page 71.

Chapter 6: Deployment Manager—New system installation and commissioning

This chapter provides the procedures for an end-to-end installation and commissioning of Linux Base and applications. At this stage, Linux Base must be installed on the Primary security server (Deployment Server) but it is not configured.

Navigation

- [Installation workflow](#) on page 69
- [Primary security server configuration](#) on page 70
- [Deployment Manager—Server preconfiguration](#) on page 75
- [6.0 Deployment Targets](#) on page 112
- [NFS based new installation](#) on page 117

Installation workflow

The following figure provides an overall workflow for a new Avaya Communication Server 1000 (Avaya CS 1000) system Linux installation and commissioning. The workflow indicates the recommended sequence of events to follow and provides the technical document number for the detailed procedures required for the task.




Figure 37: New Linux system installation workflow

Primary security server configuration

This section provides the procedures for configuring the primary security server. For more information about security server configuration, see [Configuring the primary security server](#) on

page 71 or *Avaya Unified Communications Management Common Services Fundamentals*, NN43001-116.

Configuring the primary security server

Configure the primary security server.

1. In the Web browser Address bar, type `https://<FQDN or IP address>/local-login/` of the primary security server, enter the UserID and password as configured during the Linux Base installation, Password Configuration step and press **Enter**.
2. On the Security Configuration page, select **Full security configuration**, as shown in the following figure.




Figure 38: Security configuration page

3. Click **Security Configuration**.

The FQDN validation page appears, as shown in the following figure.



4. Confirm the IP address and FQDN is correct, and click **Next**.

Important:

If using a DNS server, the DNS server must be configured before proceeding.

5. On the Select server type page, select **Primary security server**, and click **Next**.




Figure 39: Select server type page

6. On the Enter server information page, type the Administrator password for the built-in Admin account, and retype the password in the **Confirm Administrator** password field, and click **Next**, as shown in the following figure.

Managing: sys219.canada.com
Security Configuration

Security Configuration

Step 3: Enter server information.

Server Information

The information in the fields below are for the "admin" account.

Note: The "admin" account is the default full-privilege account for administration. Immediately after this initial security configuration, it is the only user ID that can be used to create individual administrative user accounts and complete remaining network and policy configuration tasks (the OS account you are currently using is for local server configuration only).

User ID:

Administrator password: *

Confirm Administrator password: *

Allowed characters: a-zA-Z0-9()!/_-[]^_*@#
The password must have at least 8 characters including:
1 lowercase, 1 uppercase, 1 numeric and 1 special characters.

* Required value.

Figure 40: Server Information page

7. On the Enter Certificate information page, configure the following values and then click **Finish**.

Friendly name: Type a string that would be used to identify the certificate, for example, UCM Primary Security Server.

Bit length: Type a value that represents the number of bits used for encryption. Values can be 512, 1024, and 2048. More CPU is required for processing as the bit value increases.

Organization: Your company name.

Organization unit: A division within your company.

Common name: FQDN of the server. The default is a combination of Windows environment variables Computername and Userdnsdomain. Ensure this field matches the hostname of the system the certificate is on.

Country/Region: Select a country from the list.

State/Province: A State/Province where the primary server is located.

City/Locality: A City/Locality where the primary server is located.

Managing: sys219.canada.com
Security Configuration

Security Configuration

Step 4: Enter certificate information.

Certificate Information
The certificate information used to create the certificate that is used to secure web traffic.

Friendly name: *

Bit length: *

Organization: *

Organizational unit: *

Common name: *

Country/Region: *

State/Province: *

City/Locality: *

* Required value.

Figure 41: Certificate Information page

8. On the Security server configuration progress page, click **Restart** to restart the Web server and the security configuration changes to take effect.

Managing: sys219.canada.com
Security Configuration

Security Configuration Progress

Security server configuration progress:

Installing private certificate authority and certificate: Completed
Configuring Common Network Directory: Completed

The fingerprint of the primary security server is :

11:ba:e1:cfa4:c3:c3:04:e6:8c:40:14:e9:43:2e:c3

This fingerprint will be required when installing other servers

To complete configuration please click on the Restart button to restart the web server. Wait a few minutes to allow the web server to startup, then login again.

Figure 42: Security server configuration progress page

The Restarting the server Web page appears.

9. Close the Web browser and proceed to [Deployment Manager—Server preconfiguration](#) on page 75.

Important:

Wait several minutes after configuring the primary security server before logging on to UCM.

Deployment Manager—Server preconfiguration

You have installed Linux Base on your primary security server (Deployment Server). You can now begin the preconfiguration stage to logically configure the member and backup servers before physically installing the Servers and joining them to the domain. Proceed to [Preconfiguring process using Deployment View](#) on page 75.

Prerequisites

- The latest software release of Linux Base must be running on your primary security server (Deployment Server), see [Installing a new Linux Base](#) on page 54 or [Upgrading Linux Base](#) on page 123.
- You must have all the configuration details prepared before you begin preconfiguring the Primary, Member, and Backup servers using Deployment Manager.
- You must be able to log on to UCM. For more information, see [Logging on to Unified Communications Management](#) on page 78.

The primary security server must be configured. For more information, see [Configuring the primary security server](#) on page 71.

- Must be able to access Deployment Manager. For more information, see [Accessing Deployment Manager](#) on page 78.
- Ensure your hardware is a COTS, CP PM, CP MG, or CP DC.
- For Internet Explorer 8. You must update the compatibility view setting if using the tree view structure. For more information, see [Internet Explorer](#) on page 44.

Preconfiguring process using Deployment View

Use the following procedure to guide you through the process of configuring your member and backup servers. This is the Avaya recommended method.

Note:

Your servers do not have to be physically connected at this stage.

1. Log on to the UCM primary security server with the account that has the NetworkAdministrator role assigned.
2. On the navigation pane, click **Network, Software Deployment**.

The Deployment View page appears, as shown in [Figure 43: Deployment View commit screen](#) on page 77.

3. On the navigation pane, click **Software Loads**.
4. Select the required .nai files to upload to the deployment server library. For detailed procedures, see [Adding a software load from the Client Machine](#) on page 80.

Important:

You can upload only one version of each load type. All deployed servers use the same load version.

5. Add the backup and member Linux servers. For detailed procedures, see [Adding a Linux server](#) on page 84. If your servers have joined the security domain, proceed to [Step 7](#) on page 76; otherwise, continue to the next step to add the VxWorks Call Servers to your network.

Important:

The server does not need to be physically installed at this step. The configuration details are only required.

A Linux Base element is created in UCM and the element name is visible from the default Deployment View or UCM Elements page.

Important:

On the Deployment view page, the Linux Base version does not appear under the Base Version field and the Status field is identified as Preconfigured. The server is still a logical server at this point. After you physically install the server, the Base Version and Status fields show the new version number and Configured status.

6. Add the VxWorks Call Servers to your network, as described in [Adding a VxWorks Call Server](#) on page 90 or [Adding a VxWorks Call Server for a High Availability system](#) on page 90.

Note:

If your VxWorks Call Server has joined the security domain, proceed to the next step.

An active VxWorks Call Server element appears on the Deployment View page. For HA systems, an inactive VxWorks Call Server also appears on the Deployment View page.

Important:

The servers are not physically installed or registered to the security domain at this stage.

7. Allocate the servers into the hierarchical groups which determines the application packages required for deployment.

The servers can be allocated into the following groups:

- Network Services: for detailed procedures, see the following:
 - [Adding a MAS service](#) on page 91
 - [Adding a Network Routing Service](#) on page 92
 - [Adding a Subscriber Manager service](#) on page 93
 - [Adding a SIP Trunk Bridge](#) on page 94

- Avaya CS 1000 systems: for detailed procedures, see the following:
 - [Adding a CS 1000 system](#) on page 96
 - [Defining a new CS 1000 High Scalability system](#) on page 101

On the Deployment view page, the Status field changes from Preconfigured to Predeployed to identify that the server is now part of one or more groups. The Predeployed Applications field shows the applications that correspond to the selected services.

8. On the Deployment View page, choose Servers from the **View** list, and click **Commit**, as shown in the following figure.

Important:

The Commit button is a system wide operation. All servers in the Predeployed status are committed.

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Deployment View Print | Refresh

Linux Server Deployment Actions View: Servers

Host Name ^	Address	Type	Status	Predeployed Applications	Base Version
<input type="radio"/> 192.168.209.115(Active)	192.168.209.115	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.116(Active)	192.168.209.116	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.117 (Inactive)	192.168.209.117	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.55.118(Active)	192.168.55.118	VxCS	Preconfigured	N/A	
<input type="radio"/> hpss7.us.avaya.com (member)	192.168.55.150	Linux	Committed	CS1000HS-EM	
<input type="radio"/> ibmss10.us.avaya.com (primary)	192.168.55.178	Linux	Committed	SubM, NRS, EM, SS	7.50.07
<input type="radio"/> test1.us.avaya.com (member)	192.168.55.190	Linux	Committed	EM, SS, NRS	
<input type="radio"/> test2.us.avaya.com (member)	192.168.55.211	Linux	Preconfigured	None	

NFS status: enabled

Servers that are already deployed with specified applications, and need to be configured into systems.
 Servers which have only Linux base applications installed.

Note: All servers have to be in the committed state for further deployment operations.
 Undeploy option will only be available for servers that are not part of any network services or CS1000 systems.

Figure 43: Deployment View commit screen

The Deployment View status is updated to Committed and the Linux servers are now ready for installation and deployment.

9. Install the VxWorks Call Servers and join the security domain, if not already done.
10. You must now physically connect the member and backup servers. If Linux Base for the backup and member servers is not installed, proceed to [NFS based new installation](#) on page 117 or if Linux Base is already installed from installation media and security is configured, proceed to [Deploying applications on a Server](#) on page 107.

Logging on to Unified Communications Management

Access UCM for application deployment using Deployment Manager.

1. Open the Web browser.
2. Enter one of the following in the Address bar:
 - Fully Qualified Domain Name (FQDN) for the UCM server (preferred). For example, `https://<FQDN>`.
 - Unified Communications Management (UCM) framework IP address. After you enter the UCM framework IP address, a Web page appears stating that you must access Unified Communications Management by using the FQDN for the UCM server. Click the link on this Web page to use the FQDN for the UCM server.
3. In the **User ID** field, log on using the admin2 account.
4. In the **Password** field, enter your password.
5. Click **Log In**.

The default navigation Web page for UCM appears.

Accessing Deployment Manager

Access Deployment Manager from UCM.

1. Log on to UCM. See [Logging on to Unified Communications Management](#) on page 78.
2. In the navigation pane, click **Network, Software Deployment**.
3. Validation is performed. If you are logging on for the first time or your credentials have changed, you are prompted for the **Primary Security server user ID** and **Primary Security server password**, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

User Information

Primary Server User Configuration

Please provide the details of the user account which has enough permissions for registering the backup and member server in UCM security domain. This details will be saved in Deployment manager and will not be prompted until the provided user account exists and the password is not expired.

Primary Security server user ID: *

Primary Security server password: *

Please make sure you have a valid user configured in UCM security domain with required permissions. If it does not exist please go back to UCM and create a new account before launching Deployment manager.

* Required value.

Figure 44: Deployment Manager validation

4. Click **Save**.

Software loads

This section describes how to upload software to Deployment Manager for predeployment. For an overview about software loads, see [Software loads](#) on page 45.

Note:

If you are using Deployment Manager on your Deployment Server as your unified solution for end-to-end installation and configuration of Linux Base and applications, you must use the process as described in [Preconfiguring process using Deployment View](#) on page 75.

Prerequisites

- Upload the appropriate .nai file (Avaya Communication Server 1000 or MAS) from the software download site to the server running Deployment Manager.
- Collect your network setup information.
- Must be logged on to the UCM Primary security server using the Admin account. For more information, see [Logging on to Unified Communications Management](#) on page 78.
- Must have accessed the Software Deployment section from UCM. For more information, see [Accessing Deployment Manager](#) on page 78.
- To avoid a session timeout when adding a software load from a client machine, increase the maximum idle time to 120 minutes on System Manager.
 - a. Log on to SMGR, and click **UCM Services**.
 - b. On the navigation tree, click **Security > Policies**.
 - c. Click the **Session Properties** tab, and click **Edit**.
 - d. Change the **Maximum Idle time** to 120, and click **Save**.

Adding a software load from the Deployment Server

Add a software load from the Deployment Server for predeployment.

1. Click **Software Loads** from the **Deployment Manager** navigation tree.

The Software Loads screen appears, as shown in the following figure.




Figure 45: Software Loads screen

2. In the **Select software load location** list, select **Deployment Server**.
3. In the **Select media** list, the choices presented to you are determined by the hardware type for the Deployment Manager.

- CP DC and CP MG servers: USB Device
- CP PM: USB and Compact Flash
- COTS: USB and CD/DVD-ROM

4. Click **Browse** to locate the software load.

A warning screen appears to ensure that you insert the correct software media on the deployment server or that you upload the correct software to the Deployment Manager Library.

5. Click **Add Load**.

An upload progress screen appears.

6. The Software Loads screen appears when the upload is complete.

Adding a software load from the Client Machine

Perform the following procedure to add a software load from a client machine.

1. Click **Software Loads** from the **Deployment Manager** navigation tree.

The Software Loads screen appears, as shown in the following figure.




Figure 46: Software Loads screen for Client Machine

2. In the **Select software load location** list, select **Client Machine**.
3. In the **Specify software load file** field, click **Browse** to locate the software load on the client machine.

The Add Load button is now available.

4. Click **Add Load**.

The upload progress screen appears.

5. The Software Loads screen appears when the upload is complete.

Deleting a software load

Delete a software load.

1. Click **Software Loads** from the **Deployment Manager** navigation tree.

The Software Loads screen appears, as shown in [Figure 45: Software Loads screen](#) on page 80.

2. Select the check box beside the software load to delete.

The Delete button is now available for you to select.

3. Click **Delete**.

NFS security hardening

Every Primary security server (deployment server) must have the Network File System (NFS) enabled when you deploy the Linux Base and applications to the target servers. By enabling NFS, the server can be an NFS server. Avaya recommends that you disable NFS upon completing the transfer of the Linux Base and application software to the target server. You cannot enable NFS on the member or backup security servers. For information about CLI commands for harden nfs, see [Table 20: securityadmin CLI commands](#) on page 252.

Enabling or disabling NFS from Deployment Manager

Enable or disable NFS on the Primary security server. The default state is enabled.

Prerequisites

- Must be able to access Deployment Manager. For more information, see [Accessing Deployment Manager](#) on page 78.

Procedure steps

1. On the **Deployment View** page, choose **Servers** from the **View** list.
2. In the **NFS status** section, click **Enable** to enable NFS.

The NFS status is refreshed to show the status as enabled, as shown in the following figure.

The screenshot shows the 'Deployment View' page in the Deployment Manager. At the top, it says 'Managing: DEPLOYMENT MANAGER' and 'Software Version: 7.5'. Below this is a table of servers with columns for Host Name, Address, Type, Status, Predeployed Applications, and Base Version. The table contains several rows, including VxCS and Linux servers. Below the table, there is a section for 'NFS status: enabled' with a 'Disable' button. A legend below explains the server status indicators: a blue square for servers already deployed with specified applications, and a green square for servers with only Linux base applications installed. A note states: 'Note: All servers have to be in the committed state for further deployment operations. Undeploy option will only be available for servers that are not part of any network services or CS1000 systems.'

Host Name	Address	Type	Status	Predeployed Applications	Base Version
192.168.209.115(Active)	192.168.209.115	VxCS	Preconfigured	N/A	
192.168.209.116(Active)	192.168.209.116	VxCS	Preconfigured	N/A	
192.168.209.117 (Inactive)	192.168.209.117	VxCS	Preconfigured	N/A	
192.168.55.118(Active)	192.168.55.118	VxCS	Preconfigured	N/A	
hpss7.us.avaya.com (member)	192.168.55.150	Linux	Committed	CS1000HS-EM	
ibmss10.us.avaya.com (primary)	192.168.55.178	Linux	Committed	SubM, NRS, EM, SS	7.50.07
test1.us.avaya.com (member)	192.168.55.190	Linux	Committed	EM, SS, NRS	

NFS status: enabled

■ Servers that are already deployed with specified applications, and need to be configured into systems.
■ Servers which have only Linux base applications installed.

Note: All servers have to be in the committed state for further deployment operations.
 Undeploy option will only be available for servers that are not part of any network services or CS1000 systems.

Figure 47: NFS status enabled

OR

Click **Disable** to disable NFS after the Linux Base and applications are deployed to the server.

Important:

The current state of NFS is displayed in the NFS status section on the Deployment View, Servers page.

Deployment View

This section describes how to add servers, Network Services, and Avaya CS 1000 systems, and commit the software for deployment.

Note:

If you are using Deployment Manager on your Deployment Server as your unified solution for end-to-end installation and configuration of Linux Base and applications, you must use the process as described in [Preconfiguring process using Deployment View](#) on page 75.

From UCM, you can access the Deployment View page by clicking Software Deployment, UCM Deployment Manager. For an overview of the Deployment View page, see [Deployment View](#) on page 42.

From Deployment View, you can access the following:

- [Servers](#) on page 83
- [Network Services](#) on page 91
- [CS 1000 systems](#) on page 96

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Deployment View Print | Refresh

Linux Server Deployment Actions View: Servers

Host Name	Address	Type	Status	Predeployed Applications	Base Version
<input type="radio"/> 192.168.209.115(Active)	192.168.209.115	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.116(Active)	192.168.209.116	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.117 (Inactive)	192.168.209.117	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.55.118(Active)	192.168.55.118	VxCS	Preconfigured	N/A	
<input type="radio"/> hpss7.us.avaya.com (member)	192.168.55.150	Linux	Committed	CS1000HS-EM	
<input type="radio"/> ibmss10.us.avaya.com (primary)	192.168.55.178	Linux	Committed	SubM, NRS, EM, SS	7.50.07
<input type="radio"/> test1.us.avaya.com (member)	192.168.55.190	Linux	Committed	EM, SS, NRS	
<input type="radio"/> test2.us.avaya.com (member)	192.168.55.211	Linux	Preconfigured	None	

NFS status: enabled

Servers that are already deployed with specified applications, and need to be configured into systems.
 Servers which have only Linux base applications installed.

Note: All servers have to be in the committed state for further deployment operations.
 Undeploy option will only be available for servers that are not part of any network services or CS1000 systems.

Figure 48: Deployment View page

Servers

This section describes how to add and remove Linux Servers and VxWorks Call Servers.

Navigation:

- [Adding a Linux server](#) on page 84
- [Configuring the clock source for a Primary server](#) on page 88
- [Configuring the clock source for a secondary server](#) on page 89
- [Configuring a server that is not a clock server](#) on page 89
- [Deleting a Linux server](#) on page 89
- [Adding a VxWorks Call Server for a High Availability system](#) on page 90
- [Adding a VxWorks Call Server](#) on page 90
- [Deleting a VxWorks Call Server](#) on page 91

Adding a Linux server

Add a Linux server to Deployment Manager.

1. On the **Deployment View** page, select **Linux Server** from the list, and click **Add**, as shown in [Figure 48: Deployment View page](#) on page 83.

The Enter the network parameters, such as ELAN/TLAN IP addresses, hostname and domain screen appears, as shown in the following figure.

2. In the **Embedded LAN (ELAN)** section, type the IP address, Gateway, and Netmask.

In the **Fully qualified domain name (FQDN)** section, type the Host name and Domain.

Figure 49: Add a server

3. In the **Telephony LAN (TLAN)** section, select the TLAN address type **IPv4 only**.

OR

IPv4 and IPv6.

If you choose only IPv4, type the IPv4 IP address, Gateway, and Netmask.

OR

If IPv4 and IPv6 is chosen, you must also type the IPv6 address and IPv6 gateway, as shown in the previous figure.

4. Click **Next**.

The Enter the DNS parameters, such as primary/secondary DNS servers IP addresses page appears.

5. In the **Primary** section, type the Primary DNS IP Address .

In the **Secondary** section, type the Secondary DNS IP Address, and click **Next**.

The Enter NTP related information and time zone page appears, as shown in the following figure.

Figure 50: Enter NTP related information page

6. In the **Time Zone** section, choose the time zone setting for this server.

7. In the **Network Time Protocol** section, select the Transfer mode as **Secure** or **Insecure**.

Important:

If the Insecure option is selected, the Key ID and Private key fields are dimmed and cannot be changed.

8. If you select the Secure option:

In the **Key ID** field, enter a value for key ID.

In the **Private key** field, enter a value for private key.

In the **Confirm private key** field, enter the private key value again.

Important:

The Private key must not exceed 16 characters. The pound (#) symbol, single quotation marks ('), and spaces are not accepted in the string.

9. In the **Clock Source** section, choose one of the following from the **NTP server type** list:

- Primary server
- Secondary server
- Not a clock server

10. Enter the **External clock source IP Address** and click **Add**.

11. Click **Next**.

12. If you select **Primary server** from the NTP server type list, see [Configuring the clock source for a Primary server](#) on page 88.

If you select **Secondary server** from the NTP server type list, see [Configuring the clock source for a secondary server](#) on page 89.

If you select **Not a clock server** from the NTP server type list, see [Configuring a server that is not a clock server](#) on page 89.

The Enter passwords, hardware type and other base related information page appears.

13. In the **Hardware type** list, choose one of the following:

- CPDC
- CPPM
- Dell R300
- HP DL320G4
- HP DL360G7
- IBM X306M
- IBM X3350

14. In the **avaya password** field, type the Avaya password and then confirm the password in the **confirm avaya password** field.
15. In the **root password** field, type the root password and then confirm the root password in the **confirm root password** field.
16. Click **Next**.

The Select server type for the Security Configuration page appears.

17. Click **Member server** or **Backup security server** as the Server Type.
18. Click **Next**.

The Verify primary security server fingerprint page appears, as shown in the following figure.

The screenshot shows a web interface for 'Managing Test.test2.ca.avaya.com' with the title 'Security Configuration'. The current step is 'Step 2: Verify primary security server fingerprint.' The page displays the following information:

- Address of the Primary security server : **47.11.44.178:443**
- Fully Qualified Domain Name (FQDN) of the Primary security server : **Innov-r44178.ca.avaya.com:443**
- The fingerprint of the primary security server is : **c0:a0:53:55:79:7f:f9:76:59:10:c8:c3:a9:97:58:e5**

Below this information, there is a text block: 'This should match the fingerprint that you have obtained. If so, enter the corresponding credentials of a user with the below role on the primary security server, then click on Next. Backup server registration : Network Administrator role. Member server registration : Network Administrator or Member Registrar role.'

At the bottom, there are two input fields: 'Primary Security server user ID:' and 'Primary Security server password:'. Below these fields, there are three buttons: 'Back', 'Next', and 'Cancel'. A 'Required value.' label is positioned to the left of the 'Back' button.

Figure 51: Verify primary security server fingerprint

19. Type the **Primary Security server user ID** and **Primary Security server password**.

Important:

The primary security server user ID and password is requested only for the first server configured. If you add additional servers, the values are filled in automatically.

20. Click **Next**.

The Enter certificate information page appears.

21. Confirm the Certificate Information, and click **Finish**.

A Linux Base element is created in UCM and the element name is visible from the default Deployment View and UCM Elements page.

Important:

The Linux Base version does not appear in the Base Version field and the Status field is identified as Preconfigured. The server is still a logical server at this point. After you physically install the server, the Base Version and Status fields show the new version number and Configured status.

22. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Configuring the clock source for a Primary server

Configure the clock source for a Primary server.

Prerequisites:

You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps:

1. Perform Steps [1](#) on page 84 to [9](#) on page 86 in [Adding a Linux server](#) on page 84.
2. In the **Clock Source** section, type an IP address for the external clock source in the **External clock source IP address** field, and click **Add**, as shown in the following figure.




Figure 52: Clock source screen

3. Enter additional external clock sources as required, and click **Add**.

Important:

You can add up to 10 external clock sources in order of priority.

4. Click **Next**.
5. Proceed to [13](#) on page 86 in [Adding a Linux server](#) on page 84

Configuring the clock source for a secondary server

Configure the clock source for a secondary server.

1. Perform Steps [1](#) on page 84 to [9](#) on page 86 in [Adding a Linux server](#) on page 84.

Upon choosing Secondary Server, the page refreshes to show Primary NTP server IP address.

2. In the **Primary NTP server IP address** field, type a value for the IP address of the Primary NTP server.
3. In the type of clock source field, select **Internal** and proceed to [13](#) on page 86 in [Adding a Linux server](#) on page 84 to continue the configuration.

OR

In the type of clock source list, select **External**.

The Add a Server page is refreshed.

4. Proceed to [13](#) on page 86 in [Adding a Linux server](#) on page 84.

Configuring a server that is not a clock server

Configure a server that is not a clock server.

1. Perform Steps [1](#) on page 84 to [9](#) on page 86 in [Adding a Linux server](#) on page 84.

Upon choosing Not a clock server, the page refreshes to show Primary and Secondary NTP server IP address fields.

2. In the **Primary NTP server IP address** field, type a value for the IP address of the Primary NTP server.
3. In the **Secondary NTP server IP address** field, type a value for the IP address of the Secondary NTP server. Use of a Secondary NTP server is optional.
4. Click **Next**.
5. Proceed to Step [13](#) on page 86 in [Adding a Linux server](#) on page 84.

Deleting a Linux server

Delete a Linux server.

Prerequisites

- Ensure the Linux server is not a Primary Security Server.
- Ensure the Linux server is not a member of a group.
- Log on to UCM. See [Logging on to Unified Communications Management](#) on page 78.
- Access Deployment Manager. See [Accessing Deployment Manager](#) on page 78.

Procedure steps

Important:

You cannot delete the server if it is a Primary Security Server or a member of a group.

1. On the Deployment View page, choose **Servers** from the **View** list on the right of the page.
2. Click the option button beside the Host Name of the server to delete.
3. Click **Delete**.
A confirmation dialog box appears.
4. Click **Yes** to delete the server.
5. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Adding a VxWorks Call Server for a High Availability system

If your VxWorks Call Server is not registered, add a VxWorks Call Server to the Deployment Manager to create an active and inactive VxWorks Call Server for a High Availability system.

1. On the **Deployment View** page, select **VxWorks Call Server** from the list, and click **Add**.
The Enter Call Server details page appears.
2. Select the **High Availability System** check box.
3. In the **Active call server ELAN IP** field, enter the ELAN IP address for the Active Call Server.
4. In the **Inactive call server ELAN IP** field, enter the ELAN IP address for the Inactive Call Server.
5. Click Finish.

The Deployment View page appears with the active and inactive VxWorks Call Servers added.

6. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Important:

You must register the Call Server after it is up and running.

Adding a VxWorks Call Server

Add an active VxWorks Call Server to the Deployment Manager.

1. On the **Deployment View** page, select **VxWorks Call Server** from the list, and click **Add**.

The Enter Call Server details page appears.

2. In the **Active call server ELAN IP** field, enter the ELAN IP address for the Active Call Server.
3. Click **Finish**.

The Deployment View page appears with the active VxWorks Call Servers added.

4. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Deleting a VxWorks Call Server

Delete a VxWorks server.

Prerequisites

- Ensure the VxWorks server is not a member of a group.
- Ensure the server is not an inactive Call Server of a High Availability (HA) system.
- Log on to UCM. See [Logging on to Unified Communications Management](#) on page 78.
- Access Deployment Manager. See [Accessing Deployment Manager](#) on page 78.

Procedure steps

1. On the **Deployment View** page, select **Servers** from the **View** list on the right of the page.
2. Click the option button beside the active server to delete.

Important:

Deleting the active Call Server for a High Availability system also deletes the inactive Call Server.

3. Click **Delete**.
A confirmation dialog box appears.
4. Click **Yes** to delete the server.

Network Services

This section contains procedures to view, add, or delete NRS, MAS, Subscriber Manager, and SIP Trunk Bridge.

Adding a MAS service

Add Media Application Server (MAS) as a network service. For more information about MAS, see the following documents.

- *Avaya Media Application Server Commissioning, NN44471-301*
- *Avaya Media Application Server Upgrades and Patches, NN44471-400*

- *Avaya Media Application Server Administration and Security, NN44471-600*
- *Avaya Media Application Server Administration Application Management, NN44471-601*
- *Avaya Media Application Server Fault Management, NN44471-700*
- *Avaya Media Application Server VoiceXML and CCXML Application Programming, NN44471-501*

Prerequisites:

- You must first upload the MAS software load. See [Software loads](#) on page 79.
- Ensure your hardware is a COTS2, Common Server, or CP DC.

Procedure steps:

1. On the **Deployment View** page, choose **Network Services** from the **View** list.
2. Choose **MAS** from the list, and click **Add**.

The Enter a name and a description for the service page appears.

3. In the **Name** field, enter a service name.
4. In the **Description** field, enter a description.
5. Click **Next**.

The Choose the Server for the selected Network Service page appears.

6. In the **Server** field, choose a Server from the list, and click **Next**.

The Pre-configuration for MAS server page appears.

7. Click **Browse** to choose a keycode file, and click **Validate**.

OR

Use MAS Element Manager to choose a keycode file at a later time.

8. Click **Finish**.

The Deployment view page appears with a tree view of the MAS server association. The MAS server is now a member of the primary security server.

9. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Adding a Network Routing Service

Add a Network Routing Service (NRS) from the Deployment View page.

Prerequisites:

- You must first upload the CS 1000 application software load. See [Software loads](#) on page 79.

Procedure steps:

1. On the **Deployment View** page, and choose **Network Services** from the **View** list.
2. Choose **NRS** from the list, and click **Add**, as shown in [Figure 53: NRS](#) on page 93.

The Enter a name and a description for the service page appears.

3. In the **Name** field, enter a service name.
4. In the **Description** field, enter a description.
5. Click **Next**.

The Choose the primary and secondary NRS servers page appears.

6. In the **Primary NRS Server** field, choose a server from the list.
7. In the **Secondary NRS Server** field, choose a server from the list.
8. Click **Finish**.

The Deployment view page appears with a tree view of the NRS server association. The primary and secondary NRS servers are now members of the NRS group, as shown in the following figure.




Figure 53: NRS

9. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Adding a Subscriber Manager service

Add a Subscriber Manager service from the Deployment View.

Prerequisites:

- You must first upload the CS 1000 application software load. See [Software loads](#) on page 79.

Procedure steps:

1. On the **Deployment View** page, and choose **Network Services** from the **View** list.

2. Choose **Subscriber Manager** from the list, and click **Add**.

The Enter a name and a description for the service page appears.

3. In the **Name** field, enter a service name.
4. In the **Description** field, enter a description.
5. Click **Next**.

The Choose the primary server page appears.

6. In the **Name** field, leave the previously entered name or type a new name.
7. In the **Server** field, choose the Primary Security server from the list.
8. Click **Finish**.

The Subscriber service is available only on the primary security server. The Subscriber group is created with the specified name and the selected server is a member of the group.

Important:

The Finish button is dimmed until you select a Primary Server. Allow several seconds for the button to be available to click.

9. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Adding a SIP Trunk Bridge

Add a SIP Trunk Bridge.

Prerequisites:

- You must first upload the CS 1000 application software load. See [Software loads](#) on page 79.

Procedure steps:

Important:

Values are required for all fields.

1. On the **Deployment View** page, choose **Network Services** from the **View** list.
2. Choose **SIP Trunk Bridge** from the list, and click **Add**.
The Enter a name and a description for the service page appears.
3. In the **Name** field, enter a cluster name (service name).
4. In the **Description** field, enter a description.
5. Click **Next**.

The Choose the SIP Trunk Bridge Cluster Servers page appears.

- In the **Cluster ID** field, choose a value from 1 to 255 from the list.

Important:

The Cluster ID must be unique for the network service; therefore, only the available Cluster IDs appear in the list.

- In the **Cluster Virtual Address** field, enter a valid IP address.

Important:

The cluster Virtual IP Address must be unique. For example, it cannot be the same as the ELAN or TLAN IP address of the Primary or Secondary server of the cluster or any IP or Virtual IP Address of any server or cluster.

- In the **Mode** field, choose a value from the list. Options are **1** for single server mode or **1+1** for redundant mode.
- In the **Server** or **Primary Server** field, choose a server from the list.
- If you select 1+1 mode, choose a Server from the **Secondary Server** field.
- Click **Finish**.

Important:

The Finish button is dimmed until you have selected one or two servers as required for the selected mode. The Cluster Virtual IP is validated only when you click Finish. If there is an error with the IP as entered, it is indicated by red text beside the entered value. In this case, you must correct the error and click Finish again to complete adding this service.

A SIP Trunk Bridge group appears with the associated primary and secondary servers as members to the group, as shown in the following figure.



Figure 54: SIP Trunk Bridge service

- To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Deleting a Network Service

You can delete any Network Service.

Note:

When you add CS 1000 or Network Services groups in Deployment Manager, the tree view of UCM updates. However, if you delete all groups from the UCM tree view it has the following impacts on Deployment Manager:

- If you delete all groups from the UCM Tree view, all groups are removed in Deployment Manager but you cannot undeploy applications.
- If you delete all groups from the UCM Tree view, System Upgrade is available in the Deployment Actions list in Deployment Manager. You can upgrade the system to a new load/release; however, the Avaya applications do not deploy.
 1. On the **Deployment View** page, choose **Network Services** from the **View** list.

The Deployment View page refreshes to show the tree.
 2. Expand the tree view by clicking the plus (+) sign.
 3. Select the check box beside the server name to delete.

The Delete button becomes available for you to click. You can select more than one service to delete.
 4. Click **Delete**.

A confirmation dialog box appears.
 5. Click **Yes** to delete.
 6. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

CS 1000 systems

The following section contains procedures for viewing, adding, or deleting CS 1000 or CS 1000 High Scalability systems.

Adding a CS 1000 system

Add a CS 1000 system.

Prerequisites:

- Ensure you add all the VxWorks servers required for your CS 1000 system, as described in [Adding a VxWorks Call Server](#) on page 90.
- Ensure you add all the Linux servers required for your CS 1000 system, as described in [Adding a Linux server](#) on page 84.
- Allocate one or two Linux servers to use for Element Manager.

Important:

After the CS 1000 server is created, the allocated Linux servers that run Element Manager cannot be changed. To change an Element Manager role running on a Linux Signaling Server, you must delete the CS 1000 system and recreate it.

Procedure steps:

1. On the Deployment View page, select **CS 1000 systems** from the **View** list, as shown in the following figure.




Figure 55: CS 1000 Deployment View screen

2. Select **CS 1000** from the list, and click **Add**.

The Enter the Call Server Information page appears, as shown in [Figure 56: Add a CS 1000 system](#) on page 98.

3. In the **CS 1000 name and description** section, enter the following:
 - **CS 1000 Name:** enter the name for the entire system you are configuring. This name appears on the top level of the hierarchical tree view.
 - **Description:** enter a description.
4. In the **Call Server and Tape ID details** section, enter the following
 - **Call Server:** choose a server name from the list.
 - **Call server tape ID:** enter the tape ID value.

Important:

If the selected server is a server that has not joined the security domain at this time, for example, a VXworks server or a Linux server that was just added, you must manually enter the tape ID. Deployment Manager automatically determines the tape ID of the Call Server application that is deployed on a Linux server when it is chosen as a Call Server.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

Add a CS1000 System

Step 1: Enter the Call Server Information.

CS1000 name and description:

CS1000 Name: *

Description:

Call Server and Tape ID details

Call Server: ▼

Call server tape ID: *

Figure 56: Add a CS 1000 system

5. Click **Next**.

The Pre-configuration for the Linux call server. Keycode uploading and validation. Language and database selection page appears.

6. In the **Select keycode location** field, select **Client Machine** from the list.

7. In the **Keycode file** field, click **Browse** to obtain the keycode file to upload, and click **Validate** to validate and upload the file.

Note:

A 7.5 keycode must be uploaded for 7.0 and 7.5 targets. This keycode is meant for NFS installation.

The keycode is not validated on the target system; however, minimal prevalidation occurs from the deployment server.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

Add a CS1000 call server

[Print](#) | [Refresh](#)

Step 2: Pre-configuration for the linux call server. Keycode uploading and validation. Language and database selection.

Host name: hp2s108

Select the Keycode file to upload and click Validate button to validate and upload the file.

Select keycode location: ▼

Keycode file:

Figure 57: Keycode file screen

OR

If **Deployment Server** is selected, the page is refreshed, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

Add a CS1000 call server [Print](#) | [Refresh](#)

Step 2: Pre-configuration for the linux call server. Keycode uploading and validation. Language and database selection.

Host name: hp2s108

Select the Keycode file to upload and click Validate button to validate and upload the file.

Select keycode location:

Media:

Figure 58: Deployment Server screen

8. In the **Media** field, select **USB Device** from the list, and click **Browse** .

The page refreshes to show the Keycode file field.

9. In the **Keycode file** field, select a keycode file from the list of keycodes on the USB device and click **Validate** to validate and upload the file.

Keycode files must end with the .kcd filename extension. If you select a Keycode from the Deployment Server USB device, click Browse to show a list of all files on the USB device ending in kcd. For example, backup/single/keycode.kcd.

10. Click **Next**.

The page refreshes to show the validation completed and keycode accepted. The language and Database fields appear.

11. In the **Language** field, select a language from the list.
12. In the **Database** field, select one of the following from the list.
 - **Default Database:** This is the prepackaged database that is delivered with the software.
 - **Existing Database**
 - **Customer Database on Client Machine:** The database can be uploaded from any device connected to the client machine.
 - **Customer database on Deployment Server USB:** The database can be uploaded from a USB device connected directly to the server hosting the Deployment Manager (primary security server).

Note:

If you select Customer Database on Deployment Server USB, click Browse to show a list of all directories that should be valid Call Server databases. The directory name must be generated by the Call Server to be valid. Final validation is performed after you click Upload.

13. Click **Next**.

The page refreshes to show the Media field.

14. In the **Media** field, select **USB Device** from the list and click **Browse**.
The page refreshes to show the Path field.
15. In the **Path** field, select **backup** from the list and click **Upload**.
The page refreshes to confirm the uploaded database is valid.
16. Click **Next**.
17. In the **CS 1000 Element Manager** field, choose the server to use for Element Manager.
18. In the **Alternate CS 1000 Element Manager** field, choose a server if you want to configure an alternate Element Manager server.

Note:

If you choose an Alternate Element Manager server, Deployment Manager installs Element Manager to this server. However, no date synchronization occurs between the two servers.

On the Deployment View page, the Predeployed Applications field is updated to show Element Manager.

19. In the **Description** field, type a description.
20. In the **Add Signaling Servers** section, choose your Signaling Servers from the list the Linux servers, and click **Add**.

On the **Deployment View** page, the Predeployed Applications field is updated to show SS.

21. Click **Finish**.
22. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Note:

Only the servers that can host a particular application, appear in the list.

Important:

After the CS 1000 group is created, the Signaling Server tree displays all the available Signaling Servers that are added as part of the CS 1000 group. After you add or modify IP Telephony Nodes in Element Manager, a subgroup called Node Group is created or updated with all the node member information. This Node Group appears in Deployment Manager as Node XXXX, where XXXX represents the Node ID of the IP Telephony Node, as shown in [Figure 55: CS 1000 Deployment View screen](#) on page 97. After the Signaling Server is part of a Node Group, it is removed from the Signaling Server group to ensure that the same server does not appear in both places. Any servers that belong to the Signaling Server group can be added to any Nodes within that CS 1000 group. When the IP Telephony Node is deleted from Element Manager, all the servers that were part of the Node group go back to the Signaling Server group. These servers are now available to be added to other IP Telephony Nodes.

Defining a new CS 1000 High Scalability system

Add a CS 1000 High Scalability (HS) system. A High Availability (HA) group consists of VxWorks Call Server and a number of Signaling Servers. An HS system consists of multiple HA groups. Each HA group consists of a pair of VxWorks Call Servers and a group of Signaling Servers.

Prerequisites:

- Determine the Linux and VxWorks Call Servers that are to be used for each HA group.
- Identify the Linux servers to use as Signaling Servers and the associated HA group.
- Determine one or two Linux servers to be used for Element Manager HS.

Note:

Element Manager HS is a stand-alone application and must be on a dedicated Linux server. You can allocate a second stand-alone server for redundancy support.

Important:

After the CS 1000 server is created, the allocated Linux server that run Element Manager cannot be changed. To change an Element Manager role running on a Linux Signaling Server, you must delete the CS 1000 system and recreate it.

Procedure steps:

1. On the **Deployment View** page, select **CS 1000 systems** from the list on the right of the page.
2. Select **CS 1000 HS**, and click **Add**.
The Enter the High Scalability System Information page appears.
3. In the **Name** field, enter the name of the High Scalability server.
4. In the **Description** field, enter a description.
5. Click **Next**.
The Enter the High Scalability System Management Information page appears.
6. In the **CS 1000 Element Manager** field, choose the server to use for Element Manager from the list.
7. In the **Alternate CS 1000 Element Manager** field, choose a server if you want to configure an alternate Element Manager server from the list.
8. In the **Description** field, enter a description.
9. Click **Next**.
The Add CS 1000 high availability systems page appears.
10. Click **Add** to add a new HA system.

The Add CS 1000 high availability systems page appears.

11. In the **Call Server** field, choose a server from the list.

Important:

You see only the available VxWorks Call Servers. The VxWorks Call Servers that are already defined for other CS 1000 or CS 1000 HS systems do not appear.

In the **Inactive call server ELAN IP** field, the Inactive Call Server IP address appears.

12. In the **Name** field, type a name for the HA system.
13. In the **Description** field, type a description.
14. In the Choose signaling servers section, choose your Signaling Servers from the list the Linux servers, and click **Add**.
15. Click **Save**.

On the Deployment View page, the Predeployed Applications field is updated to show SS.

16. Repeat [10](#) on page 101 to [15](#) on page 102 in this procedure to add additional HA groups.
17. Click **Finish**.
18. To continue the preconfiguration process, proceed to [7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Editing a CS 1000 system

Add or change the Alternate CS 1000 Element Manager and add or delete Signaling Servers.

1. On the **Deployment View** page, select **CS 1000 systems** from the **View** list on the right of the page.
2. Select the check box of the CS 1000 system, and click **Edit**.

The Call Server information page appears, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Edit the CS1000 System

Step 1: The Call Server Information.

CS1000 name and description:

CS1000 Name: *

Description:

Call Server and Tape ID details

Call Server:

Call server tape ID: *

Figure 59: Edit the CS 1000 system

3. Click **Next**.

The Pre-configuration for the Linux call server. Keycode uploading and validation. Language and database selection screen appears.

4. To upload a different keycode, select **Click here**, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

Edit a CS1000 call server

[Print](#) | [Refresh](#)

Step 2: Pre-configuration for the linux call server. Keycode uploading and validation. Language and database selection.

Host name: hp2s108

Keycode uploaded during preconfiguration is valid. Keycode accepted.

[Click here if you need to upload a different keycode.](#)

Select the language(s) to be installed.

Language:

Specify the database to be used. An existing customer database may be uploaded below, or a default database will be created.

Warning: The existing database option should only be chosen if you plan to perform a system upgrade or a deploy and restore operation.

Database:

[Click here to re-configure language and database.](#)

Figure 60: Edit a CS 1000 Call Server screen

5. To change the **Language**, select **Click here**, as shown in the preceding figure.

The list is no longer dimmed.

6. To change the **Database**, select **Click here**, as shown in the preceding figure. You can choose from **Default Database**, **Existing Database**, **Customer Database on Client Machine**, and **Customer Database on Deployment Server USB**.

Important:

The Customer Database list does not show whether it is Customer Database on Deployment Server USB or Customer Database on Client Machine. If you have previously configured one of these and do not want to change this configuration, just click Save & Next to leave your configuration unchanged. However, if you had previously configured Customer Database on Client Machine and select

"Click here", the default selection appears as Customer Database on Deployment Server USB because if you select Customer Database on Client Machine, a tool is started for uploading a new database from the PC. Therefore, if you have already configured Customer Database on Client Machine and do not want to change, just click Save & Next to avoid starting this tool.

7. Click **Save & Next**. Proceed to [8](#) on page 104 through [10](#) on page 104 if you chose the Database option as Customer Database on Deployment Server USB; otherwise, skip to [11](#) on page 104.

The page refreshes to show the Media field.

8. To change the **Media**, click **Browse**.
9. Click **Browse** to get a list of databases available on the USB device.

The pages refreshes to show the Path field.

10. To change the **Path**, choose from the list and click **Upload**, as shown in the following figure.

The screenshot shows a web-based configuration interface for a CS1000 call server. The title bar reads 'Managing: DEPLOYMENT MANAGER' and 'Software Version: 7.0'. The main heading is 'Edit a CS1000 call server'. Below this, it indicates 'Step 2: Pre-configuration for the linux call server. Keycode uploading and validation. Language and database selection.' The host name is 'hp2s108'. A message states 'Keycode uploaded during preconfiguration is valid. Keycode accepted.' with a link to 'Click here if you need to upload a different keycode.' The 'Language' dropdown is set to 'Global 10 Languages'. A warning message is present: 'Warning: The existing database option should only be chosen if you plan to perform a system upgrade or a deploy and restore operation.' The 'Database' dropdown is set to 'Customer Database on Deployment Server USB'. The 'Media' dropdown is set to 'USB Device' with a 'Browse' button next to it. The 'Path' dropdown is set to 'backup/' with an 'Upload' button next to it. A status message at the bottom says 'Uploaded database is valid.' The footer contains three buttons: '<Back', 'Save & Next>', and 'Cancel'.

Figure 61: Edit a CS 1000 call server

11. Click **Save & Next**.
The Select the Alternate CS 1000 Element Manager screen appears. From this screen, you can only select the Alternate CS 1000 Element Manager field if it is not configured and add or remove Signaling Servers.
12. Select an **Alternate CS 1000 Element Manager** from the list to add an Alternate Element Manager or change your selection.
13. In the **Add signaling servers** section, you can **Add** or **Delete** Signaling Servers.
14. Click **Finish**.

Editing a CS 1000 HS system

Edit the CS 1000 HS system and the Alternate CS 1000 HS and add or delete Signaling Servers.

1. On the **Deployment View** page, select **CS 1000 systems** from the **View** list on the right of the page.
2. Select the check box of the CS 1000 HS system, and click **Edit**.
The Call Server information page appears.
3. Click **Next**.
The Select the Alternate High Scalability Manager page appears.
4. Select an Alternate CS 1000 Element Manager HS from the list to add an Alternate Element Manager or change your selection.
5. Click **Next**.
The Add edit, or delete CS 1000 high availability systems page appears.
6. Select a High Availability system and click **Add** , **Edit** , or **Delete**.

If you select Add or Edit, the Add or Edit existing CS 1000 high availability systems page appears, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Edit the High Scalability System

Step 4: Edit existing CS1000 high availability systems.

Call Server: 192.168.209.116 (Active call server ELAN IP)
Inactive call server ELAN IP: 192.168.209.117
Name: <input type="text" value="CS1000 HS"/> *
Description: <input type="text"/>

Choose signaling servers:

No signaling server is available for HA system.

* Required value.

Figure 62: Add or Edit an existing CS 1000 high availability system screen

7. In the **Add signaling servers** section, you can **Add** or **Delete** Signaling Servers.
8. Click **Save**.

Deleting a CS 1000 system

Important:

A CS 1000 system that has servers defined under Node xxxx, as described in the Attention box at the end of [Adding a CS 1000 system](#) on page 96 cannot be deleted directly from Deployment Manager in the CS 1000 view.

Use the following procedure to delete a CS 1000 system.

Procedure steps:

1. From Element Manager, click **IP Network, Nodes: Servers, Media Cards**.
2. Select the check box beside the node to export.
3. Click **Export** and specify the location to export the file.
4. Click **Delete**.

Note:

Avaya recommends deleting the IP Telephony Node during a maintenance window.

5. On the Deployment View page, select **CS 1000 systems** from the **View** list on the right of the page.
6. Select the check box of any CS 1000 system, and click **Delete**.
The Confirmation window appears.
7. Click **Yes** to delete the selected groups or **No** to cancel.

Note:

The IP Telephony Node is now available to be imported to another CS 1000 system.

Deleting a CS 1000 HS system

The following procedure deletes a CS 1000 HS system. To delete a single HA group, see [Deleting a CS 1000 system](#) on page 105

1. From Element Manager, click **IP Network, Nodes: Servers, Media Cards**.
2. Select the check box beside the node to export.
3. Click **Export**.
4. Click **Delete**.

Note:

Avaya recommends deleting the IP Telephony Node during a maintenance window.

5. On the Deployment View page, select **CS 1000 systems** from the **View** list on the right of the page.
6. Select the check box of any CS 1000 HS system, and click **Delete**.
The Confirmation window appears.
7. Click **Yes** to delete the selected groups or **No** to cancel.

Note:

The IP Telephony Node is now available to be imported to another CS 1000 system.

Deployment Actions

This section describes the options available under the Deployment Actions list. This list is context-sensitive so only the actions that are available to select appear in the list.

Note:

If you are using Deployment Manager on your Deployment Server as your unified solution for end-to-end installation and configuration of Linux Base and applications, you must use the process as described in [Preconfiguring process using Deployment View](#) on page 75.

The following is a list of the possible actions:

- Deploy: See [Deploying applications on a Server](#) on page 107
- Undeploy: See [Removing applications on a server](#) on page 109
- Backup: See [Performing a backup](#) on page 110
- Restore: See [Restoring data](#) on page 110
- System Upgrade: See [System upgrade](#) on page 49

Deploying applications on a Server

Choose Deploy when you have completed the predeployment process and the Server is installed with the latest software release of Linux Base. If you are upgrading applications and a backup exists, you can use this procedure to restore your configuration and data.

Prerequisites

The Deployment View status must show the following:

- The **Status** field is in a Committed status. If not, return to [Step 8](#) on page 77 in [Preconfiguring process using Deployment View](#) on page 75.
- The **Server Status** field is in the Undeployed status. If the status is in a Deployed state and you want to redeploy, see [Removing applications on a server](#) on page 109 to undeploy.
- The Software Load version and Release number must be equal to or greater than the Base version.

Procedure steps

1. On the **Deployment View** page, choose **Servers** from the **View** list.
2. Select the server(s) you want to deploy.
3. From the **Deployment Actions** list, choose **Deploy**.
4. Click **OK** to confirm deployment.

Note:

If a backup archive already exists, you are presented with the **Target Deployment & Restore** screen, as shown in the following figure. You have the option to restore your configuration and data. If no previous backup archive exists, the Call Server Preconfiguration details page appears, go to [Step 7](#) on page 108.

5. Select the **Upgrade** check box if you want to restore your configuration and data, as shown in the following figure.



6. Click **Continue** and proceed to [Step 10](#) on page 109.
7. If no previous backup archive exists, the Call Server Preconfiguration details page appears, as shown in the following figure.




Figure 63: Example of an archive backup

8. Select **Click here** to reconfigure the language and database location, and click **Next**.

Important:

The Database field must be defined; otherwise, it uses the Default Database. The Default Database is the prepackaged database that is delivered with the software.

9. In the **Customer database directory** field, click **Browse** to search for the database location, and click **Upload**, as shown in the previous figure.

Tip:

The backup folder structure must not be changed; otherwise, it is not recognized by Deployment Manager.

For example:

- For backup, the folder structure is: /ARCH_DB/ cust_named_folder/*.rec.
- For a large system backup, the folder structure is: /backup/single/*.rec.
- For archive backup, you must navigate to the "cust_named_folder" for upload to Deployment Manager.

10. Click **Return** to return to the Deployment View page. The Deployment View page refreshes to show the applications deployed.

Note:

If you are prompted for keycode validation, you must provide a 7.0 keycode for Release 7.0 and a 7.5 keycode for 7.5 targets.

Removing applications on a server

Remove applications from a previously deployed server (undeploying a server).

Prerequisites

- The server must be removed from all existing groups.
- The Undeploy option is available under the following conditions:
 - The Status field is in a Configured state.
 - The Predeployed Applications field must state N/A.
 - The Base Version field must not be empty.

Procedure steps

1. On the **Deployment View** page, choose **Servers** from the **View** list.
2. Click the option button beside the Host Name of the server from which to remove the applications.
3. From the **Deployment Actions** list, choose **Undeploy**.

Performing a backup

Ensure the latest service pack is applied before performing a backup.

Feature interactions

- Only one backup for each Member server is permitted on the Deployment Server (Primary security server). You must delete the current backup archive before you can perform another backup or choose another backup location.
- There are a maximum of 10 backup archive files allowed on the Deployment Server. You must remove or overwrite an existing backup archive before you can perform another backup.

Note:

For procedures on deleting an existing backup archive, see [Backups](#) on page 111

Procedure steps

1. On the Deployment View page, choose **Servers** from the list on the right of the page.
2. Select a server from the list.
3. From the Deployment Actions list, choose **Backup**.
4. In the Select backup location field, choose from the list.
5. Click **Start Backup**.
6. If a backup archive already exists for a target, you are prompted to overwrite the existing backup. Click **OK** to overwrite and **Cancel** to abort the backup operation.

Restoring data

Restore system data.

Prerequisites

The Base version field must not be empty.

Procedure steps

1. On the **Deployment View** page, select **Servers** from the **View** list on the right of the page.
2. Select a server from the list.
3. From the **Deployment Actions** list, choose **Restore**.

The restore page appears, as shown in the following figure.

Figure 64: Restore page

4. Select the check box if you want to **Restore data for deployed applications only**.

OR

Clear the check box if you want to restore pre-installed applications and deployed applications.

5. In the **Select restore source**, choose from the list.
6. Click **Start Restore**.

System upgrade

A system upgrade includes a reinstallation of Linux Base and applications with your system data restored. For more information, see [Upgrading a backup or member server from Release 6.0 or later](#) on page 130.

Backups

This section describes how to delete existing backup files. You can have a maximum of three backup files for each server and can manage your backups from this link. From UCM, click Software Deployment, Backups.

Deleting an existing backup file

Delete existing backup files on the target server to create space for new backup files.

1. From the Navigation tree, click **Backups**.

The Backups screen appears.

2. Select the backup file to delete.
3. Click **Delete**.

The backup file is deleted from the hard drive.

6.0 Deployment Targets

This section is for Release 6.0 systems only. It describes how to manage and deploy application software and backup and restore system data for Release 6.0. For Release 7.0 and later, see [Deployment Manager—New system installation and commissioning](#) on page 69.

Important:

Do not use this section for deploying application software for Release 7.0 or later.

Prerequisites

- Must have the Release 6.00.18 software load for your Release 6.0 target servers.

Deploy

For Release 6.0, use Deployment Manager for software application deployment from the primary security server to other Linux servers in the same security domain. The primary security server is the central repository for the software application load and deployment occurs remotely, which eliminates the need to log on to each target server.

Deploying application software to a Call Server

This section, for Release 6.0, describes the procedures for deploying software on an existing configuration or a new configuration for predeployment. You can also use this section to backup and restore.

Prerequisites:

- The target server must be in the Undeployed status.
- Deployment Manager must have a software load that matches the Base version.

Procedure steps:

1. On the **Deployment Manager** page, click **6.0 Deployment Targets**.
2. Click the option button beside the Host Name of the server to deploy.

Important:

The Deploy button is not available to select until the target server has a status of Undeployed.

3. Click **Deploy**.

The Target Deployment page appears, as shown in the following figure.

Managing: DEPLOYMENT MANAGER Software Version: 7.0

Target Deployment [Print](#) | [Refresh](#)

Host name: co-res-cppm
Type: Avaya CPPMv1

Server status: Deployed
Deployed version: avaya-7.50.07
Services: CS+SS+NRS+EM, SubM

Current operation status: None
Last operation result: **Deployment successful.**

Last deployment summary: Refer to the [deployment summary](#) for more information.

Software Applications

Select the software version to deploy or upgrade. Except for upgrades, previously deployed packages (shown above if applicable) must be undeployed first.

Software versions: ▾

No software applications available for this target. To deploy software applications, a software load of the same release as this target's Linux Base must be added. To upgrade the currently deployed applications, a software load of a higher version must be added. To add software versions to the deployment library, navigate to Software Loads.

Figure 65: Target Deployment and Software Applications

4. In the **Software versions** field, select the software version from the list.
5. Select the check box beside the Deployment package to deploy and click **Deploy**.

Important:

Software applications must be undeployed first.

Undeploying application software

Undeploy previously deployed software packages.

1. On the **Deployment Manager** page, click **6.0 Deployment Targets**.
2. Click the option button beside the Host Name of the server.

Important:

The Deploy button is not available to select until the target server has a status of Undeployed.

3. Click **Deploy**.

The Target Deployment page appears, as shown in [Figure 65: Target Deployment and Software Applications](#) on page 113.

4. In the **Software versions** field, select the software version from the list.
5. Select the check box beside the Deployment package to undeploy and click **Undeploy**.

Backing up existing system data files

Backup existing system data files on the target server to free disk space before the backup.

1. On the **Deployment Manager** page, click **6.0 Deployment Targets**.

The Deployment Targets page appears.

2. Click the option beside the server to remove existing backup files.
3. Click **Backup**.

The Backup page appears.

4. In the **Select backup location** field, choose a backup location to store the backup data. Select either **Deployment Server** or **SFTP Backup Server** from the list.

Important:

Sufficient space must be available on the target server hard drive for the backup file. If space is not available, you must delete a previous backup file before you start. You can store a maximum of three backup files on the target server hard drive; then you must delete a backup file before you add another. For information about deleting backup files from the target server hard drive, see [Deleting an existing backup file](#) on page 112.

5. If you choose **Deployment Server** as the backup location, proceed to [11](#) on page 115 in this procedure.

- If you choose SFTP Backup Server as the backup location, the Backup screen refreshes with additional Secure File Transfer Protocol (SFTP) fields, as shown in the following figure. Proceed to [7](#) on page 115 in this procedure.

Managing: DEPLOYMENT MANAGER Software Version: 6.0

Backup [Refresh](#)

Host name: prisec6-0
Type: IBM X306M

Server status: Deployed
Deployed version: 6.00.08
Applications: NRS+SS, EM, SubM

Current operation status: None

Select backup location:

SFTP server IP address: *

Directory on SFTP server: *

SFTP server username: *

SFTP server password: *

* Required value.

Figure 66: SFTP Backup Server window

- In the **SFTP server IP address** field, type a value for the SFTP server IP address.
- In the **Directory on SFTP server** field, type a value for the SFTP server directory.
- In the **SFTP server username** field, type a value for SFTP server user name.
- In the **SFTP server password** field, type a value for SFTP server password.
- Click **Start Backup** to start the backup.

OR

Click **Return** to cancel the backup and return to the Deployment Targets screen.

The Backup screen displays the **Last backup result**, **Last backup time**, and **Last backup name**, as shown in the following figure.




Figure 67: Backup results window

Restoring system data

Restore system data.

1. On the **Deployment Manager** page, click **6.0 Deployment Targets**.
The Deployment Targets page appears.
2. Click the option button beside the server to restore.
3. Click **Restore**.
The Restore page appears.
4. In the **Select restore source** field, select the source of the application data backup file from the list.

If you select **Deployment Server (current target)** as the backup file source, proceed to [5](#) on page 116 in this procedure.

If you select **Deployment Server (all targets)** as the backup file source, proceed to [6](#) on page 116.

If you select **Client Machine** as the backup file source, proceed to [7](#) on page 116.

If you select **SFTP Backup Server** as the backup file source, Proceed to [8](#) on page 117.
5. Select the backup file from the list of backup files stored on the current target server, and proceed to [12](#) on page 117.
6. Select the backup file from the list of backup files stored on all targets in the security domain, and proceed to [12](#) on page 117.
7. Type the backup file name in the **Specify restore file name** field.

OR

Click **Browse** to browse to the backup file.

Proceed to [12](#) on page 117.

8. In the **SFTP server IP address** field, type a value for the SFTP server IP address.
9. In the **File path of backup on SFTP server** field, type the complete file path for the backup file.

Note:

You must enter the complete file path, including the file name.

10. In the **SFTP server username** field, type a value for SFTP server user name.
11. In the **SFTP server password** field, type a value for SFTP server password.
12. Click **Start Restore** to restore the application data.

OR

Click **Return** to cancel the restore process and return to the Deployment Targets page.

NFS based new installation

This section describes the recommended approach for installing Linux Base on the member and backup target servers using an Network File System (NFS) based remote installation method.

For Linux Base upgrades or Disaster Recovery procedures, see the following sections:

- [Upgrade Linux Base](#) on page 123
- [Disaster recovery](#) on page 177

Installation workflow using NFS

The following figure shows the workflow for a new Avaya CS 1000 system Linux installation and commissioning using NFS. The flow indicates the recommended sequence of events to follow and provides the technical document number for the detailed procedures required for the task.




Figure 68: Workflow using NFS

NFS based remote installation topology

The following figure depicts a detailed NFS-based installation. Only the TLAN network interface is supported on the Deployment Server and target servers. In this diagram, TLAN A, B, C, and D are on different subnets in a WAN environment.

Network (NFS) based Remote Installation (using TLAN)




Figure 69: NFS-based remote installation topology (using TLAN)

Prerequisites

- You must connect your terminal to a serial port or kvm (for COTS, CP DC, or CP MG).
- The Deployment Manager must already be commissioned on a server.
- The target servers must be in a Committed status.
- Ensure that the proper TLAN routing on your data network is enabled.
- Ensure NFS service is Enabled from Deployment Manager in the Servers view.
- Ensure NFS traffic is allowed on your data network.
- On the target servers, ensure the correct IP addresses are provided during the NFS restart process.
- On the target server, ensure the Deployment Server TLAN IP address is provided during the NFS restart process.
- On the target server, ensure the cables for your ELAN/TLAN interfaces are connected.

Installing the servers (NFS-based new installation)

Use the following procedure for installing a new Linux Base on your target servers using NFS. For a network topology diagram of NFS, see [Figure 69: NFS-based remote installation topology \(using TLAN\)](#) on page 119.

1. Insert the installation media: (DVD, Compact Flash, or USB memory stick) for your specific member server and restart the server.
 - For CP PM servers, insert the compact flash installation media.
 - For CP MG and CP DC, insert the USB 2.0 memory stick.
 - For COTS servers, insert the DVD installation media.

Note:

You must have a Compact Flash (CF) card or USB 2.0 memory stick with a capacity of at least 2 GB.

Note:

The N0220961 USB memory stick is supported for Avaya Communication Server 1000. Not all USB memory sticks are supported.

2. Restart the server.
3. For COTS: Watch for the boot prompt during the restart process and proceed to [4](#) on page 121 in this procedure.

Important:

The boot prompt appears only briefly. You have about eight seconds to type `com1-nfs` before it defaults to `com1`. If you miss the prompt, return to [2](#) on page 120 above.

OR

For CP DC and CP MG servers, press the F key immediately after the server begins rebooting and proceed to [4](#) on page 121 in this procedure.

OR

For a CP PM server, at the Linux Base installer screen, you see ..., at this point press the F key to force the board to boot from the faceplate drive, as shown in the following figure. Proceed to [4](#) on page 121 in this procedure.

```

-----+-----
System BIOS Configuration, (C) 2005 General Software, Inc.
-----+-----
System CPU       : Pentium M       | Low Memory      : 632KB
Coprocesor      : Enabled         | Extended Memory : 2035MB
Ide 0 Type      : 3                | Serial Ports 1-2 : 03F8 02F8
Ide 1 Type      : 3                | ROM Shadowing   : Enabled
Ide 2 Type      : 3                | BIOS Version    : NTDU74AA 18
-----+-----

Press F to force board to boot from faceplate drive.
....._

```

Figure 70: Force board to boot screen

4. At the boot prompt, type `com1-nfs` or `kvm-nfs`.

Note:

Kvm-nfs is not a valid option for CP PM servers.

5. On the Manual IP Configuration page, type the Target Server TLAN IP Address, the TLAN Netmask, the TLAN Gateway address, and the Deployment Server TLAN IP address, as shown in the following figure.

```

Welcome to Red Hat Enterprise Linux Server
-----+-----+ Manual IP Configuration +-----+
|
| Enter the Deployment Target TLAN IPv4 settings.
| example: 192.168.10.10 / 255.255.255.0 / 192.168.10.1
| The Deployment Server TLAN IP field must be a
| valid IPv4 address.
|
| (After selecting OK, avoid hitting
| any key until next screen ...)
|
| Enter TLAN IP Address: █
| Enter TLAN Netmask:
| Enter TLAN Gateway:
| Deployment Server TLAN IP:
|
|
| +----+
| | OK |
| +----+
|
+-----+-----+
<Tab>/<Alt-Tab> between elements | <Space> selects | <F12> next screen

```

Figure 71: Manual IP configuration screen

6. Select **OK**.

The console displays installation details during the automated process. Upon completion, you receive the logon prompt.

Important:

Expect this procedure to take some time. Upon completion, the member server is installed with the Linux Base, security configured, and the required applications are deployed.

Chapter 7: Upgrade Linux Base

This chapter describes the procedures for upgrading Linux Base on the following platforms:

- CP PM
- CP DC
- CP MG
- COTS servers
- Common Server

Navigation

- [Prerequisites to upgrading Linux Base](#) on page 123
- [Upgrading Linux Base](#) on page 123

Prerequisites to upgrading Linux Base

- You must create a copy of the keycodes before you perform the upgrade procedure.
- You must be able to log on using the nortel (for Release 7.0 systems) or admin2 (for Release 7.5 systems) accounts or any user account with the network administrator role assigned.

Upgrading Linux Base

 **Warning:**

During an upgrade, the hard drive is formatted and all data is lost. To preserve the data, perform a backup to an external source before you attempt an upgrade.

If the MAS application is deployed on the server, MAS must use Element Manager to backup MAS data. For more information, see [Backup and restore application data](#) on page 47

1. Log on to the server using an account with networkadministrator privileges. For example, admin2.
2. At the command prompt, type `upgrade`, as shown in the following figure.

```
Avaya Inc. Linux Base 7.50
The software and data stored on this system are the property of,
or licensed to, Avaya Inc. and are lawfully available only
to authorized users for approved purposes. Unauthorized access
to any software or data on this system is strictly prohibited and
punishable under appropriate laws. If you are not an authorized
user then do not try to login. This system may be monitored for
operational purposes at any time.

cores2.ca .avaya .com login: admin2
Password:
  To access the UCM Web page, go to:
    UCM URL: http://<FQDN|IP>
[admin2@cores2 ~]$ upgrade
```

Figure 72: Upgrade

3. Type `Y` at the command prompt to continue the upgrade, as shown in the following figure.

```
This tool will perform Linux Base upgrade. Before the upgrade
it will back up all data.

Do you want to continue upgrade? (Y/N) [N]? y_
```

Figure 73: Continue upgrade screen

The tool backs up all system data before upgrading. The system data is saved to the `/admin` partition. Use the option Re-use `/admin` partition during Linux Base installation.

4. Type `Y` at the prompt to backup data to external source (USB/SFTP), as shown in the following figure.

```
Do you want to backup data to external source (USB/SFTP) as well? (Y/N) [Y]? y
1. Backup to USB device.
2. Backup to SFTP server.

Enter your choice (q for exit): 1
```

Figure 74: Backup source

Type `1`, if you would like to backup to a USB device or type `2`, if you would like to backup your data to an SFTP server, as shown in the previous figure.

OR

Type `q` to exit and not save the system data to an external source.

5. On the IP address line for the secure FTP server, type a value for secure FTP server IP address.

On the SFTP login line, type a value for SFTP login.

On the SFTP password line, type a value for SFTP password.

On the remote SFTP directory line, type a value for remote SFTP directory.

Important:

If you perform SFTP as the admin2 user (non-jailed) then an example of an absolute sftp path is: /var/opt/avaya/patch. If you perform SFTP as any other user (jailed) then an example of an absolute sftp path is: /patch (assuming that the user is part of the patchadmin group). For users other than admin2 (jailed), the directories available using SFTP depends on what group they belong to.

6. Insert the Linux Base upgrade media, and press any key to continue.
7. Type **Y** if you want to proceed with the installation, as shown in the following figure.

```

Checking for previous installation...
#####
#####

Installation of New Linux base Operating System
Existing Linux base release:
System Release:      cs1000-linuxbase-7.50.07.00
Build Timestamp:    Wed Sep 22 15:44:49 EDT 2010

New Linux base release:
System Release:      cs1000-linuxbase-7.50.11.00
Build Timestamp:    Tue Oct  5 18:49:16 EDT 2010

This is a Linux Base UPGRADE operation.
There is backup data available in the 'admin'
partition. This data could be reused, based on
the selection made at the subsequent
"Base Configuration Data Selection" stage.

#####
#####

Do you wish to proceed with installation (Y/N) [Y]? █

```

Figure 75: Confirmation screen

You are now prompted to format the administration partition. Only format the partition if you suspect the integrity of the partition has been compromised, for example, a corrupted disk, the local backup information is incorrect, etc.

8. Type **N** if you do not want to format the existing administration partition.

OR

Type **Y** if you want to format the existing administration partition, as shown in the following figure.

```
Existing Configuration Partition Usage
-----
A pre-existing administration partition has been found on this system.

If this re-installation is due to a possible disk corruption, it
is recommended that you format this partition to avoid any file
corruption that may be present. In this case, all data will be
removed from this partition and you will be required to manually
enter all installation questions from the beginning.

If this re-installation is not due to disk corruption, then leaving
the partition is a safe option, and if valid data from the previous
configuration exists, you will be given the option of reusing that data
during this installation.

Do you wish to format the administration partition (Y/N) [N]?
```

Figure 76: Existing administration partition confirmation screen

The Base Configuration Data Selection screen appears, as shown in the following figure.

9. Type one of the following, as shown in the following figure:
 - a. Type 1 to reuse the data from the preexisting configuration file. That data input validation screens are shown for validation.
 - b. Type 2 to load previously backed up data from a USB storage device.
 - c. Type 3 to load previously backed up data from SFTP server.
 - d. Type 4 to ignore the data from the preexisting configuration file. The standard system configuration prompts are presented.

```
-----
A pre-existing Base configuration data file has been found
on this computer.
  Base configuration data includes:
    Network Configuration
    Time Zone Configuration
    NTP Configuration
    DNS Configuration
    Local Accounts Passwords
You may choose to do one of the following:

1) Reuse the data from this pre-existing configuration file. The data
   input-validation-screens will be shown for validation.

2) Use backed up data from a USB storage device.
   (Note: Only one USB storage device should be plugged-in.)

3) Use remote backed up data from a SFTP-server. This requires the
   provision of SFTP server information.

4) Ignore the data in pre-existing configuration file. The standard
   system-configuration-prompts will be presented.

Select an option (1-4):
```

Figure 77: Base configuration data selection screen

10. Proceed to [8](#) on page 58 to [24](#) on page 68 in [Installing a new Linux Base](#) on page 54 to continue the installation process.

Chapter 8: Upgrade Avaya Communication Server 1000 system Linux installation

This chapter provides the procedures for an end-to-end upgrade of Linux Base and applications. At this stage, Linux Base has been upgraded on the Primary security server (Deployment Server).

 **Warning:**

During an upgrade, the hard drive is formatted and all data is lost. To preserve the data, perform a backup to an external source before you attempt an upgrade.

 **Warning:**

During an upgrade procedure, keycodes for Co-res installations and for installations of Subscriber Manager are lost. You must create a copy of the keycodes before you perform the upgrade procedure.

 **Warning:**

If you access the Linux server through a Terminal Server connected to the COM port, it is possible that garbled characters (such as uuuuuu) can appear during a system restart (for example, during the installation or upgrade procedure). This appearance can make the system seem to hang.

You can resolve the problem by reestablishing the COM1 connection from the client PC or work station to the Linux server.

Do not manually restart the system during the upgrade or installation. This can result in hard drive corruption and forces you to reinstall the system.

Navigation

- [Upgrading a backup or member server from Release 6.0 or later](#) on page 130
- [Accessing the Local Deployment Manager](#) on page 133

Upgrading a backup or member server from Release 6.0 or later

Upgrade a backup or member server from Release 6.0 or later. A system upgrade includes performing a latest software release installation of Linux Base and applications with your system data restored.

The following figure provides an example workflow for upgrading an Avaya Communication Server 1000 (Avaya CS 1000) system Linux installation and commissioning on a patched Release 6.0 system. The flow indicates the recommended sequence of events to follow and provides the technical document number for the detailed procedures required for the task.




Figure 78: System upgrade patched Release 6.0

Prerequisites:

- The Primary security server (Deployment Server) must already be upgraded to the latest CS 1000 software release. See [Upgrading Linux Base](#) on page 123.

Note:

If you delete all groups from the UCM Tree view, System Upgrade is available in the Deployment Actions list in Deployment Manager. You can upgrade the system to a new load/release; however, the Avaya applications do not deploy.

Procedure steps:

1. Apply the Service Update (SU) patch for your current software release on the Target Server.
2. Allocate the servers into the hierarchical groups which determines the application packages required for deployment.

The servers can be allocated into the following groups:

Important:

If you are upgrading a previously deployed server and there is a previous configuration or a subset of a supported software configuration, the grouping can only be applied to a supported software configuration. For example, if the previously configured server contained NRS+SS_EM, then this server can be configured for the NRS group, SS group, and you can choose Element Manager. You cannot configure this server as a Call Server. You must also ensure that the server is associated in the same group. For example, if the previously configured server was configured with EM to manage a particular call server, you need to associate this server in the same group as that call server.

- Network Services: for detailed procedures, see the following:
 - [Adding a MAS service](#) on page 91
 - [Adding a Network Routing Service](#) on page 92
 - [Adding a Subscriber Manager service](#) on page 93
 - [Adding a SIP Trunk Bridge](#) on page 94
- Avaya CS 1000 systems: for detailed procedures, see the following:
 - [Adding a CS 1000 system](#) on page 96
 - [Defining a new CS 1000 High Scalability system](#) on page 101

On the Deployment view page, the Status field changes from Preconfigured to Predeployed to identify that the server is now part of one or more groups. The Predeployed Applications field shows the applications that correspond to the selected services.

3. On the Deployment View page, choose **Servers** from the View list, and click **Commit**, as shown in the following figure.

Important:

The Commit button is a system wide operation. All servers in the Predeployed status are committed.

Managing: DEPLOYMENT MANAGER Software Version: 7.5

Deployment View Print | Refresh

Linux Server Deployment Actions View: Servers

Host Name ▲	Address	Type	Status	Predeployed Applications	Base Version ▲
<input type="radio"/> 192.168.209.115(Active)	192.168.209.115	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.116(Active)	192.168.209.116	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.209.117 (Inactive)	192.168.209.117	VxCS	Preconfigured	N/A	
<input type="radio"/> 192.168.55.118(Active)	192.168.55.118	VxCS	Preconfigured	N/A	
<input type="radio"/> hpss7.us.avaya.com (member)	192.168.55.150	Linux	Committed	CS1000HS-EM	
<input type="radio"/> ibmss10.us.avaya.com (primary)	192.168.55.178	Linux	Committed	SubM, NRS, EM, SS	7.50.07
<input type="radio"/> test1.us.avaya.com (member)	192.168.55.190	Linux	Committed	EM, SS, NRS	
<input type="radio"/> test2.us.avaya.com (member)	192.168.55.211	Linux	Preconfigured	None	

Figure 79: Deployment View commit screen

4. Select the server to upgrade and select **System Upgrade** from the Deployment Actions list

If required, you can monitor the installation and deployment progress by using a serial port console.

5. You must register the upgraded element using one of the following two options:

In LD 117, type REGISTER UCMSECURITY SYSTEM FORCE

OR

From UCM, select the element to update and click **Edit**.

6. From the Element Details page, click **Edit**.

The Release page appears.

7. Select Release 7.5 from the list and click **Save**.

Note:

If you are prompted for a keycode validation, you must provide a 7.5 keycode (for Release 7.0 targets).

Accessing the Local Deployment Manager

Application software can be deployed locally on a server. To do this, you must log on to the local server and use the local Deployment Manager to deploy the software. After the server joins the security domain, local deployment information is recognized by Deployment Manager on the Primary Security server (Deployment Server). For information about joining the security domain, see *Unified Communications Management Common Services Fundamentals, NN43001-116*.

Prerequisites:

- Download the appropriate .nai file (Avaya CS 1000 or MAS) from the software download site to the server running Deployment Manager.

Procedure steps:

1. Log on to the server using the admin2 user ID and password.

The Security Configuration screen appears, as shown in [Figure 80: Security Configuration window](#) on page 134.




Figure 80: Security Configuration window

2. Click **Local Administration**.

The screen appears, as shown in [Figure 81: Base Manager window](#) on page 135.



Figure 81: Base Manager window

3. In the navigation pane, click **Deployment**.

The Deployment Manager screen appears, as shown in [Figure 82: Deployment Manager window](#) on page 135.




Figure 82: Deployment Manager window

4. Click the button beside the hostname.
5. Click **Deploy**.
6. Click **Upgrade**.
7. To allocate the target servers to a group, proceed to [Step 7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Note:

Servers that are deployed with applications but are not configured into systems are represented in blue in Deployment Manager

Chapter 9: Base Manager

This chapter contains information and procedures for managing specific network servers on an individual basis using Base Manager. References to the various Element Manager, Network Routing Service Manager, and Patching Manager documentation are provided. IPv6 is supported for Base Manager.

Use Base Manager to manage the base system in the following functional areas:

- Base System
 - Networking (Network Identity, DNS and Hosts, Route Table).
 - Explicit Congestion Notification
 - Date and Time
 - SSH Keys
- Software
 - Applications
 - Deployment (See [Deployment Manager—New system installation and commissioning](#) on page 69)
 - Patches
- Tools
 - Logs

Note:

The server must be part of the security domain before you can perform Base Manager configuration procedures through UCM. For more details about UCM configuration of the primary, backup, and member servers, see *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116*. For more information about security management, see *Avaya Security Management Fundamentals, NN43001-604*.

Navigation

- [Accessing Base Manager through UCM](#) on page 138
- [Accessing Base Manager through local logon](#) on page 140
- [Deploying software in local login mode](#) on page 142
- [Undeploying software in local login mode](#) on page 142
- [Rebooting the server](#) on page 143

- [Base system configuration using Base Manager](#) on page 144
- [Regenerating SSH Keys for a UCM Member server](#) on page 167
- [Software maintenance using Base Manager](#) on page 169
- [View and export logs using Base Manager](#) on page 171

Accessing Base Manager through UCM

Perform the following procedure to access to Base Manager through UCM.

1. Open the Web browser.

Note:

You must use Microsoft Internet Explorer 6.02600 or later.

2. Enter one of the following in the Address bar, and then press `Enter`:
 - Unified Communications Management (UCM) framework IP address. After you enter the UCM framework IP address, a Web page appears stating that you must access Unified Communications Management by using the Fully Qualified Domain Name (FQDN) for the UCM server. Click the link on this Web page to use the FQDN for the UCM server.
 - FQDN for the UCM server.
3. Click **OK** or **Yes** to accept the security windows that appear.

The UCM Login Web page appears.
4. In the **User ID** field, enter your user id.
5. In the **Password** field, enter your password.
6. Click **Log In**.

The UCM default navigation screen appears, as shown in the following figure.




Figure 83: UCM default navigation window

7. On the Elements page of Unified Communications Management, under the **Element Name** column, click on an element of type Linux Base to navigate to Base Manager for that element.

The Base Overview page appears, as shown in the following figure.



Figure 84: Base Overview window

Accessing Base Manager through local logon

Perform the following procedure to log on to the server locally and access Base Manager.

1. Open the Web browser.

Note:

You must use Microsoft Internet Explorer 6.02600 or later.

2. Enter the following in the Address bar: `http://<FQDN>/local-login`

The Server logon screen appears, as shown in the following figure.



Figure 85: Server logon window

3. In the **User ID** type, admin2.

Note:

You must use the admin2 account to log on to the server locally.

4. In the **Password** field, type the password.
5. Click **Log In**.

The Security Configuration screen appears, as shown in the following figure.




Figure 86: Security Configuration window

6. Click **Local Administration**.

Base Manager opens and the Base Overview screen appears, as shown in the following figure.




Figure 87: Base Overview window

Deploying software in local login mode

Prerequisite:

- Upload the appropriate .nai file (Avaya Communication Server 1000 or MAS) from the software download site to the server running the local Deployment Manager. The .nai distribution can be loaded from the local server using a USB or CF device (as appropriate) or from the client PC connected to the server.

Procedure steps:

Use local login to deploy software.

1. Follow the procedures in [Accessing Base Manager through local logon](#) on page 140.
2. From the navigation pane, click **Software Deployment**.
The Deployment Targets page appears.
3. Select the hostname and click **Deploy**.

Note:

Previously deployed software must first be undeployed.

4. Select the check box beside the deployment package you want to **Deploy**.
5. To allocate the target servers to a group, proceed to [Step 7](#) on page 76 in [Preconfiguring process using Deployment View](#) on page 75.

Note:

Servers that are deployed with applications but are not configured into systems are represented in blue in Deployment Manager

Undeploying software in local login mode

Prerequisite:

- The application .nai file must first be uploaded.

Procedure steps:

Use the following procedure to undeploy a software package.

1. Follow the procedures in [Accessing Base Manager through local logon](#) on page 140.
2. From the navigation pane, click **Software Deployment**.
The Deployment Targets page appears.
3. Select a hostname and click **Deploy**.
4. Click **Undeploy**.

Rebooting the server

Some procedures require a server reboot for configuration changes to take effect. Perform the following procedures to reboot the server.

1. Log on to UCM and navigate to Base Manager. See [Accessing Base Manager through UCM](#) on page 138.
2. Press **Reboot**.

Note:

You must have a user role of System Administrator to reboot the server. If you do not have a user role of System Administrator, the Reboot button is not active.

A confirmation screen appears, as shown in the following figure.




Figure 88: Reboot confirmation window

3. Press **OK** to confirm the server restart.

Base system configuration using Base Manager

You can configure networking values by using Base Manager. You can alter Telephony LAN (TLAN) and Embedded LAN (ELAN) values to edit the network identity, or add or delete hosts. You can add or delete routes to update route tables.

Use Base Manager to configure date and time values. Set system values or configure automatic date and time values using network time servers.

You can also use Base Manager to enable or disable Explicit Congestion Notification (ECN).

Editing network identity for a Member server

Perform the following procedure to manually edit values for ELAN and TLAN.

Important:

You cannot change the FQDN or host name of the primary or backup server using Base Manager; you must use CLI commands. Changing the FQDN or host name can have serious implications for the network. If you change the FQDN on the PSS or the BSS, a re-install is

required. Consult *Avaya Unified Communications Management Common Services Fundamentals, NN43001-116* before you attempt to change the FQDN or host name.

Note:

After you edit the network identity, you must manually restart the server for the changes to take effect.

Procedure steps:

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Networking**.

The Networking screen appears, as shown in the following figure.

Managing: 172.16.101.5 (Primary UCM security server)
Base System » Networking

Networking

[Network Identity](#)
Change ELAN and TLAN IP addresses and set host name and domain.

[DNS and Hosts](#)
Set primary and alternate DNS for domain name resolution. Also add or delete the hosts.

[Route Table](#)
Add or remove routes.

Figure 89: Networking window

3. In the Networking screen, click **Network Identity**.

The Network Identity screen appears, as shown in the following figure.




Figure 90: Network Identity window

Note:

If the TLAN IP address is not the default gateway value, a warning appears that indicates that the default gateway value is an IP address other than the TLAN IP address.

4. Click **Edit**.

The Edit Network Identity screen appears, as shown in the following figure.




Figure 91: Edit Network Identity window

5. In the **Embedded LAN (ELAN)** section, complete the following:
 - **IP address:** enter a value for the ELAN IP address.
 - **Gateway:** enter a value for ELAN gateway.

- **Netmask:** enter a value for ELAN netmask.
6. In the **Fully Qualified Domain Name (FQDN)** section, complete the following:
 - **Host name:** enter a value for host name.
 - **Domain:** enter a domain value.
 7. **Telephony LAN (TLAN)** section, complete the following:
 - **TLAN address type:** click **IPv4 only** or **IPv4 and IPv6**.
 - **IPv4 address:** enter a value.
 - **Gateway** enter a value for TLAN gateway.
 - **Netmask** enter a value for TLAN netmask.

If you selected IPv4 and IPv6 as the TLAN address type, complete the following two fields:

- **IPv6 address:** enter a value for the IPv6 address.
 - **IPv6 gateway:** enter a value for the IPv6 gateway.
8. Click **Save and reboot** to save your configuration changes and restart the server. After restarting, log on to verify the saved configuration.

OR

Press **Cancel** to discard your changes and return to the Network Identity screen.

DNS and Hosts

Perform the following procedures to add a new host and to remove an existing host.

Adding a host

Perform the following procedure to add a host value to the host table.

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Networking**.

The Networking screen appears, as shown in the following figure.



Figure 92: Networking window

3. In the Networking screen, select **DNS and Hosts**.

The Domain Name Server (DNS) screen appears, as shown in the following figure.




Figure 93: Domain Name Server (DNS) window

4. Click **Add**.

The New Host screen appears, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)
 Base System » Networking » DNS and Hosts » New Host

New Host

IP address: *

Host name: *

Domain: *

*Required value.

Save Cancel

Figure 94: New Host window

5. In the **IP address** field, enter a value for IP address.
6. In the **Host name** field, enter a value for host name.
7. In the **Domain** field, enter a value for Domain.
8. Click **Save**.

The Domain Name Server (DNS) screen displays the new host, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)
 Base System » Networking » Domain Name Server

Domain Name Server (DNS)

Primary and Secondary servers are set manually.

DNS IP addresses Edit...

Primary: 0.0.0.0
 Secondary: 0.0.0.0

Hosts

Host IP address configuration.

Add... Delete Refresh

<input type="checkbox"/>	Host ID ^	IP Address	Host Name	Domain
<input type="checkbox"/>	1	192.168.55.22	hpss1	ca.avaya.com

Results Per Page: 10 Page 1 of 1

Figure 95: Domain Name Server (DNS) host added

Deleting a host

Perform the following procedure to delete a host value from the host table.

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Networking**.

The Networking screen appears, as shown in the following figure.



Figure 96: Networking window

3. In the Networking screen, select **DNS and Hosts**.

The Domain Name Server (DNS) screen appears, as shown in the following figure.




Figure 97: Domain Name Server (DNS) window

4. Select the host that you want to delete.

The Delete button becomes active.

5. Click **Delete**.

The Domain Name Server (DNS) screen appears and the host is removed, as shown in the following figure.




Figure 98: Domain Name Server (DNS) host removed

Adding a route entry

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Networking**.

The Networking screen appears, as shown in the following figure.



Figure 99: Networking window

3. In the Networking screen, select **Route Table**.

The Routes screen appears, as shown in the following figure.




Figure 100: Routes window

4. Click **Add**.

The New Route screen appears, as shown in the following figure.




Figure 101: New Route window

5. In the **Destination IP address** box, enter a value for the destination IP address.

Note:

Avaya recommends that the Call Server (CS) and Element Manager (EM) reside on the same subnet. When the CS and EM reside on different subnets, you must

configure a route from the EM server to the CS server, using the CS IP address as the destination address and the EM server ELAN gateway as the interface value.

6. In the **Gateway IP address** box, enter a value for gateway IP address.
7. In the **Destination netmask** box, you can enter a value for destination netmask.

Note:

You do not need to provide a netmask. If you do provide a netmask, the format must be 255.255.255.255.

8. In the **Interface** list, you can select a value for network interface.
9. Press **Save** to save your configuration changes.

OR

Press **Cancel** to discard your changes and return to the Routes screen.

Deleting a route entry

Perform the following to delete an entry from the routing table.

Note:

All routes configured in Base Manager have a Tag value of Manual. Routes with other Tag values are inserted by applications; these routes should only be modified or deleted by configuring the application. Do not use Base Manager to delete a route inserted by an application; this can lead to a malfunction in the application.

Procedure steps:

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Networking**.

The Networking screen appears, as shown in the following figure.



Figure 102: Networking window

3. In the Networking screen, select **Route Table**.

The Routes screen appears, as shown in the following figure.




Figure 103: Routes window

4. Select the route that you want to delete.
5. Click **Delete**.

The Route delete confirmation screen appears, as shown in the following figure.




Figure 104: Route delete confirmation window

6. Click **OK**.

The route is deleted, as shown in the following figure.




Figure 105: Route deleted window

Configuring Explicit Congestion Notification

Explicit Congestion Notification in the Internet Protocol allows the server and a router to exchange notifications in cases of network congestion. If the data network is relatively poor the Linux server can be given higher priority network routing treatment by enabling the explicit network congestion setting.

Note:

The routers in the network infrastructure must also support the explicit network congestion feature.

Procedure steps:

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Explicit Congestion Notification**.

The ECN screen appears, as shown in the following figure.



Figure 106: Explicit Congestion Notification window

3. Press **Enable** to enable Explicit Congestion Notification.

OR

Press **Disable** to disable Explicit Congestion Notification.

Date and time configuration

The following section contains the procedures to manually configure system date and time value and to synchronize the data and time with network time servers.

The NTP client running on the Linux element obtains time updates by polling an NTP server. The polling interval ranges from 64 to 1024 seconds. After a restart of the element or after NTP synchronization configuration, the initial polling interval is 64 seconds. As the clock stabilizes the interval doubles until it reaches the maximum of 1024 seconds. The polling interval decreases if the clock is not stable; the polling interval increases if the clock cannot be reached. For a newly installed system it can take an additional 15 minutes (approximately) for the clock to stabilize the first time synchronization occurs.

After the clock stabilizes, there can be situations where the NTP clock source time changes. In these situations you can use the Sync Now feature in Base Manager to force an immediate time synchronization, rather than wait as long as 1024 seconds for the next poll to occur.

Configuring system date and time

Prerequisites:

You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Note:

Internally there is no way to distinguish the Sync Now request failure caused by initial configuration having just been performed from other rare error conditions (such as NTP software not responding). Any errors from the Sync Now operation are ignored.

Note:

You can configure a maximum of 11 external clock source IP addresses for the primary NTP server; you can configure a maximum of 10 IP addresses for the secondary NTP server.

Procedure steps:

Perform the following procedure to manually configure system values for date and time. If you configure NTP parameters, synchronization is done automatically; you do not need to use the Sync Now feature.

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Date and Time**.

The date and Time screen appears, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)
Base System » Date And Time

Date and Time

The system clock may be set manually, or synchronized with a network time server.

Current System Date and Time Edit...

Manual time changes are not required if the server is synchronized to an external clock.

Date: 3/23/2009
Time: 13:26:24

Time Zone Edit...

Time Zone: (GMT-05:00) Eastern Time (US & Canada)
(with Daylight saving adjustments)

Network Time Protocol

Configure automatic date and time coordinated with network time servers.

Network Time Protocol Sync Now Edit...

Clock Source: Primary
Clock Type: Internal (Unreliable)

Figure 107: Date and Time window

3. Navigate to the **Current System Date and Time** section.
4. Click **Edit**.

The Edit Date and Time screen appears, as shown in [Figure 108: Edit Date and Time window](#) on page 158.

Figure 108: Edit Date and Time window

5. In the **Date** box, enter the date in the format yyyy-mm-dd.

⚠ Warning:

If you modify the date and time to a future value, your session expires and the initial Base Manager screen displays.

OR

Press the Browse (...) button to select the date from a calendar.

6. In the **Time** lists, select values for hours (hh) and minutes (mm).
7. Click **Save** to save your configuration changes.

OR

Press **Cancel** to discard your changes and return to the Date and Time screen.

8. Navigate to the **Time Zone** section.
9. Click **Edit**.

The Time Zone screen appears, as shown in the following figure.



Figure 109: Time Zone screen

10. In the **Time Zone** list, select a value for Time Zone.
11. Click **Save** to save your configuration changes.

OR

Press **Cancel** to discard your changes and return to the Date and Time screen.

Synchronizing date and time with network time servers

Prerequisites:

- You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps:

Perform the following procedure to synchronize system date and time values with network time servers.

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Date and Time**.

The date and Time screen appears, as shown in [Figure 110: Date and Time window](#) on page 160.




Figure 110: Date and Time window

3. Navigate to the **Network Time Protocol** section.
4. If you want to force an immediate time synchronization with the NTP server click **Sync Now**.

The time is synchronized with the NTP server and the procedure ends at this point.

5. Click **Edit**.

The Network Time Protocol screen appears, as shown in [Figure 111: Network Time Protocol window](#) on page 161.

Managing: 47.11.44.178 (Primary UCM security server)
 Base System » Date and Time » Network Time Protocol

Network Time Protocol

Transfer mode: Secure
 Insecure

Key ID: *(1-65535)

Private key: *

Confirm private key: *

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type: ▼

Type of clock source: Internal
 External

*Required value. Save Cancel

Figure 111: Network Time Protocol window

6. Perform [Configuring NTP transfer mode](#) on page 161
7. If you are configuring the clock source for a primary NTP server, perform [Configuring the clock source for a primary server](#) on page 162.
8. If you are configuring the clock source for a secondary NTP server, perform [Configuring the clock source for a secondary server](#) on page 164.
9. If you are configuring the clock source for a server that is not a clock source, perform [Configuring a server that is not a clock server](#) on page 166.

Configuring NTP transfer mode

Configure NTP to operate using a secure or insecure transfer mode. If you choose a secure transfer mode you must also provide a key ID and private key.

Prerequisites:

- You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps:

1. Navigate to the Transfer mode section.
2. If you want an insecure transfer mode select the **Insecure** option. Proceed to [7](#) on page 161 in [Synchronizing date and time with network time servers](#) on page 159.

OR

If you want a secure transfer mode select the **Secure** option.

3. In the **Key ID** field, enter a value for key ID.
4. In the **Private key** field, enter a value for private key.
5. Proceed to [7](#) on page 161 in [Synchronizing date and time with network time servers](#) on page 159.

Configuring the clock source for a primary server

Configure the clock source for a primary server.

Prerequisites

- You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps

1. Navigate to the Clock Source section.
2. Select **Primary** in the **NTP server type** list.
3. In the type of clock source list, select **Internal**, if you want an internal clock source.
4. In the type of clock source list, select **External**, if you want an external clock source.

If you select an external clock source, additional fields appear on the screen, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)
 Base System » Date and Time » Network Time Protocol

Network Time Protocol

Transfer mode: Secure
 Insecure

Key ID: *(1-65535)

Private key: *

Confirm private key: *

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type: ▼

Type of clock source: Internal
 External

External clock source IP address: *

Enter an IP address and click Add to add it to the list.

Figure 112: Primary server clock source window

5. In the **External clock source IP address** field, type a value for the external clock source IP address.
6. Click **Add**.

The value is added to the list of IP addresses, as shown in the following figure.

Managing: 192.168.55.128 (Primary UCM security server)
 Base System » Date and Time » Network Time Protocol

Network Time Protocol

Transfer mode: Secure
 Insecure

Key ID: 300 *(1-65535)

Private key:

Confirm private key:

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type: Primary server

Type of clock source: Internal
 External

External clock source IP address:

Add up to ten external clock sources in order of priority. The first item in the list will be used first. Enter an IP Address below and click Add to add it to the bottom of the list.

3.0.0.0

Figure 113: External clock source IP address window

7. If you want to remove a value from the IP address list, highlight the value and click **Remove**.
 8. Click **Save** to save the clock source configuration.
- OR**
- Click **Cancel** to return to the Date and Time screen.
9. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Configuring the clock source for a secondary server

Configure the clock source for a secondary server.

Prerequisites

You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps

1. Navigate to the Clock Source section.
2. Select **Secondary** in the **NTP server type** list.
3. In the **Primary NTP server IP address** field, type a value for the IP address of the primary NTP server.

4. In the Type of clock source list, select **Internal**. if you want an internal clock source.
5. In the Type of clock source list, select **External**. if you want an external clock source.

If you select an external clock source, additional fields appear on the screen, as shown in the following figure.

Managing: 192.168.55.128 (Primary UCM security server)
 Base System » Date and Time » Network Time Protocol

Network Time Protocol

Transfer mode: Secure
 Insecure

Key ID: 300 *(1-65535)

Private key: *

Confirm private key: *

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type: Secondary server ▼

Primary NTP server IP address: *

Type of clock source: Internal
 External

External clock source IP address: *

Add up to ten external clock sources in order of priority. The first item in the list will be used first. Enter an IP Address below and click Add to add it to the bottom of the list.

3.0.0.0

*Required value.

Figure 114: Secondary server clock source window

6. In the **External clock source IP address** field, type a value for the external clock source IP address.
7. Click **Add**.

The value is added to the list of IP addresses, as shown in the following figure.

Transfer mode: Secure
 Insecure

Key ID: *(1-65535)

Private key: *

Confirm private key: *

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type:

Primary NTP server IP address: *

Type of clock source: Internal
 External

External clock source IP address: *

Enter an IP address and click Add to add it to the list.

192.168.55.45	<input type="button" value="Remove"/>
192.168.55.22	

*Required value.

Figure 115: External clock source IP address (secondary server) window

8. If you want to remove a value from the IP address list, highlight the value and click **Remove**.
 9. Click **Save** to save the clock source configuration.
- OR**
- Click **Cancel** to return to the Date and Time screen.
10. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Configuring a server that is not a clock server

Configure the clock source for a server that is not a clock server.

Prerequisites

You must log on using a role from the systemadmin or timeadmin access groups to perform date and time configuration.

Procedure steps

1. Navigate to the Clock Source section.
2. Select **Not a clock server** in the **NTP server type** list.

The clock source fields appear, as shown in the following figure.

Managing: 47.11.44.19 (Backup UCM security server)
 Base System » Date and Time » Network Time Protocol

Network Time Protocol

Transfer mode: Secure
 Insecure

Key ID: *(1-65535)

Private key: *

Confirm private key: *

The length of the private key should be at most 16 characters where #, single quotes and spaces are not accepted.

Clock Source

NTP server type: ▼

Primary NTP server IP address: *

Secondary NTP server IP address:

*Required value.

Figure 116: Clock source fields for a server that is not a clock server

3. In the **Primary NTP server IP address** field type a value for the IP address of the primary NTP server.
4. In the **Secondary NTP server IP address** type a value for the IP address of the secondary NTP server.

Note:

Use of a secondary NTP server is optional.

5. Click **Save** to save the clock source configuration.

OR

Click **Cancel** to return to the Date and Time screen.

6. Return to the [Preconfiguring process using Deployment View](#) on page 75.

Regenerating SSH Keys for a UCM Member server

Use Regenerating SSH Keys for a UCM Member server to regenerate the SSH keys for a UCM Member server.

Note:

SSH key regeneration is only available for UCM Member servers. The option to regenerate SSH keys is not available for Primary UCM and Backup UCM servers.

Prerequisites:

- You must log on using a role from the Security Administrator access group to perform SSH key regeneration.

Procedure steps:

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **SSH Keys**.

The SSH Keys page appears, as shown in [Figure 117: SSH Keys page](#) on page 168.




Figure 117: SSH Keys page

3. Click **Regenerate now**.

The following message displays on the SSH Keys page:

The SSH host key has been successfully regenerated.

If the regeneration is not successful, the following message displays on the SSH Keys page:

SSH host key regeneration failed.

If you attempted to regenerate the keys on a server that is not a Member server, the following message displays on the SSH Keys page:

```
SSH host key regeneration only allowed on (Member UCM
server).
```

Software maintenance using Base Manager

Stopping or restarting applications can impact system operations. It may be desirable to gracefully idle down the system or transfer operations to other redundant devices before stopping or restarting. Restarting or stopping an application can affect other systems, as in the case of network wide virtual office or branch office. Restarting or stopping an application can also cause some applications to issue alarms or generate logs.

There are operational impacts and interactions among applications. Before you stop an application it may be necessary to stop dependent applications. The following table provides a list of interactions among applications.

Table 6: Applications and dependencies

Application	Impact
Base - all	Impacts base and all Avaya applications.
Jboss	Impacts all management applications. Note: The web session is disrupted if you restart Jboss.
SNMP	Affects the ability of other applications to send traps.
Database server	Impacts most applications (CS, SS, PD, SIPL, NRS, SubM, EM).
Signaling Server	Impacts TPS, CSV, VTRK, and PD.
Virtual Trunk (VTRK)	Impacts SS applications.
Connection Service (CSV)	Impacts TPS.
Terminal Proxy Server (TPS)	Can be stopped independently.
Personal Directory (PD)	Can be stopped independently.
SIP Proxy server	Can be stopped independently.
Gatekeeper	Can be stopped independently.
Network Connect Server	Can be stopped independently.

Application	Impact
Avaya - all	Impacts all higher level applications (all related to call processing).

Managing application status

Perform the following procedure to view the status of installed applications and to start, stop, or restart the applications.

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Software > Applications**.

The **Application Status** screen appears, as shown in the following figure.




Figure 118: Application Status window

3. Select an application from the application list.

Note:

If you select **Base All** you can only perform the status operation. If you select **Jboss** you can only perform status and restart operations. For all other applications status, start, stop, and restart operations are valid.

Note:

For start, stop, and restart operations, a confirmation message is displayed when you select the operation.

4. Click **Status** to display the status of the application.
5. Click **Start** to start the application.
6. Click **Stop** to stop the application.
7. Click **Restart** to restart the application.

View and export logs using Base Manager

Base Manager provides access to logs generated by installed applications. You can view the logs or you can export the logs to a file which can be saved locally.

Viewing application logs


1. Log on to UCM and navigate to Base Manager.

OR

Log on to the target server locally and navigate to Base Manager.

2. In the navigation pane, select **Tools**,

The Tools screen appears, as shown in the following figure.



Managing: 172.16.101.5 (Primary UCM security server)
Tools

Tools

[Logs](#)

Local server OAM event, security event and Application logs.

Figure 119: Tools window

3. In the Tools window, click **Logs**.

The Application Logs screen appears, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)

[Base System](#) >> Application

Application Logs

Local server OAM event, security event and Application logs

[Hide](#)

Enter criteria values and click View

Log type:

Limit log entries to: Filter string:

Log Entries

Click on View to see the content of the logs.
Click on Export to export the logs.

Figure 120: Application Logs window

4. In the **Log type** list, select an application log type.
5. In the **Limit log entries to: Filter string** box, enter a character string to limit the log entry search. If you leave the **Limit log entries to: Filter string** blank, the search returns all log entries.
6. Press **View**.

The application log entries appear, as shown in the following figure

Managing: 47.11.44.178 (Primary UCM security server)

Base System >> Application

Application Logs

Local server OAM event, security event and Application logs

[Hide](#)

Enter criteria values and click View

Log type: Limit log entries to: Filter string:

View

Export

Log Entries Found (1226)

Index	Date ^	Message
1	Mar 13 16:35:00	linuxbase: (INFO) Base: baseParams.pm(884); PID[27463]: File /admin/userinfo.bt is updated
2	Mar 13 16:35:00	linuxbase: (INFO) Base: baseParams.pm(1125); PID[27463]: Parameters updated successfully
3	Mar 13 16:35:00	linuxbase: (INFO) Base: baseParams.pm(1630); PID[27463]: Timezone configured
4	Mar 13 16:35:00	linuxbase: (INFO) Base: datetimeconfig(226); PID[27463]: TimeZone has been setup successfully
5	Mar 13 16:35:01	linuxbase: (INFO) Base: baseParams.pm(1152); PID[27463]: Set new date: Fri Mar 13 16:35:00 EDT 2009
6	Mar 13 16:35:01	linuxbase: (INFO) Base: baseParams.pm(1028); PID[27463]: Validation successful
7	Mar 14 10:14:00	linuxbase: (WARNING) Base: install_common.pm(695); PID[16332]: Cannot find /admin.avaya/install/install.xml.
8	Mar 14 10:14:00	linuxbase: (INFO) Base: common_functions.pm(290); PID[16332]: /admin/avaya/install/installedconfig does not exist.

Figure 121: Application Logs - search results window

Exporting application logs

1. Log on to UCM and navigate to Base Manager. For details about logging on to UCM and accessing Base Manager, see [Accessing Base Manager through UCM](#) on page 138.

OR

Log on to the target server locally and navigate to Base Manager. For details about logging on to the target server locally and accessing Base Manager, see [Accessing Base Manager through local logon](#) on page 140.

2. In the navigation pane, select **Tools, Logs, Application**.

The Application Logs screen appears, as shown in the following figure.

Managing: 47.11.44.178 (Primary UCM security server)

[Base System](#) >> Application

Application Logs

Local server OAM event, security event and Application logs

[Hide](#)

Enter criteria values and click View

Log type:

Limit log entries to: Filter string:

Log Entries

Click on View to see the content of the logs.
Click on Export to export the logs.

Figure 122: Application Logs window

3. In the **Log type** list, select an application log type.
4. In the **Limit log entries to: Filter string** box, enter a character string to limit the log entry search. If you leave the **Limit log entries to: Filter string** blank, the search returns all log entries.
5. Press **Export**
 - . A file download prompt appears, as shown in the following figure.




Figure 123: Application Logs - file download prompt window

6. Press **Open** to open a file that contains the application log entries.

OR

Press **Save** to save the application logs entries file locally.

Chapter 10: Disaster recovery

This chapter describes the prerequisites and procedures for Avaya Linux system disaster recovery on a Server. For more information about disaster recovery, see [Disaster recovery](#) on page 34.

Navigation

- [Prerequisites](#) on page 177
- [Performing disaster recovery for Avaya Linux Base](#) on page 177
- [UCM considerations for disaster recovery](#) on page 181
- [Changing Linux Base passwords](#) on page 182

Prerequisites

- You must have a system backup file stored on a USB device or SFTP server. Use [Backing up existing system data files](#) on page 114 to perform a system back up to an external SFTP or USB source.
- If a fault occurs in the existing Primary UCM Server and a system backup file is not available, you cannot restore the data; you must perform a fresh installation of a new Primary Server. For more information, see [UCM considerations for disaster recovery](#) on page 181.

Performing disaster recovery for Avaya Linux Base

Perform the following procedure to perform disaster recovery for an Avaya Linux Base on a Server.

1. Connect to the Server using the serial console or using the keyboard and video monitor (kvm).
2. Insert the Linux Base installation media. The installation media is either a DVD, USB, or CF card depending on your hardware platform.

⚠ Warning:

If using a Linux Base DVD on a COTS server, only insert the DVD in the drive during the Linux Base installation (this does not apply to Server cards). Normally the DVD auto-ejects after the Linux Base installation is complete. If the Linux Base DVD is accidentally left in the DVD drive after installation and a system restart occurs, the system will boot into the installation program. This can be interpreted as a hung system. If this occurs, eject the DVD and restart the system.

3. Restart the server.

Note:

For Server cards, re-seat the card to ensure a successful restart.

When the server boots up, the Avaya Communication Server 1000 (Avaya CS 1000) Linux Base System Installer window appears.

For Server cards, the Avaya CS 1000 Linux Base System Installer window appears, as shown in the following figure.




Figure 124: CS 1000 Linux Base system installer (Server cards)

OR

For COTS servers, the CS 1000 Linux Base System Installer window appears, as shown in the following figure.

```

ISOLINUX 3.11 2005-09-02 Copyright (C) 1994-2005 H. Peter Anvin
System Release:      cs1000-linuxbase-7.00.04.00-00
Build Timestamp:    Fri Mar 19 02:36:42 EDT 2010

Welcome to the CS 1000 Linux Base System Installer

- To install via a serial console on COM1, type com1 <ENTER>.
- To install via NFS network boot on COM1, type com1-nfs <ENTER>.
  All input and output will be directed to the COM1 serial port. The system
  console will be permanently installed on COM1.

- To install via an attached keyboard/monitor/mouse, type kvm <ENTER>.
- To install via NFS network boot on KVM, type kvm-nfs <ENTER>.
  All input and output will be directed to the attached keyboard/monitor/mouse.
  During installation, you will be given the opportunity to permanently
  install the system console on a user specified serial port. If you choose
  not to, the system console will be permanently installed on the attached
  keyboard/monitor/mouse.

  ***The default is --- com1***.

boot:

```

Figure 125: CS 1000 Linux Base system installer (COTS server)

4. Type `com1` or press `Enter` to install using a serial console on COM1.

OR

Type `kvm` to install using an attached keyboard and video monitor.

⚠ Warning:

If you log on to the COM1 port, make sure that **Caps Lock** is turned off before you log on.

The disaster recovery procedure uses steps in the new and upgrade Linux Base procedures, as referenced in the following steps.

5. If you are attempting a disaster recovery and the following screen appears, the disk is more than likely new, corrupted, or has been formatted. Proceed to follow the procedures in Step 5 on page 56 from [Installing a new Linux Base](#) on page 54.



Figure 126: CS 1000 Linux Base installer confirmation screen

OR

If you are attempting a disaster recovery and the following screen appears, the disk information is retrievable from the existing /admin partition. If the data stored in the /admin partition is not corrupt and you trust the content, proceed to follow the procedures in Step 8 on page 125 from [Upgrading Linux Base](#) on page 123.

Important:

If you are attempting to recover a server that has been upgraded from Communication Server 1000 Release 6.0 and does not have the latest backup data (either USB or SFTP), perform a backup data restore during the Linux Base installation. Performing a restore ensures a graceful reregistration to the UCM Security Domain and UCM Deployment Manager. During the Linux Base installation, select Option 2 or 3 at the Base Configuration Data Selection screen, as shown in Step 9 on page 126 from [Upgrading Linux Base](#) on page 123.

```

#####
#####
Installation of New Linux base Operating System
Existing Linux base release:
  System Release:      cs1000-linuxbase-7.50.07.00
  Build Timestamp:    Wed Sep 22 15:44:49 EDT 2010

New Linux base release:
  System Release:      cs1000-linuxbase-7.50.11.00
  Build Timestamp:    Tue Oct  5 18:49:16 EDT 2010

This is a Linux Base UPGRADE operation.
There is backup data available in the 'admin'
partition. This data could be reused, based on
the selection made at the subsequent
"Base Configuration Data Selection" stage.

#####
#####
Do you wish to proceed with installation (Y/N) [Y]? █

```

Figure 127: CS 1000 Linux Base system installer confirmation window

Note:

The disaster recovery process is not complete until you perform an application deployment and a patch deployment.

UCM considerations for disaster recovery

If a hardware fault occurs in a Primary UCM Server, there are security domain implications for backup and member servers that impact disaster recovery.

Primary UCM Server replacement

If a fault occurs on the Primary Security Server and a system backup archive is available, then the recovery operation on the new Primary UCM Server restores all Linux base system settings, UCM data, and application data.

- You do not need to rejoin backup or member servers to the security domain because the security domain does not change.
- The FQDN of the new Primary Server must be the same as the FQDN of the damaged Primary Server
- You must perform application deployment and patch deployment on the Primary UCM Server. For information about application deployment, see [Deployment Manager—New system installation and commissioning](#) on page 69. For more information about Linux patching, see *Avaya Patching Fundamentals, NN43001-407*.

If a fault occurs on the Primary Security Server and a system backup archive is not available, then the recovery of the Primary Server is not possible. You must perform a new installation

of the Linux base and Avaya applications, deploy and configure applications, perform patch deployment, and re-configure the system settings and security configuration. All member and backup servers must join the new security domain.

- **Backup UCM Server considerations in case of Primary UCM Server replacement**

If you restore the Primary UCM Server from a system backup archive, no action is required for the existing Backup UCM Server.

Note:

If the IP address of the Primary Server changes, the backup security server must use the new IP address.

If a fault occurs on the Primary Security Server and a system backup archive is not available, you must perform a new installation. In this case, the security domain is changed and you must either demote the existing backup server to a member server in the new domain, or perform a fresh installation and rejoin the security domain as a backup server. For information about demoting a backup server, see *Unified Communications Management Common Services Fundamentals, NN43001-116*.

Note:

The Backup UCM Server application data can be restored using the command `sysrestore --deployed_apps`. This command restores deployed Avaya applications only; it does not restore base applications.

Member UCM Server considerations in case of Primary UCM Server replacement

If you restore the Primary UCM Server from a system backup archive, no action is required for the existing Member UCM Server.

Note:

If the IP address of the Primary Server changes, the member servers must use the new IP address.

If you perform a fresh installation of the Primary UCM Server (there is no backup archive), the member server must join the new security domain.

Changing Linux Base passwords

Perform the following procedure to change the Avaya Linux Base passwords for the root or admin2 accounts.

Prerequisites:

- Ensure you have physical access to the system.
- Ensure you have access to the serial COM port of the Linux server.
- Ensure you have the Linux Base installation media.
 - USB 2.0 memory stick for CP DC and CP MG cards

- DVD for COTS Servers
- RMD for Server cards

Procedure steps:

1. Insert the Linux Base installation media.
2. Restart the system.
3. If you connect to the server through the COM1 console, type `recovery-com1` in the CS 1000 Linux Base system installer screen and press `Enter`.

OR

If you connect to the server using a keyboard and video monitor (kvm) type `recovery-kvm` in the CS 1000 Linux Base system installer screen, and press `Enter`.

Note:

If you connect to the IBM x3350 server with a terminal for setup, the server does not function with the serial cable that was previously shipped with the ISP 1100 or other COTS platforms. The IBM x3350 server requires the new NTRX26NPE6 9 pin female to 9 pin female null modem cable. For a picture of the null modem cable, see [Figure 180: NTRX26NPE6 9 pin female to 9 pin female null modem cable](#) on page 237.

The Recovery Console menu appears, as shown in the following figure.

```
Recovery Console: Please, be careful. You may break your system.

You may choose to do one of the following:
1) Boot loader recovery
2) Password recovery
3) Check installation media
4) Log files inspection
5) Recovery shell
6) Check file system
7) Reboot system
Select an option (1-7):
```

Figure 128: Recovery Console window

4. Select option 2 for password recovery and press `Enter`.

The Password recovery screen appears, as shown in the following figure.

```
Password recovery:
You may change password one of the following users:
1) root
2) admin2
3) exit
Select an option (1-3):2

For security reasons, password entry keystrokes
will not be shown as they typed.
Please ensure you type the correct password.
A valid password should be a mix of upper and
lower case letters, digits, and other characters.
You can use an 8 character long password with
characters from at least 3 of these 4 classes.
An upper case letter that begins the password
and a digit that ends it do not count towards
the number of character classes used.

new password:
repeat password:
User password has been changed successfully!
Press <Enter> to continue:
```

Figure 129: Password recovery window

5. Type the option number for the password that you want to change, and press Enter.
6. Enter the new password. For password creation guidelines, see [Password creation guidelines](#) on page 34.
7. Reenter the new password.
8. Press Enter.

Appendix A: Hardware platforms

The Linux Base is supported on various hardware platforms. For more information on the supported hardware platforms, see [Supported hardware platforms](#) on page 17.

Important:

Instructions to install a commercial off-the-shelf (COTS) server is not included in this document. Detailed installation instructions can be found in the documentation shipped with the server.

This section contains general instructions to install a Server. This section also includes instructions to connect all types of servers to the ELAN and TLAN subnets of an Avaya Communication Server 1000 (Avaya CS 1000) system and to connect a maintenance terminal to each type of Server.

Navigation

- [Creating a bootable RMD for Linux Base installations](#) on page 186
- [Hardware installation checklist](#) on page 191
- [CP PM card](#) on page 192
- [CP DC card](#) on page 205
- [CP MG card](#) on page 205
- [Dell R300 server](#) on page 205
- [HP DL320 G4 server](#) on page 213
- [HP DL360 G7 server](#) on page 221
- [IBM x306m server](#) on page 226
- [IBM x3350 server](#) on page 236

Configuring the privilege level for Windows Vista or Windows 7

If you are using Windows Vista or Windows 7, configure the privilege level to run as administrator prior to creating a bootable RMD for Linux installations

1. Create a temporary folder on your local drive.
2. Open a Web browser window and navigate to <http://www.avaya.com>.
3. Navigate to **Support > Downloads**.
4. Select the Release number from the list, and click the required software load zip file for the server platform, for example **Communication Server 1000 Software Downloads – Release x.x**.

Note:

The default release is 7.5.x.

5. Click the **Downloads** tab.
6. Click the software load zip file, for example, cs1000–linuxbase-7.5.017.00_cf.exe.
7. Unzip the files in the software load zip file to the newly created temporary folder. The following folders appear in the temporary folder:
 - baseapps
 - extra
 - license
 - relnotes
 - scripts
 - utilities
8. Open the **utilities** folder.
9. Right-click **syslinux.exe**, and select **Properties**.
10. Click the **Compatibility** tab.
11. In the **Privilege level** section, select the **Run this program as administrator** check box.
12. Click **Apply** and click **OK** to exit the syslinux properties window.
13. You can now proceed to [Creating a bootable RMD for Linux Base installations](#) on page 186.

Creating a bootable RMD for Linux Base installations

Linux Base installation requires the following bootable Removable Media Device (RMD):

- CP PM require a Compact Flash (CF) card.
- CP DC and CP MG require a USB memory stick.

Important:

To ensure that the latest boot loader is installed on the media boot sector, use a clean disk and repeat the steps in this procedure for every new software load.

Prerequisites:

- You must have a Compact Flash (CF) card or USB 2.0 memory stick with a capacity of at least 2 GB.
- You must use the correct bootable device for your hardware type:
 - CP PM requires a Compact Flash (CF) card.
 - CP DC and CP MG requires a USB memory stick.

Note:

The N0220961 USB memory stick is supported for CS 1000. Not all USB memory sticks are supported.

- If you are using Windows Vista or Windows 7, you must configure the Privilege Level, see [Configuring the privilege level for Windows Vista or Windows 7](#) on page 185.

Procedure steps:

1. Create a temporary folder on your local drive.
2. Open a Web browser window, and go to <http://www.avaya.com>.
3. Navigate to **Support > Downloads**.
4. Select the Release number from the list, and click the required software load zip file for the server platform, for example **Communication Server 1000 Software Downloads – Release x.x**.

Note:

The default release is 7.5.x.

5. Click the **Downloads** tab.
6. Click the software load zip file, for example, cs1000–linuxbase-7.5.017.00_cf.exe.
7. Unzip the files in the software load zip file to the newly created temporary folder.

The following folders appear in the temporary folder:

- baseapps
- extra
- license
- relnotes
- scripts
- utilities

8. Open the **utilities** folder.
9. Double-click the **mkbootrmd.bat** file, and press any key to continue, as shown in the following figure.




Figure 130: mkbootrmd.bat screen

10. At the prompt, **Please enter the Drive letter of your RMD**, type a drive letter, as shown in the following figure.
11. At the prompt, **Create bootable Compact flash or USB stick**, select either **c** for Compact Flash or **u** for USB device, as shown in the following figure.




Figure 131: Select bootable media screen

Important:

If the USB memory stick is selected, some additional files are copied to overwrite the files for a Compact Flash installation, the following message appears, Configuring for USB install. The same is also true if the Compact Flash is selected; however, the additional files are copied to overwrite the files for a USB stick.

12. Select **Yes** if you want to proceed.

OR

Select **No** to return to the drive selection screen, or **Abort** to exit the utility without making changes to the selected drive, as shown in the following figure.

```

C:\WINDOWS\system32\cmd.exe
*
* -----
* THIS UTILITY FORMATS THE RMD
* THE DATA ON THE CARD WILL BE ERASED...!
*
*
* This utility creates Bootable RMD for CS1000,
* which can be used to boot a system with a CPMG, CPDC, or
* CPMG processor.
*
* This utility assumes that the drive entered is correct.
* So, please enter the correct RMD drive.
*
* For more information please read README_BOOTABLE_RMD.txt
*
* *****
Press any key to continue . . .
Please enter the Drive letter of your RMD:J
Create bootable Compact flash or Usb stick (C/U)? [C] U
Install files will be configured for a Usb flash drive.
Note: Only the CPMG and CPDC support USB install. CPMG only supports CF install.
Drive J: will be formatted, do you wish to proceed(Yes/No/Abort)? [N]

```

Figure 132: Confirmation screen

Important:

USB 2.0 memory stick is the only media supported for CP MG and CP DC. USB 1.0 and 1.1 are not supported. USB and CF have the same size requirements.

13. Copy the distribution image from the temporary folder to your installation media. You must always reformat your installation media using `mkbootrmd.bat` before you copy the distribution image from the temporary folder to your installation media.

Important:

- Do not unzip the software load zip file directly to the installation media.
- Do not copy the contents of the temporary folder to the installation media without first running `mkbootrmd.bat`.
- Do not copy the contents of the temporary folder to an installation USB if `mkbootrmd.bat` was most recently run selecting the CF option.
- Do not copy the contents of the temporary folder to an installation CF if `mkbootrmd.bat` was most recently run selecting the USB option

Important:

If you do not select the correct bootable device for your hardware type (as described in the preceding Prerequisites), you must repeat the procedures in Creating a bootable RMD for Linux Base installations; otherwise, you receive error messages, as shown in the following table.

Table 7: Error messages when using the incorrect bootable device

Error condition:	Error message:
<p>If a USB is created as a bootable Compact Flash by mistake and com1-nfs install is used on a CP DC or CP MG, and the error message appears on the COM port console.</p>	<pre>----- Networking Device ----- You have multiple network devices on this system. Which would you like to install through? eth - Intel Corporation Unknown device 5045 eth0 - Intel Corporation Unknown device 5049 eth1 - Intel Corporation Unknown device 5041 OK Identify Back</pre>
<p>If a USB is created as a bootable Compact Flash by mistake and com1 install is used on a CP DC or CP MG, and the error message appears on the COM port console.</p>	<pre>---- Error Downloading kickstart file ----- Unable to download the kickstart file. Please modify the kickstart parameter below or press Cancel to proceed as an interactive installation. hd:hdc1:/ks_cppm.cfg OK Cancel</pre>
<p>If a Compact Flash is created as a bootable USB by mistake and com1-nfs install is used on a CP PM, the user would see slow message output, a messy display, and the error message appears on the COM port console after IP input.</p>	<pre>---- Deployment Target booting error ---- Unable to access files on Deployment Server. Check the connection from the Deployment Server (e.g. ping) If it is reachable from the Deployment Server, check: 1. Does the data network block NFS traffic? 2. Is this target 'Committed' in the Deployment Manager servers view? 3. Is NFS 'enabled' in the Deployment Manager servers view? If it is not reachable from Deployment Server, check: 1. ELAN/TLAN in the Deployment Manager view are not interchanged. 2. Valid IP settings are provided. 3. A valid Deployment Server TLAN IP Address is provided. 4. The physical cable connectivity of your ELAN/TLAN interfaces. 5. Ensure that proper TLAN routing on data network is enabled. Please press OK to proceed to reboot. OK</pre>
<p>If a Compact Flash is created as a bootable USB by mistake and com1 install is used on a CP PM, the user would see slow message output, a messy display, and the error message appears on the COM port console after IP input.</p>	<pre>----- Error downloading kickstart file ----- Unable to download the kickstart file. Please modify the kickstart parameter below or press Cancel to proceed as an interactive installation. hd:sdb1:/ks_usb.cfg OK Cancel</pre>

Hardware installation checklist

Before installing a Signaling Server in a CS 1000 system, complete the following checklist.

⚠ Warning:

Do not modify or use a supplied AC-power cord if it is not the exact type required in the region where you install and use the Signaling Server. Be sure to replace the cord with the correct type.

Table 8: Installation checklist

Have you:
Received all server equipment and peripherals? For a COTS server: <ul style="list-style-type: none"> • installation accessories for rack-mounting the server • AC-power cord • a DTE-DTE null modem cable (supplied) • NTE90672: Linux Signaling Server software DVD for COTS servers For an Avaya CS 1000M Server cards (NTDW66 CP PM and NTDW54 CP DC) <ul style="list-style-type: none"> • CP PM Signaling Server Linux Upgrade kit (CP PM only), which includes <ul style="list-style-type: none"> - CP PM Hard Drive kit (optional, provided if required) - 2 GB Compact Flash (CF) with Linux software, 2 GB blank CF - 1 GB DDR SO-DIMM memory upgrade (optional, provided if required) • NTAK19ECE6: 2 port SDI Cable assembly kit • NTDW69AAE5: Large System Cabling kit • a DTE-DTE null modem cable (supplied) <p>Note: Save the packaging and packing materials in case you must ship the equipment or peripherals.</p>
Made sure the area meets all environmental requirements?
Checked for all power requirements?
Verify the CP PM hardware meets all required specifications (2GB ram, 40GB hard drive, CP PM BIOS version 18 or higher)?
Checked for correct grounding facilities?
Obtained the following?

Have you:
<ul style="list-style-type: none">• screwdrivers• an ECOS 1023 POW-R-MATE or similar type of multimeter• appropriate cable terminating tools• a computer (maintenance terminal) to connect directly to the Signaling Server, with:<ul style="list-style-type: none">- teletype terminal (ANSI-W emulation, serial port, 9600 bps)- a Web browser for Element Manager (configure cache settings to check for new Web pages every time the browser is invoked, and to empty the cache when the browser is closed)
Prepare the network data as suggested in <i>Avaya Converging the Data Network with VoIP, NN43001-260</i> and <i>Avaya Communication Server 1000E: Planning and Engineering, NN43041-220</i> or <i>Avaya Communication Server 1000M and Meridian 1: Large System Planning and Engineering, NN43021-220</i> , as appropriate for your Avaya CS 1000 system?
Read all safety instructions in <i>Avaya Communication Server 1000E Installation and Commissioning, NN43041-310</i> or <i>Avaya Communication Server 1000M and Meridian 1 Large System Installation and Commissioning, NN43021-310</i> , as appropriate for your Avaya CS 1000 system?

CP PM card

The Common Processor Media Card is a Server card that you can deploy as a VxWorks Call Server, a Linux Base Signaling Server, or a Linux Base Co-resident Call Server and Signaling Server (Co-res CS and SS).

The CP PM card is available in multiple variants:

- a single slot card for CS 1000E systems (NTDW61)
- a double-slot card for CS 1000M systems (NTDW66)
- a single slot metal faceplate for CS 1000E systems (NTDW99)

Note:

Co-res CS and SS can only be installed on a NTDW61BAE5 CP PM server.

Avaya Linux Base requires CP PM servers to meet criteria for disk size, memory size, and BIOS version. Perform the following procedures to determine CP PM disk size, CP PM memory size, and CP PM BIOS version, and to upgrade the CP PM BIOS version.

Note:

If you require IPv6 on CP PM platforms, Avaya recommends that you use a dedicated third-party hardware firewall.

Determining CP PM disk size

Perform the following procedure to determine the CP PM disk size.

1. Connect to the CP PM server remotely by using SSH or locally by using a serial port.

Important:

The Avaya NTAK19EC cabling kit is required to connect a maintenance terminal to the serial port of a CP PM or CP DC card as follows.

- to adapt the 50-pin MDF connector at the back of the CS 1000E Media Gateway or the CS 1000M Universal Equipment Module (UEM) to a 25-pin DB connector
 - a 25-pin to 9-pin straight-through serial cable (not supplied) is required to connect the 25-pin DB connector to a 9-pin serial port on the maintenance terminal
2. Log on to the CP PM server in a systemadmin role.
 3. Issue the Linux `hdparm` command:

The disk size appears as shown in the following figure.

```
[root@davecppm3 dev]# /sbin/hdparm -I /dev/hda
/dev/hda:
ATA device, with non-removable media
Model Number: ST940815A
Serial Number: 5LX09DNH
Firmware Revision: 3.ALD
Standards:
Used: ATA/ATAPI-6 T13 1410D revision 2
Supported: 6 5 4 3
Configuration:
Logical max current
cylinders 16383 65535
heads 16 1
sectors/track 63 63
--
CHS current addressable sectors: 4128705
LBA user addressable sectors: 78140160
LBA48 user addressable sectors: 78140160
device size with M = 1024*1024: 38154 MBytes
device size with M = 1000*1000: 40007 MBytes (40 GB)
Capabilities:
LBA, IORDY(can be disabled)
bytes avail on r/w long: 4 Queue depth: 1
:
:
```

Figure 133: CP PM disk size

Determining CP PM memory size

Perform the following procedure to determine the CP PM memory size.

1. Connect to the CP PM server remotely by using SSH or locally by using a serial port.
2. Log on to the CP PM server.
3. Issue the Linux command to read the /proc/meminfo file.

The command and results appear in the following figure.

```
[ avaya@ccVxELL cppm ~]$ cat /proc/meminfo
MemTotal: 1023548 kB <- need to update with 2G nums
MemFree: 841920 kB
Buffers: 28732 kB
Cached: 120380 kB
SwapCached: 0 kB
```

Figure 134: CP PM memory size

BIOS methods

This section provides the procedures for determining and upgrading the CP PM BIOS.

Determining CP PM BIOS Method 1

Determine the CP PM BIOS Method 1.

1. Power up the CP PM hardware.
2. Observe the CP PM BIOS output in the bootup screen, as shown in the following figure.

```
+-----+
| System BIOS Configuration, (C) 2005 General Software, Inc.
+-----+
| System CPU : Pentium M | Low Memory   : 632KB |
| Coprocessor: Enabled  | Extended Memory : 1011MB |
| Ide 0 Type : 3        | Serial Ports 1-2 : 03F8 02F8 |
| Ide 1 Type : 3        | ROM Shadowing   : Enabled |
| Ide 2 Type : 3        | BIOS Version    : NIDU74AA 18 |
+-----+
Press F to force board to boot from faceplate drive.
```

Figure 135: CP PM boot up window

3. If the BIOS needs to be updated, see [Upgrading the CP PM BIOS](#) on page 196

Determining CP PM BIOS Method 2

Determine the CP PM BIOS Method 2.

1. Connect to the CP PM server remotely by using SSH or locally by using a serial port.
2. Log on to the CP PM server.
3. Type the Linux command to read the cppmHWInfo.dat file in the /etc/opt/avaya/base folder.

The BIOS version appears as shown in the following figure.

```
[avaya@ccVxELL_cppm~]$ cat /ect/opt/avaya/cppmHWInfo.dat
BIOSVer: NTDU74AA18
MSP430Ver: 12
Slot: 3
PECSerial: NTDW61BAE5 NNTMG19Y7VJ0
```

Figure 136: CP PM BIOS version display

Upgrading the CP PM BIOS

Upgrade the BIOS on a CP PM server.

Prerequisites:

- You must have a bootable Removable Media Device (RMD) Compact Flash (CF).
 1. Connect to serial port 1 on the CP PM server.
 2. Insert the Linux Base installation CF card into the faceplate CF slot.
 3. Power on the system.

Once the initial boot and memory check completes, the CP PM initial boot screen appears.

4. Press the F key to boot from the Linux Base installation faceplate CF card.
5. Press ENTER to direct the input and output to COM1.

The CS 1000 Linux Base system installer (CP PM server) screen appears, as shown in the following figure.

```

Welcome to the CS 1000 Linux Base System Installer

To install via a serial console on COM1, type com1 <ENTER>.
All input and output will be directed to the COM1 serial port. The system
console will be permanently installed on COM1.

***The default is --- com1***.

*** WARNING ***

CP-PM BIOS must be at least release 18 or Linux boot-up will fail.

```

Figure 137: CS 1000 Linux Base system installer (CP PM server)

If the CP PM server BIOS version is lower than 18, the BIOS upgrade screen appears, as shown in the following figure.

```

#####
#
#   CP-PM BIOS version is less than 18. BIOS upgrade is required.   #
#
# To complete the upgrade, BIOS settings must be changed to defaults. #
#   Please refer to the documentation for more information.         #
#
#####

Do you want to upgrade BIOS ROM up to the version 18? (yes/no): yes

BIOS ROM upgrade. Please wait...

BIOS ROM upgrade is finished.

Machine will be rebooted right now... Press Enter key to continue

```

Figure 138: CP PM BIOS upgrade window

6. Type `yes` to proceed with the automatic upgrade.
7. Verify that the BIOS upgrade is finished.
8. Press `F` to restart the server.
9. During the restart memory check, press `Ctrl c` to access the CP PM BIOS setup menu.

Note:

If you miss the timing to press `Ctrl c` you must restart the system and try again. The Linux Base installation software displays a warning if you do not reset the CP PM BIOS to factory defaults.

The CP PM BIOS setup screen appears, as shown in the following figure.

```
System BIOS Setup - Utility v5.3
(C) 2005 General Software, Inc. All rights reserved
-----

Basic CMOS Configuration
Features Configuration
Custom Configuration
PnP Configuration
Start System BIOS Debugger
Reset CMOS to last known values
>Reset CMOS to factory defaults
Write to CMOS and Exit
Exit without changing CMOS

-----

^E/^Z/^Tab> to select. <Esc> to continue (no save)
www.gensw.com
```

Figure 139: CP PM BIOS setup window

10. Select **Reset CMOS to factory defaults** from the menu.

The CP PM BIOS reset screen appears, as shown in the following figure.

```

-----
                        System BIOS Setup - Utility v5.3
                (C) 2005 General Software, Inc. All rights reserved
-----

                        Basic CMOS Configuration
                        Features Configuration
+-----+
| Reset CMOS to factory defaults? (Y/N): y |
+-----+

                        Reset CMOS to last known values
                        Reset CMOS to factory defaults
                        Write to CMOS and Exit
                        Exit without changing CMOS

-----

^E/^X/<Tab> to select. <Esc> to continue (no save)
                        www.genSW.com

```

Figure 140: CP PM BIOS reset window

11. Press `y` to reset CMOS to factory defaults.
12. The system restarts. After initial boot, the CP PM initial boot screen appears and the new BIOS version is displayed. Verify the BIOS version is 18. You can now press the F key to boot from the faceplate CF card and proceed with the Linux Base software installation.

CP PM Signaling Server

This section contains instructions to install and connect the NTDW61BAE5 and NTDW66AAE5 models of the CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000E and CS 1000M system, respectively. The CP PM Signaling Server is a circuit card and therefore is not mounted in a rack. This section also contains instructions to connect a maintenance terminal to the CP PM Signaling Server.

The NTDW61BAE5 model of the CP PM Signaling Server is designed for use in a CS 1000E system. It is inserted into a slot of the Media Gateway (MG 1000E or MG 1000B). The Media Gateway also hosts the Gateway Controller that has Ethernet ports for connecting to the ELAN and TLAN subnets of your CS 1000 system. However, it is common in a CS 1000E system for the Call Server to connect to the Gateway Controller through the ELAN port. If the Call Server does not connect to the Gateway Controller through this port, the NTDW61BAE5 model of the CP PM Signaling Server uses it to connect to the ELAN subnet of the CS 1000E system. If the Call Server uses the Gateway Controller ELAN port, the CP PM Signaling Server connects

directly to the ELAN and TLAN Ethernet switches from the faceplate ELAN and TLAN Ethernet ports.

The NTDW66AAE5 model of the CP PM Signaling Server is designed for use in a CS 1000M system. It is inserted into a slot of a Universal Equipment Module (UEM). UEMs do not have built-in ELAN and TLAN Ethernet ports. These Ethernet ports must be installed on the back of the UEM to enable the CP PM Signaling Server to connect to the ELAN and TLAN subnets of your CS 1000 system.

The following figure shows the faceplates of the two models of the CP PM server with labeling for all components (NTDW61BAE5 on the left and NTDW66AAE5 on the right).




Figure 141: Faceplates of the CP PM server

Refer to the preceding figure when you perform the following procedures.

Connecting a CP PM Signaling Server

Perform the following procedure to connect a CP PM Signaling Server.

1. Establish a maintenance terminal connection at the back of the Media Gateway (CS 1000E) or Universal Equipment Module (CS 1000M) shelf.

The com (SDI) port of the CP PM server is routed through the backplane to the 50-pin MDF connector on the back of the MG or UEM shelf. A special cable (NTAK19EC) ships with the CP PM server that adapts the 50-pin MDF connector to a 25-pin DB connector. You need a 25-pin to 9-pin straight-through serial cable to connect from the 25-pin DB connector to the serial port on the back of your PC.

- a. Connect the NTAK19EC cable (shipped with the CP PM server) to the 50-pin MDF connector on the back of the shelf.
 - b. Connect a 25-pin to 9-pin straight-through serial cable to the 25-pin DB connector at the end of the NTAK19EC cable.
 - c. Connect the other end of the serial cable to the serial port on the maintenance terminal.
2. Insert the CP PM server into the slot corresponding to the shelf where you connected the NTAK19EC cable.

The server is hot-pluggable so you can insert it without powering off the system.

The maintenance terminal is now connected to the server.

3. Connect the CP PM Signaling Server to the ELAN and TLAN subnets of the CS 1000 system.
 - If you have a CS 1000E system, perform [Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000E system](#) on page 203.
 - If you have a CS 1000M system, perform [Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000M system](#) on page 204.
4. Configure the baud rate for the serial port on the Signaling Server to 9600 bits per second.

Note:

The CP PM Signaling Server ships with the serial port configured to 9600 bits per second.

To verify or change the baud rate on a CP PM Signaling Server, see [Changing the baud rate on a CP PM Signaling Server](#) on page 202.

5. Configure the connected maintenance terminal.

Changing the baud rate on a CP PM Signaling Server

Perform this procedure to verify or change the baud rate on a CP PM Signaling Server.

1. Press the **RST** button on the faceplate of the Signaling Server to boot the Signaling Server.
2. Press **Ctrl+C** keys at the same time to invoke the BIOS Setup menu.

The CP PM System BIOS Menu screen appears.

```

System BIOS Setup - Custom Configuration
(c) 2005 General Software, Inc. All rights reserved

>Basic CMOS Configuration
Features Configuration
Custom Configuration
  PnP Configuration
  Start System BIOS Debugger
  Reset CMOS to last known values
  Reset CMOS to factory defaults
  Write to CMOS and Exit
  Exit without changing CMOS

AE/AX/<Tab> to select. <Esc> to continue (no save)
www.gensw.com

```

Figure 142: CP PM System BIOS menu

3. Navigate to **Custom Configuration** and select the option.

The Custom Configuration screen appears.

```

System BIOS Setup - Custom Configuration
(c) 2005 General Software, Inc. All rights reserved

UART 1      : Enabled      | UART 2      : Enabled
UART 1 Address : 3F8h         | UART 2 Address : 2F8h
UART 1 IRQ    : 4           | UART 2 IRQ    : 3
UART 1 Baud Rate : >9600    | UART 2 Baud Rate : 9600
UART 1 Data Length : 8       | UART 2 Data Length : 8
UART 1 Parity  : NONE      | UART 2 Parity  : NONE
UART 1 Stop Bits : 1       | UART 2 Stop Bits : 1

CPU side      : side 0
Loop          : 0 0 0
Shelf        : 0

AE/AX/AE/AX/<Tab> to select or +/- to modify save)
<Esc> to return to main menu

```

Figure 143: CP PM Customer Configuration

4. Navigate to the **UART 1 Baud Rate** option and change as necessary.
5. Navigate to the **UART 2 Baud Rate** option and change as necessary.

Note:

UART 2 connection does not print BIOS messages.

6. Press **Esc** to save the settings and return to the BIOS Menu screen.
7. Select **Write to CMOS and Exit** to exit the CP PM server BIOS menu.

Installation in a CS 1000E system

The NTDW61BAE5 model of the CP PM Signaling Server is designed for use in an Avaya CS 1000E system. The first task that must be performed is to install the hard drive shipped with the server.

You can insert the NTDW61BAE5 model of the CP PM server into any slot of a CS 1000E Media Gateway (MG 1000E or MG 1000B) or 11C cabinet or chassis, except slot 0. Slot 0 is reserved for a Small System Controller (SSC) card or a Gateway Controller. Keying prevents the NTDW61BAE5 model from being inserted into this slot.

 Warning:

Do not insert the NTDW61BAE5 model of the CP PM server into any slot of a CS 1000M Universal Equipment Module (UEM). Doing so can cause electrical shorts on adjacent circuit cards.

Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000E system

Perform the following procedure to connect a CP PM Signaling Server (model NTDW61BAE5) to the ELAN and TLAN subnets of a CS 1000E system.

1. Connect the Signaling Server to the ELAN subnet.
 - if the CS 1000 Call Server is not connected to the Gateway Controller.
 - Insert the end of one customer supplied 25-cm RJ-45 CAT5 Ethernet cable into the ELAN network interface port (ELAN port) on the faceplate of the CP PM Signaling Server.
 - Insert the other end of the 25-cm RJ-45 CAT5 Ethernet cable into the Gateway Controller ELAN Ethernet port.

- if the CS 1000 Call Server is connected to the Gateway Controller
 - Insert the end of a longer RJ-45 CAT5 Ethernet cable (not supplied) into the ELAN network interface port (ELAN port) on the faceplate of the CP PM Signaling Server.
 - Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the ELAN Ethernet switch.
- 2. Connect the Signaling Server to the TLAN subnet.
 - if the CS 1000 Call Server is not connected to the Gateway Controller
 - Insert the end of one customer supplied 25-cm RJ-45 CAT5 Ethernet cable into the TLAN network interface port (TLAN port) on the faceplate of the CP PM Signaling Server.
 - Insert the other end of the 25-cm RJ-45 CAT5 Ethernet cable into the Gateway Controller TLAN Ethernet port.
 - if the Call Server is connected to the Gateway Controller
 - Insert the end of a longer RJ-45 CAT5 Ethernet cable (not supplied) into the TLAN network interface port (TLAN port) on the faceplate of the CP PM Signaling Server.
 - Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the TLAN Ethernet switch.

Note:

If the Call Server is connected to the Media Gateway Controller, you must obtain CAT5 Ethernet cables that are long enough to connect the Signaling Server directly to the ELAN and TLAN Ethernet switches from the faceplate ELAN and TLAN Ethernet ports.

Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000M system

Perform this procedure to connect a CP PM Signaling Server (model NTDW66AAE5) to the ELAN and TLAN subnets of a CS 1000M system.

Important:

IMPORTANT!

Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000M system causes a service disruption.

1. Insert the end of an RJ-45 CAT5 Ethernet cable (not supplied) into the ELAN network interface port (ELAN port) on the back of the CS 1000M UEM.

You installed this ELAN port at the back of the UEM when you installed the Signaling Server in the UEM.

2. Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the ELAN Ethernet switch.
3. Insert the end of another RJ-45 CAT5 Ethernet cable (not supplied) into the TLAN network interface port (TLAN port) on the back of the CS 1000M UEM.

You installed this TLAN port at the back of the UEM when you installed the Signaling Server in the UEM.

4. Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the TLAN Ethernet switch.

CP DC card

The Common Processor Dual Core (CP DC) server is a dual core platform required for many of the new applications such as Media Application Services (MAS) and CS 1000 SIP Trunk Bridge. It can also be used for Co-Res CS and SS systems up to approximately 800 users with a Media Gateway Card.

CP MG card

The CP MG card functions as a Server and the Gateway Controller while occupying slot zero in a chassis, cabinet and MG 1010.

- CP MG 32: This hardware is a combination Server and a Gateway Controller with 32 DSPs. It frees up a slot and is used in a Co-Res CS and SS mode for cost effective solution for Branch Offices under 100 users.
- CP MG 128: This hardware is a combination Server and a Gateway Controller with 128 DSPs. It frees up a slot and is the standard solution for Co-Res CS and SS systems for up to approximately 800 users and for Branch Offices.

Dell R300 server

The Dell R300 server provides the following features:

- Intel Xeon (quad-core) processor
- Two 80 GB SATA Hard drives (1 configured)
- Four GB PC2-4200 ECC DDR2 SDRAM (2 GB configured)

- Two 10/100/1000BaseT Ethernet ports
- Three USB ports
- One CD-R/DVD ROM drive
- One serial port
- A reset button

The following figure shows the front view of the Dell R300 server.



Figure 144: Dell R300 server front view

The following figure shows the rear view of the Dell R300 server.

DELL R300 (Rear View)




Figure 145: Dell R300 server rear view

Configuring the COM1 serial port on a Dell R300 server

Perform the following procedure to configure the COM1 serial port.

1. Press **F2** to navigate to the BIOS configuration main menu screen using a Keyboard Video Monitor (KVM) terminal.

OR

Press **ESC-2** to navigate to the BIOS configuration main menu screen using the console terminal.

The BIOS configuration main menu screen appears, as shown in [Figure 146: BIOS configuration main menu window](#) on page 207.

```

Dell Inc. (www.dell.com) - PowerEdge R300
BIOS Version 1.2.0
*****
* Service Tag: 10KS4G1          * Asset Tag:
*****
System Time ..... 17:14:13
System Date ..... Fri Dec 05, 2008
Memory Information ..... <ENTER>
CPU Information ..... <ENTER>
SATA Configuration ..... <ENTER>
Boot Sequence ..... <ENTER>
Boot Sequence Retry ..... Disabled
Integrated Devices ..... <ENTER>
PCI IRQ Assignment ..... <ENTER>
Serial Communication ..... <ENTER>
Embedded Server Management ..... <ENTER>

```

Figure 146: BIOS configuration main menu window

2. In the BIOS configuration main menu screen, select **Serial Communication** and press **Enter** to continue. The Serial Communication screen appears.
3. In the Serial Communication line, type `On with Console Redirection` through COM1.
4. In the External Serial Connector line, type `COM1`.
5. In the Failsafe Baud Rate line, type `9600`.
6. In the Remote Terminal Type line, type `Remote Terminal Type`.
7. In the Redirection After Boot line, type `Enabled`.

The Serial Communication screen containing the correct values appears in [Figure 147: Serial Communication window](#) on page 208.




Figure 147: Serial Communication window

8. Press **Esc** to return to the BIOS configuration main menu.

In the BIOS configuration main menu screen you can perform other changes or you can exit and save the changes you made.

9. If you want to exit and save your changes, press **Esc**.

A prompt to save changes appears, as shown in [Figure 148: Save changes and exit window](#) on page 209.

```

Dell Inc. (www.dell.com) - PowerEdge R300
BIOS Version 1.2.0
*****
Service Tag: 10KS4G1      Asset Tag:
*****
System Time ..... 17:42:40
System Date ..... Sat Dec 06, 2008
Memory Information ..... <ENTER>
CPU Information ..... <ENTER>
*****
SATA Configuration ..... Save Changes and Exit .. <ENTER>
                          Discard Changes and Exit
Boot Sequence ..... Return to Setup .. <ENTER>
Boot Sequence Retry ..... Disabled
Integrated Devices ..... <ENTER>
PCI IRQ Assignment ..... <ENTER>
Serial Communication ..... <ENTER>
Embedded Server Management ..... <ENTER>

```

Figure 148: Save changes and exit window

10. Select **Save Changes and Exit**, and then press **Enter**.

Setting the BIOS password for the Dell R300 server

Perform the following procedure to set the BIOS password.

1. Press **F2** to navigate to the BIOS configuration main menu screen using a Keyboard Video Monitor (KVM) terminal.

OR

Press **ESC-2** to navigate to the BIOS configuration main menu screen using the console terminal.

The BIOS configuration main menu screen appears, as shown in [Figure 149: BIOS configuration main menu window](#) on page 210.




Figure 149: BIOS configuration main menu window

- In the main menu screen, select System Security and press Enter.

The System Security menu appears, as shown in [Figure 150: System Security menu](#) on page 210.




Figure 150: System Security menu

- In the System Security menu, select **Setup Password** and press **Enter**.

The password entry screen appears, as shown in [Figure 151: Password entry window](#) on page 211.

```

Dell Inc. (www.dell.com) - PowerEdge R300
BIOS Version 1.2.0
*****
Service Tag: 1OKS4G1      Asset Tag:
*****
CPU Information ..... <ENTER>
SATA Configuration ..... <ENTER>
Bo System
Bo Setup Enter Password .... [
Passw Confirm Password .. [
In
PC TPM Security ..... Off
TPM Activation ..... No Change
Se TPM Clear ..... No
Em
System Security ..... <ENTER>
Keyboard NumLock ..... On
Report Keyboard Errors ..... Report
Up,Down Arrow to select  SPACE,+, - to change  ESC to exit  F1=Help

```

Figure 151: Password entry window

4. Type the new password. Press **Enter** to continue.
5. Type the password again to confirm the values, and then press **Enter**.

The password is now enabled, as shown in [Figure 152: Password enabled window](#) on page 212.




Figure 152: Password enabled window

6. Press **Esc** to return to the BIOS configuration main menu.

In the BIOS configuration main menu screen you can perform other changes, or you can exit and save the changes you made.

7. If you want to exit and save your changes, press **Esc**.

A prompt to save changes appears, as shown in [Figure 153: Save changes and exit window](#) on page 213.




Figure 153: Save changes and exit window

8. Select **Save Changes and Exit**, and then press **Enter**.

Configuring RAID settings

Avaya does not support PER PLM Raid drive configurations.

HP DL320 G4 server

The HP DL320 G4 server provides the following features:

- Intel Pentium 4 processor (3.6 GHz)
- Two 80 GB SATA Hard drives (1 configured)
- Four GB PC2-4200 ECC DDR2 SDRAM (2 GB configured)
- Two 10/100/1000BaseT Ethernet ports
- Three USB ports
- One CD-R/DVD ROM drive
- One serial port
- A reset button

[Figure 154: HP DL320 G4 front view](#) on page 214 shows the front view of the HP DL320 G4 server.




Figure 154: HP DL320 G4 front view



Figure 155: HP DL320 G4 front view: LEDs

Table 9: HP DL320 G4 LED item description and status

Item	Description	Status
1	UID button LED (Unit Identification)	Blue – Identification is activated. Flashing blue – System is remotely managed. Off – Identification is deactivated.
2	Internal health LED	Green – System health is normal. Amber – System is degraded. To identify the component, check the system board LEDs. Red – Critical. To identify the component in a critical state, check the system board LEDs.

Item	Description	Status
		Off – System health is normal (when in standby mode).
3	NIC 1 link/activity LED	Green – Network link exists. Flashing green – Network link and activity exist. Off – No link to network exists.
4	NIC 2 link/activity LED	Green –Network link exists. Flashing green – Network link and activity exist. Off – No link to network exists.
5	Drive activity LED	Green – Drive activity is normal. Amber – Drive failure occurred. Off – No drive activity.
6	Power button and LED	Green – System is on. Amber – System is shut down, but power is still applied. Off – Power not available.




Figure 156: HP DL320 G4 rear view

Important:

The TLAN and ELAN port positions are reversed (L and R, 1 and 2) compared to the IBM x306m server.

HP DL320 G4 BIOS settings

The Basic Input Output System (BIOS) settings on the HP DL320 G4 server shipped through Avaya are correct. The BIOS settings do not require adjustment unless they are reset due to

a fault or through maintenance. If a reset of the BIOS settings occurs, check the serial port option. The HP DL320 G4 BIOS settings can be seen at [Table 10: HP DL320 G4 default BIOS settings](#) on page 216. The HP DL320 G4 servers provide a physical COM1 serial port and a virtual (ILO) COM2 serial port. If the setting for the serial console port is Auto, output can be directed to either the COM1 port or COM2 ILO port. Set the serial console port option to COM1 to ensure the console output goes to the physical COM1. See [Configuring the COM1 serial port on an HP DL320 G4 server](#) on page 216 for instructions. The HP DL320 G4 server shipped through Avaya has a default baud rate of 9600 bits per second and does not require a reset. If an error occurs and you want to reset the baud rate, or if you want to change to another baud rate, see [Changing the baud rate on an HP DL320 G4 Signaling Server](#) on page 217 for instructions.

For information about how to enable or disable the BIOS password on the HP DL320 G4 server see [Setting the HP DL320 G4 server BIOS password](#) on page 219.

Table 10: HP DL320 G4 default BIOS settings

BIOS value	Default setting
Devices and I/O port - serial port A	Enabled
Devices and I/O port - baud rate	9600 baud
Devices and I/O port - type of connector	9-pin serial female
Start options - legacy USB support	Disabled

Configuring the COM1 serial port on an HP DL320 G4 server

1. Press Power to boot the server.

The server boots and the HP DL320 G4 boot screen appears.

```

Press "F9" key for ROM-Based Setup Utility
Press "F10" key for System Maintenance Menu
Press "F12" key for PXE boot
For access via BIOS Serial Console
Press "ESC+9" for ROM-Based Setup Utility
Press "ESC+0" for System Maintenance Menu
Press "ESC+@" for PXE boot

```

Figure 157: HP DL320 G4 server boot screen

Note:

If the server is already up and running, power the server off and on to restart and receive the HP DL320 G4 boot screen.

2. Press F9 to invoke the ROM-based setup utility (RBSU) menu screen.

The RBSU menu screen appears.

```

+-----+
|System Options
|PCI Devices
|Standard Boot Order (IPL)
|Boot Controller Order
|Date and Time
|Server Availability
|Server Passwords
|BIOS Serial Console & EMS
|Server Asset Text
|Advanced Options
|Utility Language
+-----+
HP ProLiant DL320 G4
S/N: USE648NCKK
Product ID: AH509A
HP BIOS D20 08/25/2006
Backup Version 08/25/2006
Bootblock 06/01/2005

2048MB Memory Configured

Proc 1: Intel 3.60GHz, 2MB L2 Cache
MAC address for NIC 1: 0019BB257A6F
MAC address for NIC 2: 0019BB257A70

<Enter> to View/Modify System Specific Options
<↑/↓> for Different Selection; <ESC> to Exit Utility

```

Figure 158: HP DL320 G4 server RBSU menu

3. Navigate to the **BIOS Serial Console & EMS** option and press Enter.

A BIOS Serial Console & EMS configuration menu screen appears.

4. Navigate to the **BIOS Serial Console Port** option and press **Enter**.

A BIOS Serial Console Port configuration screen appears. This screen presents you with four options:

- 1 | Auto
- 2 | Disabled
- 3 | COM1
- 4 | COM 2

5. Navigate to the **COM1** option and press **Enter**.

This configures the COM1 port as the serial port for communicating with the connected maintenance terminal.

The BIOS Serial Console & EMS configuration menu screen reappears.

6. Press **ESC** to exit the BIOS Serial Console & EMS configuration menu screen.

The RBSU menu screen reappears.

7. Press **ESC** to exit the ROM-based Setup Utility.

Changing the baud rate on an HP DL320 G4 Signaling Server

Important:

The HP DL320 G4 server shipped through Avaya has a default Baud rate of 9600 bits per second and does not require a reset. Use this procedure only if you want to use another Baud rate, or to correct the Baud rate after it is reset due to an error.

1. Press Power to boot the server.

The server boots and the HP DL320 G4 boot screen appears.

```

Press "F9" key for ROM-Based Setup Utility
Press "F10" key for System Maintenance Menu
Press "F12" key for PXE boot
For access via BIOS Serial Console
Press "ESC+9" for ROM-Based Setup Utility
Press "ESC+0" for System Maintenance Menu
Press "ESC+@" for PXE boot

```

Figure 159: HP DL320 G4 server boot screen

Note:

If the server is already up and running, power the server off and on to restart and receive the HP DL320 G4 boot screen.

2. Press **F9** to invoke the ROM-based Setup Utility (RBSU) menu screen.

The RBSU menu screen appears.

```

+-----+
|System Options
|PCI Devices
|Standard Boot Order (IPL)
|Boot Controller Order
|Date and Time
|Server Availability
|Server Passwords
|BIOS Serial Console & EMS
|Server Asset Text
|Advanced Options
|Utility Language
+-----+
|HP ProLiant DL320 G4
|S/N: USE648NCKK
|Product ID: AH509A
|HP BIOS D20 08/25/2006
|Backup Version 08/25/2006
|Bootblock 06/01/2005
|
| 2048MB Memory Configured
|
|Proc 1: Intel 3.60GHz, 2MB L2 Cache
|MAC address for NIC 1: 0019BB257A6F
|MAC address for NIC 2: 0019BB257A70
+-----+
<Enter> to View/Modify System Specific Options
<↑/↓> for Different Selection; <ESC> to Exit Utility

```

Figure 160: HP DL320 G4 server RBSU menu

3. Navigate to the **BIOS Serial Console & EMS** option and press Enter.

A BIOS Serial Console & EMS configuration screen appears.

4. Navigate to the **BIOS Serial Console Baud Rate** option and press Enter.

A BIOS Serial Console Baud Rate configuration window appears. This window presents you with four settings for the serial port speed:

- 9600
- 19200
- 57600
- 115200

3. Select the Server Passwords option and press Enter.
4. Select the Set Admin Password option and press Enter.
5. At this point refer to the manufacturer's manual for specific instructions on how to enable or disable the BIOS password.

For additional operating information see the Server Product Guide on the resource CD-ROM shipped with the HP DL320 G4 server .

Connecting an HP DL320 G4 Signaling Server

In geographic regions that are susceptible to electrical storms, Avaya recommends that you plug the HP DL320-G4 server into an AC surge suppressor.

The following figure depicts the back of an HP DL320 G4 server.




Figure 163: Back of an HP DL320 G4 server

1. Connect the server to the TLAN subnet.
Insert the RJ-45 CAT5 (or better) cable into the connector labeled with the number 5 (TLAN network interface) on the back of the server.
2. Connect the server to the ELAN subnet.
Insert the RJ-45 CAT5 (or better) cable into the connector labeled with the number 6 (ELAN network interface) on the back of the server.
3. Connect a DTE–DTE null modem serial cable from the serial port on the back of the server (COM1) to a maintenance terminal.
4. Connect the server power cord.
 - a. Check that the power cord is the type required in the region where you are installing the server.
Do not modify or use the supplied AC power cord if it is not the correct type.

- b. Attach the female end of the power cord to the mating AC power receptacle on the right side of the back panel. Plug the male end of the AC power cord into the AC power source (wall outlet).
5. Configure the COM1 serial port as the communication port for the connected maintenance terminal.

See [Configuring the COM1 serial port on an HP DL320 G4 server](#) on page 216 for instructions.

6. Set the baud rate for the COM1 serial port on the Signaling Server to 9600 bits per second.

See [Changing the baud rate on an HP DL320 G4 Signaling Server](#) on page 217 for instructions.

Note:

The HP DL320-G4 Signaling Server ships with the serial port configured to 9600 bits per second.

7. Configure the connected maintenance terminal.

HP DL360 G7 server

The HP DL360 G7 server provides the following features:

- Intel E5620 Quad core processor (2.4 GHz)
- 146 GB Dual port hard drive, SAS 2.5" form factor, 10 000 RPM
- Base configuration:
 - 272 total: RAID 5, 3 x 146 GB drive
- Serial attached SCSI
- Three USB ports
- One optical drive
- One USB port in the front, Two USB ports in the back, and one internal USB
- One serial port
- 4 x 1 GB Network Interface Card (NIC) ports

The Common Server capacity ratings are the same as the COTS2 servers. For more information about the COTS2 ratings, see *Communication Server 1000E Planning and Engineering, NN43041–220*.

HP documentation

To view or download all HP ProLiant DL360 G7 server documentation, go to the HP Web site <http://www.hp.com>.

Front panel components

The following figure shows the front view of the HP DL360 G7 server.




Figure 164: HP DL360 G7 front panel view

Front panel LED lights and buttons:

The following figure shows the LED lights and power button on the front panel of the HP DL360 G7 server. For a description of the LED lights and power button, see [Table 11: HP DL360 G7 front panel LED description and status](#) on page 222.




Figure 165: Front panel LED lights and buttons

Table 11: HP DL360 G7 front panel LED description and status

Item	Description	Status
1	UID button LED (Unit Identification)	Blue: Identification is activated. Flashing blue: System is remotely managed. Off: Identification is deactivated.
2	Internal health LED	Green: System health is normal. Amber: System is degraded. To identify the component, check the system board LEDs.

Item	Description	Status
		Red: Critical. To identify the component in a critical state, check the system board LEDs. Off : System health is normal (when in standby mode).
3	Power On/Standby button and system power LED	Green: System is on. Amber: System is in standby, but power is still applied. Off : Power cord is not attached, power supply failure has occurred, no power supplies are installed, facility power is not available, or the power button cable is disconnected.

Back panel components

The following figure shows the back panel view of the HP DL360 G7 server.




Figure 166: HP DL360 G7 back panel view

Note:

The HP DL360 G7 server is shipped with the Integrated Lights Out (iLO3) as a standard feature. The Avaya installed applications do not depend on iLO for operation. For more information about iLO, see <http://www.hp.com/servers/lights-out>.

ROM-Based setup utility interface

This section provides procedures for configuring the HP DL360 G7 server from the ROM-Based Setup Utility (RBSU). You can configure a physical COM1 serial port to the BIOS serial console. By default, the BIOS serial console is configured to Auto. You can disable the BIOS serial console in the RBSU. For information about how to configure the BIOS Serial Console port on the HP DL360 G7 server, see [Configuring the BIOS serial console](#) on page 224.

For more information about the ROM-Based Setup Utility interface, see *HP ROM-Based Setup Utility User Guide* on the Documentation CD or go to the HP Web site. For details about navigating the HP Web site, see [HP documentation](#) on page 221.

Configuring the BIOS serial console

Verify or configure the BIOS serial console.

Note:

The BIOS Serial Console is auto enabled by default.

1. Press the power button to start the server.
2. Press `F9` to access the ROM-Based Setup Utility (RBSU) menu.
3. From the RBSU main menu, navigate to the **BIOS Serial Console & EMS** option, and press `Enter`.
4. Navigate to the **BIOS Serial Console Port** option, and press `Enter` to view or modify.

A BIOS Serial Console Port configuration screen appears. There are four options:

- Auto BSC Enabled
- Disabled
- COM1
- COM2

5. Navigate to the **Disabled** option, and press `Enter` to save your selection.

The BIOS Serial Console & EMS configuration menu screen reappears.

6. Press `ESC` to exit the BIOS Serial Console & EMS menu.

Configuring the baud rate

Verify or configure the baud rate on an HP DL360 G7 Signaling Server.

Note:

The HP DL360 G7 server is configured with a default Baud rate of 9600 bits per second.

1. Press the Power button to start the server.
2. Press `F9` to access the ROM-based setup utility (RBSU) menu.
3. From the RBSU main menu, navigate to **BIOS Serial Console & EMS**, and press `Enter`.

4. Navigate to the **BIOS Serial Console Baud Rate** option, and press `Enter` to view or modify.

There are four options:

- 9600
- 19200
- 57600
- 115200

5. Navigate to the **9600** option, and press `Enter` to save your selection.
6. Press `ESC` to exit the BIOS Serial Console & EMS menu.

Configuring VT100 terminal emulation

BIOS Serial Console supports ANSI and VT100 terminal emulation. VT100 is supported by all terminal emulation programs.

1. Press the power button to start the server.
2. Press `F9` to access the ROM-Based Setup Utility (RBSU) menu.
3. From the RBSU main menu, navigate to **BIOS Serial Console & EMS**, and press `Enter`.
4. Navigate to the **Terminal Emulation Mode** option, and press `Enter` to view or modify.

A BIOS Serial Console Port configuration screen appears. There are two options:

- VT100
- ANSI

5. Navigate to the **VT100** option, and press `Enter` to save your selection.

The BIOS Serial Console & EMS configuration menu screen reappears.

6. Press `ESC` to exit the BIOS Serial Console & EMS menu.

Connecting an HP DL360 G7 Signaling Server

In geographic regions that are susceptible to electrical storms, Avaya recommends that you plug the HP DL360 G7 server into an AC surge suppressor. To view the back panel of an HP DL360 G7 server, see [Back panel components](#) on page 223.

1. Connect the server to the TLAN subnet.

Insert the RJ-45 CAT5 (or better) cable into the Network Interface Card (NIC) 2 slot in the back of the server.

2. Connect the server to the ELAN subnet.

Insert the RJ-45 CAT5 (or better) cable into the Network Interface Card (NIC) 1 slot in the back of the server.

3. Connect a DTE-DTE null modem serial cable from the serial port on the back of the server (configured as COM1) to a maintenance terminal.
4. Connect the server power cord.

⚠ Warning:

Check that the power cord is the type required in the region where you are installing the server. Do not modify or use the supplied AC power cord if it is not the correct type.

5. Configure the COM1 serial port as the communication port for the connected maintenance terminal.

See [Configuring the BIOS serial console](#) on page 224 for instructions.

6. Configure the baud rate for the COM1 serial port on the Signaling Server to 9600 bits per second.

See [Configuring the baud rate](#) on page 224 for instructions.

Note:

The HP DL360 G7 server ships with the serial port configured to 9600 bits per second.

7. Configure the connected maintenance terminal.

For VT100 terminal emulation, see [Configuring VT100 terminal emulation](#) on page 225.

IBM x306m server

The IBM x306m server provides the following features:

- an Intel Pentium 4 processor (3.6 GHz)
- 2 simple swap Serial ATA, 80 GB (1 drive configured)
- 8 GB of RAM PC4200 DDR II by means of 4 DIMM slots (2 GB configured)
- Two Gigabit Ethernet ports
- Four USB ports (two front, two back)

- One DVD-COMBO (DVD/CD-RW) drive
 - You use this to load the Signaling Server software files for the Signaling Server, Voice Gateway Media Cards, and IP Phones
- One serial port (back of Signaling Server)
- A reset button

For complete details and specifications about the IBM x306 server, visit the manufacturer's Web site at <http://www.ibm.com>.




Figure 167: IBM x306m front view



Figure 168: IBM x306m front view: LEDs

Table 12: IBM x306m LED description and status

Description	Status
Power LED	If this LED is lit, it indicates that the server is turned on. If this LED is off, it indicates that AC power is not present, or the power supply or the LED itself failed.
Hard disk LED	If this LED is lit, it indicates that a hard disk drive is in use.
Locator LED	When this LED is lit, it is lit remotely by the system administrator to aid in visually locating the server.
System Error LED	If this LED is lit, it indicates that a system error occurred.




Figure 169: IBM x306m rear view

Important:

The TLAN & ELAN port positions are reversed (L and R, 1 and 2) compared to the HP DL320 server. Ethernet speed LED:

- Lit indicates Ethernet network speed of 1 Gbps.
- Off indicates Ethernet network speed is 10/100 Mbps.

IBM x306m BIOS settings

The following BIOS settings are for the IBM x306m server that are shipped through Avaya.

Table 13: IBM x306m default BIOS settings

BIOS value	Default setting
Devices and I/O port - serial port A	Enabled
Devices and I/O port - baud rate	9600 baud
Devices and I/O port - console type	PC ANSI
Devices and I/O port - flow control	Off
Devices and I/O port - continue C.R. after POST	On
Devices and I/O port - type of connector	9-pin serial female
Start options - legacy USB support	Disabled

The IBM x306m server default BIOS settings can be changed by a BIOS reset or other maintenance activity. To return the BIOS settings to the appropriate values, see [Changing the baud rate on an IBM X306m Signaling Server](#) on page 234 for instructions.

For information about how to enable or disable the BIOS password about the IBM x306m server, see [Setting the IBM x306m server BIOS password](#) on page 231.

Changing the BIOS settings on an IBM x306m server

1. Press the Power switch to boot the server.

The server boots and the Press F1 for Configuration/Setup message appears on the maintenance terminal.

Note:

If the server is already up and running, power the server off and on or press the reset button to restart and receive the Press F1 for Configuration/Setup message.

2. Press F1 to invoke the IBM x306m server Configuration/Setup Utility.

The Configuration/Setup Utility menu screen appears.



Figure 170: IBM x306m server Configuration/Setup Utility menu

3. Navigate to the **Devices and I/O Ports** option and press Enter. The Devices and I/O Ports menu screen appears.



Figure 171: Devices and I/O Ports menu

4. Navigate to the **Remote Console Redirection** option and press Enter. The Remote Console Redirection screen appears.




Figure 172: IBM x306m server Remote Console Redirection

5. Navigate to the option you wish to change and enter the appropriate value.
6. Press Enter to change the setting.
7. Press ESC to exit the **Remote Console Redirection** option.
The Devices and I/O Ports menu screen appears.
8. Press ESC to exit the **Devices and I/O Ports** option.
The Configuration/Setup Utility menu screen appears.
9. Navigate to the **Save Settings** option and press Enter to save the changed parameters.
10. Navigate to the **Exit Setup** option and press Enter to exit the IBM x306m Configuration/Setup Utility.
The server will restart automatically.

Setting the IBM x306m server BIOS password

1. Press the Power switch to boot the server.
The server boots and the Press F1 for Configuration/Setup message appears on the maintenance terminal.

Note:
If the server is already up and running, power the server off and on or press the reset button to restart and receive the Press F1 for Configuration/Setup message.
2. Press F1 to invoke the IBM x306m server Configuration/Setup Utility.
The Configuration/Setup Utility menu screen appears.



Figure 173: IBM x306m server Configuration/Setup Utility menu

3. Select the System Security option and press Enter.
4. Select the Administrator Password option and press Enter.
5. At this point refer to the manufacturer's manual for specific instructions on how to enable or disable the BIOS password.

For additional operating information see the Server Product Guide on the resource CD-ROM shipped with the IBM x306m server .

Connecting an IBM X306m server

In geographic regions that are susceptible to electrical storms, Avaya recommends that you plug the IBM X306m server into an AC surge suppressor. Use the following procedures to connect an IBM X306m server.

The following figure depicts the back of an IBM X306m server.




Figure 174: Back of an IBM X306m server

1. Connect the server to the TLAN subnet.
 Insert the RJ-45 CAT5 (or better) cable into the Ethernet 1 connector (TLAN network interface) on the back of the server.
 2. Connect the server to the ELAN subnet.
 Insert the RJ-45 CAT5 (or better) cable into the Ethernet 2 connector (ELAN network interface) on the back of the server.
 3. Connect a DTE–DTE null modem serial cable from the serial port on the back of the Signaling Server to the serial port on a maintenance terminal.
 4. Connect the server power cord.
 - a. Check that the power cord is the type required in the region where you use the server.
 Do not modify or use the supplied AC power cord if it is not the correct type.
 - b. Attach the female end of the power cord to the mating AC power receptacle on the left side of the server back panel. Plug the male end of the AC power cord into the AC power source (wall outlet).
 5. Configure the baud rate for the serial port on the Signaling Server to 9600 bps. See [Changing the baud rate on an IBM X306m Signaling Server](#) on page 234 for instructions.
- Note:**
 The IBM X306m Signaling Server ships with the serial port configured to 9600 bps.
6. Configure the connected maintenance terminal.

Changing the baud rate on an IBM X306m Signaling Server

Perform the following procedure to verify or change the baud rate on an IBM X306m Signaling Server.

1. Press the Power switch to boot the server.

The server boots and a **Press F1 for Configuration/Setup** message appears on the maintenance terminal.

Note:

If the server is running, press the Reset button on the front of the IBM X306m server to restart and receive the **Press F1 for Configuration/Setup** message.

2. Press **F1** to invoke the IBM X306m server Configuration/Setup Utility.

The Configuration/Setup Utility menu screen appears.




Figure 175: IBM X306m server Configuration/Setup Utility menu

3. Navigate to the **Devices and I/O Ports** option and press **Enter**.

The Devices and I/O Ports menu screen appears.



Figure 176: IBM X306m server Devices and I/O Ports menu

4. Navigate to the **Remote Console Redirection** option and press **Enter**.
The Remote Console Redirection screen appears.



Figure 177: IBM X306m server Remote Console Redirection

5. Navigate to the **Baud Rate** option and enter the value 9600.
6. Press **Enter** to change the serial port speed to 9600 bits per second.
7. Press **ESC** to exit the **Remote Console Redirection** option.
The Devices and I/O Ports menu screen appears.
8. Press **ESC** to exit the **Devices and I/O Ports** option.
The Configuration/Setup Utility menu screen appears.

9. Navigate to the **Save Settings** option and press **Enter** to save the changed parameters.
10. Navigate to the **Exit Setup** option and press **Enter** to exit the IBM X306m Configuration/Setup Utility.

The server restarts automatically.

Refer to the Server Product Guide on the resource CD-ROM shipped with the IBM X306m server for additional operating information.

IBM x3350 server

The IBM x3350 server provides the following features:

- Intel Core 2 Quad CPU –2.66GHz
- 250 Gbyte RAID 1 array (2x 250 Gbyte hard drives, hot-swappable)
- 4 Gbyte memory
- CD-RW/DVD drive
- Redundant power supply (hot-swappable)
- Dual GigaBit ethernet ports

For complete details and specifications about the IBM x3350 server, visit the manufacturer's Web site at <http://www.ibm.com>.




Figure 178: IBM x3350 server front view




Figure 179: IBM x3350 server rear view

If you connect to the IBM x3350 server with a terminal for setup, the server does not function with the serial cable that was previously shipped with the ISP 1100 or other COTS platforms. The IBM x3350 server requires the new NTRX26NPE6 9 pin female to 9 pin female null modem cable, as shown in the following figure.



Figure 180: NTRX26NPE6 9 pin female to 9 pin female null modem cable

Configuring COM port settings for the IBM x3350 server

Perform the following procedures for configuring the BIOS settings.

1. Press F1 to navigate to the BIOS configuration main menu screen using a Keyboard Video Monitor (KVM) terminal.

OR

Press ESC-1 to navigate to the BIOS configuration main menu screen using the console terminal.

The BIOS Configuration/Setup Utility main menu screen appears, as shown in [Figure 181: BIOS Configuration/Setup Utility main menu window](#) on page 238.




Figure 181: BIOS Configuration/Setup Utility main menu window

2. In the BIOS Configuration/Setup Utility main menu select Devices and I/O Ports and press Enter.

The Devices and I/O Ports screen appears, as shown in [Figure 182: Devices and I/O Ports window](#) on page 239.




Figure 182: Devices and I/O Ports window

- In the Devices and I/O Ports screen, select Remote Console Redirection and press Enter. The Remote Console Redirection screen appears, as shown in [Figure 183: Remote Console Redirection window](#) on page 239.




Figure 183: Remote Console Redirection window

- Navigate to Remote Console Serial Port and type Serial Port 1.
- Navigate to Baud Rate and type 9600.

6. Navigate to Console Type and type PC ANSI.
7. Navigate to Flow Control and type None.
8. Navigate to Remote Console Active After Boot and type On.
9. Press Esc twice to return to the BIOS Configuration/Setup Utility main menu.
10. In the BIOS Configuration/Setup Utility main menu screen, select Save Settings and press Enter. A confirmation prompt appears, as shown in [Figure 184: Save Settings confirmation window](#) on page 240.




Figure 184: Save Settings confirmation window

11. In the Save Settings confirmation screen press enter to confirm your changes. The BIOS Configuration/Setup Utility main menu screen appears.
12. Press Esc to exit the BIOS Configuration/Setup Utility main menu. A confirmation screen appears, as shown in [Figure 185: BIOS Configuration/Setup Utility main menu exit confirmation window](#) on page 241.




Figure 185: BIOS Configuration/Setup Utility main menu exit confirmation window

13. Navigate to Yes, exit the Setup Utility and press Enter.

Setting the BIOS password for the IBM x3350 server

Perform the following procedure for setting the BIOS password.

1. Press F1 to navigate to the BIOS configuration main menu screen using a Keyboard Video Monitor (KVM) terminal.

OR

Press ESC-1 to navigate to the BIOS configuration main menu screen using the console terminal.

The BIOS Configuration/Setup Utility main menu screen appears, as shown in [Figure 186: BIOS Configuration/Setup Utility main menu window](#) on page 242.




Figure 186: BIOS Configuration/Setup Utility main menu window

2. In the BIOS Configuration/Setup Utility main menu screen, select System Security and press Enter.

The System Security menu appears, as shown in [Figure 187: System Security menu](#) on page 242.




Figure 187: System Security menu

3. In the System Security menu, navigate to Administrator Password and press Enter.

The Administrator Password menu screen appears, as shown in [Figure 188: Administrator Password menu window](#) on page 243.




Figure 188: Administrator Password menu window

4. In the Administrator Password menu screen, navigate to Enter Administrator Password and type a password.
5. Navigate to Enter Administrator Password Again and retype the password.
6. Navigate to Change Administrator Password and press Enter.

The Change Administrator Password confirmation screen appears, as shown in [Figure 189: Change Administrator Password confirmation window](#) on page 244.




Figure 189: Change Administrator Password confirmation window

Appendix B: Installation times

This section contains the average installation times using a variety of installation methods.

Average installation times by media type

Note:

The numbers in the following table are approximate and actual times can vary according to network characteristics and other factors.

The following table provides the average Linux Base installation times on the supported hardware platforms by media type.




Figure 190: Average installation times by media type

Linux Base and application deployment—average installation time

Note:

The numbers in the following table are approximate and actual times can vary according to network characteristics and other factors.

The following table provides the average installation time using Deployment Manager. Deployment Manager includes a system upgrade of the Linux Base installation and application deployment.




Figure 191: Average installation time using Deployment Manager

Appendix C: Media Application Server

This section is for information related specifically for Media Application Server (MAS).

Checklist for adding a new maintenance release for MAS

The following checklist describes how to up-issue a new MAS software load (.nai file). If a new maintenance release of MAS is available, you can reinstall the MAS .nai file. You are not required to perform a complete Avaya Communication Server 1000 (Avaya CS 1000) member upgrade.

If you are upgrading a MAS that belongs to a cluster, you must upgrade each MAS in the cluster. Upgrade the servers in the following order:

- Primary MAS
- Secondary MAS
- Standard MAS
 1. Using Element Manager, backup your MAS data to an available destination, for example, Local server or remote FTP server. For more information about MAS data backup using Element Manager, see the MAS documentation *Media Server Administration and Security, NN44471-600*.
 2. Log on to the Primary UCM (Deployment Server) using an account with the NetworkAdministrator role assigned, as described in [Logging on to Unified Communications Management](#) on page 78.
 3. Delete the MAS service for the server being up-issued, as described in [Deleting a Network Service](#) on page 95.
 4. Undeploy the MAS application, as described in [Removing applications on a server](#) on page 109.
 5. Restart the Jboss-Quantum application on the MAS member server.
 6. Delete the MAS .nai file, as described in [Deleting a software load](#) on page 81.
 7. Load the up-issued MAS .nai file from the Deployment Manager library, as described in [Software loads](#) on page 79.
 8. Recreate a new MAS service to the server where you want to install MAS, as described in [Adding a MAS service](#) on page 91.

9. On the Deployment View page, choose **Servers** from the **View** list, and click **Commit**.
10. Deploy the MAS application, as described in [Deploying applications on a Server](#) on page 107.
11. Restore the MAS data from the Element Manager MAS data backup location.

Note:

You must restore the data for each MAS within a cluster.

Checklist for upgrading a standalone MAS

The following checklist describes how to upgrade a standalone MAS running version 6.4 software for Communication Server Release 7.0 to MAS version 7.0 for Communication Server Release 7.5. Before beginning this procedure, ensure you have obtained the required MAS licences.

Note:

MAS cluster upgrade is not applicable for migration from Communication Server Release 7.0 to Communication Server Release 7.5.

1. Using Element Manager, backup your MAS data. For more information about MAS data backup using Element Manager, refer to the MAS documentation.
2. Using Avaya Unified Communication Management, perform the MAS system upgrade. For more information, see [Checklist for adding a new maintenance release for MAS](#) on page 247.
3. Restore the MAS data from the Element Manager MAS data backup location.
4. Restart the Jboss-Quantum application on the server where MAS is deployed.
5. Apply the required licenses.

Appendix D: Avaya Linux Base CLI commands

Avaya Linux Base CLI commands contains a list of the command line interface (CLI) commands used in Avaya Linux Base. Type `(linuxbase-command) -h | --help | help` at the command prompt to display a brief summary of the CLI command, as shown in [Table 14: Linux CLI command help](#) on page 249. Type `man (linuxbase-command)` at the command prompt for a more detailed description, as shown in [Table 15: Linux man command example](#) on page 249.

Table 14: Linux CLI command help

```
$ poos --help Usage: poos (patch_id)|-app *(app_name)*|--help,-h Options: (patch_id) Deactivate patch with (patch_id) handle. -app *(app_name)* Deactivate all patches for the application (app_name). --help Print this help message and exit.
```

Table 15: Linux man command example

```
$ man poos POOS(1) User Contributed Avaya Documentation POOS(1) NAME poos - Put a patch out of service. SYNOPSIS poos (patch_id)| -app (app_name) | --help,-h DESCRIPTION Remove a patch from service. The patch is removed from service from all processes in which it was in service. OPTIONS (patch_id) Deactivate patch with (patch_id) handle. -app (app_name) Deactivate all patches for the application (app_name). --help Print this help message and exit. EXAMPLES Deactivate patch with 2 handle $ poos 2 Patch handle: 2 Please ensure that the application solid is stopped before proceeding patch un-installation. Do you want to continue patch un-installation? (Y/N) [N]? y Performing the un-installation: Performing uninstall RPM patch... Preparing... ##### [100%] 1:avaya-cs1000-solid ##### [100%] executing Solid DB post install...Installation avaya Solid database server completed. Uninstalling the Solid database server package done Done. The RPM patch un-installation is completed. The patch 2 has been deactivated successfully. Deactivate all sunAm patches $ poos -app sunAm Patch handle: 0 Performing the un-installation: The patch 0 has been deactivated successfully. SEE ALSO pload, pout, pins, pstat, plis 5.50 2007-12-18 POOS(1)
```

Avaya Linux Base uses common (no access restrictions) CLI commands plus 8 categories of CLI commands that correspond to the 8 Avaya Linux Base user groups. The 8 categories of CLI commands are shown in the following list:

- backupadmin
- dbadmin
- logadmin
- maintadmin

- patchadmin
- securityadmin
- systemadmin
- timeadmin

Table 16: Common CLI commands

Command	Description
appVersionShow	Print the application software version for the server.
baseVersionShow	Print the Base software version for the server.
echo	Display a line of text on the terminal screen.
find	Search for files in a directory hierarchy.
ftp	Transfer files to and from a remote network site.
ifconfig	Configure a network interface.
ls - ll	List directory contents.
man	Format and display the online manual pages.
printenv	Print all or part of environment.
scp	Copy files between hosts on a network using ssh.
sftp	Transfer files to and from a remote network site secure file transfer program.
ssh	Run OpenSSH SSH client (remote login program) to provide secure encrypted communications between two untrusted hosts over an insecure network.
su	Run a shell with substitute user and group IDs.
swVersionShow	Print the server's software version.
telnet	Communicate with another host using the TELNET protocol.
whoami	Print the user name associated with the current effective user ID.

Table 17: backupadmin CLI commands

Command	Description
sysbackup	Perform a system backup (both base and applications).

Table 18: maintadmin CLI commands

Command	Description
consoleShow	Displays console speed.
gnome-system-monitor	GNOME process viewer and system monitor with a nice easy-to-use interface.
netstat	Print network connections, routing tables, interface statistics, masquerade connections, and multicast memberships.
pcapConfig	Configure PCAP for Linux.
pcapCtrlRemove	Stops the PCAP for Linux listener interface.
pcapCtrlStart	Start the PCAP for Linux listener interface.
pcapRestart	Restart PCAP for Linux.
pcapStatus	Displays the current status of PCAP for Linux.
pcapStop	Stop PCAP for Linux.
wireshark	Network protocol analyzer.
pcap	Tools for Linux is a network packet capture utility.
ppp	Initiate a PPP connection.
tcpdump	Command-line packet analyzer.

Table 19: patchadmin CLI commands

Command	Description
issp	Generates a list of installed RPMs, SUs and patches.
pins	Put the patch in service.
plis	Show detailed information about the patch.
pload	Load the patch into the system database.
poos	Put the patch out of service.
pout	Unload the patch from the system database.
pstat	Show a list of installed patches.
spins	Put a Service Pack into service.
spload	Load a Service Pack (bundle of patches and SUs) into the system database.
spout	Unload a Service Pack (bundle of patches and SUs) from the system database.

Command	Description
spstat	Show the installed and in service SPs.

Table 20: securityadmin CLI commands

Command	Description
basefirewallconfig	Configure firewall settings.
checkIPsecStatus	Use “Check IP Security Status” command.
disableAllTargets	Disable all IPSec targets and remove all IPSec data.
harden	Command to manage Avaya Communication Server 1000 hardening items.
harden audit status	Displays the status of the Linux Audit Daemon.
harden banners set/file	Modify the banner text. The banner text will be replaced by the content from the file.
harden banners status	Enables or disables the pre-login banners.
harden core dumps status	Enables or disables the core dump service.
harden ftp status	Shows that FTP service is turned on or off.
harden help	Displays help information for using the command.
harden nettools status	Enables or /disables the nettools service.
harden nfs help	Displays help information for using the command.
harden nfs on	Enables Network File System (NFS) when deploying the primary security server.
harden nfs off	Disables NFS after deployment is complete.
harden nfs status	Shows that NFS is turned on or off.
harden passwd_days off	Disable previously configured parameters.
harden passwd_days on	Enables previously configured parameters.
harden passwd_days set -max	Configure the value of the PASS_MAX_DAYS parameter. The default value is 90.
harden passwd_days set -min	Configure the value of the PASS_MIN_DAYS parameter. Note: This parameter must be set to a value >or = 1. The default value is 1.

Command	Description
harden passwd_days status	Provides the current value of the parameters from hardening storage.
harden rlogin	Apply hardening to remote logons. Note: rlogin is only available in Co-res Avaya CS and SS configurations.
harden ssh_filter status	Shows the list of the names of the hosts which are allowed to connect to Linux Base by SSH.
harden status	Retrieve the status of Linux Base Enhanced Hardening options.
harden telnet status	Shows that telnet service is turned on or off.
harden tftp status	Shows that TFTP service is turned on or off.
isssDecom	Clean up ISSS settings and delete ISSS configuration files.
isssReset	Reset ISSS configuration.
isssShow	Print out ISSS settings.
masterfirewallconfig	Master firewall configuration.
nfsexportsconfig	Network File System Export Configuration.
sshconfig	Configure SSH keys.

Table 21: systemadmin CLI commands

Command	Description
appinstall	Install Avaya applications. Note: Do not use the appinstall command unless you are directed to use it by Avaya support.
appstart	Stop, start, or restart Avaya applications.
arp	Manipulate the system ARP cache.
baseparamsconfig	Configure base parameters. ⚠ Warning: Do not change the FQDN of the primary or backup security server when you use the baseparamsconfig command.
datetimeconfig	Configure the date and time.
dnsconfig	Configure DNS values.

Command	Description
ecnconfig	Configure Explicit Congestion Notification settings.
hdStat	Displays the size of the hard disk.
hostconfig	Configure the static lookup table for host names.
memShow	Displays available, free, and used server memory.
memSizeShow	Displays the total server memory.
networkconfig	Configure network settings. ⚠ Warning: Do not change the FQDN of the primary or backup security server when you use the networkconfig command.
ntpconfig	Configure Network Time Protocol settings.
reboot	Restart the entire system.
routeconfig	Configure routing entries. Note: When you use routeconfig to add a host route you do not need to provide a netmask. If you do provide a netmask, the format must be 255.255.255.255.
stty	Change and print terminal line settings.
sysbackup	Configure system backup.
syslogFacilitySet	Set the facility value.
syslogLevelSet	Set a value for level.
syslogShow	Display syslog processes. Note: The help key is not valid for syslogShow . If you want to retrieve help information, you must use the format syslogShow -h or syslogShow -help .
sysrestore	Perform a restore of the application data (backed up by sysbackup).
timeadj	Specify system clock parameters.
upgrade	Select the backup data source and reinstall Linux Base.

Note:

You might need to add the primary host entry in backup and member servers before you can access them using the `hostconfig` command.

The command syntax is `admin2 user ---> hostconfig add -ip <PRIMARY SERVER IP> -host <PRIMARY SERVER HOST NAME> -domain <PRIMARY SERVER DOMAIN NAME>`.

Table 22: timeadmin CLI commands

Command	Description
<code>datetimeconfig</code>	Configure the date and time.
<code>ntpconfig</code>	Configure Network Time Protocol settings.
<code>timeadj</code>	Specify system clock parameters.

Appendix E: Troubleshooting

This chapter contains information on troubleshooting application deployment errors.

Deployment errors

The following table provides a list of the possible errors that can appear during application deployment with a description of the possible causes and actions to help troubleshoot the error.

Table 23: Deployment errors

Error Message	Description	Action
Applications are already installed.	Possible causes: Case: deploy is called when Avaya Applications are already installed.	From the Deployment Actions list, choose Deploy .
Applications are not installed.	Deployment manager status may not have been correct initially. Case: deploy is called when Avaya Applications are already installed. This case supports auto-recovery – the server status should reset to correct one automatically.	No action is required, the server status should be reset to correct value.
Error occurred while backup of target.	Possible causes: General error for any backup failure. Any one of the backup scripts failed. Network problem.	Check your network (on TLAN) between the deployment server and the target. Check your network between the target and the SFTP server. Check permissions on the file system. Check whether the SFTP server has enough free disk space to keep the backup archive.
Failed to clear a directory in pre-installation phase.	Possible causes: Generic error. Could be some permission issue.	Check the permissions. Try the operation again.
Failed to create a directory in pre-installation phase.	Possible causes: Generic error. Could be some permission issue.	Check the permissions. Try the operation again.

Error Message	Description	Action
Input parameter(s) validation failed.	Possible causes: Provided keycode file does not exist (something must have gone wrong during the keycode file upload).	Browse and validate the keycode again.
Can't copy installation xml.	Possible causes: Some permission problem which is disallowing the copy of the install.xml file under the /admin partition.	Check file permissions of the / admin partition. Repeat the operation again.
No configure.xml files found.	Corrupted .nai file. Damaged installation.	Upload the software load again. Try the application installation again. Backup the data, and reinstall Linux Base again.
Please login as a user with valid permissions to use Deployment Manager.	Deployment manager is not running as user admin2.	Make sure that Jboss is running as user admin2. Perform "ps -ef grep jbossd" and check whether the user is admin2
Cannot get preconfig data.	Possible causes: Can be set if preconfig data are found on the target but cannot be extracted from an archive file.	Try again, and if problem persists, get Avaya help.
Failed to prepare or transfer deployment data. Make sure the network connection to your target is in working condition. See Help for more details.	Possible causes: Network connection between the deployment server and the target may have some problem Available disk size and permission problem.	Try the operation again. Check available disk space.
Installation data preparations error.	Possible causes: Couldn't create the necessary files for this particular target.	Try again, and if problem persists, get Avaya help.
Restore of applications failed.	Possible causes: General error for any restore failure. Any one of the backup scripts failed. Network problem.	Check network connection, permissions and try one more time. Make sure that there is enough space on the server to keep restore archive. Check the linuxbase.log from Base manager.
RPM database is corrupted. Re-installation of Linux Base is required.		

Error Message	Description	Action
RPM installation failed.	Possible causes: Corrupted .nai file.	Check the appinstall_stderr.log, appinstall_stdout.log and linuxbase.log. Check to see whether there is any dependency problems (which will be indicated in the appinstall_stderr.log). Try the operation again.
RPM uninstallation failed.		
Operation is blocked by another process. Please try again.	Possible causes: Applicable for Deploy, Undeploy, Backup, Restore and Upgrade cases. Indicates that semaphore is busy and operation cannot be started to avoid data integrity corruption.	Wait for sometime and try the same operation again.
Remote script failed.	Possible causes: Generic error. Applicable for Deploy, Undeploy, keycode validate and Upgrade cases. Set if for example, remote script cannot be executed, command is not found, not enough permissions and so on.	Check permission of the file system. Check the connection between the deployment server and the target.
Transfer failed.	Possible causes: SCP operation (remote copy command) failed.	Check your network (on TLAN) between the deployment server and the target.
Undeployment error.	Possible causes: There are some patches that cannot be removed.	Check the appinstall_stderr.log , appinstall_stdout.log, and the linuxbase.log. Check the network connection. Try undeployment again.
Undefined parameter.	Possible causes: Some mandatory values are not set in deployment manager properly.	Set all required values, and try the operation again. Seek help from Avaya.
Undefined parameter.	Possible causes: Some mandatory values are not set in deployment manager properly.	Set all required values, and try the operation again. Seek help from avaya.
An unexpected error occurred.		Please try the operation again. If not successful seek help from Avaya.

Error Message	Description	Action
Error occurred while restoring Could not retrieve the information for the target on the deployment server.	Please try the operation again. If not successful seek help from Avaya.	
Error occurred while saving target.	Possible causes: Problem in writing the target information on the deployment server. Frequency: Very Low Severity: Major	Please try the operation again. Go to the folder /var/opt/avaya/deployment/deployed/<hostname> and check for any permission or disk space issues that could prevent writing to this folder. If not successful seek help from Avaya.
Could not retrieve UCM elements temporarily. Please refresh the page.	Possible causes: There was a problem retrieving the linux Base element(s) from UCM. Refresh the page by clicking on the refresh link.	Refresh the page by clicking on the refresh link.
Target in an invalid status for requested action.	Possible causes: Someone else may have started another operation on the target. The information on the deployment server is corrupted.	Refresh the page. Try again later. If not successful seek help from Avaya.
Error occurred while deploying/upgrading/undeploying target.	Possible causes: Could not make the system call to execute the linux Base commands to perform the deploy/upgrade/undeploy operation.	Seek help from Avaya.
Failed to generate a pre configuration file.	Possible causes: ElementInternalID is blank for the chosen call server. Could not create the cs1000.properties file. Error while writing to the cs1000.properties file. Could not create the csinst.ini file. Could not create the preconfiguration directory.	Check the file system for disk space and permissions.
Maximum number (3) of simultaneous deployment reached.	There are already 3 deployment operations in progress.	Wait for at least one deployment to complete before starting a new deployment.
Could not validate keycode. Error occurred during validation process.	Could not make the system call to run the keycode validation base command.	Check whether the keycodeValidate API exists on the server. Also check whether

Error Message	Description	Action
		executable permissions are set properly.
Keycode file missing on target, or can't read the file.	There has been some problem in the keycode uploading process.	Browse and validate the keycode again. Check whether the keycode is of non-zero size.
Version in keycode does not match software version to be installed.		Make sure that the Release and Issue of the keycode are matching the version of the software to be installed. Obtain a proper keycode or use the proper software version.
System type in keycode does not match the hardware type.		Browse and validate the keycode again. Obtain a proper keycode or use the proper software version.
Keycode file corrupted.		Browse and validate the keycode again. If it does not work, try regenerating the keycode.
Cannot detect dongle, dongle missing, or cannot read the dongle.	Dongle is not installed (or not properly installed) on the system. Dongle is hot-plugged in without restarting the server. Dongle is bad.	Make sure the dongle is properly installed. Restart the server with the dongle installed. Replace the dongle with a good one.
Keycode does not match dongle.	Keycode maybe invalid. Dongle maybe invalid.	Make sure the keycode is right and the dongle is right, and they match.
Keycode file contains invalid load build cycle.	The load build cycle on the keycode is not valid. Only valid load build cycle is "MR (market release)".	Obtain a keycode with a valid load build cycle.
Could not validate keycode. Error occurred during validation process.	Could not execute the keycode validation software.	Make sure that the kcv software is present, and with executable permission.
Could not mount software load: Invalid mount point. Restart the server and try again.		
Could not find a valid software load. File or media may be invalid.	Software load .nai file maybe corrupt.	Try uploading the .nai file again.

Error Message	Description	Action
Software load could not be copied to the deployment server.		Check whether there is enough disk space on the deployment server to copy the .nai file.
Software Load media is not accessible. Media not present or busy.		Check whether the CD/DVD or Compact Flash is inserted properly in the drive. Check whether the CD/DVD or Compact Flash has the application software or customer database, whichever you are trying to upload.
Could not determine hardware type of this server.	The h/w type is not in the baseOs.properties file.	Check the /admin/avaya-linuxbase-info file for the SYSTEM_HW_PLATFORM field. If it is proper, then do a system restart, otherwise seek help from Avaya.
Failed to get Software Load information - install.xml file does not exist.	Install.xml file is missing in the load (i.e. corrupted software load)	Try uploading the software load .nai file again. Check the directory /var/opt/avaya/deployment/app_loads/<app_load>/ to see whether the install.xml file is present. Check whether the .nai file you got is of expected size.
Failed to get Software Load information - Could not read install.xml.	Could not read install.xml file. Must be corrupted.	Try uploading the software load .nai file again. Check whether the .nai file you got is of expected size.
Failed to access software load data file. Please try again.	Could not access the software load .nai file.	Check whether you can access this file on your PC or the CD/DVD or compact flash that you are trying to upload from. Check whether it has the right permissions.
Software load add is already in progress.	Another user has started a software upload process.	Refresh the page. This should show the same page as the other user is getting. Wait until the other upload is done before initiating the software add.
Software load already exists. If you would like to replace the existing load, please delete it	The software load that you are trying to upload already exists on the deployment server.	As suggested, first delete the software load from the table. Then try the add again.

Error Message	Description	Action
from the table and add again.		
Failed to create the preconfig directory for call server configuration.	Could not create the directory /var/opt/avaya/deployment/deployed/<hostname>/preconfig/cs or /var/opt/avaya/deployment/deployed/<hostname>/preconfig/em. Could be disk space issue or permission issue.	Check the disk space and permissions for the above mentioned directory.
Unable to retrieve target server details. Please cancel and try again.		
Maximum number (3) of software loads reached on this server. Please delete one of the loads before proceeding with an add operation.		
Cannot delete the selected software load(s). Make sure all deployment and upgrade operations are completed before deleting a load.	Some other user maybe performing a deployment or upgrade which uses this load.	Wait till other operations are done (can check on the deployment targets page), and then retry the deletion.
Backup file is null or the file type is invalid.	Possible causes: Backup file is empty, or the extension is not .tar.gz as expected. Severity: Minor	Browse an appropriate backup file.
Backup file not found.		
An I/O error occurred while uploading backup file.		
Unexpected error occurred while uploading backup file.		
Backup file name is invalid.	Backup filename extension is not .tar.gz as expected.	Make sure that proper backup file is being used.
Keycode file is null or the file type is invalid.	Keycode file that was browsed is empty or the extension is not .kcd as expected.	Choose a proper keycode file that ends with .kcd.

Error Message	Description	Action
Keycode file not found.	Keycode file upload had some issues.	Browse and validate the keycode again. Make sure that the keycode is valid.
An I/O error occurred while uploading keycode file.	Keycode file upload had some issues.	Browse and validate the keycode again. Make sure that the keycode is valid.
Unexpected error occurred while uploading keycode file.	Keycode file upload had some issues.	Browse and validate the keycode again. Make sure that the keycode is valid.
An I/O error occurred while uploading customer database file.	Customer database file upload had some issues.	Browse and upload the customer database again. Make sure that the customer database is valid.
Unexpected error occurred while uploading customer database file.	Customer database file upload had some issues.	Browse and upload the customer database again. Make sure that the customer database is valid.
An I/O error occurred while extracting customer database archive file.	Customer database file upload had some issues.	Browse and upload the customer database again. Make sure that the customer database is valid.
Failed to extract customer database from the archive file.	Customer database file upload had some issues.	Browse and upload the customer database again. Make sure that the customer database is valid.
Software version delete failed for one/ more selected loads.		
Error occurred while backing up target.	Could not make the system call to execute the base commands appBackup.	Check whether the appBackup script exists on the server, with executable permission.
Error occurred while restoring target.	Could not make the system call to execute the base commands appRestore. System call got interrupted for some reason.	Check whether the appRestore script exists on the server, with executable permission.
Invalid IPv4 format.		
Maximum number of backups reached. Please delete any of the existing backups for the same target	Only three backups are allowed to be stored on the deployment server, per target.	

Error Message	Description	Action
using Backups management.		
Failed to delete one/ more backups.		Try refreshing the page, and try the delete again.
Maximum number (3) of simultaneous restores reached.	Only three restore operations are allowed simultaneously.	Wait for a short period of time, and then try the restore operation.
Maximum number (3) of simultaneous backups reached.	Only three backup operations are allowed simultaneously.	Wait for a short period of time, and then try the backup operation.
Selected file does not match required format(.tar.gz).		
Server path cannot be empty.		
Required fields cannot be empty.		
Server IP address cannot be empty.		
Username cannot be empty.		
Password cannot be empty.		
Not enough disk space available for backup. Please ensure that the /var partition has at least 20% space available, and try the backup again.		
Could not validate size of the disk. Please try again.		
Note - An automatic status update was not available. Click the refresh link (above, right) to verify current status.	Could not retrieve information from UCM regarding the targets. This is a temporary problem due to concurrent access and race conditions.	As suggested, refresh the page again.
Failed to delete elements on this target. Please	After undeployment, DM deletes the associated elements (CS 1000, NRSM,	Go to the UCM elements page and find the corresponding elements, and delete them.

Error Message	Description	Action
manually delete the elements from UCM elements table.	Subscriber Manager depending on what was deployed). For some reason, it couldn't delete these elements.	
Call server ELAN IP cannot be empty or invalid IPv4 format.		
Call server tape ID cannot be empty.		Check the tape ID on the call server dongle.
Call server tape ID must be alphanumeric		Check the tape ID on the call server dongle. It cannot have any special characters.
MAC address format is invalid.		
The target is performing an operation launched from another deployment server. Please try again later.	If you are performing a operation centrally, then it could be that some other user is performing some operation locally on the box and vice versa.	Make sure that no one else is performing any operation on the box from anywhere else.
Cannot find install.xml file.	Corrupted .nai file.	Upload the software load again.
Cannot add node in Element Manager. Signaling Server does not appear in list.	Applications were deployed locally and the target server does not belong to a group.	Avaya recommends using Deployment Manager Preconfiguring process using Deployment View on page 75 to configure target servers. Otherwise, create a CS 1000 group and Commit the locally deployed server.

Linux Base installation errors

The following list contains information to help you troubleshoot errors during the Linux Base installation. For more information about hard drive, memory, and BIOS requirements for the COTS and CP PM platforms, see [Hardware platforms](#) on page 185.

Insufficient hard drive capacity

The platform must meet the hard drive and memory requirements; otherwise, the Linux Base installation fails and the server returns to the previous state.

If the hard drive is less than 40 GB, the following screen appears:

```
Starting pre-installation...(please wait)...Physical memory size: 1023
1023 does not meet the minimum memory requirement of 2048

Scanning for SCSI devices...
Scanning for IDE devices...
Scanning for CCISS devices...
SCSI disks:
IDE disks:
0: hda,30000
1: hdc, Inaccessible
CCISS disks:
30000 does not meet the minimum Hard Drive requirement of 40000

This installation has been halted.

Installation was not completed.

Press the ENTER key to shutdown the system
```

Figure 192: Insufficient hard drive capacity

Insufficient memory size

If there is less than 1 GB of memory available, the following screen appears:

```
Starting pre-installation...(please wait)...Physical memory size: 1023
1023 does not meet the minimum memory requirement of 2048

This installation has been halted.

Installation was not completed.

Press the ENTER key to shutdown the system
```

Figure 193: Insufficient memory size

Log file

Description:

The status of the Linux Base version did not change during a new installation and the applications did not deploy.

Action:

Check the `/var/log/avaya/linuxbase.log` file.

If the logs shows that the applications deployed properly but it is not reflected in Deployment Manager, then UCM registration was not successful. You can also use the `swVersionShow` command to see if deployment was successful.

Backup security server configuration error

The FQDN of the backup security server is associated with the TLAN IP address of the server. Although the backup security server is also connected to the ELAN, you must always configure it using the TLAN. If you used the ELAN IP address to join the security domain when installing and configuring the backup security server, you can correct this issue by doing the following:

1. Power down the backup security server.
2. From the Primary security server, remove the backup security server from the list of elements.
3. Rebuild the backup security server.
4. Rejoin the backup security server to the security domain.

Appendix F: Network configuration for Secure File Transfer Protocol (SFTP) data backup

Use the guidelines in this appendix to assist in data backup to an SFTP server. The section [Network configuration](#) on page 269 provides details on network requirements and the section [SFTP logon](#) on page 269 provides SFTP logon details. The section [SFTP network configuration requirements](#) on page 270 provides specific Embedded Local Area Network (ELAN) and Telephony Local Area Network (TLAN) requirements for SFTP network configuration.

Network configuration

The network must be configured correctly for data backup to an SFTP server. In order to configure the network you must understand the difference between the ELAN and the TLAN. The ELAN and TLAN are defined as follows:

- ELAN - The ELAN is a secure local area network. The scope of this network is limited to one subnet or node; however the scope of the ELAN network can be expanded to cover multiple nodes with advanced router (data path) configurations.
- TLAN - The TLAN spans the entire enterprise network. Every node on the TLAN has access to every other node.

The TLAN supports both IPv4 and IPv6 addresses.

Note:

The definitions of ELAN and TLAN are a subset of the definitions provided in the voice media gateway cards section of *Avaya Signaling Server IP Line Applications Fundamentals*, NN43001-125.

SFTP logon

Data backup to an SFTP server requires a user logon, password, and path to access the SFTP server storage. The user logon can contain a maximum of 32 characters comprised of lower and uppercase letters, numeric digits, and the special characters _ . - and \$. You cannot use

the character - at the beginning of the logon string and you can use \$ only at the end of the logon string.

Avaya Linux Base uses the character / to specify paths in the system. Use the / character when you specify the SFTP directory.

SFTP network configuration requirements

The SFTP option requires an operational ELAN network because the backup and recovery of data must use the ELAN interface. Avaya recommends the destination SFTP server reside on the same ELAN network as the source SFTP server. If the destination SFTP server resides outside the subnet of the source SFTP server, use one of the two options shown in [Table 24: SFTP network configuration requirements](#) on page 270.

Note:

Not all Windows based SFTP servers can be used as SFTP backup servers. The following Windows based SFTP servers can be used:

- Sysax Multi Server
- OpenSSH for Windows

The following Windows based SFTP servers are not supported:

- Core FTP mini-sftp-server
- CrushFTP
- freeFTPd
- NullFTP
- TitanFTP
- winSSHD

Table 24: SFTP network configuration requirements

Option	Details
1	The router connecting the two subnets must be configured to allow pings to pass through. This ensures there is a valid data path between the two subnets. If the default gateway is set to the TLAN interface gateway, a routing entry is required to ensure that all ELAN data uses only the ELAN NIC. Use the CLI command <code>routeconfig</code> to add the routing entry. An example of the <code>routeconfig</code> command is as follows: <code>routeconfig add -net destination_ip -netmask subnet_mask -gw gateway_ip -dev eth0</code>
2	On the source server set the ELAN interface gateway as the default gateway.

Appendix G: Passthrough end user license agreement

Important:

Do not contact Red Hat for technical support for your Avaya version of the Linux Base operating system. If you require technical support, contact Avaya technical support through your regular channels.

This section governs the use of the Red Hat Software and any updates to the Red Hat Software, regardless of the delivery mechanism and is governed by the laws of the state of New York in the U.S.A. The Red Hat Software is a collective work under U.S. Copyright Law. Subject to the following terms, Red Hat, Inc. ("Red Hat") grants to the user ("Customer") a license to this collective work pursuant to the GNU General Public License. Red Hat Enterprise Linux (the "Red Hat Software") is a modular operating system consisting of hundreds of software components. The end user license agreement for each component is located in the component's source code. With the exception of certain image files identified below, the license terms for the components permit Customer to copy, modify, and redistribute the component, in both source code and binary code forms. This agreement does not limit Customer's rights under, or grant Customer rights that supersede, the license terms of any particular component. The Red Hat Software and each of its components, including the source code, documentation, appearance, structure and organization are owned by Red Hat and others and are protected under copyright and other laws. Title to the Red Hat Software and any component, or to any copy, modification, or merged portion shall remain with the aforementioned, subject to the applicable license. The "Red Hat" trademark and the "Shadowman" logo are registered trademarks of Red Hat in the U.S. and other countries. This agreement does not permit Customer to distribute the Red Hat Software using Red Hat's trademarks. If Customer makes a commercial redistribution of the Red Hat Software, unless a separate agreement with Red Hat is executed or other permission granted, then Customer must modify any files identified as "REDHAT-LOGOS" and "anaconda-images" to remove all images containing the "Red Hat" trademark or the "Shadowman" logo. As required by U.S. law, Customer represents and warrants that it: (a) understands that the Software is subject to export controls under the U.S. Commerce Department's Export Administration Regulations ("EAR"); (b) is not located in a prohibited destination country under the EAR or U.S. sanctions regulations (currently Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria); (c) will not export, re-export, or transfer the Software to any prohibited destination, entity, or individual without the necessary export license(s) or authorizations(s) from the U.S. Government; (d) will not use or transfer the Red Hat Software for use in any sensitive nuclear, chemical or biological weapons, or missile technology end-uses unless authorized by the U.S. Government by regulation or specific license; (e) understands and agrees that if it is in the United States and exports or transfers the Software to eligible end users, it will, as required by EAR Section 740.17(e), submit semi-annual reports to the Commerce Department's Bureau of Industry & Security (BIS), which include the name and address (including country) of each transferee; and (f) understands that countries other than the United States may restrict the import, use, or export of encryption products and that it shall be solely responsible for compliance with any such import, use, or export restrictions. Red Hat may distribute third party software programs with the Red Hat Software that are not part of the Red Hat Software. These third party programs are subject to their own license terms. The license terms either accompany the programs or can be viewed at <http://www.redhat.com/licenses/>. If Customer does not agree to abide by the applicable license terms for such programs, then Customer may not install them. If

Customer wishes to install the programs on more than one system or transfer the programs to another party, then Customer must contact the licensor of the programs. If any provision of this agreement is held to be unenforceable, that shall not affect the enforceability of the remaining provisions. Copyright © 2003 Red Hat, Inc. All rights reserved. "Red Hat" and the Red Hat "Shadowman" logo are registered trademarks of Red Hat, Inc. "Linux" is a registered trademark of Linus Torvalds. All other trademarks are the property of their respective owners.