



NORTEL

Nortel Communication Server 1000

Network Routing Service Installation and Commissioning

Release: 5.5
Document Revision: 02.10

www.nortel.com

NN43001-564

Nortel Communication Server 1000
Release: 5.5
Publication: NN43001-564
Document release date: 27 July 2009

Copyright © 2007-2009 Nortel Networks. All Rights Reserved.

LEGAL NOTICE

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, the Nortel Logo, the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

Contents

New in this Release	9
Network Routing Service	9
Linux-based NRS	9
VxWorks-based NRS	9
Other	10
Revision History	10
How to Get Help	13
Getting help from the Nortel web site	13
Getting help over the telephone from a Nortel Solutions Center	13
Getting help from a specialist by using an Express Routing Code	13
Getting help through a Nortel distributor or reseller	14
Network Routing Service overview	15
Contents	15
Introduction	16
Network protocol component	19
Session Initiation Protocol	19
SIP entities	20
User agent	20
SIP Proxy Server	20
SIP Redirect Server	21
SIP Registrar	21
NRS SIP server implementation	21
Back-to-Back User Agent	22
SIP domains	22
Location Service	22
NRS purpose	23
Signaling Gateways	23
SIP Gateway	24
SIP services	24
H.323 protocol	25
H.323 entities	25
H.323 terminal	25
H.323 Gatekeeper	25

Gatekeeper zones	26
H.323 Gateway	26
SIP and H.323 interworking	26
Network Connection Service	27
SIP NRS Privacy within a Trusted Network	27
Primary and Secondary NRS	28
NRS Failsafe	28
CS 1000 Release 5.0 interoperability with NRS Release 5.5	29
Database component	29
NRS Database	29
Database synchronization/operation component	38
Synchronization of the active and standby databases on a Network Routing Server	39
Synchronization of the databases on the VxWorks-based Primary and Alternate Network Routing Servers.	42
Synchronization of the databases on the Linux-based Primary and Secondary Network Routing Servers.	42
Failsafe NRS Synchronization	42
NRS functionality	43
Contents	43
Introduction	43
Network overview	44
NRS Manager	54
NRS operating parameters	56
Standalone NRS support for Meridian 1 and BCM nodes	63
Numbering plans	67
Contents	67
Introduction	67
Address translation and call routing	73
Numbering plans and routing	81
SIP Phone support	89
Contents	89
Introduction	89
SIP Phone calls	92
SIP Phone dynamic registration	101
Installing a SIP Phone	102
Configuring a SIP Phone	102
Configure and manage the Linux-based Network Routing Service	105
Contents	105
Introduction	106
Installation of Linux operating system, ECM framework and NRS application	108

Upgrade Linux-based NRS Release 5.0 to Release 5.5	109
Access NRS Manager through the ECM	111
Initial configuration of Linux-based NRS on a new IP Peer network	111
Configure Gateway endpoints	113
Nortel recommendation for load-balancing across the Primary and Secondary Linux-based NRS servers	114
Configure NRS database user endpoints	115
Upgrade of an IP Peer Network from VxWorks-based NRS to Linux-based NRS with SIP Proxy	115
Recommended upgrade procedure	115
Re-use the existing NRS IP addresses for Linux-based NRS upgrade procedure	116
New NRS IP address assignments upgrade procedure	130
Recovery from failure of Linux-based NRS	132
Operation and maintenance of Linux-based NRS	132
Access to NRS CLI commands	132
SIP Proxy	133
H.323 Gatekeeper	135
Solid database commands	137
Browser configuration	138
Log in to ECM and Access NRS Manager	140
NRS Manager interface	143
NRS Manager Navigator	143
Navigation of NRS Manager web pages	144
NRS Manager features	146
Mandatory fields on NRS Manager web pages	148
Numbering Plans inherited fields	148
Help and Logout links	149
Log out of ECM	150
Configure the Primary and Secondary NRS Server Settings	150
Configure system-wide settings	156
Configure the NRS database	157
Switch between the Active and Standby databases	158
Manage a Service Domain	160
Add a Service Domain	160
View the Service Domain	162
Edit a Service Domain	163
Delete a Service Domain	164
Manage a Level 1 Domain (UDP)	166
Add an L1 Domain (UDP)	166
View an L1 Domain (UDP)	169
Edit an L1 Domain (UDP)	171
Delete an L1 Domain (UDP)	173
Manage a Level 0 Domain (CDP)	174

Add an L0 Domain (CDP)	175
View an L0 Domain (CDP)	178
Edit an L0 Domain (CDP)	180
Delete an L0 Domain (CDP)	182
Manage a Collaborative Server	184
Add a Collaborative Server	184
View a Collaborative Server	189
Edit a Collaborative Server	190
Delete a Collaborative Server	191
Manage a Gateway Endpoint	192
Add a Gateway Endpoint	192
View Gateway Endpoint Dynamic Registration Information	200
View the Gateway Endpoints	202
Edit the Gateway Endpoints	204
Delete the Gateway Endpoints	205
Manage Post-routing SIP URI Modification	207
Add Post-routing SIP URI Modification	207
View Post-routing SIP URI Modification	209
Edit Post-routing SIP URI Modification	210
Delete Post-routing SIP URI Modification	211
Manage a User Endpoint	212
Unqualified number routing	213
Task summary	213
Add a User Endpoint (SIP Phone)	213
View User Endpoint Dynamic Registration Information	217
View the User Endpoints	218
Edit a User Endpoint	220
Delete a User Endpoint	221
SIP Phone Context	222
Manage a Routing Entry	224
Add a Routing Entry	224
View the Routing Entries	226
Edit a Routing Entry	227
Delete a Routing Entry	229
Copy a Routing Entry	230
Move Routing Entries	232
Search Routing Entries	234
Manage a Default Route	235
Add a Default Route	235
View Default Routes	237
Edit a Default Route	238
Delete a Default Route	239
Manage bulk export of routing entries	241
Bulk export of routing entries	241

Manage bulk import of routing entries	243
Recommendations	243
Bulk import of routing entries	244
Import CSV file specifications	246
Verify the numbering plan and save the NRS configuration	255
H.323 and SIP Routing Tests	256
Perform an H.323 Routing Test	256
Perform a SIP Routing Test	257
Enable, disable and restart the NRS Server	259
Disable the NRS server	260
Enable the NRS server	260
Restart the NRS Server	261
Perform NRS database actions	261
Perform a database Cut over	263
Revert the database changes	264
Perform database Roll back	264
Commit the database changes	265
Backup the database	266
Automatically backup the database	266
Manually backup the database	267
Download the latest backup file	268
Download the latest backup log file	270
Restore the NRS database	271
Restore the database	272
Restore from the connected Signaling Server	273
Restore from a secure FTP site	274
Restore from a client machine	275
Download the latest restore log file	277
GK/NRS Data Upgrade	278
Migration overview	278

Configure and manage the VxWorks-based Network Routing Service **281**

Contents	281
Introduction	282
Browser configuration	283
Enabling and configuring the NRS server	285
Task summary	290
Accessing NRS Manager	294
The NRS Manager interface	299
Logging out of NRS Manager	302
Home tab	302
Edit the login warning banner	311
Configuration tab	312

Tools tab 369

Reports tab 398

Administration tab 401

Accessing the NRS directly from the Signaling Server 406

Passthrough End User License Agreement

409

New in this Release

Network Routing Service

CS 1000 Release 5.5 Network Routing Service (NRS) is offered in two versions: (1) a Linux-based NRS and (2) a VxWorks-based NRS.

Linux-based NRS

Bulk export and import of routing entries

The NRS supports up to 20000 routing entries and default routes. Release 5.5 introduces a new feature “Bulk export and import ” to improve the provisioning of the routing entries. A Comma Separated Value (CSV) file is used to create routing entries in the Standby database. The routing entries in the Standby or Active database can be exported into a CSV file. The CSV file can be edited and imported into the same NRS or into another NRS.

Enhancement of the NRS Manager User Interface

The following functionality has been added to the NRS Manager User Interface

- The NRS Manager Navigator can be expanded to the lowest leaf level of each node by clicking on the root node.
- A **Hide** and **Show** link is introduced into the Endpoints and Routes web pages. Clicking on the **Hide** link removes the search criteria panel from the web pages, providing a larger panel for the display of the Routing Entries and Endpoints.

VxWorks-based NRS

Edit the login warning banner

The VxWorks-based NRS provides a customizable login banner that appears when a user logs on to the system. The customizable banner is intended for use by customers that have security policies that require network equipment to display a specific message to users when they log on.

Other

Revision History

July 2009

Standard 02.10. This document is up-issued to reflect changes in technical content.

April 2009

Standard 02.09. This document is up-issued to reflect changes in technical content.

December 2008

Standard 02.08. This document is up-issued to reflect changes in technical content.

November 2008

Standard 02.07. This document is up-issued to reflect changes in technical content.

February 2008

Standard 02.06. This document is up-issued to reflect changes in technical content.

January 2008

Standard 02.05. This document is up-issued to reflect changes in technical content.

December 2007

Standard 02.04. This document is up-issued to support Communication Server 1000 Release 5.5.

June 2007

Standard 01.03. This document is up-issued, specifying in the "Enable, disable and restart the NRS Server" section of the "Configure and manage the Linux-based Network Routing Service" chapter that:

- The SIP Proxy must be started and running before you can disable or enable the application. To enable the SIP Proxy, click the Restart button in the Service Status pane of the NRS Server web page.
- To enable the Network Connection Service or the H.323 Gatekeeper, select Enable from the Service Status pane of the NRS Server web page.

June 2007

Standard 01.02. This document is up-issued, specifying in the Linux-based NRS procedure for Configuring the Primary and Secondary NRS Server Settings that UDP transport must be enabled if a Release 5.0 Linux-based NRS is installed in a network with Release 4.x CS 1000 gateways.

May 2007

Standard 01.01. This document is a new NTP for Communication Server 1000 Release 5.0. It was created to support a restructuring of the Documentation Library. This document is comprised of (1) information on Network Routing Service that was previously contained in the legacy document *IP Peer Networking: Installation and Configuration* (553-3001-213) (), now retired and (2) a description of the operation and configuration of Communication Server 1000 Release 5.0 Network Routing Service.

How to Get Help

Getting help from the Nortel web site

The best way to get technical support for Nortel products is from the Nortel Technical Support web site:

www.nortel.com/support

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. From this site, you can:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting help over the telephone from a Nortel Solutions Center

If you do not find the information you require on the Nortel Technical Support web site, and you have a Nortel support contract, you can also get help over the telephone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following web site to obtain the telephone number for your region:

www.nortel.com/callus

Getting help from a specialist by using an Express Routing Code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

www.nortel.com/erc

Getting help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Network Routing Service overview

Contents

This section contains information on the following topics:

- “Introduction” (page 16)
- “Network protocol component” (page 19)
 - “Session Initiation Protocol” (page 19)
 - “SIP entities” (page 20)
 - “User agent” (page 20)
 - “SIP Proxy Server” (page 20)
 - “SIP Redirect Server” (page 21)
 - “SIP Registrar” (page 21)
 - “NRS SIP server implementation” (page 21)
 - “Back-to-Back User Agent” (page 22)
 - “SIP domains” (page 22)
 - “Location Service” (page 22)
 - “NRS purpose” (page 23)
 - “Signaling Gateways” (page 23)
 - “SIP Gateway” (page 24)
 - “SIP services” (page 24)
 - “H.323 protocol” (page 25)
 - “H.323 entities” (page 25)
 - “H.323 terminal” (page 25)
 - “H.323 Gatekeeper” (page 25)
 - “Gatekeeper zones” (page 26)
 - “H.323 Gateway” (page 26)
 - “SIP and H.323 interworking” (page 26)
 - “Network Connection Service” (page 27)

[“SIP NRS Privacy within a Trusted Network” \(page 27\)](#)

[“NRS Failsafe” \(page 28\)](#)

[“CS 1000 Release 5.0 interoperability with NRS Release 5.5” \(page 29\)](#)

[“Database component” \(page 29\)](#)

[“NRS Database” \(page 29\)](#)

[“Database synchronization/operation component” \(page 38\)](#)

[“Synchronization of the active and standby databases on a Network Routing Server” \(page 39\)](#)

[“Synchronization of the databases on the VxWorks-based Primary and Alternate Network Routing Servers.” \(page 42\)](#)

[“Synchronization of the databases on the Linux-based Primary and Secondary Network Routing Servers.” \(page 42\)](#)

Introduction

The convergence of voice, video and data on a single IP network reduces the costs and complexities of communication technology. There are two standards for call signaling and control of Voice over IP (VoIP): the IETF SIP protocol and the ITU-T H.323 protocol.

IP Peer Networking enables customers to distribute the functionality of CS 1000 systems over a Wide Area Network, using either Nortel SIP or H.323 Gateways, or third-party SIP or H.323 Gateways.

The Network Routing Service (NRS) provides routing services to both SIP and H.323-compliant devices. The NRS allows customers to manage a single network dialing plan for SIP, H.323, and mixed SIP/H.323 networks.

IP Peer Networking and NRS provide an integrated VoIP network for the delivery of voice, video, and data. The NRS is comprised of three components:

- network protocol component with a transport layer subcomponent
- database component
- NRS Manager

NRS Manager, a web-based management application, is used to configure, provision, and maintain the NRS.

NRS for CS 1000 Release 5.0 or later software is offered in two versions: a SIP Proxy NRS and a SIP Redirect Server NRS.

The SIP Proxy NRS is comprised of

1. network protocol component consisting of

- SIP component
- H.323 Gatekeeper component
- Network Connection Service (NCS)

The SIP component is comprised of a

- SIP Proxy and Redirect Server
- SIP Registrar
- Transport Layer Security component

By default the SIP Proxy and Redirect Server acts as a SIP Proxy. However, an endpoint can request transaction by transaction that the SIP Proxy and Redirect Server act as a SIP Redirect Server.

2. NRS Database component.

The NRS Database component supports

- a Routing and Location Service shared by the SIP Proxy and Redirect Server, the SIP Registrar, and the H.323 Gatekeeper
- database synchronization


3. NRS Manager

The SIP Proxy NRS is hosted in a stand-alone mode on a dedicated server running the Linux™ real-time operating system.

The SIP Proxy NRS will be referred to as the Linux-based NRS.

[Figure 1 "Linux-based NRS components" \(page 18\)](#) shows a graphical view of the Linux-based NRS.

Figure 1
Linux-based NRS components



The SIP Redirect Server NRS is comprised of

1. network protocol component consisting of
 - SIP component
 - H.323 Gatekeeper component
 - Network Connection Service (NCS)

The SIP component is comprised of a

- SIP Redirect Server
 - SIP Registrar
 - Transport Layer protocol component
2. NRS Database component.

The NRS Database component supports

- a Routing and Location Service shared by the SIP Redirect Server, the SIP Registrar, and the H.323 Gatekeeper
- database synchronization


3. NRS Manager

The SIP Redirect Server NRS is hosted either co-resident with Signaling Server applications, or in a stand-alone mode on a dedicated server running the VxWorks™ real-time operating system.

The SIP Redirect Server NRS will be referred to as the VxWorks-based NRS.

Figure 2 "VxWorks-based NRS components" (page 19) shows a graphical view of the VxWorks-based NRS.

Figure 2
VxWorks-based NRS components



Network protocol component

The NRS Network Protocol component is comprised of

- SIP Proxy and Redirect Server and a SIP Registrar, or a SIP Redirect Server and a SIP Registrar
- H.323 Gatekeeper
- Network Connection Service

and a transport layer subcomponent.

The SIP servers are network protocol components that serve SIP endpoints.

An H.323 Gatekeeper is a network protocol component that serves H.323 endpoints.

Session Initiation Protocol

Session Initiation Protocol (SIP) is a signaling protocol used for establishing, modifying, and terminating conference and telephony sessions in IP networks. A session can be a simple two-way telephone call or it can be a collaborative multimedia conference session. SIP initiates real-time, multimedia sessions which can integrate voice, data, and video. The protocol's text-based extensible architecture speeds access to new services with greater flexibility and more scalability.

The CS 1000 implementation of SIP complies with the standards described in the following Request for Comments (RFC) Internet Engineering Task Force (IETF) documents:

- RFC 3261 – SIP: Session Initiation Protocol
- RFC 3262 – Reliability of Provisional Responses in the Session Initiation Protocol (SIP)
- RFC 2806 – URLs for Telephone Calls
- RFC 3264 – An Offer/Answer Model with the Session Description Protocol (SDP)
- RFC 3265 – Session Initiation Protocol (SIP)-Specific Event Notification
- RFC 3311 – The Session Initiation Protocol (SIP) UPDATE Method
- RFC 2976 – The SIP INFO Method
- RFC 3323
- RFC 3324
- RFC 3325

SIP entities

A SIP network is composed of five logical entities. The logical SIP entities are:

- User agent
- SIP Proxy Server
- SIP Redirect Server
- SIP Registrar Server
- Back-to-Back User Agent

User agent

A SIP user agent is an endpoint entity that initiates and terminates sessions by exchanging requests and responses. This document refers to SIP user agents as “SIP endpoints”. SIP endpoints are IP phones or SIP Gateways.

SIP Proxy Server

A SIP Proxy acts as both a server and a client. A SIP Proxy receives requests, determines where to send the requests, and acting as a client on behalf of SIP endpoints passes requests on to another server.

A SIP Proxy can be either a SIP stateful proxy server or a SIP stateless proxy server. A proxy server in a stateful mode remembers the incoming requests it receives, along with the responses it sends back and the outgoing requests it sends on. A proxy server acting in a stateless mode forgets all information once it has sent a request.

SIP Redirect Server

A SIP Redirect Server provides telephone number to IP address resolution. It translates telephone numbers recognized by Enterprise Business Network (EBN) voice systems to IP addresses in a SIP domain.

A SIP Redirect Server receives requests, but does not pass the requests onto another server. Instead, a SIP Redirect Server sends a response back to the SIP endpoint, indicating the IP address of the called user. Because the response includes the address of the called user, the caller can then directly contact the called party.

SIP Registrar

A SIP Registrar is a server that accepts REGISTER requests and updates the NRS database with the contact information specified in the request. A SIP Registrar accepts registration requests from SIP Phones, SIP Trunk Gateways, and other certified compatible third-party SIP endpoints.

Each endpoint will be able to register more than a single transport and IP address with the SIP Registrar deployed by the SIP Proxy. Furthermore, endpoint identifiers can be reused across service domains.

NRS SIP server implementation

The SIP standard does not specify how the functionality of the SIP server logical entities are implemented. They may be hosted on the same hardware platform or distributed across different servers. In the Network Routing Service, a single network server functions as both a SIP Proxy and Redirect Server and as a SIP Registrar, or as both a SIP Redirect Server and as a SIP Registrar. When emphasizing the network server's dual functionality, it will be referred to as a SIP Proxy/Registrar Server or as a SIP Redirect/Registrar Server.

In the Linux-based Network Routing Service the SIP Registrar is co-resident with the SIP Proxy and Redirect Server on a dedicated server running the Linux™ real-time operating system. The SIP Proxy NRS is not co-resident with Signaling Server applications.

In the VxWorks-based Network Routing Service the SIP Registrar is co-resident with the SIP Redirect Server. The SIP Redirect Server is hosted either co-resident with Signaling Server applications, or in a stand-alone mode on a dedicated server running the VxWorks™ real-time operating system.

The SIP Proxy/Registrar Server and the SIP Redirect/Registrar Server are network protocol components of the Network Routing Service that serve SIP endpoints.

Back-to-Back User Agent

A SIP User Agent can act as a User Agent client and as a User Agent server. As a client a User Agent initiates SIP requests. As a server a User Agent returns a response. A Back-to-Back User Agent (B2BUA) processes a request on behalf of a client as a server. To determine how to answer a request, a B2BUA acts as a client and generates requests.

Unlike a SIP Proxy, a B2BUA must maintain call state and must participate in all requests sent on the calls it has established. A B2BUA can disconnect a call or alter SIP messages. A SIP Proxy can not.

The Multimedia Communication Server (MCS) 5100 is a SIP B2BUA.

SIP domains

SIP endpoints (User agents) are grouped into domains. A SIP domain is managed by a SIP Proxy/Registrar Server or by a SIP Redirect/Registrar Server. A SIP domain is an administrative unit in the NRS database. NRS SIP domains comprise SIP Service Domains and L1 and L0 Regional Domains.

A SIP service domain can and should map into a fully qualified DNS namespace domain. NRS does not have a DNS client. NRS interoperates with third party gateways that may have a DNS client.

L1 and L0 Regional Domains are SIP subdomains. L1 and L0 SIP subdomains are not part of the DNS namespace. L1 and L0 SIP subdomains are not DNS subdomains.

For more information on SIP domains see [Figure 4 "Hierarchy of the NRS database components" \(page 31\)](#) and ["SIP Uniform Resource Identifiers" \(page 34\)](#).

Location Service

Users may move between SIP endpoints and they may be addressable by multiple names. SIP deals with this complexity by distinguishing between an address of record (AOR) and contact addresses.

An AOR is a SIP, or SIPS, Uniform Resource Identifier (URI) that points to a domain with a location service. A contact address is an IP address or DNS name for a SIP device.

A User, User Agent or Service has a unique AOR. A user can have more than one contact address. A user is not limited to registering from a single device. Similarly, more than one user can be registered to a single device.

SIP registration expires unless refreshed. At periodic intervals SIP devices send REGISTER messages to inform the SIP Registrar of the device's current contact address. The SIP Registrar associates (or binds) the AOR in the REGISTER message with the contact address. The SIP Registrar writes the binding to a database. This database is called a location service. The location service contains a list of bindings of AORs to zero or more contact addresses. The NRS database is a location service.

The location service and routing tables in the NRS database are used by a SIP Proxy or a SIP Redirect Server for AOR-to-contact-address resolution.

A SIP endpoint registers with a SIP Registrar to get authorization to initiate a call and/or receive other services. The SIP Registrar updates the NRS database with the client contact information. The NRS database provides a location service that is used by the SIP Proxy or SIP Redirect Server to locate the SIP Trunk Gateway that serves the target of a SIP request. A SIP Trunk Gateway has a number of non-SIP lines and trunks behind it which do not have their own identity in the SIP domain. These non-SIP endpoints are accessed by mapping SIP URIs based on telephony Directory Numbers (DN) to one or more SIP Trunk Gateways. The location service is effectively a matching mechanism that allows a fully-qualified telephone number to be associated with a range of telephone numbers and the SIP Trunk Gateway that provides access to that DN range.

NRS purpose

The NRS:

- Populates the location and registration database.
- Populates routing tables.
- Adds SIP Proxy and Redirect Servers, or SIP Redirect Servers, to the customer network.
- Provides a translation database for telephone numbers contained within the SIP Uniform Resource Identifier (URI) in order to present a well-formed, syntactically-correct telephone number to the location service within the proxy.
- Linux-based NRS populates post-routing SIP URI modification tables.

Signaling Gateways

Signaling gateways translate signaling messages between one medium and another. They provide a bridge between analog or digital devices and IP networks.

Signaling gateways also provide a bridge between one set of IP devices and another set of IP devices.

The IP Peer Network supports the following signaling gateways:

1. SIP gateway
2. H.323 gateway
3. ISDN (Integrated Services Digital Network) PRI (Primary Rate Interface) and ISDN BRI (Basic Rate Interface) to SIP conversion
4. PBX (Private Branch Exchange) to SIP conversion
5. T1/E1 to SIP conversion - bridge between PSTN and an IP network

SIP Gateway

SIP Gateway Signaling is an industry-standard, SIP-based, IP Peer solution that delivers a SIP interface for interoperability with standard SIP-based products.

- uses Virtual Trunks to enable direct, end-to-end paths between two SIP compatible IP devices.
- provides an interface between SIP networks and legacy ISDN and PSTN switched circuit networks. Gateways provide signaling mapping as well as transcoding between IP packet and circuit-switched formats.

The SIP Trunk Gateway provides a direct trunking interface between the CS 1000 systems and a SIP domain. The SIP Trunk Gateway application resides on a Signaling Server and has two functions:

- acts as a SIP User Agent, which services one or more end users in making/receiving SIP calls
- acts as a signaling gateway for all CS 1000 telephones (IP Phones, analog [500/2500-type] telephones, and digital telephones), which maps ISDN messages to and from SIP messages

CS 1000 supports SIP Gateway Signaling and SIP Services

SIP services

SIP Services, include

- Converged Desktop Service (CDS). SIP CDS integrates CS 1000 telephony features with Multimedia Communication Server (MCS) 5100 applications.

SIP CDS allows users to use their existing telephony system for voice communication and to use their PC for multimedia communication.

- Microsoft LCS 2500 Office Communicator.
- IBM Lotus Notes Converged Desktop.

H.323 protocol

H.323 is a signaling protocol for the real-time integration of voice, video, and data in a VoIP network.

The CS 1000 implementation of H.323 complies with the standards of the International Telecommunication Union (ITU) described in the following Recommendation documents of the ITU Telecommunication Standardization Sector (ITU-T):

- H.245
- H.225
- Registration Admission Status (RAS)
- Real-Time Transport Protocol (RTP) and Real-Time Control Protocol (RTCP)

H.323 entities

An H.323 network is composed of four H.323 entities defined by the ITU-T H.323 standard. The four H.323 entities are:

- H.323 terminal
- H.323 Gatekeeper
- Gatekeeper zone
- H.323 Gateway

H.323 terminal

An H.323 terminal is an endpoint that enables real-time communication with other H.323 terminals. This document refers to H.323 terminals as “H.323 endpoints”. H.323 endpoints are IP Phones and H.323 Gateways.

H.323 Gatekeeper

Gatekeepers manage H.323 endpoints in an H.323 network. H.323 endpoints register to a gatekeeper. H.323 endpoints communicate with gatekeepers using the Registration Admission Status (RAS) protocol.

An H.323 Gatekeeper is a network protocol component of the Network Routing Service that serves H.323 endpoints.

Gatekeeper zones

H.323 endpoints are grouped into zones. Each zone is managed by a gatekeeper. A gatekeeper zone is an administrative unit within an IP Peer Network. Separate NRS databases must be managed for each zone.

H.323 Gateway

An H.323 Gateway

- uses Virtual Trunks to enable direct, end-to-end paths between two H.323 compatible IP devices.
- provides an interface between H.323 IP networks and legacy ISDN and PSTN switched circuit networks. Gateways provide signaling mapping as well as transcoding between IP packet and circuit-switched formats.

SIP and H.323 interworking

[Table 1 "Comparison of SIP and H.323 terminology" \(page 26\)](#) summarizes SIP and H.323 interworking terminology.

Table 1
Comparison of SIP and H.323 terminology

NRS Server	In SIP, a SIP Proxy/Registrar or SIP Redirect/Registrar Server In H.323 a Gatekeeper
Endpoint	SIP endpoint (SIP User Agent) H.323 endpoint (H.323 Terminal)
Address Format	SIP supports the URI (Universal Resource Indicator) address format
Endpoint Registration	In Linux-based NRS a SIP client registers to a SIP Proxy/Registrar to update the NRS database. In Vxworks-based NRS a SIP client registers to a SIP Redirect/Registrar Server to update the NRS database. An H.323 endpoint registers with a H.323 Gatekeeper to update the NRS database

The interworking between SIP-oriented services and H.323-oriented services is achieved through the CS 1000 Call Server.

Network Connection Service

The NCS is used to support the Media Gateway 1000B (MG 1000B), IP Line Virtual Office, Branch Office (including the SRG), and Geographic Redundancy features. The NCS provides an interface to the TPS, enabling the TPS to query the NRS using the UNISim protocol.

- Network Connection Service (NCS) – The NCS is required for the IP Line Virtual Office, Branch Office (including the SRG), and Geographic Redundancy features. The NCS allows the Line TPS (LTPS) to query the NRS using the UNISim protocol.

There are four areas in CS 1000 Element Manager and in NRS Manager for configuring the NCS:

- In Element Manager, the H.323 Gateway Settings contains the NCS configuration. See **IP Network > Node: Servers, Media Cards > Configuration > Edit > Signaling Servers > Signaling Server Properties > H323 GW Settings** in the Element Manager Navigator.
- In VxWorks-based NRS Manager, NCS is configured in the following areas:
 - For configuration of the NRS server to support the NCS, see **Home > NRS Server Settings > NCS Settings** (see [Procedure 80 “Configuring NRS Server Settings” \(page 305\)](#)).
 - Configuration of Virtual Office and branch office (including the SRG) user redirection to the main office, see **Configuration > Gateway Endpoints** (see [Procedure 94 “Adding a Gateway Endpoint” \(page 332\)](#)).
 - Configuration of the Virtual Office Login, see **Configuration > Collaborative Servers** (see [Procedure 111 “Viewing the Collaborative Servers” \(page 366\)](#)).

SIP NRS Privacy within a Trusted Network

Within the Linux-based NRS the SIP Proxy asserts a network identity of a caller in a SIP session within an established trust domain as set forth in RFC 3323, RFC 3324 and RFC 3325. This allows the Proxy to convey privacy on behalf of a SIP endpoint within the trusted network. The proxy will withhold a particular SIP endpoint’s identity outside of the trust domain if indicated by the end user or by network policy. This notion of providing privacy Identification is needed in order to deliver, within the trust domain, such features as Caller ID, Caller Name and Number Blocking, and Calling Name and Number. In addition, the use of this feature allows a public and private name to be identified between trusted entities.

Primary and Secondary NRS

All systems in the IP Peer network must register with the Network Routing Service. In order to eliminate a single point of failure in the IP Peer network, Nortel recommends the deployment of both a Primary and a Secondary NRS. (In the VxWorks-based Network Routing Service the Secondary Network Routing Server is referred to as the Alternate Server.) The Secondary Network Routing Server will provide Network Routing Service to the IP Peer network if the Primary Network Routing Server fails.

NRS Failsafe

Within the Linux-based NRS, a failsafe mechanism, used to update CS1000 SIP Gateways configured with the failsafe function, has been deployed in CS 1000 Release 5.5. The failsafe function on the IP Peer Gateways is used as a mechanism by which the SIP Gateways stay in contact with the CS1000 switching agent when network connectivity has been lost to both the primary and secondary NRS service. In order to use proper routing data, the Linux-based NRS, at the prescribed time, will initiate an update session with the CS1000 SIP Gateway, format the SIP routing data from the NRS on Linux, and begin the transfer of the data to the gateway.

In order to perform the failsafe synchronization, the Linux-based NRS should update the solid data remotely to the failsafe server running on VxWorks. At intervals of every 6 hours, the failsafe mechanism synchronizes and updates the routing data with the NRS on Linux for registered failsafe supported gateways.

To reduce CPU load, the failsafe synchronization is only triggered if there is a change to the solid database on Linux. When Cut over and Commit database action is performed, only the changed data needs to be updated on the failsafe server running on VxWorks.

Since the failsafe mechanism is executed periodically, the Linux cron takes care to trigger the operation every 6 hours.

When the Linux cron starts the failsafe synchronization, it may get aborted for the following reasons:

1. When there is no failsafe server configured.
2. When there is no change done to solid database on Linux.
3. When the failsafe data entry is NULL.

Failsafe NRS Synchronization

The Failsafe NRS synchronization script provides a manual command to invoke Failsafe NRS synchronization immediately, instead of waiting up to 6 hours for the Linux cron to invoke the scheduled Failsafe

NRS synchronization. To manually invoke Failsafe NRS database synchronization type in the full pathname to the database synchronization script

```
/opt/nortel/sps/scripts/failsafe.pl main
```

CS 1000 Release 5.0 interoperability with NRS Release 5.5

CS 1000 Release 5.0 endpoints can register as SIP Gateways and H.323 Gatekeepers with NRS Release 5.5.

Database component

NRS Database

The NRS database is comprised of endpoints (IP phones, SIP gateways, H.322 gateways, and collaborative servers), routing tables containing routes to these endpoints and post-routing SIP URI modification tables.

The NRS database stores the central dialing plan in XML format for the SIP Proxy, the SIP Redirect Server and the H.323 Gatekeeper. The SIP Proxy, the SIP Redirect Server and the H.323 Gatekeeper access this common endpoint and gateway database.

The NRS allows for the configuration of multiple customers.

The advantages of the NRS database are:

- simplicity of administration
- troubleshooting
- capacity enhancements
- synchronization
- authentication
- maintenance
- web-based interface (NRS Manager)

The database component of the NRS is responsible for:

- configuring the numbering plan
- reading and updating the active and standby databases on disk
- resolving all registrations and requests which the NRS passes to the database


The NRS numbering plan configuration is stored in XML format in two databases on disk. The active database is used for call processing and the standby database is used for configuration changes.

The database component interfaces with the active and standby databases on disk. All call processing requests that the NRS passes to the database are resolved using the active database. The database uses the information that the NRS extracted from the request to search its database. For example, in the case of a SIP? message or an H.323 ARQ message, the database attempts to find a registered endpoint that can terminate the call.

The NRS Manager web server interfaces with the database for viewing, adding, deleting, or modifying numbering plan configuration data and routing entries. All changes to the numbering plan database are carried out on the standby database. Changes that the administrator makes to the numbering plan database do not affect call processing immediately. The database must first be cut over to the active database. The database is cut over to the active database by executing a database **Cut over** command.

The NRS database provides a central database of addresses that are required to route calls across the network. The NRS database resides on the server hosting the Network Routing Service (see [Figure 3 "NRS database and network protocol components"](#) (page 30)).

Figure 3
NRS database and network protocol components




The SIP Proxy, the SIP Redirect Server and the H.323 Gatekeeper have access to the endpoint/location database.

- The SIP Proxy and the Redirect Server access the location database on CS 1000 systems to direct SIP Trunk Gateways within a networked environment.
- The H.323 Gatekeeper also accesses the central location database, but to direct H.323 Gateways.

The routing data is the same for SIP and H.323. As a result, the SIP Proxy, the SIP Redirect Server and the H.323 Gatekeeper provide address-resolution functionality for the CS 1000 Call Server.

Figure 4 "Hierarchy of the NRS database components" (page 31) shows a hierarchical view of the database. The data is stored and organized in the database as described in "Hierarchical model of the Network Routing Service" on page 41. The data is used by the SIP Proxy, the SIP Redirect Server and the H.323 Gatekeeper.

Figure 4
Hierarchy of the NRS database components



Hierarchical model of the Network Routing Service


The NRS can support multiple customers and can provide routing services to several service provider networks. To do this, the NRS server uses the hierarchical model outlined in [Table 2 "Hierarchical model of the Network Routing Service" \(page 32\)](#). This model determines how information is stored and organized in the database. The data stored in the database is common to both H.323 and SIP.

Table 2
Hierarchical model of the Network Routing Service

Level	Description
Service Domain	<p>Represents a service provider network.</p> <p>A service domain maps into a SIP-domain.</p> <p>Example: myServiceProvider.com</p>
Level 1 Regional Domain	<p>Represents a subdomain in a Service Domain.</p> <p>Note 1: The Level 1 Regional Domain is also referred to as the L1-domain (in the context of the Network Routing Service). An L1-domain maps into an enterprise/customer network as well as a Meridian Uniform Dialing Plan (UDP) domain. The L1-domain should match across the UDP domain including E.164. Example: myCompany.com</p> <p>Note 2: UDP means all the call types in the dialing plan which include private (special numbers) and public (national, international, subscriber, and special numbers).</p>
Level 0 Regional Domain	<p>Represents a subdomain in a Level 1 Regional Domain.</p> <p>Note 1: The Level 0 Regional Domain is also referred to as the L0-domain (in the context of the Network Routing Service). An L0-domain maps to a site level as well as a Meridian Coordinated Dialing Plan (CDP) domain. The L0-domain should match across the CDP domain. Example: myCdpDomain</p> <p>Note 2: A site can be a street address, a campus, or a metropolitan area.</p>
Gateway Endpoint	<p>Represents a gateway. It exists within an L0 Domain. A site can have many endpoints.</p> <p>Example: sipGWSite1, sipGWSite2</p>
User Endpoints	<p>Represents a SIP Phone. It exists with the L0 domain. A site can have many SIP Phones.</p> <p>Example: johndoe, janesmith</p>
Routing Entry	<p>Represents a range of addresses (URIs) where a gateway can terminate calls. A routing entry exists within a gateway. These are the routing entries that the gateway supports.</p>

Figure 5 "Hierarchical structure of the Network Routing Service" (page 33) shows the hierarchical structure of the Network Routing Service.

Figure 5
Hierarchical structure of the Network Routing Service



Note: If there is no Service Domain, the Service Domain must be configured the same as the Level 1 Regional Domain.

For example:

- Bell Canada is the Service Provider.
- Nortel is the Level 1 Domain.
- Sites within Canada can make up the Level 0 Domains (such as Belleville or Ottawa).
- Switches at the sites are the Gateway Endpoints.

SIP authentication

The data that the SIP Proxy/Registrar and the SIP Redirect/Registrar Server needs to successfully perform authentication is configured in two ways:

- Group identity
 - against an enterprise network (that is, the Level 1 Regional domain)
 - against a site in the enterprise network (that is, the Level 0 Regional (CDP) Domain)
- Individual endpoint identity

- against a Gateway Endpoint
- against a SIP User Endpoint

If a gateway endpoint does not have individual identity configured, then the L0 Domain group identity data is used by the SIP Proxy/Registrar and the SIP Redirect/Registrar Server during the authentication procedure.

If neither the individual endpoint identity nor the L0 identity is provided, then L1 Domain identity is used.

Configuring authentication in the NRS

Authentication is configured using NRS Manager. Authentication can be configured at the following levels in the NRS:

Level 1 Domain and Level 0 Domain Authentication can be turned on or off at this level. If authentication is turned on, then all Gateway Endpoints and SIP User Endpoints require authentication.


Gateway Endpoints and SIP User Endpoints Authentication can also be turned on or off at the Gateway Endpoint and SIP User Endpoint levels. This level provides three authentication options:

- Not configured — If this option is selected, then the endpoint uses the Level 1 or Level 0 Domain authentication (if Level 1 authentication is enabled).
- Authentication off — If authentication is turned off, then authentication is off for this endpoint even if Level 1 or Level 0 Domain authentication is enabled. This endpoint authentication setting overrides the Level 1 and Level 0 Domain authentication setting.
- Authentication on — If authentication is turned on, then authentication is on for this endpoint and the authentication overrides the Level 1 and Level 0 Domain authentication (if it is enabled). This endpoint authentication setting overrides the Level 1 and Level 0 Domain authentication setting.

SIP Uniform Resource Identifiers

The NRS supports SIP URIs (see [Figure 6 "SIP URI example" \(page 34\)](#)). A SIP URI is a user's SIP identity.

Figure 6
SIP URI example



The ISDN NPI/TON field explicitly maps to the SIP phone-context attribute. The public numbering plans map to SIP URI by rules specified in RFC 2806 and RFC 3261. The exception is TON = unknown and TON = special number.

The private numbering plans, public/unknown numbers, and public/special numbers also have explicit one-to-one mappings to SIP URI. They must be defined by preconfigured subdomain names. The subdomain name must be defined on both Gateway and proxy/registrar.

The NRS also facilitates a translation database for phone numbers contained within the SIP URI, in order to present a well formed, syntactically correct phone number to the location service. Therefore, the NRS is designed to operate with both the phone-context and NPI/TON qualified numbers.

Example

[Table 3 "Numbering plan mapping" \(page 36\)](#) provides an example of the numbering plan mapping to clarify how different dialing plans are mapped to a SIP URI. Two methods can be used to configure the URI map — one for the NRS and one for the MCS 5100. [Table 3 "Numbering plan mapping" \(page 36\)](#) provides examples for both the NRS and MCS 5100.

Assume the following:

- The SIP Trunk Gateway has registered at a domain called myServiceProvider.com.
- A telephone user resides at sipGWSite1 and has ESN Location Code 343 with extension 3756. The Direct Inward Dialing (DID) number is 1-613-967-3756.

Refer to [Figure 5 "Hierarchical structure of the Network Routing Service" \(page 33\)](#) for the SIP address hierarchy tree.

Table 3
Numbering plan mapping

NPI/TON/DN	SIP URI
E.164/ International/ 1-613-967-3756	<p>NRS example: sip:+16139673756@myServiceProvider.com;user=phone</p> <p>MCS 5100 example: sip:+16139673756@myServiceProvider.com;user=phone</p> <p>Note: Public international numbers do not have a phone context, as these numbers are globally unique within a domain. A plus sign (+) is automatically added by the gateway before the digits to indicate that the number is an international number.</p>

Table 3
Numbering plan mapping (cont'd.)

NPI/TON/DN	SIP URI
E.164/National/ 613-967-3756	<p>NRS example: sip:6139673756;phone-context=+1@myServiceProvider.com;user=phone</p> <p>MCS 5100 example: sip:6139673756;phone-context=mynation.national.e164.myrootdomain@myServiceProvider.com;user=phone</p>
E.164/Subscriber/ 967-3756	<p>NRS example: sip:9673756;phone-context=+1613@myServiceProvider.com;user=phone</p> <p>MCS 5100 example: sip:9673756;phone-context=myarea.mynation.local.e164.myrootdomain@myServiceProvider.com;user=phone</p>
E.164/Unknown /9-1-613-967-3756	<p>Not supported for the NRS.</p> <p>MCS 5100 example: sip:916139673756;phone-context=myarea.mynation.unknown.e164.myrootdomain@myServiceProvider.com;user=phone</p>
E.164/ Special Number/ 911	<p>Not supported for the NRS.</p> <p>MCS 5100 example: sip:911;phone-context=myarea.mynation.special.e164.myrootdomain@myServiceProvider.com;user=phone</p>
Private/UDP/ 343-3756	<p>NRS example: sip:3433756;phone-context=myCompany.com@myServiceProvider.com;user=phone</p> <p>MCS 5100 example: sip:3433756;phone-context=level1.private.myenterprise@myServiceProvider.com;user=phone</p>
Private/CDP/ 3756	<p>NRS example: sip:3756;phone-context=myCdpDomain.myCompany.com@myServiceProvider.com;user=phone</p> <p>MCS 5100 example: sip:3756;phone-context=mylocation.level0.private.myenterprise@myServiceProvider.com;user=phone</p>

Table 3
Numbering plan mapping (cont'd.)

NPI/TON/DN	SIP URI
Private/ Special Number/ 911	NRS example: sip:911;phone-context=special.myCdpDomain.myCompany.com @myServiceProvider.com;user=phone MCS 5100 example: sip:911;phone-context=mylocation.special.private.myenterprise @myServiceProvider.com;user=phone
Private/ Unknown (Vacant Number Routing)/ 343-3756	No configuration is required for NRS. MCS 5100 example: sip:3433756; phone-context=mylocation.unknown.private.myenterprise @myServiceProvider.com;user=phone
Unknown/ Unknown/ 6-343-3756	No configuration is required for NRS. MCS 5100 example: sip:63433756; phone-context=mylocation.unknown.unknown. myrootdomain@myServiceProvider.com;user=phone

Database synchronization/operation component

The Network Routing Service can be redundantly instantiated across a cluster of Network Routing Servers sharing a distributed database. In CS 1000 Release 5.0 or later the cluster is comprised of a Primary Network Routing Server and a Secondary Network Routing Server.

Note: In the VxWorks-based Network Routing Service the Secondary Network Routing Server is referred to as the Alternate Server.

The NRS database for each Network Routing Server has two schemas — an active schema and a standby schema.

- The active database is used for runtime location queries by SIP Proxy, Gatekeeper and Network Connection Service.
- The standby database is used by the administrator to modify the NRS database. An Administrator can only make changes to the standby database.

The database synchronization component has two functions:

1. Synchronization of the active and standby databases on a Network Routing Server.
2. Synchronization of the databases on the Primary and Secondary Network Routing Servers.


Synchronization of the active and standby databases on a Network Routing Server

Cut over and revert

Figure 8 "NRS database actions - Cut over and Revert" (page 39) shows both the active and standby database when **Cut over** and **Revert** database commands are issued.

1. The active and standby databases are synchronized.
2. A change is made to the standby database.
3. The standby database is changed and the active database is unchanged. The databases are not synchronized.
4. The database **Cut over** command is issued.
5. The changed database becomes the active database.
6. The database **Revert** command is issued. (Perhaps the Administrator wants to make more changes to the database.)
7. The changed database becomes the standby database.

Figure 8
NRS database actions - Cut over and Revert




Cut over and commit

Figure 9 "NRS database actions - Cut over and Commit" (page 40) shows both the active and standby database when **Cut over** and **Commit** database commands are issued.

1. The active and standby databases are synchronized.
2. A change is made to the standby database.
3. The standby database is changed and the active database is unchanged. The databases are not synchronized.
4. The database **Cut over** command is issued.
5. The changed database becomes the active database.

6. The database **Commit** command is issued. (The administrator wants to submit the changes made to the database.)
7. The databases are synchronized. Both databases are changed.

Figure 9
NRS database actions - Cut over and Commit




Single-step Cut over and Commit

Figure 10 "NRS database actions - single-step Cut over and Commit" (page 41) shows both the active and standby database when a single-step **Cut over and Commit** database command is issued:

1. The active and standby databases are synchronized.
2. A change is made to the standby database.
3. The standby database is changed and the active database is unchanged. The databases are not synchronized.
4. The database single-step **Cut over and Commit** command is issued.
5. The databases are synchronized. Both databases are changed.

Figure 10
NRS database actions - single-step Cut over and Commit




Rollback

Figure 11 "NRS database actions - rollback" (page 42) shows both the active and standby database when a **Rollback** database command is issued:

1. The active and standby databases are synchronized.
2. A change is made to the standby database.
3. The standby database is changed and the active database is unchanged. The databases are not synchronized.
4. The database **Rollback** command is issued. (The administrator wants to undo the changes to the database.)
5. The databases are synchronized. Neither database is changed.

Figure 11
NRS database actions - rollback



To perform database actions using NRS Manager, refer to [“Performing NRS database actions”](#) (page 376).

Synchronization of the databases on the VxWorks-based Primary and Alternate Network Routing Servers.

The time interval between database synchronization of the Primary NRS and the Alternate NRS is a configurable parameter in the VxWorks-based NRS. The time interval between database synchronization of the Primary NRS and the Alternate NRS is in the range 1 to 24 hours.

Note: To manually force synchronization of the active NRS database with the Alternate or Failsafe NRS database, the administrator should issue the Command Line Interface (CLI) command `nrsDBSyncForce`

Synchronization of the databases on the Linux-based Primary and Secondary Network Routing Servers.

Synchronization of the Primary NRS database and the Secondary NRS database occurs in real-time in the Linux-based NRS.

Failsafe NRS Synchronization

The Failsafe NRS synchronization script provides a manual command to invoke Failsafe NRS synchronization immediately, instead of waiting up to 6 hours for the Linux cron to invoke the scheduled Failsafe NRS synchronization. To manually invoke Failsafe NRS database synchronization type in the full pathname to the database synchronization script

```
/opt/nortel/sps/scripts/failsafe.pl main
```

NRS functionality

Contents

This section contains information on the following topics:

- “Introduction” (page 43)
- “Network overview” (page 44)
 - “Coordinated endpoint configuration across multiple NRS zones” (page 44)
 - “NRS purpose” (page 49)
 - “H.323 Gatekeeper discovery” (page 50)
 - “H.323 Endpoint registration” (page 50)
- “NRS Manager” (page 54)
 - “Security” (page 55)
- “NRS operating parameters” (page 56)
- “Standalone NRS support for Meridian 1 and BCM nodes” (page 63)
 - “Meridian 1/BCM node-based numbering plan” (page 63)
 - “NRS-based numbering plan” (page 64)

Introduction

All systems in the IP Peer network must register with the NRS.

The primary function of the NRS is to provide the following services:

- endpoint and Gateway registration
- call admission control
- address translation and telephone number-to-IP lookup
- centralized numbering plan administration

Note: The NRS can operate in stand-alone mode, without being connected to the Call Server.

The NRS is SIP- and H.323-compliant. It can provide NRS features to other SIP-compliant and H.323-compliant Nortel endpoints (for example, CS 1000 systems and IP Trunk 3.0 (or later) endpoints). A static IP address must be configured for these endpoints, as well as the telephone numbers that the endpoints can terminate.

Note: Systems that do not support H.323 RAS procedures and H.323 Gatekeeper procedures are referred to as non-RAS endpoints.

Network overview

With IP Peer Networking, each network zone contains one active NRS. The NRS can run on any of the Signaling Server platforms on any of the CS 1000 nodes in the network. The NRS is configured with numbering plan information for every node in the network zone.

Coordinated endpoint configuration across multiple NRS zones

IP Peer Networking supports multiple SIP and H.323 zones. Separate NRS databases must be managed for each zone in a 1:1 relationship. Each NRS zone contains a Primary NRS, optionally an Alternate NRS, and multiple Gateway Endpoints or User Endpoints. The reasons for implementing multiple NRS zones are:

1. to scale up to very large networks with hundreds of registered endpoints
2. to divide a network of any size into convenient administration zones (for example, Western Europe and North America)

When a CS 1000 system places an IP call to another node, the originating Gateway signaling server sends a message to the NRS, specifying the destination telephone number. The NRS consults its internal numbering plan database and determines which node is the correct destination node.

SIP operation

The SIP Redirect Server allows SIP Trunk Gateways to communicate with other SIP Trunk Gateways across an enterprise. The SIP Trunk Gateway must keep information only about various lines and applications for which it is responsible, and it must have enough knowledge to contact the SIP Redirect Server. The SIP Redirect Server then redirects the SIP Trunk Gateway to where it needs to send its signaling.

A SIP Redirect Server receives requests but, rather than passing these requests onto another redirect server, it sends a response back to the originator of the request.

SIP Trunk Gateways, SIP Proxy Servers (for example, the MCS 5100), and SIP Phones forward calls to the contact address returned by the SIP Redirect Server. For instance, a SIP Trunk Gateway sends an INVITE


message to the SIP Redirect Server. The SIP Redirect Server then sends a redirect message back to the originator with the addressing information for the destination node. The originator then sends an INVITE message directly to the SIP Trunk Gateway destination node.

For example, User A would like to contact User B across the enterprise network. The following sequence occurs:

- User A contacts its SIP Trunk Gateway. (That is, User A sends an address-resolution request to the SIP Trunk Gateway.)
- User A's SIP Trunk Gateway contacts the EBN SIP Redirect Server.
- The EBN SIP Redirect Server executes a location look-up to see if its database contains an address match for the domain of User B.
- If a match is found, the SIP Redirect Server returns a response back to User A indicating the contact address required for User A to call the called party. (That is, the EBN SIP Redirect Server redirects User A's SIP Trunk Gateway to User B's SIP Trunk Gateway.)
- User A's SIP Trunk Gateway uses the provided contact address and directly communicates with User B's SIP Trunk Gateway.
- A direct media path is then set up between User A and User B.

[Figure 12 "SIP Signaling and SIP Redirect Server" \(page 46\)](#) shows how the SIP Redirect Server accepts a request from a SIP Trunk Gateway and sends the response back to the SIP Trunk Gateway. The SIP Trunk Gateway can then contact the called party's SIP Trunk Gateway directly. Once the SIP Trunk Gateway contacts the called party's SIP Trunk Gateway, a direct media path is set up between the caller and the called party.

Figure 12
SIP Signaling and SIP Redirect Server



If the SIP Redirect Server does not find any matching numbering plan entries, (a NULL entry is returned by the database), then the SIP Redirect Server transmits a SIP 404 (Not Found) response.

Similarly, if a request fails due to registration failure, a SIP 401 (Unauthorized) response is transmitted.

Note: All redirect server logs use the existing RPT report log facility.

H.323 operation

An H.323 Gateway sends an ARQ message to the H.323 Gatekeeper. If a match is found for the called-party number digits in the ARQ, then the H.323 Gatekeeper sends an ACF message to the call originator and includes addressing information for the destination node.

If no numbering plan entries are found, the H.323 Gatekeeper queries all the H.323 Gatekeepers on its list, using H.323 LRQ/LCF (Location Request/ Location Confirm) multicast protocol.

For example, a caller located at Node A places a call and sends an ARQ message to the H.323 Gatekeeper. The H.323 Gatekeeper consults its numbering plan database, determines that Node B is the correct destination, and returns the addressing information for Node B in an ACF message. Node A then sends the SETUP message directly to the H.323 Gateway Signaling Proxy Server on Node B.

If an H.323 Gatekeeper cannot resolve the destination address received in an incoming ARQ message, then it sends a LRQ message to other network zone H.323 Gatekeepers in order to resolve the number.

Note: The H.323 Gatekeeper sending the LRQ message includes its own identification in the LRQ message and does not include the H323-ID of the gateway that sent the original ARQ message.

The peer H.323 Gatekeeper that resolves the number sends an LCF message with the destination Call Signaling address.

If an H.323 Gatekeeper cannot resolve the destination address in an incoming LRQ, it sends a Location Reject (LRJ) message to the originator of the LRQ message.

The behavior of the H.323 Gatekeeper (that sent the LRQ messages) depends on the responses from the remote H.323 Gatekeepers. When an LCF is received from a remote H.323 Gatekeeper, the local H.323 Gatekeeper immediately sends the ACF to the gateway at Node A. If an ARJ is received indicating "incomplete number", further digits are required. An immediate ARJ indicating the need for further digits is sent to Node A. Node A retries on receiving more digits. Otherwise, the local H.323 Gatekeeper waits until either all the remote Gateways have responded, or a timer expires indicating that one or more Gatekeepers could not reply. At this time, either an ARJ indicating call failure is returned, or an ACF indicating the default route is returned.

Incoming LRQ messages When an H.323 Gatekeeper receives an incoming LRQ message, it checks to see if the H.323 Gatekeeper that sent the request is configured in its database. The information received in the **sourceInfo** field is used for authentication.

Table 4
How the H.323 Gatekeeper authenticates incoming LRQ messages

If the H.323 Gatekeeper sending the LRQ is a...	Then its sourceInfo field contains...	And the H.323 Gatekeeper has to check...
CS 1000 Release 4.0 (or later) H.323 Gatekeeper or	the alias address of the peer H.323 Gatekeeper that sent the LRQ message	(not applicable)

If the H.323 Gatekeeper sending the LRQ is a...	Then its sourceInfo field contains...	And the H.323 Gatekeeper has to check...
Succession 3.0 H.323 Gatekeeper		
CS 1000 Release 2.0 H.323 Gatekeeper	the alias address of the H.323 Gateway	for the alias in the <ul style="list-style-type: none"> • network zone H.323 Gatekeeper list • endpoints list

If the information in the sourceInfo field cannot be authenticated, then the H.323 Gatekeeper rejects the incoming LRQ.

On receiving the incoming LRQ, the H.323 Gatekeeper parses the sourceInfo field. It searches for the source alias address as a URL ID type or an H323-ID type.

The H.323 Gatekeepers send the gatekeeper alias address along with the CDP domain information as a URL string. The format of the URL string is:

```
h323:gkH323ID;phone-context=cdpDomain
```

This URL string contains two variables that are configured at the far end:

- gkH323ID
- cdpDomain

This URL string is parsed for incoming LRQs and is used to extract the H.323 Gatekeeper alias name and the CDP domain information.

- The H.323 Gatekeeper alias name is used for gatekeeper authentication.
- The CDP domain information is used to search in the same CDP domain if the destination info was private.level0 type of number.

Note: The cdpDomain is a string of characters that can be of any format. Typically, it would be something like the following to ensure uniqueness: "CDP-TorontoOntarioCanada.cdp.corporateTitle.com".

Outgoing LRQ messages An H.323 Gatekeeper can be configured with a list of IP addresses of alternate H.323 Gatekeepers in different network zone. The H.323 Gatekeeper can then send LRQ requests in an attempt to resolve ARQ requests for which it cannot find registered matches in its own numbering plan database.

The configuration of H.323 Gatekeepers Collaborative Servers includes:

- an IP address
- an H.323 ID
- a CDP domain (Level 0 Domain)

See [Procedure 110 “Adding a Collaborative Server” \(page 362\)](#).

This information is used for incoming LRQs and is also used to determine the H.323 Gatekeepers in which to send outgoing LRQs. If a Network Zone H.323 Gatekeeper is configured with a CDP domain, then it is sent an LRQ only if the endpoint sending the ARQ is also in the same CDP domain. If an ARQ request arrives, and there is no matching numbering plan entry for the destination telephone number or there is a match but the matching entry (plus any alternates) is not currently registered, then the H.323 Gatekeeper sends an LRQ to all other H.323 Gatekeepers on the network whose IP addresses have been configured.

Each H.323 Gatekeeper is configured with an H.323 Gatekeeper alias name which is an H323-ID. The outgoing LRQ message contains the H.323 Gatekeeper alias name in the sourceInfo field instead of the H323-ID received in the incoming ARQ message.

NRS purpose

IP Peer Networking uses optionally redundant NRS to support a centralized Network Numbering Plan. Each NRS has a zone that administers its own numbering plan and requests other NRS for the numbering plan in their respective zones. A numbering plan specifies the format and structure of the numbers used within that plan. A numbering plan consists of decimal digits segmented into groups to identify specific elements used for identification, routing, and charging capabilities. A numbering plan does not include prefixes, suffixes, and additional information required to complete a call. The Dialing Plan contains this additional information. The Dialing Plan is implemented by the endpoints in a network. A Dialing Plan is a string or combination of digits, symbols, and additional information that defines the method by which the numbering plan is used. Dialing Plans are divided into the following types:

- Private (on-net) dialing
- Public (off-net) dialing

For more information about numbering plans and dialing plans, see [“Numbering plans” \(page 67\)](#).

H.323 Gatekeeper discovery

Endpoints that require admission to the IP network and address translation must discover their NRS. Endpoints can be configured with the static IP address of the NRS running on the network's Primary NRS. This ensures that the IP address stays constant across restarts, and, therefore, the endpoints with statically configured NRS IP addresses can always discover the NRS. These endpoints send a message directly to the NRS over the User Datagram Protocol/Internet Protocol (UDP/IP). This is the recommended approach; however, endpoints not configured with the IP address of the NRS can use multicast to discover the IP address of their NRS.

The message requesting the IP address of the H.323 Gatekeeper contains the endpoint alias and the RAS signaling transport address of the endpoint. This is so the H.323 Gatekeeper knows where to send return messages. The message from the endpoint to the H.323 Gatekeeper also contains vendor information. Thus, the H.323 Gatekeeper determines the specific product and version that is attempting discovery. The H.323 Gatekeeper only uses this information if the request for discovery is rejected.

Nortel recommends that endpoints use the endpoint Alias.h323-ID alias types.

The Gatekeeper contains a list of predefined endpoint aliases. The Gatekeeper attempts to match the H323-ID in the message from the endpoint with one of the endpoint aliases in the list. If it cannot find a match, it rejects the discovery request.

The Gatekeeper returns its RAS signaling transport address to any endpoints that are allowed to register, so the endpoints know where to send RAS messages. The Gatekeeper also returns a list of Alternate Gatekeepers, if any are configured. Therefore, if the Gatekeeper is removed from service gracefully or if it cannot be reached by an endpoint, the endpoints can attempt to register with the Gatekeepers in the Alternate Gatekeepers list.

Note: Gatekeeper Discovery using the Multicast approach is not recommended over large networks, because all routers between the endpoint requesting Gatekeeper discovery and the Gatekeeper must support Internet Group Management Protocol (IGMP).

H.323 Endpoint registration

After Gatekeeper discovery is complete, endpoints must register with the Gatekeeper. The Signaling Server platform, on which the H.323 Proxy Server for the node runs, has an IP address. This IP address is both

the RAS signaling transport address and the call-signaling transport address. The endpoints register with the Gatekeeper by sending a registration-request message to the Gatekeeper.

Registering endpoints must provide vendor information, as well as its alias name in the registration-request message. The Gatekeeper tracks the vendor information for management purposes. The administrator can determine the exact product and version of all registered endpoints using NRS Manager or the CLI. The Gatekeeper also uses this information if registration fails.

If the Gatekeeper accepts the registration request, it responds with a registration confirmation message. In this message, the Gatekeeper can include the IP address of an Alternate Gatekeeper (if one is configured). Endpoints also provide call signaling and RAS transport addresses in the registration-request message. The Gatekeeper supports the receipt of multiple transport addresses and gives priority to the first address in each list.

Note 1: IP Trunk 3.0 (or later) nodes always register multiple IP addresses due to the load-balancing architecture of the IP Trunk 3.0 (or later) nodes. The first IP address in the registration request is the node IP address and the remaining IP addresses are the IP addresses of the individual trunk cards in the node. When a call terminates on an IP Trunk 3.0 (or later) node, the Gatekeeper returns only the node IP address. The Gatekeeper knows that the endpoint is an IP Trunk 3.0 (or later) node, as its vendor information is provided in the request for registration message.

Note 2: IP Trunk 3.0 (or later) nodes use multiple IP addresses when sending admission requests to the Gatekeeper. The card that is the RTP endpoint for the call uses its own IP address for the ARQ. However, to ensure that the node can carry out load-balancing, the node "Leader" IP address is sent to the Gatekeeper in the registration request; no other IP addresses are provided, to allow the IP Trunk node to control load balancing. The Gatekeeper knows that the IP Trunk 3.0 (or later) IP address used in the ARQ belongs to the node, since the Gatekeeper provides an endpoint identifier in the registration sequence, and this is included in all ARQs.

The Gatekeeper extracts the H323-ID from the incoming request for registration message and attempts to match it with one of the preconfigured endpoint H323-ID aliases in its internal database. If no match is found, the Gatekeeper rejects the registration request. If a match is found, the Gatekeeper accepts registration and extracts the call signaling and RAS transport addresses from the registration-request message. The Gatekeeper updates its internal database with this

information and then sends a registration confirmation message to the endpoint. If an Alternate Gatekeeper is configured, the Gatekeeper also returns the Alternate Gatekeeper's IP address.

The Gatekeeper assigns the endpoint a unique Endpoint Identifier and returns this identifier in the registration confirmation message. This Endpoint Identifier is included in all subsequent RAS requests that the endpoint sends to the Gatekeeper. The Gatekeeper tracks the value of the assigned Endpoint Identifier for the duration of the endpoint's registration. The Gatekeeper can then match any incoming RAS request with the registration confirmation sent previously.

Note: The Gatekeeper accepts registration-request messages from an endpoint even if the Gatekeeper has not received a Gatekeeper discovery request from that particular endpoint.

Time-to-Live

The registration message includes Time-to-Live information. Endpoints periodically send registration-request messages to the NRS in order to remain registered and so that the NRS knows that the endpoints are alive.

An endpoint's registration with the NRS can expire. Registering endpoints must include Time-to-Live information in their registration-request messages. The NRS responds with the same Time-to-Live information or the Time-to-Live information currently configured on the NRS if the NRS timer is shorter. This is a time-out in seconds. After this time, the registration expires. Before the expiration time, the endpoint sends a registration-request message with the "Keep Alive" bit configured. When the NRS receives this request, it extends the endpoints registration and resets the Time-to-Live timer.

If the Time-to-Live timer expires, the NRS unregisters the endpoint. The endpoint's entry in the internal database is updated to indicate that it is no longer registered and that the associated transport addresses are no longer valid.

Configure the Time-to-Live timer using NRS Manager. Nortel recommends that the timer be configured to 30 seconds. Refer to [Procedure 79 "Configuring system-wide settings" \(page 304\)](#).

Multiple registration requests

The NRS supports re-registration requests by an endpoint, provided that the information contained in the registration request is identical to that in the initial registration request. For example, if an endpoint crashes and then restarts after the boot sequence, it attempts to reregister with the NRS by sending another registration-request message. The NRS accepts this registration by sending a confirmation message to the endpoint.

Registration requests when the NRS is out-of-service

The NRS can be taken out-of-service through NRS Manager. If the NRS receives a registration-request message from an endpoint while it is out-of-service, it rejects the registration request. However, the NRS sends the IP address of the Alternate NRS in the reject message.

Unregistration

An endpoint should be taken out-of-service prior to changing its IP address or performing software upgrades. Once out-of-service, an endpoint unregisters from the NRS by sending an unregister message. The NRS updates the endpoint's entry in the internal database to indicate that it is no longer registered and that the associated transport addresses are no longer valid.

If the endpoint does not send an unregister message to the NRS, the NRS automatically unregisters the endpoint when the Time-to-Live timer expires.

SIP registration

The SIP Registrar accepts REGISTER requests. A request is a SIP message sent from a client to a server to invoke a particular operation.

Note: A response is a SIP message sent from a server to a client to indicate the status of a request sent from the client to the server.

Registration entails sending a REGISTER request to the SIP Registrar. The SIP Registrar acts as the front end to the location service (database) for a domain, reading and writing mappings based on the contents of REGISTER requests. This location service is then typically consulted by a SIP Redirect or Proxy Server that is responsible for routing requests for that domain.

The SIP Registrar places the information it receives (in the requests) into the location service for the domain it handles. The location service is used by the SIP Redirect and Proxy Servers to locate the SIP Trunk Gateway that serves the target of the request. A SIP Trunk Gateway has a number of non-SIP lines and trunks behind it which do not have their own identity in the SIP domain. These non-SIP endpoints are accessed by mapping SIP URIs based on telephony DNs to one or more SIP Trunk Gateways. The location service is a matching mechanism that allows a fully-qualified telephone number to be associated with a range of telephone numbers and the SIP Trunk Gateway that provides access to that DN range.

SIP endpoints are also known as User Agents. User Agents have two functions:

- act as User Agent Clients — initiate request
- act as User Agent Servers — process requests and generate responses to the requests

The SIP Registrar is a special type of User Agent Server.

The REGISTER request

A REGISTER request is used for registering contact information. The REGISTER request is used by SIP clients to notify a SIP network of its current IP address and the URLs for which it would like to receive a call. This SIP mechanism is used by called parties to register in order to receive incoming calls from proxies that serve that domain.

Dynamic registration

Dynamic registration facilitates the creation of a contact list for the authorized SIP Trunk Gateway Endpoints and SIP Phones (SIP User Endpoints).

Dynamic registration of SIP Trunk Gateway Endpoints SIP Trunk Gateway dynamic registration facilitates the creation of the contact list for the authorized Gateway endpoints. The gateways dynamically register their IP address with the SIP Redirect/Proxy Server (that is, with the SIP Registrar component). This eliminates some manual provisioning at the SIP Redirect Server. It also reduces the potential for error when manually entering the IP address of the SIP Trunk Gateway in the SIP Redirect Server.

Dynamic registration of SIP Phones (SIP User Endpoints) SIP Phone dynamic registration facilitates the creation of the contact list for the authorized SIP Phones. For more information about SIP Phone registration, refer to [“SIP Phone dynamic registration” \(page 101\)](#).

Database synchronization Database synchronization treats dynamically registered data the same way as the H.323 Gatekeeper:

- If the Alternate NRS database takes over, then registrations are lost.
- If the Failsafe NRS database takes over, then registrations are kept.

NRS Manager

NRS Manager is a web-based configuration interface. Use NRS Manager to configure the NRS. You can use NRS Manager to view, add, modify, or delete all numbering plan configuration data.

You can perform the following NRS configuration functions using NRS Manager:

- configure a numbering plan
- add, modify, or delete preconfigured endpoint data
- add, modify, or delete numbering plan entries on a per-endpoint basis
- retrieve the current configuration database
- interwork with a preconfigured database
- revert to the standby database
- change system passwords

Security

NRS Manager is password-protected.

The NRS has two access levels:

- Administrator level
- Monitor level

Refer to *Security Management (NN43001-604)*, for detailed information on CS 1000 system security including protection of signaling and the media stream from privacy intrusions or disruption, and the administration and use of secure remote access.

Administrator access

A user with administration-level access can view and modify the NRS. Administrator-level access is the highest authority level. An administrator has the authority to manage the entire NRS.

The administrator has the ability to view, create, and modify the login names and passwords that are used for configuration and maintenance.

If you log in to NRS Manager as an administrator, you have full administrative access. You can update all configuration entries, and you have full write access to the database, including the ability to change all NRS passwords.

The NRS administrator username and password are used only when accessing NRS Manager. Changing the NRS administrator username and password does not change the username and password for the Signaling Server shell.

ATTENTION

Nortel recommends that default usernames and passwords be changed for increased network security.

Changing username and passwords The usernames and passwords used to access the NRS can be changed under the Administration tab in NRS Manager. See “[Configuring and administering users](#)” (page 401).

All user login names and passwords are recorded in the NRS database. The passwords are stored in an encrypted format.

Monitor access

A user with monitor-level access can only view existing NRS configuration data. The user cannot modify any NRS configurations or settings. A user with monitor access can only change their own password.

NRS Manager blocks certain navigation operations for monitor-access level users. If a user is a monitor-level user, then NRS Manager does not allow the user to change NRS provisioning operations.

If you log in to the NRS as a monitor, you can:

- view configuration data
- execute H.323 and SIP routing tests
- review reports

Note: CS 1000 Element Manager includes performance and traffic monitoring functions.

NRS operating parameters

The NRS can co-reside on the Signaling Server with other applications (co-resident mode). For large networks, if the Signaling Server does not have enough capacity to support the NRS functionality in conjunction with other applications, a dedicated Signaling Server can be required for the NRS (stand-alone mode). The NRS (Primary, Alternate, or Failsafe) cannot reside on an Alternate Signaling Server. It has to be on a Primary (Leader) Signaling Server.

The NRS has no knowledge of dialing plans implemented on endpoints. The NRS only has knowledge of numbering plans and deals only with fully-qualified E.164/International numbers, fully-qualified E.164/National numbers, and fully-qualified Private numbers.

The NRS can use prefix routing as long as the prefix is qualified. That is, you do not need 1-613-969-7944; 1-613-969 may be enough.

Endpoints do not have to register the telephone numbers or range of telephone numbers that they support with the NRS. If endpoints register with this information, it is not used but can be made available for management purposes to Element Manager.

Information regarding the numbers which an endpoint can terminate must be configured in the NRS. This ensures that the numbering plan for the entire network is managed from a central location and that endpoints cannot support numbers which are not preconfigured on the NRS. If an endpoint provides this number information when registering with the NRS, it is ignored.

H.323 endpoints which register using RAS messages must provide an H323-ID or a similar alias (for example, URL-ID or e-mail ID).

The NRS supports only direct-routed call signaling and RAS messaging for call control.

- All H.323 endpoints registered with the H.323 Gatekeeper must use the ARQ mechanism and must consult with the H.323 Gatekeeper for admission and address translation. The H.323 Gatekeeper does not pre-grant an ARQ for the call originator, but does pre-grant for the call terminator. This is because the H.323 Gatekeeper does not track call state, and has no easy way of correlating the ARQ between call originators and terminators.
- All SIP endpoints registered with the SIP Redirect Server must use the SIP INVITE message.

All H.225/Q.931 call-signaling messages and all H.245 call-control messages are not directed to the NRS and are passed directly between endpoints. This approach enables the NRS to be more scalable and to handle a larger number of simultaneous calls.

Each NRS supports up to 100 000 calls per hour.

The IP Peer Networking feature uses direct-routed call signaling; therefore, use of the NRS has no impact on MCDN or QSIG tunneling. For example, if MCDN or QSIG is tunneled between a CS 1000 node and an IP Trunk 3.0 (or later) node, then the tunneling takes place in the H.225/Q.931 call signaling. The tunneling is completely independent of the RAS which is routed to the NRS.

The NRS (H.323 Gatekeeper only) supports Overlap Sending according to H.323; however, allowable configuration items on the H.323 Gatekeeper must be taken into consideration. For more information about overlap signaling, refer to *IP Peer Networking Installation and Commissioning (NN43001-313)* ().

The NRS (stand-alone mode only) generates SNMP traps and sends them to a configured SNMP host. The NRS uses the SNMP services provided by the Signaling Server platform.

The NRS supports IP multicast for discovery and location-request messages.

Note: NRS/H.323 Gatekeeper Discovery using the Multicast approach is not recommended over large networks, because all routers between the endpoint requesting NRS discovery and the NRS must support Internet Group Management Protocol (IGMP).

The NRS supports multiple customers. Multiple customers can be configured with each customer having their own unique dialing or numbering plan.

The NRS does not track the state of active calls, keep count of the total number of active calls, or generate Call Detail Recording (CDR) records. Therefore, all Disengage Request (DRQ) messages are automatically confirmed. The NRS does not have traffic management capabilities, such as maximum calls allowed for each endpoint or maximum bandwidth allowed for each endpoint or zone.

Alternate routing based on the geographical zone of the call originator is not supported. This has implications for 911 handling. In order to provide different routing for 911 calls from different originating CS 1000 nodes, some form of digit manipulation is required. In the case of two nodes, for example, one node could prefix 911 with 1, and the other node could prefix 911 with 2. The NRS could have two different numbering plan entries, one for 1911 and one for 2911 and provide different routing in this fashion.

Zone management on the Call Server provides an alternate mechanism for routing 911 calls, based on the branch office or SRG zone. For more information, refer to *Branch Office Installation and Commissioning (NN43001-314)* ().

The NRS, like all CS 1000 components, does not support the H.235 security protocol.


All number and cost factor pairs within a numbering plan table are unique for private numbering plans. When adding an H.323 alias for a predefined H.323 endpoint, the request is rejected if the administrator specifies an alias type and provides a number string and cost factor that is already in the numbering plan table for that alias type.

For example, [Figure 13 "Example of all call routing plans"](#) (page 59) illustrates the configuration of a CS 1000 System.

- SCN_MPK1 terminates privateNumber.level1RegionalNumber 265 with cost factor 1.
- BCM_BVW_1 also terminates this number but with a different cost factor, 2.

If the administrator had attempted to configure this number on BCM_BVW_1 and had specified a cost factor of 1, the request would be rejected.

Figure 13
Example of all call routing plans



Number and cost factor pairs can be the same across different numbering plan tables. The numbering plan tables shown have only three columns for terminating route H323-ID and cost factor pairs. These are for illustrative purposes and in practice there can be as many alternate routes with different cost factors as required.

Similarly, configure the default routes according to alias type and CDP domain, as many alternate routes and associated cost factors can be required.

The NRS places the numbers in the numbering plan tables in ascending order. This accelerates the search when performing address translations.

When additional numbering plan entries are added using NRS Manager, they are inserted in the middle of the table. For example, if an entry with `publicNumber.internationalNumber` alias type and numbering plan digits 1514 is added, it is inserted in the table between the 1414 and 1613 entries.

If an alias is added whose left most digits match an existing alias of the same type, it is placed below the existing entry in the table. For example, in the `privateNumber.level1RegionalNumber` table, the 2651 entry is below the 265 entry. This is similar to the ordering of entries in IP network routing tables, with more specific entries appearing below more general entries.

Note: Tables generated in this example are represented in “[Example generated tables](#)” (page 61).

When the NRS is resolving the IP address, if the number to be resolved begins with 2651XXX, the IP address of `SCN_MPK_3` is returned (if it is registered). If the number to be resolved begins with 2652XXX, the IP address of `SCN_MPK_1` is returned (if it is registered).

Ranges of leading digits can be configured (for example, a `privateNumber.level1RegionalNumber` entry of 665-669). This means that any numbers of this type beginning with 665, 666, 667, 668, or 669 are resolved to the IP address of `SCN_MPK_1`.

Leading digit ranges can be overridden by configuring more precise numbering plan entries or numbers with a greater number of leading digits. For example, a `privateNumber.level1RegionalNumber` of 6651200# takes precedence over an entry of 665-669.

This means that the number 6651299 would resolve to the IP address of `SCN_MPK_1`, but 6651200 would resolve to the IP address of `BCM_BVW_1`. Note that due to the octothorpe character (#) length requirement, 66512001 would not match the 6651200# numbering plan table entry and would resolve to `SCN_MPK_1`.

Endpoints that do not support RAS procedures have their IP address entered directly into the numbering plan table entry H323-ID field or the default route H323-ID field.

All H323-IDs are included in alphabetical order in the endpoint status table. This includes default endpoints.

The IP address field in the endpoint status table is only updated if it is known (that is, if the endpoint with the associated H323-IDs has registered).

CDP numbering plan entries can be the same provided that the terminating endpoints belong to different CDP domains. For example, the CDP entries 40-43 for SCN_MPK_1 and 40-44 for BCM_BVW_1.

No special configuration items are present for ESN5 or Carrier Access Code support. If the Signaling Server is unable to provide a fully-qualified number in ARQ to the H.323 Gatekeeper and the number is prefixed with ESN5 prefix 100, then this prefix is placed before the existing entry in the numbering plan table.

National numbers are inserted into the publicNumber.internationalNumber table with the country code prefixed.

Example generated tables

The configuration shown in [Figure 13 "Example of all call routing plans" \(page 59\)](#) would result in [Table 5 "privateNumber.level1RegionalNumber numbering plan" \(page 61\)](#) through [Table 12 "Endpoint Status Table" \(page 63\)](#).

Table 5
privateNumber.level1RegionalNumber numbering plan

Digits	Terminating Routes			
	H323-ID	Cost Factor	H323-ID	Cost Factor
265	SCN_MPK_1	1	BCM_BVW_1	2
2651	SCN_MPK_3	1		
343	BCM_BVW_1	1	SCN_MPK_1	2
570	ITG_GAL_1	1	47.102.7.49	2
665-669	SCN_MPK_1	1		
6651200#	BCM_BVW_1	1		

Table 6
privateNumber.plSNSpecificNumber numbering plan

Digits	Terminating Routes	
	H323-ID	Cost Factor
265	SCN_MPK_2	1

Table 7
publicNumber.internationalNumber numbering plan

Digits	Terminating Routes					
	H323-ID	Cost Factor	H323-ID	Cost Factor	H323-ID	Cost Factor
1408	SCN_MPK_1	1	BCM_BVW_1	2		

Table 7
publicNumber.internationalNumber numbering plan (cont'd.)

Digits	Terminating Routes					
	H323-ID	Cost Factor	H323-ID	Cost Factor	H323-ID	Cost Factor
1414	SCN_MPK_1	1	SCN_MPK_2	2	ITG_GAL_1	3
1613	BCM_BVW_1	1	SCN_MPK_1	2		
352	47.102.7.49	1				
35391	ITG_GAL_1	1	47.102.7.49	2	SCN_MPK_1	3

Table 8
CDP domain table

CDP Domain Name	Default Routes	
	H323-ID	Cost Factor
CDP_DOMAIN_2	47.85.2.100	1
MPK_CDP_DOMAIN		

Table 9
CDP_DOMAIN_2 numbering plan

Digits	Terminating Routes			
	H323-ID	Cost Factor	H323-ID	Cost Factor
40-44	BCM_BVW_1	1		
45-48	ITG_GAL_1	1		
49	47.102.7.49	1	47.102.7.50	2

Table 10
MPK_CDP_DOMAIN numbering plan

Digits	Terminating Routes	
	H323-ID	Cost Factor
40-43	SCN_MPK_1	1
44-47	SCN_MPK_2	1
48-49	SCN_MPK_3	1

Table 11
Default route table

Alias Type	Default Routes			
	H323-ID	Cost Factor	H323-ID	Cost Factor
publicNumber.internationalNumber	INTN_GW_1	1	INTN_GW_2	2
privateNumber.level1RegionalNumber	PRIV_GW	1		

Table 12
Endpoint Status Table

H323-ID	IP
BCM_BVW_1	
SCN_MPK_1	47.82.33.47
SCN_MPK_2	47.82.33.50
SCN_MPK_3	
INTN_GW_1	
INTN_GW_2	47.50.10.20
ITG_GAL_1	47.85.2.201
PRIV_GW	

Standalone NRS support for Meridian 1 and BCM nodes

Nortel supports the use of an NRS for Meridian 1 Release 25.40 and Business Communications Manager (BCM) 3.6 nodes using H.323 endpoints that use IP Trunk 3.0 (or later).

The NRS in a stand-alone configuration can be used to migrate numbering plans from node-based numbering plans to centralized NRS-based numbering plans. This provides increased functionality as well as the flexibility to migrate a traditional Meridian 1 or BCM-based network to a CS 1000 network.

To illustrate how the NRS fits into a Meridian 1/BCM network using IP Trunks, it is useful to first look at how the Meridian1/BCM handles call admission control and numbering plan resolution.

Meridian 1/BCM node-based numbering plan

Figure 14 "Meridian 1/BCM node-based numbering plan" (page 64) illustrates how the Meridian1/BCM handles call admission control and numbering plan resolution.

Figure 14
Meridian 1/BCM node-based numbering plan




Figure 14 "Meridian 1/BCM node-based numbering plan" (page 64) shows a Meridian 1/BCM network with the Meridian 1/BCM nodes equipped with IP Trunks. The IP Trunk routes are point-to-multipoint. Regardless of where the terminating node is located, all calls can be sent out over the same route. The calls can be routed to the correct destination over the packet-based IP network by the IP Trunk.

Every IP Trunk node in the network has its own numbering plan database. All IP Trunk nodes are configured with the following:

- The static IP address of every other IP Trunk node on the network.
- The numbering plan to route calls to the correct destination node.


When the Meridian 1/BCM wishes to make an IP Trunk call, the following occurs:

1. The node consults its numbering plan.
2. The node determines where the destination is located.
3. The node retrieves the statically configured destination IP address.
4. The node routes the call directly to the destination node.

NRS-based numbering plan

In a Meridian 1/BCM network running IP Trunks and a stand-alone NRS, the network numbering plan is centrally administered by the NRS, as shown in Figure 15 "NRS-based numbering plan" (page 65).

Figure 15
NRS-based numbering plan



The NRS is configured with numbering plan information for every Meridian 1/BCM node in the network zone.

The typical Meridian 1/BCM network is configured to use H.323 Gatekeeper Resolved signaling. With H.323 Gatekeeper Resolved signaling, the H.323 Gatekeeper provides address resolution; however, call setup is performed directly between the nodes.

When a node wishes to place an IP call to another IP Trunk-enabled node, the originating node looks at its internal dialing plan table for address translation. If the originating node cannot find a match, it then sends ARQ (Admission Request) to the H.323 Gatekeeper specifying the destination phone number. When configured to use H.323 Gatekeeper, the node automatically sends the ARQ to the H.323 Gatekeeper. The H.323 Gatekeeper consults its internal numbering plan database and determines which Meridian 1/BCM node is the correct destination node. The H.323 Gatekeeper then sends an Admission Confirm (ACF) to the call originator and includes addressing information for the destination node. Standard call setup is then performed between the two nodes.

Numbering plan information is stored centrally on the NRS for the entire network zone which greatly reduces the administrative overhead.

Note: For customers using a stand-alone NRS, note that QoS Fallback to PSTN is not supported for IP Trunk destination nodes whose called telephone numbers are resolved by the NRS. Meridian 1 IP Trunk nodes that must use QoS Fallback to PSTN must continue to use the node-based dialing plan table entries to resolve each other's telephone numbers. NRS number resolution can be used concurrently for any IP Trunk destination nodes that do not use QoS Fallback to PSTN. In order to eliminate a single point of failure in their network, Nortel recommends the deployment of both a Primary and an Alternate NRS.

Numbering plans

Contents

This section contains information on the following topics:

- “Introduction” (page 67)
 - “Private (on-net) numbering plans” (page 68)
 - “Public (off-net) numbering plans” (page 71)
- “Address translation and call routing” (page 73)
 - “H.323” (page 73)
 - “SIP” (page 73)
 - “Basic call routing” (page 73)
 - “Numbering plan entry overview” (page 78)
- “Numbering plans and routing” (page 81)
 - “Using an NRS for routing” (page 81)
 - “Transferable DN call routing operation” (page 82)
 - “CDP call routing operation” (page 84)
 - “UDP call-routing operation” (page 85)
 - “Off-net call routing operation” (page 86)
 - “Routing to and from a branch office or SRG” (page 86)

Introduction

When configuring a CS 1000 network, several numbering plans can be used. The numbering plan depends on customer preferences for dialing and configuration management requirements.

Note: The numbering plan information required for the Call Server software to internally route calls, such as routing information for locally accessible numbers, must be configured within each Call Server.

“Numbering plan entry overview” (page 78) describes the implementation of the numbering plans. The sections below describe the following types according to their use:

- Uniform Dialing Plan
 - North American Numbering Plan
 - Flexible Numbering Plan
- Coordinated Dialing Plan
 - Transferable Directory Number
 - Group Dialing Plan
- Vacant Number Routing
- Special Numbering Plan

Private (on-net) numbering plans

Private (on-net) dialing refers to the dialing situations that occur when dialing telephones located within a local (private) network.

Uniform Dialing Plan

A Uniform Dialing Plan (UDP) enables users to dial all calls in a uniform manner, regardless of the location of the calling party or the route that the call takes. When using a Uniform Dialing Plan (UDP) to address private numbers, each location is assigned a Location Code (LOC). Each telephone has a Directory Number (DN) that is unique within the Call Server (and Customer). To reach a user, you must know the user’s Location Code and DN. To reach an on-net location, the user dials the following:

Network Access Code (AC1 or AC2) + LOC + DN

For example, if:

- Network Access Code (AC1 or AC2) = 6
- LOC = 343
- DN = 2222

The user dials: 6 343 2222

The NRS must keep the Home Location (HLOC) code of every Gateway that is registered for UDP routing. To route a call, the Gateway passes the LOC and DN to the NRS to determine the IP addressing information of the desired Gateway. The NRS searches for the LOC within its database and returns the IP addressing information for the site. Then, the Gateway software can directly set up a call to the desired Gateway.

For more information on UDP, refer to *Basic Network Features (NN43001-579)* ().

For call routing information, see [“UDP call-routing operation” \(page 85\)](#).

Coordinated Dialing Plan

With a Coordinated Dialing Plan (CDP), each location is allocated one or more Steering Codes that are unique within a CDP domain. Steering Codes are configured within a dialing plan and are part of the DN itself. They route calls on the network by a DN translator. The NRS has a list of Distant Steering Codes to route a call, while the Call Server has a list of Local Steering Codes, which act like an HLOC.

Steering Codes enable you to reach DNs on a number of Call Servers with a short dialing sequence. Each user's DN (including the Steering Code) must be unique within the CDP domain.

For example, a number of Call Servers can be coordinated so that five-digit dialing can be performed within a campus environment. For example:

- **Call Server A:** Steering codes 3 and 4 (that is, DNs in the range 3xxxx and 4xxxx)
- **Call Server B:** Steering code 5 (that is, DNs in the range 5xxxx)

Within this group of Call Servers, users can reach each other by dialing their unique DNs. However, all DNs on Call Server A must be in the range 3xxxx or 4xxxx, whereas all DNs on Call Server B must be in the range 5xxxx.

Note: If a user moves from one Call Server to another, the user's DN must change in the CDP numbering plan (see [“Transferable Directory Number” \(page 70\)](#)).

You can use CDP in conjunction with UDP. You use UDP by dialing AC1 or AC2 to reach UDP Location Codes, but use CDP by dialing CDP DNs within a CDP domain.

For a detailed description, refer to *Dialing Plans: Description (NN43001-283)* ().

For call routing, see [“CDP call routing operation” \(page 84\)](#).

Group Dialing Plan

Group Dialing Plan (GDP) enables coordinated dialing within a network using LOCs. Each group is assigned a LOC. From outside the group, you must dial the LOC as a prefix to the group CDP. In this case, the telephone's dialed number can be different when dialed from different locations.

For example, if:

- Network Access Code (AC1 or AC2) = 6
- LOC = 343
- DN = 3861

The user dials: 6 343 3861 from anywhere on the network, or the user dials only the DN (3861) from within the same CDP group.

Group Dialing Plans are part of Flexible Numbering Plans. For more detailed information, refer to *Dialing Plans: Description (NN43001-283)* ().

Transferable Directory Number

With Transferable Directory Numbers, each user is provided with a unique DN that does not change if the user moves to a different Call Server. The NRS must keep track of each Transferable Directory Number in the network so that it knows which Gateway(s) to return when asked to resolve a Transferable Directory Number address.

For call routing information, see [“Transferable DN call routing operation” \(page 82\)](#).

Vacant Number Routing

Vacant Number Routing (VNR) is supported in order to keep the Transferable Numbering Plan at a manageable level. As a result, small sites, such as the branch office, require minimal configuration to route calls through other Call Servers or through the NRS. Instead of changing the numbering trees and steering codes at each location, all the routing information can be kept at one central location.

If a vacant number is dialed, the call is routed to the NRS. The NRS decides where the terminal is located. If the terminal cannot be located, then vacant number treatment at the terminating location is given. The DN is not treated as invalid at the location where vacant number dialing is in effect.

Vacant Number Routing must be configured on the Media Gateway 1000B (MG 1000B) Core Small System Controller (SSC). Refer to *Branch Office Installation and Commissioning (NN43001-314)* () for more information.

VNR enables data manipulation index (DMI) numbers for all trunk types so that an alternate route can be used for the VNR route. The VNR enhancement increases the flexible length of UDP digits from 10 to 19 and as a result, international calls can be made.

Based on the analysis of the dialed digits sets, TON/NPI for Virtual Trunk calls removes the NARS access code and the national or international prefix (dialed after NARS access code) so the NRS can route the call correctly.

This process minimizes the configuration on the branch office. Only CDB NET data must be defined on the originating node (the branch office). There is no need to define NET data (in LD 90) and all UDP calls (International, National, NXX LOC) are working using VNR route.

Note: LOC and NXX must use different NARS access codes. That is, if LOC is using AC2 then NXX must be defined for AC1. When defining CDB, you must only define dialing plans which use AC2. All others default to use AC1.

Public (off-net) numbering plans

Public (off-net) dialing refers to dialing situations that occur when dialing a telephone that is not part of the local (private) network.

Uniform Dialing Plan

An off-net call using UDP is a call that does not terminate within the local (private) network; although, some on-net facilities can be used to complete a portion of the call routing. UDP uses network translators AC1 and AC2 to route calls. UDP uses Special Numbers (SPNs) to enable users to dial numbers of varying lengths.

For example, a UDP call is considered off-net if a user at LOC 343 dials the following:

AC1 or AC2 +1 + NPA + NXX + XXXX

For example, if:

- Network Access Code (AC1 or AC2) = 6
- NPA = 416
- NXX = 475
- XXXX = 7517

The user dials: 6 + 1 (416) 475-7517.

For call routing information, see [“UDP call-routing operation” \(page 85\)](#).

North American Numbering Plan

The Call Server supports North American Numbering Plan routing. The North American Numbering Plan is used to make North American public network calls through the private network. The North American Numbering Plan accommodates dialing plans based on a fixed number of digits. A user can dial AC1 or AC2 + NXX + XXXX for local calls or AC1 or AC2 + 1 + NPA + NXX + XXXX for toll calls.

For example, if:

- Network Access Code (AC1 or AC2) = 9
- NPA = 506
- NXX = 755
- XXXX = 8518

The user dials: 9 + 1 (506) 755-8518

Flexible Numbering Plan

Flexible Numbering Plan (FNP) accommodates dialing plans that are not based on a fixed number of digits (for example, International numbers). FNP uses SPNs to enable users to dial numbers of varying lengths. Also, the total number of digits dialed to reach a station can vary from station to station. FNP also enables flexibility for the length of location codes from node to node. An FNP can be used to support country-specific dialing plans. For example, to reach an international number from North America, a user can dial: AC1 or AC2 + 011 + Country Code + City Code + XXXXXX.

For example, if:

- Network Access Code (AC1 or AC2) = 9
- Country Code = 33
- City Code = 1
- XXXXXX = 331765

The user dials: 9 + 011 + 33 + 1 + 331765

For information on FNP operation and package dependencies, refer to *Dialing Plans: Description (NN43001-283)* ().

Special Numbering Plan

SPNs exist for each country's dialing plan. In North America, the recognizable SPNs are 411, 611, 0, and 011 for international calling. The circuit switch or NRS recognizes the digits that are not part of, or do not comply with, the regular dialing plan, such that further dialing-string analysis is rarely possible (this is referred to as a catch-all configuration).

Europe uses SPN dialing plans almost exclusively, because European numbering plans are not as rigid as North American plans.

Address translation and call routing

H.323

When an H.323-compliant entity on the network wants to place a call, it sends an admission request (ARQ) to the H.323 Gatekeeper. The endpoint includes the destination telephony number in this message. The destination information is an H.323 alias. The H.323 Gatekeeper extracts the destination alias and ensures that it is one of the supported types. The H.323 Gatekeeper then searches its numbering plan database to determine which endpoints on the network can terminate the telephone number and whether or not these endpoints are registered. The H.323 Gatekeeper returns the IP address of any endpoints which can terminate this number and are registered to the endpoint.

Note: Endpoints that do not support RAS messaging do not register with the H.323 Gatekeeper.

SIP

When a SIP-compliant entity on the network wants to place a call, it sends an INVITE message to the SIP Redirect Server by way of the SIP Trunk Gateway. The endpoint includes the destination telephony number in this message. The destination information is a SIP URI (see "[SIP Uniform Resource Identifiers](#)" (page 34)). The SIP Redirect Server searches its numbering plan database to determine which endpoints on the network can terminate the telephone number and whether or not these endpoints are registered. Address lookup is based on the digits, phone context, and domain name.

The SIP Redirect Server returns the IP address of any endpoints that can terminate this number and that are registered to the endpoint.

Basic call routing

The routing of calls within the CS 1000 networks depends on the type of numbering plan in use and the number dialed. "[Transferable DN call routing operation](#)" (page 82) provides a description of how a call is routed from the call originator to the desired desktop or PSTN using the Transferable DN type of numbering plan. This is the most flexible numbering plan. It illustrates the configuration and operation of the routing

software. The operation for “Private (on-net) numbering plans” (page 68) and “Public (off-net) numbering plans” (page 71) are described in “Numbering plans and routing” (page 81).

The NRS plays a key role in configuring numbering plans in a network. It provides IP address resolution based on dialed numbers.

Supported alias types (for H.323)

The H.323 Gatekeeper performs address translations on H.323 partyNumber alias types and on E.164 alias types. The partyNumber alias can be one of several subtypes according to the H.323 standard. The only partyNumber subtypes that the H.323 Gatekeeper supports are partyNumber.publicNumber and partyNumber.privateNumber. These also have subtypes. See Table 13 “H.323 term explanations” (page 74).

Table 13
H.323 term explanations

H.323 signaling protocol	CS 1000 term
publicNumber.internationalNumber (Note 1)	E.164 International (UDP)
publicNumber.nationalNumber (Note 1)	E.164 National (UDP)
publicNumber.subscriber	See Note 2.
publicNumber.unknown	See Note 3.
privateNumber.level1RegionalNumber (Note 1)	Uniform Dialing Plan Location Code (UDP LOC)
privateNumber.pISNSpecificNumber (Note 1)	Special Numbers (SPN)
privateNumber.localNumber (Note 1)	Coordinated Dialing Plan (CDP)
privateNumber.unknown	Unknown (UKWN) (Note 4)
e164	See Note 5.
Note: 1. Only these alias types can be entered as numbering plan table entries using the web browser interface. The other alias types have no Type Of Number (TON) information.	
Note: 2. Not supported by the H.323 Gatekeeper. The Call Server algorithmically converts any public subscriber number to a supported type (for example, converts a publicNumber.internationalNumber by adding the country code and area code).	
Note: 3. Not supported by the Call Server, but is supported by the H.323 Gatekeeper for third-party interoperability. This is treated as a publicNumber.internationalNumber.	

Table 13
H.323 term explanations (cont'd.)

H.323 signaling protocol	CS 1000 term
<p>Note: 4. Not supported by the Call Server, but is supported by the NRS for third-party interoperability. The Call Server can generate privateNumber.unknown types with the limitation that INAC does not work. The NRS attempts to convert the number to privateNumber.localNumber (that is, CDP) or privateNumber.level1RegionalNumber (that is, UDP LOC) by analyzing the digits. If the NRS cannot determine which type to use based on digit analysis, it assumes that privateNumber.localNumber (that is, CDP) should be used.</p>	
<p>Note: 5. Not supported by the Call Server, but is supported by the NRS for third-party interoperability. A default prefix can be configured on a per-NRS basis to distinguish between public and private numbers. For example, a prefix of "9" can be configured as the public number prefix. A prefix of "6" can be configured as the private default prefix. The NRS looks at the first digit. If it matches the public prefix (for example, "9"), it treats the subsequent digits as a publicNumber.internationalNumber. If the first digit matches the private prefix (for example, "6"), it treats the subsequent digits as a privateNumber.localNumber (that is, CDP) or privateNumber.level1RegionalNumber (that is, UDP LOC), depending on its digit examination.</p>	

If the H.323 Gatekeeper receives an admission-request message requesting translation for any other alias type (for example, publicNumber.subscriberNumber), it rejects the request.

The H.323 Proxy Server, which sends the admission request to the H.323 Gatekeeper, is responsible for mapping Numbering Plan Indicator (NPI)/Type of Number (TON) values in the ISDN SETUP Called Party Number Information Element to one of the eight H.323 alias types listed in [Table 13 "H.323 term explanations" \(page 74\)](#).

Mapping between CS 1000 NPI/TON and H.323 alias types The CS 1000 system supports the NPI and TON values shown in [Table 14 "NPI values" \(page 75\)](#) and [Table 15 "TON values" \(page 76\)](#). These values are for Universal ISDN Protocol Engine (UIPE)-formatted NPI/TON numbers.

Table 14
NPI values

NPI on Call Server	UIPE-formatted description
0	UNKNOWN
1	E164
2	PRIVATE
3	E163

Table 15
TON values

TON	UIPE-formatted description
0	UNKNOWN
1	INTERNATIONAL
2	NATIONAL
3	SPECIAL
4	SUBSCRIBER
5	UNIFIED (UDP location code).
6	COORDINATED (CDP distant/trunk steering code)
<p>Note: The H.323 Gatekeeper sees a trunk steering code as privateNumber.unknown. The H.323 Gatekeeper then converts the code to privateNumber.localNumber in CDP.</p>	

Table 16 "NPI/TON to H.323 alias mapping" (page 76) shows the NPI/TON pairs, the corresponding call types, and their corresponding H.323 alias types for which the H.323 Gatekeeper accepts translation requests. The call type for outgoing routes is manipulated by configuring a DMI in LD 86 and specifying the Call Type (CTYP).

If the H.323 Proxy Server receives a Q.931 SETUP message for an NPI/TON pair not included in Table 16 "NPI/TON to H.323 alias mapping" (page 76), it must map the number according to one of the NPI/TON pairs/H.323 alias types which the H.323 Gatekeeper supports. This process can require modifications to the called number dialing string.

CTYP is the mnemonic in the ESN overlays.

Table 16
NPI/TON to H.323 alias mapping

NPI UIPE	TON UIPE	CTYP	H.323 alias
E164 or E163	INTERNATIONAL	INTL	publicNumber.internationalNumber
	NATIONAL	NPA	publicNumber.nationalNumber
	UNKNOWN		publicNumber.unknown

Table 16
NPI/TON to H.323 alias mapping (cont'd.)

NPI UIPE	TON UIPE	CTYP	H.323 alias
PRIVATE	SPECIAL	SPN	privateNumber.plSNSpecificNumber
	UNIFIED (see Table 15 "TON values" (page 76))	LOC	privateNumber.level1RegionalNumber
	COORDINATED (see Table 15 "TON values" (page 76))	CDP	privateNumber.localNumber
	UNKNOWN	UKWN	privateNumber.unknown

The endpoints must correctly map the UIPE NPI/TON pairs to a valid partyNumber type that the H.323 Gatekeeper supports. The administrator must coordinate the numbering plan on the H.323 Gatekeeper with the mapping carried out by the endpoints.

LD 96 shows NPI/TON and ESN call types for D-channel monitoring. Calling and Called number information for level 0 D-channel tracing includes the TON and ESN call types.

[Table 17 "Q.931 TON mapping" \(page 77\)](#) shows Q.931 TON mapping.

Table 17
Q.931 TON mapping

NPI	TON
x000xxxx	Unknown
x001xxxx	International Number
x010xxxx	National Number
x011xxxx	Network Specific Number
x100xxxx	Subscriber Number
x110xxxx	Abbreviated Number
x101xxxx	Reserved for Extension
x111xxxx	

[Table 18 "NPI/TON to ESN Call type mapping" \(page 77\)](#) shows the NPI/TON to ESN Call type mapping.

Table 18
NPI/TON to ESN Call type mapping

NPI	TON	ESN
0001 - E.164	010 - National	NPA

Table 18
NPI/TON to ESN Call type mapping (cont'd.)

NPI	TON	ESN
0001 - E.164	100 - Subscriber	NXX
1001 - PRIVATE	011 - Network Specific	SPN
1001 - PRIVATE	101 - Reserved	LOC
1001 - PRIVATE	110 - Abbreviated	CDP

Numbering plan entry overview

A numbering plan entry can be private or public. Private numbers can be configured using CDP, or UDP Location Code (LOC) entries. Public numbers can be configured using E.164 International or E.164 National entries.

When configuring a predefined endpoint on the NRS, the administrator must add the required numbering plan entries. The administrator adds the numbers or number ranges that the endpoint can terminate. For every numbering plan entry, the administrator must specify the DN type, the default route, the DN prefix, and the cost factor associated with the route. See ["Adding a Routing Entry" \(page 348\)](#).

Using the cost factor to determine the entry or the path and endpoint, the NRS can match multiple entries to a dialed number. This enables alternate routing based on the cost of facilities. The NRS matches the number string with the most matching digits. For example, the following are defined as entries:

- 1613
- 161396
- 1613967

If a user dials "1613966", the NRS matches entries with "161396". See [Table 19 "Cost factors" \(page 78\)](#) for the cost factors associated with these entries.

Table 19
Cost factors

Entry	Cost factor
1613	1
161396	1
161396	2
1613967	1

In this case, the NRS first returns the entries with the lowest cost entry.

The administrator must also specify if the endpoint belongs to a CDP domain. If the endpoint does belong to a CDP domain, the administrator must specify the CDP domain name. However, before specifying an endpoint's CDP domain membership, the administrator must configure the CDP domain. The administrator does this by adding a new CDP domain and specifying its name. The alias type `privateNumber.localNumber` corresponds to a CDP number. When configuring a numbering plan entry for this alias type, the administrator must have previously specified the CDP domain to which the endpoint belongs.

Default routes can also be configured for each of the supported numbering plan types. These entries are configured by entering the DN type and their associated cost factors.

Note: For alias type `privateNumber.localNumber` (for example, CDP numbers), multiple default routes for each CDP domain can be configured. Each CDP domain must have its own default routes.

The NRS has one standard numbering plan table for each of the `publicNumber.internationalNumber` (CTYP = INTERNATIONAL), `privateNumber.pISNSpecificNumber` (CTYP = COORDINATED), and `privateNumber.level1RegionalNumber` (CTYP = UNIFIED) supported alias types.

Note: Although `publicNumber.nationalNumber` aliases can be configured, there is no numbering plan table associated with this alias type, as these aliases are inserted in the `publicNumber.internationalNumber` table.

The NRS also has one numbering plan table for each CDP domain configured. Therefore, there are multiple numbering plan tables configured for the `privateNumber.localNumber` alias type. Each table contains lists of numbering plan entries with each entry containing the following information:

- leading digit string
- cost factor associated with the route to this endpoint

The NRS has a table for each of the standard alias types (`internationalNumber.pISNSpecificNumber` and `level1RegionalNumber`) which provides the default routes associated with each type. The tables contain the H323-ID of the default routes or the IP address if the default route does not support RAS procedures and the cost factor associated with the route. There is also a table of default routes for each CDP domain.

Number Type support

The NRS enables address-translation requests for publicNumber.nationalNumber and publicNumber.internationalNumber types. The NRS can be used for address translation across several countries; therefore, the NRS must be able to identify from which country the request came. The NRS must also be able to handle country codes correctly.

A system-wide configuration variable specifies the default country code. For example, this variable could be configured as "1" if the majority of the NRS traffic is within North America. There is also the option to configure a country code for every endpoint that overrides the default system-wide country code. For example, if one CS 1000 node is in Galway, Ireland and all other nodes are in North America, the default system-wide country code could be configured as "1" and the country code for the node in Galway could be configured as "353".

When configuring numbering plan table entries, the administrator can configure national number entries. When configuring a national number entry, either the system-wide country code or the endpoint-specific country code must be configured first. The NRS automatically prefixes the national numbering plan entry with the country code and then inserts this entry in the international numbering plan table. No table exists for national numbers. All national numbers are converted to international. When the NRS receives an admission request for a national number, the NRS determines the originator of the request, extracts the destination telephony number, prefixes the number with the relevant country code (either the country code for the endpoint or the system-wide country code), and resolves the number by searching in the international number table.

Note that the numbering plan entries in the NRS conform strictly to the E.164 International standard. Calls on Virtual Trunks that access the NRS must be tagged correctly.

For example, an endpoint can make an international call to 1-416-xxxxxxx. If this digit sequence is sent to the NRS, it must have a Call Type of "International", because the country Code ("1") is included. The same endpoint can make a call to 416-xxxxxxx, but in this case the Call Type must be "National", because the country code is not included. Both of these scenarios work correctly, as the NRS is set up to process both 416/National and 1416/International.

However, it is not valid to send digits 1-416-xxxxxx with a Call Type of "National"; the NRS cannot recognize this, and the call is not routed.

Numbering plans and routing

When users attempt to make calls on a CS 1000 system, they use dialed digits to indicate which telephone or service they would like to reach. Within the Call Server, these digits are translated to determine whether the user is attempting to reach an internal telephone or service, or trying to reach another user or service outside of the CS 1000 system. This is the first level of routing.

If the user is trying to reach a device that is internal to the CS 1000 system, the Call Server terminates the call as appropriate on the internal device. If the user is trying to reach a device outside the CS 1000 system, several options can be configured within the system.

The system administrator can choose to use one of the PBX Networking numbering plans, such as CDP, to help route the call to the appropriate trunk route, or the administrator can choose to use Vacant Number Routing (VNR), where any number that is not known to the Call Server is routed out a specified trunk route. An NRS can therefore determine the final destination of the call from a central database.

Refer to *Dialing Plans: Description (NN43001-283)* () for information on VNR operation.

Using an NRS for routing

Once the system determines that a user is attempting to reach a telephone or service using the IP network, the call is routed to the Gateway software, which uses the NRS to help with the routing of the call.

The basic role of an H.323 Gatekeeper is to perform address translation from an alias (in this case, a telephone number) to an IP signaling address, and to authorize the call in the H.323 network.

The basic role of a SIP Redirect Server is to perform address translation from a SIP URI to an IP signaling address and to authorize the call in the SIP network.

The NRS is the central location where the numbering plan information is configured. The identity of each endpoint (for example, a CS 1000 system) is configured in the NRS with the numbers it can reach. For example, an entry could look like the following:

"Santa Clara-01"

PublicNumber = +1 408 XXX XXXX

PrivateNumber = Electronic Switched Network (ESN) 265 XXXX, ESN
655 XXXX

At power-up, an H.323 endpoint performs Gatekeeper Discovery using a configured H.323 Gatekeeper address. The endpoint then registers with its primary H.323 Gatekeeper at the address returned by the Gatekeeper Discovery process using the H.225.0 (RAS) protocol by sending its H323-ID and its IP address. In the example above, it would use the following:

"Santa_Clara-01"

Signaling IP address = 47.0.1.2

Upon receipt of the registration, the H.323 Gatekeeper matches the name "Santa_Clara-01" in the registration with the configured information in its database, and adds the IP address.

When a user behind an H.323 proxy wants to reach another user, its H.323 proxy sends a call request to its H.323 Gatekeeper. The H.323 Gatekeeper determines any endpoint(s) that are responsible for that particular user and returns its signaling IP address(es) in the direct-routed model, which is the preferred model.

Using the same example, the user dials "62653756". The Call Server at the originating end determines that this call is destined to ESN 265 3756, based on the dialing prefix, and routes the call to the H.323 Gateway. The H.323 Gateway sends an admission request to the H.323 Gatekeeper for PrivateNumber ESN 265 3756. The H.323 Gatekeeper then consults its database and performs the closest match (that is, "ESN 265 XXXX" in the "Santa_Clara-01" entry) and returns the IP address that was previously provided by "Santa_Clara-01" at registration time (that is, 47.0.1.2).

Transferable DN call routing operation

With the Transferable Directory Number type of CDP numbering plan, networks provide the ability to enable users to move from location to location while retaining their Directory Number. This capability is provided by a combination of Network Management and the call routing capabilities of the Call Server software. The NRS must be updated to reflect the current location of the DNs.

Note: Transferable Directory Numbers are usually used in conjunction with Vacant Number Routing (VNR).

Figure 16 "Transferable DN routing" (page 84) shows a network of CS 1000 Systems in which each user wants to retain their unique seven-digit Directory Number. Table 20 "DNs with their associated Call Servers" (page 84) provides a summary of the DNs in Figure 16 "Transferable DN routing" (page 84), as well as their associated Call Server.

Each user in the network is associated with a Call Server and its group of SIP Trunk and/or H.323 Gateways. The Gateways provide call-processing features and redundancy. The NRS in [Figure 16 "Transferable DN routing" \(page 84\)](#) is aware of the location of any user with a given Directory Number within the network. In this case, the user with Directory Number 22221 is located at Call Server A. When a user dials the last digit of this number, their Call Server determines whether the user is within its local database, and if so, handles the call directly.

For example, if the user with Directory Number 22222 dials 22221, Call Server A handles the call directly.

However, if the Directory Number is not within the local database of the initial Call Server, the call is routed through the Gateway software on the Signaling Server in order to locate the user. This routing uses a feature called Network Number Resolution. Because the NRS knows where to locate any user with a Transferable Directory Number, it directs the call to the proper Call Server.

For example, if the user with DN 22224 dials DN 22221, Call Server B routes the call to the Gateway software, which requests the location of the desired Call Server from the NRS. The NRS responds with the address information of Call Server A, at which time Call Server B attempts a call setup to Call Server A and completes the call.

Figure 16
Transferable DN routing




Table 20
DNs with their associated Call Servers

DN	Call Server
22221	A
22222	A
22223	A
22224	B
22225	B

CDP call routing operation

The routing of calls in a CDP-type of numbering plan is the same as that for Transferable Directory Number, with the following exceptions:

- Only the Steering Codes must be stored in the NRS, because entire ranges of DNs are located within the same Call Server.
- With CDP, Call Servers and MG 1000B platform systems can be grouped into CDP domains, all sharing a CDP. This enables more convenient number dialing within a complex, such as a campus with several Call Servers. When configuring CDP numbers at the NRS, administrators must also specify to which CDP domain they belong.

Figure 17 "CDP call routing" (page 85) shows an example of CDP routing. Table 21 "DNs with their associated Call Servers and CDP domains" (page 85) shows the DN with their associated Call Servers and CDP domains.

Figure 17
CDP call routing




Table 21
DNs with their associated Call Servers and CDP domains

DN	Call Server	CDP domain
22221	A	"CDP_BVW"
22222	A	"CDP_BVW"
22223	A	"CDP_BVW"
22301	MG 1000B	"CDP_BVW"
32224	B	"CDP_ASIA"
32225	B	"CDP_ASIA"

UDP call-routing operation

The routing of calls in a UDP private numbering plan is basically the same as that for Transferable Directory Number, except that only the Location Codes must be stored in the NRS because the user uniquely identifies the specific location by dialing this code.

CDP and Transferable Directory Number numbering plans can coexist within the same network. The dialing of a network access code (AC1 or AC2) enables the Call Server to differentiate between calls that must be resolved using the UDP Type of Number (TON) and those that must be resolved using the CDP TON.

Note: Transferable Directory Numbers are considered CDP numbers.

Off-net call routing operation

When dialing calls to PSTN interfaces, the Call Server determines that the call is destined off-net, based on digit analysis that must be configured at major Call Servers in the network. This determination enables the Gateway software to request the location of public E.164 numbers from the NRS. The NRS is configured with a list of potential "alternate routes" that can be used to reach a certain number, each of which is configured with a Cost Factor to help determine the least-cost route for the call.

When an NRS replies to the Gateway with the address information for E.164 numbers, it provides a list of alternate gateways, sorted in order of cost. If a Gateway is busy when a call attempt is made, the originating Gateway tries the next alternative in the list. If none of the alternatives are available over the IP network, the originating Call Server can be configured to step to the next member of its route list, which could be a PSTN or TIE alternate route.

For example, in the event of an IP network outage that does not enable voice calls to terminate over the IP network, calls are rerouted to any alternate PSTN or TIE routes.

Routing to and from a branch office or SRG

Because IP Phone users can be located at a branch office equipped with an MG 1000B Core or SRG, the routing of calls to the local gateway is important (especially when toll charges are applicable to calls made from the central Call Server that is controlling the telephone). The administrator can configure digit manipulation for IP Phones that are located near an MG 1000B Core or SRG, selecting a gateway that provides PSTN access local to the telephone.

Note: The Branch Office feature (which includes the SRG) supports the various PSTN interfaces. Refer to *Electronic Switched Network: Signaling and Transmission Guidelines (NN43001-280)* () for further information.

Calls from the PSTN to users within the network can be routed either using the various ESN numbering plan configurations or using the Vacant Number Routing (VNR) feature. This process enables small sites, such as those using the MG 1000B Core, to require minimal configuration to route calls through other Call Servers or through the NRS.

Outgoing calls to access local PSTN resources can be routed using ESN, as well as zone parameters that enable digit insertion. The zone parameters enable calls made by a branch office or SRG user to be routed to the desired local PSTN facilities. Refer to *Branch Office Installation and Commissioning (NN43001-314)* () for further information.

SIP Phone support

Contents

This section contains information on the following topics:

- “Introduction” (page 89)
 - “SIP Phone interaction” (page 90)
 - “SIP Phone features” (page 91)
- “SIP Phone calls” (page 92)
 - “SIP Phone-to-SIP Phone communication” (page 93)
 - “SIP Trunk Gateway-to-SIP Phone communication” (page 96)
- “SIP Phone dynamic registration” (page 101)
 - “Assumptions” (page 102)
 - “Log files” (page 102)
- “Installing a SIP Phone” (page 102)
- “Configuring a SIP Phone” (page 102)
 - “Routing of unqualified numbers” (page 102)
 - “Task summary” (page 103)
- “Adding a User Endpoint (SIP Phone)” (page 341)

Introduction

Certified compatible third-party industry-standard SIP Phones are supported.

SIP Phones are configured on, and register to the NRS (specifically, the SIP Redirect Server), where they are configured as SIP user endpoints. As such, they communicate directly with the SIP Redirect Server, SIP Trunk Gateways, and other SIP Phones on the system. In contrast, IP Phones are configured on, and are controlled by, the Call Server.

IP Phones use the Unified Networks IP Stimulus Protocol (UNISim) and are stimulus-based telephones. The features on an IP Phone are delivered by the Communication Server. SIP Phones use the Session

Initiation Protocol which is an open industry standard-based signaling protocol. Some of the telephony features of the SIP Phones are delivered by the Communication Server. However, SIP Phones can have additional features that are available on the telephone itself. These features vary based on manufacturer and the model of the telephone.

A SIP Phone is a standards-based SIP device.

Note: CS 1000 does not support Call Forward across NRS Collaborative Servers by third-party SIP Phones.

SIP Phone interaction

Table 22 "SIP Phone and CS 1000 component interaction" (page 90) shows the interaction between SIP Phones and components in the CS 1000 network.

Table 22
SIP Phone and CS 1000 component interaction

Component	Description
SIP Phone	SIP Phones are intelligent telephones which deliver many common business telephony features (for example, CLID, Conference, Transfer, MWI, and Name Display). See "SIP Phone features" (page 91) for more details. SIP Phones can also have other manufacturer-dependant features.
SIP Redirect Server	The NRS, specifically the SIP Redirect Server, provides the following: <ul style="list-style-type: none"> • a web-based interface (NRS Manager) for provisioning SIP Phones • registration and authentication for SIP Phones • routing definitions for all SIP traffic (including SIP Phones)
SIP Trunk Gateway	The SIP Trunk Gateway provides the following: <ul style="list-style-type: none"> • a signaling gateway for all SIP calls originating from and terminating to the CS 1000 system • standard SIP support for CLID, MWI, Name Display, and Call Redirection

Table 22
SIP Phone and CS 1000 component interaction (cont'd.)

Component	Description
CS 1000 Call Server	<p>The Call Server provides call processing software which enables the following:</p> <ul style="list-style-type: none"> • CDR using the tandem CDR feature • Trunk Access Restrictions using Class of Service (CLS) and Trunk Group Access Restrictions (TGAR) • SIP Access Port Licenses
TDM telephones and IP Phones, IP Trunk, and CallPilot	SIP Phones can interwork with the full suite of CS 1000 TDM and IP endpoints. CallPilot provides Unified Messaging for SIP Phones, including MWI.

SIP Phone features

The following is a list of features delivered through the CS 1000 system:

- Calling Line Identification (CLID)
- Network Call Party Name display
- Network Call Redirection
- Message Waiting Indication
- Network Class of Service Access controls
- Network Alternate Route Selection (NARS, UDP, CDP)
- Call Detail Recording (CDR) using Tandem CDR features

The following is a list of intelligent SIP Phone-based features supported by the CS 1000 system. The features are dependant on the SIP Phone.

- Conference calling
- Call hold
- Call waiting
- Call forwarding
- Call transfer
- Caller ID
- Call waiting caller ID

The following features are available through the user interface in a web server-based configuration:

- Speed dial from phone book
- Call logs


SIP-compliant telephones can interoperate with voice, data, video, and Internet applications and services that are SIP-enabled or provide full SIP support.

SIP Phones are configured on the Signaling Server using NRS Manager. See [“Configuring a SIP Phone”](#) (page 102).

SIP Phone calls

Figure 18 [“SIP Phones and SIP Trunk Gateways in the network”](#) (page 92) shows SIP Phone-to-SIP Phone connectivity and SIP Phone-to-SIP Trunk Gateway connectivity.

Figure 18
SIP Phones and SIP Trunk Gateways in the network



When two SIP Phones (SIP Phones A and B) want to communicate with each other, the originating SIP Phone must communicate directly with the SIP Redirect Server for authentication and address resolution. Then communication is established between the two SIP Phones. Refer to [“SIP Phone-to-SIP Phone communication”](#) (page 93) for the call flow between two SIP Phones in the same network.

When a SIP Phone (A) wants to communicate with another non-SIP telephone (for example, IP Phone C), then the SIP Trunk Gateway is involved. Refer to [“SIP Trunk Gateway-to-SIP Phone communication” \(page 96\)](#) for the call flow between a SIP Phone and another telephone using the SIP Trunk Gateway.

Note: The following call flows are not exhaustive descriptions of the protocol, and exclude some of the components in the CS 1000 system. They are examples for illustrative purposes only.


SIP Phone-to-SIP Phone communication

When SIP Phone User A wants to call SIP Phone User B, the following occurs:

1. SIP Phone A sends an INVITE message to the NRS (specifically the SIP Redirect Server). See [Figure 19 "SIP Phone A sends INVITE message to SIP Redirect Server" \(page 93\)](#).


Figure 19

SIP Phone A sends INVITE message to SIP Redirect Server




2. The SIP Redirect Server responds with a REDIRECT message and informs SIP Phone User A to directly contact SIP Phone User B. See [Figure 20 "SIP Redirect Server responds to SIP Phone A" \(page 94\)](#).

Figure 20
SIP Redirect Server responds to SIP Phone A



3. SIP Phone A sends an INVITE message directly to SIP Phone B. SIP Phone B rings. See [Figure 21 "SIP Phone A sends INVITE message to SIP Phone B"](#) (page 94).


Figure 21
SIP Phone A sends INVITE message to SIP Phone B



553-AAA2330


4. SIP Phone User B sends a SIP 200 OK message to SIP Phone User A. SIP Phone A replies by sending a 200 ACK message to SIP Phone B. See [Figure 22 "SIP Phone B sends 200 OK message to SIP Phone A"](#) (page 95).

Figure 22
SIP Phone B sends 200 OK message to SIP Phone A



5. The call is set up between the two SIP Phones, and two-way RTP messages are exchanged between SIP Phone A and SIP Phone B. See [Figure 23 "SIP Phones start the direct IP media paths"](#) (page 96).

Figure 23
SIP Phones start the direct IP media paths




SIP Trunk Gateway-to-SIP Phone communication

When IP Phone User A wants to call SIP Phone User B, the following occurs:


1. IP Phone A makes a call that is routed through Call Server A. See [Figure 24 "IP Phone A sends message to SIP Trunk Gateway A" \(page 97\)](#).

Figure 24
IP Phone A sends message to SIP Trunk Gateway A




2. SIP Trunk Gateway A sends an INVITE message to the NRS (SIP Redirect Server). See [Figure 25 "SIP Trunk Gateway A sends INVITE message to SIP Redirect Server"](#) (page 97).

Figure 25
SIP Trunk Gateway A sends INVITE message to SIP Redirect Server




3. The SIP Redirect Server replies back to SIP Trunk Gateway A with a REDIRECT message. The SIP Redirect Server informs SIP Trunk Gateway A of the location of SIP Phone B. See [Figure 26 "SIP Redirect Server replies to SIP Trunk Gateway A"](#) (page 98).

Figure 26
SIP Redirect Server replies to SIP Trunk Gateway A



4. SIP Trunk Gateway A acknowledges the message from the SIP Redirect Server with an ACK message. SIP Trunk Gateway A then sends an INVITE message directly to SIP Phone B. See [Figure 27 "SIP Trunk Gateway A sends INVITE message to SIP Phone B"](#) (page 98).


Figure 27
SIP Trunk Gateway A sends INVITE message to SIP Phone B



5. SIP Phone B sends a TRYING message and a Ringing message to the SIP Trunk Gateway A. SIP Trunk Gateway A then sends an Alerting


message to IP Phone A. See [Figure 28 "SIP Phone B communicates with SIP Trunk Gateway A and SIP Trunk Gateway A communicates with IP Phone A"](#) (page 99).

Figure 28
SIP Phone B communicates with SIP Trunk Gateway A and SIP Trunk Gateway A communicates with IP Phone A




- SIP Phone B sends a SIP 200 OK message to the SIP Trunk Gateway A. SIP Trunk Gateway A sends a Connect message to IP Phone A. See [Figure 29 "SIP Trunk Gateway A communicates with SIP Phone B and IP Phone A"](#) (page 99).

Figure 29
SIP Trunk Gateway A communicates with SIP Phone B and IP Phone A




7. IP Phone User A responds to SIP Trunk Gateway A with a Connect ACK message. SIP Trunk Gateway A sends a SIP 200 ACK message to SIP Phone B. See [Figure 30 "IP Phone A acknowledges SIP Trunk Gateway A and SIP Trunk Gateway A sends SIP 200 ACK message to SIP Phone B"](#) (page 100).

Figure 30
IP Phone A acknowledges SIP Trunk Gateway A and SIP Trunk Gateway A sends SIP 200 ACK message to SIP Phone B



8. The call is set up between IP Phone A and SIP Phone B. Two-way RTP messages are exchanged between IP Phone A and SIP Phone B. See [Figure 31 "Direct media path is set up between IP Phone A and SIP Phone B"](#) (page 101).

Figure 31
Direct media path is set up between IP Phone A and SIP Phone B



SIP Phone dynamic registration

SIP Phone dynamic registration facilitates the creation of a contact list for the authorized SIP Phones. A SIP Phone client registers as an endpoint with the SIP Redirect Server (in the NRS). A phone number and a username are mandatory routing entries for the endpoint and are provided during provisioning in the NRS (see [Procedure 98 "Adding a User Endpoint"](#) (page 341)).

At registration, only one IP address of the SIP Phone is registered in the endpoint contact list. That is, if a SIP Phone provides more than one IP address in the registration message, then only one IP address (the first one) is stored on the NRS. Usually only one IP address is provided in the registration message; however, the number of provided IP addresses depends on the SIP Phone.

The SIP Redirect Server provides the phone context for SIP Phones when calling users behind the SIP Trunk Gateway.

Note: SIP Phones typically do not qualify DN-based URIs with the phone context. Basic support for dealing with raw numbers (as they are dialed by the user) is provided by the SIP Redirect Server. The SIP Redirect Server provides support of unqualified DN-based URIs by performing a pretranslation in order to find the appropriate phone-context.

Assumptions

SIP Phones must support the following for the dynamic registration and establishment of the SIP Phone calls:

- REGISTER message
- 302 message
- Re-INVITE message
- REFER message
- SUBSCRIBE message
- NOTIFY message
- INFO message for end-to-end DTMF
- phone-context transfer from 302 message to INVITE message
- vendor information
- username and password
- static or DHCP assigned IP address
- Expires and Expires Refresh Time based on a 423 (Interval Too Brief) message

Log files

SIP Phones generate log files. SIP Phone user registration and deregistration generate informational report log entries. However, SIP Trunk Gateways generate both log files and SNMP alarms. SIP Trunk Gateway endpoint registration and deregistrations generate SNMP alarms, as well as report log entries.

Installing a SIP Phone

Follow the manufacturer's installation and configuration instructions to set up your SIP Phone.

Configuring a SIP Phone

A SIP Phone is configured as a User Endpoint using NRS Manager. A SIP Phone registers and communicates as an User Endpoint in the NRS.

Routing of unqualified numbers

To support routing of unqualified numbers dialed by SIP Phones, the NRS provides several types of dialing prefixes at the Level 1 regional domain, Level 0 regional domain, and for endpoints. The dialing prefixes include the following:

- E.164 International dialing access code (for example, 6011)
- E.164 National dialing access code (for example, 61)

- E.164 Local dialing access code (for example, 9)
- Level 1 Regional dialing access code (for example, 6)
- Level 0 Regional dialing access code (the default, if none of above match)

Up to two special numbers can be specified at L1 and/or L0.

Task summary

Before a SIP Phone can be added as a User Endpoint in the NRS, the Service Domain, Level 1 Regional Domain, and Level 0 Regional Domain must be configured. To complete these tasks, perform the following procedures:

In the Vxworks-based NRS see

- [Procedure 82 “Adding a Service Domain” \(page 315\)](#)
- [Procedure 86 “Adding an L1 Domain \(UDP\)” \(page 319\)](#)
- [Procedure 90 “Adding an L0 Domain \(CDP\)” \(page 326\)](#)

In the Linux-based NRS see

- [Procedure 8 “Adding a Service Domain” \(page 160\)](#)
- [Procedure 12 “Adding an L1 Domain” \(page 166\)](#)
- [Procedure 16 “Adding an L0 Domain \(CDP\)” \(page 175\)](#)

To add a SIP Phone in Linux-based NRS as a User Endpoint, perform the steps in [Procedure 33 “Adding a User Endpoint” \(page 213\)](#).

To add a SIP Phone as a User Endpoint in VxWorks-based NRS, perform the steps in [Procedure 98 “Adding a User Endpoint” \(page 341\)](#).

Configure and manage the Linux-based Network Routing Service

Contents

This section contains information on the following topics:

- [“Introduction” \(page 106\)](#)
- [“Installation of Linux operating system, ECM framework and NRS application” \(page 108\)](#)
- [“Upgrade Linux-based NRS Release 5.0 to Release 5.5” \(page 109\)](#)
- [“Access NRS Manager through the ECM” \(page 111\)](#)
- [“Initial configuration of Linux-based NRS on a new IP Peer network” \(page 111\)](#)
- [“Configure NRS database user endpoints” \(page 115\)](#)
- [“Upgrade of an IP Peer Network from VxWorks-based NRS to Linux-based NRS with SIP Proxy” \(page 115\)](#)
- [“Recovery from failure of Linux-based NRS” \(page 132\)](#)
- [“Operation and maintenance of Linux-based NRS” \(page 132\)](#)
- [“Browser configuration” \(page 138\)](#)
- [“Log in to ECM and Access NRS Manager” \(page 140\)](#)
- [“NRS Manager interface” \(page 143\)](#)
- [“Log out of ECM” \(page 150\)](#)
- [“Configure the Primary and Secondary NRS Server Settings” \(page 150\)](#)
- [“Configure system-wide settings” \(page 156\)](#)
- [“Configure the NRS database” \(page 157\)](#)
- [“Switch between the Active and Standby databases” \(page 158\)](#)
- [“Manage a Service Domain” \(page 160\)](#)
- [“Manage a Level 1 Domain \(UDP\)” \(page 166\)](#)
- [“Manage a Level 0 Domain \(CDP\)” \(page 174\)](#)
- [“Manage a Collaborative Server” \(page 184\)](#)
- [“Manage a Gateway Endpoint” \(page 192\)](#)

- [“Manage Post-routing SIP URI Modification” \(page 207\)](#)
- [“Manage a User Endpoint” \(page 212\)](#)
- [“SIP Phone Context ” \(page 222\)](#)
- [“Manage a Routing Entry” \(page 224\)](#)
- [“Manage a Default Route” \(page 235\)](#)
- [“Manage bulk export of routing entries” \(page 241\)](#)
- [“Manage bulk import of routing entries” \(page 243\)](#)
- [“Verify the numbering plan and save the NRS configuration” \(page 255\)](#)
- [“H.323 and SIP Routing Tests” \(page 256\)](#)
- [“Enable, disable and restart the NRS Server” \(page 259\)](#)
- [“Perform NRS database actions” \(page 261\)](#)
- [“Backup the database” \(page 266\)](#)
- [“Restore the NRS database” \(page 271\)](#)
- [“GK/NRS Data Upgrade” \(page 278\)](#)

Introduction

Note: When components of an IP Peer network are upgraded to Release 5.0 or later, the Network Routing Servers must be running the highest release software installed on the network.

The Network Routing Service (NRS) can be configured and maintained through a web interface called NRS Manager. The Linux-based NRS Manager is a component of the Nortel Enterprise Common Manager (ECM). The ECM provides security and navigation infrastructure services for the web-based management applications: Element Manager (EM) and NRS Manager.

It is best practice to configure both a Primary and Secondary NRS to assure high availability of the IP Telephony network.

It is best practice to configure both a Primary and a Backup Security Server per ECM security domain to assure a highly available authentication and authorization service for OA&M users who need to access managed systems/elements in the ECM security domain, as well as for auxiliary applications that rely on continuous availability of the ECM framework web services API to monitor and control the CS 1000.

ECM Framework is installed from the NRS application Install CD (or from the EM application Install CD). Installation of ECM Framework is the first part of every Nortel application Install CD. The `appinstall` command always begins by installing the ECM Framework, then goes on to install the specific Nortel application.

For example, before NRS data can be provisioned using NRS Manager:

1. The Nortel-customized Red Hat Enterprise Linux operating system must be installed on an IBM 306m (NTDU99AA) or on a HP DL320 G4 (NTDU97AA) stand-alone server.
2. The Primary NRS and the ECM framework must be installed, and the co-resident Primary Security Service must be installed if a new ECM Security Domain will be created simultaneously with the installation of the Primary NRS. Alternatively, the Primary NRS can become a member of an existing ECM Security Domain. Optionally a co-resident Backup Security Service may be installed with the installation of the Primary NRS for an existing ECM Security Domain if a Backup Security Service does not already exist.

Note: In CS 1000 RIs 5.0 or later the Linux-based NRS must run on a stand-alone Linux-base COTS server, even for a small IP Telephony network that does not require high availability of the NRS services. Linux-based NRS in RIs 5.0 or alter does not run co-resident with Signaling Server applications on a CS 1000 system. For small CS 1000 networks that do not require high-availability, but do require some of the features introduced with the Linux-based NRS, the customer may choose to avoid the cost of provisioning a Secondary Linux-based NRS. A customer with similar requirements prior to CS 1000 RIs 5.0 would have relied on Primary and Secondary VxWorks-based NRS that are co-resident with Signaling Server applications on two geographically distributed CS 1000 systems. It is best practice to configure a Backup Security Service when one or more Nortel Linux-based servers are joined as members of an existing ECM Security Domain, to ensure continued access to ECM-based system management applications in case of failure of the ECM Primary Security service. It is best practice to configure a Secondary NRS for every NRS zone to ensure high-availability of the CS 1000 NRS.

3. Add the NRS Manager for the Primary and Secondary NRS servers as managed elements of the ECM.
4. Create user accounts and assign roles and permissions for access to the Primary and Secondary NRS servers from the ECM.

There is a bootable CD to install the Linux operating system and required third party software such as a Web server. There are two application CDs: the NRS CD and the EM CD. The NRS CD contains the NRS, the Primary Security Service and the Backup Security Service. The EM CD contains the EM, the Primary Security Service and the Backup Security Service.

Installation of Linux operating system, ECM framework and NRS application

There is one bootable CD to install the Nortel Linux-base operating system (RHEL 4.0), and to configure IP addresses for dual network interfaces, DNS name server IP addresses, Network Time Protocol, and Linux base built-in user accounts (`root` and `nortel`).

There are two Nortel application install CDs: the NRS CD and the EM CD. Either the NRS or the EM application, but not both, can be installed on the Nortel Linux base server in CS 1000 RIs 5.0 or later.

The NRS CD contains

- the Network Routing Service application
- the ECM framework
- the ECM Security Service (configurable as Primary Security Service, Backup Security Service, or Security Domain Member)
- Solid database (configurable as Hotstandby primary Solid server, Hotstandby secondary Solid server, or Standalone Solid Server)
- NRS Manager

The EM CD contains

- the Element Manager application
- the ECM framework
- the ECM Security Service (configurable as Primary Security Service, Backup Security Service, or Security Domain Member)
- Solid database

The Linux-based NRS server must be enabled and properly configured before the NRS data can be provisioned using NRS Manager.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the NRS application and the NRS Manager, the ECM Framework, the Solid database, and the ECM Security Services.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on adding a managed element to the ECM, creating user accounts, and assigning roles and permissions for access to the NRS server from the ECM.

The NRS and EM are installed on stand-alone servers. The Primary Security Service and the Backup Security Service can be installed with either NRS or EM. The NRS server will usually have a heavier load than the EM server. To optimize the servers' load balance, Nortel **recommends** that, if both Linux-based EM and Linux-based NRS are installed, the Primary Security Service be installed on the EM server and the Backup Security Service be installed on the Primary NRS server. In this case the Secondary NRS will be a security client of the Primary and Backup Security servers.

If Linux-based EM is **not** being installed, Nortel **recommends** that the Primary Security Service be installed on the Primary NRS server and the Backup Security Service be installed on the Secondary NRS server.

Note 1: An ECM security domain member server is a server that has the ECM installed, but does not have the Primary Security Service or the Backup Security Service installed. All ECM security domain member servers must have IP connectivity to either the Primary or Backup security server. If IP connectivity to both the Primary and Backup security servers is unavailable then the ECM security domain member server web pages are inaccessible.


Note 2: If the Primary Security Service is installed on the EM server the NRS server must have IP connectivity to the EM server. If IP connectivity to the EM server is unavailable then the NRS Manager web pages are inaccessible. IP connectivity between an NRS server and the EM server will be assured if the servers are on the same LAN.

Refer to *Security Management (NN43001-604)* (), for detailed information on CS 1000 system security including protection of signaling and the media stream from privacy intrusions or disruption, and the administration and use of secure remote access.

Upgrade Linux-based NRS Release 5.0 to Release 5.5

Use [Figure 32 "Linux base and applications upgrade for Primary or Backup ECM server"](#) (page 110) to determine the steps to upgrade the Linux base and NRS application on a Primary or Backup ECM server.


Figure 32
Linux base and applications upgrade for Primary or Backup ECM server



Use [Figure 33 "Linux base and applications upgrade for ECM member server"](#) (page 110) to determine the steps to upgrade the Linux base and NRS application on a ECM member server.

Note: Either the NRS or the EM application, but not both, can be installed on the Nortel Linux base server in CS 1000 RIs 5.0 or later.

Figure 33
Linux base and applications upgrade for ECM member server



Refer to ["Backup the database"](#) (page 266) for detailed information on backing up the NRS database.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)*, for detailed information on upgrading the Linux operating system, the NRS application and the NRS Manager, the ECM Framework, the Solid database, and the ECM Security Services.

Refer to [“Restore the NRS database” \(page 271\)](#) for detailed information on restoring the NRS database.

Access NRS Manager through the ECM

Access NRS Manager through the ECM. See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#) to access NRS Manager.

Configure your web browser and windows display before logging in to ECM. NRS Manager is supported only on Microsoft Internet Explorer version 6.0 (or later). See [Procedure 1 “Configuring the Internet Explorer browser settings” \(page 139\)](#) to configure the Internet Explorer browser. See [Procedure 2 “Configuring the Windows Display settings” \(page 140\)](#) to configure the Windows display settings.

Initial configuration of Linux-based NRS on a new IP Peer network

This section provides a high-level overview of the initial configuration of the Linux-based NRS on a new IP Peer network. The main steps are:

- Accessing the NRS Manager.
- Configuring the Primary and Secondary NRS servers.
- Starting services.
- Configuring system wide NRS settings.
- Configuring the NRS database (the Solid database). The NRS database provides a central database of addresses that are required to route calls across the network.
- Logging out of the ECM.

In more detail, the initial configuration of the Linux-based NRS on a new IP Peer network task is comprised of:

1. **Accessing NRS manager.** See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).
2. **Configure the Primary and Secondary NRS server settings.** See [Procedure 5 “Configuring the Primary and Secondary NRS Server Settings” \(page 151\)](#).

ATTENTION

The Primary and Secondary NRS servers must be configured one by one. The user *must* be logged on the specific (either Primary or Secondary) server to configure it. See [Step 4 of Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).

3. **Start services.**

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

4. **Configure system wide settings.** See [Procedure 6 “Configuring system-wide settings” \(page 156\)](#).

5. **Build the NRS database.**

The NRS database comprises

- service domains, L1 domains and L0 domains
- collaborative servers
- gateway endpoints
- routing entries
- post-routing SIP URI modification table entries

Note: This task is related to building the NRS database gateway endpoints. It is not related to building the NRS database user endpoints.

ATTENTION

The following steps **must** be performed in the order given.

- a. Create the Service Domain, Level 1 Domains (UDP), Level 0 Domains (CDP), which hold the endpoint numbering plans on the NRS. This is complementary to the CDP configuration on the Call Server.
 - i. See [Procedure 8 “Adding a Service Domain” \(page 160\)](#).
 - ii. See [Procedure 12 “Adding an L1 Domain” \(page 166\)](#).
 - iii. See [Procedure 16 “Adding an L0 Domain \(CDP\)” \(page 175\)](#).
- b. Add collaborative servers.
 - See [Procedure 20 “Adding a Collaborative Server” \(page 184\)](#).
- c. Add gateway endpoints and endpoint prefixes. See [Procedure 24 “Adding a Gateway Endpoint” \(page 193\)](#).
- d. Add the numbering plan entries for each gateway endpoint, including the Cost Factor for each entry.

- i. See [Procedure 39 “Adding a Routing Entry”](#) (page 224).
 - ii. See [Procedure 46 “Adding a Default Route”](#) (page 235).
 - e. Post-routing SIP URI modification table entries
 - i. See [Procedure 29 “Adding Post-routing SIP URI Modification”](#) (page 207).
 - ii. See [Procedure 31 “Editing Post-routing SIP URI Modification”](#) (page 210).
 - iii. See [Procedure 32 “Deleting Post-routing SIP URI Modification”](#) (page 211).
6. **Test the numbering plans .**
 - a. See [Procedure 53 “Performing an H.323 Routing Test”](#) (page 256).
 - b. See [Procedure 54 “Performing a SIP Routing Test”](#) (page 257).
7. **Perform database actions.** See [“Perform NRS database actions”](#) (page 261). To save the NRS configuration, refer to the procedures in this section.
 - See [Procedure 58 “Cutting over the database”](#) (page 263).
 - See [Procedure 59 “Reverting the database changes”](#) (page 264).
 - See [Procedure 60 “Rolling back changes to the database”](#) (page 265).
 - See [Procedure 61 “Committing the database”](#) (page 265).
8. **Back up the NRS database.** See [“Backup the database”](#) (page 266).
 - See [Procedure 62 “Backing up the database automatically”](#) (page 266).
 - See [Procedure 63 “Backing up the database manually”](#) (page 267).
9. **Log out of ECM .** See [Procedure 4 “Logging out of ECM ”](#) (page 150).
10. To return to the ECM web page without terminating the current ECM session see [“Common Manager link”](#) (page 150).

Configure Gateway endpoints

See the Element Manager procedures in *IP Peer Networking Installation and Commissioning (NN43001-313)* () to configure H.323 and SIP gateway endpoints. When configuring the gateway endpoints see the [“Nortel recommendation for load-balancing across the Primary and Secondary Linux-based NRS servers”](#) (page 114).

Nortel recommendation for load-balancing across the Primary and Secondary Linux-based NRS servers

The Linux-based NRS has an active-active database model. In the active-active database model:

- Both the Primary and Secondary NRS can register endpoints.
- A registration event updates a common database shared by the Primary and Secondary NRS.
- Both the Primary and Secondary NRS can route calls to endpoints that are registered to either the Primary or Secondary NRS.

Load-balancing across the Primary and Secondary NRS servers can be implemented by configuring half of the gateway endpoints to target the Primary NRS server as their first choice for registration and half of the gateway endpoints to target the Secondary NRS server as their first choice for registration. The gateway will register with only one of the NRS servers.

There are two IP addresses assigned when configuring H.323 gateway settings: a **Primary gatekeeper IP address** and an **Alternate gatekeeper IP address**. In this context, the **Primary gatekeeper IP address** is the IP address of the gateway's first choice for registration and the **Alternate gatekeeper IP address** is the IP address of the gateway's alternate choice for registration, if it's first choice is not in service.

Thus, to optimize load-balancing across the Primary and Secondary NRS servers when configuring the gateway endpoints, for half of the H.323 gateway endpoints enter the **IP address of the Primary NRS server** in the **Primary gatekeeper IP address** text box and enter the **IP address of the Secondary NRS server** in the **Alternate gatekeeper IP address** text box.

Reverse this assignment for the other half of the H.323 gateway endpoints. That is enter the **IP address of the Secondary NRS server** in the **Primary gatekeeper IP address** text box and enter the **IP address of the Primary NRS server** in the **Alternate gatekeeper IP address** text box.

Similarly, there are two IP addresses assigned when configuring SIP gateway settings: a **Primary Proxy/Re-direct IP address** and a **Secondary Proxy/Re-direct IP address**. In this context, the **Primary Proxy/Re-direct IP address** is the IP address of the gateway's first choice for registration and the **Secondary Proxy/Re-direct IP address** is the IP address of the gateway's alternate choice for registration, if it's first choice is not in service.

Thus to optimize load-balancing across the Primary and Secondary NRS servers when configuring the gateway endpoints, for half of the SIP gateway endpoints enter the **IP address of the Primary NRS**

server in the **Primary Proxy/Re-direct IP address** text box and enter the **IP address of the Secondary NRS server** in the **Secondary Proxy/Re-direct IP address** text box.

Reverse this assignment for the other half of the SIP gateway endpoints. That is enter the **IP address of the Secondary NRS server** in the **Primary Proxy/Re-direct IP address** text box and enter the **IP address of the Primary NRS server** in the **Secondary Proxy/Re-direct IP address** text box.

Configure NRS database user endpoints

1. **SIP phones.** A SIP Phone registers and communicates as a user endpoint in the NRS. To add a User Endpoint, refer to [Procedure 33 “Adding a User Endpoint” \(page 213\)](#).
2. **View the SIP Phone Context.** See [Procedure 38 “Mapping the SIP Phone Context” \(page 222\)](#) to view the SIP phone context.

Upgrade of an IP Peer Network from VxWorks-based NRS to Linux-based NRS with SIP Proxy

Recommended upgrade procedure

There are two upgrade paths of an existing IP Peer Network from VxWorks-based NRS to Linux-based NRS:

1. **Re-use the existing NRS IP addresses for Linux-based NRS servers**
2. **New NRS IP address assignments**

Nortel *recommends* following the upgrade procedures that **Re-use the existing NRS IP addresses for Linux-based NRS servers** in order to avoid configuration changes to all existing SIP and H.323 endpoints. The recommended procedure also allows rapid switchover from the existing VxWorks-based NRS to the new Linux-based NRS while minimizing IP Telephony service interruption.

You must follow the alternative upgrade procedures for **New NRS IP address assignments** (a) when the new Linux-based NRS must be installed at a different location with different IP address scopes, or (b) when the new Linux-based NRS must be installed as a Collaborating NRS zone parallel to the existing VxWorks-based NRS during a gradual upgrade process with gradual switchover of the SIP and H.323 endpoints to the new Linux-based NRS.

Re-use the existing NRS IP addresses for Linux-based NRS upgrade procedure

If the Linux-based NRS can be installed in the same physical location as the existing VxWorks-based NRS, there are several advantages to this upgrade path:

- All VxWorks-based SIP and H.323 endpoints can be simultaneously switched over to the Linux-based NRS by manipulating Layer 1 and Layer 2 network connections of the VxWorks-based and Linux-Based NRS. Consequently, the NRS service will not be interrupted due to the upgrade.
- Endpoints (virtual trunk Gateways and IP Phones) do not have to be manually re-configured to target new Primary and Secondary NRS IP addresses.
- Provided the endpoints have not been re-configured to use features that are unique to the Linux-base NRS (for example, network post-translation, TLS, or transport normalization), it is possible to revert all endpoints with minimum disruption to the VxWorks-based NRS by manipulating Layer 1 and Layer 2 network connections (such as moving the ethernet cables) on the VxWorks-based and Linux-based NRS servers.

One might wish to revert to the VxWorks-based NRS, if service needs to be restored rapidly after a switch over to the Linux-based NRS due to a configuration mistake or missing software patches.

Overview of upgrade procedure

The following considerations determine how the upgrade procedure is implemented:

1. If the Linux-based NRS servers re-use existing IP addresses, it is necessary to ensure that duplicate IP addresses do not appear on the enterprise network during the upgrade.

To ensure that duplicate IP addresses do not appear on the enterprise network during the upgrade, isolate the existing VxWorks-based Primary NRS from the enterprise network by unplugging it from the network.

This forces the endpoints to register to the VxWorks-based Alternate NRS. Network services will be maintained by the Alternate NRS during the upgrade. If the Alternate NRS were to fail, the Failsafe NRS, co-resident with CS 1000 gateway endpoints, provides system redundancy for the IP Peer network during the upgrade and migration to Linux-based NRS.

2. A Linux-based NRS application must be installed on an ECM security domain. An ECM security domain is defined by the ECM Primary Security server. An ECM security domain is comprised of the ECM

Primary Security server, an optional ECM Backup Security server and any associated security domain member servers. An ECM security domain member server is a server that has the ECM framework and the Linux-based EM application or the Linux-based NRS application installed, but does not have the Primary Security Service or the Backup Security Service installed.

If single sign-on is required for EM and NRS Manager than the Linux-based NRS servers and Linux-based EM must be members of the same ECM security domain.

The Linux-based NRS and the Linux-based EM applications are installed on stand-alone servers. The ECM Primary Security Service can be installed with either NRS or EM. To optimize the servers' load balance Nortel **recommends** that, if both Linux-based EM and Linux-based NRS are installed, the Primary Security Service be installed on the EM server. If Linux-based EM is not being installed, Nortel **recommends** that the Primary Security Service be installed on the Primary NRS server.

3. By contrast, the VxWorks-based NRS is hosted either co-resident with Signaling Server applications, or in a stand-alone mode on a dedicated server running the VxWorks real-time operating system. VxWorks servers do not rely on ECM security domains for installation or operation.

If the VxWorks-based NRS is co-resident with Signaling Server applications, the Signaling Server must be assigned a new TLAN host IP address that is not in use on the TLAN network.

Linux-based NRS dependency on ECM security domain

There must be network connectivity to the ECM Primary Security Service during the installation of the Primary and Secondary NRS. There are two configurations for the deployment of the ECM Primary Security Service:

1. Linux-based EM has not been installed and is not being installed now. The ECM Primary Security Service is being installed on the Linux-based Primary NRS server and the ECM Backup Security Service is being installed on the Linux-based Secondary NRS server.
2. Both the Linux-based EM and Linux-based NRS are being installed. The ECM Primary Security Service is being installed on the EM server and the ECM Backup Security Service is being installed on the Linux-based Primary NRS server. The Linux-based Secondary NRS will be a security client of the ECM Primary and Backup Security servers.

Install Linux-based NRS by isolating VxWorks-based NRS from customer network: scenario 1

Follow this upgrade path if the Linux-based EM has not been installed and is not being installed now. The ECM Primary Security Service is being installed on the Linux-based Primary NRS server and the ECM Backup Security Service is being installed on the Linux-based Secondary NRS server.

This section provides a task summary of the main steps in the upgrade procedure.

1. Log on to VxWorks-based Primary NRS.

See [“Accessing NRS Manager” \(page 294\)](#).

2. Monitor the VxWorks-based IP Peer network.

View SIP gateways, H.323 gateways, user endpoints, collaborative servers, a representative sample of routes and the database backup log file. Carefully note which endpoints are registered and which endpoints are not registered.

Follow the VxWorks-based procedures:

[Procedure 95 “Viewing the Gateway Endpoints” \(page 339\)](#).

[Procedure 98 “Adding a User Endpoint” \(page 341\)](#). (This procedure also shows how to view user endpoints).

[Procedure 111 “Viewing the Collaborative Servers” \(page 366\)](#).

[Procedure 103 “Viewing the Routing Entries” \(page 353\)](#).

[Procedure 127 “Downloading the latest backup log file” \(page 387\)](#)

3. To ensure that the Alternate NRS is communicating with the Primary NRS and that the databases are synchronized, use the CLI command to invoke database synchronization.

4. Backup the VxWorks-based NRS database. See [“Backing up the database” \(page 384\)](#).

5. Gracefully disable the VxWorks-based Primary NRS server forcing all endpoints to register with the VxWorks-based Alternate NRS. See [Procedure 117 “Disabling the NRS server” \(page 374\)](#).

6. Log in to VxWorks-based Alternate NRS. See [“Accessing NRS Manager” \(page 294\)](#).

Verify that the SIP gateways, H.323 gateways and user endpoints have registered with the VxWorks-based Alternate NRS.

Follow the VxWorks-based procedures:

[Procedure 95 “Viewing the Gateway Endpoints” \(page 339\)](#) .

[Procedure 98 “Adding a User Endpoint” \(page 341\)](#). (This procedure also shows how to view user endpoints).

7. Disconnect the existing VxWorks-based Primary NRS from the enterprise network.

- a. If the VxWorks-based Primary NRS server is in stand-alone mode (that is, not co-resident with Signaling Server applications), disconnect it from the enterprise network and connect the Linux-based Primary NRS server to the enterprise network.
- b. If the VxWorks-based Primary NRS is co-resident with Signaling Server applications, do not disconnect the Primary NRS from the enterprise network.

Instead,

- i. Re-configure the Signaling Server with a newly assigned TLAN host IP address that is not in use on the TLAN network.
- ii. Reboot the Signaling Server. Doing so momentarily disrupts applications, such as
 - UNISTim terminal Proxy
 - SIP gateway
 - H.323 gateway

ATTENTION

You must complete step 7 before step 8

8. Install the Linux-based Primary NRS server.

- a. Install the Linux operating system on a COTS stand-alone server. There is a bootable CD to install the Linux operating system.

Note: the VxWorks-based Primary NRS IP address must be assigned as the TLAN IP address of the Primary NRS during installation of the Linux operating system.

- b. Install the NRS and the ECM Primary Security Service. During the installation of the NRS application configure the Solid database server as **Hotstandby primary Solid server**.

The NRS CD contains the NRS and ECM Primary Security Service.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework, the NRS and the ECM Primary Security Service.

9. Add the NRS Manager for the Primary and Secondary NRS servers as managed elements of the ECM.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on adding a managed element to the ECM.

10. **Create user accounts and assign roles and permissions** for access to the Primary and Secondary NRS servers from the ECM.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on creating user accounts, and assigning roles and permissions for access to the NRS servers from the ECM.

11. **Log in to NRS Manager for the Linux-based Primary NRS server.**

See [Procedure 3 "Logging in to ECM and Accessing NRS Manager"](#) (page 140).

12. **Configure the Linux-based Primary server settings.** See [Procedure 5 "Configuring the Primary and Secondary NRS Server Settings"](#) (page 151).

— Assign the IP address of the VxWorks-based Primary NRS server to the Linux-based Primary NRS server. Assign the IP address of the VxWorks-based Alternate NRS server to the Linux-based Secondary NRS server. Choose **Primary** from the **server role** drop down list. See [Figure 46 "Edit Server Configuration web page"](#) (page 151).

— If the IP network NRS zone contains H.323 endpoints, configure H.323 Gatekeeper settings.

— Configure SIP Server settings.

— Configure Network Connection Server settings.

13. **Start services on the Primary NRS server.**

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

After services are started the Primary NRS will respond to polling and registration requests.

14. **Restore the VxWorks-based NRS database** backed up in step 4.

See the procedures in ["Restore the NRS database"](#) (page 271) to restore an NRS Release 5.5, 5.0, 4.5 or 4.0 database. See ["GK/NRS Data Upgrade"](#) (page 278) to restore a 3.0 H.323 Gatekeeper.

ATTENTION

Restoring the previous release database should always be followed by cross checking changes in the Primary and Secondary NRS Server settings (see [Figure 46 "Edit Server Configuration web page"](#) (page 151)) and saving them in the new restored database.

15. To ensure that the correct database file has been restored and that it looks similar to the database that was backed up in step 4, review the restored database.

Follow the Linux-based procedures:

[Procedure 95 “Viewing the Gateway Endpoints” \(page 339\)](#)

[Procedure 103 “Viewing the Routing Entries” \(page 353\)](#)

[Procedure 21 “Viewing a Collaborative Server” \(page 189\)](#)

[Procedure 35 “Viewing the User Endpoints” \(page 219\)](#)

- 16. Monitor the SIP gateway, H.323 gateway and user end points** on the Linux-based IP Peer network to ensure that they have registered with the Linux-based Primary NRS server.

Follow the Linux-based procedures:

[Procedure 26 “Viewing the Gateway Endpoints” \(page 202\).](#)

[Procedure 35 “Viewing the User Endpoints” \(page 219\)](#)

All gateways and end points should have registered with the Linux-based Primary NRS within five minutes.

Carefully note which endpoints are registered and which endpoints are not registered.

Compare this list of registered endpoints with the list of registered endpoints in step 2 to ensure that all SIP and H.323 endpoints that were registered to the VxWorks-based NRS are now registered to the Linux-based Primary NRS.

- 17. Disconnect the existing VxWorks-based Alternate NRS from the enterprise network.**

- a. If the VxWorks-based Alternate NRS server is in stand-alone mode (that is not co-resident with Signaling Server applications), disconnect it from the enterprise network and connect the Linux-based Secondary NRS server to the enterprise network.
- b. If the VxWorks-based Alternate NRS is co-resident with Signaling Server applications, do not disconnect the Alternate NRS from the enterprise network.

Instead,

- i. Re-configure the Signaling Server with a newly assigned TLAN host IP address that is not in use on the TLAN network.
- ii. Reboot the Signaling Server. Doing so momentarily disrupts applications, such as
 - UNISTim terminal Proxy
 - SIP gateway
 - H.323 gateway

ATTENTION

You must complete step 17 before step 18

ATTENTION

The IP Peer network will have a Linux-based Primary NRS server without a Linux-based Secondary NRS server or a VxWorks-based Alternate server deployed between the completion of step 18 and the completion of step 22. The network should not be left in this configuration. Coordinate the completion of the tasks in step 18 and step 21, to ensure that the network is not left in this configuration for a long period of time.

18. Install the Linux-based Secondary NRS server.

- a. Install the Linux operating system on a COTS stand-alone server.
There is a bootable CD to install the Linux operating system.

Note: the VxWorks-based Alternate NRS IP address must be assigned as the TLAN IP address of the Secondary NRS during installation of the Linux operating system.

- b. Install the NRS and the ECM Backup Security Service. During the installation of the NRS application configure the Solid database server as **Hotstandby secondary Solid server**.

The NRS CD contains the NRS application and ECM Backup Security Service.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework, the NRS and the ECM Primary Security Service.

19. Log in to NRS Manager for the Secondary NRS server. See [Procedure 3 "Logging in to ECM and Accessing NRS Manager" \(page 140\)](#).

20. Configure the Linux-based Secondary server settings. See [Procedure 5 "Configuring the Primary and Secondary NRS Server Settings" \(page 151\)](#).

- Assign the IP address of the VxWorks-based Primary NRS server to the Linux-based Primary NRS server. Assign the IP address of the VxWorks-based Alternate NRS server to the Linux-based Secondary NRS server. Choose **Secondary** from the **server role** drop down list. See [Figure 46 "Edit Server Configuration web page" \(page 151\)](#).
- If the IP network NRS zone contains H.323 endpoints, configure H.323 Gatekeeper settings.
- Configure SIP Server settings.
- Configure Network Connection Server settings.

21. Start services on Secondary NRS server.

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

Both the Linux-based Primary and Secondary NRS are in service. The endpoints should remain registered to the Primary NRS server. The Solid database synchronization link should be established between the Primary and Secondary NRS servers. The Solid databases on the Primary and Secondary servers should synchronize automatically.

22. Ensure Linux-based Primary and Secondary NRS servers are synchronizing.

To ensure the NRS servers are synchronizing

- Log onto the Primary NRS Manager. See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).
- View the Gateway Endpoints on the Active Database. See [Procedure 26 “Viewing the Gateway Endpoints” \(page 202\)](#).
- Note the number of Gateway Endpoints.
- View the User Endpoints on the Active Database. See [Procedure 35 “Viewing the User Endpoints” \(page 219\)](#).
- Note the number of User Endpoints
- Log onto the Secondary NRS Manager. See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).
- View the Gateway Endpoints on the Active Database. See [Procedure 26 “Viewing the Gateway Endpoints” \(page 202\)](#).
- Note the number of Gateway Endpoints
- View the User Endpoints on the Active Database. See [Procedure 35 “Viewing the User Endpoints” \(page 219\)](#).
- Note the number of User Endpoints
- If the number of endpoints on the Primary NRS and the Secondary NRS databases are the same, then the databases are synchronized.

End of task summary for upgrade procedure.

Install Linux-based NRS by isolating VxWorks-based NRS from customer network: scenario 2

This section provides a task summary of the main steps in the upgrade procedure.

Note: If Linux-based EM was installed with the ECM Primary Security Service prior to the installation of the Linux-based NRS, proceed directly to step 2.

1. Follow this upgrade path if the Linux-based EM and Linux-based NRS are being installed at the same time. The ECM Primary Security Service is being installed on the EM server and the ECM Backup Security Service is being installed on the Linux-based Primary NRS server. The Linux-based Secondary NRS will be a security client of the ECM Primary and Backup Security servers.

Install and configure the Linux-based EM server

- a. Install the Linux operating system on a COTS stand-alone server.
There is a bootable CD to install the Linux operating system.

Note: the VxWorks-based Primary NRS IP address must be assigned as the TLAN IP address of the Primary NRS during installation of the Linux operating system.

- b. Install the EM and the ECM Primary Security Service.
The EM CD contains the EM and ECM Primary Security Service.
Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework, the NRS and the ECM Primary Security Service.

2. **Add the NRS Manager for the Primary and Secondary NRS servers as managed elements of the ECM.**

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on adding a managed element to the ECM.

3. **Create user accounts and assign roles and permissions** for access to the Primary and Secondary NRS servers from the ECM.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on creating user accounts, and assigning roles and permissions for access to the NRS servers from the ECM.

4. **Log on to VxWorks-based Primary NRS.** See [“Accessing NRS Manager” \(page 294\)](#).

5. **Monitor the VxWorks-based IP Peer network.**

View SIP gateways, H.323 gateways, user endpoints, collaborative servers and a representative sample of routes. Carefully note which endpoints are registered and which endpoints are not registered.

Follow VxWorks-based procedures:

[Procedure 95 “Viewing the Gateway Endpoints” \(page 339\)](#).

[Procedure 98 “Adding a User Endpoint” \(page 341\)](#). (This procedure also shows how to view user endpoints).

[Procedure 111 “Viewing the Collaborative Servers” \(page 366\)](#).

[Procedure 103 “Viewing the Routing Entries” \(page 353\).](#)

[Procedure 127 “Downloading the latest backup log file” \(page 387\).](#)

6. To ensure that the Alternate NRS is communicating with the Primary NRS and that the databases are synchronized, use the CLI command to invoke database synchronization.
7. **Backup the VxWorks-based NRS database.** See [“Backing up the database” \(page 384\).](#)
8. **Gracefully disable the VxWorks-based Primary NRS server** forcing all endpoints to register with the VxWorks-based Alternate NRS. See [Procedure 117 “Disabling the NRS server” \(page 374\).](#)
9. **Log in to VxWorks-based Alternate NRS.** See [“Accessing NRS Manager” \(page 294\).](#)

Verify that the SIP gateways, H.323 gateways and user endpoints have registered with the VxWorks-based Alternate NRS.

Follow VxWorks-based procedures:

[Procedure 95 “Viewing the Gateway Endpoints” \(page 339\).](#)

[Procedure 98 “Adding a User Endpoint” \(page 341\).](#) (This procedure also shows how to view user endpoints).

10. **Disconnect the existing VxWorks-based Primary NRS from the enterprise network.**
 - a. If the VxWorks-based Primary NRS server is in stand-alone mode (that is, not co-resident with Signaling Server applications), disconnect it from the enterprise network and connect the Linux-based Primary NRS server to the enterprise network.
 - b. If the VxWorks-based Primary NRS is co-resident with Signaling Server applications, do not disconnect the Primary NRS from the enterprise network.

Instead,

- i. Re-configure the Signaling Server with a newly assigned TLAN host IP address that is not in use on the TLAN network.
- ii. Reboot the Signaling Server. Doing so momentarily disrupts applications, such as
 - UNISim terminal Proxy
 - SIP gateway
 - H.323 gateway

ATTENTION

You must complete step 10 before step 11.

11. **Install the Linux-based Primary NRS server.**

- a. Install the Linux operating system on a COTS stand-alone server. There is a bootable CD to install the Linux operating system.

Note: the VxWorks-based Primary NRS IP address must be assigned as the TLAN IP address of the Primary NRS during installation of the Linux operating system.

- b. Install the NRS and the ECM Backup Security Service. During the installation of the NRS application configure the Solid database server as **Hotstandby primary Solid server**

The NRS CD contains the NRS and ECM Primary Security Service.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework, the NRS and the ECM Backup Security Service.

12. Log in to NRS Manager for the Linux-based Primary NRS server.

See [Procedure 3 "Logging in to ECM and Accessing NRS Manager"](#) (page 140).

13. Restore the VxWorks-based NRS database backed up in step 7.

See the procedures in ["Restore the NRS database"](#) (page 271) to restore an NRS Release 5.5, 5.0, 4.5 or 4.0 database. See ["GK/NRS Data Upgrade"](#) (page 278) to restore a 3.0 H.323 Gatekeeper.

ATTENTION

Restoring the previous release database should always be followed by cross checking changes in the Primary and Secondary NRS Server settings (see [Figure 46 "Edit Server Configuration web page"](#) (page 151)) and saving them in the new restored database.

14. To ensure that the correct database file has been restored and that it looks similar to the database that was backed up in step 7, review the restored database.

Follow Linux-based procedures to:

[Procedure 26 "Viewing the Gateway Endpoints"](#) (page 202)

[Procedure 40 "Viewing the Routing Entries"](#) (page 226)

[Procedure 21 "Viewing a Collaborative Server"](#) (page 189)

[Procedure 35 "Viewing the User Endpoints"](#) (page 219)

15. **Configure the Linux-based Primary server settings.** See [Procedure 5 "Configuring the Primary and Secondary NRS Server Settings"](#) (page 151).

— Assign the IP address of the VxWorks-based Primary NRS server to the Linux-based Primary NRS server. Assign the IP address of the VxWorks-based Alternate NRS server to the Linux-based

Secondary NRS server. Choose **Primary** from the **server role** drop down list. See [Figure 46 "Edit Server Configuration web page" \(page 151\)](#).

- If the IP network NRS zone contains H.323 endpoints, configure H.323 Gatekeeper settings.
- Configure SIP Server settings.
- Configure Network Connection Server settings.

16. Start services on the Primary NRS server.

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

After services are started the Primary NRS will respond to polling and registration requests.

17. Monitor the SIP gateway, H.323 gateway and user endpoints on the Linux-based IP Peer network to ensure that they have registered with the Linux-based Primary NRS server.

Follow the Linux-based procedures:

[Procedure 26 "Viewing the Gateway Endpoints" \(page 202\)](#).

[Procedure 35 "Viewing the User Endpoints" \(page 219\)](#)

All gateways and end points should have registered with the Linux-based Primary NRS within five minutes.

Carefully note which endpoints are registered and which endpoints are not registered.

Compare this list of registered endpoints with the list of registered endpoints in step 5 to ensure that all SIP endpoints that were registered to the VxWorks-based NRS are now registered to the Linux-based Primary NRS.

18. Disconnect the existing VxWorks-based Alternate NRS from the enterprise network.

- a. If the VxWorks-based Alternate NRS server is in stand-alone mode (that is not co-resident with Signaling Server applications), disconnect it from the enterprise network and connect the Linux-based Secondary NRS server to the enterprise network.
- b. If a Signaling Server is co-resident with the VxWorks-based Alternate NRS do not disconnect the VxWorks-based Alternate NRS from the enterprise network.

Instead,

- i. Re-configure the Signaling Server with a newly assigned TLAN host IP address that is not in use on the TLAN network.
- ii. Reboot the Signaling Server. Doing so momentarily disrupts applications, such as
 - UNISlim terminal Proxy
 - SIP gateway
 - H.323 gateway

ATTENTION

Complete step 18 before step 19.

ATTENTION

The IP Peer network will have a Linux-based Primary NRS server without a Linux-based Secondary NRS server or a VxWorks-based Alternate server deployed between the completion of step 19 and the completion of step 23. The network should not be left in this configuration. Coordinate the completion of the tasks in step 19 and step 23, to ensure that the network is not left in this configuration for a long period of time.

19. Install the Linux-based Secondary NRS server.

- a. Install the Linux operating system on a COTS stand-alone server.
There is a bootable CD to install the Linux operating system.

Note: the VxWorks-based Alternate NRS IP address must be assigned as the TLAN IP address of the Secondary NRS during installation of the Linux operating system.

- b. Install the NRS as an ECM security domain member, that is, without the ECM Primary or Backup Security service. The Secondary NRS will be a security client of the ECM Primary and Backup Security servers. During the installation of the NRS application configure the Solid database server as **Hotstandby secondary Solid server**.

The NRS CD contains the NRS application.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework and the NRS.

20. Log in to NRS Manager for the Secondary NRS server. See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).

21. Configure the Linux-based Secondary server settings. See [Procedure 5 “Configuring the Primary and Secondary NRS Server Settings” \(page 151\)](#).

- Assign the IP address of the VxWorks-based Primary NRS server to the Linux-based Primary NRS server. Assign the IP address of the VxWorks-based Alternate NRS server to the Linux-based Secondary NRS server. Choose **Secondary** from the **server role** drop down list. See [Figure 46 "Edit Server Configuration web page" \(page 151\)](#).
- If the IP network NRS zone contains H.323 endpoints, configure H.323 Gatekeeper settings.
- Configure SIP Server settings.
- Configure Network Connection Server settings.

22. Start services on Secondary NRS server.

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

Both the Linux-based Primary and Secondary NRS are in service. The endpoints should remain registered to the Primary NRS server. The Solid database synchronization link should be established between the Primary and Secondary NRS servers. The Solid databases on the Primary and Secondary servers should synchronize automatically.

23. Ensure Linux-based Primary and Secondary NRS servers are synchronizing..

To ensure the NRS servers are synchronizing

- Log onto the Primary NRS Manager. See [Procedure 3 "Logging in to ECM and Accessing NRS Manager" \(page 140\)](#).
- View the Gateway Endpoints on the Active Database. See [Procedure 26 "Viewing the Gateway Endpoints" \(page 202\)](#).
- Note the number of Gateway Endpoints.
- View the User Endpoints on the Active Database. See [Procedure 35 "Viewing the User Endpoints" \(page 219\)](#).
- Note the number of User Endpoints
- Log onto the Secondary NRS Manager. See [Procedure 3 "Logging in to ECM and Accessing NRS Manager" \(page 140\)](#).
- View the Gateway Endpoints on the Active Database. See [Procedure 26 "Viewing the Gateway Endpoints" \(page 202\)](#).
- Note the number of Gateway Endpoints
- View the User Endpoints on the Active Database. See [Procedure 35 "Viewing the User Endpoints" \(page 219\)](#).

- Note the number of User Endpoints
- If the number of endpoints on the Primary NRS and the Secondary NRS databases are the same, then the databases are synchronized.

End of task summary for upgrade procedure.

New NRS IP address assignments upgrade procedure

1. Backup the VxWorks-based NRS (Release 4.0, 4.5, 5.0 or 5.5) or H.323 Gatekeeper database. See [“Backing up the database”](#) (page 384).
2. Install and configure the Linux-based NRS Primary and Secondary servers with the new IP addresses. See [“Introduction”](#) (page 106) and [“Installation of Linux operating system, ECM framework and NRS application”](#) (page 108).

This step has four substeps:

- a. Install the Linux operating system on a COTS stand-alone server. There is a bootable CD to install the Linux operating system.
- b. Install the Primary and Secondary NRS, the Primary Security Service and the Backup Security Service.
- c. Add the NRS Manager for the Primary and Secondary NRS servers as managed elements of the ECM.
- d. Create user accounts and assign roles and permissions for access to the Primary and Secondary NRS servers from the ECM.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* (), for detailed information on installing the Linux operating system, the ECM framework and the NRS.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* (), for detailed information on adding a managed element to the ECM, creating user accounts, and assigning roles and permissions for access to the NRS servers from the ECM.

3. **Log in to NRS Manager.** See [Procedure 3 “Logging in to ECM and Accessing NRS Manager”](#) (page 140).
4. **Assign the new IP addresses to the Primary and Secondary NRS servers.** See [Procedure 5 “Configuring the Primary and Secondary NRS Server Settings”](#) (page 151).

ATTENTION

The primary and secondary NRS servers must be configured one by one. The user *must* be logged on the specific (either primary or secondary) server to configure it. See [Step 4 of Procedure 3 “Logging in to ECM and Accessing NRS Manager”](#) (page 140).

5. Restore the VxWorks-based NRS database backed up in "step 1" (page 130) . If a Succession 3.0 H.323 Gatekeeper database is being restored see "GK/NRS Data Upgrade" (page 278). If an NRS Release 4.0, 4.5, 5.0 or 5.5 database is being restored follow the procedures in "Restore the NRS database" (page 271).

ATTENTION

Restoring the previous release database should always be followed by cross checking changes in the Primary and Secondary NRS Server settings (see Figure 46 "Edit Server Configuration web page" (page 151)) and saving them in the new restored database.

6. **Start services.**

In the **NRS Manager Navigator** select **System > NRS Server**. The **NRS Server** web page opens. Click the **Restart** button on the **Service Status** pane of the **NRS Server** web page.

7. Re-configure all endpoints to target the new IP addresses of the Primary and Secondary NRS servers.

ATTENTION

Re-configuring the endpoints to target the new IP addresses of the Primary and Secondary NRS servers interrupts the NRS service for parts of the IP Peer Network.

ATTENTION

Follow the "Nortel recommendation for load-balancing across the Primary and Secondary Linux-based NRS servers" (page 114) when re-configuring the **gateway** endpoints.

- a. See the Element Manager procedure in *IP Peer Networking Installation and Commissioning (NN43001-313)* () to re-configure H.323 gateway endpoints.
- b. See the Element Manager procedure in *IP Peer Networking Installation and Commissioning (NN43001-313)* () to re-configure SIP gateway endpoints.
- c. See Procedure 22 "Editing a Collaborative Server" (page 190) to re-configure collaborative servers.
- d. See BCM product documentation to re-configure BCM endpoints.
- e. See MCS 5100 product documentation to re-configure MCS 5100 endpoints.
- f. See *Nortel Converged Office Implementation Guide (NN43001-525)* () to re-configure Nortel Multimedia Convergence Manager (MCM).
- g. Consult the manufacturer's documentation to re-configure third party SIP phones .

End of task summary for upgrade procedure.

Recovery from failure of Linux-based NRS

To recover from a failure of Linux-based NRS

1. **Download** the latest **backup log** and the latest **backup file**.
 - See [Procedure 65 “Downloading the latest backup log file”](#) (page 271).
 - See [Procedure 64 “Downloading the latest backup file”](#) (page 268).
2. **Restore NRS database**.
 - See [“Restore the NRS database”](#) (page 271).

Operation and maintenance of Linux-based NRS

ATTENTION

A policy should be in place for automatic and manual backup of the NRS database. See [Procedure 62 “Backing up the database automatically”](#) (page 266) and [Procedure 63 “Backing up the database manually”](#) (page 267).

Access to NRS CLI commands

To access NRS CLI commands:

- Use a SSH client to log into the Linux-based NRS `nortel1` account. The `nortel1` account password is set during the installation of the Linux operating system.
 - Gatekeeper maintenance:
 - To start the Operation, Administration, and Maintenance oam shell type the full pathname to the oam script
`/opt/nortel/gk/bin/oamShell`
 - To start the Problem Determination Tools pdt shell type the full pathname to the pdt shell script
`/opt/nortel/gk/bin/pdtShell`
- Note:** A GK/NRS data upgrade must be performed before the Gatekeeper maintenance scripts can be run. To upgrade a Succession 3.0 H.323 Gatekeeper to a CS 1000 Release 4.0 (or later) NRS, see [“GK/NRS Data Upgrade”](#) (page 278).
- To manually invoke Failsafe NRS database synchronization type in the full pathname to the database synchronization script
`/opt/nortel/sps/scripts/failsafe.pl main`

SIP Proxy

Linux Commands

The following Linux commands are helpful in diagnosing SIP Proxy application issues:

- traceroute
- free
- ipcs
- ldconfig
- ping
- netstat
- ifconfig

Each of the above commands is described in the Linux man pages.

SIP Proxy Command

The syntax of the SIP Proxy `spcmd` command is:

usage: `spcmd [cmd family] [[parameter <value>]...]`

synopsis: `spcmd -[H|L|O|R|S|V] -[s|t|u|v] <defined value>]...`

Table 23
spcmd Command Description

Family	Parameter	Description
-L	-v debug info all	Write debug, info, or all (i.e. both) logs in addition to the sipLogFile.
	-s on off	Turn on/off the log types listed by the -v parameter. If no parameter is given, the default is set to on. Default is on.
-O	-v 400 401 407 hw ss	Display OM report for 400, 401, 407, or 3XX responses as well as the high water (hw) mark for internal queue memory usage and the number of SIP sessions (ss) that have been established.

-R	-s force wait now -t now 1..99 -u min sec	Execute a shutdown and restart of the application immediately or in some given time unit (min\sec) whether call are executing or not by either forcing the application or waiting for call processing to stop.
-S	-s force wait -t now 1..99 -u min sec	Execute a switching of activity from the running application processing to stop where a timer value can be given.
- V	-v app stack all	Show the version of the application, oSIP stack, or both.

Table 24
Script Commands

Name	Parameters	Description
chkreg	None	Display endpoint registration information
gwshow	None	Display of Endpoint information
l0dshow	None	Display level 0 domain information
l1dshow	None	Display level 1 domain information
qyshow	None	Display routing query entry information
ryshow	None	Display routing entry information
sdmshow	None	Display service domain information
urshow	None	Display user domain information
failsafe.pl	None	Execute the failsafe sync immediately

NRS Application Monitor Subsystem

MONIT is an open source package used for monitoring the important daemon services automatically initiated at startup. If a malfunction occurs, MONIT provides actions such as alert, start, stop, and restart. In order to provide these actions, applications must be registered with MONIT, and the appropriate actions for each application must be specified.

The SIP Proxy application will be registered with the MONIT application upon installation and startup of the application. MONIT will query the applications and processes related to the SIP Proxy and determine if the application must be shutdown or restarted.

The script to run MONIT is `/admin/nortel/base/log/monit_install.log`

H.323 Gatekeeper

There are no functional changes in the H.323 Gatekeeper CLI commands in CS 1000 RIs 5.0 or later, as compared with CS 1000 RIs 4.5.

Operation, Administration, and Maintenance oam commands Gatekeeper

- gkDiscoveryTrace
- gkRegTrace
- gkCallTrace
- gkProtocolTrace
- gkTraceOff
- gkTraceOutput
- gkTraceSettings
- gkTraceTbIClear
- gkTraceTbiShow

nrsDB

- nrsGWEndpointShow
- nrsUserEPShow
- nrsCollaboratingServerShow
- nrsL0DomainShow
- nrsL1DomainShow
- nrsRoutingEntryShow
- nrsServiceDomainShow
- nrsCollaboratingServerQuery
- nrsGWEndpointQuery
- nrsUserEPQuery
- nrsL0DomainQuery
- nrsL1DomainQuery

- nrsServiceDomainQuery
- nrsDefaultRouteQuery
- nrsDBShow
- nrsDBSyncForce
- nrsDBStateShow

nrsomm

- NrsOmmShow
- NrsOmmAvShow

System

- swVersionShow

Problem Determination Tools pdt commands

Gatekeeper

- gkDiscoveryTrace
- gkRegTrace
- gkCallTrace
- gkProtocolTrace
- gkTraceOff
- gkTraceOutput
- gkTraceSettings
- gkTraceTblClear
- gkTraceTblShow

nrsDB

- nrsGWEndpointShow
- nrsUserEPShow
- nrsCollaboratingServerShow
- nrsL0DomainShow
- nrsL1DomainShow
- nrsRoutingEntryShow
- nrsServiceDomainShow
- nrsCollaboratingServerQuery

- nrsGWEndpointQuery
- nrsUserEPQuery
- nrsL0DomainQuery
- nrsL1DomainQuery
- nrsServiceDomainQuery
- nrsDefaultRouteQuery
- nrsDBShow
- nrsDBSyncForce
- nrsDBStateShow
- disNRS
- forcedisNRS
- enINRS
- nrsGKTestQuery
- nrsSIPTestQuery

nrsomm

- NrsOmmShow
- NrsOmmAvShow

System

- syslogShow
- syslogLevelSet
- swVersionShow

Solid database commands

Database link synchronization

To ensure Linux-based Primary and Secondary database servers are synchronizing

- Log in to the **nortel** account on the Primary NRS server.

To Log in to the nortel account access the Linux command line through a telnet or SSH client, or locally attach an EIA232 terminal to the COM port.

The **nortel** account password is set during the installation of the Linux operating system.

- Run the command `/opt/nortel/solid/bin/hsbchk` from the Linux command line.

The Primary and Secondary databases are in the process of synchronizing, if the state of the Primary database server is "PRIMARY ACTIVE".

The link between the database servers may be down and the databases may not be synchronizing, if the state of the database server is "PRIMARY ALONE".

Failsafe NRS Synchronization

The Failsafe NRS synchronization script provides a manual command to invoke Failsafe NRS synchronization immediately, instead of waiting up to 6 hours for the Linux cron to invoke the scheduled Failsafe NRS synchronization. To manually invoke Failsafe NRS database synchronization type in the full pathname to the database synchronization script

```
/opt/nortel/sps/scripts/failsafe.pl main
```

Browser configuration

ATTENTION

Nortel discourages use of the Back, Forward, and Refresh buttons of the browser.

Use of the Back button is not recommended while the NRS Manager application is launched, because NRS Manager pages contain dynamic data content. NRS Manager provides a path for navigation purposes on top of every NRS Manager page.

Nortel recommends that the user click the navigation path to go back to the previous page (instead of using the Back button).

Configure the browser and display settings

Before you can use NRS Manager, the following tasks must be completed:

- Enable pop-ups in the browser search utility (mandatory).
- Configure the Internet Explorer browser settings (mandatory).
- Configure the Windows Display settings (highly recommended).

Note: The interface for the Internet Explorer browser settings and Windows Display settings may vary by browser version and by operating system.

Enable pop-ups

If you are using a browser search utility (such as the Google™ search engine or the Yahoo!™ search engine), ensure that pop-ups are enabled. Enabling pop-up windows is usually done at the search utility's toolbar.

ATTENTION

Do not block pop-up windows if you are using a search utility (such as Google™ or Yahoo!™ search engines) in your browser.

Configure the browser settings

See [Procedure 1 “Configuring the Internet Explorer browser settings” \(page 139\)](#) to configure the following Internet Explorer browser settings:

- Browser retrieve page information.
- Empty session information.
- Deselect the AutoComplete options.

Procedure 1**Configuring the Internet Explorer browser settings**

Step	Action
1	Select View > Text Size > Medium to configure text size in the browser.
2	Select Tools > Internet Options in the Internet Explorer browser window. The Internet Options window opens.
3	Configure the browser retrieve page information: <ol style="list-style-type: none"> a On the General tab under the Temporary Internet files section, click Settings. The Settings window opens. b Under the Check for newer versions of stored pages section, select the Every visit to the page option. c Click OK.
4	Configure the empty session information: <ol style="list-style-type: none"> a Select the Advanced tab. b Under Security, select Empty Temporary Internet Files folder when browser is closed.
5	Deselect the AutoComplete options. <ol style="list-style-type: none"> a Select the Content tab. b Under Personal Information, click AutoComplete. The AutoComplete Settings window opens. c Under the Use AutoComplete for section, deselect Forms and User names and passwords on forms. Click OK (to close the AutoComplete Settings window)

Click **OK** (to close the **Internet Options** window)

--End--

Configure the Windows Display settings

See [Procedure 2 “Configuring the Windows Display settings” \(page 140\)](#) to configure the Windows display settings.

Procedure 2 Configuring the Windows Display settings

Step	Action
1	Select Start > Settings > Control Panel > Display . The Display Settings window opens.
2	Select the Settings tab.
3	Select True Color (32 bit) from the Colors drop-down list.
4	Under Screen area , select 1280 by 1024 pixels .
5	Click OK .

--End--

Log in to ECM and Access NRS Manager

Access NRS Manager through the ECM . See [Procedure 3 “Logging in to ECM and Accessing NRS Manager” \(page 140\)](#).

Two types of access privileges are supported:

- Administrative privileges — Administrators have full read/write privileges. An administrator can view and modify NRS configuration data.
- Monitor privileges — Monitors have read-only privileges. A Monitor can only view the NRS configuration data.


Procedure 3 Logging in to ECM and Accessing NRS Manager

Step	Action
1	Open a Web browser.

- 2 In the Address bar of the Web browser enter the Fully Qualified Domain Name (FQDN) of an ECM server that is a member of the security domain that the NRS server is a member of.

Note: The link to the FQDN of the ECM server can be bookmarked in the Internet Explorer Favorites list. See Figure 34 "Link to FQDN" (page 141).

Figure 34
Link to FQDN



The Security Alert web page opens. See Figure 35 "Security Alert web page" (page 141). Click the **Yes** button.

Figure 35
Security Alert web page



- 3 The ECM log in web page opens. See Figure 36 "ECM log in web page" (page 141).

Figure 36
ECM log in web page



Enter **User Name** and **Password** in the text boxes. Click the **Log in** button.


If this is your first time logging in, you will be prompted to change your password. See [Figure 37 "Change Password web page" \(page 142\)](#).

Figure 37
Change Password web page



4 The ECM Elements web page opens. See [Figure 38 "ECM Elements web page" \(page 142\)](#). Click the link to the NRS Manager in the **Element Name** column.


Figure 38
ECM Elements web page



ElementName	System Type	Address	Description
CS1000E-NRS	Network RoutingService	192.167.103.11	Linux NRSM
CS1000E-FIV	CS1000 Release 5	192.167.102.3	Pentium IV, Node 9
CS1000E-FM11	CS1000 Release 5	192.167.104.53	CS1000E CP-FM, Node 11

The NRS server web page opens, as shown in [Figure 39 "NRS Server web page" \(page 143\)](#).

Figure 39
NRS Server web page



--End--

NRS Manager interface

NRS Manager Navigator

The **NRS Manager Navigator**, located on the left side of the NRS Manager web pages, contains links to other web pages. **Common Manager**, the root of the NRS Manager Navigator, is a link to the ECM web page. The **NRS Manager Navigator** is comprised of three main branches: **System**, **Numbering Plans**, and **Tools**.

The **System** branch contains links to

- NRS Server
- Database
- System Wide Settings

The **Numbering Plans** branch contains links to

- Domains (Service, L1 and L0 Domains)
- Endpoints (Gateway and User Endpoints)
- Routes
- Network Post-Translation
- Collaborative Servers


The **Tools** branch contains links to

- SIP Phone Context
- H.323 Routing Test
- SIP Routing Test

- (Database) Backup
- (Database) Restore
- GK/NRS Data upgrade

In [Figure 40 "NRS Manager Navigator" \(page 144\)](#), the NRS Manager Navigator is expanded to display all available links.

Figure 40
NRS Manager Navigator



Navigation of NRS Manager web pages

There are three navigation areas in NRS Manager web pages:

1. NRS Manager Navigator

The NRS Manager navigation tree, shown in [Figure 40 "NRS Manager Navigator" \(page 144\)](#), is located on the left side of NRS Manager web pages. It contains links to other web pages. The web pages are opened by clicking a branch of the NRS Manager navigation tree.

2. Navigation Path.

The navigation path is located at the top of NRS Manager web pages. For example, to add an L0 Domain open the **Add L0 Domain** web page shown in [Figure 69 "Add L0 Domain web page" \(page 176\)](#). The navigation path for this web page is **Numbering Plans >> Domains >> L0 Domain**. To open a parent web page click on a link in the navigation path.

3. Numbering Plans web pages.

The **Numbering Plans** web page shown in [Figure 41 "Numbering Plans web page" \(page 145\)](#), contains links to Domain, Endpoints,

Routes, Network Post-Translation and Collaborative Servers web pages. Click on a link to open a web page.

Figure 41
Numbering Plans web page

Numbering Plans

Numbering plan is the key step for users to define numbering plan strategy for the whole network. It involves defining the domains, endpoints, associated routing entries, network post-translations and collaborative servers.

Domains
Domains establish the basic structure of your converged network, defined by Service Domains, L1 (CDP) Domains and L0 (JDP) Domains

Totally configured Service Domains: 1
Totally configured L1 Domains: 1
Totally configured L0 Domains: 1

Endpoints
Configure gateway and user endpoint within each domain.

Totally configured Gateway Endpoints: 1
Totally configured User Endpoints: 1

Routes
Create, maintain and test routing plans for gateway endpoints, including default routes.

Totally configured Routing Entries: 1
Totally configured Default Routes: 0

Each of the Numbering Plans component summary web pages contain links to other web pages. For example, the **Service Domains** web page, shown in [Figure 52 "Service Domains pane" \(page 160\)](#), contains columns entitled # of L1 Domains, # of L0 Domains, and # of Gateway Endpoints. Click on one of the links in those columns to go to the associated subcomponent summary page of a Service Domain.

Navigation examples

1. Go from **Add L0 Domain** web page to **Service Domains** web page.
 - a. In the **NRS Manager Navigator** select **Numbering Plans > Domains**.
 - Or
 - b. Click on **Domains** in the **Numbering Plans >> Domains >> L0 Domain** navigation path.
2. Add a Gateway endpoint
 - a. In the **NRS Manager Navigator** select **Numbering Plans > Endpoints**.
 - b. Ensure **Standby database** is selected.
 - c. The **Limit results to Domain:** drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
 - d. Click the **Gateway Endpoints** tab.
 - e. Click the **Add....** button.

Or

3. Add a Gateway endpoint from
 - **Service Domains** web page shown in [Figure 52 "Service Domains pane" \(page 160\)](#).
 - or
 - **L1 Domains** web page shown in [Figure 60 "L1 Domains pane" \(page 167\)](#).
 - or
 - **L0 Domains** web page shown in [Figure 68 "L0 Domain \(CDP\) pane" \(page 175\)](#).
 - a. Ensure **Standby database** is selected.
 - b. Click a link in the **# of Gateway Endpoints** column.
 - c. Select correct domain path from the **Limit results to Domain:** drop-down lists.
 - d. Click the **Add....** button.

NRS Manager features

1. **Sort Numbering Plans** web pages by ascending or descending order.
 - The **ID** column in the Service Domains, L1 Domains, L0 Domains, Gateway Endpoints and User Endpoints web pages can be sorted by ascending or descending alphabetical order.
 - The **DN Prefix** column in the Routing Entries web page can be sorted by ascending or descending numerical order.
 - The **DN type** column in the Default Routes web page can be sorted by ascending or descending alphabetical order.
 - The **Originating Endpoint** column in the Network Post-Translation web page can be sorted by ascending or descending alphabetical order
 - The **Server Fully Qualified Domain** column in the Collaborative Servers web page can be sorted by ascending or descending alphabetical order.

Click on the column link to invert the sort order on the Numbering Plans web page. The Service Domains shown in [Figure 42 "Descending Alphabetical sort order" \(page 147\)](#) are sorted in descending alphabetical order.

Figure 42
Descending Alphabetical sort order

Description	# of L0 Domains	# of Gateway Endpoints	# of Routing Entries	Content
uda	1	1	2	quantum1.com
mlUdpDomain	0	0	0	quantum1.com

2. Filter by Domain

- The L1 Domains for all Service Domains can be displayed in the **L1 Domains (UDP)** web page. Or the L1 Domains for a specific Service Domain can be displayed in the **L1 Domains (UDP)** web page by selecting the Service Domain from the **Filter by Domain:** drop-down list.
- The L0 Domains for all Service Domains and all L1 Domains can be displayed in the **L0 Domains (UDP)** web page. Or the L0 Domains for a specific Service Domain and/or L1 Domain can be displayed in the **L0 Domains (UDP)** web page by selecting the Service Domain and/or L1 Domain from the **Filter by Domain:** drop-down lists.
- The Network Post-translations for all Service Domains can be displayed in the **Network Post-Translation** web page. Or the Network Post-translations for a specific Service Domain can be displayed in the **Network Post-Translation** web page by selecting the Service Domain from the **Filter by Domain:** drop-down list.

3. Limit results to Domain

- The Gateway and User Endpoints for all Service Domains and all L1 Domains and all L0 Domains can be displayed in the **Endpoints** web page. Or the Gateway and User Endpoints for a specific Service Domain and/or L1 Domain and/or L0 Domain can be displayed in the **Endpoints** web page by selecting the Service Domain and/or L1 Domain and/or L0 Domain from the **Limit results to Domain** drop-down lists.
- Routing entries for all Service Domains and all L1 Domains and all L0 Domains and all Gateway Endpoints can be displayed in the **Routing Entries** and **Default Routes** web pages. Or the Routing entries for a specific Service Domain and/or L1 Domain and/or L0 Domain and/or Gateway Endpoint can be displayed in the **Routing Entries** web page by selecting the Service Domain and/or L1 Domain and/or L0 domain from the **Limit results to Domain** drop-down lists and/or the Gateway Endpoint from the **Endpoint Name:** drop-down list.

4. Pagination

The entries tabulated on the Service Domains, L1 Domains (UDP), L0 Domains (CDP), Gateway and User Endpoints, Routing Entries and

Default Routes, Network Post-Translation and Collaborative Servers web pages may not fit on one page. Navigate to the First, Previous, Next or Last page by using the pagination links on the right side of the web page footer, shown in [Figure 43 "Pagination" \(page 148\)](#).

Figure 43
Pagination

First| Previous| Next| Last

5. The following functionality has been added to the NRS Manager User Interface in Release 5.5
 - The NRS Manager Navigator can be expanded to the lowest leaf level of each node by clicking on the root node.
 - A **Hide** and **Show** link is introduced into the Endpoints and Routes web pages. Clicking on the **Hide** link removes the search criteria panel from the web pages, providing a larger panel for the display of the Routing Entries and Endpoints.

Mandatory fields on NRS Manager web pages

Mandatory fields on NRS Manager web pages are denoted by an *. All other fields on NRS Manager web pages are optional.

Numbering Plans inherited fields

The NRS database provides a central database of addresses that are required to route calls across the network. The NRS uses the hierarchical model outlined in Table 2 "Hierarchical model of the Network Routing Service" (page 29) to store and organize information in the database. In this hierarchical model

- an L1 domain is a subdomain of a Service domain
- an L0 domain is a subdomain of an L1 domain
- Gateway and User endpoints exist within an L0 domain
- a Routing entry represents a range of addresses (URIs) where a gateway can terminate calls. A routing entry exists within a Gateway

In provisioning the NRS, an L1 domain, an L0 domain and a Gateway endpoint can inherit configuration parameters from its parent. The inherited fields are:

- Endpoint authentication enabled
- Authentication password
- E.164 country code
- E.164 area code

- E.164 international dialing access code
- E.164 international dialing code length
- E.164 national dialing access code
- E.164 national dialing code length
- E.164 local (subscriber) dialing access code
- E.164 local (subscriber) dialing code length
- Private L1 domain (UDP location) dialing access code
- Private L1 domain (UDP location) dialing code length
- Special number
- Special number dialing code length
- Emergency service access prefix

Benefits of inherited fields

The benefits of inherited fields are:

- An inherited field that is provisioned in a parent component does not have to be explicitly provisioned in sublevel components
- An inherited field can be redefined in a sublevel component with a value that overwrites the value inherited from its parent

Help and Logout links

The **Help** and **Logout** links are located on the right side of the NRS Manager web page header. See [Figure 44 "Help and Logout Links" \(page 149\)](#).

Figure 44
Help and Logout Links



Help link

Select the **Help** link to access the **NRS Manager Help Files**.

NRS Manager provides context-sensitive help. That is, the help page displayed depends on the NRS Manager web page from which it is opened. Once a help page is opened, click the **Show** link in the upper left corner of the page to display the **Contents** and an **Index** of the **NRS Manager Help Files**.

Logout link

Select the **Logout** link to terminate the current Enterprise Common Manager session. See [Procedure 4 “Logging out of ECM ” \(page 150\)](#).


Common Manager link

Select the **Common Manager** link on the **NRS Manager Navigator** to return to the ECM web page without terminating the current ECM session. See [“NRS Manager interface” \(page 143\)](#).

Log out of ECM

See [Procedure 4 “Logging out of ECM ” \(page 150\)](#) to log out of the ECM . Logging out of the ECM terminates the current session.

Procedure 4 Logging out of ECM

Step	Action
1	<p>Click the Logout link on the right side of the NRS Manager web page header.</p> <p>The Enterprise Common Manager Logout successful web page opens.</p> <p>Figure 45 Enterprise Common Manager Logout successful web page</p> 
2	<p>Close the browser window.</p>

--End--

Configure the Primary and Secondary NRS Server Settings

The NRS Server Settings comprise:

- NRS Settings: These are generic settings applicable to H.323, SIP, and Network Connection Service.
- H.323 Gatekeeper Settings
- SIP Server Settings
- Network Connection Server (NCS) Settings

ATTENTION

The primary and secondary NRS servers must be configured one by one. The user **must** be logged on the specific (either primary or secondary) server to configure it. See [Step 4 of Procedure 3 "Logging in to ECM and Accessing NRS Manager"](#) (page 140).

Procedure 5 Configuring the Primary and Secondary NRS Server Settings

- | Step | Action |
|------|---|
| 1 | In the NRS Manager Navigator select System > NRS Server .
The NRS Server web page opens. |
| 2 | To configure the NRS Server Settings , click the Edit button in the Server Configuration pane of the NRS Server web page. The Edit Server Configuration web page opens, as shown in Figure 46 "Edit Server Configuration web page" (page 151). |

Figure 46**Edit Server Configuration web page**

The screenshot shows the 'Edit Server Configuration' page in the NRS Manager. The left sidebar contains a navigation menu with categories like 'Common Manager', 'System', 'Numbering Plans', 'Tools', and 'H.323 Gatekeeper Settings'. The main content area is titled 'Edit Server Configuration' and contains the following fields:

- Hostname: HostName
- Primary TLAN IP address: 0.0.0.0
- Secondary TLAN IP address: 0.0.0.0
- Secondary server host name: SecondaryHostName
- Control priority: 40
- Server male communication port: 5005
- Realm name: realmName
- Server role: Primary
- H.323 Gatekeeper Settings: Location request (LRQ) response timeout: 3 seconds

- 3 Configure the **NRS Server Settings**:
- Host name:** Enter the Primary server host name in the text box. The host name must be alphanumeric and can be up to 20 characters in length.
 - Primary TLAN IP address:** Enter the IP address of the Primary NRS (that is, the TLAN network interface IP address) in the text box. The default is 0.0.0.0.
 - Secondary TLAN IP address:** Enter the IP address of the Secondary NRS (that is, the TLAN network interface IP address), in the text box. The default is 0.0.0.0.
 - Secondary server host name:** Enter the Secondary server host name in the text box.
 - Control priority:** Enter a value for the control priority in the text box. This is a priority bit setting inside the protocol that determines the signaling routing priority. The range is 0 to

63. The default value is 40. The control priority must be a numeric value.
- f Server mate communication port:** Enter a value for the Server mate communication port in the text box. The Server mate communication port is numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 50005.
 - g Realm name:** Enter a value for the Realm name in the text box. The Realm name is alphanumeric and can be up to 20 characters in length.
 - h Server role:** Choose **Primary** or **Secondary** from the drop down list.
- 4** To configure **H.323 Gatekeeper Settings** scroll down to the H.323 Gatekeeper Settings section of the Edit Server Configuration web page. See [Figure 46 "Edit Server Configuration web page" \(page 151\)](#).
- a** Set the LRQ response timeout parameter by selecting a value from the **Location request (LRQ) response timeout [Seconds]** drop-down list. The minimum value is 1 second and the maximum value is 10 seconds. The default value is 3 seconds.
- 5** To configure **SIP Server Settings** scroll down to the SIP Server Settings section of the Edit Server Configuration web page. See [Figure 46 "Edit Server Configuration web page" \(page 151\)](#).
- a** Select **Proxy** from the **Mode** drop-down list. This is the mode of the SIP Server. A SIP Proxy acts as both a server and a client. A SIP Proxy receives requests, determines where to send the requests, and acting as a client on behalf of SIP endpoints passes requests on to another server.
 - b** Enter the **Public name for non-trusted networks** in the text box.
 - c** Enter the **Public number for non-trusted networks** in the text box.
 - d** Select the transport protocol.

ATTENTION

If a Release 5.0 or later Linux-based NRS is installed in a network with 4.x CS1000 gateways, the UDP transport protocol has to be enabled. It is recommended that the UDP transport protocol be enabled on a Release 5.0 or later Linux-based NRS, since UDP is the default protocol. To enable the other transport protocols the UDP transport protocol should be enabled.

To enable UDP:

1. Select the **UDP transport enabled** check box.
2. Enter the **Primary server UDP IP** in the text box.
3. Enter the **Primary server UDP port** in the text box. The UDP port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5060.
4. Enter the **Secondary server UDP IP** in the text box.
5. Enter the **Secondary server UDP port** in the text box. The UDP port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5060.
6. Enter the **UDP maximum transmission unit (MTU)** in the text box. MTU is the maximum size of an Ethernet Layer 2 packet going out on the IP network. In this context, MTU is the maximum size of a SIP packet that is sent out on the UDP interface. The default value is 1500 bytes. The maximum value for MTU is 64K. When configuring the MTU, remember that there is a trade-off between packet size and the number of packets that have to be transmitted over the network.

To enable TCP:

1. Select the **TCP transmission enabled** check box.
2. Enter the **Primary server TCP IP** in the text box.
3. Enter the **Primary server TCP port** in the text box. The TCP port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5060.
4. Enter the **Secondary server TCP IP** in the text box.
5. Enter the **Secondary server TCP port** in the text box. The TCP port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5060.
6. Enter the **TCP maximum transmission unit (MTU)** in the text box. MTU is the maximum size of an Ethernet Layer 2 packet going out on the IP network. In this context, MTU is the maximum size of a SIP packet that is sent out on the TCP interface. The default value is 1500 bytes. The maximum value for MTU is 64K. When configuring the MTU, remember that there is a trade-off between packet size and the number of packets that have to be transmitted over the network.

To enable TLS:

1. Select the **TLS transmission enabled** check box.
2. Enter the **Primary server TLS IP** address in the text box.
3. Enter the **Primary server TLS port** in the text box. The TLS port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5061.
4. Enter the **Secondary server TLS IP** address in the text box.
5. Enter the **Secondary server TLS port** in the text box. The TLS port must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port number is 5061.
6. Enter the **TLS maximum transmission unit (MTU)** in the text box. MTU is the maximum size of an Ethernet Layer 2 packet going out on the IP network. In this context, MTU is the maximum size of a SIP packet that is sent out on the TLS interface. The default value is 1500 bytes. The maximum value for MTU is 64K. When configuring the MTU, remember that there is a trade-off between packet size and the number of packets that have to be transmitted over the network.

- 6 To configure **Transport Layer Security (TLS) Settings** scroll down to the Transport Layer Security (TLS) Settings section of the Edit Server Configuration web page. See [Figure 47 "Transport Layer Security \(TLS\) Settings and Network Connection Server \(NCS\) settings"](#) (page 155).
 - a Enter **Maximum session cache** in text box.
 - b Enter **Session cache timeout** in text box.
 - c Enter **Renegotiation in byte** in text box.
 - d Select the **X509 Certificate authority** check box.
 - e Select the **Client authority** check box.

Figure 47
Transport Layer Security (TLS) Settings and Network Connection Server (NCS) settings

- 7** To configure **Network Connection Server (NCS) Settings** scroll down to the Network Connection Server (NCS) Settings section of the Edit Server Configuration web page. See [Figure 47 "Transport Layer Security \(TLS\) Settings and Network Connection Server \(NCS\) settings"](#) (page 155)
- a Primary NCS port:** Enter a port number for the Primary NCS in the text box. The port number must be numeric and can be up to five digits in length. The range is 1024 to 65535. The default value is 16500.
 - b Secondary NCS port:** Enter a port number for the Secondary NCS in the text box. The port number must be numeric and up to five digits in length. The range is 1024 to 65535. The default value is 16500.
 - c Primary NCS timeout [Seconds]:** Select a timeout value for the Primary NCS from the drop-down list. The minimum value is 1 second and the maximum value is 30 seconds. The default value is 10 seconds.
- Note:** The NCS Settings are used for the Branch Office (including the Survivable Remote Gateway [SRG]), Virtual Office, and Geographic Redundancy features.
- 8** Click the **Save** button.
- 9** The NRS Server web page reopens. Select at least one element on the **Service Status** pane of the **NRS Server** web page and click the **Restart** button.

--End--

Configure system-wide settings

The **System-wide settings** web page is used (1) to configure system-wide settings and (2) to schedule backup jobs. System-wide settings include:

- SIP registration and H.323 Gatekeeper registration Time-to-Live timer settings.
- H.323 Gatekeeper alias name.
- Automatic backup time setting.
- Whether automatic backup to an FTP site is enabled. If enabled, the IP address, path, and username for the FTP site must be provided.


See [Procedure 6 “Configuring system-wide settings” \(page 156\)](#) to configure system-wide settings.

Procedure 6 Configuring system-wide settings

Step	Action
1	In the NRS Manager Navigator select System > System Wide Settings .

The **System Wide Settings** web page opens. See [Figure 48 “System Wide Settings web page” \(page 156\)](#).

Figure 48
System Wide Settings web page



2 Enter values for the Time-to-Live timers.

- a Enter a value in the **SIP registration time to live timer [Seconds]** text box. Nortel recommends that the timer be set to 30 seconds. The range is 30 to 3600 seconds.
 - b Enter a value in the **H.323 gatekeeper registration time to live timer [Seconds]** text box. Nortel recommends that the timer be set to 30 seconds. The range is 30 to 3600 seconds.
- 3 Enter the alias name of the H.323 Gatekeeper in the **H.323 alias name** text box. This is a mandatory field. The alias name must be alphanumeric, can be up to 30 characters in length, and cannot have spaces.

To send out Location Requests (LRQ), the H.323 Gatekeeper must have an H.323 Gatekeeper alias name. An H.323 Gatekeeper alias name is also referred to as an H323-ID.
- 4 Enter the time when the database backup will automatically occur in the **Auto backup time [HH:MM]** text box.
- 5 Complete the following steps to automatically back up the NRS database to an FTP site.
 - a Select the **Auto backup to secure FTP site enabled** check box.
 - b Enter the IP address of the FTP site in the **Auto backup to secure FTP site's IP address** text box.
 - c Enter the path to the FTP site in the **Auto backup secure FTP site's path** text box. The FTP site path must be alphanumeric and can be up to 120 characters in length.
 - d Enter the user name used to access the FTP site in the **Auto backup secure FTP user name** text box. The FTP user name must be alphanumeric and can be up to 30 characters in length.
 - e Enter the password used to access the FTP site in **Auto backup secure FTP password** text box. The FTP password must be alphanumeric and can be up to 24 characters in length but cannot include the single quote (') symbol.
- 6 Click the **Save** button.

--End--

Configure the NRS database

The NRS (Solid) database is used by both the SIP Proxy/Redirect Server and the H.323 Gatekeeper. For more information on the NRS database see ["Database component" \(page 29\)](#).

Task summary list

See the procedures in this section to configure the NRS database.

- [Procedure 7 “Switching between the Active and Standby databases” \(page 159\)](#)
- [Procedure 8 “Adding a Service Domain” \(page 160\)](#)
- [Procedure 12 “Adding an L1 Domain” \(page 166\)](#)
- [Procedure 16 “Adding an L0 Domain \(CDP\)” \(page 175\)](#)
- [Procedure 24 “Adding a Gateway Endpoint” \(page 193\)](#)
- [Procedure 39 “Adding a Routing Entry” \(page 224\)](#)
- [Procedure 20 “Adding a Collaborative Server” \(page 184\)](#)
- [Procedure 58 “Cutting over the database” \(page 263\)](#)
- [Procedure 61 “Committing the database” \(page 265\)](#)

Note 1: To add a SIP Phone as a User Endpoint refer to [Procedure 33 “Adding a User Endpoint” \(page 213\)](#).

Note 2: The standby database is used to modify the configuration data. Changes made to the standby database do not immediately effect call processing. Before changes made to the standby database effect call processing, the active and standby databases must be swapped by executing a database **Cut over** command.

Switch between the Active and Standby databases

The database has two schemas, Active and Standby. For more information see [“Database synchronization/operation component” \(page 38\)](#).

- The Active database is used for runtime location queries by SIP Proxy, Gatekeeper and NCS.
- The Standby database is used for administrator modifications.


Note: By default, the database is in Active database view when the **Domains** web page is first opened. To modify the database it must be in Standby database view. Only users with administrative authority can modify the database.

Below the NRS Manager header in the Numbering Plans branch of the NRS Manager navigator is an area for switching between the Active and Standby databases. See [Procedure 7 “Switching between the Active and Standby databases” \(page 159\)](#) to switch between the Active and Standby database.

Procedure 7 Switching between the Active and Standby databases


Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).

Figure 49
Domains web page



- 2 Click **Standby database** to switch to the Standby database. See [Figure 50 "Active database selected"](#) (page 159). The Standby database is used for database modifications.


Figure 50 Active database selected



or

- 3 Click **Active database** to switch to the Active database. See [Figure 51 "Standby database selected"](#) (page 159). The Active database is used for database queries.

Figure 51 Standby database selected



--End--

Note: Procedure 8 “Adding a Service Domain” (page 160) to Procedure 39 “Adding a Routing Entry” (page 224) use the example hierarchy (myServiceProvider.com, myCompany.com, and so on) provided in the “Network Routing Service overview” (page 15) chapter.

Manage a Service Domain

The Service Domain is a building block of the routable SIP URI. It represents the service domain name field in the URI (see “SIP Uniform Resource Identifiers” (page 34)). For more information on Service Domains see Figure 4 “Hierarchy of the NRS database components” (page 31).

Add a Service Domain

Use the following procedure to add a service domain.

Procedure 8 Adding a Service Domain

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 “Domains web page” (page 159).
2	Ensure Standby database is selected. See Procedure 7 “Switching between the Active and Standby databases” (page 159).

The **Domains** web page refreshes displaying the **Service Domains** pane, as shown in Figure 52 “Service Domains pane” (page 160).

Figure 52
Service Domains pane



3 Click the **Add...** button.

The **Add Service Domain** web page opens, as shown in Figure 53 “Add Service Domain web page” (page 161).

Figure 53
Add Service Domain web page

- 4 Enter a **Domain name** for the Service Domain in the text box. For example, enter myServiceProvider.com.
- 5 Enter a **Domain description** for the Service Domain in the text box.
- 6 Click the **Save** button. The standby database is updated.

The **Service Domains** web page opens, showing the newly added myServiceProvider.com Service Domain. See [Figure 54 "Added Service Domain"](#) (page 161).

Figure 54
Added Service Domain

ID	Description	# of L1 domains	# of L0 domains	# of gateway endpoints
1	ccsipo.com	1	1	2
2	myServiceProvider	0	0	0

- 7 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 8 Test the configuration changes.
- 9 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--


View the Service Domain

Use the following procedure to view the service domains.

Procedure 9 Viewing the Service Domains

Step	Action
1	<p>In the NRS Manager Navigator select Numbering Plans > Domains. The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).</p> <p>The Service Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .</p>
2	<p>Select the Active or Standby database. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time.</p> <p>The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 55 "Service Domains pane Active Database" (page 162).</p>


Figure 55
Service Domains pane Active Database



- 3 Click a link in the **ID** column of the **Service Domains** pane.
- The **Edit Service Domain** web page opens and displays the configured data for the selected Service Domain, as shown in [Figure 56 "Edit Service Domains web page Active Database"](#) (page 163).

Note: See [Procedure 10 "Editing a Service Domain"](#) (page 163) to Edit the Service Domain.

Figure 56
Edit Service Domains web page Active Database



--End--


Edit a Service Domain

Use the following procedure to edit a service domain.

Procedure 10 Editing a Service Domain

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159) . The Service Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) . The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160) .
3	Click a link in the ID column of the Service Domains pane. The Edit Service Domain web page opens, as shown in Figure 57 "Edit Service Domain web page" (page 164) .

Figure 57
Edit Service Domain web page



- 4 Modify the **Domain name** or the **Domain description** .
- 5 Click the **Save** button. The standby database is updated.
 The **Service Domains** web page opens, as shown in [Figure 52 "Service Domains pane"](#) (page 160).
- 6 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 7 Test the configuration changes.
- 8 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

Delete a Service Domain

Use the following procedure to delete a service domain.

Procedure 11 Deleting a Service Domain

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159). The Service Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160).

- 3 Select a check box beside one or more configured **Service Domains** in the **ID** column of the **Service Domains** pane.
- 4 Click **Delete**.

A **Confirmation Box** opens requesting confirmation before deleting the selected **Service Domain**.

Figure 58
Confirmation Box




- 5 Click **OK**.

If there is **not** an associated **L1 Domain** or **Collaborative Server** configured, the standby database is updated and the **Domains** web page refreshes displaying the **Service Domains** pane, as shown in [Figure 52 "Service Domains pane"](#) (page 160).

If there is an associated **L1 Domain** or **Collaborative Server** configured, the **Service Domain** can not be deleted and an error message is displayed.

Figure 59
Delete Service domain error message



The associated **L1 Domain** or **Collaborative Server** must be deleted before the **Service Domain** can be deleted.

See [Procedure 15 "Deleting an L1 Domain \(UDP\)"](#) (page 173) to delete the associated **L1 Domain**.

See [Procedure 23 "Deleting a Collaborative Server"](#) (page 192) to delete the associated **Collaborative Server**.

- 6 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state.

- 7 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes

--End--

Manage a Level 1 Domain (UDP)

The Level 1 (L1) Domain is a building block of the phone context for private addresses. It is the phone context root. For more information on phone context, see ["SIP Uniform Resource Identifiers"](#) (page 34). For more information on L1 Domains, see [Figure 4 "Hierarchy of the NRS database components"](#) (page 31).


Add an L1 Domain (UDP)

Use the following procedure to add an L1 Domain (UDP).

Procedure 12 Adding an L1 Domain

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160).
3	Click L1 Domains (UDP) drop-down list. The Domains web page refreshes displaying the L1 Domains (UDP) pane, as shown in Figure 53 "L1 Domains (UDP) pane" (page 160). The L1 Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .

Figure 60
L1 Domains pane




- 4 The **Filter by Domain:** drop-down list contains configured Service Domains. Select the **Service Domain**, where the new L1 subdomain will be added, from the drop-down list.

- 5 Click the **Add...** button.

The **Add L1 Domain** web page opens, as shown in [Figure 61 "Add L1 Domain web page"](#) (page 167).

Figure 61
Add L1 Domain web page



- 6 Enter the **Domain name** of the L1 Domain in the text box. The name must be alphanumeric and can be up to 30 characters in length.

For example, enter myCompany.com.

- 7 Enter the **Domain description** in the text box. The description can include any character except single quotes and can be up to 120 characters in length.

Note: An L1 Domain can inherit configuration parameters from its parent Service Domain. See [“Numbering Plans inherited fields” \(page 148\)](#).
- 8 Select **Authentication on** or **Authentication off** from the **Endpoint authentication enabled** drop-down list.


If **Authentication on** is selected, then all endpoints require authentication.
- 9 Enter the **Authentication password** in the text box, if **Authentication on** was selected in [step 8](#). The password must be alphanumeric and can be up to 24 characters in length.
- 10 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to 30 digits in length.
- 11 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to 30 digits in length.
- 12 Any SIP endpoint that does not support SIP phone context should include prefix to dialed numbers in a prefix in the **E.164 international dialing access code** text box, so that NRS can resolve them. The code must be numeric and can be up to eight digits in length.
- 13 Enter the **E.164 international dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 international dialing access code length.
- 14 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 15 Enter the **E.164 national dialing access code length** in the text box. The code length must be numeric and has to exceed the E.164 national dialing access code length.
- 16 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 17 Enter the **E.164 local (subscriber) dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 local (subscriber) dialing access code length.
- 18 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 19 Enter the **Private L1 domain (UDP location) dialing code length** in the text box. The code length must be numeric and

has to exceed the Private L1 domain (UDP location) dialing access code length.

- 20 Enter the **Special number** in the text box. The number must be numeric and can be up to 30 digits in length.
- 21 Enter the **Special number dialing code length** in the text box. The code length must be numeric and equal to the Special number length.
- 22 Enter the **Emergency service access prefix** in the text box. The number must be numeric and can be up to 30 digits in length.
- 23 Enter the **Special number label** in the text box. The label must be alphanumeric and can be up to 30 characters in length.
- 24 Click the **Save** button. The standby database is updated.

The **Domains** web page opens, showing the newly added myCompany.com L1 domain in the myServiceProvider.com Service Domain. See [Figure 62 "Added L1 Domain" \(page 169\)](#).

Figure 62
Added L1 Domain



- 25 See [Procedure 58 "Cutting over the database" \(page 263\)](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 26 Test the configuration changes.
- 27 See [Procedure 61 "Committing the database" \(page 265\)](#) to update the database with the configuration changes.

--End--

View an L1 Domain (UDP)

Use the following procedure to view an L1 Domain (UDP).

Procedure 13
Viewing an L1 Domain (UDP)


- | Step | Action |
|------|---|
| 1 | In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159). |
| 2 | Select the Active or Standby database. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time.

The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 55 "Service Domains pane Active Database" (page 162). |
| 3 | Click L1 Domains (UDP) drop-down list.

The Domains web page refreshes displaying the L1 Domains (UDP) pane, as shown in Figure 63 "L1 Domains (UDP) pane Active database" (page 170).

The L1 Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) . |

Figure 63
L1 Domains (UDP) pane Active database




- The **Filter by Domain:** drop-down list contains configured Service Domains. Select the **Service Domain**, that the L1 domain is a subdomain of, from the drop-down list. The **Domains** web page refreshes.
- Click a **link** in the **ID** column of the L1 domains (UDP) web page. The **Edit L1 Domain** web page opens and displays the configured data for the selected L1 Domain, as shown in [Figure](#)

64 "Edit L1 Domain (UDP) web page Active database" (page 171).

Note: See Procedure 14 “Editing an L1 Domain (UDP)” (page 171) to Edit the L1 Domain.

Figure 64
Edit L1 Domain (UDP) web page Active database



--End--

Edit an L1 Domain (UDP)

Use the following procedure to edit an L1 Domain (UDP).

Procedure 14 Editing an L1 Domain (UDP)

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) . The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160) .
3	Click L1 Domains (UDP) drop-down list.

The **Domains** web page refreshes displaying the **L1 Domains (UDP)** pane, as shown in [Figure 60 "L1 Domains pane" \(page 167\)](#).

The L1 Domains can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID" \(page 146\)](#).

- 4 The **Filter by Domain:** drop-down list contains configured Service Domains. Select the **Service Domain**, where the L1 subdomain will be edited, from the drop-down list.
- 5 Click on a link in the **ID** column of the **L1 Domains (UDP)** pane.

The **Edit L1 Domain** web page opens, as shown in [Figure 65 "Edit L1 Domain web page" \(page 172\)](#).

Figure 65
Edit L1 Domain web page

- 6 Modify the fields of the **Edit L1 Domain** web page as appropriate. See ["Manage a Level 1 Domain \(UDP\)" \(page 166\)](#).

Note: An L1 Domain can inherit configuration parameters from its parent Service Domain. See ["Numbering Plans inherited fields" \(page 148\)](#).

- 7 Click the **Save** button.
The standby database is updated. The **Domains** web page opens displaying the **L1 Domains (UDP)** pane, as shown in [Figure 60 "L1 Domains pane" \(page 167\)](#).
- 8 See [Procedure 58 "Cutting over the database" \(page 263\)](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 9 Test the configuration changes.

- 10 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--


Delete an L1 Domain (UDP)

Use the following procedure to delete an L1 Domain (UDP).

Procedure 15 Deleting an L1 Domain (UDP)

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160).
3	Click L1 Domains (UDP) drop-down list. The Domains web page refreshes displaying the L1 Domains (UDP) pane, as shown in Figure 60 "L1 Domains pane" (page 167). The L1 Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
4	The Filter by Domain: drop-down list contains configured Service Domains. Select a Service Domain from the drop-down list.
5	Select a check box beside one or more configured L1 Domains in the ID column of the L1 Domains (UDP) pane.
6	Click the Delete button. A Confirmation Box opens requesting confirmation before deleting the selected L1 Domain .

**Figure 66
Confirmation Box**




- 7 Click **OK**.

If there is **not** an associated **L0 Domain** or **Collaborative Server** configured, the standby database is updated and the **Domains** web page opens displaying the **L1 Domains (UDP)** pane, as shown in [Figure 60 "L1 Domains pane"](#) (page 167).

If there is an associated **L0 Domain** or **Collaborative Server** configured, the **L1 Domain** can not be deleted and an error message is displayed. See [Figure 67 "Delete L1 Domain error message"](#) (page 174).

Figure 67
Delete L1 Domain error message



The associated **L0 Domain** or **Collaborative Server** must be deleted before the **L1 Domain** can be deleted.

See [Procedure 19 "Deleting an L0 Domain \(CDP\)"](#) (page 182) to delete the associated **L0 Domain**.

See [Procedure 23 "Deleting a Collaborative Server"](#) (page 192) to delete the associated **Collaborative Server**.

- 8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state.
- 9 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

Manage a Level 0 Domain (CDP)

The Level 0 (L0) Domain is a building block of the phone context for private addresses. For more information on phone context, see ["SIP Uniform Resource Identifiers"](#) (page 34). For more information on L0 Domains, see [Figure 4 "Hierarchy of the NRS database components"](#) (page 31).


Add an L0 Domain (CDP)

Use the following procedure to add an L0 Domain (CDP).

Procedure 16 Adding an L0 Domain (CDP)

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160).
3	Click L0 Domains (CDP) tab. The Domains web page refreshes displaying the L0 Domains (CDP) pane, as shown in Figure 68 "L0 Domain (CDP) pane" (page 175).

Figure 68
L0 Domain (CDP) pane



- 4 The **Filter by Domain:** drop-down lists contain configured Service Domains and L1 Domains. Select the Service Domain and the L1 Domain, where the new L0 subdomain will be added, from the respective drop-down lists.
- 5 Click the **Add...** button.

The **Add L0 Domain** web page opens, as shown in [Figure 69 "Add L0 Domain web page"](#) (page 176).

Figure 69
Add L0 Domain web page

The screenshot shows the 'Add L0 Domain' configuration page in the Nortel Network Routing Service Manager. The page title is 'Add L0 Domain (myServiceProvider / myCompany.com)'. The form includes the following fields and options:

- Domain name:
- Domain description:
- Endpoint authentication enabled:
- Authentication password:
- E.164 country code:
- E.164 area code:
- Private unqualified number label:
- E.164 international dialing access code:
- E.164 international dialing code length:
- E.164 national dialing access code:
- E.164 national dialing code length:
- E.164 local (unqualified) dialing access code:


At the bottom right, there are 'Save' and 'Cancel' buttons. A footer note states: '* Required value. Copyright © 2006 Nortel Networks. All rights reserved.'

- 6 Enter the **Domain name** of the L0 Domain in the text box. The name must be alphanumeric and up to 30 characters in length. For example, enter myCdpDomain.
- 7 Enter the **Domain description** in the text box. The description can include any character except single quotes and can be up to 120 characters in length.

Note: An L0 Domain can inherit configuration parameters from its parent L1 Domain. See [“Numbering Plans inherited fields”](#) (page 148).
- 8 Select **Not configured**, **Authentication on**, or **Authentication off** from the **Endpoint authentication enabled** drop-down list. If **Authentication on** is selected, then all endpoints require authentication.
- 9 Enter the **Authentication password** in the text box, if **Authentication on** was selected in [step 8](#). The password must be alphanumeric and up to 24 characters in length.
- 10 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to 30 digits in length.
- 11 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to 30 digits in length.
- 12 Enter the **Private unqualified number label** in the text box. The label must be alphanumeric and can be up to 30 characters in length. The first character in the label must be alphabetic.

- 13 Enter the **E.164 international dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 14 Enter the **E.164 international dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 international dialing access code length.
- 15 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 16 Enter the **E.164 national dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 national dialing access code length.
- 17 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 18 Enter the **E.164 local (subscriber) dialing code length** in the text box. The code must be numeric and has to exceed the E.164 local (subscriber) dialing access code length.
- 19 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 20 Enter the **Private L1 domain (UDP location) dialing code length** in the text box. The code must be numeric and has to exceed the Private L1 domain (UDP location) dialing access code length.
- 21 Enter the **Special number** in the text box. The number must be numeric and can be up to 30 digits in length.
- 22 Enter the **Special number dialing code length** in the text box. The number must be numeric and equal to the Special number length.
- 23 Enter the **Emergency services access prefix** in the text box. The number must be numeric and can be up to 30 digits in length.
- 24 Click the **Save** button. The standby database is updated.
The **Domains** web page opens, showing the newly added myCdpDomain L0 domain. See [Figure 70 "Added L0 Domain" \(page 178\)](#).

Figure 70
Added L0 Domain



- 25 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 26 Test the configuration changes.
- 27 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

View an L0 Domain (CDP)

Use the following procedure to view an L0 Domain (CDP).

Procedure 17 Viewing an L0 Domain (CDP)


Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).
2	Select the Active or Standby database. See Procedure 7 “Switching between the Active and Standby databases” (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time. The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 55 "Service Domains pane Active Database" (page 162).

- 3 Click **L0 Domains (CDP)** drop-down list.

The **Domains** web page refreshes displaying the **L0 Domains (CDP)** pane, as shown in [Figure 71 "L0 Domain \(CDP\) pane Active database"](#) (page 179).

The L0 Domains can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID"](#) (page 146) .

Figure 71
L0 Domain (CDP) pane Active database



- 4 The **Filter by Domain:** drop-down lists contain configured Service Domains and L1 Domains. Select a Service Domain and L1 Domain from the drop-down lists.

The web page displays a list of configured L0 Domains.


- 5 Click a **link** in the **ID** column of the L0 Domains (CDP) pane.

The **Edit L0 Domain** web page opens and displays the configured data for the selected L0 Domain.

See [Figure 72 "Edit L0 Domain \(CDP\) web page Active database"](#) (page 180).

Note: See [Procedure 18 "Editing an L0 Domain \(CDP\)"](#) (page 180) to Edit the L0 Domain.

Figure 72
Edit L0 Domain (CDP) web page Active database



--End--

Edit an L0 Domain (CDP)

Use the following procedure to edit an L0 Domain (CDP).

Procedure 18 Editing an L0 Domain (CDP)

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160).
3	Click L0 Domains (CDP) tab. The Domains web page refreshes displaying the L0 Domains (CDP) pane, as shown in Figure 68 "L0 Domain (CDP) pane" (page 175). The L0 Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .

- 4 The **Filter by Domain:** drop-down lists contain configured Service Domains and L1 Domains. Select a Service Domain and L1 Domain from the drop-down lists.

The web page refreshes displaying a list of configured L0 Domains.

- 5 Click on a link in the **ID** column of the **L0 Domains (CDP)** pane. The **Edit L0 Domain** web page opens, as shown in [Figure 73 "Edit L0 Domain web page"](#) (page 181).

Figure 73
Edit L0 Domain web page

- 6 Modify the fields of the **Edit L0 Domain** web page as appropriate. See [Procedure 16 "Adding an L0 Domain \(CDP\)"](#) (page 175).

Note: An L1 Domain can inherit configuration parameters from its parent L0 Domain. See ["Numbering Plans inherited fields"](#) (page 148)

- 7 Click the **Save** button. The standby database is updated. The **Domains** web page opens displaying the **L0 Domains (UDP)** pane, as shown in [Figure 68 "L0 Domain \(CDP\) pane"](#) (page 175).
- 8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 9 Test the configuration changes.
- 10 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.


--End--

Delete an L0 Domain (CDP)

Use the following procedure to delete an L0 Domain (CDP).

Procedure 19 Deleting an L0 Domain (CDP)


Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Domains . The Domains web page opens, as shown in Figure 49 "Domains web page" (page 159) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) . The Domains web page refreshes displaying the Service Domains pane, as shown in Figure 52 "Service Domains pane" (page 160) .
3	Click L0 Domains (CDP) drop-down list. The Domains web page refreshes displaying the L0 Domains (UDP) pane, as shown in Figure 68 "L0 Domain (CDP) pane" (page 175) . The L0 Domains can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
4	The Filter by Domain: drop-down lists contain configured Service Domains and L1 Domains. Select a Service Domain and L1 Domain from the drop-down lists. The web page displays a list of configured L0 Domains.
5	Select a check box beside one or more configured L0 Domains in the ID column of the L0 Domains (CDP) pane.
6	Click Delete . A Confirmation Box opens requesting confirmation before deleting the selected L0 Domain . Figure 74 Confirmation Box
7	Click OK . If there is not an associated Collaborative Server configured, the standby database is updated and the Domains web page



opens displaying the **L0 Domains (UDP)** pane, as shown in Figure 68 "L0 Domain (CDP) pane" (page 175).

If there is an associated **Collaborative Server** configured, the **L0 Domain** can not be deleted and an error message is displayed, as shown in Figure 75 "Delete L0 Domain error message" (page 183).

Figure 75
Delete L0 Domain error message



The associated **Collaborative Server** must be deleted before the **L0 Domain** can be deleted.

See [Procedure 23 "Deleting a Collaborative Server"](#) (page 192) to delete the associated **Collaborative Server**.

Note: An error message is displayed if there is a Gateway Endpoint or a routing entry configured in the L0 Domain. The Gateway Endpoint or routing entry must be deleted before the L0 domain can be deleted. See [Procedure 28 "Deleting the Gateway Endpoints"](#) (page 206) to delete a Gateway Endpoint. See [Procedure 42 "Deleting a Routing Entry"](#) (page 229) to delete a routing entry.

- 8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state.
- 9 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

Manage a Collaborative Server

A Collaborative Server is a server in another network zone that can be used to resolve requests when the NRS cannot find a match in its numbering plan database.

NRS Manager provides a utility for adding and viewing Collaborative Servers, either system-wide or in different network domains.

The configuration of a Collaborative Server as system-wide allows IP addresses to be shared by users across multiple domains. This also allows domains to be spread geographically.

NRS Collaborative Servers in different network domains can also be specified in the NRS.

If a request comes in from a gateway and the NRS cannot find a match in its database for the request, the NRS provides the IP address of a Collaborative Server to the gateway. The gateway can then send its request to the Collaborative Server.

Note: Calls can only be made in the same domain, even though calls go through the Collaborative Server to find a match. Ensure that the Destination endpoint, which is Gatekeeper, is provisioned in the same Service Domain, Level 1 Domain (UDP) and Level 0 Domain (CDP) as the Originating endpoint.

For more information about the Collaborative Server, refer to *IP Peer Networking Installation and Commissioning (NN43001-313)*.


Add a Collaborative Server

Use the following procedure to add a Collaborative Server.

Procedure 20 Adding a Collaborative Server

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Collaborative Servers . The Collaborative Servers web page opens, as shown in Figure 76 "Collaborative Servers web page" (page 185) .

Figure 76
Collaborative Servers web page




2 Ensure **Standby database** is selected. See [Procedure 7 "Switching between the Active and Standby databases"](#) (page 159)

3 Click the **Add....** button.

The **Add Collaborative Server** web page opens, as shown in [Figure 77 "Add Collaborative Server \(System wide\)"](#) (page 185).

Figure 77
Add Collaborative Server (System wide)



4 Select the **Domain type for Collaborative Server** from the drop-down list.

- Select **System wide** if the Collaborative Server is to be a system-wide server. See [Figure 77 "Add Collaborative Server \(System wide\)"](#) (page 185).
- Select **Service domain** if the Collaborative Server is to be a Service Domain server.
 An additional field **Service domain name** is displayed, as shown in [Figure 78 "Add Collaborative Server \(Service](#)

domain)" (page 186). Select the Service domain name from the drop-down list.

- Select **L1 domain** if the Collaborative Server is to be an L1 Domain server.
Two additional fields are displayed: (1) **Service domain name** and (2) **L1 domain name**, as shown in [Figure 79 "Add Collaborative Server \(L1 Domain\)" \(page 187\)](#). Select the Service Domain name and the L1 Domain name from the drop-down lists.
- Select **L0 domain** if the Collaborative Server is to be an L0 Domain server.
Three additional fields are displayed: (1) **Service domain name**, (2) **L1 domain name** and (3) **L0 domain name**, as shown in [Figure 80 "Add Collaborative Server \(L0 Domain\)" \(page 187\)](#). Select the Service Domain name, the L1 Domain name and the L0 Domain name from the drop-down lists.

Figure 78
Add Collaborative Server (Service domain)




Figure 79
Add Collaborative Server (L1 Domain)

The screenshot shows the 'Add Collaborative Server' form in the Nortel Network Routing Service Manager. The form is titled 'Add Collaborative Server' and is part of the 'Collaborative Servers' section. The 'Domain type for the collaborative server' is set to 'L1 domain'. The 'Service domain name' is 'ccsp.com', the 'L1 domain name' is 'innovata', and the 'Server address type' is 'IP version 4'. The 'Server address' field is empty. The 'H.323 support' checkbox is unchecked, 'RAS port' is '1719', 'SIP support' is unchecked, and 'SIP TCP transport enabled' is unchecked. The 'SIP TCP port' is '5060'. There are 'Save' and 'Cancel' buttons at the bottom right of the form.


Figure 80
Add Collaborative Server (L0 Domain)

The screenshot shows the 'Add Collaborative Server' form in the Nortel Network Routing Service Manager. The form is titled 'Add Collaborative Server' and is part of the 'Collaborative Servers' section. The 'Domain type for the collaborative server' is set to 'L0 domain'. The 'Service domain name' is 'ccsp.com', the 'L1 domain name' is 'innovata', and the 'L0 domain name' is 'saintjohns'. The 'Server address type' is 'IP version 4'. The 'Server address' field is empty. The 'H.323 support' checkbox is unchecked, 'RAS port' is '1719', 'SIP support' is unchecked, and 'SIP TCP transport enabled' is unchecked. The 'SIP TCP port' is '5060'. There are 'Save' and 'Cancel' buttons at the bottom right of the form.

- 5 Enter the **Alias name** of the collaborative server in the text box. The alias name must be alphanumeric and can be up to 30 characters in length. The name cannot include spaces.
- 6 **IP version 4** in the **Server address type** drop-down list is selected by default. This option has been added for future use.
- 7 Enter the IP address of the L1 domain server in the **Server address** text box.
- 8 Select the protocol(s) supported by the server.
 - If H.323 is supported, perform the following steps:

- a. Select the **H.323 support** check box.
 - b. Enter the **RAS port** number. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 1719.
 - If SIP is supported, perform the following steps:
 - a. Select the **SIP support** check box.
 - b. Select the transport protocol:
 - If SIP TCP is supported:
 - Select the **SIP TCP transport enabled** check box.
 - Enter the **SIP TCP port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5060.
 - If SIP UDP is supported:
 - Select the **SIP UDP transport enabled** check box.
 - Enter the **SIP UDP port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5060.
 - If SIP TLS is supported:
 - Select the **SIP TLS transport enabled** check box.
 - Enter the **SIP TLS port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5061.
 - If **End to end security** is supported, select the End to end security check box.
- 9** Click **Save**. The standby database is updated.
- The **Collaborative Servers** web page opens with the newly added collaborative server, as shown in [Figure 81 "Added Collaborative Server"](#) (page 189).

Figure 81
Added Collaborative Server



- 10 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 11 Test the configuration changes.
- 12 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

View a Collaborative Server

Use the following procedure to view a Collaborative Server.

Procedure 21 Viewing a Collaborative Server

- | Step | Action |
|------|--|
| 1 | In the NRS Manager Navigator select Numbering Plans > Collaborative Servers . The Collaborative Servers web page opens, displaying a list of configured Collaborative Servers as shown in Figure 76 "Collaborative Servers web page" (page 185).


The Collaborative Servers can be sorted in ascending or descending alphabetical order. See "Sort web page by Server Fully Qualified Domain" (page 146) . |
| 2 | Select the Active or Standby database. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time. |
| 3 | Click a link in the Server Fully Qualified Domain column of the Collaborative Servers web page. |

The **Edit Collaborative Server** web page opens and displays the configured data for the selected Collaborative Server.

See [Figure 82 "Edit Collaborative Server web page Active database"](#) (page 190).

Note: See [Procedure 22 "Editing a Collaborative Server"](#) (page 190) to Edit the Collaborative Server.

Figure 82
Edit Collaborative Server web page Active database



--End--

Edit a Collaborative Server

Use the following procedure to edit a Collaborative Server.

Procedure 22 Editing a Collaborative Server

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Collaborative Servers . The Collaborative Servers web page opens displaying a list of configured Collaborative Servers, as shown in Figure 76 "Collaborative Servers web page" (page 185). The Collaborative Servers can be sorted in ascending or descending alphabetical order. See "Sort web page by Server Fully Qualified Domain" (page 146) .

- 2 Ensure **Standby database** is selected. See [Procedure 7 “Switching between the Active and Standby databases”](#) (page 159)
- 3 Click a **link** in the **Server Fully Qualified Domain** column of the Collaborative Servers web page.

The **Edit Collaborative Server** web page opens and displays the configured data for the selected Collaborative Server, as shown in [Figure 83 “Edit Collaborative Server web page”](#) (page 191).

Figure 83
Edit Collaborative Server web page

The screenshot shows the 'Edit Collaborative Server' web page. At the top, it says 'NORTEL NETWORK ROUTING SERVICE MANAGER' with 'Hello | Logout' on the right. Below that, it indicates 'Managing: Active database 192.167.103.11' and 'Standby database' with a link to 'Numbering Plan > Collaborative Servers'. The main section is titled 'Edit Collaborative Server' and contains the following fields:

- Domain type for the collaborative server: L0 domain (dropdown)
- Service domain name: myServiceProvider.com (dropdown)
- L1 domain name: mycompany.com (dropdown)
- L0 domain name: myCdpDomain (dropdown)
- Alias name: (text input)
- Server address type: IP version 4 (dropdown)
- Server address: 192.168.104.12 (text input, marked as required)
- H.323 support:
- RAS port: 1719 (text input)
- SIP support:
- SIP TCP transport enabled:

At the bottom, there are 'Save' and 'Cancel' buttons and a note: '* Required value'.


- 4 Modify the fields of the **Edit Collaborative Server** web page as appropriate. See [Procedure 20 “Adding a Collaborative Server”](#) (page 184).
- 5 Click **Save**. The standby database is updated.
The **Collaborative Servers** web page opens, as shown in [Figure 76 “Collaborative Servers web page”](#) (page 185).
- 6 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 7 Test the configuration changes.
- 8 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

Delete a Collaborative Server

Use the following procedure to delete a Collaborative Server.

Procedure 23 Deleting a Collaborative Server

Step	Action
1	<p>In the NRS Manager Navigator select Numbering Plans > Collaborative Servers. The Collaborative Servers web page opens displaying a list of configured Collaborative Servers, as shown in Figure 76 "Collaborative Servers web page" (page 185).</p> <p>The Collaborative Servers can be sorted in ascending or descending alphabetical order. See "Sort web page by Server Fully Qualified Domain" (page 146) .</p>
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159)
3	Select a check box beside one or more links in the Server Fully Qualified Domain column of the Collaborative Servers web page.
4	<p>Click Delete.</p> <p>A Confirmation Box opens requesting confirmation before deleting the selected Collaborative Server. See Figure 84 Confirmation Box</p>
	
5	Click OK . The standby database is updated. The Collaborative Servers web refreshes displaying a list of configured collaborative servers, as shown in Figure 76 "Collaborative Servers web page" (page 185).
6	See Procedure 58 "Cutting over the database" (page 263) to place the database in a Switched Over state.
7	See Procedure 61 "Committing the database" (page 265) to update the database with the configuration changes.

--End--

Manage a Gateway Endpoint

Add a Gateway Endpoint


Use the following procedure to add a Gateway Endpoint.

Procedure 24 Adding a Gateway Endpoint

Step	Action
------	--------

- | | |
|---|---|
| 1 | In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) . |
|---|---|

Figure 85
Endpoints web page




- 2 Ensure **Standby database** is selected. See [Procedure 7 "Switching between the Active and Standby databases" \(page 159\)](#).
- 3 The **Limit results to Domain:** drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.

- 4 Click the **Gateway Endpoints** tab.

The **Endpoints** web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in [Figure 86 "Gateway Endpoints pane" \(page 194\)](#).


The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID" \(page 146\)](#).

Figure 86
Gateway Endpoints pane



5 (Optional) Click the **Search** button to display a list of configured Gateway Endpoints associated with the selected Service Domain, L1 domain, and L0 Domain, as shown in [Figure 87 "Gateway Endpoints for selected Service Domain, L1 Domain and L0 Domain."](#) (page 194).

Figure 87
Gateway Endpoints for selected Service Domain, L1 Domain and L0 Domain.



6 Click the **Add....** button.
 The **Add Gateway Endpoint** web page opens, as shown in [Figure 88 "Add Gateway Endpoint web page"](#) (page 195).

Figure 88
Add Gateway Endpoint web page

The screenshot shows the 'Add Gateway Endpoint' web page in the Nortel Network Routing Service Manager. The page title is 'Add Gateway Endpoint (myServiceProvider / myCompany.com / myCDPDomain)'. The form includes the following fields and options:

- End point name:
- Description:
- Trust Node:
- Tandem gateway endpoint name:
- Endpoint authentication enabled:
- Authentication password:
- E.164 country code:
- E.164 area code:
- E.164 international dialing access code:
- E.164 international dialing code length:
- E.164 national dialing access code:
- E.164 national dialing code length:

Copyright © 2006 Nortel Networks. All rights reserved.

- 7 Enter the **Endpoint name** of the gateway in the text box. The name must be alphanumeric and can be up to 30 characters in length.
For example, enter sipGWSite1.
- 8 Enter a description of the endpoint in the **Description** text box. The description must be alphanumeric and can be up to 120 characters in length.
- 9 Check the **Trust Node:** check box.
- 10 Select the **Tandem gateway endpoint name** from the drop-down list, if required. This indicates whether the endpoint is used to tandem calls from outside the network. The name must be alphanumeric and can be up to 30 characters in length.

Note: A Gateway Endpoint can inherit configuration parameters from the L0 Domain that it exists within. See [“Numbering Plans inherited fields” \(page 148\)](#).

- 11 Select an option from the **Endpoint authentication enabled** drop-down list.

The three options are:

- **Not configured:** If this option is selected, then the gateway endpoint uses the L1 or L0 Authentication (if L1 or L0 authentication is enabled).
- **Authentication on:** If this option is selected, then authentication is on for this gateway endpoint and the

authentication overrides the L1 or L0 authentication (if it is enabled).

- **Authentication off:** If this option is selected, then authentication is off for this gateway endpoint even if L1 or L0 authentication is enabled.

- 12 Enter the **Authentication password** in the text box, if **Authentication on** was selected. The password must be alphanumeric and can be up to 24 characters in length.
- 13 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to eight digits in length.
- 14 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to eight digits in length.
- 15 Enter the **E.164 international dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 16 Enter the **E.164 international dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 international dialing access code length.
- 17 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 18 Enter the **E.164 national dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 national dialing access code length.
- 19 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 20 Enter the **E.164 local (subscriber) dialing code length** in the text box. The code length must be numeric and has to exceed the E.164 local (subscriber) dialing access code length.
- 21 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to eight digits in length.
- 22 Enter the **Private L1 domain (UDP location) dialing code length** in the text box. The code length must be numeric and has to exceed the Private L1 domain (UDP location) dialing access code length.
- 23 Enter the **Private special number 1** in the text box. The number must be numeric and can be up to 30 digits in length.
- 24 Enter the **Private special number 1 dialing code length** in the text box. The code length must be numeric and equal to the Private special number 1 length.

- 25 Enter the **Private special number 2** in the text box. The number must be numeric and can be up to 30 digits in length
- 26 Enter the **Private special number 2 dialing code length** in the text box. The code length must be numeric and equal to the Private special number 2 length.

Note: You must avoid conflict of data when you configure the access codes. This is to support unqualified DN-based URIs by performing a pre-translation in order to find the appropriate phone context.

- 27 Select **IP Version 4** from the **Static endpoint address type** drop-down list.

- 28 Enter the **Static endpoint address** in the text box.

This is the Node IP address of the Signaling Server. If a third-party gateway is being used, then it is the IP address of the gateway.

- 29 Select whether H.323 support is enabled from the **H.323 Support** drop-down list.

The three options are:

- H.323 not supported
- RAS H.323 endpoint
- Not RAS H.323 endpoint.

Note 1: If an H.323 Gateway Endpoint is configured with an H.323 Support type of RAS H.323 endpoint, then NRS Manager displays Endpoint Dynamic Registration information after the H.323 Gateway registers with the NRS.

Note 2: Endpoint Dynamic Registration information includes the following: Call Signaling IP, RAS IP, Alias name, t35Country code, t35Extension, Manufacturer code, Product ID, and Version ID.

Note 3: The H.323 **Endpoint Dynamic Registration Information** is displayed only when NRS Manager is in **Active database** view. The detailed dynamic registration information also is displayed only inside the Gateway Endpoint web page. See [Procedure 25 "Viewing Gateway Endpoint Dynamic Registration Information"](#) (page 200).

- 30 Configure SIP support.
- a Select an option from the **SIP Support** drop-down list. The three options are: SIP not supported, Static SIP endpoint, and Dynamic SIP endpoint.
- b If SIP support is enabled, select the transport protocol:
- If SIP TCP is supported, perform the following steps:

- Select the **SIP TCP transport enabled** check box.
- Enter the **SIP TCP port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5060.
- If SIP UDP is supported, perform the following steps
 - Select the **SIP UDP transport enabled** check box.
 - Enter the **SIP UDP port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5060.
- If SIP TLS is supported, perform the following steps:
 - Select the **SIP TLS transport enabled** check box.
 - Enter the **SIP TLS port** number in the text box. The port number must be numeric and can be up to five digits in length. The range is 0 to 65535. The default port value is 5061.

Note: If a SIP Trunk Gateway Endpoint is configured with a SIP Support type of Dynamic SIP endpoint, then NRS Manager displays Endpoint Dynamic Registration Information for SIP after the SIP Trunk Gateway registers with the NRS. Endpoint Dynamic Registration Information includes the following: SIP IP, Registration expiry time, User agent, and Preference. The **SIP Endpoint Dynamic Registration Information** is displayed only when NRS Manager is in **Active DB view**. The detailed dynamic registration information also is displayed only inside the Gateway Endpoint web page. See [Procedure 25 “Viewing Gateway Endpoint Dynamic Registration Information”](#) (page 200).

- 31 Check the **Persistent TCP support enabled** check box.
- 32 If **End to end security** is supported, select the End to end security check box.
- 33 Select the **Network Connection Server is enabled** check box if this Gateway Endpoint supports the NCS for branch office or SRG user redirection to the main office, Virtual Office, or Geographic Redundancy.
- 34 Select whether Redundancy is enabled from the **Redundancy enabled** drop-down list.

The three options are:

 - Not configured
 - Main Office
 - Redundant Office

Geographic redundant gateways (Main Office and Redundant office endpoints) can be linked.

To set the main endpoint

- select **Main Office** from the **Redundancy enabled** drop-down list
- select the desired endpoint name in the **Redundant endpoint name** drop-down list.

To set the redundant endpoint


- select **Redundant Office** from the **Redundancy enabled** drop-down list
- select the desired endpoint name in the **Main endpoint name** field

If two endpoints are linked (configured properly), NRS Manager will prompt the user to configure routes for the redundant endpoint with pre-set values when routes are added to the main endpoint. This feature enables the configuration of two routes (one for the main office endpoint and one for the redundant office endpoint) at the same time with pre-set values.

- 35** The **Main endpoint name** is dynamically generated based on the Gateway Endpoint configuration. The default selection is **Not configured**.
- 36** The **Redundant endpoint name** is dynamically generated based on the Gateway Endpoint configuration. The default selection is **Not configured**.
- 37** Click the **Save** button. The standby database is updated.

The **Gateway Endpoints** web page opens, showing the newly added sipGWSite1 endpoint. See [Figure 89 "Gateway Endpoints web page for added Gateway Endpoint"](#) (page 200).

Figure 89
Gateway Endpoints web page for added Gateway Endpoint



- 38** See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 39** Test the configuration changes.
- 40** See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

View Gateway Endpoint Dynamic Registration Information

Use the following procedure to view the Gateway Endpoint Dynamic Registration Information.

Procedure 25 Viewing Gateway Endpoint Dynamic Registration Information

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193).
2	Ensure Active database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains.


Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.

- 4 Click the **Gateway Endpoint** tab.

The **Endpoints** web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in [Figure 90 "Gateway Endpoints Summary web page" \(page 201\)](#).

The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID" \(page 146\)](#).

Figure 90
Gateway Endpoints Summary web page



- 5 Click a **link** in the **ID** column of the **Endpoints** pane.

The **Edit Gateway Endpoint** web page opens and displays the configured data for the selected Gateway Endpoint, as shown in [Figure 93 "Edit Gateway Endpoint web page Active database" \(page 204\)](#).

Note 1: If an H.323 Gateway Endpoint is configured with an H.323 Support type of RAS H.323 endpoint, then NRS Manager displays Endpoint Dynamic Registration information after the H.323 Gateway registers with the NRS. Endpoint Dynamic Registration information includes the following: Call Signaling IP, RAS IP, Alias name, t35Country code, t35Extension, Manufacturer code, Product ID, and Version ID.

Note 2: If a SIP Trunk Gateway Endpoint is configured with a SIP Support type of Dynamic SIP endpoint, then NRS Manager displays Endpoint Dynamic Registration Information for SIP after the SIP Trunk Gateway registers with the NRS. Endpoint Dynamic Registration Information includes the following: SIP IP, Registration expiry time, User agent, and Preference.

- 6 Scroll down the page to display **Endpoint Dynamic Registration Information for RAS H.323** and **Endpoint Dynamic Registration Information for SIP**, as shown in [Figure 91 "Gateway Endpoints Property web page" \(page 202\)](#).

Figure 91
Gateway Endpoints Property web page



--End--

View the Gateway Endpoints


Use the following procedure to view the Gateway Endpoints.

Procedure 26 Viewing the Gateway Endpoints

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193).
2	Select the Active or Standby database. See Procedure 7 "Switching between the Active and Standby databases" (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time.

The **Endpoints** web page refreshes, as shown in [Figure 92 "Endpoints web page Active database"](#) (page 203).


Figure 92
Endpoints web page Active database



- 3 The **Limit results to Domain:** drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 4 Click the **Gateway Endpoints** tab. The **Endpoints** web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in [Figure 86 "Gateway Endpoints pane" \(page 194\)](#).
The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID" \(page 146\)](#).
- 5 Click a **link** in the **ID** column of the **Endpoints** pane.
The **Edit Gateway Endpoint** web page opens and displays the configured data for the selected Gateway Endpoint, as shown in [Figure 93 "Edit Gateway Endpoint web page Active database" \(page 204\)](#).

Note: See [Procedure 27 "Editing the Gateway Endpoints" \(page 204\)](#) to Edit the Gateway Endpoint.

Figure 93
Edit Gateway Endpoint web page Active database



--End--

Edit the Gateway Endpoints

Use the following procedure to edit the Gateway Endpoints.

Procedure 27 Editing the Gateway Endpoints

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the Gateway Endpoint tab. The Endpoints web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in Figure 86 "Gateway Endpoints pane" (page 194) . The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .

- 5 Click a **link** in the **ID** column of the Endpoints pane. The **Edit Gateway Endpoint** web page opens and displays the configured data for the selected Gateway Endpoint, as shown in [Figure 94 "Edit Gateway Endpoint web page"](#) (page 205).

Figure 94
Edit Gateway Endpoint web page

Note: A Gateway Endpoint can inherit configuration parameters from the L0 Domain that it exists within . See ["Numbering Plans inherited fields"](#) (page 148).

- 6 Modify the fields of the **Edit Gateway Endpoint** web page as appropriate. See [Procedure 24 "Adding a Gateway Endpoint"](#) (page 193).
- 7 Click the **Save** button. The standby database is updated. The **Endpoints** web page opens displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in [Figure 86 "Gateway Endpoints pane"](#) (page 194).
- 8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 9 Test the configuration changes.
- 10 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--


Delete the Gateway Endpoints

Use the following procedure to delete the Gateway Endpoints.

Procedure 28
Deleting the Gateway Endpoints

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the Gateway Endpoints tab. The Endpoints web page opens displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in Figure 86 "Gateway Endpoints pane" (page 194) . The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
5	Select a check box beside one or more links in the ID column of the Endpoints pane.
6	Click Delete . A Confirmation Box opens requesting confirmation before deleting the selected Gateway Endpoint , as shown in Figure 95 "Confirmation Box" (page 206) .

Figure 95
Confirmation Box



- 7 Click **OK**. The standby database is updated. The **Endpoints** web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in [Figure 86 "Gateway Endpoints pane" \(page 194\)](#).

Note: The standby database is updated only for Gateway Endpoints that do not have routing entries or default routes. If a Gateway Endpoint has routing entries or default routes they have to be deleted before the Gateway Endpoint can be deleted.

- 8 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state.
- 9 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

Manage Post-routing SIP URI Modification


Add Post-routing SIP URI Modification

Use the following procedure to add Post-routing SIP URI Modification.

Procedure 29 Adding Post-routing SIP URI Modification

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Network Post-Translation . The Network Post-translations web page opens, as shown in Figure 96 "Network Post-translations web page" (page 207).

Figure 96
Network Post-translations web page



- 2 Ensure **Standby database** is selected. See [Procedure 7 “Switching between the Active and Standby databases”](#) (page 159).
- 3 Select a **Service domain** from the **Filter by Domain:** drop-down list.
- 4 Click the **Add....** button.
The **Add Network Post Translations** web page opens, as shown in [Figure 97 "Add Network Post Translations web page"](#) (page 208).

Figure 97
Add Network Post Translations web page

The screenshot shows the 'Add Network Post Translations' web page in the Nortel Network Routing Service Manager. The page title is 'Add Network Post Translations (myServiceProvider.com)'. The form contains the following fields:


- Originating gateway endpoint: A dropdown menu with 'sipGWSite1' selected.
- Target phone context: A text input field with a yellow highlight.
- Terminating gateway endpoint: A dropdown menu with 'sipGWSite1' selected.
- Replacing target phone context with: A text input field with a yellow highlight.
- Originating routing string length: A text input field with a maximum value of 5 (1-24).
- Originating routing digit to start with: A text input field.
- Originating routing digits remove by: A text input field.
- Adding prefix to the routing digits with: A text input field.

At the bottom right of the form, there are 'Save' and 'Cancel' buttons. A legend at the bottom left indicates that an asterisk (*) denotes a required value.

- 5 Select an **Originating gateway endpoint** from the drop down list.
- 6 Enter a **Target phone context** in the text box. The name must be alphanumeric and can be up to 64 characters in length.
- 7 Select a **Terminating gateway endpoint** from the drop down list.
- 8 Enter a **Replacing target phone context with** in the text box. The name must be alphanumeric and can be up to 64 characters in length.
- 9 Enter an **Originating routing string length** in the text box. The string length must be numeric and can be up to 5 digits in length.
- 10 Enter an **Originating routing digit to start with** in the text box. The parameter must be numeric and can be up to 24 digits in length.
- 11 Enter an **Originating routing digits remove by** in the text box. The parameter must be numeric and **can not** exceed the value of the **Originating routing string length**.
- 12 Enter a **Adding prefix to the routing digits with** in the text box. The parameter must be numeric and can be up to 64 digits in length. The parameter **can not** contain a leading + character.
- 13 Click the **Save** button. The standby database is updated.

The **Network Post-translations** web page opens displaying the added Network Post-translation, as shown in [Figure 98 "Added Network Post-translations web page"](#) (page 209).

Figure 98
Added Network Post-translations web page



- 14 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 15 Test the configuration changes.
- 16 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

View Post-routing SIP URI Modification

Use the following procedure to view Post-routing SIP URI Modification.

Procedure 30

Viewing Post-routing SIP URI Modification

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Network Post-Translation . The Network Post-translations web page opens, as shown in Figure 96 "Network Post-translations web page" (page 207).
2	Select the Active or Standby database. See Procedure 7 “Switching between the Active and Standby databases” (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time. The Network Post-translations web page refreshes, as shown in Figure 96 "Network Post-translations web page" (page 207).
3	Select a Service domain from the Filter by Domain: drop-down list.
4	Click the Refresh link.

The **Network Post-translations** web page refreshes displaying a list of **Originating Endpoints**.

The Originating Endpoints can be sorted in ascending or descending alphabetical order. See "[Sort web page by Originating Endpoint](#)" (page 146) .

- 5 Click a **link** in the **Originating Endpoint** column of the **Network Post-translations** web page.

The **Edit Network Post Translations** web page opens, as shown in [Figure 99 "Edit Network Post Translations web page"](#) (page 211), and displays the configured data for the selected Network Post Translation.

--End--

Edit Post-routing SIP URI Modification

Use the following procedure to edit Post-routing SIP URI Modification.

Procedure 31 Editing Post-routing SIP URI Modification

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Network Post-Translation . The Network Post-translations web page opens, as shown in Figure 96 "Network Post-translations web page" (page 207).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	Select a Service domain from the Filter by Domain: drop-down list.
4	Click the Refresh link. The Network Post-translations web page refreshes displaying a list of Originating Endpoints . The Originating Endpoints can be sorted in ascending or descending alphabetical order. See " Sort web page by Originating Endpoint " (page 146) .
5	Click a link in the Originating Endpoint column of the <i>Network Post-translations</i> web page. The Edit Network Post Translations web page opens, as shown in Figure 99 "Edit Network Post Translations web page" (page 211), and displays the configured data for the selected Network Post Translation.

Figure 99
Edit Network Post Translations web page

- 6 Modify the fields of the **Edit Network Post Translations** web page as appropriate. See [Procedure 29 “Adding Post-routing SIP URI Modification”](#) (page 207).
- 7 Click the **Save** button. The standby database is updated.
 The **Network Post-translations** web page opens, as shown in [Figure 96 “Network Post-translations web page”](#) (page 207).
- 8 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 9 Test the configuration changes.
- 10 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

Delete Post-routing SIP URI Modification

Use the following procedure to delete Post-routing SIP URI Modification.

Procedure 32

Deleting Post-routing SIP URI Modification

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Network Post-Translation . The Network Post-translations web page opens, as shown in Figure 96 “Network Post-translations web page” (page 207).
2	Ensure Standby database is selected. See Procedure 7 “Switching between the Active and Standby databases” (page 159).

3 Select a **Service domain** from the **Filter by Domain:** drop-down list.

4 Click the Refresh link.

The **Network Post-translations** web page refreshes displaying a list of **Originating Endpoints**.

The Originating Endpoints can be sorted in ascending or descending alphabetical order. See "[Sort web page by Originating Endpoint](#)" (page 146) .

5 Select a check box beside one or more **links** in the **Originating Endpoint** column of the Network Post-translations web page.

6 Click the **Delete** button. A **Confirmation Box** opens, as shown in [Figure 100 "Confirmation Box"](#) (page 212), requesting confirmation before deleting the selected **Network Post Translation**.

Figure 100
Confirmation Box



7 Click **OK**. The standby database is updated.

The **Network Post-translations** web page opens, as shown in [Figure 96 "Network Post-translations web page"](#) (page 207).

8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.

9 Test the configuration changes.

10 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

Manage a User Endpoint

A SIP Phone registers and communicates as a user endpoint in the NRS. To add a User Endpoint, refer to [Procedure 33 "Adding a User Endpoint"](#) (page 213).

Unqualified number routing

To support routing of unqualified numbers dialed by SIP Phones, the NRS provides several types of dialing prefixes at the Level 1 regional domain, Level 0 regional domain, and for endpoints. The dialing prefixes include the following:

- E.164 International dialing access code (for example, 6011)
- E.164 National dialing access code (for example, 61)
- E.164 Local dialing access code (for example, 9)
- Level 1 Regional dialing access code (for example, 6)
- Level 0 Regional dialing access code (the default, if none of above match)

Up to two special numbers can be specified at L1 and/or L0.

Task summary

Before a SIP Phone can be added as a User Endpoint in the NRS, the Service Domain, Level 1 Regional Domain, and Level 0 Regional Domain must be configured. To complete these tasks, see

- [Procedure 8 “Adding a Service Domain” \(page 160\)](#)
- [Procedure 12 “Adding an L1 Domain” \(page 166\)](#)
- [Procedure 16 “Adding an L0 Domain \(CDP\)” \(page 175\)](#)

Add a User Endpoint (SIP Phone)


Use the following procedure to add a User Endpoint.

Procedure 33 Adding a User Endpoint

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 “Endpoints web page” (page 193) .
2	Ensure Standby database is selected. See Procedure 7 “Switching between the Active and Standby databases” (page 159) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.


- 4 Click the **User Endpoints** tab. The **Endpoints** web page opens displaying a list of configured User Endpoints in the Endpoints pane, as shown in [Figure 101 "User Endpoints pane" \(page 214\)](#).

Figure 101
User Endpoints pane



- 5 Click the **Add....** button. The **Add User Endpoint** web page opens, as shown in [Figure 102 "Add User Endpoint web page" \(page 214\)](#).

Figure 102
Add User Endpoint web page



- 6 Enter a **User name** for the endpoint. The endpoint's user name must be alphanumeric and can be up to 30 characters in length. The user name, together with the Service Domain names, becomes a string that is used to build the user's SIP URI:
Example: [username]@[service_domain_name]

- This SIP URI is used during SIP Phone registration. The username is used by the SIP authentication procedures.
- 7 Enter the **User endpoint description**. The endpoint's description must be alphanumeric (except single quotes) and can be up to 120 characters in length.
 - 8 Check the **Trust Node**: check box.
 - 9 Choose a **Tandem gateway endpoint name** from the drop-down list.

A tandem gateway endpoint must be an existing endpoint on the network. It is usually a Gateway Endpoint. The tandem gateway endpoint name is used to tandem all calls originating from this User Endpoint. That is, all calls originating from this User Endpoint are forwarded to the tandem gateway endpoint, which then routes all the call to the appropriate destinations. This is useful for generating Call Records for originating User Endpoint calls.

Note: A tandem gateway endpoint must ONLY be configured if the customer wants all the outgoing calls from the SIP User Endpoint to tandem through a SIP Trunk Gateway Endpoint, in that case the SIP Trunk Gateway Endpoint name should be specified in the tandem endpoint box.

- 10 Enter the **L0 directory number (DN)** of the User Endpoint. The DN must be numeric and can be up to 30 digits in length.
An example is 5000. The DN is the user's DN. That is, the CDP number.
- 11 Enter the **L1 directory number (DN) prefix**. The DN prefix must be numeric and can be up to eight digits in length.
An example is 343. The L1 DN prefix together with the L0 DN creates the user's DN which is unique within the parent L1 Regional Domain. That is, the UDP number. For example, 3435000.
$$\text{L1 domain prefix} + \text{L0 DN} = \text{User's DN}$$
$$343 + 5000 = 3435000$$
- 12 Enter the **E.164 local directory number (DN) prefix**. The DN prefix must be numeric and can be up to eight digits in length.
An example is 967. The E.164 local DN prefix is the location code. The E.164 local prefix, together with the L0 DN, creates the user's E.164 Local (subscriber) DN. For example, 9675000.
$$\text{E.164 local prefix} + \text{L0 DN} = \text{User's E.164 Local (subscriber) DN}$$
$$967 + 5000 = 9675000$$
- 13 Enter the **E.164 area code**. The code must be numeric and can be up to eight digits in length.

An example is 613. The E.164 area code together with both the E.164 local prefix and L0 DN creates the user's national E.164 National DN. For example, 6139675000.

E.164 area code + E.164 local prefix + L0 DN = User's E.164 National DN
 613 + 967 + 5000 = 6139675000

- 14 Enter the **E.164 country code**. The code must be numeric and can be up to eight digits in length.


An example is 1 (for North America). The E.164 country code, together with the E.164 area code, E.164 local prefix, and L0 DN, creates the user's E.164 International DN. For example, 16139675000.

E.164 country code + E.164 area code + E.164 local prefix + L0 DN
 = User's E.164 International DN
 1 + 613 + 967 + 5000 = 16139675000

- 15 Select **Authentication** on from the **Authentication enabled** drop-down list, if you want to enable authentication for this endpoint.
- 16 If authentication is enabled in , then enter the **Authentication password**. The password must be alphanumeric and can be up to 24 characters in length.
- 17 Click the **Save** button. The standby database is updated.

The **Endpoints** web page opens, showing the newly added User Endpoint in the **User Endpoints** pane. See [Figure 103 "Added User Endpoints"](#) (page 216).

Figure 103
Added User Endpoints



- 18 If required, click **Add...** to add additional User Endpoints.

Any new endpoints are displayed in the **User Endpoints** web page.

Note 1: A maximum of 100 user endpoints can be displayed on the **User Endpoints** web page.

Note 2: If a User Endpoint is configured, then the supported protocol type is dynamic SIP. NRS Manager displays User Endpoint Dynamic Registration Information after the User Endpoint registers with the NRS. User Endpoint Dynamic Registration information includes the following: SIP IP, Registration expiry time, User agent, and Preference. The **User Endpoint Dynamic Registration Information** is displayed only when NRS Manager is in Active database mode. Detailed dynamic registration information is displayed inside the **User Endpoints Property** web page. See [Procedure 34 "Viewing User Endpoint Dynamic Registration Information"](#) (page 217).

- 19 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 20 Test the configuration changes.
- 21 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

View User Endpoint Dynamic Registration Information

Use the following procedure to view the User Endpoint Dynamic Registration Information.

Procedure 34 Viewing User Endpoint Dynamic Registration Information

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193).
2	Ensure Active database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the User Endpoints tab. The Endpoints web page refreshes displaying a list of configured User Endpoints in the Endpoints pane, as shown in Figure 104 "User Endpoints

Summary web page" (page 218). The User Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .

Figure 104
User Endpoints Summary web page

ID	LD DN	L1 DN Prefix	E.164 Local DN Prefix	E.164 Area Code	E.164 Country Code	Registration Status	Contact
2100	7100	575	999	813	1	47.11.108.108	interop.com / udpininterop.com / cdp
2101	7101	575	999	813	1	47.11.108.104	interop.com / udpininterop.com / cdp
2102	7102	575	999	813	1	47.11.108.105	interop.com / udpininterop.com / cdp

5 Click a **link** in the **ID** column of the **Endpoints** pane.

The **Edit User Endpoint** web page opens and displays the configured data for the selected User Endpoint, as shown in Figure 105 "User Endpoints Property web page" (page 218).

Note: If a User Endpoint is configured, then the supported protocol type is dynamic SIP. NRS Manager displays User Endpoint Dynamic Registration Information after the User Endpoint registers with the NRS User Endpoint Dynamic Registration information includes the following: SIP IP, Registration expiry time, User agent, and Preference.

Figure 105
User Endpoints Property web page

Managing: Active database 47.11.108.112
 Standby database NumberofSIP - Endpoints - User Endpoint

Edit User Endpoint (interop.com / udpininterop.com / cdp)

Trust Node:

Tandem gateway endpoint name:

LD directory number (DN):

L1 directory number (DN) prefix:

E.164 local directory number (DN) prefix:

E.164 Area Code:

E.164 Country Code:

Authentication enabled:

Authentication password:

User Endpoint Dynamic Registration Information

SIP IP: 47.11.108.108
 Registration expiry time: 65535
 User agent: ipDialog SipTone(TM) III 1.3.1 build 13 patch 3 UA
 Preference: 1

* Required value

6 Scroll down the page to display **User Endpoint Dynamic Registration Information**.

--End--

View the User Endpoints


Use the following procedure to view the User Endpoints.

Procedure 35
Viewing the User Endpoints

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) .
2	Select the Active or Standby database. See Procedure 7 "Switching between the Active and Standby databases" (page 159) . The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time. The Endpoints web page refreshes, as shown in Figure 92 "Endpoints web page Active database" (page 203) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the User Endpoints tab. The Endpoints web page refreshes displaying a list of configured User Endpoints in the Endpoints pane, as shown in Figure 101 "User Endpoints pane" (page 214) . The User Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
5	Click a link in the ID column of the Endpoints pane. The Edit User Endpoint web page opens and displays the configured data for the selected User Endpoint, as shown in Figure 106 "Edit User Endpoint web page Active database" (page 220) .

Note: See [Procedure 36 "Editing a User Endpoint" \(page 220\)](#) to Edit the User Endpoint.

Figure 106
Edit User Endpoint web page Active database



--End--


Edit a User Endpoint

Use the following procedure to edit a User Endpoint.

Procedure 36 Editing a User Endpoint

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the User Endpoints tab. The Endpoints web page opens displaying a list of configured User Endpoints in the Endpoints pane, as shown in Figure 101 "User Endpoints pane" (page 214) . The User Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
5	Click a link in the ID column of the Endpoints pane. The Edit User Endpoint web page opens and displays the configured data for the selected User Endpoint, as shown in Figure 107 "Edit User Endpoint web page" (page 221) .

Figure 107
Edit User Endpoint web page



- 6 Modify the fields of the **Edit User Endpoint** web page as appropriate. See [Procedure 33 “Adding a User Endpoint”](#) (page 213).
- 7 Click the **Save** button. The standby database is updated. The **Endpoints** web page opens, as shown in [Figure 85 "Endpoints web page"](#) (page 193)
- 8 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 9 Test the configuration changes.
- 10 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

Delete a User Endpoint

Use the following procedure to delete a User Endpoint.

Procedure 37 Deleting a User Endpoint

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193).

- 2 Ensure **Standby database** is selected. See [Procedure 7 "Switching between the Active and Standby databases"](#) (page 159).
- 3 The **Limit results to Domain:** drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 4 Click the **User Endpoints** tab. The **Endpoints** web page opens, as shown in [Figure 85 "Endpoints web page"](#) (page 193)
The User Endpoints can be sorted in ascending or descending alphabetical order. See ["Sort web page by ID"](#) (page 146) .
- 5 Select a check box beside one or more **links** in the **ID** column of the Endpoints pane.
- 6 Click **Delete**. A **Confirmation Box** opens, as shown in [Figure 108 "Confirmation Box"](#) (page 222), requesting confirmation before deleting the selected **User Endpoint**.

Figure 108
Confirmation Box



- 7 Click **OK**. The standby database is updated. The **Endpoints** web page opens, as shown in [Figure 85 "Endpoints web page"](#) (page 193).
- 8 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state.
- 9 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--


SIP Phone Context

The SIP Phone Context web page provides a view of SIP phone-context constructions under a configured Service Domain, Level 1 Domain and Level 0 Domain or Gateway Endpoint. To open the SIP Phone Context web page select **Tools > SIP Phone Context** in the NRS Manager Navigator, or follow the steps in [Procedure 38 "Mapping the SIP Phone Context"](#) (page 222).

Procedure 38 Mapping the SIP Phone Context


Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Endpoints . The Endpoints web page opens, as shown in Figure 85 "Endpoints web page" (page 193) .
2	Select Standby database or Active database . See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Click the Gateway Endpoints tab. The Endpoints web page refreshes displaying a list of configured Gateway Endpoints in the Endpoints pane, as shown in Figure 86 "Gateway Endpoints pane" (page 194) . The Gateway Endpoints can be sorted in ascending or descending alphabetical order. See "Sort web page by ID" (page 146) .
5	Select a check box beside a link in the ID column of the Endpoints pane.
6	Click the SIP phone context tab. The SIP Phone Context web page opens, as shown in Figure 109 "SIP Phone Context web page" (page 223) .

Figure 109
SIP Phone Context web page



7	Click the View tab. The SIP Phone Context web page expands to display the SIP Phone Context Mapping pane, as shown in Figure 110 "SIP Phone Context Mapping web page" (page 224) .
---	---

Figure 110
SIP Phone Context Mapping web page



--End--

Manage a Routing Entry


Add a Routing Entry

Use the following procedure to add a Routing Entry.

Procedure 39

Adding a Routing Entry

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224). Figure 111 Routes web page




- 2 Ensure **Standby database** is selected. See [Procedure 7 "Switching between the Active and Standby databases"](#) (page 159).
- 3 The **Limit results to Domain:** drop-down lists, in the **Search for Routing Entries** pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 4 Select a **Gateway Endpoint** from the **Endpoint Name** drop-down list in the **Search for Routing Entries** pane.
- 5 Click the **Routing Entries** tab.
- 6 Click the **Add** button. The **Add Routing Entry** web page opens, as shown in [Figure 112 "Add Routing Entry web page"](#) (page 225).

Figure 112
Add Routing Entry web page

- 7 Select the **DN type** from the **DN Type** drop-down list. The six choices are E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.
- 8 Enter the **DN prefix** in the text box. The DN prefix can include 0-9, #, -, ?. The prefix can be up to 30 characters in length; however, the first character must be numeric.
- 9 Enter the **Route cost** in the text box. The range is 1-255. The cost must be numeric and can be up to three digits in length. The Route Cost is used to define least-cost routing. Higher numbers indicate higher costs.
- 10 Click the **Save** button. The standby database is updated. The **Routes** web page opens, displaying the newly added routing entry in the Routing Entries pane, as shown in [Figure 113 "Added Routing Entry"](#) (page 226).

Figure 113
Added Routing Entry



- 11 See [Procedure 58 “Cutting over the database” \(page 263\)](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 12 Test the configuration changes.
- 13 See [Procedure 61 “Committing the database” \(page 265\)](#) to update the database with the configuration changes.

--End--

View the Routing Entries

Use the following procedure to view the Routing Entries.

Procedure 40 Viewing the Routing Entries

- | Step | Action |
|------|---|
| 1 | In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 “Routes web page” (page 224) . |
| 2 | Select the Active or Standby database. See Procedure 7 “Switching between the Active and Standby databases” (page 159) . The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time.


The Routes web page refreshes. |

- 3 Enter a **DN Prefix** in the text box.
- 4 Select the DN type(s) from the **DN Type** drop-down list. The seven choices are All DN Types, E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.
- 5 The **Limit results to Domain:** drop-down lists, in the **Search for Routing Entries** pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 6 Select a **Gateway Endpoint** from the **Endpoint Name** drop-down list in the **Search for Routing Entries** pane.
- 7 Click the **Routing Entries** tab.
- 8 Click **Search**.

The web page refreshes to display a list of configured Routing Entries, as shown in [Figure 114 "Search for Routing Entries web page"](#) (page 227).

The Routing Entries can be sorted in ascending or descending numerical order. See ["Sort web page by DN Prefix"](#) (page 146) .

Figure 114
Search for Routing Entries web page



--End--

Edit a Routing Entry

Use the following procedure to edit a Routing Entry.

Procedure 41 Editing a Routing Entry

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.
5	Click the Routing Entries tab.
6	Click Search . The web page refreshes to display a list of configured Routing Entries, as shown in Figure 114 "Search for Routing Entries web page" (page 227). The Routing Entries can be sorted in ascending or descending numerical order. See "Sort web page by DN Prefix" (page 146) .
7	Click a link in the DN Prefix column of the Routing Entries pane. The Edit Routing Entry web page opens, as shown in Figure 115 "Edit Routing Entry web page" (page 228).

Figure 115
Edit Routing Entry web page

- 8 Modify the **DN Type**, **DN Prefix** or **Route Cost**.
- 9 Click the **Save** button. The standby database is updated. The **Routes** web page opens, as shown in [Figure 111 "Routes web page"](#) (page 224).

-
- 10 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
 - 11 Test the configuration changes.
 - 12 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.
-

--End--


Delete a Routing Entry

Use the following procedure to delete a Routing Entry.

Procedure 42 Deleting a Routing Entry

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224).
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.
5	Click the Routing Entries tab.
6	Click Search . The web page refreshes to display a list of configured Routing Entries, as shown in Figure 114 "Search for Routing Entries web page" (page 227). The Routing Entries can be sorted in ascending or descending numerical order. See "Sort web page by DN Prefix" (page 146) .
7	Select a check box beside one or more links in the DN Prefix column of the Routing Entries pane.
8	Click the Delete button. A Confirmation Box opens, as shown in Figure 116 "Confirmation Box" (page 230), requesting confirmation before deleting the selected Routing Entry .

Figure 116
Confirmation Box



- 9 Click **OK**. The standby database is updated. The **Routes** web page refreshes, as shown in [Figure 111 "Routes web page" \(page 224\)](#).
- 10 See [Procedure 58 "Cutting over the database" \(page 263\)](#) to place the database in a Switched Over state.
- 11 See [Procedure 61 "Committing the database" \(page 265\)](#) to update the database with the configuration changes.

--End--

Copy a Routing Entry

Use the following procedure to copy a Routing Entry.

Procedure 43 Copying a Routing Entry

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.
5	Click the Routing Entries tab.
6	Click Search . The web page refreshes to display a list of configured Routing Entries, as shown in Figure 114 "Search for Routing Entries web page" (page 227) .

The Routing Entries can be sorted in ascending or descending numerical order. See ["Sort web page by DN Prefix" \(page 146\)](#) .

- 7 Select a check box beside a **link** in the **DN Prefix** column of the Routing Entries pane.
- 8 Click **Copy**.

The **Copy Wizard: Routing Entry Verify Copy Context** web page opens, as shown in [Figure 117 "Copy Wizard: Routing Entry Verify Copy Context web page" \(page 231\)](#).


Figure 117
Copy Wizard: Routing Entry Verify Copy Context web page



- 9 Select **Total number of copy** from the drop down list.
- 10 Click **Next**.

The **Copy Wizard: Routing Entry Creates Copy Sheets** web page opens, as shown in [Figure 118 "Copy Wizard: Routing Entry Creates Copy Sheets web page" \(page 231\)](#).

Figure 118
Copy Wizard: Routing Entry Creates Copy Sheets web page




- 11 Modify the copy sheet(s).
- 12 Click **Finish**. The standby database is updated.

The **Copy Wizard: Routing Entry Status of Creating Routing Entries** web page opens, as shown in [Figure 119 "Copy Wizard: Routing Entry Status of Creating Routing Entries web page" \(page 231\)](#).

Routing Entry Status of Creating Routing Entries web page" (page 232).

Figure 119

Copy Wizard: Routing Entry Status of Creating Routing Entries web page



- 13 See [Procedure 58 “Cutting over the database” \(page 263\)](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 14 Test the configuration changes.
- 15 See [Procedure 61 “Committing the database” \(page 265\)](#) to update the database with the configuration changes.

--End--

Move Routing Entries

Use the following procedure to move a Routing Entries.

Procedure 44 Moving Routing Entries

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224) .
2	Ensure Standby database is selected. See Procedure 7 “Switching between the Active and Standby databases” (page 159) .
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.

5 Click the **Routing Entries** tab.

6 Click **Search**.

The web page refreshes to display a list of configured Routing Entries, as shown in [Figure 114 "Search for Routing Entries web page" \(page 227\)](#).

The Routing Entries can be sorted in ascending or descending numerical order. See ["Sort web page by DN Prefix" \(page 146\)](#).

7 Select a check box beside one, or up to ten, **links** in the **DN Prefix** column of the Routing Entries pane.

8 Click **Move**.

The **Moving Wizard: Routing Entry Verify Moving Context** web page opens, as shown in [Figure 120 "Moving Wizard: Routing Entry Verify Moving Context web page" \(page 233\)](#).

Figure 120

Moving Wizard: Routing Entry Verify Moving Context web page



9 Choose the destination endpoint from the **Gateway endpoint is** drop-down list.

10 Click **Next**.

The **Moving Wizard: Routing Entry Creates Moving Sheets** web page opens, as shown in [Figure 121 "Moving Wizard: Routing Entry Creates Moving Sheets web page" \(page 233\)](#).

Figure 121

Moving Wizard: Routing Entry Creates Moving Sheets web page



11 Modify the copy sheet(s).

12 Click **Finish**. The standby database is updated.

The **Moving Wizard: Routing Entry Status of Moving Routing Entries** web page opens, as shown in [Figure 122 "Moving Wizard: Routing Entry Status of Moving Routing Entries web page"](#) (page 234).

Figure 122
Moving Wizard: Routing Entry Status of Moving Routing Entries web page



- 13 See [Procedure 58 "Cutting over the database"](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 14 Test the configuration changes.
- 15 See [Procedure 61 "Committing the database"](#) (page 265) to update the database with the configuration changes.

--End--

Search Routing Entries

Use the following procedure to search Routing Entries by DN Prefix.

Procedure 45 Searching Routing Entries

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224).
2	Select Standby database or Active database . See Procedure 7 "Switching between the Active and Standby databases" (page 159).
3	Select the Routing Entries tab.
4	Enter a DN Prefix in the text box.

Specify* (wild card) for all prefixes, DN digits combined with the wild card or DN digits.

- 5 Select the **All DN Types** from the **DN Type** drop-down list.
- 6 The **Limit results to Domain:** drop-down lists, in the **Search for Routing Entries** pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 7 Select a **Gateway Endpoint** from the **Endpoint Name** drop-down list.
- 8 Click **Search**.

The web page refreshes to display a list of configured Routing Entries, as shown in [Figure 114 "Search for Routing Entries web page" \(page 227\)](#).

The Routing Entries can be sorted in ascending or descending numerical order. See ["Sort web page by DN Prefix" \(page 146\)](#).

--End--

Manage a Default Route

If the routing entry DN prefix in an incoming H.323/SIP signaling request does not match a DN prefix Gateway Endpoint routing entry recorded in the NRS database, the default route is returned to the gateway.

Add a Default Route

Use the following procedure to add a Default Route.


Procedure 46 Adding a Default Route

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.

- 5 Click the **Default Routes** tab. The **Routes** web page refreshes to display a list of configured default routes,
- 6 Click the **Add** button.

The **Add Default Route** web page opens, as shown in [Figure 123 "Add Default route web page"](#) (page 236).

Figure 123
Add Default route web page




- 7 Select the **DN type** from the drop down list.
The six options are E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.

The DN type attribute determines how the phone context value, that is used to qualify the DN prefix, is built from the building blocks configured for the routing entry parents.

Note: Each DN type has only one default route.

- 8 Enter the **Route cost**. The range is 1-255. The cost must be numeric and can be up to three digits in length.
- 9 Click the **Save** button. The standby database is updated. The **Routes** web page opens displaying the new default route, as shown in [Figure 124 "Added Default route"](#) (page 237).

Figure 124
Added Default route



- 10 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 11 Test the configuration changes.
- 12 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.

--End--

View Default Routes

Use the following procedure to view Default Routes.

Procedure 47 Viewing Default Routes

- | Step | Action |
|------|--|
| 1 | In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224). |
| 2 | Select the Active or Standby database. See Procedure 7 “Switching between the Active and Standby databases” (page 159). The Active database is used for runtime queries. To modify the database it must be in Standby database view. Only Administrators can modify the standby database. One can switch between Active and Standby database views at any time.


The Routes web page refreshes. |

- 3 The **Limit results to Domain:** drop-down lists, in the **Search for Routing Entries** pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 4 Select a **Gateway Endpoint** from the **Endpoint Name** drop-down list in the **Search for Routing Entries** pane.
- 5 Click the **Default Routes** tab.
- 6 Click **Search**.

The web page expands to display a list of configured Default Route(s), as shown in [Figure 125 "Search for Default Routes web page"](#) (page 238).

The Default Routes can be sorted in ascending or descending alphabetical order. See ["Sort web page by DN type"](#) (page 146) .

Figure 125
Search for Default Routes web page



--End--

Edit a Default Route

Use the following procedure to edit a Default Route.

Procedure 48 Editing a Default Route

- | Step | Action |
|------|--|
| 1 | In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224). |

- 2 Ensure **Standby database** is selected. See [Procedure 7 “Switching between the Active and Standby databases”](#) (page 159).
- 3 Select the **DN Type** from the **DN Type:** drop-down list.
- 4 The **Limit results to Domain:** drop-down lists, in the **Search for Routing Entries** pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
- 5 Select a **Gateway Endpoint** from the **Endpoint Name** drop-down list in the **Search for Routing Entries** pane.
- 6 Click the **Default Routes** tab
- 7 Click **Search**.

The web page expands to display a list of configured Default Route(s), as shown in [Figure 125 “Search for Default Routes web page”](#) (page 238).

The Default Routes can be sorted in ascending or descending alphabetical order. See [“Sort web page by DN type”](#) (page 146) .
- 8 Click a **link** in the **DN Type** column of the Default Routes pane.

The **Edit Default Route** web page opens.
- 9 Modify the **DN Type** or **Route Cost**.
- 10 Click the **Save** button. The standby database is updated. The **Routes** web page opens displaying the modified default route, as shown in [Figure 111 “Routes web page”](#) (page 224)
- 11 See [Procedure 58 “Cutting over the database”](#) (page 263) to place the database in a Switched Over state. The configuration changes can now be tested.
- 12 Test the configuration changes.
- 13 See [Procedure 61 “Committing the database”](#) (page 265) to update the database with the configuration changes.


--End--

Delete a Default Route

Use the following procedure to delete a Default Route.

Procedure 49
Deleting a Default Route

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224) .
2	Ensure Standby database is selected. See Procedure 7 "Switching between the Active and Standby databases" (page 159) .
3	The Limit results to Domain: drop-down lists, in the Search for Routing Entries pane, contain configured Service Domains, L1 Domains and L0 Domains. Select a Service Domain, a L1 Domain and a L0 Domain from the respective drop-down lists.
4	Select a Gateway Endpoint from the Endpoint Name drop-down list in the Search for Routing Entries pane.
5	Click the Default Routes tab.
6	Click Search . The web page expands to display a list of configured Default Route(s), as shown in Figure 125 "Search for Default Routes web page" (page 238) . The Default Routes can be sorted in ascending or descending alphabetical order. See "Sort web page by DN type" (page 146) .
7	Select a check box beside one or more links in the DN Type column of the Default Routes pane.
8	Click Delete . A Confirmation Box opens, as shown in Figure 126 "Confirmation Box" (page 240) , requesting confirmation before deleting the selected Default Route . Figure 126 Confirmation Box
9	Click OK . The standby database is updated. The Routes web page opens, as shown in Figure 111 "Routes web page" (page 224) .
10	See Procedure 58 "Cutting over the database" (page 263) to place the database in a Switched Over state.



- 11 See [Procedure 61 “Committing the database” \(page 265\)](#) to update the database with the configuration changes.

--End--

Manage bulk export of routing entries

The NRS supports up to 20000 routing entries and default routes. A Comma Separated Value (CSV) file is used to create routing entries in the Standby database. The routing entries in the Standby or Active database can be exported into a CSV file.

Bulk export of routing entries

Use the following procedure for bulk export of routing entries.


Procedure 50

Bulk export of routing entries

Step	Action
------	--------


- 1 In the **NRS Manager Navigator** select **Numbering Plans > Routes**. The **Routes** web page opens, as shown in [Figure 127 "Routes web page" \(page 241\)](#).

Figure 127
Routes web page



- 2 Select the **Active** or **Standby** database. See [Procedure 7 “Switching between the Active and Standby databases” \(page 159\)](#).
- 3 Click the **Export** button. The **Bulk Export for Routing Entries and Default Routes** web page opens, as shown in [Figure 128 "Bulk Export for Routing Entries and Default Routes web page" \(page 242\)](#), summarizing the number of routing entries exported.

Figure 128
Bulk Export for Routing Entries and Default Routes web page



- 4 Click the **Download Exported Routes** link to download and save the CSV file. The **File Download** web page opens, as shown in [Figure 129 "File Download web page"](#) (page 242).


Figure 129
File Download web page



Note: Even if there are no routing entries or default routes configured in the selected database, the **Download Exported Routes** link will still be displayed. The exported file can be used as the specification for the import CSV file.


- 5 Click the **Save** button. The **Save As** web page opens, as shown in [Figure 130 "Save As web page"](#) (page 243).

Figure 130
Save As web page



- 6 Select a folder from the **Save in:** drop down list and click the **Save** button. The **Download Complete** web page opens, as shown in [Figure 131 "Download complete web page"](#) (page 243).

Figure 131
Download complete web page



- 7 Click the **Close** button.

--End--

Manage bulk import of routing entries

Recommendations

ATTENTION

The existing routing entries and default routes in the Standby database will be deleted completely during a bulk import operation, even if the import operation fails.

Nortel recommends that

- a CSV file containing configured routing entries and default routes in the Active and Standby databases be saved before a bulk import operation.
- the Active database is manually backed up before a bulk import operation. To manually backup the Active database see [Procedure 63 “Backing up the database manually” \(page 267\)](#).
- bulk export and import operations be performed during maintenance windows.
- necessary routing tests to validate the configuration be performed before committing the imported routing entries to the Active database.

Bulk import of routing entries

The bulk import operation imports routing entries into the Standby database. Routing entries can not be imported directly into the Active database. To import routing entries into the Active database

- import routing entries into the Standby database
- perform a database **Cut over**. See [Procedure 58 “Cutting over the database” \(page 263\)](#).
- perform a database **Commit**. See [Procedure 61 “Committing the database” \(page 265\)](#).


The import CSV file should contain the Service Domain, L1 Domain, L0 Domain and Endpoints which are present in the database. If the respective Service Domain, L1 Domain, L0 Domain and Endpoints are not present, then the routes will be skipped.

Use the following procedure for bulk import of routing entries into the Standby database.

Procedure 51 Bulk import of routing entries

Step	Action
1	In the NRS Manager Navigator select Numbering Plans > Routes . The Routes web page opens, as shown in Figure 111 “Routes web page” (page 224) .
2	Select the Standby database. See Procedure 7 “Switching between the Active and Standby databases” (page 159) .
3	Click the Import button. The Bulk Import for Routing Entries and Default Routes web page opens, as shown in Figure 132 “Bulk Import for Routing Entries and Default Routes web page” (page 245) .


Figure 132
Bulk Import for Routing Entries and Default Routes web page



Note: The **Import** button will be enabled only if the **Standby** database is selected.

- 4 Click the **Browse** button to choose the CSV file to be imported, or type the file name in the **Specify the import CSV file name** text box.
- 5 Click the **Submit** button. The results of the **Import** operation are shown in the web page text area.
- 6 If there are errors, edit the import CSV file and repeat the import operation. The import operation is stopped if there are more than 20 errors. There is no restriction on the editors that can be used to edit the import CSV file. The CSV file must follow the specifications summarized in “[Import CSV file specifications](#)” (page 246). See [Figure 133 "Bulk Import Results with errors web page"](#) (page 245) for an example of a **Bulk Import Results with errors web page**.


Figure 133
Bulk Import Results with errors web page



ATTENTION
The existing routing entries and default routes in the Standby database will be deleted completely during a bulk import operation, even if the import operation fails.

If there are no Import Results errors the warning page shown in [Figure 134 "Bulk Import warning web page"](#) (page 246) opens.

Figure 134
Bulk Import warning web page



- 7 Click the **OK** button to confirm the import operation, or click the **Cancel** button to abort the import operation.

--End--

Import CSV file specifications

1. Comments are indicated by # at the beginning of the line.
 2. The order of the eight mandatory data fields in each record is as follows:
 - a. serviceDomain
 - b. l1Domain
 - c. l0Domain
 - d. gatewayEndpoint
 - e. dnType
 - f. defaultRouteFlag
 - g. dnPrefix
 - h. routeCost
- Note:** All of the above 8 data fields are mandatory except dnPrefix when defaultRouteFlag is 1 (default route).
3. Each field has to be separated by a comma.
 4. NRSM is restricting singlequote, comma, and new line character in the description field of service domain, L1 domain, L0 domain, Gateway Endpoint, and user Endpoint. If any of these values are entered, an error message is thrown in the UI stating that its an invalid input character for the description field.
 5. Each record takes up one row.
 6. Fields serviceDomain/l1Domain/l0Domain/gatewayEndpoint are text fields. Domain names are case sensitive.

7. Field dnType is numeric:
 - 1: E.164 international
 - 11:E.164 national
 - 21:E.164 local (subscriber)
 - 2: Private level 1 regional (UDP location code)
 - 3: Private special
 - 4: Private level 0 regional (CDP steering code)
8. Field defaultRouteFlag is numeric:
 - 0: routing entry
 - 1: default route
9. Field dnPrefix is a text field and can have only the following characters:
 - 0-9
 - - (dash: for specifying a range. It can not be the first character of this field.)
 - # (pound sign. It can not be the first character of this field.)
 - ? (question mark. It can not be the first character of this field.)

Note: The dnPrefix field should be left blank for default route records. The input will be ignored if it is not left blank.
10. Field routeCost is numeric (range 1-255).
11. Any invalid input in a Web UI routes data entry is also invalid in an import CSV file.
12. Data entered in the ninth column (field) and beyond is ignored.
13. There is not a limit to the size of the CSV file, but a maximum of 20000 entries can be imported.

For further details on the data fields in the CSV file, see [Table 25 "Specification of data fields in the CSV file" \(page 247\)](#).

Table 25
Specification of data fields in the CSV file

Order of fields in each record	Field Type	Type	Valid characters	Mandatory	Remarks
1	serviceDomain	text field	0-9 a-z should begin with a	yes	

			<p>letter or a number (.dot sign) -(dash: for specifying a range. It can not be the first character of this field) 0-29 : maximum number of characters allowed</p>		
2	l1Domain	text field	<p>0-9 a-z should begin with a letter or a number (.dot sign) -(dash: for specifying a range. It can not be the first character of this field) 0-29 : maximum number of characters allowed</p>	yes	
3	l0Domain	text field	<p>0-9 a-z should begin with a letter or a number (.dot sign) -(dash: for specifying a range. It can not be the first character of this field) 0-29 : maximum number of characters allowed</p>	yes	
4	gatewayEndpoint	text field	<p>0-9 a-z should begin with a letter or a number (.dot sign) -(dash: for specifying a range. It can not be the first character of this field) 0-29 : maximum number of characters allowed</p>	yes	

5	description	text field	0-120 : maximum number of characters allowed can contain all alphanumeric characters except single quote '(single quote: It cannot be used)	no	
6	trustNodeEnabled	boolean	should be true or false default value will be 'true'	no	
7	tandemEndpointId	numeric		no	contains the gatewayEndpoint ids default value will be 'Not configured'
8	authEnabled	numeric	0: Not configured 1: Authentication on 2: Authentication off	no	
9	password	text field	0-24 : maximum number of characters allowed _(underscore: is allowed and also can begin with this symbol) other special characters are not allowed	no: When the field 'authEnabled' is 0: Not configured or 2: Authentication off yes: When the field 'authEnabled' is 1: Authentication on	
10	e164CountryCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	

11	e164AreaCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
12	intDialingAccessCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
13	intDialingLen	numeric	0-99 : numbers in this range is only allowed special characters and alphabets are not allowed should exceed the length of intDialingAccessCode	no	
14	natDialingAccessCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
15	natDialingLen	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
16	localDialingAccessCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	

17	localDialingLen	numeric	0-99 : numbers in this range is only allowed special characters and alphabets are not allowed should exceed the length of localDialingAccessCode	no	
18	privateL1DialingAccessCode	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
19	privateL1DialingLen	numeric	0-99 : numbers in this range is only allowed special characters and alphabets are not allowed should exceed the length of privateL1DialingAccessCode	no	
20	privateSpecialNumber1	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	
21	privateSpeNumLen1	numeric	0-99 : numbers in this range is only allowed special characters and alphabets are not allowed should exceed the length of privateSpecialNumber1	no	
22	privateSpecialNumber2	numeric	0-8 : maximum number of digits allowed 0-9 digits allowed special characters and alphabets are not allowed	no	

23	privateSpeNumLen2	numeric	0-99 : numbers in this range is only allowed special characters and alphabets are not allowed should exceed the length of privateSpecialNumber2	no	
24	addressType	numeric	0 : always contains this default value		value cannot be altered
25	address	numeric	should be in ip address format 00.00.00.00 0-255: range		
26	h323SupportType	numeric	0: H.323 not supported 1: RAS H.323 endpoint 2: Not RAS H.323 endpoint	if 2: Not RAS H.323 endpoint is selected the 'address' field should be filled with valid ip address	
27	sipSupportType	numeric	0: SIP not supported 1: Static SIP endpoint 2: Dynamic SIP endpoint	if 1: Static SIP endpoint is selected the 'address' field should be filled with valid ip address if 2: Dynamic SIP endpoint is selected any one of the fields 'sipTcpTransportEnabled' or 'sipUdpTransportEnabled' or 'sipTlsTransportEnabled' should contain the value "true"	

28	sipTcpTransportEnabled	boolean	should be 'true' or 'false' default value will be 'false'		
29	sipTcpPort	numeric	0-65535 : numbers in this range is only allowed 0-5 : maximum number of digits allowed special characters and alphabets are not allowed		
30	sipUdpTransportEnabled	boolean	should be 'true' or 'false' default value will be 'false'		
31	sipUdpPort	numeric	0-65535 : numbers in this range is only allowed 0-5 : maximum number of digits allowed special characters and alphabets are not allowed		
32	sipTlsTransportEnabled	boolean	should be 'true' or 'false' default value will be 'false'		
33	sipTlsPort	numeric	0-65535 : numbers in this range is only allowed 0-5 : maximum number of digits allowed special characters and alphabets are not allowed		
34	persistentTcpSupportEnabled	boolean	should be 'true' or 'false' default value will be 'false'		
35	sipsSupportEnabled	boolean	should be 'true' or 'false' default value will be 'false'		

36	ncsEnabled	boolean	should be 'true' or 'false' default value will be 'false'		
37	redundancyEnabled	numeric	0: Not Configured 1: Main Office 2: Redundant Office		
38	mainEndpointId	numeric	contains the gatewayEndpoint ids default value will be 'Not configured'		
39	redundantEndpointId	numeric	contains the gatewayEndpoint ids default value will be 'Not configured'		
40	dnType	numeric	1: E.164 international 11: E.164 national 21: E.164 local (subscriber) 2: Private level 1 regional (UDP location code) 3: Private special 4: Private level 0 regional (CDP steering code)	yes	
41	defaultRouteFlag	numeric	0: routing entry 1: default route	yes	
42	dnPrefix	text field	0-9 - (dash: for specifying a range. It can not be the first character of this field.) # (pound sign. It can not be the first character of this field.) ? (question mark. It can not be the first character of this field.)	yes	dnPrefix should be left blank for default route records. The input will be ignored if it is not left blank.

43	routeCost	numeric	range is 1 - 255	yes	
44	Data entered in this field and beyond is ignored. These columns can be used for comments.				

See [Figure 135 "Example of a CSV file" \(page 255\)](#) for an example of a CSV file.

Figure 135
Example of a CSV file

The image shows a spreadsheet with 27 rows of text. The first row is a title: "# Specifications for import CSV file". The following rows contain numbered comments and instructions, such as "# 1. Comments are indicated by # at the beginning of the line.", "# 2. The order of the 44 data fields in each record is as follows:", "# 3. serviceID,Domain,IPAddress, gateway,Er,description,trust,mode,tandem,Er,auth,Er,natbi,password, e164Count,e164Area,Er,Date,Er", "# 4. Each field has to be separated by comma.", "# 5. No comma is allowed within a data field.", "# 6. Each record takes up one row.", "# 7. Fields serviceID,Domain,IPAddress, gateway,Er,description,trust,mode,tandem,Er,auth,Er,natbi,password, e164Count,e164Area,Er,Date,Er are text fields.", "# 8. Domain names should have been configured in the standby database.", "# 9. Domain names are case sensitive.", "# 10. Field gateway,Er,description is a text field and this field can have only the following characters: 0-9, a-z, should begin with a letter or a number.", "# 11. (00 cannot be the first character of this field)", "# 12. dashes for specifying a range. It can not be the first character of this field)", "# 13. 0-29 maximum number of characters allowed.", "# 14. this is a mandatory field.", "# 15. Field description is a text field and this field can have only the following characters: 0-120 maximum number of characters allowed.", "# 16. can contain all alphanumeric characters except single quote", "# 17. (single quote: it cannot be used)", "# 18. Field trust,mode,Er,natbi is boolean.", "# 19. should be true or false.", "# 20. default value will be true".

Verify the numbering plan and save the NRS configuration

You should verify your numbering plan after it is configured in the NRS.

Use the following procedure to verify the numbering plan.

Procedure 52 Verifying the numbering plan

Step	Action
1	Perform a database Cut over . Cutting over places the database on the network. See Procedure 58 "Cutting over the database" (page 263) .
2	Perform the routing tests. <ul style="list-style-type: none"> • See Procedure 53 "Performing an H.323 Routing Test" (page 256). • See Procedure 54 "Performing a SIP Routing Test" (page 257).
3	If the routing tests succeed, perform a database Commit . See Procedure 61 "Committing the database" (page 265) .
4	If there are problems with the network testing, use the database Revert command to undo the Cut over . See Procedure 59 "Reverting the database changes" (page 264)

If you want to undo the latest provisioning changes, use a database **Rollback** command to synchronize the Standby database with the previous Active database. See [Procedure 60 “Rolling back changes to the database”](#) (page 265)

--End--

H.323 and SIP Routing Tests

To ascertain if a numbering plan entry exists in the active or standby database:

- See [Procedure 53 “Performing an H.323 Routing Test”](#) (page 256) to perform an H.323 Routing Test.
- See [Procedure 54 “Performing a SIP Routing Test”](#) (page 257) to perform a SIP Routing Test.

Perform an H.323 Routing Test

Use the following procedure to perform an H.323 Routing Test.

Procedure 53 Performing an H.323 Routing Test

Step	Action
1	In the NRS Manager Navigator select Tools > Routing Tests > H.323 .

The **H.323 Routing Test** web page opens, as shown in [Figure 136 “H.323 routing Test”](#) (page 256).


Figure 136
H.323 routing Test



- 2 Select **Active database** or **Standby database**. See [Procedure 7 "Switching between the Active and Standby databases"](#) (page 159)
- 3 Select the **Service domain name** from the drop-down list.
- 4 Select the **L1 domain name** from the drop-down list.
- 5 Select the **L0 domain name** from the drop-down list.
- 6 Select the **Originating gateway endpoint name** from the drop-down list.
- 7 Enter a numbering plan entry you want to check in the **DN to query** text box.
- 8 Select a number type from the **DN type** drop-down list.
- 9 Click **Test**.

The results of the H.323 Routing Test are displayed, as shown in [Figure 137 "H.323 Routing Test results"](#) (page 257).

Figure 137
H.323 Routing Test results



--End--

Perform a SIP Routing Test


Use the following procedure to perform a SIP Routing Test.

Procedure 54 Performing a SIP Routing Test

Step	Action
1	In the NRS Manager Navigator select Tools > Routing Tests > SIP .

The **SIP Routing Test** web page opens, as shown in [Figure 138 "SIP Routing Test"](#) (page 258).


Figure 138
SIP Routing Test



- 2 Select **Active database** or **Standby database**. See [Procedure 7 "Switching between the Active and Standby databases"](#) (page 159)
- 3 Select the Service Domain from the **Service domain name** drop-down list.
- 4 Select the L1 Domain name from the **L1 domain name** drop-down list.
- 5 Select the L0 Domain name from the **L0 domain name** drop-down list.
- 6 Ensure IP version 4 is selected from the **Originating endpoint address type** drop-down list.
- 7 Select the **Originating gateway endpoint name** from the drop-down list.
- 8 Enter a numbering plan entry you want to check in the **DN to query** text box.
- 9 Select the DN type you want to check from the **DN type** drop-down list.
- 10 Enter the **Phone context to query** in the text box.
- 11 Click **Test**.

The results of the SIP Routing Test are displayed, as shown in [Figure 139 "SIP Routing Test results"](#) (page 259).

Figure 139
SIP Routing Test results



--End--

Enable, disable and restart the NRS Server

Actions to:

- Forcefully disable the NRS server (nrsForceDisableServer)
- Gracefully disable the NRS server (nrsDisableServer) This command should not interrupt the existing calls.
- Enable the NRS server (nrsEnableServer)

can be performed using NRS Manager or the Command Line Interface (CLI).

The NRS can be taken out-of-service to perform maintenance or to place an Alternate NRS into service.

Note: Only users with administrator privileges can execute the NRS server action commands.

See [Procedure 55 “Disabling the NRS server” \(page 260\)](#) to take the NRS out-of-service (disabling the NRS server).

See [Procedure 56 “Enabling the NRS server” \(page 260\)](#) to bring the NRS back in to service.

See [Procedure 57 “Restarting the NRS Server” \(page 261\)](#) to restart the NRS.

The SIP Proxy must be started and running before you can disable or enable the application. To enable the SIP Proxy, click the **Restart** button in the **Service Status** pane of the **NRS Server** web page. See [Procedure 57 “Restarting the NRS Server” \(page 261\)](#).


To enable the Network Connection Service or the H.323 Gatekeeper, select **Enable** from the **Service Status** pane of the **NRS Server** web page. See [Procedure 56 “Enabling the NRS server” \(page 260\)](#).

Disable the NRS server

Use the following procedure to disable the NRS server.

Procedure 55 Disabling the NRS server

Step	Action
1	In the NRS Manager Navigator select System > NRS Server . The NRS Server web page opens.
2	Select a check box beside one or more configured services in the service name column of the Service Status pane of the NRS Server web page. See Figure 140 "Service Status pane" (page 260) . Figure 140 Service Status pane
3	Select Graceful disable from the Service Status pane of the NRS Server web page. The system disables the selected services.



--End--

Enable the NRS server

Use the following procedure to enable the NRS server.

Procedure 56 Enabling the NRS server

Step	Action
1	In the NRS Manager Navigator select System > NRS Server . The NRS Server web page opens
2	Select a check box beside one or more configured services in the service name column of the Service Status pane of the NRS Server web page. See Figure 140 "Service Status pane" (page 260) .

- 3 Select **Enable** from the **Service Status** pane of the **NRS Server** web page.

The system enables the selected services.

--End--

Restart the NRS Server

Use the following procedure to restart the NRS Server.

Procedure 57 Restarting the NRS Server

Step	Action
1	In the NRS Manager Navigator select System > NRS Server . The NRS Server web page opens.
2	Select a check box beside one or more configured services in the service name column of the Service Status pane of the NRS Server web page. See Figure 140 "Service Status pane" (page 260) .
3	Click the Restart button in the Service Status pane of the NRS Server web page.

--End--

Perform NRS database actions

The NRS database has two schemas: an active schema and a standby schema

- The active database is used for runtime queries.
- The standby database is used to modify the configuration data. Changes can be made only to the standby database.

The following database commands can be performed using NRS Manager:

- **Cut over** : Swaps the active and standby databases by interchanging the active and standby database access pointers. The active and standby databases must be swapped before configuration changes can take effect.
- **Commit**: Copies data *from* the active database *to* the standby database. Synchronizes the standby database with the active database. Overwrites the previous configuration data with the new configuration data.

- **Revert:** After a Cut over, a revert interchanges the active and standby database access pointers. The active and standby databases are swapped.
- **Roll back :** Before a Commit, a roll back undoes changes made to the standby database. A Roll Back copies data *from* the active database *to* the standby database. As a result, any changes made during the latest provisioning to the standby database are erased. The standby database is synchronized with the active database. This operation is available after a Cut over and before a Commit.

Note: Only users with administrator privileges can execute the database action commands.

Database commands are executed from the **Database** web page. The database has three states: Committed, Switched Over and Changed. The current database status is displayed in the **Database status** pane of the **Database** web page as shown in [Figure 141 "Database status: Changed" \(page 263\)](#). Depending on the database status, some commands may not be available.

For example:

- If the database is in the **Committed** state, no commands are available.
- If the database is in the **Switched Over** state, the available commands are **Commit**, **Revert**, and **Roll back**.
- If the database is in the **Changed** state, the available commands are **Cut over** and **Roll back**.

For information about database commands, refer to "[Database synchronization/operation component](#)" (page 38).

To perform a:

- database **Cut over**, see [Procedure 58 "Cutting over the database" \(page 263\)](#).
- database **Revert**, see [Procedure 59 "Reverting the database changes" \(page 264\)](#).
- database **Commit**, see [Procedure 61 "Committing the database" \(page 265\)](#).
- database **Roll back**, see [Procedure 60 "Rolling back changes to the database" \(page 265\)](#).

Perform a database Cut over


Cutting over a database switches the active and standby database access pointer. This swaps the primary and standby databases, so configuration changes take effect.

See <Fix link> to perform a database cut over.

Procedure 58 Cutting over the database


Step	Action
1	In the NRS Manager Navigator select System > Database . The Database web page opens, as shown in Figure 141 "Database status: Changed" (page 263).

Figure 141
Database status: Changed



- 2 Click the **Cut over** button. The Cut over command is issued, and the database is placed into a *Switched over* state, as shown in Figure 142 "Database status: Switched over" (page 263).

Figure 142
Database status: Switched over



- 3 Perform a database **Commit** to save the changes after the cut over. See [Procedure 61 "Committing the database" \(page 265\)](#). If you do not want to save the changes to the database, perform a database Revert (see [Procedure 59 "Reverting the database changes" \(page 264\)](#)) or database Roll back (see [Procedure 60 "Rolling back changes to the database" \(page 265\)](#)).

--End--

Revert the database changes

After a database **Cut over**, the **Revert** command interchanges the active and standby database access pointers. The active and standby databases are swapped.

See [Procedure 59 "Reverting the database changes" \(page 264\)](#) to interchange the active and standby database access pointers .

Procedure 59 Reverting the database changes

Step	Action
1	In the NRS Manager Navigator select System > Database . The Database web page opens. The Database status is <i>Switched over</i> , as shown in Figure 142 "Database status: Switched over" (page 263) .
2	Click the Revert button. The Revert command is issued, and the database is placed into a <i>Changed</i> state, as shown in Figure 141 "Database status: Changed" (page 263) .

--End--

Perform database Roll back


The **Roll back** command copies the active database to the standby database. As a result, any changes made during the latest provisioning to the standby database are erased. The standby database is synchronized with the active database. The **Roll back** command is available if the database is in the *Changed* or *Switched Over* state.

To roll back changes made to the standby database, perform [Procedure 60 "Rolling back changes to the database" \(page 265\)](#).

Procedure 60 Rolling back changes to the database

Step	Action
1	In the NRS Manager Navigator select System > Database . The Database web page opens. The Database status is <i>Switched over</i> , as shown in Figure 142 "Database status: Switched over" (page 263) .
2	Select the Roll back button. The Roll back command is issued, and the database is placed into a <i>Committed</i> state, as shown in Figure 143 "Database status: Committed" (page 265) .

Figure 143
Database status: Committed



--End--

Commit the database changes

After a database **Cut over**, the **Commit** command copies data *from* the active database *to* the standby database. The previous configuration data is overwritten with the new configuration data. The standby database is synchronized with the active database.

See [Procedure 61 "Committing the database" \(page 265\)](#) to perform a database **Commit**.

Procedure 61 Committing the database

Step	Action
1	In the NRS Manager Navigator select System > Database . The Database web page opens. The Database status is <i>Switched</i>

over, as shown in [Figure 142 "Database status: Switched over"](#) (page 263).

- 2 Select the **Commit** button. The **Commit** command is issued, and the database is placed into a *Committed* state, as shown in [Figure 143 "Database status: Committed"](#) (page 265).

--End--

Backup the database

NRS Manager provides a facility for backing up the NRS database.

The database can be automatically backed up or manually backed up.

- See the **automatic backup** option in [Procedure 6 "Configuring system-wide settings"](#) (page 156) to configure the backup time and location.
- The **manual backup** option allows you to immediately back up the database.

Note 1: Autobackup settings are saved during a database backup and are not changed during a database restore.

Note 2: Only users with administrator privileges can execute the database backup commands.


Automatically backup the database

Use the following procedure to automatically backup the database.

Procedure 62 Backing up the database automatically

Step	Action
1	In the NRS Manager Navigator select Tools > Backup . The Database Backup web page opens, as shown in Figure 144 "Database Backup web page" (page 267).

Figure 144
Database Backup web page



- 2 Select **Auto backup** from the **Select backup action** drop-down list.
- 3 Click the **Submit** button.
The **System Wide Settings** web page opens, as shown in [Figure 48 "System Wide Settings web page" \(page 156\)](#).
- 4 Perform step 3 to step 6 of [Procedure 6 "Configuring system-wide settings" \(page 156\)](#).

--End--

Manually backup the database

Use the following procedure to manually backup the database.

Procedure 63 Backing up the database manually

Step	Action
1	In the NRS Manager Navigator select Tools > Backup . The Database Backup web page open, as shown in Figure 144 "Database Backup web page" (page 267) .
2	Select Manual backup from the Select backup action drop-down list.
3	Click the Submit button. A summary of the manual backup is displayed in the text area of the Database Backup web page, as shown in Figure 145 "Manual back up" (page 268) .


Two links appear on the screen:

- **Download the latest log file.**

See [Procedure 65 “Downloading the latest backup log file” \(page 271\)](#) to download the latest backup log file.

- **Download the latest backup file.**
See [Procedure 64 “Downloading the latest backup file” \(page 268\)](#) to download the latest backup file.

Figure 145
Manual back up



--End--

Download the latest backup file

Use the following procedure to download the latest backup file.

Procedure 64 Downloading the latest backup file

Step	Action
1	See Procedure 63 “Backing up the database manually” (page 267)
2	Click the Download the latest backup file link on the Database Backup web page. See Figure 145 "Manual back up" (page 268) .

The **File Download** dialog box opens.


Figure 146
File Download dialog box



The **File Download** dialog box provides the option to open the latest backup file or download and save the latest backup file to the user's local client (PC).

- 3 Click **Open** to view the latest backup file.

Figure 147
Latest backup file



The file is a compressed file that contains multiple backup files. The name of the compressed file is nrsback.tar


Select a file from the **Name** column. Click the **Extract** icon to download the selected file.

Or

- 4 Click **Save** to save the file to a local client.

The **Save As** dialog box opens.


Figure 148
Save As dialog box



- 5 Select a folder from the **Save in** drop down list. Enter a file name in the **File name** text box. Click **Save**.

The **Download complete** window opens.

Figure 149
Download complete window



- 6 Click **Close**.

--End--

Download the latest backup log file

Use the following procedure to download the latest backup log file.

Procedure 65 Downloading the latest backup log file

Step	Action
1	See Procedure 63 "Backing up the database manually" (page 267)
2	Click Download the latest log file link on the Database Backup web page. See Figure 145 "Manual back up" (page 268).

A window opens containing the latest backup log file, as shown in [Figure 147 "Latest backup file"](#) (page 269). The name of the log file is DbBackupLog.xml. The DbBackupLog.xml file contains information about the backup. For example, if there were errors during the back up process.

Figure 150
Backup log file



3	The backup log file can be saved using the File > Save As... menu option.
---	---

--End--

Restore the NRS database

The database can be restored:

- From the connected Signaling Server
- From a secure FTP site
- From the client machine

Note 1: Autobackup settings are saved during a database backup and are not changed during a database restore.

Note 2: Only users with administrator privileges can execute the database restore commands.

Upon executing the database restore operation on the same database, the ID (that is, Primary Key) is changed in the standby schema. As a result, during Cut over (just before swapping the active and standby schema), it removes the old registration details and updates the new registration entries because of data mismatch. So, all the endpoints will be

deregistered for a limited time until the next re-registration occurs. This action functions in the same manner as Release 4.0/4.5. To minimize the impact of the operation due to the execution of the database restore and Cut over, the following steps should be followed:

1. Set the re-registration time to 30 seconds, and wait for the original time period to expire.
2. Perform the database restore and Cut over and wait for 30 seconds
3. If desired, return the re-registration time back to its original value

For instance, if the original registration period is set to five minutes, perform the following steps:

1. Change the re-registration period to 30 seconds and wait for five minutes.
2. Execute the database restore and Cut over operations and wait for 30 seconds.
3. Change the re-registration period back to five minutes.


Restore the database

Use the following procedure to restore the database.

Procedure 66 Restoring the database

Step	Action
1	In the NRS Manager Navigator select Tools > Restore . The Database Restore web page opens, as shown in Figure 151 "Database Restore web page" (page 272).

Figure 151
Database Restore web page



- 2 The database can be restored from three source locations:

- From the **Connected Signaling Server**.
See [Procedure 67 “Restoring from the connected Signaling Server” \(page 273\)](#) to restore the database from the Connected Signaling Server.
- From a secure **FTP site**.[Procedure 69 “Restoring from a client machine” \(page 275\)](#)
See [Procedure 68 “Restoring from a secure FTP site” \(page 274\)](#) to restore the database from a secure FTP site.
- From the **Client machine**.
See to restore the database from the Client machine.

--End--


Restore from the connected Signaling Server

Use the following procedure to restore from the connected Signaling Server.

Procedure 67 Restoring from the connected Signaling Server

Step	Action
1	In the NRS Manager Navigator select Tools > Restore . The Database Restore web page opens, as shown in Figure 151 "Database Restore web page" (page 272) .
2	Select Connected Signaling Server from the Select restore source from drop-down list. See Figure 151 "Database Restore web page" (page 272) .
3	Click the Submit button. A message displays in the text area of the Database Restore web page showing a summary of the database restore from the Signaling Server. See Figure 152 "Database Restore from connected Signaling Server" (page 274) . The Download the latest log file link also appears on the web page. See Procedure 70 “Downloading the latest restore log file” (page 277) for downloading the restore log file.

Figure 152
Database Restore from connected Signaling Server



--End--


Restore from a secure FTP site

Use the following procedure to restore from a secure FTP site.

Procedure 68
Restoring from a secure FTP site

Step	Action
1	In the NRS Manager Navigator select Tools > Restore . The Database Restore web page opens, as shown in Figure 151 "Database Restore web page" (page 272).
2	Select FTP site from the Select restore source from drop-down list.
3	Click the Submit button. The DB Restore from FTP Site web page opens, as shown in Figure 153 "Database Restore from FTP site" (page 274).

Figure 153
Database Restore from FTP site




- 4 Enter the **FTP restore site's IP address** in the text box.
- 5 Enter the **FTP restore site's path** in the text box.
- 6 Enter the **FTP restore site's username** in the text box.
- 7 Enter the **FTP restore site's password** in the text box.
- 8 Click **Restore**.

A message is displayed in the text area of the DB Restore from FTP Site web page, showing a summary of the database restore from the FTP site. See [Figure 154 "Database Restore from FTP site results"](#) (page 275).

The **Download the latest log file** link also appears on the web page. See [Procedure 70 "Downloading the latest restore log file"](#) (page 277) for downloading the restore log file.

Figure 154
Database Restore from FTP site results



--End--

Restore from a client machine


Use the following procedure to restore from a client machine.

Procedure 69

Restoring from a client machine

Step	Action
1	In the NRS Manager Navigator select Tools > Restore . The Database Restore web page opens, as shown in Figure 151 "Database Restore web page" (page 272).
2	Select Client machine from the Select restore source from drop-down list. See Figure 151 "Database Restore web page" (page 272). The Database Restore web page opens, as shown in Figure 155 "Database Restore from client machine" (page 276).


Figure 155
Database Restore from client machine



- 3 The **Database Restore** web page contains a **Specify restore file name** text box and a **Browse** button. Click **Browse** to navigate to the folder containing the backup file.

The **Choose file** dialog window opens.

Figure 156
Choose file dialog window



- 4 Select the backup file, and click **Open**.


The **Specify restore file name** text box auto-fills with the path and filename of the backup file.

- 5 Click the **Submit** button.

A message is displayed in the text area of the **Database Restore** web page showing a summary of the database restore

from the client machine. See [Figure 157 "Database Restore client machine results"](#) (page 277).

Figure 157
Database Restore client machine results



The **Download the latest log file** link also appears on the web page. See [Procedure 70 "Downloading the latest restore log file"](#) (page 277) to download the restore log file.

--End--

Note: During a 'Restore' operation it is not allowed to do a 'reboot' of the system. In case the system goes down due to reasons such as power failure, it is recommended that the restore operation be restarted again.

Download the latest restore log file

Use the following procedure to download the latest restore log file.

Procedure 70 Downloading the latest restore log file

Step	Action
1	<p>NRS Manager provides the option to restore the database from three source locations:</p> <ul style="list-style-type: none"> • See Procedure 67 "Restoring from the connected Signaling Server" (page 273) to restore the database from the Connected Signaling Server. • See Procedure 68 "Restoring from a secure FTP site" (page 274) to restore the database from a secure FTP site. • See Procedure 69 "Restoring from a client machine" (page 275) to restore the database from the Client machine.

- 2 Click the **Download the latest log file** link to view the Restore log file.

A window opens containing the latest restore log file, as shown in [Figure 158 "Restore log file" \(page 278\)](#). The name of the log file is DbRestoreLog.xml. The DbRestoreLog.xml file contains information about the database restore.

Figure 158
Restore log file



- 3 The restore log file can be saved, using the **File > Save As...** menu option.

--End--

GK/NRS Data Upgrade

The **Tools > GK/NRS Data Upgrade** link in the **NRS Manager Navigator** is used to upgrade a Succession 3.0 H.323 Gatekeeper to a CS 1000 Release 4.0 (or later) NRS. If required, this procedure must be completed as part of your upgrade procedures.

For detailed procedures, refer to *Signaling Server Installation and Commissioning (NN43001-312)* ().

Migration overview

It is best practice to configure both a Primary and Secondary NRS to assure high availability of the IP Telephony network.

It is best practice to configure both a Primary and a Backup Security Server per ECM security domain to assure a highly available authentication and authorization service for OA&M users who need to access managed systems/elements in the ECM security domain, as well as for auxiliary applications that rely on continuous availability of the ECM framework web services API to monitor and control the CS 1000.

To migrate your system, you must convert the Succession 3.0 H.323 Gatekeeper database into a CS 1000 Release 4.0 (or later) NRS database. This involves the following tasks:

- Backing up the Succession 3.0 H.323 Gatekeeper database using Element Manager to ftp site or management PC.
- Installing and configuring the Linux-based NRS Primary and Secondary servers with the new IP addresses. See [“Introduction” \(page 106\)](#) and [“Installation of Linux operating system, ECM framework and NRS application” \(page 108\)](#).

This step has four substeps:

- a. Install the Linux operating system on IBM 306m (NTDU99AA) or on HP DL320 G4 (NTDU97AA) stand-alone servers.
- b. Install the Primary and Secondary NRS, the Primary Security Service and the Backup Security Service.
- c. Add the NRS Manager for the Primary and Secondary NRS servers as managed elements of the ECM.
- d. Create user accounts and assign roles and permissions for access to the Primary and Secondary NRS servers from the ECM.

Refer to *Linux Platform Base and Applications Installation and Commissioning (NN43001-315)* () for detailed information on installing the Linux operating system, the ECM framework, the NRS and the Primary and Backup Security Services.

Refer to *Enterprise Common Manager Fundamentals (NN43001-116)* () for detailed information on adding a managed element to the ECM, creating user accounts, and assigning roles and permissions for access to the NRS server from the ECM.

- Adding a Service Domain and Level 1 domain using NRS Manager. (These two domains do not exist in the Release 3.0 Gatekeeper.) See [Procedure 8 “Adding a Service Domain” \(page 160\)](#) to add a Service Domain . See [“Manage a Level 1 Domain \(UDP\)” \(page 166\)](#) to add a Level 1 Domain.
- Using the **Tools > GK/NRS Data Upgrade** link in the **NRS Manager Navigator** to convert the H.323 Gatekeeper database to the CS 1000 Release 4.0 (or later) NRS database using NRS Manager.
- Performing database **Cut over** and database **Commit** commands.

The converted H.323 Gatekeeper database is stored in the NRS standby database. Changes made to the standby database do not immediately effect call processing. Before changes made to the standby database effect call processing, database **Cut over** and **Commit** commands must be executed. See [“Perform NRS database actions” \(page 261\)](#).

See Procedure 58 “Cutting over the database” (page 263) to perform a database **Cut over** . See Procedure 61 “Committing the database” (page 265) to perform a database **Commit**.

Note: Only users with administrator privileges can execute Gatekeeper/NRS (GK/NRS) data conversion.

Figure 159 "GK/NRS Data Upgrade web page" (page 280) and Figure 160 "GK/NRS Data Upgrade results" (page 280) are only for illustration purposes, to show the user interface for the Gatekeeper to NRS Upgrade area in NRS Manager.

Figure 159
GK/NRS Data Upgrade web page





Figure 160
GK/NRS Data Upgrade results



Configure and manage the VxWorks-based Network Routing Service

Contents

This section contains information on the following topics:

- “Introduction” (page 282)
- “Browser configuration” (page 283)
 - “Supported browser” (page 283)
 - “Configuring the browser and display settings” (page 283)
- “Enabling and configuring the NRS server” (page 285)
 - “Standalone mode” (page 286)
 - “Co-resident mode” (page 287)
- “Accessing NRS Manager” (page 294)
- “The NRS Manager interface” (page 299)
 - “NRS Manager toolbar” (page 299)
 - “Help and Logout links” (page 301)
- “Logging out of NRS Manager” (page 302)
- “Home tab” (page 302)
 - “Verifying that the NRS is the Primary NRS and is active” (page 302)
 - “Configuring system-wide settings” (page 303)
 - “Configuring the Primary and Alternate NRS Server Settings” (page 305)
 - “Edit the login warning banner” (page 9)
- “Configuration tab” (page 312)
 - “Configuring the NRS database” (page 312)
 - “Switching between the active and standby databases” (page 313)
 - “Adding a Service Domain” (page 315)
 - “Adding a Level 1 Domain (UDP)” (page 319)

- “Adding a Level 0 Domain (CDP)” (page 325)
- “Adding a Gateway Endpoint” (page 332)
- “Adding a User Endpoint (SIP Phone)” (page 341)
- “Adding a Routing Entry” (page 348)
- “Adding Default Routes” (page 356)
- “Adding a Collaborative Server” (page 362)
- “Tools tab” (page 369)
 - “H.323 and SIP Routing Tests” (page 369)
 - “Enabling and disabling the NRS Server” (page 374)
 - “Performing NRS database actions” (page 376)
 - “Backing up the database” (page 384)
 - “Restoring the database” (page 388)
 - “GK/NRS Data Upgrade” (page 394)
 - “SIP Phone Context” (page 396)
 - “SSL/TLS Configuration” (page 398)
- “Reports tab” (page 398)
 - “Viewing the database reports” (page 398)
- “Administration tab” (page 401)
 - “Configuring and administering users” (page 401)
 - “Creating new users” (page 402)
 - “Viewing configured users” (page 403)
 - “Editing or deleting configured users” (page 404)
 - “Changing your password” (page 406)
- “Accessing the NRS directly from the Signaling Server” (page 406)

Introduction

The Network Routing Service (NRS) can be configured and maintained through a web interface called NRS Manager. NRS Manager is a multi-customer user interface. The NRS includes a Service Domain level that is used to support multiple customers.

Note: NRS Manager replaces the Succession 3.0 H.323 Gatekeeper web pages in CS 1000 Element Manager in CS 1000 Release 4.0 and later.

The NRS can also be accessed directly from the Command Line Interface of the Signaling Server. This does not provide access to NRS Manager, but does allow users to run NRS-specific CLI commands.

Browser configuration

Your web browser must be properly configured before using NRS Manager.

Supported browser

NRS Manager is supported only on Microsoft Internet Explorer version 6.0 (or later).

ATTENTION

Nortel discourages use of the Back, Forward, and Refresh buttons of the browser.

Use of the Back button is not recommended while the NRS Manager application is launched, because NRS Manager pages contain dynamic data content. NRS Manager provides a path for navigation purposes on top of every NRS Manager page.

Nortel recommends that the user click the navigation path to go back to the previous page (instead of using the Back button).

Configuring the browser and display settings

Before you can use NRS Manager, the following tasks must be completed:

- Enable pop-ups in the browsers search utility (mandatory).
- Configure the Internet Explorer browser settings (mandatory).
- Configure the Windows Display settings (highly recommended).

Note: The interface for the Internet Explorer browser settings and Windows Display settings may vary by browser version and by operating system.

Enabling pop-ups

If you are using a browser search utility (such as the Google™ search engine or the Yahoo!™ search engine), ensure that pop-ups are enabled. Enabling pop-up windows is usually done at the search utility's toolbar.

ATTENTION

Do not block pop-up windows if you are using a search utility (such as Google™ or Yahoo!™ search engines) in your browser.

Configuring the browser settings

Follow [Procedure 71 "Configure the Internet Explorer browser settings" \(page 284\)](#) to configure the following Internet Explorer browser settings:

- Browser retrieve page information.
- Empty session information.
- Deselect the AutoComplete options.

Procedure 71
Configure the Internet Explorer browser settings

Step	Action
1	Select View > Text Size > Medium to configure text size in the browser.
2	Select Tools > Internet Options in the Internet Explorer browser window. The Internet Options window opens.
3	Configure the browser retrieve page information: a On the General tab under the Temporary Internet files section, click Settings . The Settings window opens. b Under the Check for newer versions of stored pages section, select the Every visit to the page option. c Click OK .
4	Configure the empty session information: a Select the Advanced tab. b Under Security , select Empty Temporary Internet Files folder when browser is closed .
5	Deselect the AutoComplete options. a Select the Content tab. b Under Personal Information , click AutoComplete . The AutoComplete Settings window opens. c Under the Use AutoComplete for section, deselect Forms and User names and passwords on forms . Click OK (to close the AutoComplete Settings window) Click OK (to close the Internet Options window)

--End--

Configuring the Windows Display settings

Follow [Procedure 72 "Configuring the Windows Display settings"](#) (page 285) to configure the Windows display settings.

Procedure 72
Configuring the Windows Display settings

Step	Action
1	Select Start > Settings > Control Panel > Display . The Display Settings window opens.
2	Select the Settings tab.
3	Select True Color (32 bit) from the Colors drop-down list.
4	Under Screen area , select 1280 by 1024 pixels .
5	Click OK .

--End--

Enabling and configuring the NRS server

The NRS server must be enabled and properly configured before any NRS data can be provisioned using NRS Manager.

ATTENTION

The Network Routing Service can be redundantly installed across a cluster of Network Routing Servers sharing a distributed database.

In CS 1000 Release 5.0 or later the cluster is comprised of a Primary Network Routing Server and an Alternate Network Routing Server. Optionally, a Failsafe Network Routing Server can be co-resident with an IP Peer Gateway (H.323 or SIP) on a Signaling Server in an IP telephony node.

The Primary, Alternate and (optional) Failsafe Network Routing Servers must host the same major software release. For example, all servers must host release 4.50.xx or 5.00.xx. Network Routing Servers hosting different major software releases cannot synchronize the NRS databases.

Refer to Signaling Server: Installation and Configuration (553-3001-212) for detailed information on the Network Routing Server installation procedures.

The VxWorks-based NRS server can be configured in two modes:

- Standalone mode — The host Signaling Server is not registered to a Call Server. During installation of the Signaling Server, ensure that the Call Server IP address is configured as 0.0.0.0.

Note: During installation of the Signaling Server in stand-alone mode (using the Signaling Server Software Install Tool), the administrator is not prompted to enter the Call Server IP address. Instead, the Call Server IP address defaults to 0.0.0.0. During the installation, the parameter confirmation screen displays the IP address as 0.0.0.0.

- Co-resident mode — The NRS is co-resident on a Signaling Server that is registered to a Call Server. The Signaling Server can also run other applications, such as the IP Line TPS and the Virtual Trunk applications.

Standalone mode

Procedure 73

Enabling and configuring the NRS server in stand-alone mode

Step	Action
1	<p>Enable the NRS and configure the NRS server settings using the Signaling Server Software Install Tool.</p> <p>Refer to <i>Signaling Server Installation and Commissioning (NN43001-312)</i> () for detailed information on the Signaling Server Software Install Tool and for detailed installation procedures for configuring a stand-alone Signaling Server.</p> <p>The following is a summary of the tasks required for the installation of a stand-alone Signaling Server. Follow the detailed procedures presented in <i>Signaling Server Installation and Commissioning (NN43001-312)</i> () for complete instructions.</p> <ol style="list-style-type: none"> Perform the introductory steps for the Signaling Server installation. Configure the Signaling Server as a Leader, when prompted. Configure stand-alone mode (NRS only — no Call Server) for the Signaling Server. Select whether the NRS supports the SIP Redirect Server, the H.323 Gatekeeper, or both. Select the type of NRS — Primary or Alternate. Enter the following:

1. Enter the hostname.
 2. Enter the ELAN network interface IP address, subnet mask, and gateway IP address.
 3. Enter the TLAN network interface IP address, subnet mask, and gateway IP address.
- g** The Call Server IP address defaults to 0.0.0.0. for a stand-alone Signaling Server.
- h** Enter the IP address of the NRS (Primary or Alternate NRS IP address).
- 2** Restart the Signaling Server after proper configuration of the Signaling Server.
- If the Signaling Server restarts successfully, the NRS is configured with the default settings.
- 3** Log in to the NRS Manager using the default user ID and password. See [Procedure 76 "Logging in to NRS Manager using the browser address field" \(page 295\)](#).
- 4** Configure the NRS Server Settings in NRS Manager. See [Procedure 80 "Configuring NRS Server Settings" \(page 305\)](#).
- 5** Log out of the NRS. See [Procedure 77 "Logging out of NRS Manager" \(page 302\)](#).
- 6** Restart the Signaling Server.
- If the Signaling Server boots successfully, then the NRS server is properly configured.

--End--

Co-resident mode

Procedure 74

Enabling and configuring the NRS server in co-resident mode

Step	Action
------	--------

Note: If the Signaling Server has been configured in co-resident mode, proceed directly to [step 3](#).

- | | |
|----------|--|
| 1 | Enable the NRS and configure the NRS server settings using the Signaling Server Software Install Tool. |
|----------|--|

Refer to *Signaling Server Installation and Commissioning (NN43001-312)* () for detailed information on the Signaling Server Software Install Tool and for detailed installation procedures for configuring a co-resident Signaling Server.

The following is a summary of the tasks required for the installation of a co-resident Signaling Server. Follow the detailed

procedures presented in *Signaling Server Installation and Commissioning (NN43001-312)* () for complete instructions.

- a Perform the introductory steps for the Signaling Server installation.
 - b Configure the Signaling Server as a Leader, when prompted.
 - c Select co-resident mode (LTPS + VTRK + NRS) for the Signaling Server.
 - d Select whether the NRS supports the SIP Redirect Server, the H.323 Gatekeeper, or both. (The option to configure no NRS is also available.)
 - e Select the type of NRS — Primary, Alternate or Failsafe.
 - f Enter the following:
 1. Enter the hostname.
 2. Enter the ELAN network interface IP address, subnet mask, and gateway IP address.
 3. Enter the TLAN network interface IP address, subnet mask, and gateway IP address.
 - g Enter the IP address of the NRS (Primary and/or Alternate NRS IP address).
- 2 Restart the Signaling Server after proper configuration of the Signaling Server.
 - 3 Log in to Element Manager.
 - 4 Select **IP Telephony > Nodes: Servers, Media Cards > Configuration** from the navigator.

The **Node Configuration** web page opens.
 - 5 Click **Edit**.

The **Edit** web page opens.
 - 6 Click **Signaling Servers** to expand the section.

A list of Signaling Servers opens.
 - 7 Select the appropriate **Signaling Server xxx.xxx.xxx.xxx Properties**.

The properties for that Signaling Server display, as shown in [Figure 161 "Signaling Server xxx.xxx.xxx.xxx properties" \(page 289\)](#).

Figure 161
Signaling Server xxx.xxx.xxx.xxx properties

Signaling Server 207.179.153.100 Properties		Remove
Role	Leader	
Management LAN (ELAN) IP address	<input type="text" value="207.179.153.100"/>	*
Management LAN (ELAN) MAC address	<input type="text" value="00:02:B3:CF:0A:EC"/>	*
Voice LAN (TLAN) IP address	<input type="text" value="192.168.253.6"/>	*
Voice LAN (TLAN) gateway IP address	<input type="text" value="192.168.253.1"/>	
Hostname	<input type="text" value="NODE8"/>	*
H323 ID	<input type="text" value="SCSE1_GW"/>	
Enable set TPS	<input checked="" type="checkbox"/>	
Enable virtual trunk TPS	<input type="text" value="H.323 only"/>	
Enable SIP Proxy / Redirect Server	<input checked="" type="checkbox"/>	
SIP Transport Protocol	<input type="text" value="TCP"/>	
Local SIP Port	<input type="text" value="5060"/>	
SIP Domain name	<input type="text" value="myServiceProvider.cor"/>	
SIP Gateway Endpoint Name	<input type="text" value="sipGWsite1"/>	
SIP Gateway Authentication Password	<input type="text"/>	
Enable H323 Gatekeeper	<input checked="" type="checkbox"/>	
Network Routing Service Role	<input type="text" value="Primary"/>	
System name	<input type="text" value="InnLab"/>	
System location	<input type="text" value="T5"/>	
System contact	<input type="text" value="Buck"/>	

- 8 To enable the NRS, do the following:
- a Enable the SIP Proxy/Redirect Server and/or the H.323 Gatekeeper, as appropriate:
 - Select the **Enable SIP Proxy / Redirect Server** check box to enable the SIP Redirect Server (see [Figure 162 "Enabling the SIP Redirect Server"](#) (page 289)).

Figure 162
Enabling the SIP Redirect Server

Enable SIP Proxy / Redirect Server

Note 1: CS 1000 VxWorks-based NRS does not support the SIP Proxy Server.

Note 2: The SIP Trunk Gateway must also be configured.

 - Select the **Enable H.323 Gatekeeper** check box to enable the H.323 Gatekeeper (see [Figure 163 "Enabling the H.323 Gatekeeper"](#) (page 290)).

Figure 163
Enabling the H.323 Gatekeeper

Enable H323 Gatekeeper

Note: The H.323 Gateway must also be configured..

- b** Select the role of the NRS from the **Network Routing Service Role** drop-down list.

The three options are Primary, Alternate, and Failsafe.

- 9 Configure the other required Signaling Server properties.
 - 10 Click **Save and Transfer** to save the changes and transfer the properties to all nodes.
 - 11 Click **Logout** at the bottom of the navigator to log out of Element Manager.
 - 12 Restart the Signaling Server.
 - 13 After a successful restart of the Signaling Server, log in to NRS Manager using the default user ID and password. See [Procedure 76 “Logging in to NRS Manager using the browser address field” \(page 295\)](#).
 - 14 Configure the NRS Server Settings in NRS Manager. See [Procedure 80 “Configuring NRS Server Settings” \(page 305\)](#).
 - 15 Log out of the NRS. See [Procedure 77 “Logging out of NRS Manager” \(page 302\)](#).
 - 16 Restart the Signaling Server.
- If the Signaling Server boots successfully, then the NRS server is properly configured.

--End--

Changing a co-resident NRS server to a stand-alone NRS server

Use the Signaling Server Software Install Tool to change a co-resident NRS server to a stand-alone NRS.

Task summary

This section provides a high-level overview of the Configuring and Managing the VxWorks-based NRS task. The main steps are:

- Accessing the NRS Manager.
- Configuring the NRS.
- Configuring the Primary and Alternate NRS servers.

- Configuring and managing the NRS database. The NRS database provides a central database of addresses that are required to route calls across the network.
- Procedures for performing other tasks in the NRS including testing routes, enabling/disabling the NRS server, viewing the SIP Phone Context, and viewing database reports.
- Administering NRS Manager users.
- Logging out of NRS Manager.

In more detail, the Configuring and Managing the VxWorks-based NRS task is comprised of:

Step	Action
1	<p>Log in to NRS Manager. See “Accessing NRS Manager” (page 294).</p> <p>You can log in two ways:</p> <ul style="list-style-type: none"> • See Procedure 75 “Logging in to NRS Manager from Element Manager” (page 294) • See Procedure 76 “Logging in to NRS Manager using the browser address field” (page 295)
2	<p>Verify that the NRS is the Primary NRS and is active. See Procedure 78 “Verifying that the NRS is the Primary NRS and is active” (page 302)</p>
3	<p>Configure System Wide Settings. See Procedure 79 “Configuring system-wide settings” (page 304)</p>
4	<p>Configure the Primary and Alternate NRS Server Settings. See Procedure 80 “Configuring NRS Server Settings” (page 305)</p>
5	<p>Build the NRS database.</p> <p>The NRS database comprises</p> <ul style="list-style-type: none"> • service domains, L1 domains and L0 domains • collaborative servers • gateway endpoints • routing entries <p>Note: The following steps must be performed in the order given.</p> <p>a Create the Service Domain, Level 1 Domains (UDP), Level 0 Domains (CDP), which hold the endpoint numbering plans</p>

on the NRS. This is complementary to the CDP configuration on the Call Server.

1. See [“Adding a Service Domain”](#) (page 315)
2. See [“Adding a Level 1 Domain \(UDP\)”](#) (page 319)
3. See [“Adding a Level 0 Domain \(CDP\)”](#) (page 325)

b Add collaborative servers.

Note: You do not have to configure Gateway Endpoint, User Endpoints, or Routing Entries before you configure the Collaborative Servers.

1. See [Procedure 110 “Adding a Collaborative Server”](#) (page 362)
2. See [Procedure 111 “Viewing the Collaborative Servers”](#) (page 366)

c Add the endpoints and add the endpoint prefixes.

1. See [“Adding a Gateway Endpoint”](#) (page 332)
2. See [Procedure 98 “Adding a User Endpoint”](#) (page 341)

d Add the numbering plan entries for each endpoint, including the Cost Factor for each entry.

1. See [Procedure 102 “Adding a Routing Entry”](#) (page 348)
2. See [Procedure 106 “Adding a Default Route”](#) (page 356)

e **Verify the numbering plan configuration.** See [“Verifying the numbering plan and saving the NRS configuration”](#) (page 369)

f **Perform database actions.** See [“Performing NRS database actions”](#) (page 376) To save the NRS configuration, refer to the procedures in this section.

6 **Test the numbering plans** (see [“H.323 and SIP Routing Tests”](#) (page 369)).

- See [Procedure 115 “Performing an H.323 Routing Test”](#) (page 369)
- See [Procedure 116 “Performing a SIP Routing Test”](#) (page 371)

7 **Perform server actions** (see [“Enabling and disabling the NRS Server”](#) (page 374)).

- See [Procedure 117 “Disabling the NRS server”](#) (page 374)
- See [Procedure 118 “Enabling the NRS server”](#) (page 375)

-
- 8 **Perform database actions** (see “Performing NRS database actions” (page 376)).
- See Procedure 119 “Cutting over the database” (page 378)
 - See Procedure 120 “Reverting the database changes” (page 379)
 - See Procedure 121 “Rolling back changes to the database” (page 380)
 - See Procedure 122 “Committing the database” (page 381)
 - See Procedure 123 “Cutting over and committing changes to the database” (page 383)
- 9 **Back up the NRS database.** See “Backing up the database” (page 384)
- See Procedure 124 “Automatically backing up the database” (page 384)
 - See Procedure 125 “Manually backing up the database” (page 385)
- The NRS database can also be restored, if required. See “Restoring the database” (page 388)
- See Procedure 129 “Restoring from the connected Signaling Server” (page 389)
 - See Procedure 130 “Restoring from an FTP site” (page 390)
 - See Procedure 131 “Restoring from a client machine” (page 392)
- 10 If necessary, **convert** the Succession 3.0 Gatekeeper **database** to a CS 1000 Release 4.0 (or later) NRS database. See “GK/NRS Data Upgrade” (page 394) and refer to the Upgrades NTPs for detailed information.
- 11 **View the SIP Phone Context.** See “SIP Phone Context” (page 396).
- 12 **View reports** on the status of the database. See “Viewing the database reports” (page 398).
- 13 **Administer users** of the NRS (see “Configuring and administering users” (page 401)).
- See “Creating new users” (page 402)
 - See “Viewing configured users” (page 403)
 - See “Editing or deleting configured users” (page 404)

- 14 **Log out of NRS Manager.** See [Procedure 77 “Logging out of NRS Manager” \(page 302\)](#)

--End--

Accessing NRS Manager

Access NRS Manager in one of the following two ways:

- Click the **Network Routing Service** link in the navigator within Element Manager. See [Procedure 75 “Logging in to NRS Manager from Element Manager” \(page 294\)](#).
- Enter the IP address of NRS Manager in the browser’s address field. See [Procedure 76 “Logging in to NRS Manager using the browser address field” \(page 295\)](#).

Note: To access the NRS directly from the Signaling Server, see [“Accessing the NRS directly from the Signaling Server” \(page 406\)](#).

To log in to the NRS from Element Manager, follow the steps in [Procedure 75 “Logging in to NRS Manager from Element Manager” \(page 294\)](#).

Procedure 75 Logging in to NRS Manager from Element Manager

Step	Action
1	Log in to Element Manager.
2	<p>Select Dialing and Numbering Plans > Network Routing Service from the navigator.</p> <p>The Network Routing Service (NRS) web page opens (see Figure 164 “Network Routing Service (NRS) configuration web page” (page 294)).</p> <p>Figure 164 Network Routing Service (NRS) configuration web page</p>

Managing: [207.179.153.99](#)
Dialing and Numbering Plans » Network Routing Service (NRS)

Network Routing Service (NRS)

Please enter the NRS IP Address then press button " Next > "

Input description	Input value
NRS IP Address:	<input type="text" value="192.168.253.6"/>

- 3 Enter the IP address of the NRS in the **NRS IP Address** text box.

Note: The IP address that automatically appears may not be the IP address of the NRS. The displayed address is the address defined in Element Manager for the H.323 Gatekeeper or SIP Redirect Server.

- 4 Click **Next>**.

The **Network Routing Service** login window opens (see [Figure 165 "NRS Manager login web page" \(page 296\)](#))


- 5 Go to [step 4 of Procedure 76 "Logging in to NRS Manager using the browser address field" \(page 295\)](#).

--End--

Procedure 76
Logging in to NRS Manager using the browser address field

Step	Action
1	Open the Microsoft Internet Explorer 6.0 (or later) browser.
2	Type the URL for NRS Manager into the address field of the browser. The URL has the following format: http://[Signaling_Server_ELAN_network_interface_IP_address]/nrs/
3	The NRS Manager Login web page displays (see Figure 165 "NRS Manager login web page" (page 296)).

Figure 165
NRS Manager login web page



Note: The H.323 Gatekeeper or SIP Redirect Server must be enabled before you can log into NRS Manager. If the H.323 Gatekeeper or the SIP Redirect Server are not enabled, the web page turns white, and the following error message is displayed:

```
Error code is WC0030:  
Error: Network Routing Service (NRS) Manager is not  
accessible when neither Gatekeeper nor SIP Proxy/Redirect  
applications are enabled.
```

Please close the IE window. Enable the application(s). Reboot the Signaling Server, then access NRS Manager again.

Note 1: To enable the H.323 Gatekeeper or SIP Redirect Server, refer to [Procedure 73 “Enabling and configuring the NRS server in stand-alone mode”](#) (page 286) or [Procedure 74 “Enabling and configuring the NRS server in co-resident mode”](#) (page 287).

Note 2: To add a bookmark to your Internet Explorer Favorites list, click the **Bookmark NRS Manager** link on the login page before logging in.

- 4 Enter the **User ID** and **Password** to log in.

A username and password must be provided to prevent unauthorized access.

ATTENTION

Nortel recommends that you log in to NRS Manager using the default User ID and Password when configuring the NRS server. When the NRS server configuration is complete, change the User ID and Password for increased system security.

The default values are:

- User ID — **admin**
- password — **admin**

Note: NRS Manager is not available directly from the Signaling Server. To log in to the NRS from the Signaling Server, see [“Accessing the NRS directly from the Signaling Server” \(page 406\)](#).

Security is implemented through authentication and database access privileges. A username and password is required to access the NRS database. The username and password are stored (in encrypted format) in the same database as the SIP Redirect Server or Proxy Server data. The authentication parameters are configurable in the Element Manager but the NRS does the authentication.

Two types of access privileges are supported:

- Administrative privileges — Administrators have full read/write privileges. An administrator can view and modify NRS configuration data.
- Monitor privileges — Monitors have read-only privileges. A Monitor can only view the NRS configuration data.

Note 1: Once logged in, an administrator can create new users using [Procedure 136 “Creating new users” \(page 402\)](#).

Note 2: An administrator must create each monitor user individually. There is no default User ID and password for a monitor.

Note 3: After 60 minutes of inactivity the session times out and the user is logged out of NRS Manager. The administrator can view session management attributes such as login time, logout time, and timeout limits in `amssso.nlog` through the CLI command `/opt/nortel/logs/3rd_party/security/slis/logs`

5 Click **Login**.


If login is successful, the User ID and Password are securely transferred from the web client to the NRS web server. The web server verifies the User ID and Password. If the User ID and Password are valid the **NRS Overview** web page opens. (See [Figure 166 “NRS Overview web page” \(page 298\)](#))

NRS Manager allows you to navigate to specific components of the NRS, and allows you to configure and maintain those components.

If the login is not successful, you may have entered an incorrect User ID or Password.

Note: The **Reset** button clears the User ID and Password text boxes.

Figure 166
NRS Overview web page



An overview of the NRS is displayed in the main area of the **NRS Overview** web page:

- **Network Routing Service:**
The upper part of the web page provides the following information about the NRS:
 - The software version
 - The role of the connected NRS
 - The IP address of the Primary NRS
 - The state of the Primary NRS
 - The IP address of the Alternate NRS
 - The state of the Alternate NRS
 - Whether the Alternate NRS is permanently in service
- **Configured Components**
The middle part of the web page provides the number of configured components of the NRS:
 - Number of Service domains
 - Number of Level 1 Domains (this maps to UDP)
 - Number of Level 0 Domains (this maps to CDP)
 - Number of Gateway Endpoints

- Number of User Endpoints
- Number of Routing Entries
- Number of Default Endpoints
- Number of Collaborative Servers
- **Users Logged into this NRS Manager**
The lower part of the web page provides a list of logged-in users and their IP Addresses.

--End--

The NRS Manager interface

The **NRS Manager toolbar** is located in the NRS Manager web page header. The toolbar has a set of five tabs for configuring and maintaining the NRS. **Help** and **Logout** links are also provided in the header of the NRS Manager web page. See [Figure 167 "NRS Manager toolbar" \(page 299\)](#).

Figure 167
NRS Manager toolbar



The **navigator** located on the left side of the NRS manager web pages contains links to other web pages. In the [Figure 166 "NRS Overview web page" \(page 298\)](#) the navigator contains links to the **NRS Overview**, the **System Wide Settings** and the **NRS Server Settings** web pages.

NRS Manager toolbar

The NRS Manager toolbar has five tabs, as shown in [Figure 167 "NRS Manager toolbar" \(page 299\)](#).

Home tab

Selecting the **Home** tab opens the **NRS Overview** web page. The **NRS Overview** web page provides summary information about the NRS, the number of configured components and a list of users logged in to the NRS Manager. The navigator on the **Home** web pages contains links to the

- NRS Overview
- System Wide Settings
- NRS Server Settings

web pages.

See [“Home tab” \(page 302\)](#).

Configuration tab

Selecting the **Configuration** tab opens the **Service Domains** configuration web page. The **Configuration** web pages are used to modify the NRS database. The navigator on the **Configuration** web pages contains links to the

- Service Domains
- L1 Domains (UDP)
- L0 Domains (CDP)
- Gateway Endpoints
- User Endpoints
- Routing Entries
- Default Routes
- Collaborative Servers

web pages.

See [“Configuration tab” \(page 312\)](#).

Tools tab

Selecting the **Tools** tab opens the **H.323 Routing Test tool** web page. The **Tools** web pages provides a group of tools for performing the following:

- H.323 and SIP routing tests against the active and standby databases
- server actions such as enabling and disabling the database
- database-related actions such as cut over, commit, revert, rollback, and single-step cut over and commit
- database backups and restores
- database conversion/upgrade (such as converting the Succession 3.0 H.323 Gatekeeper database to the CS 1000 Release 4.0 (or later) NRS database)
- SIP Phone context

The navigator on the **Tools** web pages contains links to the

- H.323 routing Test
- SIP Routing Test
- Server Actions

- Database Actions
- Database Backup
- Database Restore
- GK/NRS Data Upgrade
- SIP Phone Context
- SSL/TLS Configuration

web pages.

See [“Tools tab” \(page 369\)](#).

Reports tab

Selecting the **Reports** tab opens the **Database Report** web page. The **Reports** web page provides three types of database reports:

- Last database synchronized for the Alternate NRS (if configured)
- Last database synchronized for the Failsafe NRS (if configured)
- Current database status.

See [“Reports tab” \(page 398\)](#).

Administration tab

Selecting the **Administration** tab opens the **Users** web page. Open the **Users** web page to administer, configure, and view users. Users can be added and user privileges can be modified.

See [“Administration tab” \(page 401\)](#).

Help and Logout links

The **Help** and **Logout** links are located on the right side of the NRS Manager web page header (see [Figure 168 “Help and Logout links” \(page 301\)](#)).

Figure 168
Help and Logout links



Help link

Select the **Help** link to access the **NRS Manager Help Files** .

NRS Manager provides context-sensitive help. That is, the help page displayed depends on the NRS Manager web page from which it is opened. Once a help page is opened, click the **Show** link in the upper left corner of the page to display the **Contents** and an **Index** of the **NRS Manager Help Files**.

Logout link

Select the **Logout** link to terminate the current session. See “Logging out of NRS Manager” (page 302).

Logging out of NRS Manager

Follow the steps in [Procedure 77 “Logging out of NRS Manager”](#) (page 302) to log out of NRS Manager. Logging out of NRS Manager terminates the current session.

Procedure 77 Logging out of NRS Manager

Step	Action
1	Click Logout (see Figure 169 “Logout link” (page 302)). Figure 169 Logout link



The **Network Routing Service Manager** logout web page opens.

2	Close the browser window.
---	---------------------------

--End--

Home tab

Verifying that the NRS is the Primary NRS and is active

To verify that the NRS is the Primary NRS and that it is active, follow [Procedure 78 “Verifying that the NRS is the Primary NRS and is active”](#) (page 302).

Procedure 78 Verifying that the NRS is the Primary NRS and is active

Step	Action
1	Select the Home tab from the NRS Manager toolbar.

The **NRS Overview** web page opens, as shown in [Figure 166 "NRS Overview web page"](#) (page 298).

- 2 In the **Network Routing Service** section (the top section of the **NRS Overview** web page), shown in [Figure 170 "Network Routing Service section"](#) (page 303):
 - a Ensure that **Connected NRS Role** = PrimaryNRS.
 - b Ensure that **Primary NRS State** = Active.

Figure 170
Network Routing Service section

Network Routing Service	
Software version	sse-4.30.20
Connected NRS role	PrimaryNRS
Primary NRS IP (TLAN)	192.168.253.6
Primary NRS state	ACTIVE
Alternate NRS IP (TLAN)	Unknown
Alternate NRS state	Unknown
Alternate permanent in service	OFF

--End--

Configuring system-wide settings

The **System-wide settings** web page is used (1) to configure system-wide settings and (2) to schedule backup jobs. System-wide settings include:

- Database synchronization interval for the Alternate and Failsafe NRS databases.
- SIP registration and H.323 Gatekeeper registration Time-to-Live timer settings.
- H.323 Gatekeeper alias name.
- Whether the Alternate NRS server is permanently in service.
- Automatic backup time setting.
- Whether automatic backup to an FTP site is enabled. If enabled, the IP address, path, and username for the FTP site must be provided.

Follow [Procedure 79 "Configuring system-wide settings"](#) (page 304) to configure system-wide settings.

Procedure 79 Configuring system-wide settings

Step	Action
1	Select the Home tab on the NRS Manager toolbar.
2	Click System Wide Settings in the navigator.

The **Setting Wide Settings** web page opens (see [Figure 171 "System Wide Settings"](#) (page 304)).

Figure 171 System Wide Settings

*Mandatory field indicator

- 3 Enter a value in the **DB sync interval for alternate [Hours]** text box. This is the time interval between database synchronization of the Primary NRS and the Alternate NRS. The range is 1 to 24 hours.
- 4 Enter values for the Time-to-Live timers.
 - a Enter a value in the **SIP registration time to live timer [Seconds]** text box. Nortel recommends that the timer be set to 30 seconds. The range is 30 to 3600 seconds.
 - b Enter a value in the **H.323 gatekeeper registration time to live timer [Seconds]** text box. Nortel recommends that the timer be set to 30 seconds. The range is 30 to 3600 seconds.
- 5 Enter the alias name of the H.323 Gatekeeper in the **H.323 alias name** text box. This is a mandatory field. The alias name must be alphanumeric, can be up to 30 characters in length, and cannot have spaces.

To send out Location Requests (LRQ), the H.323 Gatekeeper must have an H.323 Gatekeeper alias name. An H.323 Gatekeeper alias name is also referred to as an H323-ID. The default value of this parameter is the "HostName" value configured in the Signaling Server's config.ini file.

- 6 Select the **Alternate NRS server is permanent** check box if you want the Alternate NRS Server to be permanently in service.
Select the check box if the Alternate NRS Server is to remain in service after a switchover, even if the Primary NRS recovers. Clear the check box if the Alternate NRS will switchover functions to the Primary NRS Server after the Primary NRS Server recovers.
- 7 Enter the time when the database backup will automatically occur in the **Auto backup time [HH:MM]** text box.
- 8 If you want to automatically back up the NRS database to an FTP site, then complete the following steps:
 - a Select the **Auto backup to FTP site enabled** check box.
 - b Enter the IP address of the FTP site in the **Auto backup FTP site IP address** text box.
 - c Enter the path to the FTP site in the **Auto backup FTP site path** text box. The FTP site path must be alphanumeric and can be up to 120 characters in length.
 - d Enter the username used to access the FTP site in the **Auto backup FTP username** text box. The FTP username must be alphanumeric and can be up to 30 characters in length.
 - e Enter the password used to access the FTP site in **Auto backup FTP password** text box. The FTP password must be alphanumeric and can be up to 30 characters in length but cannot include the single quote (') symbol. The FTP username must be alphanumeric and can be up to 30 characters in length.
- 9 Click Save.

--End--

Configuring the Primary and Alternate NRS Server Settings

Procedure 80

Configuring NRS Server Settings

Step	Action
1	Select the Home tab on the NRS Manager toolbar.
2	Click NRS Server Settings in the navigator.

The **NRS Server Settings** web page opens (see [Figure 172 "NRS Server Settings"](#) (page 306)).

Figure 172
NRS Server Settings

Location: Home > NRS Server Settings >

NRS Settings

Host name: NODE8

Primary IP (TLAN): 192.168.253.6

Alternate IP (TLAN): 0.0.0.0

Control priority: 40

H.323 Gatekeeper Settings

Location request (LRQ) response timeout [Seconds]: 3

SIP Server Settings

Mode: Redirect

UDP transport enabled:

UDP port: 5060

UDP maximum transmission unit (MTU): 1500

TCP transport enabled:

TCP port: 5060

TCP maximum transmission unit (MTU): 1500

Network Connection Server (NCS) Settings

Primary NCS port: 16500

Alternate NCS port: 16500

Primary NCS timeout [Seconds]: 10

Save

*Mandatory field indicator

The NRS Server Settings comprise:

- NRS Settings — These are generic settings applicable to H.323, SIP, and Network connection Service.
- H.323 Gatekeeper Settings
- SIP Server Settings
- Network Connection Server (NCS) Settings
- SNMP Settings — These settings are available only when the connected NRS is in stand-alone mode. If the connected NRS is in co-resident mode, the SNMP Settings section is not displayed in NRS Manager. In co-resident mode, the SNMP parameters are configured using Element Manager. For more information, refer to *Simple Network Management Protocol: Description and Maintenance (553-3001-519)* ().

- 3** To configure the **NRS Settings** (see [Figure 173 "NRS Settings section"](#) (page 307))

- a **Host name:** Enter the name of the connected host Signaling Server in the text box. The host name must be alphanumeric and can be up to 20 characters in length.
- b **Primary IP (TLAN):** Enter the IP address of the Primary NRS (that is, the TLAN network interface IP address) in the text box. The default is 0.0.0.0.
- c **Alternate IP (TLAN):** If the Alternate NRS is configured, enter the IP address of the Alternate NRS (that is, the TLAN network interface IP address), in the text box. The default is 0.0.0.0.
- d **Control priority:** Enter a value for the control priority in the text box. This is a priority bit setting inside the protocol that determines the signaling routing priority. The range is 0 to 63. The default value is 40. The control priority must be a numeric value.

Figure 173
NRS Settings section

NRS Settings	
Host name	<input type="text" value="NODE8"/>
Primary IP (TLAN)	<input type="text" value="192.168.253.6"/>
Alternate IP (TLAN)	<input type="text" value="0.0.0.0"/>
Control priority	<input type="text" value="40"/>

- 4 To configure **H.323 Gatekeeper Settings** (see [Figure 174 "H.323 Gatekeeper Settings section" \(page 307\)](#)) set the LRQ response timeout parameter by selecting a value from the **Location request (LRQ) response timeout [Seconds]** drop-down list. The default value is 3 seconds. The minimum value is 1 second and the maximum value is 10 seconds.

Figure 174
H.323 Gatekeeper Settings section

H.323 Gatekeeper Settings	
Location request (LRQ) response timeout [Seconds]	<input type="text" value="3"/>

- 5 To configure **SIP Server Settings** (see [Figure 175 "SIP Server Settings section" \(page 309\)](#)) configure the following:
- a Select **Redirect** from the **Mode** drop-down list. This is the mode of the SIP Server. A redirect server receives requests, but rather than passing the request onto another server, it sends a response to the caller indicating the address of the called user. This provides the address for the caller to contact the called party directly.
 - b Select the transport protocol.

Two options are available when selecting the transport protocol:

- UDP only
- Both UDP and TCP.

TCP cannot be enabled without enabling UDP.

To enable UDP:

1. Select the **UDP transport enabled** check box.
2. Enter the **UDP port** in the text box. The default port number is 5060. The UDP port must be numeric and can be up to five digits in length.
3. Enter the **UDP maximum transmission unit (MTU)** in the text box. MTU is the maximum size of an Ethernet Layer 2 packet going out on the IP network. In this context, MTU is the maximum size of a SIP packet that is sent out on the UDP interface. The default value is 1500 bytes. The maximum value for MTU is 64K. When configuring the MTU, remember that there is a trade-off between packet size and the number of packets that have to be transmitted over the network.

Note: To enable TCP, UDP must also be enabled. TCP cannot be enabled without enabling UDP. SIP using TCP as transport will have required SIP UDP signaling packets for correct operation of endpoint registration and failover operations.

To enable TCP:

1. Select the **TCP transmission enabled** check box.
2. Enter the **TCP port** number in the text box. The default port number is 5060. The TCP must be numeric and can be up to five digits in length.
3. Enter the **TCP maximum transmission unit (MTU)** in the text box. MTU is the maximum size of an Ethernet Layer 2 packet going out on the IP network. In this context, MTU is the maximum size of a SIP packet that is sent out on the TCP interface. The default value is 1500 bytes. The maximum value for MTU is 64K. When configuring the MTU, remember that there is a trade-off between packet size and the number of packets that have to be transmitted over the network.

Figure 175
SIP Server Settings section

SIP Server Settings	
Mode	Redirect
UDP transport enabled	<input checked="" type="checkbox"/>
UDP port	5060
UDP maximum transmission unit (MTU)	1500
TCP transport enabled	<input checked="" type="checkbox"/>
TCP port	5060
TCP maximum transmission unit (MTU)	1500

- 6 To configure **Network Connection Server (NCS) Settings** (see [Figure 176 "Network Connection Server \(NCS\) Settings section of NRS Server Settings web page" \(page 309\)](#))
- a **Primary NCS port:** Enter a port number for the Primary NCS in the text box. The port number must be numeric and up to five digits in length. The range is 1024 to 65535. The default value is 16500.
 - b **Alternate NCS port:** Enter a port number for the Alternate NCS in the text box. The port number must be numeric and up to five digits in length. The range is 1024 to 65535. The default value is 16500.
 - c **Primary NCS timeout [Seconds]:** Select a timeout value for the Primary NCS from the drop-down list. The default value is 10 seconds. The minimum value is 1 second and the maximum value is 30 seconds.

Note: The NCS Settings are used for the Branch Office (including the Survivable Remote Gateway [SRG]), Virtual Office, and Geographic Redundancy features.

Figure 176
Network Connection Server (NCS) Settings section of NRS Server Settings web page

Network Connection Server (NCS) Settings	
Primary NCS port	16500
Alternate NCS port	16500
Primary NCS timeout [Seconds]	10

- 7 If the NRS is in stand-alone mode, that is not connected to a Call Server (see ["Standalone mode" \(page 286\)](#)) go to [step 8](#) and configure the SNMP Settings.

If the NRS is in co-resident mode (see “[Enabling and configuring the NRS server](#)” (page 285)) the SNMP Settings are not displayed in NRS Manager. Go to [step 9](#).

- 8 To configure the **SNMP Settings** (see [Figure 177 "SNMP Settings"](#) (page 310))

Note: The SNMP settings are available only if the NRS is in stand-alone mode, that is not connected to a Call Server.

Figure 177
SNMP Settings

SNMP Settings

Read community name *

Write community name *

SNMP traps enabled

Trap destination IP 1

Trap destination IP 2

Trap destination IP 3

Trap destination IP 4

Trap destination IP 5

Trap destination IP 6

Trap destination IP 7

Trap destination IP 8

- a Read community name:** Enter the read community name in the text box. The name must be alphanumeric and can be up to 32 characters in length.
- b Write community name:** Enter the read/write community name in the text box. The name must be alphanumeric and can be up to 32 characters in length.

Note: The read community name and the write community name control access to the Management Information Base (MIB). For detailed information, refer to **Simple Network Management Protocol: Description and Maintenance (553-3001-519)**.

- c SNMP traps enabled:** Select the check box to enable SNMP traps if configuring one or more SNMP management IP addresses to receive SNMP traps from cards in the IP Telephony node.
- d Trap destination IP 1 to Trap destination IP 8:** If SNMP traps are enabled, the SNMP traps are sent to the IP address

entered in the text boxes. Up to eight SNMP trap servers can be defined. The default IP address is 0.0.0.0

9 Click **Save**.

--End--

Edit the login warning banner

The VxWorks-based NRS provides a customizable login banner that appears when a user logs on to the system. The customizable banner is intended for use by customers that have security policies that require network equipment to display a specific message to users when they log on. The default login warning banner message is shown in [Table 26 "Default Login warning message" \(page 311\)](#).

Table 26
Default Login warning message


The software and data stored on this system are the property of, or licensed to, [company name] and are lawfully available only to authorized users for approved purposes. Unauthorized access to any software or data on this system is strictly prohibited and punishable under appropriate laws. If you are not an authorized user then logout immediately. This system may be monitored for operational purposes at any time.

The VxWorks-based NRS server can be configured in a Standalone mode or a Co-resident mode. The default login warning message can be viewed or edited when the NRS server is in Standalone mode. The default login warning message can only be viewed (not edited) when the NRS server is in Co-resident mode. To edit the login warning banner, follow ["Editing the login warning banner" \(page 311\)](#).

Editing the login warning banner

Step	Action
1	Select the Home tab from the NRS Manager toolbar. The NRS Overview web page opens, as shown in Figure 166 "NRS Overview web page" (page 298) .
2	Click Access Warning in the navigator. The Access Warning web page opens, as shown in Figure 178 "Access Warning" (page 312) .


Figure 178
Access Warning



- 3 Click **Edit**.

The **Access Warning** web page refreshes, as shown in [Figure 179 "Edit Access Warning"](#) (page 312).

Figure 179
Edit Access Warning



- 4 Edit the text as required.
- 5 Click **Save** to save the changes, or Click **Reset** to reset the banner to the default Login warning message or Click **Cancel** to exit without saving the changes.

--End--

Configuration tab

The **Configuration** web pages, opened by selecting the configuration tab on the NRS Manager toolbar, are used to configure the NRS database. The database is used by both the SIP Redirect Server and the H.323 Gatekeeper.

Configuring the NRS database

Follow the procedures in this section to configure the NRS database.

Task summary list

Follow the procedures in this section to configure the NRS database.

- [Procedure 81 “Switching between the active and standby databases” \(page 314\)](#)
- [Procedure 82 “Adding a Service Domain” \(page 315\)](#)
- [Procedure 86 “Adding an L1 Domain \(UDP\)” \(page 319\)](#)
- [Procedure 90 “Adding an L0 Domain \(CDP\)” \(page 326\)](#)
- [Procedure 94 “Adding a Gateway Endpoint” \(page 332\)](#)
- [Procedure 102 “Adding a Routing Entry” \(page 348\)](#)
- [Procedure 110 “Adding a Collaborative Server” \(page 362\)](#)
- [Procedure 123 “Cutting over and committing changes to the database” \(page 383\)](#)

Note 1: To add a SIP Phone refer to [Procedure 98 “Adding a User Endpoint” \(page 341\)](#).

Note 2: The standby database is used to modify the configuration data. Changes made to the standby database do not immediately affect call processing. Before changes made to the standby database affect call processing, the active and standby databases must be swapped by executing a database **Cut over** command. See [Procedure 123 “Cutting over and committing changes to the database” \(page 383\)](#).

Changes can be saved individually or in batches, depending on the administrator’s preference.

Switching between the active and standby databases

The database has two schemas, active and standby.

- The active database is used for runtime queries.
- The standby database is used for administrator modifications.

Note: By default, the database is in active database view when the **Configuration** web pages are first opened. To modify the database it must be in standby database view. Only users with administrative authority can modify the database.

To the right of the NRS Manager toolbar is an area for switching between the active and standby databases (see [Figure 181 “Active DB view selected” \(page 314\)](#)).


Follow [Procedure 81 “Switching between the active and standby databases” \(page 314\)](#) to switch between the active and standby database.

Procedure 81
Switching between the active and standby databases

Step	Action
1	Click the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK .

Note: The dialog box only opens the first time that the Configuration web pages are opened.

Figure 180
Configuration tab message



- 2 Click **set Standby DB view** to switch to the standby database (see [Figure 181 "Active DB view selected" \(page 314\)](#)). The standby database is used for database modifications.

Figure 181
Active DB view selected



When the database is in standby database view, **Standby DB view** is bold (see [Figure 182 "Switching between active and standby database view" \(page 314\)](#)).

or

- 3 Click **set Active DB view** to switch to the active database (see [Figure 182 "Switching between active and standby database view" \(page 314\)](#)). The active database is used for database queries.

Figure 182
Switching between active and standby database view



When the database is in active database view, **Active DB view** is bold (see [Figure 181 "Active DB view selected" \(page 314\)](#)).

--End--

Note: Procedure 82 “Adding a Service Domain” (page 315) to Procedure 102 “Adding a Routing Entry” (page 348) use the example hierarchy (myServiceProvider.com, myCompany.com, and so on) provided in the “Contents” (page 15).

Adding a Service Domain

The Service Domain is a building block of the routable SIP URI. It represents the service domain name field in the URI (see “SIP Uniform Resource Identifiers” (page 34)).

Procedure 82 Adding a Service Domain

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK .

Note: The dialog box only opens the first time that the Configuration web pages are opened.

2	Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
---	---

The **Service Domains** web page opens.

Figure 183 Service Domains web page

Location: Configuration > Service Domains >

Service Domains					
Add...					
#	ID	Description	# of L1 domains	# of L0 domains	# of gateway endpoints
Add...					

3	Click Add...
---	---------------------

The **Add Service Domain** web page opens, as shown in [Figure 184 "Add Service Domain web page" \(page 316\)](#).

Figure 184
Add Service Domain web page

Location: Configuration > Service Domains > Add Service Domain >

Add Service Domain

Domain name

Domain description

*Mandatory field indicator

- 4 Enter a **Domain name** for the Service Domain in the text box.
For example, enter myServiceProvider.com.
- 5 Enter a **Domain description** for the Service Domain in the text box.
- 6 Click **Save**.

The **Service Domains** web page opens, showing the newly added myServiceProvider.com Service Domain. See [Figure 185 "Added Service Domain" \(page 316\)](#).

Figure 185
Added Service Domain

Location: Configuration > Service Domains >

Service Domains

#	ID	Description	# of L1 domains	# of L0 domains	# of gateway endpoints
1	myServiceProvider.com	This is the Service Domain.	0	0	0

- 7 See [<Fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 8 Test the configuration changes.
- 9 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 83
Viewing the Service Domains

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Active DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).</p> <p>The Service Domains web page opens and displays a list of configured Service Domains.</p>
3	<p>Click a link in the ID column of the Service Domains web page.</p> <p>The View Service Domain Property web page opens and displays a domain description for the selected Service Domain.</p>
--End--	

Procedure 84
Editing a Service Domain

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).</p> <p>The Service Domains web page opens.</p>

Figure 186
Service Domains web page



- 3 Click a link in the **ID** column of the **Service Domains** pane.
 The **View Service Domain Property** web page opens, as shown in [Figure 187 "View Service Domain property web page"](#) (page 318).

Figure 187
View Service Domain property web page



- 4 Edit the **Domain name** or **Domain description** of the Service Domain.
- 5 Click **Save**.
 The **Service Domains** web page opens.
- 6 See [<Fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 7 Test the configuration changes.
- 8 See [Procedure 122 "Committing the database"](#) (page 381) to update the database with the configuration changes.

--End--

Procedure 85
Deleting a Service Domain

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).

The **Service Domains** web page opens, as shown in [Figure 186 "Service Domains web page" \(page 318\)](#).

- 3 Click a link in the **ID** column of the **Service Domains** pane.

The **View Service Domain Property** web page opens, as shown in [Figure 187 "View Service Domain property web page" \(page 318\)](#).

- 4 Click **Delete**.

Note: If there is an associated L1 Domain or Collaborative Server configured, the Service Domain can not be deleted. The associated L1 Domain or Collaborative Server must be deleted before the Service Domain can be deleted. See [Procedure 89 "Deleting an L1 Domain \(UDP\)" \(page 324\)](#) to delete the associated L1 Domain. See [Procedure 113 "Deleting a Collaborative Server" \(page 368\)](#) to delete the associated Collaborative Server.

The **Service Domains** web page opens.

- 5 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Adding a Level 1 Domain (UDP)

The Level 1 (L1) Domain is a building block of the phone context for private addresses. It is the phone context root. For more information on phone context, refer to ["SIP Uniform Resource Identifiers" \(page 34\)](#).

Procedure 86 Adding an L1 Domain (UDP)

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **L1 Domains (UDP)** from the navigator.

The **L1 Domains (UDP)** web page opens, as shown in [Figure 188 "L1 Domains \(UDP\) web page" \(page 320\)](#). The drop-down list contains configured Service Domains.

Figure 188
L1 Domains (UDP) web page



- 4 Select the **Service Domain**, where the new L1 subdomain will be added, from the drop-down list.
- 5 (Optional) Click **Show** to display a list of configured L1 Domains for the selected Service Domain. See [Figure 189 "L1 Domains \(UDP\) web page for selected Service Domain" \(page 320\)](#).

Figure 189
L1 Domains (UDP) web page for selected Service Domain



- 6 Click **Add...**
- The **Add L1 Domain** web page opens, as shown in [Figure 190 "Add L1 Domain web page" \(page 321\)](#).

Figure 190
Add L1 Domain web page

Location: Configuration > L1 Domains (UDP) > Add L1 Domain >

Add L1 Domain (myServiceProvider.com)

Domain name

Domain description

Endpoint authentication enabled

Authentication password

E.164 country code

E.164 area code

E.164 international dialing access code

E.164 national dialing access code

E.164 local (subscriber) dialing access code

Private L1 domain (UDP location) dialing access code

Special number

Emergency service access prefix

Special number label

- 7 Enter the **Domain name** of the L1 Domain in the text box. The name must be alphanumeric and can be up to 30 characters in length.
 For example, enter myCompany.com.
- 8 Enter the **Domain description** in the text box. The description can include any character except single quotes and can be up to 120 characters in length.
- 9 Select **Authentication on** or **Authentication off** from the **Endpoint authentication enabled** drop-down list.
 If **Authentication on** is selected, then all endpoints require authentication.
- 10 Enter the **Authentication password** in the text box, if **Authentication on** was selected in [step 8](#). The password must be alphanumeric and up to 30 characters in length.
- 11 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to seven characters in length.
- 12 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to seven characters in length.

- 13 Enter the **E.164 international dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 14 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 15 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 16 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 17 Enter the **Special number** in the text box. The number must be numeric and can be up to 30 characters in length.
- 18 Enter the **Emergency service access prefix** in the text box. The number must be numeric and can be up to 30 characters in length.
- 19 Enter the **Special number label** in the text box. The label must be alphanumeric and can be up to 30 characters in length. The first character in the label must be alphabetic.
- 20 Click **Save**.

The **L1 Domains (UDP)** web page opens, showing the newly added myCompany.com L1 domain in the myServiceProvider.com Service Domain. See [Figure 191 "Added L1 Domain" \(page 322\)](#).

**Figure 191
Added L1 Domain**



- 21 See <Fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 22 Test the configuration changes.

- 23 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 87
Viewing the L1 Domains (UDP)

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK .
	Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Active DB view is selected. (See Procedure 81 “Switching between the active and standby databases” (page 314)).
3	Click L1 Domains (UDP) in the navigator. The L1 Domains (UDP) web page opens and displays a drop-down list of configured Service Domains.
4	Select a Service Domain from the drop-down list.
5	Click Show . The web page expands to display a list of configured L1 Domains.
6	Click a link in the ID column of the L1 domains (UDP) web page. The View L1 domain Property web page opens and displays the configured data for the selected L1 Domain (UDP).

--End--

Procedure 88
Editing an L1 Domain (UDP)

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **L1 Domains (UDP)** from the navigator.
The **L1 Domains (UDP)** web page opens, as shown in [Figure 188 "L1 Domains \(UDP\) web page" \(page 320\)](#). The drop-down list contains configured Service Domains.
- 4 Select a Service Domain from the drop-down list.
- 5 Click **Show**.
The web page expands to display a list of configured L1 Domains.
- 6 Click a **link** in the **ID** column of the L1 domains (UDP) web page.
The **View L1 Domain Property** web page opens and displays the configured data for the selected L1 Domain (UDP).
- 7 Modify the fields of the **View L1 domain Property** web page as appropriate. See [Procedure 86 "Adding an L1 Domain \(UDP\)" \(page 319\)](#).
- 8 Click the **Save** button. The standby database is updated.
The **L1 Domains (UDP)** web page opens.
- 9 See <Fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 10 Test the configuration changes.
- 11 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 89
Deleting an L1 Domain (UDP)

- | Step | Action |
|------|---|
| 1 | Select the Configuration tab on the NRS Manager toolbar. |

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **L1 Domains (UDP)** from the navigator.
The **L1 Domains (UDP)** web page opens, as shown in [Figure 188 "L1 Domains \(UDP\) web page" \(page 320\)](#). The drop-down list contains configured Service Domains.
- 4 Select a Service Domain from the drop-down list.
- 5 Click **Show**.
The web page expands to display a list of configured L1 Domains.
- 6 Click a **link** in the **ID** column of the L1 domains (UDP) web page.
The **View L1 Domain Property** web page opens and displays the configured data for the selected L1 Domain (UDP).
- 7 Click **Delete**.

Note: If there is an associated L0 Domain or Collaborative Server configured, the L1 Domain can not be deleted. The associated L0 Domain or Collaborative Server must be deleted before the L1 Domain can be deleted. See [Procedure 93 "Deleting an L0 Domain \(CDP\)" \(page 331\)](#) to delete the associated L0 Domain. See [Procedure 113 "Deleting a Collaborative Server" \(page 368\)](#) to delete the associated Collaborative Server.

The **L1 Domains (UDP)** web page opens.

- 8 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Adding a Level 0 Domain (CDP)

The Level 0 (L0) Domain is a building block of the phone context for private addresses. For more information on phone context, refer to ["SIP Uniform Resource Identifiers" \(page 34\)](#).

Procedure 90 Adding an L0 Domain (CDP)

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).</p>
3	<p>Click L0 Domains (CDP) in the navigator.</p> <p>The L0 Domains (CDP) web page opens, as shown in Figure 192 "L0 Domain (CDP) web page" (page 326). The two drop-down lists contain configured Service Domains and L1 Domains.</p> <p>Figure 192 L0 Domain (CDP) web page</p>



- | | |
|---|--|
| 4 | <p>Select the Service Domain and the L1 Domain from the respective drop-down lists.</p> |
| 5 | <p>(Optional) Click Show to display a list of configured L0 Domains for the selected Service Domain and L1 Domain. See Figure 193 "L0 Domains (CDP) web page for selected Service Domain / L1 Domain" (page 327).</p> |

Figure 193
L0 Domains (CDP) web page for selected Service Domain / L1 Domain

Location: Configuration > L0 Domains (CDP) >

L0 Domains (CDP)

Show L0 Domains for (Service Domain / L1 Domain):

myServiceProvider.com / myCompany.com Show

Add...

#	ID	Ancestor Path	Description	# of gateway endpoints	# of routing entries
Add...					

6 Click **Add...**

The **Add L0 Domain** web page opens, as shown in [Figure 194 "Add L0 Domain web page" \(page 327\)](#).

Figure 194
Add L0 Domain web page

Location: Configuration > L0 Domains (CDP) > Add L0 Domain >

Add L0 Domain (myServiceProvider.com / myCompany.com)

Domain name

Domain description

Endpoint authentication enabled

Authentication password

E.164 country code

E.164 area code

Private unqualified number label

E.164 international dialing access code

E.164 national dialing access code

E.164 local (subscriber) dialing access code

Private L1 domain (UDP location) dialing access code

Special number

Emergency service access prefix

Save

7 Enter the **Domain name** of the L0 Domain in the text box. The name must be alphanumeric and up to 30 characters in length. For example, enter myCdpDomain.

- 8 Enter the **Domain description** in the text box. The description can include any character except single quotes and can be up to 120 characters in length.
- 9 Select **Not configured**, **Authentication on**, or **Authentication off** from the **Endpoint authentication enabled** drop-down list.
If **Authentication on** is selected, then all endpoints require authentication.
- 10 Enter the **Authentication password** in the text box, if **Authentication on** was selected in [step 8](#). The password must be alphanumeric and up to 30 characters in length.
- 11 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to seven characters in length.
- 12 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to seven characters in length.
- 13 Enter the **Private unqualified number label** in the text box. The label must be alphanumeric and can be up to 30 characters in length. The first character in the label must be alphabetic.
- 14 Enter the **E.164 international dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 15 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 16 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 17 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 18 Enter the **Special number** in the text box. The number must be numeric and can be up to 30 characters in length.
- 19 Enter the **Emergency services access prefix** in the text box. The number must be numeric and can be up to 30 characters in length.
- 20 Click **Save**.
The **L0 Domains (CDP)** web page opens, showing the newly added myCdpDomain L0 domain. See [Figure 195 "Added L0 Domain"](#) (page 329).

Figure 195
Added L0 Domain

Location: Configuration > L0 Domains (CDP) >

L0 Domains (CDP)

Show L0 Domains for (Service Domain / L1 Domain):

myServiceProvider.com / myCompany.com Show

Add...

#	ID	Ancestor Path	Description	# of gateway endpoints	# of routing entries
1	myCdpDomain	myServiceProvider.com/myCompany.com	This is an Enterprise CDP Doma...	0	0

Add...

- 21 See <Fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 22 Test the configuration changes.
- 23 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 91
Viewing the L0 Domains (CDP)

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Active DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	Click L0 Domains (CDP) in the navigator. The L0 Domains (CDP) web page opens and displays two drop-down lists: Service Domain / L1 Domain.
4	Select a Service Domain and L1 Domain from the drop-down lists.
5	Click Show .

The web page expands to display a list of configured L0 Domains.

- 6 Click a **link** in the **ID** column of the L0 domains (CDP) web page.
The **View L0 Domain Property** web page opens and displays the configured data for the selected L0 Domain (CDP).

--End--

Procedure 92
Editing an L0 Domain (CDP)

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	Click L0 Domains (CDP) in the navigator. The L0 Domains (CDP) web page opens, as shown in Figure 192 "L0 Domain (CDP) web page" (page 326) . The two drop-down lists contain configured Service Domains and L1 Domains.
4	Select a Service Domain and L1 Domain from the drop-down lists.
5	Click Show . The web page expands to display a list of configured L0 Domains.
6	Click a link in the ID column of the L0 domains (CDP) web page. The View L0 domain Property web page opens and displays the configured data for the selected L0 Domain (CDP).
7	Modify the fields of the View L0 Domain Property web page as appropriate. See Procedure 90 "Adding an L0 Domain (CDP)" (page 326) .
8	Click the Save button. The standby database is updated. The L0 Domains (UDP) web page opens.

-
- 9 See <Fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
 - 10 Test the configuration changes.
 - 11 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.
-

--End--

Procedure 93 Deleting an L0 Domain (CDP)

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p style="padding-left: 40px;">Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Standby DB view is selected. (See Procedure 81 “Switching between the active and standby databases” (page 314)).</p>
3	<p>Click L0 Domains (CDP) in the navigator.</p> <p>The L0 Domains (CDP) web page opens, as shown in Figure 192 "L0 Domain (CDP) web page" (page 326). The two drop-down lists contain configured Service Domains and L1 Domains.</p>
4	<p>Select a Service Domain and L1 Domain from the drop-down lists.</p>
5	<p>Click Show.</p> <p>The web page expands to display a list of configured L0 Domains.</p>
6	<p>Click a link in the ID column of the L0 Domains (CDP) web page.</p> <p>The View L0 Domain Property web page opens and displays the configured data for the selected L0 Domain (CDP).</p>

- 7 Click the **Delete** button. The standby database is updated.

Note: If there is an associated **Collaborative Server** configured, the **L0 Domain** can not be deleted. The Collaborative Server must be deleted before the L0 Domain can be deleted. See [Procedure 113 "Deleting a Collaborative Server" \(page 368\)](#) to delete the associated **Collaborative Server**.

The **L0 Domains (UDP)** web page opens.

- 8 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Adding a Gateway Endpoint

Follow [Procedure 94 "Adding a Gateway Endpoint" \(page 332\)](#) to add a gateway endpoint.

Procedure 94 Adding a Gateway Endpoint

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	Click Gateway Endpoints in the navigator. The Gateway Endpoints web page opens, as shown in Figure 196 "Gateway Endpoints web page" (page 333) . The three drop-down lists contain configured Service Domains, L1 Domains, and L0 Domains.

Figure 196
Gateway Endpoints web page

Location: Configuration > Gateway Endpoints >

Gateway Endpoints

Show Gateway Endpoints for (Service Domain / L1 Domain / L0 Domain):

myServiceProvider.com / myCompany.com / myCdpDomain Show

Add...

- 4 Select the Service Domain, the L1 Domain, and L0 Domain from the respective drop-down lists.
- 5 (Optional) Click **Show** to display a list of configured Gateway Endpoints associated with the selected Service Domain, L1 Domain, and L0 Domain. See [Figure 197 "Gateway Endpoints web page for selected Service Domain / L1 Domain / L0 Domain" \(page 333\)](#).

Figure 197
Gateway Endpoints web page for selected Service Domain / L1 Domain / L0 Domain

Location: Configuration > Gateway Endpoints >

Gateway Endpoints

Show Gateway Endpoints for (Service Domain / L1 Domain / L0 Domain):

myServiceProvider.com / myCompany.com / myCdpDomain Show

Add...

#	ID	Support Protocol(s)	Call Signaling IP	Description	# of routing entries
Add...					

- 6 Click **Add....**
 The **Add Gateway Endpoint** web page opens, as shown in [Figure 198 "Add Gateway Endpoint web page" \(page 334\)](#).

Figure 198
Add Gateway Endpoint web page

Location: Configuration > Gateway Endpoints > Add Gateway Endpoint >

Add Gateway Endpoint (myServiceProvider.com / myCompany.com / myCdpDomain)

Endpoint name *

Endpoint description

Tandem gateway endpoint name

Endpoint authentication enabled

Authentication password

E.164 country code

E.164 area code

E.164 international dialing access code

E.164 national dialing access code

E.164 local (subscriber) dialing access code

Private L1 domain (UDP location) dialing access code

Private special number 1

Private special number 2

Static endpoint address type

Static endpoint address

H.323 Support

SIP support

SIP transport

SIP port

Network Connection Server enabled

*Mandatory field indicator

- 7 Enter the **Endpoint name** of the gateway in the text box. The name must be alphanumeric and can be up to 30 characters in length.
 For example, enter sipGWsite1.
- 8 Enter a description of the endpoint in the **Endpoint description** text box. The description must be alphanumeric and can be up to 120 characters in length.
- 9 Enter the **Tandem gateway endpoint name** in the text box, if required. This indicates whether the endpoint is used to tandem calls from outside the network. The name must be alphanumeric and can be up to 30 characters in length.

-
- 10 Select an option from the **Endpoint authentication enabled** drop-down list.
- The three options are:
- **Not configured:** If this option is selected, then the gateway endpoint uses the L1 or L0 Authentication (if L1 or L0 authentication is enabled).
 - **Authentication off:** If this option is selected, then authentication is off for this gateway endpoint even if L1 or L0 authentication is enabled.
 - **Authentication on:** If this option is selected, then authentication is on for this gateway endpoint and the authentication overrides the L1 or L0 authentication (if it is enabled).
- 11 Enter the **Authentication password** in the text box, if **Authentication on** was selected in step 9. The password must be alphanumeric and can be up to 30 characters in length.
- 12 Enter the **E.164 country code** in the text box. The code must be numeric and can be up to seven characters in length.
- 13 Enter the **E.164 area code** in the text box. The code must be numeric and can be up to seven characters in length.
- 14 Enter the **E.164 international dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 15 Enter the **E.164 national dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 16 Enter the **E.164 local (subscriber) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 17 Enter the **Private L1 domain (UDP location) dialing access code** in the text box. The code must be numeric and can be up to seven characters in length.
- 18 Enter the **Private special number 1** in the text box. The number must be numeric and can be up to 30 characters in length.
- 19 Enter the **Private special number 2** in the text box. The number must be numeric and can be up to 30 characters in length.
- 20 Select **IP Version 4** from the **Static endpoint address type** drop-down list.
- 21 Enter the **Static endpoint address** in the text box.
- This is the Node IP address of the Signaling Server. If a third-party gateway is being used, then it is the IP address of the gateway.

- 22 Select whether H.323 support is enabled from the **H.323 Support type** drop-down list.

The three options are:

- H.323 not supported
- RAS H.323 endpoint
- Not RAS H.323 endpoint.

Note 1: If an H.323 Gateway Endpoint is configured with an H.323 Support type of RAS H.323 endpoint, then NRS Manager displays Endpoint Dynamic Registration information after the H.323 Gateway registers with the NRS.

Note 2: Endpoint Dynamic Registration information includes the following: Call Signaling IP, RAS IP, Alias name, t35Country code, t35Extension, Manufacturer code, Product ID, and Version ID.

Note 3: The H.323 **Endpoint Dynamic Registration Information** web page (see [Figure 199 "H.323 Endpoint Dynamic Registration Information web page" \(page 336\)](#)) is displayed only when NRS Manager is in **Active DB view**. The detailed dynamic registration information also is displayed only inside the Gateway Endpoint web page.

Figure 199
H.323 Endpoint Dynamic Registration Information web page

Endpoint Dynamic Registration Information	
Call signaling IP	18.67.35.18
RAS IP	20.67.35.18
Alias name	kevin_wife
t35CountryCode	123
t35Extension	234
Manufacturer code	588
Product ID	kevin
Version ID	wolf

- 23 Configure SIP support.
- a Select an option from the **SIP Support type** drop-down list. The three options are: SIP not supported, Static SIP endpoint, and Dynamic SIP endpoint.
 - b If SIP support is enabled, select the transport protocol from the **SIP transport** drop-down list. The two options are: TCP and UDP. TCP is selected by default.
 - c If SIP support is enabled, enter a port number in the **SIP port** text box. The value must be numeric and can be up to

5 digits in length. The range is 0 to 65535. The default port number is **5060**.

Note: If a SIP Trunk Gateway Endpoint is configured with a SIP Support type of Dynamic SIP endpoint, then NRS Manager displays Endpoint Dynamic Registration Information for SIP after the SIP Trunk Gateway registers with the NRS. Endpoint Dynamic Registration Information includes the following: SIP IP, Registration expiry time, User agent, and Preference. The **SIP Endpoint Dynamic Registration Information** web page (see [Figure 200 "SIP Endpoint Dynamic Registration Information web page" \(page 337\)](#)) is displayed only when NRS Manager is in **Active DB view**. The detailed dynamic registration information also is displayed only inside the Gateway Endpoint web page.

Figure 200
SIP Endpoint Dynamic Registration Information web page

Endpoint Dynamic Registration Information for RAS H 323	
Call signaling IP	47.11.213.203
RAS IP	47.11.213.203
Alias name	
134CountryCode	181
135Extension	0
Manufacturer code	20052
Product ID	Nortel_CSE_1000
Version ID	1.0.x

Endpoint Dynamic Registration Information for SIP	
SIP IP	47.11.213.203
Registration expiry time	600
User agent	Nortel CS1000 SIP GW: release=4.0 version=990-3.80.12
Preference	0

24 Select the **Network Connection Server is enabled** check box if this Gateway Endpoint supports the NCS for branch office or SRG user redirection to the main office, Virtual Office, or Geographic Redundancy.

25 Click **Save**.

The **Gateway Endpoints** web page opens, showing the newly added sipGWSite1 endpoint. See [Figure 201 "Gateway Endpoints web page for added Gateway Endpoint" \(page 338\)](#).


Figure 201
Gateway Endpoints web page for added Gateway Endpoint



- 26 If required, click **Add...** to add additional gateway endpoints. Repeat [step 6](#) to [step 24](#).

Any new endpoints are displayed in the **Gateway Endpoints** web page (see [Figure 202 "Gateway Endpoints" \(page 338\)](#)).

Figure 202
Gateway Endpoints



- 27 See [<Fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 28 Test the configuration changes.
- 29 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 95
Viewing the Gateway Endpoints

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Active DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).</p>
3	<p>Click Gateway Endpoints in the navigator.</p> <p>The Gateway Endpoints web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.</p>
4	<p>Select a Service Domain, L1 Domain, and L0 Domain from the drop-down lists.</p>
5	<p>Click Show.</p> <p>The web page expands to display a list of configured Gateway Endpoints.</p>
6	<p>Click a link in the ID column of the Gateway Endpoints web page.</p> <p>The View Gateway Endpoint Property web page opens and displays the configured data for the selected Gateway Endpoint.</p>
--End--	

Procedure 96
Editing a Gateway Endpoint

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases"](#) (page 314)).
- 3 Click **Gateway Endpoints** in the navigator.
The **Gateway Endpoints** web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.
- 4 Select a Service Domain, L1 Domain, and L0 Domain from the drop-down lists.
- 5 Click **Show**.
The web page expands to display a list of configured Gateway Endpoints.
- 6 Click a **link** in the **ID** column of the Gateway Endpoints web page.
The **View Gateway Endpoint Property** web page opens and displays the configured data for the selected Gateway Endpoint.
- 7 Modify the fields of the **View Gateway Endpoint Property** web page as appropriate. See [Procedure 94 "Adding a Gateway Endpoint"](#) (page 332).
- 8 Click the **Save** button. The standby database is updated.
The **Gateway Endpoints** web page opens.
- 9 See <Fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 10 Test the configuration changes.
- 11 See [Procedure 122 "Committing the database"](#) (page 381) to update the database with the configuration changes.

--End--

Procedure 97
Deleting a Gateway Endpoint

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases"](#) (page 314)).
- 3 Click **Gateway Endpoints** in the navigator.
The **Gateway Endpoints** web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.
- 4 Select a Service Domain, L1 Domain, and L0 Domain from the drop-down lists.
- 5 Click **Show**.
The web page expands to display a list of configured Gateway Endpoints.
- 6 Click a **link** in the **ID** column of the Gateway Endpoints web page.
The **View Gateway Endpoint Property** web page opens and displays the configured data for the selected Gateway Endpoint.
- 7 Click the **Delete** button. The standby database is updated.
The **Gateway Endpoints** web page opens.
- 8 See [Procedure 122 "Committing the database"](#) (page 381) to update the database with the configuration changes.

--End--

Adding a User Endpoint (SIP Phone)

To add a SIP Phone as a User Endpoint refer to [Procedure 98 "Adding a User Endpoint"](#) (page 341).

Procedure 98 Adding a User Endpoint

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p style="text-align: center;">Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	Ensure the Standby DB view is selected.

- 3 Click **User Endpoints** from the navigator.

Note: User Endpoint configuration is currently supported only for SIP.

The **User Endpoints** web page opens, as shown in [Figure 203 "User Endpoints web page" \(page 342\)](#).


Figure 203
User Endpoints web page



- 4 Select a Service Domain, L1 Domain, and L0 Domain from the respective drop-down lists.
- 5 (Optional) Click **Show**.

The web page expands to display a list of configured User Endpoints for the selected Service Domain, L1 Domain, and L0 Domain, as shown in [Figure 204 "Configured User Endpoints" \(page 342\)](#).

Figure 204
Configured User Endpoints



- 6 Click **Add....**

The **Add User Endpoint** web page opens, as shown in [Figure 205 "Add User Endpoint web page" \(page 343\)](#).

Figure 205
Add User Endpoint web page

Location: Configuration > User Endpoints > Add User Endpoint >

Add User Endpoint (myServiceProvider.com / myCompany.com / MyCdpDomain)

User name

User endpoint description

Tandem gateway endpoint name [Look up](#)

L0 directory number (DN)

L1 directory number (DN) prefix

E.164 local directory number (DN) prefix

E.164 area code

E.164 country code

Authentication enabled

Authentication password

* Mandatory field indicator

- 7 Enter a **User name** for the SIP Phone. The endpoint's username must be alphanumeric and can be up to 30 characters in length.

The username, together with the Service Domain names, becomes a string that is used to build the user's SIP URI:

[username]@[service_domain_name]

This SIP URI is used during SIP Phone registration. The username is used by the SIP authentication procedures.

- 8 Enter the **User endpoint description**. The endpoint's description must be alphanumeric (except single quotes) and can be up to 120 characters in length.

- 9 (Optional) Enter the **Tandem gateway endpoint name**.

A tandem gateway endpoint must be an existing endpoint on the network. It is usually a Gateway Endpoint. The tandem gateway endpoint name is used to tandem all calls originating from this User Endpoint. That is, all calls originating from this User Endpoint are forwarded to the tandem gateway endpoint, which then routes all the call to the appropriate destinations. This is useful for generating Call Records for originating User Endpoint calls.

Note 1: The tandem gateway endpoint name field is also present on the Gateway Endpoint web page.

Note 2: A tandem gateway endpoint must ONLY be configured if the customer wants all the outgoing calls from the SIP User Endpoint to tandem through a SIP Trunk Gateway Endpoint, in that case the SIP Trunk Gateway Endpoint name should be specified in the tandem endpoint box.

Note 3: To accurately add the SIP Trunk Gateway Endpoint name, a **Look up** link is provided to the right of the **Tandem gateway endpoint name** text box. Clicking the **Look up** link opens the **Look up path for Gateway Endpoints** web page .

- 10** Enter the **L0 directory number (DN)** of the SIP Phone. The DN must be numeric and can be up to 30 numbers in length.

An example is 5000. The DN is the user's DN. That is, the CDP number.

- 11** Enter the **L1 directory number (DN) prefix**. The DN prefix must be numeric and can be up to seven characters in length.

An example is 343. The L1 DN prefix together with the L0 DN creates the user's DN which is unique within the parent L1 Regional Domain. That is, the UDP number. For example, 3435000.

L1 domain prefix + L0 DN = User's DN
343 + 5000 = 3435000

- 12** Enter the **E.164 local directory number (DN) prefix**. The DN prefix must be numeric and can be up to seven characters in length.

An example is 967. The E.164 local DN prefix is the location code. The E.164 local prefix, together with the L0 DN, creates the user's E.164 Local (subscriber) DN. For example, 9675000.

E.164 local prefix + L0 DN = User's E.164 Local (subscriber) DN
967 + 5000 = 9675000

- 13** Enter the **E.164 area code**. The code must be numeric and can be up to 7 characters in length.

An example is 613. The E.164 area code together with both the E.164 local prefix and L0 DN creates the user's national E.164 National DN. For example, 6139675000.

E.164 area code + E.164 local prefix + L0 DN = User's E.164 National DN
613 + 967 + 5000 = 6139675000

- 14** Enter the **E.164 country code**. The code must be numeric and can be up to 7 characters in length.

An example is 1 (for North America). The E.164 country code, together with the E.164 area code, E.164 local prefix, and L0 DN, creates the user's E.164 International DN. For example, 16139675000.

E.164 country code + E.164 area code + E.164 local prefix + L0 DN
 = User's E.164 International DN
 1 + 613 + 967 + 5000 = 16139675000

15 Select **Authentication** on from the **Authentication enabled** drop-down list, if you want to enable authentication for this endpoint.

16 If authentication is enabled in [step 16](#), then enter the **Authentication password**. The password must be alphanumeric and can be up to 30 characters in length.

17 Click **Save**.

The **User Endpoints** web page opens, showing the newly added SIP Phone user endpoint. See [Figure 206 "Added User Endpoints"](#) (page 345).

Figure 206
Added User Endpoints

Location: Configuration > User Endpoints >

User Endpoints

Show User Endpoints for (Service Domain / L1 Domain / L0 Domain):

myServiceProvider.com / myCompany.com / MyCdpDomain Show

Add...

Showing 1 - 1 of 1 < Previous Next >

#	ID	L0 DN	L1 DN Prefix	E.164 Local DN Prefix	E.164 Area Code	E.164 Country Code	Registration Status
1	slpPhone1	7700	343	967	613	1	Not available

Add...

18 If required, click **Add...** to add additional SIP Phone user endpoints..

Any new endpoints are displayed in the **User Endpoints** web page.

Note 1: A maximum of 50 user endpoints can be displayed on the **User Endpoints** web page.

Note 2: If a User Endpoint is configured, then the supported protocol type is dynamic SIP. NRS Manager displays User Endpoint Dynamic Registration Information after the User Endpoint registers with the NRS (see [Figure 207 "User Endpoint Dynamic Registration Information"](#) (page 346)). User Endpoint Dynamic Registration information includes the following: SIP IP, Registration expiry time, User agent, and Preference. The **User Endpoint Dynamic Registration Information** web page is displayed only when NRS Manager is in Active database mode. Detailed dynamic registration information is displayed inside the **User Endpoints** web page.

Figure 207
User Endpoint Dynamic Registration Information

User Endpoint Dynamic Registration Information	
SIP IP	47.11.213.18
Registration expiry time	30
User agent	ipDialing ManiTone 1.2.2 NN rc 8 CS1K_replaces UA
Preference	0

- 19 See [<fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 20 Test the configuration changes.
- 21 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 99
Viewing User Endpoints

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p style="text-align: center;">Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	Ensure the Active DB view is selected.
3	<p>Click User Endpoints from the navigator.</p> <p>The User Endpoints web page opens.</p>
4	Select a Service Domain, LI Domain, and L0 Domain from the respective drop-down lists.
5	<p>Click Show.</p> <p>The web page expands to display a list of configured User Endpoints for the selected Service Domain, L1 Domain, and L0 Domain.</p> <p style="text-align: center;">Note: User Endpoint configuration is currently supported only for SIP.</p>
6	Click a link in the ID column of the User Endpoints web page.

The **View User Endpoint Property** web page opens and displays the configured data for the selected User Endpoint.

--End--

Procedure 100
Editing a User Endpoint

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . <i>Note:</i> The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected.
3	Click User Endpoints from the navigator. The User Endpoints web page opens.
4	Select a Service Domain, LI Domain, and L0 Domain from the respective drop-down lists.
5	Click Show . The web page expands to display a list of configured User Endpoints for the selected Service Domain, L1 Domain, and L0 Domain.
6	Click a link in the ID column of the User Endpoints web page. The View User Endpoint Property web page opens and displays the configured data for the selected User Endpoint.
7	Modify the fields of the View User Endpoint Property web page as appropriate. See Procedure 98 "Adding a User Endpoint" (page 341) .
8	Click Save . The User Endpoints web page opens.
9	See <fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
10	Test the configuration changes.
11	See Procedure 122 "Committing the database" (page 381) to update the database with the configuration changes.

--End--

Procedure 101
Deleting a User Endpoint

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected.
3	Click User Endpoints from the navigator. The User Endpoints web page opens.
4	Select a Service Domain, LI Domain, and L0 Domain from the respective drop-down lists.
5	Click Show . The web page expands to display a list of configured User Endpoints for the selected Service Domain, L1 Domain, and L0 Domain.
6	Click a link in the ID column of the User Endpoints web page. The View User Endpoint Property web page opens and displays the configured data for the selected User Endpoint.
7	Click Delete . The User Endpoints web page opens.
8	See Procedure 122 "Committing the database" (page 381) to update the database with the configuration changes.

--End--

Adding a Routing Entry
Procedure 102
Adding a Routing Entry

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **Routing Entries** in the navigator.

The **Routing Entries** web page opens, as shown in [Figure 208 "Routing Entries web page" \(page 349\)](#).

Note: The **Gateway Endpoint** field is empty.

Figure 208
Routing Entries web page

- 4 Fill the **Gateway Endpoint** text box using one of the following three methods:
 - a Enter * in the **Gateway Endpoint** text box.
Click the **Show** button and the **Routing Entries** web page expands to display all Gateway Endpoints.
Cut and paste an entry from the **Gateway Endpoint** column into the **Gateway Endpoint** text box.
or
 - b Click the **Look up** link to open the **Look up path for gateway endpoints** web page, as shown in [Figure 209 "Lookup path for gateway endpoints web page - Page-by-Page search" \(page 350\)](#). The **Look up** utility allows you to search for Gateway Endpoint in two ways: **Page-by-Page** and **Name prefix**.

- The **Page-by-Page** search is the default method, and the results are displayed in the **Look up path for gateway endpoints** web page, as shown in [Figure 209 "Lookup path for gateway endpoints web page - Page-by-Page search" \(page 350\)](#).
 Click a **link** in the **ID** column and the **Gateway Endpoint** text box auto-fills with the selected Gateway Endpoint, as shown in [Figure 212 "Results of Gateway Endpoint look up" \(page 351\)](#).
- To perform a Name prefix search, select **Name prefix** from the drop-down list. In the text box, enter an alphanumeric string for the first few characters in the name of Gateway Endpoints as shown in [Figure 210 "Name prefix search entry" \(page 351\)](#).
 Click **Search**, and all Gateway Endpoints whose name begins with the alphanumeric string entered in the text box are displayed, as shown in [Figure 211 "Results of Name prefix search" \(page 351\)](#).
 Click a **link** in the **ID** column and the **Gateway Endpoint** text box auto-fills with the selected Gateway endpoint, as shown in [Figure 212 "Results of Gateway Endpoint look up" \(page 351\)](#)

or

- To perform a **Name Prefix** search enter an alphanumeric string for the first few characters in the name of Gateway Endpoints, in the **Gateway Endpoint** text box. Click the **Look up** link, and all gateway Endpoints whose name begins with the alphanumeric string entered in the text box are displayed, as shown in [Figure 211 "Results of Name prefix search" \(page 351\)](#)

Click a **link** in the **ID** column and the **Gateway Endpoint** text box auto-fills with the selected Gateway endpoint, as shown in [Figure 212 "Results of Gateway Endpoint look up" \(page 351\)](#)

Figure 209
Lookup path for gateway endpoints web page - Page-by-Page search

#	ID [Click to select]	Support Protocol(s)	Description	# of routing entries	# of default routes
1	sipGWsite1	Static SIP	This is a SIP G...	0	0
2	sipGWsite2	Static SIP	This is a SIP G...	0	0

Figure 210
Name prefix search entry

Lookup path for gateway endpoints: myServiceProvider.com / myCompany.com / myCdpDomain /

Search by:

Figure 211
Results of Name prefix search

Lookup path for gateway endpoints: myServiceProvider.com / myCompany.com / myCdpDomain /

Search by:

Showing 1 - 2 of 2 < Previous | Next >

#	ID [Click to select]	Support Protocol(s)	Description	# of routing entries	# of default routes
1	sipGWsite1	Static SIP	This is a SIP G...	0	0
2	sipGWsite2	Static SIP	This is a SIP G...	0	0

Figure 212
Results of Gateway Endpoint look up

Location: Configuration > Routing Entries >

Routing Entries

Show Routing Entries for (Service Domain / L1 Domain / L0 Domain / Endpoint)
Select domains and enter a gateway endpoint name to show specified routing entries.
Use the wildcard * by itself for all gateway endpoints:

/ /

Gateway Endpoint:

With DN Type:

- 5 Select the DN type(s) from the **With DN Type** drop-down list. The seven choices are <All DN Types>, E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.
- 6 Click **Show**.

The web page expands to display a list of DNs of the type selected in [Step 4](#), that are configured for the endpoint(s) in the Gateway Endpoint text box. See [Figure 213 "DNs of selected type associated with selected Endpoint\(s\)"](#) (page 352).

Figure 213
DNs of selected type associated with selected Endpoint(s)



7 Click **Add....**

The **Add Routing Entry** web page opens, as shown in [Figure 214 "Add Routing Entry" \(page 352\)](#).

Figure 214
Add Routing Entry



8 Select the **DN type** from the drop-down list.

The six options are E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.

The DN type attribute determines how the phone context value, that is used to qualify the DN prefix, is built from the building blocks configured for the routing entry parents.

9 Enter the **DN prefix** in the text box. The DN prefix can include 0-9, #, -, ?. The prefix can be up to 30 characters in length; however, the first character must be numeric.

10 Enter the **Route cost** in the text box. The range is 1-255. The cost must be numeric and can be up to three characters in length.

This number is used to define least-cost routing. Higher numbers indicate higher costs.

- 11 Click **Save**.

The **Routing Entries** web page opens, displaying the newly added routing entry, as shown in [Figure 215 "Added Routing Entry" \(page 353\)](#).

Figure 215
Added Routing Entry

Location: Configuration > Routing Entries >

Routing Entries

Show Routing Entries for (Service Domain / L1 Domain / L0 Domain / Endpoint)
Select domains and enter a gateway endpoint name to show specified routing entries.
Use the wildcard * by itself for all gateway endpoints:

myServiceProvider.com / myCompany.com / myCdpDomain /

Gateway Endpoint: sipGWsite1 [Look up](#)

With DN Type: < All DN Types > [Show](#)

[Add...](#)

Showing 1 - 1 of 1 < Previous Next >

#	DN Prefix	DN Type	Route Cost	SIP URI Phone Context
1	0	E.164 international	2	+

[Add...](#)

- 12 See [<fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 13 Test the configuration changes.
- 14 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 103

Viewing the Routing Entries

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK .

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Active DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **Routing Entries** in the navigator.
The **Routing Entries** web page opens and displays three drop-down lists: Service Domain / La Domain / L0 Domain.
- 4 Select a Service Domain, L1 Domain, and L0 Domain from the three drop-down lists, respectively.
- 5 Fill the **Gateway Endpoint** text using one of the methods described in [Procedure 102 "Adding a Routing Entry" \(page 348\)](#), [Step 3](#).
- 6 Select the DN type from the **With DN Type** drop-down list.
- 7 Click **Show**.
The web page expands to display a list of configured Routing Entries.
- 8 Click a **link** in the **DN Prefix** column of the Routing Entries web page.
The **View Routing Entry Property** web page opens and displays the configured data for the selected Routing Entry.

--End--

Procedure 104 Editing a Routing Entry

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	Click Routing Entries in the navigator. The Routing Entries web page opens, as shown in Figure 208 "Routing Entries web page" (page 349) .
4	Click the Look up link to open the Look up path for gateway endpoints web page, as shown in Figure 209 "Lookup path for gateway endpoints web page - Page-by-Page search" (page

350). The **Look up** utility allows you to search for Gateway Endpoint in two ways: **Page-by-Page** and **Name prefix**.

5 Select the DN type from the **With DN Type** drop-down list.

6 Click **Show**.

The web page expands to display a list of DN's, that are configured for the endpoint(s) in the Gateway Endpoint text box. See [Figure 213 "DNs of selected type associated with selected Endpoint\(s\)" \(page 352\)](#).

7 Click a **link** in the **DN Prefix** column of the Routing Entries web page.

The **View Routing Entry Property** web page opens, as shown in [Figure 216 "View Routing Entry Property" \(page 355\)](#).

Figure 216
View Routing Entry Property

8 Modify the DN Type, Prefix, and/or Route Cost and click **Save**.

9 See [<fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.

10 Test the configuration changes.

11 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 105 Deleting a Routing Entry

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK .

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases"](#) (page 314)).
- 3 Click **Routing Entries** in the navigator.
The **Routing Entries** web page opens, as shown in [Figure 208 "Routing Entries web page"](#) (page 349).
- 4 Click the **Look up** link to open the **Look up path for gateway endpoints** web page, as shown in [Figure 209 "Lookup path for gateway endpoints web page - Page-by-Page search"](#) (page 350). The **Look up** utility allows you to search for Gateway Endpoint in two ways: **Page-by-Page** and **Name prefix**.
- 5 Select the DN type from the **With DN Type** drop-down list.
- 6 Click **Show**.
The web page expands to display a list of DNs, that are configured for the endpoint(s) in the Gateway Endpoint text box. See [Figure 213 "DNs of selected type associated with selected Endpoint\(s\)"](#) (page 352).
- 7 Click a **link** in the **DN Prefix** column of the Routing Entries web page.
The **View Routing Entry Property** web page opens.
- 8 Click **Delete**.
The **Routing Entries** web page opens.
- 9 See [Procedure 122 "Committing the database"](#) (page 381) to update the database with the configuration changes.

--End--

Adding Default Routes

If the routing entry DN prefix in an incoming H.323/SIP signaling request does not match a DN prefix Gateway Endpoint routing entry recorded in the NRS database, the default route is returned to the gateway.

Procedure 106 Adding a Default Route

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Standby DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).

- 3 Click **Default Routes** in the navigator.

The **Default Routes** web page opens, as shown in [Figure 217 "Default Routes web page" \(page 357\)](#).

Figure 217
Default Routes web page

Location: Configuration > Default Routes >

Default Routes

Show Default Routing Entries for (Service Domain / L1 Domain / L0 Domain / Endpoint)
Select domains and enter a gateway endpoint name to show specified default routes.
Use the wildcard * by itself for all gateway endpoints:

myServiceProvider.com / myCompany.com / myCdpDomain /

Gateway Endpoint: [Look up](#)

With DN Type: < All DN Types > [Show](#)

[Add...](#)

- 4 Fill the **Gateway Endpoint** text box using one of the methods described in [Procedure 102 "Adding a Routing Entry" \(page 348\), Step 3](#).

- 5 Select the DN type from the **With DN Type** drop-down list.

- 6 Click **Show**.

The web page expands to display a list of DN's, of the type selected in step 6, that are configured for the endpoint(s) in the Gateway Endpoint text box.

- 7 Click **Add....**

The **Add Default Route** web page opens, as shown in [Figure 218 "Add Default Route web page" \(page 358\)](#).

Figure 218
Add Default Route web page




* Mandatory field indicator

- 8 Select the **DN type**.
 The six options are E.164 international, E.164 national, E.164 local (subscriber), Private level 1 regional (UDP location code), Private level 0 regional (CDP steering code), and Private special.
 The DN type attribute determines how the phone context value, that is used to qualify the DN prefix, is built from the building blocks configured for the routing entry parents.
- Note:** Each DN type has only one default route.
- 9 Enter the **Route cost**. The range is 1-255. The cost must be numeric and can be up to three characters in length.
- 10 Click **Save**.

The **Default Routes** web page opens showing the new default route. See [Figure 219 "Added Default Route"](#) (page 358).

Figure 219
Added Default Route



- 11 See <fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 12 Test the configuration changes.
- 13 See [Procedure 122 "Committing the database" \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 107 Viewing Default Routes

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p style="text-align: center;">Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	Ensure the Active DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	<p>Click Default Routes in the navigator.</p> <p>The Default Routes web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.</p>
4	Select a Service Domain, L1 Domain, and L0 Domain from the three drop-down lists, respectively.
5	Fill the Gateway Endpoint text using one of the methods described in Procedure 102 "Adding a Routing Entry" (page 348), Step 3 .
6	Select the DN type from the With DN Type drop-down list.
7	<p>Click Show.</p> <p>The web page expands to display a list of configured default routes.</p>
8	Click a link in the # column of the Default Routes web page and the View Default Route Property web page opens, as shown in Figure 220 "View Default Route Property web page" (page 360) .

Figure 220
View Default Route Property web page

Location: Configuration > Default Routes > View Default Route Property >

View Default Route Property (myServiceProvider.com / myCompany.com / myCdpDomain / sipGWsite1)

DN type

Route cost (1 -255)

*Mandatory field indicator

--End--

Procedure 108
Editing a Default Route

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).
3	Click Default Routes in the navigator. The Default Routes web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.
4	Select a Service Domain, L1 Domain, and L0 Domain from the three drop-down lists, respectively.
5	Fill the Gateway Endpoint text using one of the methods described in Procedure 102 "Adding a Routing Entry" (page 348) , Step 3 .
6	Select the DN type from the With DN Type drop-down list.
7	Click Show . The web page expands to display a list of configured default routes.
8	Click a link in the # column of the Default Routes web page and the View Default Route Property web page opens.
9	Edit the DN type or Route cost .

-
- 10 Click the **Save** button. The standby database is updated.
The **Default Routes** web page opens.
 - 11 See <fix link> to place the database in a Switched Over state.
The configuration changes can now be tested.
 - 12 Test the configuration changes.
 - 13 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.
-

--End--

Procedure 109
Deleting a Default Route

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 “Switching between the active and standby databases” (page 314)).
3	Click Default Routes in the navigator. The Default Routes web page opens and displays three drop-down lists: Service Domain / L1 Domain / L0 Domain.
4	Select a Service Domain, L1 Domain, and L0 Domain from the three drop-down lists, respectively.
5	Fill the Gateway Endpoint text using one of the methods described in Procedure 102 “Adding a Routing Entry” (page 348) , Step 3 .
6	Select the DN type from the With DN Type drop-down list.
7	Click Show . The web page expands to display a list of configured default routes.
8	Click a link in the # column of the Default Routes web page and the View Default Route Property web page opens.
9	Click the Delete button. The standby database is updated. The Default Routes web page opens.

- 10 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.

--End--

Adding a Collaborative Server

A Collaborative Server is a server in another network zone that can be used to resolve requests when the NRS cannot find a match in its numbering plan database.

NRS Manager provides a utility for adding and viewing Collaborative Servers, either system-wide or in different network domains.

The configuration of a Collaborative Server as “system-wide” allows IP addresses to be shared by users across multiple domains. This also allows domains to be spread geographically.

NRS Collaborative Servers in different network domains can also be specified in the NRS.

If a request comes in from a gateway and the NRS cannot find a match in its database for the request, the NRS provides the IP address of a Collaborative Server to the gateway. The gateway can then send its request to the Collaborative Server.

Note: Calls can only be made in the same domain, even though calls go through the Collaborative Server to find a match.

For more information about the Collaborative Server, refer to *IP Peer Networking Installation and Commissioning (NN43001-313)*.

Procedure 110 Adding a Collaborative Server

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar. If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK . Note: The dialog box only opens the first time that the Configuration web pages are opened.
2	Ensure the Standby DB view is selected. (See Procedure 81 “Switching between the active and standby databases” (page 314)).

- 3 Click **Collaborative Server** in the navigator.

The **Collaborative Servers** web page opens, as shown in [Figure 221 "Collaborative Servers web page"](#) (page 363).

Figure 221

Collaborative Servers web page

Location: Configuration > Collaborative Servers >

Collaborative Servers

Add...

#	Server Fully Qualified Domain	Alias Name	Domain Type	Absolute Domain Name (Service Domain / L1 Domain [/ L0 Domain])

Add...

- 4 Click **Add....**

The **Add Collaborative Server** web page opens, as shown in [Figure 222 "Add Collaborative Server \(with L1 Domain\)"](#) (page 363).

Figure 222

Add Collaborative Server (with L1 Domain)

Location: Configuration > Collaborative Servers > Add Collaborative Server >

Add Collaborative Server

Domain type for collaborative Server: L1 domain

L1 domain name (with service domain path): myServiceProvider.com / myCompany.com

Alias name:

Server address type: IP version 4

Server address:

H.323 support:

RAS port: 1719

SIP support:

SIP transport: TCP

SIP port: 5060

Network Connection Server support:

Network Connection Server transport: UDP

Network Connection Server port: 16500

Save

* Mandatory field indicator

- 5 Select the **Domain type for Collaborative Server** from the drop-down list.

- Select **System wide** if the Collaborative Server is to be a system-wide server. See [Figure 223 "Add Collaborative Server \(system-wide\)"](#) (page 364).
- Select **Service domain** if the Collaborative Server is to be a Service Domain server.
An additional field **Service domain name** is displayed, prompting for the name of the Service domain. Select the name of the Service domain from the drop-down list.
- Select **L1 domain** if the Collaborative Server is to be an L1 Domain server.
An additional field **L1 domain name (with service domain path)** is displayed, prompting for the name of the L1 domain. Select the Service Domain / L1 Domain name from the drop-down list.
- Select **L0 domain** if the Collaborative Server is to be an L0 Domain server.
Two additional fields are displayed: (1) **L1 domain name (with service domain path)** prompting for the name of the L1 domain. and (2) **L0 Domain** prompting for the name of the L0 domain. See [Figure 224 "Add Collaborative Server \(with L0 Domain\)"](#) (page 365). Select the name of the L0 Domain from the drop-down list for the second field.

Figure 223
Add Collaborative Server (system-wide)

Location: Configuration > Collaborative Servers > Add Collaborative Server >

Add Collaborative Server

Domain type for collaborative Server	System wide
Alias name	<input type="text"/>
Server address type	IP version 4
Server address	<input type="text"/> *
H.323 support	<input type="checkbox"/>
RAS port	1719
SIP support	<input type="checkbox"/>
SIP transport	TCP
SIP port	5060
Network Connection Server support	<input type="checkbox"/>
Network Connection Server transport	UDP
Network Connection Server port	16500

Save

*Mandatory field indicator

Figure 224
Add Collaborative Server (with L0 Domain)

Location: Configuration > Collaborative Servers > Add Collaborative Server >

Add Collaborative Server

Domain type for collaborative Server

L1 domain name (with service domain path)

L0 domain name

Alias name

Server address type

Server address

H.323 support

RAS port

SIP support

SIP transport

SIP port

Network Connection Server support

Network Connection Server transport

Network Connection Server port


*Mandatory field indicator

- 6 Enter the **Alias name** of the collaborative server in the text box. The alias name must be alphanumeric and can be up to 30 characters in length. The name cannot include spaces.
- 7 Select **IP version 4** from the **Server address type** drop-down list.
- 8 Enter the TLAN IP address of the server in the **Server address** text box.
- 9 Select the protocol(s) supported by the server.
 - If H.323 is supported, perform the following steps:
 - a. Select the **H.323 support** check box.
 - b. Enter the **RAS port** number. The port number must be numeric and can be up to five characters in length.
 - If SIP is supported, perform the following steps:

- a. Select the **SIP support** check box.
 - b. Select the transport protocol from the **SIP transport** drop-down list. TCP is the default.
 - c. Enter the **SIP port** number in the text box. The port number must be numeric and can be up to five digits in length.
- 10** Ensure that the **Network Connection Server support** check box is **not** selected. The Collaborative Server does not support the Network Connection Service (NCS).
- 11** Click **Save**.

The **Collaborative Servers** web page opens with the newly added collaborative server, as shown in [Figure 225 "Added Collaborative Server"](#) (page 366).

Figure 225
Added Collaborative Server



- 12** If required, click **Add....** to add additional collaborative servers. Repeat step 5 to step 11.
- 13** See [<fix link>](#) to place the database in a Switched Over state. The configuration changes can now be tested.
- 14** Test the configuration changes.
- 15** See [Procedure 122 "Committing the database"](#) (page 381) to update the database with the configuration changes.

--End--

Procedure 111
Viewing the Collaborative Servers

Step	Action
1	Select the Configuration tab on the NRS Manager toolbar.

If a dialog box displays indicating the status of the active and standby database (see [Figure 180 "Configuration tab message" \(page 314\)](#)) click **OK**.

Note: The dialog box only opens the first time that the Configuration web pages are opened.

- 2 Ensure the **Active DB view** is selected. (See [Procedure 81 "Switching between the active and standby databases" \(page 314\)](#)).
- 3 Click **Collaborative Server** in the navigator.
The **Collaborative Server** web page opens and displays a list of configured Collaborative Servers in different network zones.
- 4 Click a **link** in the **Server Fully Qualified Domain** column of the **Collaborative Servers** web page.
The **View Collaborative Server Property** web page opens and displays the configured data for the Collaborative Server.

--End--

Procedure 112 Editing a Collaborative Server

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p>Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Standby DB view is selected. (See Procedure 81 "Switching between the active and standby databases" (page 314)).</p>
3	<p>Click Collaborative Server in the navigator.</p> <p>The Collaborative Server web page opens and displays a list of configured Collaborative Servers in different network zones.</p>
4	<p>Click a link in the Server Fully Qualified Domain column of the Collaborative Servers web page.</p> <p>The View Collaborative Server Property web page opens and displays the configured data for the Collaborative Server.</p>

- 5 Modify the fields of the **View Collaborative Server Property** web page as appropriate. See [Procedure 110 “Adding a Collaborative Server” \(page 362\)](#).
- 6 Click the **Save** button. The standby database is updated.
The **Collaborative Servers** web page opens.
- 7 See <fix link> to place the database in a Switched Over state. The configuration changes can now be tested.
- 8 Test the configuration changes.
- 9 See [Procedure 122 “Committing the database” \(page 381\)](#) to update the database with the configuration changes.

--End--

Procedure 113 Deleting a Collaborative Server

Step	Action
1	<p>Select the Configuration tab on the NRS Manager toolbar.</p> <p>If a dialog box displays indicating the status of the active and standby database (see Figure 180 "Configuration tab message" (page 314)) click OK.</p> <p style="text-align: center;">Note: The dialog box only opens the first time that the Configuration web pages are opened.</p>
2	<p>Ensure the Standby DB view is selected. (See Procedure 81 “Switching between the active and standby databases” (page 314)).</p>
3	<p>Click Collaborative Server in the navigator.</p> <p>The Collaborative Server web page opens and displays a list of configured Collaborative Servers in different network zones.</p>
4	<p>Click a link in the Server Fully Qualified Domain column of the Collaborative Servers web page.</p> <p>The View Collaborative Server Property web page opens and displays the configured data for the Collaborative Server.</p>
5	<p>Click the Delete button. The standby database is updated.</p> <p>The Collaborative Servers web page opens.</p>
6	<p>See Procedure 122 “Committing the database” (page 381) to update the database with the configuration changes.</p>

--End--

Verifying the numbering plan and saving the NRS configuration

You should verify your numbering plan after it is configured in the NRS.

Procedure 114 Verifying the numbering plan

Step	Action
1	Perform a database Cut over . Cutting over places the database on the network. See Procedure 119 “Cutting over the database” (page 378) .
2	Perform the routing tests. <ul style="list-style-type: none"> • See Procedure 115 “Performing an H.323 Routing Test” (page 369). • See Procedure 116 “Performing a SIP Routing Test” (page 371).
3	If the routing tests succeed, perform a database Commit . See Procedure 122 “Committing the database” (page 381) .
4	If there are problems with the network testing, use the database Revert command to undo the Cut over . See Procedure 120 “Reverting the database changes” (page 379) If you want to undo the latest provisioning changes, use a database rollback command to resynchronize the Standby database with the previous Active database. See Procedure 121 “Rolling back changes to the database” (page 380)
--End--	

Tools tab

H.323 and SIP Routing Tests

To ascertain if a numbering plan entry exists in the active or standby database:

- Follow [Procedure 115 “Performing an H.323 Routing Test” \(page 369\)](#) to perform an H.323 Routing Test.
- Follow [Procedure 116 “Performing a SIP Routing Test” \(page 371\)](#) to perform a SIP Routing Test.

Procedure 115 Performing an H.323 Routing Test

Step	Action
1	Click the Tools tab on the NRS Manager toolbar. The H.323 Routing Test web page opens.

Figure 226
H.323 routing Test

Location: Tools > H.323 Routing Test >

H.323 Routing Test

Test numbering plan for: Active DB

Service domain name: myServiceProvider.com

L1 domain name: myCompany.com

L0 domain name: myCdpDomain

Originating gateway endpoint name: [Look up *](#)

DN to query: *

DN type: E.164 international

*Mandatory field indicator

- 2 Select **Active DB** or **Standby DB** from the **Test numbering plan for** drop-down list.
- 3 Select the **Service domain name** from the drop-down list.
- 4 Select the **L1 domain name** from the drop-down list.
- 5 Select the **L0 domain name** from the drop-down list.
- 6 Enter the **Originating gateway endpoint name** using the **Lookup** link.

Click the **Look up** link to open the **Look up path for gateway endpoints** web page.

The **Look up** utility allows you to search for Gateway Endpoints in two ways: **Page-by-Page** and **Name prefix**.

- a The **Page-by-Page** search is the default method.

Click **Search**, on the **Look up path for gateway endpoints** web page. The **Look up path for gateway endpoints** web page expands, and the results are displayed.

or

- b Select **Name prefix** from the drop-down list to perform a Name prefix search. In the text box, enter an alphanumeric string for the first few characters in the name of Gateway Endpoints.

Click **Search**, and all Gateway Endpoints whose name begins with the alphanumeric string entered in the text box are displayed.

- 7 Click a **link** in the **ID** column of the **Look up path for gateway endpoints** web page and the **Originating gateway endpoint name** text box auto-fills with the selected Gateway Endpoint.

- 8 Enter a numbering plan entry you want to check in the **DN to query** text box.
- 9 Select a number type from the **DN type** drop-down list.
- 10 Click **Submit**.

The results of the H.323 Routing Test are displayed, as shown in [Figure 227 "H.323 Routing Test - results"](#) (page 371).

Figure 227
H.323 Routing Test - results

Location: Tools > H.323 Routing Test >

H.323 Routing Test - Query Parameter	
Test numbering plan for	Standby DB
Service domain name	SDM_TEST
L1 domain name	L1D_TEST1
L0 domain name	L0D_TEST1
Originating gateway endpoint name	GEP1
DN to query	1
DN type	Level1 regional

Route found			
#	Terminating Endpoint Name	Registration Status	Route Cost
1	GEP1	Registered	1

--End--

Procedure 116

Performing a SIP Routing Test

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click SIP Routing Test in the navigator. The SIP Routing Test web page opens, as shown in Figure 228 "SIP Routing Test" (page 372).

Figure 228
SIP Routing Test

Location: Tools > SIP Routing Test >

SIP Routing Test

Test numbering plan for

Terminating service domain name

Terminating L1 domain name

Terminating L0 domain name

Originating endpoint address type

Originating endpoint IP address [Look up](#) *

DN to query *

DN type to query

Phone context to query (suggested)

* Mandatory field indicator

Note: Phone context is required for all DN types except E.164 International

- 3 Select **Active DB** or **Standby DB** from the **Test numbering plan for** drop-down list.
- 4 Select the Service Domain from the **Terminating service domain name** drop-down list.
- 5 Select the L1 Domain name from the **Terminating L1 domain name** drop-down list.
- 6 Select the L0 Domain name from the **Terminating L0 domain name** drop-down list.
- 7 Ensure IP version 4 is selected from the **Originating endpoint address type** drop-down list.
- 8 Enter the **Originating gateway endpoint name** using the **Lookup** link.

Click the **Look up** link to open the **Look up path for gateway endpoints** web page.

The **Look up** utility allows you to search for Gateway Endpoints in two ways: **Page-by-Page** and **Name prefix**.

- a The **Page-by-Page** search is the default method.

Click **Search**, on the **Look up path for gateway endpoints** web page. The **Look up path for gateway endpoints** web page expands, and the results are displayed.

or

- b Select **Name prefix** from the drop-down list to perform a Name prefix search. In the text box, enter an alphanumeric

string for the first few characters in the name of Gateway Endpoints.

Click **Search**, and all Gateway Endpoints whose name begins with the alphanumeric string entered in the text box are displayed.

- 9 Click a **link** in the **SIP Endpoint IP** column of the **Look up path for gateway endpoints** web page and the **Originating endpoint IP address** text box auto-fills with the selected SIP Endpoint IP address.
- 10 Enter a numbering plan entry you want to check in the **DN to query** text box.
- 11 Select the DN type you want to check from the **DN type to query** drop-down list.
- 12 Enter the **Phone context to query**.
- 13 Click **Submit**.

The results of the SIP Routing Test are displayed (see [Figure 229 "SIP Routing Test - results" \(page 373\)](#)).

Figure 229
SIP Routing Test - results

Location: Tools > SIP Routing Test >

SIP Routing Test - Query Parameter	
Test numbering plan for	Standby DB
Terminating service domain name	fadsa
Terminating L1 domain name	a
Terminating L0 domain name	b
Originating endpoint address type	IP version 4
Originating endpoint IP address	22.33.44.55
DN to query	1
Phone context to query	1

Route found						
#	Terminating endpoint address	Terminating server address type	Terminating SIP transport	Terminating SIP port	Routing type	Route Cost
1	47.11.254.78	IP version 4	TCP	5060	ZONE	0

--End--

Enabling and disabling the NRS Server

Actions to:

- Forcefully disable the NRS server (nrsForceDisableServer)
- Gracefully disable the NRS server (nrsDisableServer) This command should not interrupt the existing calls.
- Enable the NRS server (nrsEnableServer)

can be performed using NRS Manager or the Command Line Interface (CLI).

The NRS can be taken out-of-service to perform maintenance or to place an Alternate NRS into service.

Note: Only users with administrator privileges can execute the NRS server action commands.

To take the NRS out-of-service (disabling the NRS server), follow the steps in [Procedure 117 “Disabling the NRS server” \(page 374\)](#). To bring the NRS back in to service, follow the steps in [Procedure 118 “Enabling the NRS server” \(page 375\)](#).

Procedure 117 Disabling the NRS server

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Server Actions in the navigator. The Server Actions web page opens.
3	Select Graceful disable server or Forceful disable server from the Select server action drop-down list.
4	Click Submit . The nrsDisableServer or nrsForceDisableServer command is issued. The results are written in the text area of the Server Actions web page, as shown in Figure 230 “Disabling the server” (page 375) .

Figure 230
Disabling the server




--End--

Procedure 118
Enabling the NRS server

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Server Actions in the navigator. The Server Actions web page opens.
3	Select Enable server from the Select server action drop-down list.
4	Click Submit . The nrsEnableServer command is issued. The results are written in the text area of the Server Actions web page, as shown in Figure 231 "Enabling the server" (page 376) .

Figure 231
Enabling the server



--End--

Performing NRS database actions

The NRS database has two schemas — an active schema and a standby schema

- The active database is used for runtime queries.
- The standby database is used to modify the configuration data. Changes can be made only to the standby database.

The following database commands can be performed using NRS Manager:

- **Cut over** — Swaps the active and standby databases by interchanging the active and standby database access pointers. The active and standby databases must be swapped before configuration changes can take effect.
- **Commit** — Copies data *from* the active database *to* the standby database. Synchronizes the standby database with the active database. Overwrites the previous configuration data with the new configuration data.
- **Revert** — After a Cut over, a revert interchanges the active and standby database access pointers. The active and standby databases are swapped.

- **Roll back** — Before a Commit, a roll back undoes changes made to the standby database. A Roll Back copies data *from* the active database *to* the standby database. As a result, any changes made during the latest provisioning to the standby database are erased. The standby database is synchronized with the active database. This operation is available after a Cut over and before a Commit.
- **Cut over and Commit** — The active and standby databases are swapped and synchronized with the new data configuration in a single step. The Standby database can not Roll back to a previous data configuration after a Cut over and Commit.

Note: Only users with administrator privileges can execute the database action commands.

For more information, refer to [“Database synchronization/operation component” \(page 38\)](#).

Database commands are executed from the **DB Actions** web page. The database has three states: Committed, Switched Over and Changed. The current database status is displayed in the title of the **DB Actions** web page as shown in [Figure 232 "Database State: Changed" \(page 378\)](#). Depending on the database status, some commands may not be in the **Select database action** drop-down list.

For example:

- If the database is in the **Committed** state, no commands are available.
- If the database is in the **Switched Over** state, the available commands in the **Select database action** drop-down list are Commit, Revert, and Roll back.
- If the database is in the **Changed** state, the available commands in the **Select database action** drop-down list are Cut over, Roll back, and Cut over & Commit.

For information about database commands, refer to [“Database synchronization/operation component” \(page 38\)](#).

To perform a:

- database cut over, see [Procedure 119 “Cutting over the database” \(page 378\)](#)
- database revert, see [Procedure 120 “Reverting the database changes” \(page 379\)](#)
- database commit, see [Procedure 122 “Committing the database” \(page 381\)](#)

- database cut over and commit, see [Procedure 123 “Cutting over and committing changes to the database”](#) (page 383)
- database roll back, see [Procedure 121 “Rolling back changes to the database”](#) (page 380)

Performing a database cut over

Cutting over a database switches the active and standby database access pointer. This swaps the primary and standby databases, so configuration changes take effect.

To perform a database cut over, follow the steps in [<Fix link>](#).

Procedure 119 Cutting over the database


Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Actions in the navigator. The Database Actions web page opens. The database is in the Changed states, as shown in Figure 232 "Database State: Changed" (page 378) . Figure 232 Database State: Changed



- | | |
|---|---|
| 3 | Select Cut over from the Select database action drop-down list. |
| 4 | Click Submit .

The Cut over command is issued, and the database is placed into a Switched Over state. Text is written in the text area of the Database Actions web page indicating that the Cut over command executed successfully, as shown in Figure 233 "Database Actions Cut over" (page 379) . |

Figure 233
Database Actions Cut over



- 5 To save the changes after the cut over, perform a Commit (see [Procedure 122 “Committing the database” \(page 381\)](#)). If you do not want to save the changes to the database, perform a Revert (see [Procedure 120 “Reverting the database changes” \(page 379\)](#)) or Roll back (see [Procedure 121 “Rolling back changes to the database” \(page 380\)](#)).

--End--

Reverting the database changes

After a database Cut over, the Revert command interchanges the active and standby database access pointers. The active and standby databases are swapped.

To interchange the active and standby database access pointers, follow the steps in [Procedure 120 “Reverting the database changes” \(page 379\)](#).

Procedure 120 Reverting the database changes

Step	Action
------	--------

- 1 Click the **Tools** tab on the NRS Manager toolbar.
- 2 Click **Database Actions** in the navigator.

The **Database Actions** web pages opens. The database is in Switched Over state, as shown in [Figure 234 “Database State: Switched Over” \(page 379\)](#).

Figure 234
Database State: Switched Over



- 3 Select **Revert** from the **Select database action** drop-down list.
- 4 Click **Submit**.

The Revert command is issued, and the database is placed into a Changed state. Text is written in the text area of the Database Actions web page indicating that the Revert command executed successfully, as shown in [Figure 235 "Database Actions revert" \(page 380\)](#).

Figure 235
Database Actions revert



--End--

Performing database rollback

The Roll back command copies the active database to the standby database. As a result, any changes made during the latest provisioning to the standby database are erased. The standby database is synchronized with the active database. The Roll back command is available if the database is in the Changed or Switched Over state.

To roll back changes made to the standby database, perform [Procedure 121 "Rolling back changes to the database" \(page 380\)](#).

Procedure 121 Rolling back changes to the database

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Actions in the navigator. The Database Actions web page opens. The database is in the Changed state, as shown in Figure 236 "Database Actions Roll back" (page 381)

Figure 236
Database Actions Roll back




- 3 Select **Roll back** from the Select **database action** drop-down list.
- 4 Click **Submit**.

The Roll back command is issued, and the database is placed into a Committed state. Text is written in the text area of the Database Actions web page indicating that the Roll back command executed successfully, as shown in [Figure 237 "Database Actions Roll back \(successful\)"](#) (page 381).

The **Select database action** drop-down list is also removed from the web page.

Figure 237
Database Actions Roll back (successful)



--End--

Committing the database changes

After Cut over, the Commit command copies data *from* the active database *to* the standby database. The previous configuration data is overwritten with the new configuration data. The standby database is synchronized with the active database.

To perform a database commit, follow the steps in [Procedure 122 "Committing the database"](#) (page 381).

Procedure 122 Committing the database

Step	Action
------	--------

- | | |
|---|--|
| 1 | Click the Tools tab on the NRS Manager toolbar. |
|---|--|

- 2 Click **Database Actions** in the navigator.

The **Database Actions** web page opens. The database is in Switched Over state, as shown in [Figure 238 "Database State: Switched Over"](#) (page 382).


Figure 238
Database State: Switched Over



- 3 Select **Commit** from the **Select database action** drop-down list.
- 4 Click **Submit**.

The Commit command is issued, and the database is placed into a Committed state. Text is written in the text area of the Database Actions web page indicating that the Commit command executed successfully, as shown in [Figure 239 "Database Actions Commit"](#) (page 382).

Figure 239
Database Actions Commit



--End--

Saving changes to the database with a single-step cutover and commit

After the service domain, L1 domains, L0 domains, gateway endpoints, and routing entries are configured and tested, the changes must be saved to the database. The changes can be saved in a single step using the **Cut over & Commit** command.

To perform a single-step cut over and commit, follow the steps in [Procedure 123 "Cutting over and committing changes to the database"](#) (page 383).

Procedure 123 Cutting over and committing changes to the database

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Actions in the navigator. The Database Action web page opens. The database is in the changed state, as shown in Figure 240 "Database State: Changed" (page 383). Figure 240 Database State: Changed




3	Select Cut over & Commit from the Select database action drop-down list, as shown in Figure 241 "Database Actions Cut over and Commit" (page 383). Figure 241 Database Actions Cut over and Commit
---	--



4	Click Submit . The Cut over & Commit command is issued, and the database is placed into a Committed state. Text is written in the text area of the Database Actions web page indicating that the Cut over & Commit command executed successfully, as shown in Figure 242 "Database Actions Cut over and Commit (successful)" (page 384). The Select database action drop-down list is also removed from the web page.
---	---

Figure 242
Database Actions Cut over and Commit (successful)



Backing up the database

NRS Manager provides a facility for backing up the NRS database.

The database can be automatically backed up or manually backed up.

- The **automatic backup** option allows you to configure the backup time and location using **system-wide settings**. See [Procedure 79 "Configuring system-wide settings" \(page 304\)](#)
- The **manual backup** option allows you to immediately back up the database.


Note: Only users with administrator privileges can execute the database backup commands.

Procedure 124

Automatically backing up the database

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Backup in the navigator. The Database Backup web page opens, as shown in Figure 243 "Database Backup web page" (page 384) .

Figure 243
Database Backup web page



- | | |
|---|--|
| 3 | Select Auto backup from the Select backup action drop-down list. |
|---|--|

A dialog box opens indicating that you will be redirected to the **System Wide Settings** web page (see [Figure 244](#) "Automatically back up the database - redirection to System Wide Settings" (page 385)).

Figure 244
Automatically back up the database - redirection to System Wide Settings



- 4 Click **OK**.
The **System Wide Settings** web page opens (see [Figure 171](#) "System Wide Settings" (page 304)).
- 5 Perform the following steps from [Procedure 79](#) "Configuring system-wide settings" (page 304):
 - [step 7](#)
 - [step 8](#)
 - [step 9](#)

--End--


Procedure 125 Manually backing up the database

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Backup in the navigator. The Database Backup web page opens, as shown in Figure 243 "Database Backup web page" (page 384). Manual backup is automatically selected in the Select backup action drop-down list.
3	Click Submit . A summary of the manual backup is displayed in the text area of the Database Backup web page, as shown in Figure 245 "Manual back up." (page 386). Two links appear on the screen: <ul style="list-style-type: none"> • Download the latest backup file

(To download the latest backup file, follow [Procedure 126](#) "Downloading the latest backup file" (page 386)).

- **Download the latest backup log file**
 (To download the latest backup log file, follow [Procedure 127](#) "Downloading the latest backup log file" (page 387)).

Figure 245
Manual back up.



Procedure 126
Downloading the latest backup file

Step	Action
1	Follow the steps in Procedure 125 "Manually backing up the database" (page 385)
2	Click the Download the latest backup file link on the Database Backup web page. (See Figure 245 "Manual back up." (page 386)). The File Download dialog box opens. The File Download dialog box provides the option to view the latest backup file or download and save the latest backup file to the user's local client (PC).
3	Click Open to view the latest backup file or click Save to save the file to a local client. The file is a compressed file that contains multiple backup files. The name of the compressed file is nrsback.tar (see Figure 246 "NRS backup files" (page 387)).

Figure 246
NRS backup files

Name	Type	Modified	Size	Ratio	Packed	Path
bootp.tab	TAB File	2/23/2005 7:36 AM	750	0%	750	\u\config\
config.ini	INI File	2/23/2005 7:36 AM	2,607	0%	2,607	\u\config\
nrsConf.xml	XML File	2/15/2005 12:44 PM	1,274	0%	1,274	\u\config\
dbv.xml	XML File	2/28/2005 12:55 PM	138	0%	138	\u\db\backup\
nrs.xml	XML File	2/28/2005 12:55 PM	3,349	0%	3,349	\u\db\backup\
nrsu.xml	XML File	2/28/2005 12:55 PM	221	0%	221	\u\db\backup\
sws.xml	XML File	2/28/2005 12:55 PM	608	0%	608	\u\db\backup\

--End--

Procedure 127
Downloading the latest backup log file

Step	Action
------	--------

- | | |
|---|--|
| 1 | Follow the steps in Procedure 125 "Manually backing up the database" (page 385) |
| 2 | Click Download the latest backup log file link on the Database Backup web page. (See Figure 245 "Manual back up." (page 386)). |

A window opens containing the latest backup log file, as shown in [Figure 247 "Backup log file"](#) (page 387). The name of the log file is bkLog.xml. The bkLog.xml file contains information about the backup. For example, if there were errors during the back up process.

Figure 247
Backup log file



- | | |
|---|---|
| 3 | The backup log file can be saved using the File > Save As... menu option. |
|---|---|

--End--

Restoring the database

NRS Manager provides the option to select a restore source to complete the database restore action. Restore sources include:

- From the connected Signaling Server
- From an FTP site
- From the client machine

Note: Only users with administrator privileges can execute the database restore commands.

Procedure 128 Restoring the database

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click Database Restore in the navigator. The Database Restore web page opens, as shown in Figure 248 "Database Restore web page" (page 388) .

Figure 248
Database Restore web page



The database can be restored from three source locations:

- From the **Connected Signaling Server**
(To restore the database from the Connected Signaling

Server, follow [Procedure 129 “Restoring from the connected Signaling Server”](#) (page 389).

- From an **FTP site**
(To restore the database from an FTP site, follow [Procedure 130 “Restoring from an FTP site”](#) (page 390)).
- From the **Client machine**
(To restore the database from the Client machine, follow [Procedure 131 “Restoring from a client machine”](#) (page 392)).

--End--

Procedure 129
Restoring from the connected Signaling Server

Step	Action
1	Follow the steps in Procedure 128 “Restoring the database” (page 388)
2	Select Connected Signaling Server from the Select restore source from drop-down list. (See Figure 248 “Database Restore web page” (page 388)).
3	Click Submit . A message displays in the text area of the Database Restore web page showing a summary of the database restore from the Signaling Server. (See Figure 249 “Database Restore - from connected Signaling Server” (page 390)). The Download the latest restore log file link also appears on the web page. See Procedure 132 “Downloading the latest restore log file” (page 393) for downloading the restore log file.

Figure 249
Database Restore - from connected Signaling Server



--End--

Procedure 130
Restoring from an FTP site

Step	Action
1	Follow the steps in Procedure 128 "Restoring the database" (page 388)
2	<p>Select FTP site from the Select restore source from drop-down list (see Figure 248 "Database Restore web page" (page 388)).</p> <p>The DB Restore from FTP Site web page opens (see Figure 250 "Database Restore - from FTP site" (page 391)).</p> <ol style="list-style-type: none"> Enter the FTP restore site's IP address in the text box. Enter the FTP restore site's path in the text box. Enter the FTP restore site's username in the text box. Enter the FTP restore site's password in the text box.

Figure 250
Database Restore - from FTP site

Location: Tools > Database Restore > DB Restore from FTP Site >

DB Restore from FTP Site

FTP restore site's IP address *

FTP restore site's path *

FTP restore site's username *

FTP restore site's password *

* Mandatory field indicator

3 Click **Restore**.

A message is displayed in the text area of the DB Restore from FTP Site web page, showing a summary of the database restore from the FTP site. See [Figure 251 "Database Restore - from FTP site - results"](#) (page 391).

The **Download the latest restore log file** link also appears on the web page. See [Procedure 132 "Downloading the latest restore log file"](#) (page 393) for downloading the restore log file.

Figure 251
Database Restore - from FTP site - results

Location: Tools > Database Restore > DB Restore from FTP Site - Restore File to DB >

DB Restore from FTP Site

Saving FTP restore information ...

Saved FTP restore information ... successfully

Transferring the file from FTP site ...

Transferred the file from FTP site ... successfully

Restoring the file ...

Restored the file ... successfully

0 error(s) in extracting backup tar file

0 errors in restoring the NRS data

0 errors in restoring the tandem data

0 error(s) in System Wide Settings data

02/28/2005 17:39:49

[Download the latest restore log file](#)

--End--

Procedure 131
Restoring from a client machine

Step	Action
1	Follow the steps in Procedure 128 "Restoring the database" (page 388)
2	Select Client machine from the Select restore source from drop-down list (see Figure 248 "Database Restore web page" (page 388)).

The **Database Restore** web page opens, as shown in [Figure 252 "Database Restore - from client machine"](#) (page 392). The web page contains a **Specify restore file name** text box and a **Browse** button.

Figure 252**Database Restore - from client machine**

Location: Tools > Database Restore >

Database Restore

Select restore source from: Client machine


Specify restore file name: Browse... Submit

[Download the latest restore log file](#)

- 3 Click **Browse** to navigate to the folder containing the backup file. The **Choose file** dialog window opens.
- 4 Select the backup file, and click **OK**. The **Specify restore file name** text box auto-fills with the path and filename of the backup file.
- 5 Click **Submit**.

A message is displayed in the text area of the Database Restore window showing a summary of the database restore from the client machine. See [Figure 253 "Database Restore - client machine - results"](#) (page 393).

Figure 253
Database Restore - client machine - results



The **Download the latest restore log file** link also appears on the web page. See [Procedure 132 “Downloading the latest restore log file”](#) (page 393) for downloading the restore log file.

--End--

Procedure 132 Downloading the latest restore log file

Step	Action
1	<p>NRS Manager provides the option to restore the database from three source locations:</p> <ul style="list-style-type: none"> • Follow Procedure 129 “Restoring from the connected Signaling Server” (page 389) to restore the database from the Connected Signaling Server • Follow Procedure 130 “Restoring from an FTP site” (page 390) to restore the database from an FTP site • Follow Procedure 131 “Restoring from a client machine” (page 392) to restore the database from the Client machine
2	<p>Click the Download the latest restore log file link to view the Restore log file.</p> <p>A window opens containing the latest restore log file, as shown in Figure 254 “Restore log file” (page 394). The name of the log file is rstLog.xml. The rstLog.xml file contains information about the database restore.</p>

Figure 254
Restore log file



- 3 The restore log file can be saved, using the **File > Save As...** menu option.

--End--

GK/NRS Data Upgrade

The **GK/NRS Data Upgrade** link on the Tools web page is used to upgrade a Succession 3.0 H.323 Gatekeeper to a CS 1000 Release 4.0 (or later) NRS. If required, this procedure must be completed as part of your upgrade procedures.

For detailed procedures, refer to *Signaling Server Installation and Commissioning (NN43001-312)* ().

Migration overview

To migrate your system, you must convert the Succession 3.0 H.323 Gatekeeper database into a CS 1000 Release 4.0 (or later) NRS database. This involves the following tasks:

- backing up the Succession 3.0 H.323 Gatekeeper database using Element Manager
- verifying that the backup files (.tar file) exist
- upgrading the Signaling Server software from Succession 3.0 to CS 1000 Release 4.0 (or later)
- reconfiguring the Signaling Server
- creating a Service Domain and Level 1 domain using NRS Manager (These two domains do not exist in the Succession 3.0 Gatekeeper.)
- converting the H.323 Gatekeeper database to the CS 1000 Release 4.0 (or later) NRS database using NRS Manager
- performing a database Cut over and Commit

The converted H.323 Gatekeeper database is stored in the NRS standby database. Changes made to the standby database do not immediately affect call processing. Before changes made to the

standby database affect call processing, database Cut over and Commit commands must be executed. See [“Performing NRS database actions” \(page 376\)](#).

Note: Only users with administrator privileges can execute Gatekeeper/NRS (GK/NRS) data conversion.

Figure 255 "GK/NRS Data Upgrade web page" (page 395) and Figure 256 "GK/NRS Data Upgrade - results" (page 396) are only for illustration purposes, to show the user interface for the Gatekeeper to NRS Upgrade area in NRS Manager.

Figure 255
GK/NRS Data Upgrade web page

Location: Tools > GK/NRS Data Upgrade >

GK/NRS Data Upgrade

Service domain name	<input type="text" value="myServiceProvider.com"/>
L1 domain name	<input type="text" value="myCompany.com"/>
Select upgrade source from	<input type="text" value="Local signaling server"/>

Figure 256
GK/NRS Data Upgrade - results

Location: Tools > GK/NRS Data Upgrade >

GK/NRS Data Upgrade

Service domain name

L1 domain name

Select upgrade source from

[Download the latest GK/NRS data conversion log file](#)

```

gkNrsDataUpgrade:
*****

nrsDbCvt
*****
Found 0 error(s) in Level 0 Domain
Found 0 error(s) in Endpoint
Found 0 error(s) in RoutingEntry

nrsDbCvtLoad
*****
Found 0 error(s) in Service Domain
Found 0 error(s) in Level 1 Domain
Found 0 error(s) in Level 0 Domain
Found 0 error(s) in Collaborating Server
Found 0 error(s) in Gateway endpoint
Found 0 error(s) in Routing Entry
Found 0 error(s) in System Wide Settings

```

SIP Phone Context

The SIP Phone Context web page provides a view of SIP phone-context constructions under a configured Level 0 Domain or Gateway Endpoint.

Procedure 133 SIP Phone Context

Step	Action
1	Click the Tools tab on the NRS Manager toolbar.
2	Click SIP Phone Context in the navigator.

The **SIP Phone Context** web page opens, as shown in [Figure 257 "SIP Phone Context web page"](#) (page 397).

Figure 257
SIP Phone Context web page

Location: Tools > SIP Phone Context >

SIP Phone Context

SIP phone context for

Service domain name

L1 domain name

L0 domain name

Gateway endpoint name [Look up](#)

- 3 Select **Standby DB** or **Active DB** from the **SIP phone context** for drop-down list.
- 4 Select the **Service domain name** from the drop-down list.
- 5 Select the **L1 domain name** from the drop-down list.
- 6 Select the **L0 domain name** from the drop-down list.
- 7 If the selected **L0 domain name** has configured Gateway Endpoints, the **Look up** link appears beside the **Gateway endpoint name** text box.

The Gateway endpoint name field is optional.

- If you do not select a Gateway Endpoint name and click **View**, then the SIP Phone Context Mapping information is displayed based on L0 domain configuration (which also applies to the User Endpoint configuration).
- If you select a Gateway Endpoint name and click **View**, then the SIP Phone Context Mapping information is displayed based on Gateway Endpoint configuration.

- 8 To select a Gateway Endpoint name, click the **Look up** link to open the **Look up path for gateway endpoints** web page.

The **Look up** utility allows you to search for Gateway Endpoints in two ways: **Page-by-Page** and **Name prefix**. (See [Procedure 116 "Performing a SIP Routing Test" \(page 371\)](#))

Click a **link** in the **ID** column of the **Lookup path for Gateway endpoints** web page and the **Gateway endpoint name** text box auto-fills with the selected Gateway Endpoint.

You cannot enter an endpoint name directly in the **Gateway endpoint name** text box.

- 9 Click **View**.

The SIP Phone Context web page expands to display the **SIP Phone Context Mapping** area, as shown in [Figure 258 "SIP Phone Context Mapping"](#) (page 398).

Figure 258
SIP Phone Context Mapping

Location: Tools > SIP Phone Context >

SIP Phone Context

SIP phone context for:

Service domain name:

L1 domain name:

L0 domain name:

Gateway endpoint name: [Look up](#)

SIP Phone Context Mapping

Level 1 regional	myCompany.com
Level 0 regional	MyCdpDomain.myCompany.com
Special	Not configured
E.164 international	+
E.164 national	+1
E.164 local	+1613

--End--

SSL/TLS Configuration

The SSL/TLS Configuration utility in NRS Manager configures the SSL/TLS certificate to enforce system security. Refer to *Element Manager: System Administration (553-3001-332)* () for information on this function.

Reports tab

Viewing the database reports

NRS Manager provides three database reports. The report types are:

- Last database synchronization for the Alternate NRS
- Last database synchronization for the Failsafe NRS
- Current database status

Note: Alternate and Failsafe NRS servers must exist for [Procedure 134 "Viewing the last database synchronization for the Alternate or Failsafe NRS"](#) (page 399) and [Procedure 135 "Viewing the current database status"](#) (page 400).


Last database synchronization

Follow [Procedure 134 "Viewing the last database synchronization for the Alternate or Failsafe NRS"](#) (page 399) to view the last database synchronization.

Procedure 134


Viewing the last database synchronization for the Alternate or Failsafe NRS

Step	Action
1	Click the Reports tab on the NRS Manager toolbar. The Database Report web page opens, as shown in Figure 259 "Last DB synchronized" (page 399)
2	Select Last DB synchronized for alternate or Last DB synchronized for failsafe from the Select report type drop-down list. Figure 259 Last DB synchronized



- 3 Click **Submit**.
[Figure 260 "Last DB synchronized for Alternate - results"](#) (page 400) shows the results of the last database synchronization for the Alternate NRS.

Figure 260
Last DB synchronized for Alternate - results



--End--

Current database status

Follow [Procedure 135 "Viewing the current database status"](#) (page 400) to view the current database status.

Procedure 135 Viewing the current database status

Step	Action
1	Click the Reports tab on the NRS Manager toolbar. The Database Report web page opens, as shown in Figure 259 "Last DB synchronized" (page 399).
2	Select Current DB status from the Select report type drop-down list.
3	Click Submit . Figure 261 Viewing the current database status



There are three database states:

- **Changed** — The configuration data in the standby database has been modified. The active and standby databases are not synchronized. See Step 3 in Figure 74 of IP Peer.
- **Switched Over** — A Cut over command has been executed after the configuration data in the standby database has been modified. The active and standby databases have been swapped by interchanging the active and standby database access pointers. The standby database is now unchanged and the active database contains the modified configuration data. The active and standby databases are not synchronized. See Step 5 in Figure 74 of IP Peer.
- **Committed** — A Commit or Rollback command has been executed after the configuration data in the standby database has been modified. The active and standby databases are synchronized. See Step 7 in Figure 75 of IP Peer, or Step 5 in Figure 76 or Step 5 in Figure 77 in IP Peer.

--End--

Administration tab

Configuring and administering users

Open the **Users** web page to administer, configure, and view users. Click the **Administration** tab on the NRS Manager toolbar to open the Users web page.

NRS Manager supports two types of access privileges:

- **Administrative privileges** — Administrators have full read/write privileges. An administrator can view and modify NRS configuration data.
- **Monitor privileges** — Monitors have read-only privileges. A monitor can only view the NRS configuration data.

An administrator can view, create, and modify the login names and passwords which are used for configuration and maintenance of the NRS.

If the currently logged-in user has administrator-level access, the user:

- can only change their own properties.
- cannot delete themselves
- cannot change their user access level

Another administrator account must be used to modify an administrator account.

Note: Administrator-level users for an NRS running on a stand-alone Signaling Server can also be configured and managed using CLI commands.

Creating new users


Follow the steps in [Procedure 136 "Creating new users" \(page 402\)](#) to create new users.

Procedure 136 Creating new users

Step	Action
1	Click the Administration tab on the NRS Manager toolbar. The Users web page opens, as shown in Figure 262 "Users web page" (page 402) .
2	Select Create New User from the Select user operation drop-down list. Figure 262 Users web page



3	Click Submit . The Create New User web pages opens, as shown in Figure 263 "Create New User web page" (page 402) . Figure 263 Create New User web page
---	---



*Mandatory field indicator

- 4 Enter a **User name** in the text box. The username is alphanumeric and can be up to 30 characters in length. The username cannot have spaces and the first character must be a letter.
- 5 Enter a **Password** in the text box. The password is alphanumeric and can be up to 24 characters in length.
- 6 Re-enter the password in the **Confirm Password** text box.
- 7 Select the access level of Administrator or Monitor from the **User access level** drop-down list.
- 8 Click **Save**.

The **Manage Configured Users** web page opens, as shown in [Figure 264 "Manage Configured Users web page"](#) (page 403).

Figure 264
Manage Configured Users web page

Location: Administration > Users > Manage Configured Users >

Manage Configured Users			
#	User Name	Password	User Access Level
1	admin	Not available	Administrator
2	john_user	Not available	Administrator

Add...

--End--

Viewing configured users

Follow the steps in [Procedure 137 "Viewing configured users"](#) (page 403) to view configured users.

Procedure 137 Viewing configured users

Step	Action
1	Click the Administration tab on the NRS Manager toolbar. The Users web page opens, as shown in Figure 262 "Users web page" (page 402)
2	Select Manage Configured Users from the Select user operation drop-down list.

Figure 265
Users web page



- 3 Click **Submit**.

The **Manage Configured Users** web pages opens. A list of configured users is displayed, as shown in [Figure 264 "Manage Configured Users web page" \(page 403\)](#).

Note: You can create new users from the View Configured Users web pages by clicking **Add....** The Create New User web page opens, as shown in [Figure 263 "Create New User web page" \(page 402\)](#). Follow the steps in [Procedure 136 "Creating new users" \(page 402\)](#) to configure the new user.

--End--

Editing or deleting configured users

Follow [Procedure 138 "Editing or deleting configured users" \(page 404\)](#) to edit a user's username, password, or access level. [Procedure 138 "Editing or deleting configured users" \(page 404\)](#) can also be used to delete users.

Procedure 138 Editing or deleting configured users

Step	Action
1	Click the Administration tab on the NRS Manager toolbar. The Users web page opens, as shown in Figure 262 "Users web page" (page 402)
2	Select Manage Configured Users from the Select user operation drop-down list.
3	Click Submit . The Manage Configured Users web page opens. A list of configured users is displayed.

Figure 266
Manage Configured Users web page

Location: Administration > Users > Manage Configured Users >

Manage Configured Users			
#	User Name	Password	User Access Level
1	admin	Not available	Administrator
2	john_user	Not available	Administrator

Add...

- 4 Click a **link** in the **User Name** column.

The **Manage User Property** web page opens, as shown in [Figure 267 "Manage User Property web page" \(page 405\)](#). The web page includes two buttons: **Save** and **Delete**.

Figure 267
Manage User Property web page

Location: Administration > Users > Manage User Property >

Manage User Property	
User name	<input type="text" value="john_user"/>
Password	<input type="password"/>
Confirm Password	<input type="password"/>
User access level	<input type="text" value="Administrator"/>

Save Delete

*Mandatory field indicator

- 5 To edit the user's **Password** enter a password in the text box. The password is alphanumeric and can be up to 30 characters in length.

Re-enter the password in the **Confirm Password** text box.

Select the access level of Administrator or Monitor from the **User access level** drop-down list.

Note: The username cannot be changed. If you want to change a user's username, delete the user and then recreate the user with the new username.

- 6 Click **Save**.
 The **Manage Configured User** web page re-opens.
- 7 To delete a user, click **Delete**.

The **Manage Configured Users** web page re-opens and the user is no longer displayed in the list of configured users.

--End--

Changing your password

Follow [Procedure 139 "Changing your password" \(page 406\)](#) to change your password.

Procedure 139 Changing your password

Step	Action
1	Click the Administration tab on the NRS Manager toolbar. The Users web page opens, as shown in Figure 265 "Users web page" (page 404)
2	Select Manage Configured Users from the Select user operation drop-down list.
3	Click Submit . The Manage Configured Users web page opens.
4	Click a link in the User Name column. The Manage user Property web page opens, as shown in Figure 267 "Manage User Property web page" (page 405)
5	Enter a new password in the Password text box.
6	Re-enter your new password in the Confirm Password text box. The password is alphanumeric and can be up to 30 characters in length.
7	Click Save . The User web page re-opens.

--End--

Accessing the NRS directly from the Signaling Server

The NRS can be accessed directly from the Signaling Server using a maintenance terminal. Follow the login procedure given in *Signaling Server Installation and Commissioning (NN43001-312)* ().

Use the following login credentials:

- User ID: **admin**
- Password: **cseadmin** or **<current>**

If you use the default password, you are prompted to change your password. If this is not your first login from the Signaling Server, and you have already changed your password, enter your new password (<current> above).

Note: You cannot access NRS Manager from the Signaling Server using this access method.

After you have logged in, you can use the Signaling Server CLI commands.

Appendix

Passthrough End User License Agreement

**WARNING**

Do *not* contact Red Hat for technical support on your Nortel version of the Linux base operating system. If technical support is required for the Nortel version of the Linux base operating system, contact Nortel technical support through your regular channels.

This section governs the use of the Red Hat Software and any updates to the Red Hat Software, regardless of the delivery mechanism and is governed by the laws of the state of New York in the U.S.A. The Red Hat Software is a collective work under U.S. Copyright Law. Subject to the following terms, Red Hat, Inc. (“Red Hat”) grants to the user (“Customer”) a license to this collective work pursuant to the GNU General Public License. Red Hat Enterprise Linux (the “Red Hat Software”) is a modular operating system consisting of hundreds of software components. The end user license agreement for each component is located in the component’s source code. With the exception of certain image files identified below, the license terms for the components permit Customer to copy, modify, and redistribute the component, in both source code and binary code forms. This agreement does not limit Customer’s rights under, or grant Customer rights that supersede, the license terms of any particular component. The Red Hat Software and each of its components, including the source code, documentation, appearance, structure and organization are owned by Red Hat and others and are protected under copyright and other laws. Title to the Red Hat Software and any component, or to any copy, modification, or merged portion shall remain with the aforementioned, subject to the applicable license. The “Red Hat” trademark and the “Shadowman” logo are registered trademarks of Red Hat in the U.S. and other countries. This agreement does not permit Customer to distribute the Red Hat Software using Red Hat’s trademarks. If Customer makes a commercial redistribution of the Red Hat Software, unless a separate agreement with Red Hat is executed or other permission granted, then Customer must modify any files identified as “REDHAT-LOGOS” and

“anaconda-images” to remove all images containing the “Red Hat” trademark or the “Shadowman” logo. As required by U.S. law, Customer represents and warrants that it: (a) understands that the Software is subject to export controls under the U.S. Commerce Department’s Export Administration Regulations (“EAR”); (b) is not located in a prohibited destination country under the EAR or U.S. sanctions regulations (currently Cuba, Iran, Iraq, Libya, North Korea, Sudan and Syria); (c) will not export, re-export, or transfer the Software to any prohibited destination, entity, or individual without the necessary export license(s) or authorization(s) from the U.S. Government; (d) will not use or transfer the Red Hat Software for use in any sensitive nuclear, chemical or biological weapons, or missile technology end-uses unless authorized by the U.S. Government by regulation or specific license; (e) understands and agrees that if it is in the United States and exports or transfers the Software to eligible end users, it will, as required by EAR Section 740.17(e), submit semi-annual reports to the Commerce Department’s Bureau of Industry & Security (BIS), which include the name and address (including country) of each transferee; and (f) understands that countries other than the United States may restrict the import, use, or export of encryption products and that it shall be solely responsible for compliance with any such import, use, or export restrictions. Red Hat may distribute third party software programs with the Red Hat Software that are not part of the Red Hat Software. These third party programs are subject to their own license terms. The license terms either accompany the programs or can be viewed at <http://www.redhat.com/licenses/>. If Customer does not agree to abide by the applicable license terms for such programs, then Customer may not install them. If Customer wishes to install the programs on more than one system or transfer the programs to another party, then Customer must contact the licensor of the programs. If any provision of this agreement is held to be unenforceable, that shall not affect the enforceability of the remaining provisions. Copyright © 2003 Red Hat, Inc. All rights reserved. "Red Hat" and the Red Hat "Shadowman" logo are registered trademarks of Red Hat, Inc. "Linux" is a registered trademark of Linus Torvalds. All other trademarks are the property of their respective owners.

Nortel Communication Server 1000

Network Routing Service Installation and Commissioning

Release: 5.5

Publication: NN43001-564

Document revision: 02.10

Document release date: 27 July 2009

Copyright © 2007-2009 Nortel Networks. All Rights Reserved.

LEGAL NOTICE

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, the Nortel Logo, the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks.

All other trademarks are the property of their respective owners.

To provide feedback or to report a problem in this document, go to www.nortel.com/documentfeedback.

www.nortel.com

