

---

**Nortel Communication Server 1000**

Nortel Communication Server 1000 Release 6.0

---

# **Communication Server 1000M and Meridian 1**

## **61C to CS 1000M SG CP PIV Upgrade**

Document Number: NN43021-461

Document Release: 03.03

Date: June 2009

---

Copyright © 2009 Nortel Networks. All rights reserved.

### **LEGAL NOTICE**

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, the Nortel logo, the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks. All other trademarks are the property of their respective owners.

---



---

# Contents

---

- New in this release** ..... **7**
- Features ..... 7
- Other ..... 7
  
- Finding the latest updates on the Nortel web site** ..... **11**
  
- How to get help** ..... **13**
- Getting help from the Nortel Web site ..... 13
- Getting help over the telephone from a Nortel Solutions Center ..... 13
- Getting help from a specialist by using an Express Routing Code ..... 14
- Getting help through a Nortel distributor or reseller ..... 14
  
- System information** ..... **15**
- Subject ..... 15
- Applicable systems ..... 16
- Intended audience ..... 17
- Conventions ..... 17
- NTP feedback ..... 18
- Related information ..... 18
  
- Introduction** ..... **21**
- Contents ..... 21
- Meridian 1 Option 61C upgrade to Option 61C CP PIV ..... 21

<b>Preparing and planning for the upgrade . . . . .</b>	<b>25</b>
Contents . . . . .	25
Introduction . . . . .	26
Planning . . . . .	27
Communication Server 1000 task flow . . . . .	29
Upgrade Checklists . . . . .	31
Preparing . . . . .	31
Identifying the proper procedure . . . . .	31
Connecting a terminal . . . . .	32
Checking the Core ID switches . . . . .	33
Printing site data . . . . .	35
Performing a template audit . . . . .	38
Backing up the database (data dump and ABKO) . . . . .	39
Making the RMD bootable . . . . .	43
Transferring the database from floppy disk to CF (customer database media converter tool) . . . . .	45
Identifying two unique IP addresses . . . . .	52
Check requirements for CNI to 3PE cables (NTND14) . . . . .	53
<b>Performing the upgrade . . . . .</b>	<b>55</b>
Contents . . . . .	55
Reviewing upgrade requirements . . . . .	55
Installing Core 1 hardware . . . . .	60
Installing Core 0 hardware . . . . .	108
Making the system redundant . . . . .	146
Completing the CP PIV upgrade . . . . .	150
<b>Installing a CP PM or COTS server . . . . .</b>	<b>159</b>
Contents . . . . .	159
Introduction . . . . .	160
Signaling Server task flow . . . . .	160

Readiness checklist .....	162
Installing the CP PM hardware .....	165
Connections .....	179
Installing the software .....	189
<b>Appendix A: Upgrade checklists .....</b>	<b>197</b>
Contents .....	197
Introduction .....	197
Site details .....	198
Upgrade details .....	198
Preupgrade checklists .....	199
Preconversion steps .....	202
Postconversion checks .....	204
Quick reference .....	204
<b>Appendix B: Technical Assistance service .....</b>	<b>209</b>
Contents .....	209
Nortel Technical Assistance Centers .....	209
Services available .....	212
Requesting assistance .....	215
<b>Index .....</b>	<b>217</b>



---

## New in this release

---

This chapter contains information about Nortel Communication Server 1000 Release 6.0 new features.

### Features

SIP Line provides an IP solution to deliver Business Grade Telephony features to IP end points. SIP Line integrates SIP end points in the Communication Server 1000 system and extends telephony features to SIP clients with the use of the Call Server, a SIP Line Gateway, and a SIP Line Management Service.

Signaling Server hardware and software contain updates. New Commercial-off-the-Shelf (COTS) servers are available from IBM and Dell. Communication Server 1000 Release 6.0 Signaling Servers require a Linux Operating System, and Linux Signaling Server applications.

Unified Communications Management (UCM) is a new name for the previous Enterprise Common Manager. UCM includes new configuration features for Centralized Deployment Manager, and Element Manager (EM).

### Other

See the following sections for information about changes that are not feature-related:

## Revision history

### June 2009

Standard 03.03. This document is upissued to update the CP PM BIOS upgrade procedure.

### May 2009

Standard 03.02. This document is upissued to include task flow graphics for Nortel Communication Server 1000 Release 6.0.

### May 2009

Standard 03.01. This document is issued to support Nortel Communication Server 1000 Release 6.0.

### November 2007

Standard 02.01. This document is issued to support Nortel Communication Server 1000 Release 5.5.

### July 2007

Standard 01.03. This document is upissued with corrections for invoking the installation menu during CP PIV and CP P4 upgrades.

### June 2007

Standard 01.02. This document is upissued with corrections to requirements for CNI to 3PE cables.

### May 2007

Standard 01.01. This document is issued for Communication Server 1000 Release 5.0.

### May 2006

Standard 5.00. This document is upissued with corrections installing clock controllers and keycode upgrade procedure for CP PIV.

### January 2006

Standard 4.00. This document is upissued with corrections to various upgrade procedures.

### August 2005

Standard 3.00. This document is upissued to support CP PIV and Communication Server 1000 Release 4.5.

**September 2004**

Standard 2.00. This document is upissued for Communication Server 1000 Release 4.0.

**October 2003**

Standard 1.00. This document is a new NTP for Succession 3.0. It was created to support a restructuring of the Documentation Library. This document contains information previously contained in the following legacy document, now retired: *Upgraded Systems Installation: Upgrade to Options 51C, 61C, 81C* (553-3001-258).



---

## Finding the latest updates on the Nortel web site

---

The content of this documentation was current at the time the product was released. To check for updates to the latest documentation and software for CS 1000 Release 6.0, click one of the links below.

<a href="#">Latest Software</a>	Go directly to the Nortel page for CS 1000 Release 6.0 software.
<a href="#">Latest Documentation</a>	Go directly to the Nortel page for CS 1000 Release 6.0 documentation.



# How to get help

---

This chapter explains how to get help for Nortel products and services.

## Getting help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

[www.nortel.com/support](http://www.nortel.com/support)

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

## Getting help over the telephone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

[www.nortel.com/callus](http://www.nortel.com/callus)

## **Getting help from a specialist by using an Express Routing Code**

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

[www.nortel.com/erc](http://www.nortel.com/erc)

## **Getting help through a Nortel distributor or reseller**

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

---

# System information

---

This document is a global document. Contact your system supplier or your Nortel representative to verify that the hardware and software described is supported in your area.

## Subject

Use this document to perform upgrades on Meridian 1 Large Systems. This document also contains information about database transfers, Call Processor card upgrades, and network group upgrades.

This document also contains information about converting Release 3.0 or later software to CS 1000 Release 6.0 on Meridian 1 Options 61C, CS 1000M SG and CS 1000M MG systems. For software conversion procedures prior to Release 3.0, see the *Software conversion procedures* (553-2001-320) NTP for software Release 24.



### **IMPORTANT!**

Database conversion for Meridian 1 Options 21E, 51, 61, 71, STE, NT, and XT must be completed by Nortel's Software Conversion Lab. Consult the current Nortel price book for cost and contact information.

### **Note on legacy products and releases**

This NTP contains information about systems, components, and features that are compatible with Nortel Communication Server 1000 Release 6.0 software. For more information about legacy products and releases, click the **Technical Documentation** link under **Support** on the Nortel home page:

[www.nortel.com/](http://www.nortel.com/)

## Applicable systems

This document applies to the following systems:

- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Meridian 1 PBX 61C

*Note:* When upgrading software, memory upgrades may be required on the Signaling Server, the Call Server, or both.

### System migration

When particular Meridian 1 systems are upgraded to run CS 1000 Release 6.0 software and configured to include a Signaling Server, they become CS 1000M systems. Table 1 lists each Meridian 1 system that supports an upgrade path to a CS 1000M system.

**Table 1**  
**Meridian 1 systems to CS 1000M systems**

This Meridian 1 system...	Maps to this CS 1000M system
Meridian 1 PBX 61C	CS 1000M Single Group
Meridian 1 PBX 81C	CS 1000M Multi Group

### Signaling Server configuration

Meridian 1 Large Systems can be configured to run one or more Signaling Servers. The following Signaling Servers are supported in a Large System configuration for CS 1000 Release 6.0:

- CP PM Signaling Server
- Commercial off-the-shelf (COTS) Signaling Server

For more information, see "Installing a CP PM or COTS server" on [page 159](#).

## Upgrade paths

This document contains information about the following Large System upgrades:

- Meridian 1 Options 61C, CS 1000M SG, and CS 1000M MG
- upgrades to FNF
- software upgrades
- network additions

The upgrades documented in this NTP are structured as source platform to target platform upgrades.

## Intended audience

This document is intended for individuals responsible for upgrading Large Systems.

This document is intended for individuals responsible for software conversion and memory upgrades.

## Conventions

### Terminology

The following systems are referred to generically as “Large System”:

- Communication Server 1000M Half Group (CS 1000M HG)
- Communication Server 1000M Single Group (CS 1000M SG)
- Communication Server 1000M Multi Group (CS 1000M MG)
- Meridian 1 PBX 51C
- Meridian 1 PBX 61C
- Meridian 1 PBX 81C

## NTP feedback

Nortel strives to provide accurate documentation for our customers. However, if you feel there are errors or omissions in this document, your feedback is welcome.

Send comments via email to [gntsdoc@nortel.com](mailto:gntsdoc@nortel.com) or open a problem report via the normal procedures.

Please provide as much information as possible including the NTP number, standard version and date of the document, as well as the page, problem description, and any supporting documentation and capture files.

## Related information



### CAUTION — Data Loss

Only personnel who are familiar with the system and with conversion procedures should perform the conversion.

Read the applicable procedures carefully before beginning any the conversion.

**Note:** Converting software on single CPU systems disrupts call processing and allows service only to those telephones connected to Power Failure Transfer Units (PFTU).



### CAUTION WITH ESDS DEVICES

To avoid damaging equipment from electrostatic discharge, wear a properly connected antistatic wrist strap when working on system equipment.

Perform pre-conversion and postconversion procedures for every system conversion.

Throughout this document the term *media* refers to tape, disk, CD-ROM or Compact Flash (CF), whichever applies to the system.

The term **source** refers to the hardware and software that is currently running. The term **target** refers to the new hardware and software to which the system is converting.

**CAUTION — Data Loss**

Read “General software conversion information” in *CS 1000M and Meridian 1 Large System Upgrades Overview* (NN43021-458) before performing any operations.

It contains information vital to the conversion process.

**NTPs**

The following NTPs are referenced in this document:

- *Product Compatibility* (NN43001-256)
- *Converging the Data Network with VoIP* (NN43001-260)
- *Circuit Card: Description and Installation* (NN43001-311)
- *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315)
- *IP Peer Networking: Installation and Commissioning* (NN43001-313)
- *Features and Services* (NN43001-106)
- *Software Input/Output: Administration* (NN43001-611)
- *Element Manager: System Administration* (NN43001-632)
- *IP Trunk: Description, Installation, and Operation* (NN43001-563)
- *Signaling Server IP Line Applications Fundamentals* (NN43001-125)
- *ISDN Basic Rate Interface: Features* (NN43001-580)
- *Software Input/Output: Maintenance* (NN43001-711)
- *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (NN43021-220)
- *Communication Server 1000M and Meridian 1: Large System Installation and Commissioning* (NN43021-310)

- *Communication Server 1000M and Meridian 1: Large System Maintenance* (NN43021-700)
- *Communication Server 1000M and Meridian 1 Large System Upgrade NTPs* (NN43021-458 – NN43021-475)

## Online

To access Nortel documentation online, click the **Technical Documentation** link under **Support** on the Nortel home page:

[www.nortel.com](http://www.nortel.com)

## CD-ROM

To obtain Nortel documentation on CD-ROM, contact your Nortel customer representative.

## Technical support

For technical support contact information, see 'Technical Assistance service' on [page 209](#).

---

# Introduction

---

## Contents

This chapter contains the following topics:

[Meridian 1 Option 61C upgrade to Option 61C CP PIV](#) ..... 21

## Meridian 1 Option 61C upgrade to Option 61C CP PIV

This NTP provides instructions for upgrading a source Meridian 1 Option 61C CP3, CP4 to a target platform of Meridian 1 Option 61C CP PIV. The procedures in this section are written for a stacked configuration (Core/Net 1 on top of Core/Net 0).

**Note:** For side-by-side configuration, additional equipment such as the pedestal, top cap, shelf spacers, or NT4N41 module, and XSM cables must be ordered separately. This equipment must be installed before attempting this upgrade. All existing cables in Core/Net 1 must be checked for proper length and routing to the new configuration.

Please see *Communication Server 1000M and Meridian 1: Large System Installation and Commissioning* (NN43021-310) for instructions on how to install a column.


Procedures are written with the intent to maintain partial service. The service interruption will cause half the system to be down during most of the procedure. Some thought should be given to a complete power down hardware replacement process.

Figure 1 on page 22 shows an upgrade from a Meridian 1 Option 61C to a stacked Meridian 1 Option 61C CP PIV.


Figure 2 on page 23 shows an upgrade from a Meridian 1 Option 61C to a side-by-side Meridian 1 Option 61C CP PIV.

	<b>DANGER OF ELECTRIC SHOCK</b>
In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column <i>must</i> be shut down throughout the procedures.	

**Figure 1**  
Meridian 1 Option 61C to Meridian 1 Option 61C CP PIV stacked




**Figure 2**  
**Meridian 1 Option 61C to Meridian 1 Option 61C CP PIV side-by-side**



This upgrade takes a Meridian 1 Option 61C to a single-group Meridian 1 Option 61C with CP PIV. CP PIV cards are located in the Core/Net modules or card cage (see Figure 3 on [page 24](#)).

- The card cages in the existing Core/Net modules are replaced with NT4N40 CP card cages.
- Existing network cards are relocated to the NT4N40 CP card cage.
- The existing Clock Controllers are moved from the old Core/Net to the CP PIV Core/Net in slot 9.
- An IPE module can be installed on top of CP PIV Core/Net 0 module.

**Figure 3**  
**NT4N41 CP Core/Net Module**



## Upgrading to CS 1000M

The upgrade to CS 1000M (installing a Signaling Server) occurs after completing the procedures in this section. See Appendix : “Installing a CP PM or COTS server” on [page 159](#).

---

# Preparing and planning for the upgrade

---

## Contents

This chapter contains the following topics:

Introduction . . . . .	26
Planning . . . . .	27
Communication Server 1000 task flow . . . . .	29
Upgrade Checklists . . . . .	31
Preparing . . . . .	31
Identifying the proper procedure . . . . .	31
Connecting a terminal . . . . .	32
Checking the Core ID switches . . . . .	33
Printing site data . . . . .	35
Performing a template audit . . . . .	38
Backing up the database (data dump and ABKO) . . . . .	39
Making the RMD bootable . . . . .	43
Transferring the database from floppy disk to CF (customer database media converter tool) . . . . .	45
Identifying two unique IP addresses . . . . .	52
Check requirements for CNI to 3PE cables (NTND14) . . . . .	53

## Introduction

This document implements a “source- to-target” approach to performing an upgrade. It is important to correctly identify the source platform, target platform, and maintenance window required to perform the upgrade.



### **IMPORTANT!**

This upgrade requires that the PC you are working from is equipped with a floppy disk drive and CF reader (or, if a CF reader is not available, a PCMCIA CF adaptor).

Each section features check boxes indicating what state the system should be in at that stage of the upgrade. If the system is not in the proper state steps should be taken to correct this.

Each section is written to maintain Dial Tone where possible and limit service interruptions.

Before attempting any software or hardware upgrade field personnel should follow the steps in Table 2:

**Table 2**  
**Prepare for upgrade steps (Part 1 of 2)**

<b>Procedure Step</b>	<b>Page</b>
Planning	27
Upgrade Checklists	31
Preparing	31
Identifying the proper procedure	31
Connecting a terminal	32
Checking the Core ID switches	33
Printing site data	35
Performing a template audit	38

**Table 2**  
**Prepare for upgrade steps (Part 2 of 2)**

Procedure Step	Page
Backing up the database (data dump and ABKO)	39
Transferring the database from floppy disk to CF (customer database media converter tool)	45
Identifying two unique IP addresses	52

## Planning

### Database requirements

If the system is running prerelease 3.0 software or the source platform is a Meridian 1 Option 21E, 51, 61, 71, STE, NT or XT, the database must be sent to Nortel for conversion.

If the source platform is a Meridian 1 Option 51C, 61C, 81, or 81C equipped with IOP/CMDU cards, the database must be converted with the Database Transfer utility. See “Converting the 4 MByte database media to 2 MByte database media” on [page 42](#).

If the source platform is a Meridian 1 Option 51C, 61C, 81, or 81C equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MB floppy.

**Note:** All of the above listed system types can be converted by Nortel in the software conversion lab. Please check the current price manual for the requirements of this service.

Planning for an upgrade involves the following tasks:

- Read and understand the current release Product Bulletin.
- Conduct a site inspection to determine proper power and grounding.
- Review the site profile to determine proper foot space if adding new columns or modules.
- Ensure sufficient power for new columns/modules or applications.

- Identify all applications that are currently installed on the source platform.
- Identify and correct outstanding service problems.
- Verify the site log is updated with current trunking, call routing, application notes, and site contact information.
- Review all product bulletins and Nortel Alerts that impact the site.
- Determine if software can be converted on site or must be sent to Nortel.
- Prepare a contingency plan for backing out of the upgrade.



**DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.


## Communication Server 1000 task flow

This section provides a high-level task flow for the installation or upgrade of a CS 1000 system. The task flow indicates the recommended sequence of events to follow when configuring a system and provides the NTP number that contains the detailed procedures required for the task.

For more information refer to the following NTPs, which are referenced in Figure 4 on [page 30](#):

- *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315)
- *Communication Server 1000M and Meridian 1 Large System Installation and Commissioning* (NN43021-310)
- *Communication Server 1000M and Meridian 1 Large System Upgrades Overview* (NN43021-458)

Figure 4  
Communication Server 1000M task flow



## Upgrade Checklists

Upgrade checklists can be found in “Upgrade checklists” on [page 197](#). Engineers may print this section for reference during the upgrade.

## Preparing

Preparing for an upgrade involves the following tasks:

- Identify and become familiar with all procedures.
- Verify that all installed applications meet the minimum software requirements for the target platform (see *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (NN43021-220)).
- Verify proper cable lengths for the target platform.
- Verify card vintage requirements of the target platform.
- Determine and note current patch or Dep lists installed at the source platform.
- Determine required patch or Dep lists at the target platform.
- Determine and communicate the required maintenance window, contingency plan and the impact to the customer to complete the procedure.
- Perform an inventory on required software and hardware.
- Secure the source software and key code.
- Secure the target software and key code.
- Verify the new key code using the DKA program.
- Print site data.

## Identifying the proper procedure

Each procedure has been written in a “source- to-target” format. Each procedure features warning boxes and check boxes placed at critical points.

Changing the procedure or ignoring the warning boxes could cause longer service interruptions.



**IMPORTANT!**

Preserve database backup information for a minimum of 5 days.

## Connecting a terminal

### Procedure 1 Connecting a terminal

A maintenance terminal is required to access the Core or Core/Net modules during the upgrade procedure.

- 1 Connect a terminal to the J25 port on the I/O panel in the *inactive* Core or Core/Net module.
- 2 The settings for the terminal are:
  - a. 9600 baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 3 If only one terminal is used for both Core or Core/Net modules, the terminal must be connected from side-to-side to access each module. An "A/B" switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## Checking the Core ID switches

### Procedure 2 Checking the Core ID switches

Each NT4N40 Core/Net card cage or module (see Figure 5 on [page 34](#)) is identified as “Core 0” or “Core 1”. This setting is made by a set of option switches on the System Utility card (see Figure 6 on [page 35](#)). The Core ID switches are set in the factory. Confirm that these settings match the identification labels for the module into which they will be installed.



#### **CAUTION — Service Interruption**

The CP Core/Net card cages **MUST** be installed in the correct Core 0 or Core 1 module.


- 1 Pull the System Utility card (NT4N48) far enough out of its slot so you can see the ID switch settings.
- 2 Check and confirm the switch settings according to Table 3 on [page 33](#).
- 3 Reinstall the System Utility card.
  - a. Gently slide the card into the slot until it makes contact with the backplane. Never force a card into the slot.
  - b. Push in the top and bottom latches on the card to lock it in place.

**End of Procedure**

**Table 3**  
**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core 0	On	On
Core 1	Off	On

**Figure 5**  
**Core card placement in the NT4N40 Core/Net card cage (front)**



**Figure 6**  
**Core Module ID switch**



## Printing site data

Print site data to preserve a record of the system configuration (see Table 4 on [page 36](#)). Verify that all information is correct. Make corrections as necessary.

*Note:* Items marked with an asterisk (\*) are required. Other items are recommended for a total system status.

**Table 4**  
**Print site data (Part 1 of 3)**

Site data	Print command	
Terminal blocks for all TNs	LD 20	
	REQ	PRT
	TYPE	TNB
	CUST	<cr>
Directory Numbers	LD 20	
	REQ	PRT
	TYPE	DNB
	CUST	<cr>
Attendant Console data block for all customers	LD 20	LD 20
	REQ	PRT
	TYPE	ATT, 2250
	CUST	<cr>
*Customer data block for all customers	LD 21	LD 21
	REQ	PRT
	TYPE	CDB
	CUST	<cr>
Route data block for all customers	LD 21	
	REQ	PRT
	TYPE	RDB
	CUST	Customer number
	ROUT	<cr>
	ACOD	<cr>
*Configuration Record	LD 22	
	REQ	PRT
	TYPE	CFN

**Table 4**  
**Print site data (Part 2 of 3)**

Site data	Print command	
*Software packages	LD 22	
	REQ	PRT
	TYPE	PKG
*Software issue, ROM and tape ID	LD 22	
	REQ	ISS
	REQ	ROM
	REQ	TID
* Peripheral software versions	LD 22	
	REQ	PRT
	TYPE	PSWV
ACD data block for all customers	LD 23	
	REQ	PRT
	TYPE	ACD
	CUST	Customer Number
	ACDN	ACD DN (or <CR>)
Superloop card IDs and software version (peripheral controller, superloop network and controller cards)	LD 32	
		IDC loop
Multi-purpose ISDN Signaling Processor (MISP) card	LD 27	
	REQ	PRT
	TYPE	MISP
	LOOP	loop number (0-158)
	APPL	<cr>
	PH	<cr>
DTI/PRI data block for all customers	LD 73	
	REQ	PRT
	TYPE	DDB

**Table 4**  
**Print site data (Part 3 of 3)**

Site data	Print command	
Print the configured host information	LD 117	PRT HOST (provides system IP addresses)
Superloops and XPEs	LD 97	REQ                    CHG TYPE                    SUPL SUPL                    Vxxx V stands for a virtual superloop and xxx is the number of the virtual superloop.  xxx = 0-252 in multiples of four for MG 1000E
<b>Note:</b> Items marked with asterisks (*) are required printout for conversion. Other items are recommended for a total system status.		

## Performing a template audit

A template audit (LD 01) reviews the templates in your system. Corrupted and duplicate templates are cleaned up. An example of the information generated during the audit is listed below.

**Note:** The template audit may take an extended period of time on large systems. Run the audit during a low traffic period.



### **CAUTION — Service Interruption**

#### **Loss of Data**

Do not abort this overlay until the audit is complete. If the overlay is interrupted, data will be corrupted.

**LD 01** The audit begins as soon as LD 01 is entered.

**TEMPLATE AUDIT**

**STARTING PBX TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT</b>	<b>CHECKSUM</b>
<b>LOW</b>	<b>OK</b>

<b>TEMPLATE 0002 USER COUNT</b>	<b>CHECKSUM</b>
<b>HIGH</b>	<b>OK</b>

**TEMPLATE 0003 NO USERS FOUND**

**STARTING SL1 TEMPLATE SCAN**

<b>TEMPLATE 0001 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

•

•

<b>TEMPLATE 0120 USER COUNT OK</b>	<b>CHECKSUM</b>
	<b>OK</b>

**TEMPLATE AUDIT COMPLETE**

## **Backing up the database (data dump and ABKO)**

To back up system data, complete the following two procedures.

- 1** Perform a data dump to save all system memory to the hard disk.
- 2** Perform a ABKO (attended backup) to save the database to a spare set of floppy disks.

**Procedure 3**  
**Performing a data dump**

- 1 Log into the system.
- 2 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:

**LD 43**            Load program

- 3 When "EDD000" appears on the terminal, enter:

**EDD**            Begin the data dump



**CAUTION — Service Interruption**

**Loss of Data**

If the data dump does not succeed, do not continue. Contact your technical support organization. You must correct a data dump problem before the system can be upgraded.

- 4 The messages "DATADUMP COMPLETE" and "DATABASE BACKUP COMPLETE" will appear once the data dump is complete.

\*\*\*\*            Exit program

---

**End of Procedure**

---

**Procedure 4**  
**Performing an ABKO (save the database to floppies)**

- 1 Insert floppy diskettes into BOTH floppy disk drives in each Core IODU/C or MMDU.

**Note:** If the file is too large to fit on a single floppy disk, the ABKO command will compress the data. If the compressed data is still too large to fit on a single disk, both floppy disks in the two IODU/C drives will be used. Be sure to insert floppy disks into BOTH IODU/C drives before the ABKO backup is begun.

- 2 Load the Customer Configuration Backup and Restore (LD 143). At the prompt, enter:

**LD 143**            Load program

- 3 Run the ABKO backup (LD 143).

**ABKO**            Run backup

Result: If the backup is successful, the system displays a message that states that the database backup is complete and generates a report that indicates which floppy drives were used.

- 4 If there are validation errors, repeat the procedure.



**CAUTION — Service Interruption**

**Loss of Data**

If the backup is not successful, do not continue; contact your technical support organization. Any backup problems must be corrected before the system is upgraded to CP PIV.

- 5 Once the backup is complete, type:

\*\*\*\*                    Exit program



**IMPORTANT!**

If the system is equipped with IOP/CMDU cards the database must be converted with the Database Transfer utility below.

If the system is equipped with IODUC cards, the database should be data dumped (EDD) to a blank 2 MByte floppy.

All systems can be converted by Nortel in the software conversion lab.

**Procedure 5**  
**Converting the 4 MByte database media to 2 MByte database media**

Before the system is upgraded to CP PIV, the database must reside on a 2 MByte floppy disk for conversion to CF. Systems with an IODU/C drive already have 2 MByte floppy drive and can skip this procedure.

If the database is on a 4 MByte floppy (the system has an IOP/CMDU), the 4 MByte customer database must be transferred to a 2 MByte floppy disk.

- 1 Split the Cores and transfer call processing to Core 0.
- 2 Install the Database Transfer Utility diskette into the floppy drive on the IOP/CMDU in Core 1.
- 3 Press the reset button (MAN RST) on the Call Processor card in Core 1 to reboot the system. Start the Database Transfer Utility Tool.



**CAUTION — Service Interruption**

Select only options:

- <t> Tools Menu from the Install menu, and
- <s> To archive database from the Tools menu.

DO NOT select any other options. Other options can result in operating system corruption.

- 4 From the installation menu select:
  - <t> Go to the Tools menu.
  - <s> Archive existing database.
  - <cr> <a> Continue with archive (insert blank 2 MByte diskette from the software kit into the floppy drive in Core 1).
  - <cr> <a> Diskette is now in floppy drive in Core 1.
- 5 The message displays “Database backup complete!” and the Tool menu appears again after the backup completes correctly.

- 6 Remove the 2 MByte customer database diskette from the floppy drive of the IOP/CMDU. Do not reboot the system at this point.

---

**End of Procedure**

---

## Making the RMD bootable



### **CAUTION — Data Loss**

The PC utility used in the following procedure (mkbootrmd.exe) does not validate whether the drive letter entered is a valid RMD CF card. You must enter the correct RMD drive letter when prompted or risk formatting the incorrect drive.

The PC utility used in the following procedure (mkbootrmd.exe) will erase any data on the CF card. For more information, read the README\_BOOTABLE\_RMD.txt file.

**Note:** This utility is supported by all versions of Microsoft Windows.


The installation RMD CF card must come preformatted and bootable from Nortel. Consumer CF cards are not bootable by default and must be made bootable as outlined in Procedure 6 on [page 43](#).

### **Procedure 6 Making the RMD bootable**

- 1 After downloading the software image file, unzip it to a directory on your PC.
- 2 Open the utilities folder.


- 3 Double click the mkbootrmd.bat file. Insert a blank 512 MByte CF card (see Figure 7).

Figure 7  
mkbootrmd.bat



- 4 Enter the correct drive letter of the RMD (see Figure 8).

Figure 8  
mkbootrmd.bat



- 5 The boot sector files (bootrom.sys and nvr.am.sys) are successfully copied making the CF card bootable (see Figure 9).

**Figure 9**  
**Boot sector successfully installed**

```

. RMD format Successful ...
. Installing Boot sector ...
.
. Copying files . . .
. bootrom.sys copied OK.
. Check whether the following output shows
. "All the specified file(s) are contiguous"
.
.      * * * WARNING * * *
. IF THE FILES ARE NOT CONTIGUOUS,
. PLEASE RECREATE THE RMD
.      * * * * *
. Press any key to continue . . .
. The type of the file system is FAT.
. Volume CS1000BOOT created 4/12/2006 12:22 PM
. Volume Serial Number is 389E-1E98
. Windows is verifying files and folders...
. File and folder verification is complete.
. Windows has checked the file system and found no problems.
.
.      512,180,224 bytes total disk space.
.      352,256 bytes in 1 files.
.      511,827,968 bytes available on disk.
.
.      8,192 bytes in each allocation unit.
.      62,522 total allocation units on disk.
.      62,479 allocation units available on disk.
. All specified files are contiguous.
. Press any key to continue . . .

```

End of Procedure

## Transferring the database from floppy disk to CF (customer database media converter tool)



### IMPORTANT!

This upgrade requires that the PC you are working from is equipped with a floppy disk drive and CF reader (or, if a CF reader is not available, a PCMCIA CF adaptor).

The floppy disk that contains the backed up customer database needs to be transferred to a CF card. This procedure converts the customer database from

a 2 MByte floppy disk to CF card, which is restored during the CS 1000 Release 6.0 software upgrade later in this section. Nortel recommends using the extra CF card included with the Software Install Kit.


**Procedure 7**

**Transferring the customer database from floppy disk to CF**

This procedure requires that the PC you are working from is equipped with a floppy disk drive and CF reader (or, if a CF reader is not available, a PCMCIA CF adaptor).

- 1 After downloading the software image file, unzip it to a directory on your PC.
- 2 Open the Utilities folder. See Figure 10.

**Figure 10**  
**Utilities folder**




- 3 Insert the floppy disk containing the backed up customer database from Procedure 3 on [page 40](#).
- 4 Insert a CF card (there is one included in the Software Install Kit) into the CF reader or PCMCIA CF adapter.
- 5 Start the Database Media Converter utility by double clicking the CPP4cnvrt.exe file. The first screen (Figure 11 on [page 48](#)) prompts you to select the correct drive letter for the floppy disk drive.

**Figure 11**  
**Select the floppy disk drive**



- 6 The utility then prompts you to insert the floppy disk (diskette 1) and click OK (see Figure 12 on [page 49](#)).

**Figure 12**  
**Insert diskette 1**



- 7 After verifying the database on the floppy disk, the utility prompts you to select the CF drive (see Figure 13 on [page 50](#)).


**Note:** if the database is on more than 1 floppy, the utility prompts you to insert the next floppy until the entire database is read.

**Figure 13**  
**Select the CF drive**



- 8 At this point, 2 options are available:
- a. If the CF card already contains a previously backed-up database, a dialog box appears (see Figure 14 on [page 51](#)). Click yes to replace old database.
  - b. If the CF card is blank, the database is backed up to the CF card.

**Figure 14**  
**Replace database on CF drive**



- 9 The utility completes the transfer to CF and prompts you to copy another or EXIT.

**Figure 15**  
**Copy another or exit**



End of Procedure

## Identifying two unique IP addresses

Each CP PIV system must be configured with two unique IP addresses for LAN identification and communication. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core. In this

configuration, the *active* Core (either Core 0 or Core 1) that handles call processing is always identified by the same IP address.

Contact your System Administrator to identify two unique IP addresses before the upgrade.

## Check requirements for CNI to 3PE cables (NTND14)



### **IMPORTANT!**

When configuring NTND14 cables, observe the following rules:

- The shortest NTND14 Cable should always be used.
- A network group requires 4 NTND14 cables, 2 to each half group. Both cables to each half group must be the same length.
- A check should be made on the existing NTND14 cables. Replace any cables that do not meet the above requirement.

**Note:** The NTND14 BX 50' cables are manufacture discontinued.



---

# Performing the upgrade

---

## Contents

This chapter contains the following topics:

Reviewing upgrade requirements .....	55
Installing Core 1 hardware .....	60
Installing Core 0 hardware .....	108
Making the system redundant .....	146
Completing the CP PIV upgrade.....	150

## Reviewing upgrade requirements

### Check software received

The following software packages are required to upgrade a system to Meridian 1 Option 61C with CP PIV:

- CPP\_CNI CP Pentium Backplane for Intel Machine Package 368
- Compact Flash Software Install Kit, containing the following items:
  - One CF (512 MByte) card containing:
    - Install Software files
    - CS 1000 Release 6.0 software
    - Dep. Lists (PEPs)
    - Key code File

- One blank CF card for database backup
- One Nortel CS 1000 Release 6.0 Documentation CD

## Check equipment received

This section describes the *minimum* equipment required for CP PIV. Additional equipment can also be installed during the upgrade. Verify that *all* equipment has been received.

Meridian 1 Option 61C CP PIV equipment is configured at the factory according to customer requirements. Some cards and power supplies are shipped in separate packages to prevent damage to cards.

Before the upgrade, check that equipment on the order form is also on the packing slip. Check that all equipment has been received. If any items are missing, contact your supplier for replacements before you begin the upgrade.



### **WARNING**

#### **Service Interruption**

DO NOT proceed with the upgrade if any of the required equipment is missing. All equipment must be received to complete the upgrade.

## Check vintage requirements for existing hardware

Make sure that existing hardware meets the following minimum vintage requirements for CP PIV:

- The NT4N65 cCNI card must be minimum vintage of AC
- The NT4N48 System Utility card must be minimum vintage AA
- The QPC441 3-Port Extender (3PE) cards must be minimum vintage F.
- The NTRB53 Clock Controller cards must be minimum vintage AA.
- The existing QPC471 Clock Controller cards must be minimum vintage H or the QPC775 Clock Controller cards (all countries except USA) must be minimum vintage E.
- NT6D41CA (DC) Power Supply

- NT8D29BA (AC) Power Supply
- The QPC43 Peripheral Signaling cards must be minimum vintage R.

If any equipment does not meet these requirements, replace the equipment before you begin the upgrade.



**CAUTION — Service Interruption**

**Service Interruption**

Equipment that does not meet the minimum vintage requirements will cause system malfunctions and loss of call processing.



**WARNING**

Clock Controller cards must be of the same part number for any single system. For instance, a QPC471 card cannot be used with an NTRB53 card.

**Check required hardware (AC and DC)**

Table 5 on [page 57](#) lists the equipment required for DC-powered systems. Table 6 on [page 58](#) lists the equipment required for AC-powered systems.



**WARNING**

Ensure that power supplies NT6D41CA (DC) or NT8D29BA (AC) are used in the Core/Net shelf.

**Table 5**  
**DC requirements for Meridian 1 Option 61C CP PIV system**

Order number	Description	Quantity per system
NTHU44DA	Option 61C Single Group Base Package (DC)	1

**Table 6**  
**AC requirements for Meridian 1 Option 61C CP PIV system**

Order number	Description	Quantity per system
NTHU44AA	Option 61C Single Group Base Package (AC)	1

The equipment room must provide the appropriate number of 30 Ampere outlets. One 175-264 Vac, 47-63 Hz, 30 Ampere outlet is required for every pedestal or column.

If supporting additional Meridian 1 modules, order additional top cap & pedestal packages (NTWB15BA). One top cap and pedestal package supports up to 4 modules.

To cover all exposed module sides and to connect modules side-to-side, additional NT9D18AA module side covers and NT8D49AA column spacer kits must be ordered separately.

The NTHU44AA and DA packages contain common equipment hardware only, including two CP PIV Pentium call processor cards and two NTRB53 Clock Controller cards.

These packages are designed for computer floor installation, with all cables exiting from the pedestal. If the installation requires overhead cabling, order NT7D0009 top egress panel, one per column.

An NT8D49AA Spacer kit is provided to allow for a side-by-side installation of core/network modules. This arrangement will require an additional top cap and pedestal package and must be ordered separately.

Intelligent peripheral equipment must be ordered separately. Order NTWB15DA for any additional AC IPE Modules required.

Peripheral equipment (PE) or Enhanced peripheral equipment (EPE) is not supported on systems with Pentium Processors.

## Check personnel requirements

Nortel recommends that a minimum of two people perform the card cage upgrade.

## Database requirements

If the system is running prerelease 3.0 software or the source platform is a Meridian 1 Option 21E, 51, 61, 71, STE, NT or XT, the database must be sent to Nortel for conversion.

## System requirements



### IMPORTANT!

Systems and components delivered to customer sites may include preinstalled software. However, the preinstalled software versions are typically older and are included only for manufacturing and order management purposes. **Do not attempt to operate the system with the preinstalled software.** The latest software must be downloaded from the Nortel Software Downloads web site and installed as part of the upgrade process.

## CS 1000 compatibility

Consult *Communication Server 1000M and Meridian 1: Large System Planning and Engineering* (NN43021-220) for CS 1000 Release 6.0 product compatibility.

## Installing Core 1 hardware

### Procedure 8 Checking main Core card installation

The main Core cards are installed in the factory as shown in Figure 16 on [page 61](#):

- 1 NT4N65AC CP Core Network Interface (cCNI) cards:  
Each system contains one NT4N65 cCNI card per Core/Net module. The cCNI cards are located in slot c9. If not already installed, install a P0605337 CP Card Slot Filler Panel to cover slots c10-c12, which do not contain cCNIs.  
  
**Note:** In the NT4N41 Core/Net module, port 0 on the NT4N65 Core to Network Interface (cCNI) Card in slot c9 must be configured as “group 0.” The cCNI and 3PE cards for group 0 communicate through the NT4N29 cable. Only one cCNI card is required for group 0 in a Meridian 1 Option 61C CP PIV.
- 2 Slots c13 and c14 are left empty. If not already installed, install a P0605337 CP Card Slot Filler Panel in each slot.
- 3 NT4N48 System Utility (Sys Util) card is located in slot c15. Check side ID switch settings for SU card in Core/Net 1 according to Table 7.

**Table 7**  
**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core 0	On	On
Core 1	Off	On


- 4 NT4N39 CP PIV is located in the Call Processor slot.
- 5 The N0026096 blank faceplate is located in the extreme right-hand slot next to the CP PIV card.

---

**End of Procedure**

---

**Figure 16**  
**Core card placement in the NT4N41 Core/Net Module (front)**



**Check for the shelf power cable**

Check that the NT4N4405 Shelf Power Cable is installed in the CP card cage backplane. See Figure 17 on [page 63](#) for cable location.


## Check factory-installed cables

Table 8 lists factory-installed cables.

**Table 8**  
**Factory-installed cables**

Order Number	Description	Quantity per Core/Net shelf
NT4N4405	Shelf Power Cable	1
NT4N89AA	System Monitor cable	1
NT4N29AA	CNI to 3PE cable	2

**Figure 17**  
**Core/Net cable connections (top view)**



## Disable and remove equipment from Core 1

### Procedure 9

#### Checking that Core 0 is active

To upgrade Core 1, verify that Core 0 is the active side performing call processing:

- 1 Verify that Core 0 is active.

**LD 135** Load program

**STAT CPU** Obtain the status of the CPUs

- 2 If Core 1 is active, make Core 0 active:

**SCPU** Switch to Core 0 (if necessary)

**\*\*\*\*** Exit program

---

**End of Procedure**

---

### Procedure 10

#### Checking that Clock Controller 0 is active

- 1 Check the status of the Clock Controllers:

**LD 60** Load program

**SSCK 0** Obtain the status of Clock Controller 0

**SSCK 1** Obtain the status of Clock Controller 1

- 2 If Clock Controller 1 is active, switch to Clock Controller 0.

**SWCK** Switch to Clock Controller 0 (if necessary)

**DIS CC 1** Disable Clock Controller 1

**\*\*\*\*** Exit program

- 3 Faceplate-disable Clock Controller 1.

---

**End of Procedure**

---

**Procedure 11**  
**Splitting the Cores**

- 1 In Core 0, set the NORM/MAINT switch on the Call Processor card to MAINT.
- 2 In Core 1, set the ENB/DIS switch on the NT6D65 cCNI card to DIS.
- 3 In Core 1, set the NORM/MAINT switch on the Call Processor card to MAINT.



The system is now in split mode, with call processing on Core 0.



At this point, all applications must be shut down (CallPilot, Symposium, and so on).

## Software disable Network cards in Core/Net 1 from Core/Net 0



### CAUTION — Service Interruption

#### Service Interruption

At this point, the upgrade interrupts service.

### Procedure 12

#### Software disabling cards in network slots of Core/Net 1 from Core/Net 0

1 In Core/Net 1 only, software disable all network and I/O cards such as XNET, TTY, Conf/TDS and ISDN cards:

a. In Core/Net 1 only, disable XNET.

**LD 32** Load program

**DISL sl** sl = the superloop number of the XNET card

\*\*\*\* Exit program

b. In Core/Net 1 only, disable ENET.

**LD 32** Load program

**DISL X** X= the loop number of the ENET card

\*\*\*\* Exit program

c. In Core/Net 1 only, software disable each port on the SDI cards:

**LD 37** Load program

**DIS TTY x** x = the number of the interface device attached to a port

\*\*\*\* Exit program

d. In Core/Net 1 only, disable DTI cards.

**LD 60** Load program

**DISL x** x = the loop number of the DTI port

\*\*\*\* Exit program

e. In Core/Net 1 only, disable DCH and PRI cards.

**LD 96** Load program

**DIS DCH x** Disable DCH, where x = associated D-Channel

\*\*\*\* Exit program

**LD 60** Load program

**DISL x** Disable PRI card, where x = the loop number  
PRI port

\*\*\*\* Exit program

f. In Core/Net 1 only, disable MSDL cards.

**LD 48** Load program

**DIS MSDL x** x = the MSDL card number. System will respond  
with group 0

\*\*\*\* Exit program

g. In Core/Net 1 only, disable XCT cards.

**LD 34** Load program

**DISX x** x = the superloop number of the XCT card

\*\*\*\* Exit program

2 In Core/Net 1 only, software disable the QPC43 Peripheral Signaling  
Card:

**LD 32** Load program

**DSPS x** Table 9 lists Peripheral Signaling Card values for “x”

**\*\*\*\*** Exit program

**Table 9**  
**Peripheral Signaling Card numbers**

Group/ shelf	Peripheral Signaling Card	Loops disabled/enabled			
0 / 0	0	0	–	15	
0 / 1	1	16	–	31	

- 3 In Core/Net 1 only, faceplate-disable the 3PE, Per Sig and all network cards.

---

**End of Procedure**

---



**CAUTION — Service Interruption**

**Service Interruption**

The system can shut down if the system monitors are not removed. Remove the monitors and keep the cooling fans ON.

**Procedure 13**  
**Removing the system monitors from the Core column**

**Note:** Perform the following procedure for both AC and DC systems

- 1 In Core 0, software disable the master system monitor (NT8D22):

**LD 37** Load program

**DIS TTY #** Disable the master system monitor TTY interface

- 2 Remove J3 and J4 cables on Core 0 system monitor.

**Note:** Do *not* turn off the blower units in the front of the pedestals

- 3 Remove the system monitor from the rear of the pedestal on Core 0.

---

**End of Procedure**

---

## Power down Core/Net 1



### **CAUTION — Service Interruption**

#### **Service Interruption**

Call processing is interrupted for approximately 60 minutes while the procedures are completed.



### **DANGER OF ELECTRIC SHOCK**

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

For AC-powered systems: set the MPDU circuit breaker located at the left end of the module to OFF (down position).

For DC-powered systems: set the breaker for the Core 1 module in the back of the column pedestal to OFF (down position).

### **Procedure 14**

#### **Removing Core 1 cables and card cage**

- 1 Label and disconnect the Clock Controller 1.
  - a. Disconnect the NT8D76AC cable from the Clock Controller 1 faceplate card.
  - b. If primary and secondary clock reference cables are connected to the Clock Controller 1 faceplate, disconnect them last.
- 2 Label and disconnect all cables from the front of the module.
- 3 Tape over the contacts to avoid grounding.
- 4 Tie all cables to the sides so the working area in front of the card cage is totally clear.

- 5 Remove the I/O safety panel by turning the screws on each side. Set the I/O safety panel aside.
- 6 Tag and disconnect all cables from the backplane to the interior of the I/O assembly.
- 7 Tag and disconnect all plugs, wires, and cables to the backplane.  
**Note 1:** Leave the network cards in the card cage. You will relocate them to the CP card cage later in the upgrade procedure.  
**Note 2:** Two people are needed to remove the Core card cage because of the weight of the card cage with the cards left installed.
- 8 Use a 1/4" nut driver to remove the two mounting screws at the bottom rear of the card cage. The screws secure the card cage to the module casting. Keep the screws for use with the CP card cage.




**CAUTION — Service Interruption**

Do not drop the mounting screws into the pedestal. Doing so can cause serious damage.


- 9 Remove the front trim panels on both sides of the card cage.
- 10 Remove the three mounting screws that secure the front of the card cage to the bottom of the module. Keep the screws for use with the CP card cage.
- 11 Pull the card cage forward until it is halfway out of the module.
- 12 Disconnect cables, plugs, and wires from the rear of the module to the backplane.
- 13 Remove the logic return (LTRN) (orange) wire from the backplane bolt. Be careful; do not drop the nut or lock washer into the pedestal. See Figure 18 for DC power connectors. See Figure 19 on [page 72](#) for AC power connectors.
- 14 Remove the frame ground (FGND) (green) wire from the frame ground bolt on the module.
- 15 Label and disconnect the module power connectors. In an AC-powered system, these are small orange connectors plugged into the module power distribution unit (MPDU). In a DC-powered system, these are connected to each other.

**Figure 18**  
**DC power connectors on the Core module backplane**



- 16** Label and disconnect the system monitor ribbon cables to J1 and J2.
- 17** Remove the Core card cage from the module.
- 18** Remove the power harness and reserve it for reinstallation when you install the NT4N40 card cage. The power harness is located at the right rear lower corner and plugs into the rear of the power supply. For AC systems, relocate power harness NT8D40. For DC systems, relocate power harness NT7D11.

**Figure 19**  
**AC power connectors on the Core module backplane**



- 19** Reposition the EMI shield (it looks like a brass grill) in the base of the module. Tape over the front mounting tabs to hold the shield in position. You will remove the tape later.



**WARNING**

If you do not tape the EMI shield in position, you will not be able to install the card cage in the module correctly.



**CAUTION — Service Interruption**

**Damage to Equipment**

Check for and remove any debris (such as screws) that fell into the base of the UEM module.

---

**End of Procedure**

---

**Procedure 15**  
**Installing the CP card cage in Core 1**

- 1 Check that the card cage is configured as Core 1. See Table 10 for instructions.

	<p style="text-align: center;"><b>IMPORTANT!</b></p> <p>An NT4N41 Core/Net module with pedestal, top cap and necessary cables should already have been installed. If so, proceed to “Relocating Network cards to CP PIV Core/Net 0” on <a href="#">page 78</a>.</p>
---	---

**Table 10**  
**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core/Net 0	On	On
Core/Net 1	Off	On

- 2 For AC-powered systems only, attach the new MPDU, part of the CP PIV Upgrade kit, to the side on the NT4N40 card cage. The screws that secure the MPDU are accessible from the power supply slot. See Figure 20 on [page 75](#).

**Note:** Prethread 2 bottom mounting screws at the back of the Core/Net shelf. Check that the power harness at the right rear corner of the card cage has been transferred from the old card cage to the CP card cage.


- 3 Slide the CP card cage halfway into the module.
- 4 Hold the card cage firmly and make the following connections at the rear of the module.
  - a. In AC-powered systems, connect the remaining module power connectors to J2 on the MPDU. Then plug the module power cable

(the short harness attached to the module power connector) into connector J3 on the MPDU (attached to the side of the card cage).

**CAUTION — Service Interruption****Damage to Equipment**

Check for and remove any debris (such as screws) that may have fallen into the base of the UEM module.

**Figure 20**  
**Location of the screws for the MPDU**



- b.** In DC-powered systems, connect the module power connectors to each other.
- c.** Attach the system monitor ribbon cables:
  - i.** Connect the ribbon cable that goes down to the column to connector J1 on the backplane.
  - ii.** Connect the ribbon cable that goes up the column to J2 on the backplane.

- d. Use a 11/32" socket wrench to attach the green ground wire to the frame ground bolt on the module. Remove the nut and the lock washer at the top of the bolt. Put the frame ground wire terminal over the bolt. Reinstall the top lock washer and the nut, then tighten down the nut.

**Note:** For all of the wire terminals to fit on the bolt, remove one of the lock washers. Leave the first lock washer at the bottom of the bolt and a second at the top of the bolt. Leave a third lock washer between the second and third, or the third and fourth, wire terminals.

- e. Attach the orange logic return wire. Remove one nut and the lock washer from the LRTN bolt at the rear of the card cage. Put the wire terminal over the bolt, reinstall the lock washer and nut. Use a 1/4" socket wrench to tighten down the nut.


- 5 Slide the card cage all the way into the module.
- 6 Check the position of the EMI shield. If the EMI shield has shifted, reposition it. Remove the tape holding the EMI shield.
- 7 Secure the card cage and EMI shield to the module re-using the existing screws.
- 8 Preroute cables NT4N88AA, NT4N88BA and NT4N90BA.
  - a. Route cable NT4N88AA from COM1 on the CP PIV faceplate to J25 on the I/O panel. (NT4N88AA is used to connect a terminal.)
  - b. Route cable NT4N88BA from COM2 on the CP PIV faceplate to J21 on the I/O panel. (NT4N88BA is used to connect a modem.)
- 9 Route cable NT4N90BA from LAN 1 on the CP PIV faceplate to J31 (top) of the I/O panel.
- 10 Do not connect the NTRC17BA crossover ethernet cable at this time.

---

**End of Procedure**

---

Figure 21  
CP PIV call processor card (front)



**Procedure 16**  
**Relocating Network cards to CP PIV Core/Net 0**

- 1 Move any existing cards from slots 0-11 of the old Core/Net 0 card cage to the same slots (0-11) in the new NT4N40 Core/Net 0 card cage.
- 2 Connect the tagged cables to the relocated cards.
- 3 When you move the 3PE card, check the switch settings and jumpers. See Table 11 on [page 78](#).
  - a. All 3PE cards must be vintage F or later.
  - b. Check that the RN27 Jumper is set to "A".
- 4 The settings for 3PE cards in Core/Net shelves are different from those in all other shelves. Table 11 on [page 78](#) shows the 3PE settings for cards installed in CP Core/Net Modules.

————— **End of Procedure** —————

**Table 11**  
**QPC441 (QPC440) 3PE Card installed in the CP PIV Core/Net modules**

<b>Jumper Settings:</b> Set Jumper RN27 at E35 to "A".									
Switch Settings									
Module		D20 switch position							
CP PIV Core/Net modules only		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off

**Procedure 17**  
**Moving Clock Controller 1**

- 1 Remove Clock Controller 1 from the Core module.
- 2 Set the Clock Controller 1 switch settings according to Table 12 on [page 79](#) and Table 13 on [page 80](#).
- 3 Move Clock Controller 1 to the CP PIV Core/Net 1, slot 9. DO NOT seat Clock Controller 1 and DO NOT enable the card.
- 4 Reconnect all primary and secondary reference cables.

- 5 Do NOT connect the clock to clock cable.



**CAUTION — Service Interruption**

**Service Interruption**

At this point in the upgrade, only move Clock Controller 1; do not move Clock Controller 0.

**Table 12**  
**Clock Controller switch settings for NTRB53**

Multi-group Single group	Machine Type #1	Faceplate Cable Length CC to CC			Side Number	Machine Type #2
		3	4			
1	2	3	4		5	6
Multi-group = Off  Single group = On	21E = Off  51, 61, 51C, 61C 71, 81, 81C = On	Off	Off	0-14 Ft.	Side 0 = On  Side 1 = Off	71,81 = Off  21E, 51, 51C, 61. 61C, 81C = On
		Off	On	4.6–6.1 m (15–20 ft.)		
		On	Off	6.4–10.1 m (21–33 ft.)		
		On	On	10.4–15.2 m (34–50 ft.)		
<b>Note:</b> Switch 7 and 8 are not used.						

**Table 13**  
**Clock Controller switch settings for QPC471H, QPC771H**

Systems upgraded to CP PIV must use the Meridian 1 Option 61C CP PIV switch settings to enable Clock Hunt software. Use the settings in this table.											
SW1				SW2				SW4			
1	2	3	4	1	2	3	4	1	2	3	4
on	on	on	on	off	off	off	off	**	on	*	*
*Total cable length between the J3 faceplate connectors:											
0–4.3 m (0–14 ft.)											
										off	off
4.6–6.1 m (15–20 ft.)											
										off	on
6.4–10.1 m (21–33 ft.)											
										on	off
10.4–15.2 m (34–50 ft.)											
										on	on
** Set to ON for Clock Controller 0. Set to OFF for Clock Controller 1.											

————— End of Procedure —————

## Installing the Security Device

### Procedure 18 Installing the Security Device

The Security Device fits into the System Utility card (see Figure 22 on [page 82](#)).

If the original system had an IODU/C, remove the Security Device from the IODU/C for reuse.

- 1 Unlock the latches and remove the IODU/C card.
- 2 Remove the round 1/2" diameter IODU/C Security Device from the round black Security Device holder on the top right corner of the IODU/C card.
- 3 Insert the Security Device into the Security Device holder on the System Utility card with the "Norte!" side facing up. Check that the Security Device is securely in place.

If the original system did not have an IODU/C, use the Security Device provided with the CP PIV Software kit.


- 1** Insert the Security Device into the Security Device holder on the System Utility card with the “Nortel” side facing up. Do not bend the clip more than necessary.
- 2** Check that the Security Device is securely in place.

---

**End of Procedure**

---

**Figure 22**  
**Security Device**



## Unpack and install Power Supply

### Procedure 19

#### Installing the NT6D41CA (DC) or NT8D29BA (AC) power supply

- 1 Unpack the power supply.
- 2 Faceplate-disable the power supply.
- 3 Insert power supply into Core/Net module power supply slot.

---

End of Procedure

---

## Cable Core 1

### In Core 1, inspect the CNI to 3PE (NT4N29) and system monitor (NT4N89) cables


New NT4N29 cables must be installed for existing Network group 0. If the system has XSDI cards, reinstall the cards and attach the cables. Inspect the NT4N89 system monitor cables. See Figure 23 on [page 84](#) and Table 14.

**Table 14**  
Fanout Panel to 3PE card connectors

Group Number		Fanout Panel connector		3PE card connector
0	connects	9-0, J3		A
0	from	9-0, J4	to	B

**Note:** Group 0 cables (NT4N29) connect the fanout panel directly to the network backplane of Core/Net 1.

**Figure 23**  
**Fanout Panel connections on the CP Core/Net backplane**



## Power up Core 1

### Procedure 20 Preparing for power up

- 1 Check that a terminal is connected to the J25 I/O panel connector (COM 1) on Core/Net 1.

**Note:** A maintenance terminal is required to access the Core/Net modules during the upgrade.

- 2 Connect a terminal to the J25 port on the I/O panel in Core 1.
- 3 Check the terminal settings as follows:

- a. 9600 baud
  - b. 8 data
  - c. parity none
  - d. 1 stop bit
  - e. full duplex
  - f. XOFF
- 4 Faceplate-enable all 3PE, Per Sig, clock controller, core and network cards.

*Note:* If only one terminal is used for both cores, the terminal must be switched from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

---

**End of Procedure**

---

## **Power up Core cards**

### **Procedure 21**

#### **Powering up core cards**

- 1 For AC-powered systems (NT8D29BA): set the MPDU circuit breaker located at the left end of the module to ON (top position).
- 2 For DC-powered systems: faceplate-enable the NT6D41CA power supply and then set the breaker for the Core 1 module in the back of the column pedestal to ON (top position).

---

**End of Procedure**

---

## **Restore power**

### **Procedure 22**

#### **Restoring power**

- 1 Restore power to Core/Net 1.
- 2 Wait for the system to load/initialize.

- 3 Check that the Network and I/O cards have working power.



System is in split mode, CP 0 is active, clock 0 is active, all network cards in shelf 1 are software disabled.

---

**End of Procedure**

---

## CS 1000 Release 6.0 upgrade

### Upgrading the software

Procedure 23 outlines the steps involved in installing CS 1000 Release 6.0 for the CP PIV processor.

#### **Procedure 23** **Upgrading the software**

- 1 Check that a terminal is now connected to COM 1port in CP 1. The settings for the terminal are:
  - a. Terminal type: VT100
  - b. 9600 Baud
  - c. Data bits: 8
  - d. Parity: none
  - e. Stop bits: 1
  - f. Flow control: none
- 2 Insert the RMD into the CF card slot on Call Processor 1 (inactive).
- 3 Perform a KDIF in LD 143.
- 4 Press the manual RESET button the Call Processor 1 (inactive) card faceplate.

- 5 Call up the Software Installation Program during a SYSLOAD. During SYSLOAD, the following prompt appears:

```
Read boot parameters from:
```

```
F: Faceplate compact flash
```

```
H: Hard Drive
```

```
0 [H]
```

Press F to boot from the compact flash (which contains the software).

For the CP PIV upgrade, the **F** must be in uppercase.

- 6 Enter <CR> at the Install Tool Menu.

**Note:** Blank CF prompts begin here.

```
Mounting /cf2
Found /cf2/nvram.sys
Mounting /boot|
Found /boot/nvram.sys

                               Selecting nvram file from 2
sources

Read boot parameters from:
F: Faceplate compact flash
H: Hard Drive

10 [F]

Press <CR> when ready

Reading boot parameters from /boot/nvram.sys
Press any key to stop auto-boot...
```



```

                M A I N   M E N U

The Software Installation Tool will install or
upgrade Communication Server 1000 Software,
Database and the CP-BOOTROM. You will be
prompted throughout the installation and given
the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu
          <t> - To Tools menu.
          <q> - Quit.

Enter Choice> <u>
```

The system searches for available keycode files in the “keycode” directory on the RMD. If no keycode file is found, the system displays the following menu:

```

Communication Server 1000 Software/Database/
BOOTROM RMD Install Tool
=====
=====

No keycode files are available on the removable
media.

Please replace the RMD containing the keycode
file(s).

Please enter:

          <CR> -> <a> - RMD is now in the drive.
          <q> - Quit.

Enter choice>
```

At this point, either replace the RMD or quit the installation. If you select option "<q> - Quit.", the system requires confirmation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

Communication Server 1000 Software/Database/ BOOTROM RMD Install Tool  =====
---

```
You selected to quit. Please confirm.  
  
Please enter:  
  
    <CR> -> <y> - Yes, quit.  
  
    <n> - No, DON'T quit.  
  
Enter choice>
```

If “y” (quit) is selected, the system prints “INST0127 Keycode file is corrupted. Check Keycode file.” and returns to the installation main menu.

After accessing the RMD containing the valid keycode(s), press <CR>. The system displays the keycode file(s) available as in the following example:

```
The following keycode files are available on the  
removable media:  
  
Name                               Size   Date       Time  
-----
```

The following keycode files are available on the removable media:  Name                               Size   Date       Time -----
--

```
<CR> -> <1> -keycode.kcd 1114 mon-d-year hr:min  
<2> - KCport60430m.kcd  1114 mon-d-year hr:min  
<q> - Quit  
  
Enter choice> 2
```

**Note:** A maximum of 20 keycode files can be stored under the “keycode” directory on the RMD. The keycode files must have the same extension “.kcd”.

- 8 Select the keycode to be used on the system. The system validates the selected keycode and displays the software release and machine type authorized.

```
Validating keycode ...  
Copying "/cf2/keycode/KCport60430m.kcd" to "/u/  
keycode" -  
Copy OK: 1114 bytes copied  
The provided keycode authorizes the install of  
xxxx software (all subissues) for machine type  
xxxx (CP PIV processor on <system>).
```

**Note:** The software release displayed depends on the keycode file content. The system requests keycode validation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
=====
```

Please confirm that this keycode matches the  
System S/W on the RMD.

Please enter:

                  <CR> -> <y> - Yes, the keycode matches.  
Go on to Install Menu.

                  <n> - No, the keycode does not match.  
Try another keycode.

Enter choice>

- 9 If the keycode matches, enter <CR> to continue the installation. The system displays the Install Menu. Select option "<a>".

**Note:** Option A uses the existing db from the FMD. External database backup is Option B.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
=====
```

I N S T A L L M E N U

The Software Installation Tool will install or upgrade Communication Server 1000 Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.  
<b> - To install Software, Database, CP-BOOTROM.  
<c> - To install Database only.  
<d> - To install CP-BOOTROM only.  
<t> - To go to the Tools menu.  
<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.  
<q> - Quit.

Enter Choice> <a>

- 10 The system requires the insertion of the RMD containing the software to be installed.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

Please insert the Removable Media Device into the drive on Core x.

Please enter:

          <CR> -> <a> - RMD is now in drive.  
Continue with s/w checking.

          <q> - Quit.

Enter choice> **<CR>**

- 11 If the RMD containing the software is already in the drive, select option "<a> - RMD is now in drive. Continue with s/w checking." (or simply press <CR>) to continue. If the RMD is not yet in the drive, insert it and then press <CR>.
- 12 The system displays the release of the software found on RMD under the "swload" directory and requests confirmation to continue the installation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

The RMD contains System S/W version xxxx.

Please enter:

<CR> -> <y> - Yes, this is the correct  
version. Continue.

<n> - No, this is not the correct version.  
Try another RMD or a different keycode.

Enter choice> <CR>

**Note:** If the RMD contains the correct software release, select option "<y> - Yes, this is the correct version. Continue." (or simply press <CR>) to continue. If the software release is not correct and you want to replace the RMD, insert the correct RMD in the drive and then press <CR>. If you want to replace the keycode, select option "<n> - No, this is not the correct version".

**13** Choosing Yes for the Dependency Lists installation.

**Note:** If Dependency Lists are not installed on media, the following prompts do not appear. Proceed to step 14 on [page 96](#).

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists installation

<n> - No, Continue without Dependency Lists installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

<y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the user to deplist menu.

Enable Automatic Centralized Software Upgrade (CSU) Feature?

Please enter:

<CR> -> <y> - Yes

<n> - No

Enter choice>

**14** Select to enable/disable CSU option.

**Note:** if Sequential is selected <1>, upgrades to the MG 1000Es are performed across the LAN in a sequential manner. One MG 1000E is upgraded at a time. No other MG 1000E upgrades are initiated until the current MG 1000E completes its installation.

If Simultaneous is selected <2>, upgrades to the MG 1000Es are performed simultaneously across the LAN. Up to eight MG 1000Es are upgraded at the same time. If there are more than eight MG 1000Es, the upgrade to the next MG 1000E begins after the upgrade of one MG 1000E is complete. The following warning is presented to the installer:

```
WARNING:
Call Processing is not guaranteed to operate on the call server
during simultaneous upgrades.
Do you wish to proceed? (y/n)
```

```
Set Automatic Centralized Software Upgrade Mode to:

Please enter:
<CR> -> <1> - Sequential
        <2> - Simultaneous
Enter choice>
>Processing the install control file ...
>Installing release 0600x
```

- 15 The PSDL files menu appears. Enter the appropriate choice for the site's geographic location.

```
*****
PSDL INSTALLATION MENU

The PSDL contains the loadware for all
downloadable cards in the system and loadware for
M3900 series sets.

*****
Select ONE of the SEVEN PSDL files:

1. Global 10 Languages
2. Western Europe 10 Languages
3. Eastern Europe 10 Languages
4. North America 6 Languages
5. Spare Group A
6. Spare Group B
7. Packaged Languages
[Q]uit, <CR> - default

By default option 1 will be selected.
Enter your choice ->x

>Copying new PSDL ...
```

- 16 The installation summary screen appears. Verify the parameters and enter <CR> when ready.

- 17 Enter <CR> to confirm and continue upgrade.

**Note:** After entering yes below, the system copies the software from RMD to FMD (the files copied are listed). This file copy takes between 5 and 10 minutes to complete.

```
Please enter:
<CR> -> <y> - Yes, start upgrade.
           <n> - No, stop upgrade. Return to the Main
Menu.

           Enter choice>

>Checking system configuration

You selected to upgrade Software release: XXXX to
release: xxxx. This will erase all old system
files.

This will create all necessary directories and
pre-allocate files on the hard disk.

You may continue with software upgrade or quit
now and leave your software unchanged.

Please enter:

           <CR> -> <a> - Continue with upgrade.
           <q> - Quit.

           Enter choice>
```

- 18** Successful installation confirmation appears, enter <CR> to continue.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

Software release xxxx was installed successfully  
on Core x.

All files were copied from RMD to FMD.

Please press <CR> when ready ...

- 19** Press "Enter" after checking the Installation summary.

**20** Upon returning to the main install menu, enter **q** to quit.

```
                I N S T A L L   M E N U

The Software Installation Tool will
install or upgrade Succession Enterprise System
Software, Database and the CP-BOOTROM. You will be
prompted throughout the installation and given the
opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.

        <b> - To install Software, Database,
CP-BOOTROM.

        <c> - To install Database only.

        <d> - To install CP-BOOTROM only.

        <t> - To go to the Tools menu.

        <k> - To install Keycode only.

                For Feature Expansion, use OVL143.

        <p> - To install 3900 set Languages.

        <q> - Quit.

Enter Choice> q
```

- 21 The system then prompts you to confirm and reboot. Enter <CR> to quit. Enter <CR> again to reboot.

```
You selected to quit. Please confirm.

Please enter:

<CR> -> <y> - Yes, quit.

        <n> - No, DON'T quit.

Enter choice> <CR>

You selected to quit the Install Tool.

You may reboot the system or return to the Main
Menu.

-----

DO NOT REBOOT USING RESET BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

        <m> - Return to the Main menu.

Enter Choice> <CR>

>Removing temporary file "/u/disk3521.sys"
>Removing temporary file "/u/disk3621.sys"
>Rebooting system ...
```

At this point the system reloads and initializes.

————— **End of Procedure** —————

## Verifying the upgraded database

### Procedure 24

#### Verifying the upgraded database

- 1 Print ISSP (system software issue and patches)

**LD 22**                    Load program

**REQ**                     ISSP

**\*\*\*\***                    Exit program

- 2 Print the system configuration record in LD 22 and compare the output with the preupgraded configuration record.

**LD 22**                    Load program

**REQ**                     PRT

**TYPE**                   CFN

**\*\*\*\***                    Exit program

- 3 Print the SLT in LD 22. This output provides used and unused ISM parameters. Compare with preupgrade SLT output.

**LD 22**                    Load program

**REQ**                     SLT

**\*\*\*\***                    Exit program

- 4 Print the customer data block(s) in LD 21.

<b>LD 21</b>	Load program
<b>REQ</b>	PRT
<b>TYPE</b>	CDB
<b>CUST</b>	xx
<b>****</b>	Exit program



Core 1 is now active, clock 1 is active, CNI is disabled in Core 0.

---

**End of Procedure**

---

## Configuring IP addresses

### Procedure 25 Configuring the IP addresses

Two unique IP address are required for the CP PIV system to communicate with the LAN. One IP address is defined for the *active* Core. The second IP address is defined for the *inactive* Core.

- 1 Use the following to check the status of the system's IP address:

<b>LD 117</b>	Load program
<b>prt host</b>	Print the configured host information

If the system returns with host names "active" and "inactive", go to "Check for Peripheral Software Download to Core 1" on [page 104](#). If the system returns no host names, complete the steps below.

- 2 Contact your System Administrator to identify IP address and subnet mask information.

3 Configure the primary (*active*) and secondary (*inactive*) IP addresses:

<b>LD 117</b>	Load the program
<b>new host name 1 IP address</b>	Define the first IP address: “name 1” is an alias for the IP address such as “primary”. The IP address is the IP number.
<b>chg elnk active name 1</b>	Assign the “name 1” address to the <i>active</i> Core.
<b>new host ‘name 2’ ‘IP address’</b>	Define the second IP address: “name 2” is an alias for the IP address such as “secondary”. The IP address is the IP number.
<b>chg elnk inactive name 2</b>	Assign the “name 2” address to the <i>inactive</i> Core.
<b>chg mask xxx.xxx.xxx.xxx</b>	Set the sub-net per local site. This number allows external sub-nets to connect to the system.

4 Enable the new Ethernet interface.

<b>LD 137</b>	Load program
<b>update dbs</b>	Update the ELINK database
<b>dis elnk</b>	<i>Disable</i> the old IP interface values
<b>enl elnk</b>	<i>Enable</i> the new IP interface values

---

End of Procedure

---

## Check for Peripheral Software Download to Core 1

Enter LD 22 and print Target peripheral software version. The Source peripheral software version was printed in “Printing site data” on [page 35](#). If

there is a difference between the Source and Target peripheral software version:

- A forced download occurs during initialization when coming out of parallel reload.
- System initialization takes longer.
- The system drops established calls on IPE.

Access LD 22 and print Target peripheral software version.

<b>LD 22</b>	Load program
<b>REQ</b>	PRT
<b>TYPE</b>	PSWV
<b>ISSP</b>	Print System, DepList, and Patch information
<b>SLT</b>	Print System Limits
<b>TID</b>	Print the Tape ID
<b>****</b>	Exit program

## Reconfigure I/O ports and call registers

### Procedure 26

#### Reconfiguring I/O ports and call registers

- 1 Evaluate the number of call registers and 500 telephone buffers that are configured for the system (suggested minimum values are 20,000 and 1000 respectively). If changes are required, reconfigure the values in LD 17:

**LD 17**            Load program

**CHG**

**CFN**

**PARM YES**

**500B 1000**        Use 1000 as a minimum value

**NCR 20000**        Use 20000 as a minimum value

**\*\*\*\***             Exit program

- 2 Print the Configuration Record to confirm the changes made above:

**LD 22**            Load program

**REQ PRT**         Set the print Option

**TYPE CFN**        Print the configuration

**\*\*\*\***             Exit program

---

**End of Procedure**

---

---

## Reboot Core/Net 1

### Procedure 27 Rebooting Core 1

**CAUTION — Service Interruption****Service Interruption**

The INI may take up to 15 minutes to complete.

**CAUTION — Service Interruption****Service Interruption**

Call processing is interrupted for approximately 60 minutes while the procedures are completed.

At this stage, Core 0 is still the active call processor with Clock Controller 0 active. The following procedure will transfer call processing from Core 0 to Core 1, switching Clock Controller from 0 to 1.

- 1 In Core/Net 0 only, faceplate-disable the CNI cards.
- 2 In Core/Net 0 only, faceplate-disable the IODU/C card.
- 3 In Core/Net 0 only, unseat the Core Processor card.
- 4 Faceplate-disable Clock Controller 0 and unseat the card.
- 5 Press the 'INIT' button on the CP PIV card faceplate in Core/Net 1 to initialize the system.

- 6 Wait for “DONE” and then “INI” messages to display before you continue.



**CAUTION — Service Interruption**

**Service Interruption**

Allow the system to recover from all downloads after the INI completes.



Call processing should be active on Core/Net 1, Clock 1 ia active, Clock 0 is disabled, and Network cards in Core/Net 0 are disabled.

---

**End of Procedure**

---

## Installing Core 0 hardware

**Procedure 28**

**Faceplate disabling cards in core and network slots of Core/Net 0:**

- 1 Faceplate-disable all core and network cards in Core/Net 0.
- 2 Set the ENB/DIS switch on the 3PE card to DIS.

---

**End of Procedure**

---

## Power down Core/Net 0



### CAUTION — Service Interruption

#### Service Interruption

Call processing is interrupted for approximately 60 minutes while the procedures are completed.



### DANGER OF ELECTRIC SHOCK

In a DC-powered system, power to the column can remain on during the following procedures. In an AC-powered system, however, power to the entire column *must* be shut down throughout the procedures.

For AC-powered systems: set the MPDU circuit breaker located at the left end of the module to OFF (down position).

For DC-powered systems: set the breaker for the Core 0 module in the back of the column pedestal to OFF (down position).

### Procedure 29

#### Removing Core 0 cables and card cage

- 1 Label and disconnect the Clock Controller 0.
  - a. Disconnect the NT8D76AC cable from the Clock Controller 0 faceplate card.
  - b. If primary and secondary clock reference cables are connected to the Clock Controller 0 faceplate, disconnect them last.
- 2 Label and disconnect all cables from the front of the module.
- 3 Tape over the contacts to avoid grounding.
- 4 Tie all cables to the sides so the working area in front of the card cage is totally clear.
- 5 Remove the I/O safety panel by turning the screws on each side. Set the I/O safety panel aside.
- 6 Tag and disconnect all cables from the backplane to the interior of the I/O assembly.

- 7 Tag and disconnect all plugs, wires, and cables to the backplane.

**Note 1:** Leave the network cards in the card cage. You will relocate them to the CP card cage later in the upgrade procedure.

**Note 2:** Two people are needed to remove the Core card cage because of the weight of the card cage with the cards left installed.

- 8 Use a 1/4" nut driver to remove the two mounting screws at the bottom rear of the card cage. The screws secure the card cage to the module casting. Keep the screws for use with the CP card cage.




**CAUTION — Service Interruption**

Do not drop the mounting screws into the pedestal. Doing so can cause serious damage.


- 9 Remove the front trim panels on both sides of the card cage.
- 10 Remove the three mounting screws that secure the front of the card cage to the bottom of the module. Keep the screws for use with the CP card cage.
- 11 Pull the card cage forward until it is halfway out of the module.
- 12 Disconnect cables, plugs, and wires from the rear of the module to the backplane.
- 13 Remove the logic return (LTRN) (orange) wire from the backplane bolt. Be careful; do not drop the nut or lock washer into the pedestal. See Figure 18 for DC power connectors. See Figure 19 on [page 72](#) for AC power connectors.
- 14 Remove the frame ground (FGND) (green) wire from the frame ground bolt on the module.
- 15 Label and disconnect the module power connectors. In an AC-powered system, these are small orange connectors plugged into the module power distribution unit (MPDU). In a DC-powered system, these are connected to each other.
- 16 Label and disconnect the system monitor ribbon cables to J1 and J2.
- 17 Remove the Core card cage from the module.

**Figure 24**  
**DC power connectors on the Core module backplane**



- 18** Remove the power harness and reserve it for reinstallation when you install the NT4N40 card cage. The power harness is located at the right rear lower corner and plugs into the rear of the power supply. For AC systems, relocate power harness NT8D40. For DC systems, relocate power harness NT7D11.

**Figure 25**  
**AC power connectors on the Core module backplane**



- 19** Reposition the EMI shield (it looks like a brass grill) in the base of the module. Tape over the front mounting tabs to hold the shield in position. You will remove the tape later.



**WARNING**

If you do not tape the EMI shield in position, you will not be able to install the card cage in the module correctly.



**CAUTION — Service Interruption**

**Damage to Equipment**

Check for and remove any debris (such as screws) that fell into the base of the UEM module.

---

**End of Procedure**

---

**Procedure 30**  
**Installing the CP card cage in Core 0**

- 1 Check that the card cage is configured as Core 0. See Table 10 for instructions.

	<p><b>IMPORTANT!</b></p> <p>An NT4N41 Core/Net module with pedestal, top cap and necessary cables should already have been installed. If so, proceed to “Relocating Network cards to CP PIV Core/Net 0” on <a href="#">page 118</a>.</p>
---	--

**Table 15**  
**Core module ID switch settings (System Utility card)**

	Position 1	Position 2
Core/Net 0	On	On
Core/Net 1	Off	On

- 2 For AC-powered systems only, attach the new MPDU, part of the CP PIV Upgrade kit, to the side on the NT4N40 card cage. The screws that secure the MPDU are accessible from the power supply slot. See Figure 20 on [page 75](#).

**Note:** Prethread 2 bottom mounting screws at the back of the Core/Net shelf. Check that the power harness at the right rear corner of the card cage has been transferred from the old card cage to the CP card cage.


- 3 Slide the CP card cage halfway into the module.
- 4 Hold the card cage firmly and make the following connections at the rear of the module.
  - a. In AC-powered systems, connect the remaining module power connectors to J2 on the MPDU. Then plug the module power cable

(the short harness attached to the module power connector) into connector J3 on the MPDU (attached to the side of the card cage).

**CAUTION — Service Interruption****Damage to Equipment**

Check for and remove any debris (such as screws) that may have fallen into the base of the UEM module.

**Figure 26**  
**Location of the screws for the MPDU**



- b.** In DC-powered systems, connect the module power connectors to each other.
- c.** Attach the system monitor ribbon cables:
  - i.** Connect the ribbon cable that goes down to the column to connector J1 on the backplane.
  - ii.** Connect the ribbon cable that goes up the column to J2 on the backplane.

- d. Use a 11/32" socket wrench to attach the green ground wire to the frame ground bolt on the module. Remove the nut and the lock washer at the top of the bolt. Put the frame ground wire terminal over the bolt. Reinstall the top lock washer and the nut, then tighten down the nut.

**Note:** For all of the wire terminals to fit on the bolt, remove one of the lock washers. Leave the first lock washer at the bottom of the bolt and a second at the top of the bolt. Leave a third lock washer between the second and third, or the third and fourth, wire terminals.


- e. Attach the orange logic return wire. Remove one nut and the lock washer from the LRTN bolt at the rear of the card cage. Put the wire terminal over the bolt, reinstall the lock washer and nut. Use a 1/4" socket wrench to tighten down the nut.
- 5 Slide the card cage all the way into the module.
  - 6 Check the position of the EMI shield. If the EMI shield has shifted, reposition it. Remove the tape holding the EMI shield.
  - 7 Secure the card cage and EMI shield to the module re-using the existing screws.
  - 8 Preroute cables NT4N88AA, NT4N88BA and NT4N90BA.
    - a. Route cable NT4N88AA from COM1 on the CP PIV faceplate to J25 on the I/O panel. (NT4N88AA is used to connect a terminal.)
    - b. Route cable NT4N88BA from COM2 on the CP PIV faceplate to J21 on the I/O panel. (NT4N88BA is used to connect a modem.)
  - 9 Route cable NT4N90BA from LAN 1 on the CP PIV faceplate to J31 (top) of the I/O panel.
  - 10 Do not connect the NTRC17BA crossover ethernet cable at this time.

---

**End of Procedure**

---

Figure 27  
CP PIV call processor card (front)



**Procedure 31**  
**Relocating Network cards to CP PIV Core/Net 0**

- 1 Move any existing cards from slots 0-11 of the old Core/Net 0 card cage to the same slots (0-11) in the new NT4N40 Core/Net 0 card cage.
- 2 Connect the tagged cables to the relocated cards.
- 3 When you move the 3PE card, check the switch settings and jumpers. See Table 16 on [page 118](#).
  - a. All 3PE cards must be vintage F or later.
  - b. Check that the RN27 Jumper is set to "A".
- 4 The settings for 3PE cards in Core/Net shelves are different from those in all other shelves. Table 16 on [page 118](#) shows the 3PE settings for cards installed in CP Core/Net Modules.

————— End of Procedure —————

**Table 16**  
**QPC441 (QPC440) 3PE Card installed in the CP PIV Core/Net modules**

<b>Jumper Settings:</b> Set Jumper RN27 at E35 to "A".									
Switch Settings									
Module		D20 switch position							
CP PIV Core/Net modules only		1	2	3	4	5	6	7	8
Core/Net 0 (Shelf 0)	Group 0	off	on	on	off	on	on	on	on
Core/Net 1 (Shelf 1)	Group 0	off	on	on	off	on	on	on	off

**Procedure 32**  
**Moving Clock Controller 0**

- 1 Remove Clock Controller 0 from the Core module.
- 2 Set the Clock Controller 0 switch settings according to Table 12 on [page 79](#) and Table 13 on [page 80](#).
- 3 Move Clock Controller 0 to the CP PIV Core/Net 0, slot 9.

- 4 Reconnect all primary and secondary reference cables.

**Table 17**  
**Clock Controller switch settings for NTRB53**

Multi-group Single group	Machine Type #1	Faceplate Cable Length CC to CC			Side Number	Machine Type #2
		3	4			
1	2	3	4		5	6
Multi-group = Off  Single group = On	21E = Off  51, 61, 51C, 61C 71, 81, 81C = On	Off	Off	0-14 Ft.	Side 0 = On  Side 1 = Off	71,81 = Off  21E, 51, 51C, 61. 61C, 81C = On
		Off	On	4.6–6.1 m (15–20 ft.)		
		On	Off	6.4–10.1 m (21–33 ft.)		
		On	On	10.4–15.2 m (34–50 ft.)		
<b>Note:</b> Switch 7 and 8 are not used.						

**Table 18**  
**Clock Controller switch settings for QPC471H, QPC771H (Part 1 of 2)**

Systems upgraded to CP PIV must use the Meridian 1 Option 61C CP PIV switch settings to enable Clock Hunt software. Use the settings in this table.											
SW1				SW2				SW4			
1	2	3	4	1	2	3	4	1	2	3	4
on	on	on	on	off	off	off	off	**	on	*	*
*Total cable length between the J3 faceplate connectors: 0–4.3 m (0–14 ft.)										off	off
** Set to ON for Clock Controller 0. Set to OFF for Clock Controller 1.											

**Table 18**  
**Clock Controller switch settings for QPC471H, QPC771H (Part 2 of 2)**

Systems upgraded to CP PIV must use the Meridian 1 Option 61C CP PIV switch settings to enable Clock Hunt software. Use the settings in this table.												
SW1				SW2				SW4				
1	2	3	4	1	2	3	4	1	2	3	4	
4.6–6.1 m (15–20 ft.)									off	on		
6.4–10.1 m (21–33 ft.)									on		off	
10.4–15.2 m (34–50 ft.)									on		on	
** Set to ON for Clock Controller 0. Set to OFF for Clock Controller 1.												

————— End of Procedure —————

## Install the Security Device

### Procedure 33 Installing the Security Device

The Security Device fits into the System Utility card (see Figure 28 on [page 121](#)).

To install the Security Device:

- 1 If the original system had an IODU/C, remove the Security Device from the IODU/C for reuse.
  - a. Unlock the latches and remove the IODU/C card.
  - b. Remove the round 1/2" diameter IODU/C Security Device from the round black Security Device holder on the top right corner of the IODU/C card.

OR


If the original system did not have an IODU/C, use the Security Device provided with the CP PIV Software kit.

Insert the Security Device into the Security Device holder on the System Utility card with the “Nortel” side facing up. Do not bend the clip more than necessary.

- 2 Check that the Security Device is securely in place.

**End of Procedure**

**Figure 28**  
**Security Device**



## Cable Core 0

### Inspect the NT4N29 cables

The NT4N29 cables must be installed for existing Network group 0. If the system has XSDI cards, reinstall the cards and attach the cables. See Figure 29 on [page 123](#).

### Install intermodule cables

#### Procedure 34

#### Installing intermodule cables


- 1 Locate and unpack the NT8D99AD and NT8D80BZ cables.
- 2 Install NT8D99AD cables between the D connectors on the backplane of each Core/Net module. Install another NT8D99AD cable between the E connectors on the backplane of each Core/Net module (see Figure 29 on [page 123](#)).
- 3 Install an NT8D80BZ cable between the J3 connector on the 3PE card in Core/Net 0 and the J3 connector on the 3PE card in Core/Net 1. Install another cable between the J4 connectors on the 3PE cards (see Figure 30 on [page 124](#)).

---

**End of Procedure**

---

**Figure 29**  
**Fanout Panel connections on the CP Core/Net backplane**





**Procedure 36****If the system is connected to a LAN**

- 1 Connect the Dual Ethernet Adapter (RJ-45) for I/O Panel (NTRE40AA) to J31. Secure the adapter to J31 with the two screws included in the shipment. Insert the adapter from the inside of the I/O panel.
- 2 Connect LAN 1 (Ethernet) on the CP PIV faceplate to J31 (top) of the I/O panel with cable NT4N90BA. This connection can only be made *after* the Dual Ethernet Adapter is installed (see step 1 above).
- 3 Connect J31 to a LAN switch.

**Note:** If a LAN switch is not available, connect J31 of Core 0 to J31 of Core 1 by NTRC17BA cable.

---

**End of Procedure**


---

**Connect LAN 2**

Connect the NTR17BA Ethernet crossover cable from LAN 2 on the CP PIV card in Core 0 to the LAN 2 connection of the CP PIV card on Core 1.

This NTR17BA cable runs between the faceplates of the CP PIV cards and is run through the front cable tray.

**Figure 31**  
**Options for LAN 1 connection**



## Power up Core 0

### Procedure 37 Preparing for power up

- 1 Confirm that a terminal is connected to the J25 I/O panel connector on Core/Net 0.

**Note:** A maintenance terminal is required to access the Core/Net modules during the upgrade.

- 2 Connect a terminal to the J25 port on the I/O panel in Core 0.

3 Check the terminal settings as follows:

- a. 9600 baud
- b. 8 data
- c. parity none
- d. 1 stop bit
- e. full duplex
- f. XOFF

**Note:** If only one terminal is used for both Cores, the terminal will have to be switched from side-to-side to access each module. An “A/B” switch box can also be installed to switch the terminal from side to side.

4 Faceplate-enable all core and network cards.

---

**End of Procedure**

---

## **Power up Core cards**

### **Procedure 38**

#### **Powering up core cards**

- 1 Disconnect NTRC17BA crossover ethernet cable from the faceplate of CPU 0.
- 2 For AC-powered systems (NT8D29BA): set the MPDU circuit breaker located at the left end of the module to ON (top position).
- 3 For DC-powered systems: faceplate-enable the NT6D41CA power supply and then set the breaker for the Core 0 module in the back of the column pedestal to ON (top position).
- 4 10 seconds after power up of Core/Net 0, press the INI button on Core/Net 1.

- 5 Wait for the system to load and initialize.



Core/Net 1 is now active. All network cards in Core/Net 0 and Core/Net 1 are enabled. Call processing is resumed.

---

**End of Procedure**

---



At this point, all applications can be re-started (CallPilot, Symposium, and so on). LAN 1 and LAN 2 cables are now connected.

## Test Core/Net 1

### Procedure 39 Testing Core/Net 1

- 1 Check dial-tone.
- 2 Test the clocks:
  - a. Verify that the clock controller is assigned to the *active* Core.

**LD 60** Load program

**SSCK x** Obtain the status of the clock controllers (*x* is “0” or “1” for Clock 0 or Clock 1)

**SWCK** To switch the Clock (if necessary)

**\*\*\*\*** Exit program

- b. Verify that the clock controllers are switching correctly.

**SWCK** Switch the Clock

**Note:** You must wait a minimum of one minute for clocks to synchronize.

**SWCK** Switch the Clock again

\*\*\*\* Exit program

**3** Stat D-channels:

**LD 96**

**STAT DCH** Stat all D-channels

\*\*\*\* Exit program

**4** Stat all T1 interfaces:

**LD 60**

**STAT** Stat all DTI and PRI

\*\*\*\* Exit program

**5** Stat network cards:

**LD 32**

**STAT x** x = loop number

\*\*\*\* Exit program

**6** Print status of all controllers:

**LD 97**

**REQ** PRT

**TYPE** XPE (returns status of all controller cards)

\*\*\*\* Exit program

**7** Make internal, external and network calls.

**8** Check attendant console activity.

**9** Check DID trunks.

- 10 Check applications.

————— End of Procedure —————

## CS 1000 Release 6.0 upgrade

### Upgrading the software

Procedure 40 outlines the steps involved in installing CS 1000 Release 6.0 for the CP PIV processor.

#### Procedure 40 Upgrading the software

- 1 Check that a terminal is now connected to COM 1port in CP 1. The settings for the terminal are:
  - a. Terminal type: VT100
  - b. 9600 Baud
  - c. Data bits: 8
  - d. Parity: none
  - e. Stop bits: 1
  - f. Flow control: none
- 2 Insert the RMD into the CF card slot on Call Processor 1 (inactive).
- 3 Perform a KDIF in LD 143.
- 4 Press the manual RESET button the Call Processor 1 (inactive) card faceplate.

- 5 Call up the Software Installation Program during a SYSLOAD. During SYSLOAD, the following prompt appears:

```
Read boot parameters from:
F: Faceplate compact flash
H: Hard Drive
0 [H]
```

Press F to boot from the compact flash (which contains the software).

For the CP PIV upgrade, the **F** must be in uppercase.

- 6 Enter <CR> at the Install Tool Menu.

**Note:** Blank CF prompts begin here.

```
Mounting /cf2
Found /cf2/nvram.sys
Mounting /boot|
Found /boot/nvram.sys

                               Selecting nvram file from 2
sources

Read boot parameters from:
F: Faceplate compact flash
H: Hard Drive

10 [F]

Press <CR> when ready

Reading boot parameters from /boot/nvram.sys
Press any key to stop auto-boot...
```



```

                M A I N   M E N U

The Software Installation Tool will install or
upgrade Communication Server 1000 Software,
Database and the CP-BOOTROM. You will be
prompted throughout the installation and given
the opportunity to quit at any time.

Please enter:

<CR> -> <u> - To Install menu
          <t> - To Tools menu.
          <q> - Quit.

Enter Choice> <u>
```

The system searches for available keycode files in the “keycode” directory on the RMD. If no keycode file is found, the system displays the following menu:

```

Communication Server 1000 Software/Database/
BOOTROM RMD Install Tool
=====
=====

No keycode files are available on the removable
media.

Please replace the RMD containing the keycode
file(s).

Please enter:

          <CR> -> <a> - RMD is now in the drive.
          <q> - Quit.

Enter choice>
```

At this point, either replace the RMD or quit the installation. If you select option "<q> - Quit.", the system requires confirmation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

<pre>You selected to quit. Please confirm.  Please enter:      &lt;CR&gt; -&gt; &lt;y&gt; - Yes, quit.      &lt;n&gt; - No, DON'T quit.  Enter choice&gt;</pre>
---

If “y” (quit) is selected, the system prints “INST0127 Keycode file is corrupted. Check Keycode file.” and returns to the installation main menu.

After accessing the RMD containing the valid keycode(s), press <CR>. The system displays the keycode file(s) available as in the following example:

```
The following keycode files are available on the  
removable media:  
  
Name                               Size  Date      Time  
-----
```

<pre>&lt;CR&gt; -&gt; &lt;1&gt; -keycode.kcd 1114 mon-d-year hr:min &lt;2&gt; - KCport60430m.kcd  1114 mon-d-year hr:min &lt;q&gt; - Quit  Enter choice&gt; 2</pre>
---

**Note:** A maximum of 20 keycode files can be stored under the “keycode” directory on the RMD. The keycode files must have the same extension “.kcd”.

- 8 Select the keycode to be used on the system. The system validates the selected keycode and displays the software release and machine type authorized.

```
Validating keycode ...  
Copying "/cf2/keycode/KCport60430m.kcd" to "/u/  
keycode" -  
Copy OK: 1114 bytes copied  
The provided keycode authorizes the install of  
xxxx software (all subissues) for machine type  
xxxx (CP PIV processor on <system>).
```

**Note:** The software release displayed depends on the keycode file content. The system requests keycode validation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
=====
```

Please confirm that this keycode matches the  
System S/W on the RMD.

Please enter:

                  <CR> -> <y> - Yes, the keycode matches.  
Go on to Install Menu.

                  <n> - No, the keycode does not match.  
Try another keycode.

Enter choice>

- 9 If the keycode matches, enter <CR> to continue the installation. The system displays the Install Menu. Select option "<a>".

**Note:** Option A uses the existing db from the FMD. External database backup is Option B.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
=====
```

I N S T A L L M E N U

The Software Installation Tool will install or upgrade Communication Server 1000 Software, Database and the CP-BOOTROM. You will be prompted throughout the installation and given the opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.  
<b> - To install Software, Database, CP-BOOTROM.  
<c> - To install Database only.  
<d> - To install CP-BOOTROM only.  
<t> - To go to the Tools menu.  
<k> - To install Keycode only.

For Feature Expansion, use OVL143.

<p> - To install 3900 set Languages.  
<q> - Quit.

Enter Choice> <a>

- 10** The system requires the insertion of the RMD containing the software to be installed.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====  
Please insert the Removable Media Device into the  
drive on Core x.  
  
Please enter:  
  
        <CR> -> <a> - RMD is now in drive.  
Continue with s/w checking.  
  
        <q> - Quit.  
  
Enter choice> <CR>
```

- 11 If the RMD containing the software is already in the drive, select option "<a> - RMD is now in drive. Continue with s/w checking." (or simply press <CR>) to continue. If the RMD is not yet in the drive, insert it and then press <CR>.
- 12 The system displays the release of the software found on RMD under the "swload" directory and requests confirmation to continue the installation.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

The RMD contains System S/W version xxxx.

Please enter:

<CR> -> <y> - Yes, this is the correct  
version. Continue.

<n> - No, this is not the correct version.  
Try another RMD or a different keycode.

Enter choice> <CR>

**Note:** If the RMD contains the correct software release, select option "<y> - Yes, this is the correct version. Continue." (or simply press <CR>) to continue. If the software release is not correct and you want to replace the RMD, insert the correct RMD in the drive and then press <CR>. If you want to replace the keycode, select option "<n> - No, this is not the correct version".

**13** Choosing Yes for the Dependency Lists installation.

**Note:** If Dependency Lists are not installed on media, the following prompts do not appear. Proceed to step 14 on [page 140](#).

Do you want to install Dependency Lists?

Please enter:

<CR> -> <y> - Yes, Do the Dependency Lists installation

<n> - No, Continue without Dependency Lists installation

Enter choice>

The default choice is YES as shown in the prompt.

If the choice is no, then the following prompt will appear for the confirmation:

Are you sure?

Please enter:

<CR> -> <n> - No, Go to the Dependency List menu

<y> - Yes, Go to the next menu

Enter choice>

The default choice is NO which will return the user to deplist menu.

Enable Automatic Centralized Software Upgrade (CSU) Feature?

Please enter:

<CR> -> <y> - Yes

<n> - No

Enter choice>

**14** Select to enable/disable CSU option.

**Note:** if Sequential is selected <1>, upgrades to the MG 1000Es are performed across the LAN in a sequential manner. One MG 1000E is upgraded at a time. No other MG 1000E upgrades are initiated until the current MG 1000E completes its installation.

If Simultaneous is selected <2>, upgrades to the MG 1000Es are performed simultaneously across the LAN. Up to eight MG 1000Es are upgraded at the same time. If there are more than eight MG 1000Es, the upgrade to the next MG 1000E begins after the upgrade of one MG 1000E is complete. The following warning is presented to the installer:

```
WARNING:
Call Processing is not guaranteed to operate on the call server
during simultaneous upgrades.
Do you wish to proceed? (y/n)
```

```
Set Automatic Centralized Software Upgrade Mode to:

Please enter:
<CR> -> <1> - Sequential
        <2> - Simultaneous
Enter choice>
>Processing the install control file ...
>Installing release 0600x
```

- 15 The PSDL files menu appears. Enter the appropriate choice for the site's geographic location.

```
*****
PSDL INSTALLATION MENU

The PSDL contains the loadware for all
downloadable cards in the system and loadware for
M3900 series sets.

*****
Select ONE of the SEVEN PSDL files:

1. Global 10 Languages
2. Western Europe 10 Languages
3. Eastern Europe 10 Languages
4. North America 6 Languages
5. Spare Group A
6. Spare Group B
7. Packaged Languages
[Q]uit, <CR> - default

By default option 1 will be selected.
Enter your choice ->x

>Copying new PSDL ...
```

- 16 The installation summary screen appears. Verify the parameters and enter <CR> when ready.

17 Enter <CR> to confirm and continue upgrade.

**Note:** After entering yes below, the system copies the software from RMD to FMD (the files copied are listed). This file copy takes between 5 and 10 minutes to complete.

```
Please enter:
<CR> -> <y> - Yes, start upgrade.
           <n> - No, stop upgrade. Return to the Main
Menu.

           Enter choice>

>Checking system configuration

You selected to upgrade Software release: XXXX to
release: xxxx. This will erase all old system
files.

This will create all necessary directories and
pre-allocate files on the hard disk.

You may continue with software upgrade or quit
now and leave your software unchanged.

Please enter:
           <CR> -> <a> - Continue with upgrade.
           <q> - Quit.
           Enter choice>
```

- 18** Successful installation confirmation appears, enter <CR> to continue.

```
Communication Server 1000 Software/Database/  
BOOTROM RMD Install Tool  
  
=====
```

Software release xxxx was installed successfully  
on Core x.

All files were copied from RMD to FMD.

Please press <CR> when ready ...

- 19** Press "Enter" after checking the Installation summary.

20 Upon returning to the main install menu, enter **q** to quit.

```
                I N S T A L L   M E N U

The Software Installation Tool will
install or upgrade Succession Enterprise System
Software, Database and the CP-BOOTROM. You will be
prompted throughout the installation and given the
opportunity to quit at any time.

Please enter:

<CR> -> <a> - To install Software, CP-BOOTROM.
        <b> - To install Software, Database,
CP-BOOTROM.
        <c> - To install Database only.
        <d> - To install CP-BOOTROM only.
        <t> - To go to the Tools menu.
        <k> - To install Keycode only.

                For Feature Expansion, use OVL143.
        <p> - To install 3900 set Languages.
        <q> - Quit.

Enter Choice> q
```

- 21 The system then prompts you to confirm and reboot. Enter <CR> to quit. Enter <CR> again to reboot.

```
You selected to quit. Please confirm.

Please enter:

<CR> -> <y> - Yes, quit.

        <n> - No, DON'T quit.

Enter choice> <CR>

You selected to quit the Install Tool.

You may reboot the system or return to the Main
Menu.

-----

DO NOT REBOOT USING RESET BUTTON!!!

-----

Please enter:

<CR> -> <a> - Reboot the system.

        <m> - Return to the Main menu.

Enter Choice> <CR>

>Removing temporary file "/u/disk3521.sys"
>Removing temporary file "/u/disk3621.sys"
>Rebooting system ...
```

At this point the system reloads and initializes.

————— **End of Procedure** —————

## Verifying the upgraded database

### Procedure 41

#### Verifying the upgraded database

- 1 Print ISSP (system software issue and patches)

**LD 22**                      Load program

**REQ**                        ISSP

**\*\*\*\***                        Exit program



Core 1 is now active, clock 1 is active CNI is disabled in Core 0. The system is in split mode.

————— **End of Procedure** —————

## Making the system redundant

At this point, Core/Net 0 is ready to be synchronized with Core/Net 1.

### Procedure 42

#### Making the system redundant

- 1 Hardware enable the CNIs on Core/Net 0.
- 2 From Core/Net 1, enter LD 135 and issue the JOIN command. The high speed pipe (HSP) status is now up. This begins the synchronization of the Cores.

**LD 135**                      Load program

**JOIN**                        Join the 2 CPUs together to become redundant

- 3 Once the synchronization of memories and drives is complete, STAT the CPU and verify that the CPUs are in a true redundant state.

**LD 135**

**STAT CPU**      Obtain status of CPU and memory

**\*\*\*\***            Exit the program

```
.stat cpu

cp 0 16 PASS -- STDBY

TRUE REDUNDANT
DISK STATE = REDUNDANT
HEALTH = 20
VERSION = Mar  3 2005, 16:26:40
  Side = 0, DRAM SIZE = 512 MBytes

cp 1 16 PASS -- ENBL

TRUE REDUNDANT
DISK STATE = REDUNDANT
HEALTH = 20
VERSION = Mar  3 2005, 16:26:40
  Side = 1, DRAM SIZE = 512 MBytes
```

- 4 Tier 1 and Tier 2 health of both Cores must be identical in order to successfully switch service from Core 1 to Core 0 CPUs.

**LD 135**

**STAT HEALTH** Obtain status of CPU and memory

\*\*\*\* Exit the program

```
.stat health
Local (Side 0, Active, Redundant):
Components without TIER 1 Health contribution:
=====
    disp 0 15 1:In Service
    sio2 0 15 1:In Service
        cp 0 16:In Service
            ipb 0:In Service
TIER 1 Health Count Breakdown:
=====
    sio8 0 16 1: 0002
    sio8 0 16 2: 0002
        sutl 0 15: 0002
            strn 0 15: 0002
    xsmp 0 15 1: 0002
    cmdu 0 16 1: 0008
        eth 0 16 0: 0002
Local TIER 1 Health Total: 20
```

```

TIER 2 Health Count Breakdown:
=====
ELAN 16 IP : 47.11.138.150 Health = 2
ELAN 17 IP : 47.11.138.153 Health = 2

Local AML over ELAN Total Health:4
Local Total IPL Health = 6

IPL connection history:3 3 3 3 3 3 3 3 3 3 3 3 3
3 3 3 3 3 3

Local TIER 2 Health Total:10

Remote (Side 1, Inactive, Redundant):
Components without TIER 1 Health contribution:
    disp 1 15 1:In Service
    sio2 1 15 1:In Service
        cp 1 16:In Service
            ipb 1:In Service

TIER 1 Health Count Breakdown:
    sio8 1 16 1: 0002
    sio8 1 16 2: 0002
    sutl 1 15: 0002
    strn 1 15: 0002
    xsmp 1 15 1: 0002
    cmdu 1 16 1: 0008
    eth 1 16 0: 0002

Remote TIER 1 Health Total: 20
    
```

```
TIER 2 Health Count Breakdown:
=====
ELAN 16 IP : 47.11.138.150 Health = 2
ELAN 17 IP : 47.11.138.153 Health = 2

Remote AML over ELAN Total Health:4
Remote Total IPL health = 6

Remote TIER 2 Health Total:10
```



The system is now operating in full redundant mode with Core/Net 1 active.

## Completing the CP PIV upgrade

### LD 137

The CMDU/MMDU commands are not applicable to CP PIV. Instead, the following commands are introduced in LD 137.

- STAT FMD  
display text: **Status of Fixed Media Device (FMD)**  
command parameter: none
- STAT RMD  
display text: **Status of Removable Media Device(RMD)**  
command parameter: none

---

## Testing the Cores

### Procedure 43 Testing Core/Net 1

At this point in the upgrade, Core/Net 0 is tested from active Core/Net 1. Upon successful completion of these tests, call processing is switched and the same tests are performed on Core/Net 1 from active Core/Net 0. As a final step, call processing is then switched again to Core/Net 1.

From Core/Net 1, perform these tests:

1 Perform a redundancy sanity test:

<b>LD 135</b>	Load program
<b>STAT CPU</b>	Obtain status of CPU and memory
<b>TEST CPU</b>	Test CPU

2 Check the LCD states:

a. Perform a visual check of the LCDs.

b. Test LCDs:

<b>LD 135</b>	Load program
<b>DSPL ALL</b>	

3 Test the System Utility cards and the cCNI cards:

<b>LD 135</b>	Load program
<b>STAT SUTL</b>	Obtain the status of the System Utility card
<b>TEST SUTL</b>	Test the System Utility card
<b>STAT CNI c s</b>	Obtain status of cCNI cards (core, slot)
<b>TEST CNI c s</b>	Test cCNI (core, slot)

- 4 Test system redundancy:
  - LD 137** Load program
  - TEST RDUN** Test redundancy
  - DATA RDUN** Test database integrity
  
- 5 Install the two system monitors. Test that the system monitors are working:
  - LD 37** Load program
  - ENL TTY x** Enable the XMS, where x= system XMS
  - STAT XSM** Check the system monitors
  - \*\*\*\*** Exit program
  
- 6 Clear the display and minor alarms on both Cores:
  - LD 135** Load program
  - CDSP** Clear displays on the cores
  - CMAJ** Clear major alarms
  - CMIN ALL** Clear minor alarms

**7** Test the clocks:

- a.**
- Verify that the clock controller is assigned to the
- active*
- Core:

<b>LD 60</b>	Load program
<b>SSCK <i>x</i></b>	Obtain status of the clock controllers ( <i>x</i> is “0” or “1” for Clock 0 or Clock 1)
<b>SWCK</b>	Switch the Clock (if necessary)
<b>****</b>	Exit program

**8** Verify that the Clock Controllers are switching correctly:**SWCK** Switch Clock

**Note:** You must wait a minimum of one minute for clocks to synchronize.

**SWCK** Switch Clock again**9** Check applications.**10** Check dial tone.

---

**End of Procedure**

---

## Switching call processing

### Procedure 44 Switching call processing

- 1 Enter LD 135 on Core/Net 1 and issue the SCPUR command. Call processing switches to Call Server 0 and service is interrupted.

**LD 135**

**SCPUR**            Switch CPUs

**\*\*\*\***            Exit program



Core/Net 0 is now the active call processor.

### Procedure 45 Testing Core/Net 0

From Core/Net 0, perform these tests:

- 1 Perform a redundancy sanity test:

**LD 135**            Load program

**STAT CPU**        Obtain status of CPU and memory

**TEST CPU**        Test CPU

- 2 Check the LCD states:

- a. Perform a visual check of the LCDs.

- b. Test LCDs:

**LD 135**            Load program

**TEST LCDs**      Test LCDs

**DSPL ALL**

- 
- 3** Test the System Utility cards and the cCNI cards:
- LD 135** Load program
  - STAT SUTL** Obtain the status of the System Utility card
  - TEST SUTL** Test the System Utility card
  - STAT CNI c s** Obtain status of cCNI cards (core, slot)
  - TEST CNI c s** Test cCNI (core, slot)
- 4** Test system redundancy:
- LD 137** Load program
  - TEST RDUN** Test redundancy
  - DATA RDUN** Test database integrity
  - STAT FMD** Status of Fixed Media Device (FMD)
  - STAT RMD** Status of Removable Media Device (RMD)
- 5** Install the two system monitors. Test that the system monitors are working:
- LD 37** Load program
  - ENL TTY x** Enable the XMS, where x= system XMS
  - STAT XSM** Check the system monitors
  - \*\*\*\*** Exit program
- 6** Clear the display and minor alarms on both Cores:
- LD 135** Load program
  - CDSP** Clear displays on the cores
  - CMAJ** Clear major alarms
  - CMIN ALL** Clear minor alarms

- 7 Test the clocks:
  - a. Verify that the clock controller is assigned to the *active* Core:  

<b>LD 60</b>	Load program
<b>SSCK <i>x</i></b>	Obtain status of the clock controllers ( <i>x</i> is “0” or “1” for Clock 0 or Clock 1)
<b>SWCK</b>	Switch the Clock (if necessary)
<b>****</b>	Exit program
- 8 Verify that the Clock Controllers are switching correctly:  

<b>SWCK</b>	Switch Clock
	<b>Note:</b> You must wait a minimum of one minute for clocks to synchronize.
<b>SWCK</b>	Switch Clock again
- 9 Check applications.
- 10 Check dial tone.

---

**End of Procedure**

---

## Performing a customer backup data dump (upgraded release)

### Procedure 46

#### Performing a data dump to backup the customer database:

- 1 Log into the system.
- 2 Insert a CF card into the active Core/Net RMD slot to back up the database.
- 3 Load the Equipment Data Dump Program (LD 43). At the prompt, enter:  

<b>LD 43</b>	Load program.
<b>.</b>	EDD

- 4 When “EDD000” appears on the terminal, enter:

**EDD**            Begin the data dump.



**CAUTION — Service Interruption**

**Loss of Data**

If the data dump is not successful, do not continue; contact your technical support organization. A data dump problem must be corrected before proceeding.

- 5 When “DATADUMP COMPLETE” and “DATABASE BACKUP COMPLETE” appear on the terminal, enter:

**\*\*\*\***            Exit program

The Meridian 1 Option 61C CP3, CP4 upgrade to Meridian 1 Option 61C CP PIV is complete.



---

# Installing a CP PM or COTS server

---

## Contents

This chapter contains the following topics:

Introduction . . . . .	160
Signaling Server task flow . . . . .	160
Readiness checklist . . . . .	162
Installing the CP PM hardware . . . . .	165
Connections . . . . .	179
Installing the software . . . . .	189

## Introduction

This chapter contains general instructions to install and connect the Nortel Common Processor Pentium Mobile (CP PM) circuit card hardware. This chapter also contains only general instructions to connect Commercial off-the-shelf (COTS) servers. Detailed installation instructions for COTS servers are not included in this document. For more information COTS server installs, see the IBM, HP, or Dell server user guide provided by the manufacturer.

A Nortel CP PM or COTS server that you deploy with Signaling Server applications is referred to as a Signaling Server. A Nortel CP PM or COTS server that you deploy with SIP Line can be referred to as a SIP Line Gateway.

### IMPORTANT!

Instructions to install an IBM X306m, IBM x3350, or HP DL320-G4, or Dell R300 COTS server are not included in this chapter. Detailed installation instructions are in the IBM xSeries 306m User Guide, IBM x3350 User Guide, HP ProLiant DL320 Generation 4 Server User Guide, or the Dell PowerEdge R300 User Guide shipped with the server.


## Signaling Server task flow

This section provides a high-level task flow for the installation or upgrade of a CS 1000 system. The task flow indicates the recommended sequence of events to follow when configuring a system and provides the NTP number that contains the detailed procedures required for the task.

For more information refer to the following NTPs, which are referenced in Figure 32 on [page 161](#):

- *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315)
- *Element Manager: System Administration* (NN43001-632)
- *Signaling Server IP Line Applications Fundamentals* (NN3001-125)

**Figure 32**  
**Signaling Server task flow**



## Readiness checklist

Before installing a CP PM or COTS server in a Communication Server 1000 system, complete the following checklist.



**WARNING**

Do not modify or use a supplied AC-power cord if it is not the exact type required in the region where you install and use the Signaling Server. Be sure to replace the cord with the correct type.

**Table 19**  
**Readiness checklist (Part 1 of 2)**

<b>Have you:</b>	
Read all safety instructions in <i>Communication Server 1000M and Meridian 1 Large System Installation and Commissioning</i> (NN43021-310), as appropriate for your Communication Server 1000 system?	
Do you have all equipment and peripherals?  <b>For COTS servers:</b> <ul style="list-style-type: none"> <li>• installation accessories for rack-mounting the server</li> <li>• AC-power cord</li> <li>• a DTE-DTE null modem cable (supplied)</li> <li>• NTE90672: Linux Signaling Server software DVD for COTS servers</li> </ul> <b>For a CS 1000M Nortel CP PM (NTDW66AAE5 model)</b> <ul style="list-style-type: none"> <li>• NTM427CBE6: CP PM Signaling Server Linux Upgrade kit, which includes <ul style="list-style-type: none"> <li>— NTDW6102E5: CP PM Signaling Server Hard Drive kit (Linux OS preloaded)</li> <li>— NTM42703: 2 GB Compact Flash (CF) with Linux software, 2 GB blank CF</li> <li>— NTDW6109E6: 1 GB DDR SO-DIMM memory upgrade</li> </ul> </li> <li>• NTAK19ECE6: CP PM Signaling Server 2 port SDI Cable assembly kit</li> <li>• NTDW69AAE5: CP PM Signaling Server Large System Cabling kit</li> <li>• N0106745: CP PM Signaling Large System Cabling</li> <li>• a DTE-DTE null modem cable (supplied)</li> </ul> <b>Note:</b> Save the packaging container and packing materials in case you must ship the product.	
Make sure the area meets all environmental requirements?	
Check for all power requirements?	
Verify the CP PM or COTS hardware meets all required specifications (2GB ram, 40GB hard drive, CP PM BIOS version 18 or higher)?	
Check for correct grounding facilities?	

**Table 19**  
**Readiness checklist (Part 2 of 2)**

<b>Have you:</b>	
<p>Obtained the following</p> <ul style="list-style-type: none"> <li>• screwdrivers</li> <li>• an ECOS 1023 POW-R-MATE or similar type of multimeter</li> <li>• appropriate cable terminating tools</li> <li>• a computer (maintenance terminal) to connect directly to the Signaling Server, with                             <ul style="list-style-type: none"> <li>— teletype terminal (ANSI-W emulation, serial port, 9600 bps)</li> <li>— a Web browser for Element Manager (configure cache settings to check for new Web pages every time the browser is invoked, and to empty the cache when the browser is closed)</li> </ul> </li> </ul>	
<p>Prepared the network data as suggested in <i>Converging the Data Network with VoIP</i> (NN43001-260) or <i>Communication Server 1000M and Meridian 1 Large System Planning and Engineering</i> (NN43021-220), as appropriate for your Communication Server 1000 system?</p>	
<p>Read all safety instructions in <i>Communication Server 1000M and Meridian 1 Large System Installation and Commissioning</i> (NN43021-310), as appropriate for your Communication Server 1000 system?</p>	

## Installing the CP PM hardware

The Nortel CP PM server is a circuit card and is not mounted in a rack. This section contains instructions to install a Nortel CP PM circuit card in a Communication Server 1000M system.

This section contains only general instructions to install the CP PM circuit card in Communication Server 1000M systems. For more detailed installation instructions, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

### **IMPORTANT!**

There are several switches on CP PM circuit cards. All switch settings must be factory defaults except for the switch labelled S5. Switch S5 must be in position 2 to support the internal hard drive used on the CP PM Signaling Server circuit card.

## Installation in a Communication Server 1000M system

The NTDW66AAE5 model of the Nortel CP PM is for use in a Communication Server 1000M system. The first task that you must perform is to install the hard drive shipped with the server or Linux upgrade kit. For instructions, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

You can insert the NTDW66AAE5 model into any slot of a Communication Server 1000M Universal Equipment Module (UEM) except slot 7. The External Peripheral Equipment Controller (XPEC) is next to slot 7 and prevents the double wide faceplate of the NTDW66AAE5 model from seating into slot 7.

The next task that you must perform is to install ELAN and TLAN Ethernet ports on the back of the Communication Server 1000M UEM. These ports are used to connect your Nortel CP PM to the ELAN and TLAN Ethernet subnets of your Communication Server 1000M system.

Use the following procedure to install ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M UEM.

**IMPORTANT!**

Installing ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M Universal Equipment Module (UEM) disrupts service. You must turn off power to the shelf during this procedure.


**Procedure 47**

**Installing ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M UEM**

- 1 Obtain the special cabling kit (NTDW69AAE5) shipped with the NTDW66AAE5 model of the Nortel CP PM Signaling Server. The NTDW69AAE5 cabling kit includes the items shown in Figure 33.

**Figure 33**

**NTDW69AAE5 Cabling Kit contents**




The following is a list of items in the NTDW69AAE5 cabling kit:

- two RJ-45 CAT5 Ethernet patch cables
- two Ethernet port couplers
- one Ethernet port adapter plate
- two screws
- two nuts
- two washers
- two ferrite beads


**2** Insert an Ethernet port coupler into the adapter plate. See Figure 34.

**Figure 34**  
**One Ethernet port coupler in adapter plate**




**3** Insert the other Ethernet port coupler into the adapter plate. See Figure 35 on page 168.

**Figure 35**  
**Two Ethernet port couplers in adapter plate**




- 4 Loosely attach screws, washers, and nuts to the Ethernet port adapter plate. See Figure 36.

**Figure 36**  
**One Ethernet port coupler in adapter plate**



- 5 Switch off the UEM power supplies. See Figure 37.


Figure 37  
Shut down UEM power supplies



- 6 Select one of the J2-J5 knock-out plates on the back of the UEM. See Figure 38.


**Note:** For DC powered systems, turn off the breakers in the pedestal not on the shelf.

**Figure 38**  
**J2-J5 plates on back panel of UEM**



- 7 Knock out the metal plate from the selected J2-J5 location to provide a hole through which the Ethernet patch cables are routed and to which the Ethernet port adapter plate is attached. See Figure 39.

**Figure 39**  
**Selected J2-J5 plate on back panel of UEM**



- 8** Establish an ELAN port on the back panel of the UEM.
  - a.** Insert the end of one of the RJ-45 CAT5 Ethernet patch cables (supplied) into the ELAN network interface (ELAN port) on the server faceplate.
  - b.** Route the Ethernet patch cable through the hole you made in the back panel of the UEM.
  - c.** Plug the other end of the Ethernet patch cable into one of the Ethernet port couplers mounted in the Ethernet port adapter plate.
  - d.** Label the Ethernet port coupler as ELAN.

See Figure 40 and Figure 41.

**Figure 40**  
**ELAN connection on faceplate**



**Figure 41**  
**ELAN connection on Ethernet port coupler**



- 9** Connect the server to the TLAN subnet.
  - a.** Insert one end of the remaining RJ-45 CAT5 Ethernet patch cable (supplied) into the TLAN network interface (TLAN port) on the server faceplate.
  - b.** Route the Ethernet patch cable through the hole you made in the back panel of the UEM.
  - c.** Plug the other end of the Ethernet patch cable into the remaining Ethernet port coupler mounted in the Ethernet port adapter plate.
  - d.** Label the Ethernet port coupler as TLAN.

See Figure 42 and Figure 43.

**Figure 42**  
**TLAN connection on faceplate**



**Figure 43**  
**TLAN connection on Ethernet port coupler**



- 10** Fit the Ethernet port adapter plate into the hole on the back of the UEM and tighten the screws. See Figure 44.

**Figure 44**  
**Installed Ethernet port adapter plate**



**11** Attach the ferrite beads to the Ethernet patch cables. See Figure 45.

**Figure 45**  
**Attached Ethernet patch cable ferrite beads**



————— End of Procedure —————

## Connections

This section contains connection information.

### Connection checklist



#### **WARNING**

Do not modify or use a supplied AC power cord if it is not the correct type required for the host region.

#### **IMPORTANT!**

Nortel CP PM servers are powered through the backplane of the Media Gateway, Universal Equipment Module, or 11C cabinet into which they are installed and do not require a power cord.

Before connecting a CP PM or COTS server, ensure that you have the following materials on-hand.

**Table 20**  
**Connections checklist**

<b>Do you have:</b>	
A serial cable (DTE-DTE null modem cable) to connect the server to a maintenance terminal? The IBM x3350 requires a NTRX26NPE6 9 pin female to 9 pin female null modem cable.	
NTAK19EC cable (if you are connecting a Nortel CP PM)? This cable adapts the 50-pin MDF connector on the back of the shelf of the Media Gateway, Universal Equipment Module, or 11C cabinet to a 25-pin DB connector.	
CAT5 cables (or better) to connect the server to the ELAN and TLAN subnets?	


## Connecting a Nortel CP PM Signaling Server

This section contains instructions to connect a NTDW66AAE5 Nortel CP PM Signaling Server to the ELAN and TLAN subnet of a CS 1000M system. It also contains instructions to connect a maintenance terminal to the Nortel CP PM Signaling Server.

The NTDW66AAE5 model of the Nortel CP PM Signaling Server is for use in a Communication Server 1000M system. The Nortel CP PM Signaling Server is inserted into a slot of a Universal Equipment Module (UEM). UEMs do not have built-in ELAN and TLAN Ethernet ports. You must install Ethernet ports on the back of the UEM to enable the Nortel CP PM Signaling Server to connect to the ELAN and TLAN subnets of your Communication Server 1000 system (see Procedure 47: "Installing ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M UEM" on [page 166](#).)

Figure 46 shows the faceplates of the two models of the Nortel CP PM Signaling Server with labeling for all components (NTDW61BAE5 on the left and NTDW66AAE5 on the right).

**Figure 46**  
**Faceplates of the Nortel CP PM server**



Perform Procedure 48 to connect a Nortel CP PM Signaling Server (model NTDW66AAE5) to the ELAN and TLAN subnets of a Communication Server 1000M system.

**IMPORTANT!**

Connecting a Nortel CP PM Signaling Server to the ELAN and TLAN subnets of a CS 1000M system causes a service disruption.

**Procedure 48**

**Connecting a CP PM Signaling Server to the ELAN and TLAN subnets of a Communication Server 1000M system**

- 1 Insert the end of an RJ-45 CAT5 Ethernet cable (not supplied) into the ELAN network interface port (ELAN port) on the back of the Communication Server 1000M UEM. (You installed this ELAN port at the back of the UEM when you installed the Signaling Server in the UEM. For more information, see Procedure 47: "Installing ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M UEM" on [page 166](#).)
- 2 Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the ELAN Ethernet switch.
- 3 Insert the end of another RJ-45 CAT5 Ethernet cable (not supplied) into the TLAN network interface port (TLAN port) on the back of the Communication Server 1000M UEM. (You installed this TLAN port at the back of the UEM when you installed the Signaling Server in the UEM. For more information, see Procedure 47: "Installing ELAN and TLAN Ethernet ports on the back of a Communication Server 1000M UEM" on [page 166](#).)
- 4 Insert the other end of the RJ-45 CAT5 Ethernet cable into an Ethernet port on the TLAN Ethernet switch.

---

**End of Procedure**

---

**Verify or change the baud rate**

To verify or change the baud rate on a Nortel CP PM Signaling Server, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

## Connecting an IBM COTS server

In geographic regions that are susceptible to electrical storms, Nortel recommends that you plug the IBM COTS server into an AC surge suppressor.

Figure 47 shows the rear view of the IBM X306m server.

**Figure 47**  
**IBM X306m (rear view)**





Figure 48 shows the rear view of the IBM x3350 server.

**Figure 48**  
**IBM x3350 (rear view)**



**Note:** When you perform Procedure 49, “Connecting an IBM COTS server,” on [page 184](#), see Figure 47 or Figure 48.

**Procedure 49**  
**Connecting an IBM COTS server**

- 1 Connect the IBM server to the TLAN subnet. Insert the RJ-45 CAT5 (or better) cable into the TLAN Ethernet port on the back of the server.
- 2 Connect the IBM server to the ELAN subnet. Insert the RJ-45 CAT5 (or better) cable into the ELAN Ethernet port on the back of the server.
- 3 Connect a DTE–DTE null modem serial cable from the serial port on the back of the server to the serial port on a maintenance terminal. The IBM x3350 requires a NTRX26NPE6 9 pin female to 9 pin female null modem cable.
- 4 Connect the IBM server power cord.
  - a. Check that the power cord is the type required in the region where you use the server. Do not modify or use the supplied AC power cord if it is not the correct type.
  - b. Attach the female end of the power cord to the mating AC power receptacle on the server back panel. Plug the male end of the AC power cord into the AC power source (wall outlet).
- 5 Set the baud rate for the serial port on the server to 9600 b/ps. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

**Note:** The IBM X306m Signaling Server ships with the serial port configured to 9600 b/ps.

- 6 Configure the connected maintenance terminal. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
- 7 Press the Power switch.

**Note:** For more information about operating information, see the IBM User Guide on the CD-ROM shipped with your IBM server.

---

**End of Procedure**


---

## Connecting an HP COTS server

In geographic regions that are susceptible to electrical storms, Nortel recommends that you plug the HP server into an AC surge suppressor.

Figure 49 shows the rear view of the HP DL320-G4 server.

**Figure 49**  
**HP DL320-G4 (rear view)**



*Note:* When you perform Procedure 50, “Connecting an HP COTS server,” on [page 185](#), see Figure 49.

### **Procedure 50** **Connecting an HP COTS server**

- 1 Connect the HP server to the TLAN subnet. Insert the RJ-45 CAT5 (or better) cable into the TLAN Ethernet port on the back of the server.
- 2 Connect the HP server to the ELAN subnet. Insert the RJ-45 CAT5 (or better) cable into the ELAN Ethernet port on the back of the server.
- 3 Connect a DTE–DTE null modem serial cable from the Serial Port on the back of the server to a maintenance terminal.
- 4 Connect the HP server power cord.

- a. Check that the power cord is the type required in the region where you use the server. Do not modify or use the supplied AC power cord if it is not the correct type.
  - b. Attach the female end of the power cord to the mating AC power receptacle on the right-hand side of the server back panel. Plug the male end of the AC power cord into the AC power source (wall outlet).
- 5 Configure the COM1 serial port as the communication port for the connected maintenance terminal. Configure the COM 1 baud rate for the serial port on the server to 9600 b/ps. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
- 6 Configure the connected maintenance terminal. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
- 7 Press the Power switch.

---

**End of Procedure**


---

## Connecting a Dell COTS server

In geographic regions that are susceptible to electrical storms, Nortel recommends that you plug the Dell server into an AC surge suppressor.

Figure 50 shows the rear view of the Dell R300 server.

**Figure 50**  
**Dell R300 server (rear view)**



*Note:* When you perform Procedure 51, “Connecting a Dell COTS server,” on [page 187](#), see Figure 50.

### **Procedure 51** **Connecting a Dell COTS server**

- 1 Connect the Dell server to the TLAN subnet. Insert the RJ-45 CAT5 (or better) cable into the TLAN Ethernet port on the back of the server.
- 2 Connect the Dell server to the ELAN subnet. Insert the RJ-45 CAT5 (or better) cable into the ELAN Ethernet port on the back of the server.
- 3 Connect a DTE–DTE null modem serial cable from the Serial Port on the back of the server to a maintenance terminal.
- 4 Connect the Dell server power cord.

- a. Check that the power cord is the type required in the region where you use the server. Do not modify or use the supplied AC power cord if it is not the correct type.
  - b. Attach the female end of the power cord to the mating AC power receptacle on the right-hand side of the server back panel. Plug the male end of the AC power cord into the AC power source (wall outlet).
- 5 Configure the COM1 serial port as the communication port for the connected maintenance terminal. Configure the COM 1 baud rate for the serial port on the server to 9600 b/ps. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
- 6 Configure the connected maintenance terminal. See *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).
- 7 Press the Power switch.

---

**End of Procedure**

---

## **Maintenance terminal configuration parameters**

To configure Signaling Server maintenance terminal configuration parameters, see the Maintenance chapter of *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

---

## Installing the software

**IMPORTANT!**

The CP PM and COTS server are out of service during software installation.

### Introduction

This section provides references you can use when you install Communication Server 1000 Release 6.0 Linux Base and application software on CP PM and COTS servers.

**IMPORTANT!**

CP PM, and COTS servers support no Signaling Server software prior to Communication Server 1000 Release 5.0 and support no SIP Line software prior to Communication Server 1000 Release 6.0.

Communication Server 1000 Release 6.0 Signaling Server and SIP Line software runs only on the Linux Base platform.


### Before you begin

Before installing the software, you must perform the following

- Connect and power up the server. See “Connections” on [page 179](#).
- For CP PM Signaling Servers or Coresident CS and SS systems, ensure that Switch S5 is in position 2 (to support the internal hard drive)
- Obtain the CS 1000 Release 6.0 Linux Base installation media.
- Nortel advises that you remove the wire on the CF card clip before you insert the card into the slot. The clip can fall open and cause an electrical short.



- 5 The welcome screen appears. Press **ENTER** to direct the input and output to COM1.
- 6 Figure 52 appears if the CP PM card has a BIOS version lower than 18. Enter **yes** to proceed with the automatic upgrade.



**Figure 52**  
**CP PM BIOS automatic upgrade**

```
#####
#
#   CP-PM BIOS version is less than 18. BIOS upgrade is required.   #
#
# To complete the upgrade, BIOS settings must be changed to defaults. #
#   Please refer to the documentation for more information.         #
#
#####

Do you want to upgrade BIOS ROM up to the version 18? (yes/no): yes

BIOS ROM upgrade. Please wait...


BIOS ROM upgrade is finished.

Machine will be rebooted right now... Press Enter key to continue
```

- 7 Verify that the BIOS upgrade is finished. Press **Enter** to reboot.
- 8 During the reboot memory check, press **Ctrl c** to access the CP PM BIOS setup menu.
 

**Note:** If you miss the timing to press **Ctrl c** you must reboot the system and try again. The Linux Platform Base installation software will display a warning if you do not reset the CP PM BIOS to factory defaults.
- 9 Figure 53 appears. Select **Reset CMOS to factory defaults** from the menu.

**Figure 53**  
**CP PM BIOS setup**



**10** Figure 54 appears. Press **y** to reset CMOS to factory defaults.

**Figure 54**  
**CP PM BIOS reset**

```
System BIOS Setup - Utility v5.3
(C) 2005 General Software, Inc. All rights reserved
-----

Basic CMOS Configuration
Features Configuration
+-----+
| Reset CMOS to factory defaults? (Y/N): y |
|                                           |
| Reset CMOS to last known values          |
| Reset CMOS to factory defaults          |
| Write to CMOS and Exit                  |
| Exit without changing CMOS              |
|                                           |
+-----+

^E/^X/<Tab> to select. <Esc> to continue (no save)
www.gensw.com
```

- 11 The system reboots. After initial boot Figure 51 appears and the new BIOS version is displayed. Verify BIOS version is 18. You can now press the **F** key to boot from the faceplate CF card and proceed with the Linux Platform Base software installation.

————— **End of Procedure** —————

## Installing the Linux Base

Perform the Linux Base installation if your Signaling Server does not currently run Linux Base for Release 6.0. The CP PM Linux upgrade kit contains a hard drive with Linux Base preloaded. You can install Linux Base from the command line interface (CLI) using a bootable CF card on CP PM, and using a bootable optical disk on COTS. Configure the ELAN, TLAN, IP address, Gateway, subnet masks, date, and time settings during the Linux Base installation. For more information about installing or upgrading Linux Base, see *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

## Installing Linux applications

Nortel Communication Server 1000 Release 6.0 Signaling Server and SIP line software are Linux applications. Linux applications install on Linux Base and interact with the Linux Base application framework. You can deploy and install Linux applications with the Linux Base Centralized Deployment manager. You can configure a deploy SIP Line with Element Manager (EM).

For information about Linux applications, Centralized Deployment manager, and EM, see *Element Manager: System Administration* (NN43001-632), *Signaling Server IP Line Applications Fundamentals* (NN3001-125), and *Linux Platform Base and Applications Installation and Commissioning* (NN43001-315).

## Joining the UCM security domain

The UCM Primary Security Server acts as the RADIUS server that Communication Server 1000 devices use to obtain authentication and access control parameters for CLI access. The UCM Primary Security Server sends RADIUS related parameters to Communication Server 1000 devices using the SSH protocol.

When a device joins the UCM security domain, a mutually-trusted SSH channel is created. You must manually confirm the fingerprint of the public key before the UCM Primary Security Server RSA public key is added to the authorized key file. This verification prevents third-party intercepts.

When a mutually-trusted SSH tunnel establishes a connection to a Communication Server 1000 device, the UCM Primary Security Server can send SSH remote commands to the device using RSA public key-based authentication.

For more information about joining the UCM security domain, see *Security Management* (NN43001-604).



---

# Appendix A: Upgrade checklists

---

## Contents

This chapter contains the following topics:

Introduction . . . . .	197
Site details . . . . .	198
Upgrade details . . . . .	198
Preupgrade checklists . . . . .	199
Preconversion steps . . . . .	202
Postconversion checks . . . . .	204
Quick reference . . . . .	204

## Introduction

The following section provides Large System upgrade checklists.

### Technical Support

Nortel can provide an Installation and Upgrade Support team to assist with PBX upgrades on a scheduled bases. This service is billable and a purchase order is required. Please refer to current price book for rates.

*Note:* This service requires that a service request be opened in advance of the upgrade.

## Site details

**Table 21**  
**Site Details**

Customer Name	
Tape ID (LD 22)	
Modem Number (Core)	
Switch Room Telephone	
Baud Rate	
Modem Password	
PBX Password	
System Type	
Software Generic	

## Upgrade details

**Table 22**  
**Upgrade details**

Current Software - Generic	
Target Software - Generic	
Hardware being added	
Feature Upgrade	
License Upgrade	

## Preupgrade checklists

### Software Upgrade

#### Software audit

**Table 23**  
**Software audit**

<b>Software Audit</b>		
Perform the software audit prior to the scheduled upgrade.		
Take corrective action if answer is no		
	Yes	No
Software CD Ready		
Keycode Disk Ready		
Install Disk Ready		
DEP Patch Disk Ready		
Review Keycode Data Sheet - (SDID,PKGS,License,TID)		
Review Site Specific Patches - (Non MDCS)		
Read GRB for target Release – (Verify Memory Requirements)		

### License Upgrade

**Table 24**  
**Keycode audit**

Keycode Audit		
Perform the keycode Audit prior to the scheduled upgrade.		
Take corrective action if answer is no		
	Yes	No
Keycode Disk Ready		
Keycode Data Sheet Ready		
SDID Matches System		
TID Matches System		
Perform a KDIFF in LD 143 to compare keycodes		

### Conversion Required

**Table 25**  
**Conversion Procedures**

Conversion Procedures
Upgrades between different machine types require some type of conversion.
If the disk media is changing the database must be physically transferred
between storage devices. Please select source and target media.

**Table 26**  
**Typical Storage Media Changes Between machine Types (Part 1 of 2)**

Typical Storage Media Changes Between machine Types		
Source	Target	Procedure Required
CMDU	IODUC	4M - 2M media transfer

**Table 26**  
**Typical Storage Media Changes Between machine Types (Part 2 of 2)**

IODUC	MMDU	Disk to new Drive both use 2M Floppy Drives
MMDU	MMDU	Disk to new Drive

## Hardware Upgrade

### Hardware audit

**Table 27**  
**Hardware audit**

Hardware Audit		
Perform the Hardware Audit prior to the scheduled upgrade.		
	Yes	No
Verify Shipping List - Complete and Accurate		
Audit Site for new hardware locations		
Pre Run Cables if possible		
Review All switch settings for new cards		
Read all applicable NTP Procedures completely		

## Preconversion steps

**Table 28**  
**Preconversion steps (Part 1 of 2)**

Pre Conversion Steps
A capture file should be made of the following information using a PC or Printer.
Perform an overall system check:
LD 135 SCPU (ensure that the system is redundant)
LD 137 STAT/TEST CMDU
LD 96 STAT DCH
LD 48 STAT AML
LD 32 STAT
LD 60 STAT

**Table 28**  
**Preconversion steps (Part 2 of 2)**

LD 30 LDIS (Verify what is disabled if any)
Obtain Software Information from LD 22
ISSP - Patches in service - Future Reference if required LD 143 - MDP ISSP -Prints all inservice patches and patch handle numbers (includes all DepList patches)
TID/SLT - License Parameters - To compare with converted database
LD 21 - PRT CFN
LD 97 - PRT SUPL/XPEC
Run a Template Audit
LD 1 - Auto Run
Perform a Datadump
Backup at least two copies of the current database, retain the copies.
Print History File or System Event Log
LD 22 - Print AHST - Capture Systems Events to compare with new software if required
LD 117 - PRT SEL 500 - Same as above

## Postconversion checks

**Table 29**  
**Postconversion checks**

<b>Post Conversion Checks</b>
Perform these checks after a successful INI.
Test for dial tone
Stat D Channels for proper operation
Ensure that all XPEC's are in service via visual inspection
Ensure that all AUX applications are working
LD 30 LDIS (Verify that output is the same prior to upgrade)

## Quick reference

### IGS Cabling Chart - MultiGroup PBX - Opt 81/81C/CP (5 Groups Maximum)

**Table 30**  
**IGS cabling chart (Part 1 of 2)**

Net Group	Net Shelf	IGS Connector	IGS Net	Slot	Net	DIGS	Slot Connector	Intergroup connector	I G S	Clock
0	0	0	3	8	2	9	BOTTOM	J1	0	
0	0	1	2	9	2	9	TOP	J6	2	0
0	1	1	2	9	2	9	TOP	J17	3	1
0	1	0	3	8	2	9	BOTTOM	J22	1	
1	0	0	3	8	2	9	BOTTOM	J2	4	

**Table 30**  
**IGS cabling chart (Part 2 of 2)**

1	0	1	2	9	2	9	TOP	J7	6	0
1	1	1	2	9	2	9	TOP	J16	7	1
1	1	0	3	8	2	9	BOTTOM	J21	5	
2	0	0	3	8	2	9	BOTTOM	J3	8	
2	0	1	2	9	2	9	TOP	J8	1	0
									0	
2	1	1	2	9	2	9	TOP	J15	1	1
									1	
2	1	0	3	8	2	9	BOTTOM	J20	9	
3	0	0	3	8	2	9	BOTTOM	J4	1	
									2	
3	0	1	2	9	2	9	TOP	J9	1	0
									4	
3	1	1	2	9	2	9	TOP	J14	1	1
									5	
3	1	0	3	8	2	9	BOTTOM	J19	1	
									3	
4	0	0	3	8	2	9	BOTTOM	J5	1	
									6	
4	0	1	2	9	2	9	TOP	J10	1	0
									8	
4	1	1	2	9	2	9	TOP	J14	1	1
									9	
4	1	0	3	8	2	9	BOTTOM	J18	1	
									7	

*Note:* A DIGS Card is located in the card slot position for IGS 1 in all network shelves. The IGS 1 slot detects the clock signals from the active clock controller and distributes the clock to the entire group. Three out of four IGS cards can be disabled at any given time via LD 39, the IGS 1 that is associated with the active clock cannot be disabled via software, e.g. if clock 1 is active then IGS's 3,7,11,15 and 19 can never be disabled as they are providing clock for their respective network groups.

### Group/Loop/PS/FIJI/3PE Switch Settings

**Table 31**  
Switch settings (Part 1 of 2)

Group	Shelf	P S	Loops	FIJI*	3PE NT8D35 Net**	3PE NT5D21 Core Net**
0	0	0	0-16	0 0	off on on on on on on on	off on on off on on on on
0	1	1	16-31	0 1	off on on on on on on off	off on on off on on on off
1	0	2	32-47	1 0	off on on on on on off on	off on on off on on off on
1	1	3	48-63	1 1	off on on on on on off off	off on on off on on off off
2	0	4	64-79	2 0	off on on on on off on on	off on on off on off on on
2	1	5	80-95	2 1	off on on on on off on off	off on on off on off on off
3	0	6	96-111	3 0	off on on on on off off on	off on on off on off off on
3	1	7	112-127	3 1	off on on on on off off off	off on on off on off off off
4	0	8	128-143	4 0	off on on on off on on on	off on on off off on on on
4	1	9	144-159	4 1	off on on on off on on off	off on on off off on on off
5	0	10	160-175	5 0	off on on on off on off on	off on on off off on off on

**Table 31**  
**Switch settings (Part 2 of 2)**

5	1	1 1	176-19 1	5 1	off on on on off on off off	off on on off off on off off
6	0	1 2	192-20 7	6 0	off on on on off off on on	off on on off off off on on
6	1	1 3	208-23 3	6 1	off on on on off off on off	off on on off off off on off
7	0	1 4	224-23 9	7 0	off on on on off off off on	off on on off off off off on
7	1	1 5	240-25 5	7 1	off on on on off off off off	off on on off off off off off



---

# Appendix B: Technical Assistance service

---

## Contents

This chapter contains the following topics:

Nortel Technical Assistance Centers. . . . .	209
Services available . . . . .	212
Requesting assistance . . . . .	215

## Nortel Technical Assistance Centers

To help customers obtain maximum benefit, reliability, and satisfaction from their CS 1000E systems, Nortel provides technical assistance in resolving system problems. Table 32 on [page 210](#) lists the centers that provide this service.

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel service program, contact one of the following Nortel Technical Solutions Centers.

**Table 32**  
**Customer Technical Services (Part 1 of 2)**

Location	Contact
Nortel Global Enterprise Technical Support (GETS) PO Box 833858 2370 Performance Drive Richardson, TX 75083 USA	North America Telephone: 1 800 4NORTEL
Nortel Corp. P.O. Box 4000 250 Sydney Street Belleville, Ontario K8N 5B7 Canada	North America Telephone: 1 800 4NORTEL
Nortel Service Center - EMEA	EMEA Telephone: 00 800 8008 9009 or +44 (0)870 907 9009 E-mail: emeahelp@nortel.com
Nortel 1500 Concord Terrace Sunrise, Florida 33323 USA	Brazil Telephone: 5519 3705 7600 E-mail: entcts@nortel.com English Caribbean Telephone: 1 800 4NORTEL Spanish Caribbean Telephone: 1 954 858 7777 Latin America Telephone: 5255 5480 2170

**Table 32**  
**Customer Technical Services (Part 2 of 2)**

Location	Contact
Network Technical Support (NTS)	<p>Asia Pacific  Telephone: +61 28 870 8800</p> <p>Australia  Telephone: 1800NORTEL (1800 667835) or  +61 2 8870 8800  E-mail: asia_support@nortel.com</p> <p>People's Republic of China  Telephone: 800 810 5000  E-mail: chinatsc@nortel.com</p> <p>Japan  Telephone: 010 6510 7770  E-mail: supportj@nortel.com</p> <p>Hong Kong  Telephone: 800 96 4199  E-mail: chinatsc@nortel.com</p> <p>Taiwan  Telephone: 0800 810 500  E-mail: chinatsc@nortel.com</p> <p>Indonesia  Telephone: 0018 036 1004</p> <p>Malaysia  Telephone: 1 800 805 380</p> <p>New Zealand  Telephone: 0 800 449 716</p> <p>Philippines  Telephone: 1 800 1611 0063 or 632 917 4420</p> <p>Singapore  Telephone: 800 616 2004</p> <p>South Korea  Telephone: 0079 8611 2001</p> <p>Thailand:  Telephone: 001 800 611 3007</p>

## Services available

Services available through the Technical Assistance Centers include:

- diagnosing and resolving software problems not covered by support documentation
- diagnosing and resolving hardware problems not covered by support documentation
- assisting in diagnosing and resolving problems caused by local conditions

There are several classes of service available. Emergency requests (Class E1 and E2) receive an immediate response. Service for emergency requests is continuous until normal system operation is restored. Non-emergency

requests (Class S1, S2, and NS) are serviced during normal working hours. Tables 33 and 34 describe the service classifications.

**Table 33**  
**Technical service emergency classifications**

Class	Degree of failure	Symptoms
E1	Major failure causing system degradation or outage	<p>System out-of-service with complete loss of call-processing capability.</p> <p>Loss of total attendant console capability.</p> <p>Loss of incoming or outgoing call capability.</p> <p>Loss of auxiliary Call Detail Reporting (CDR) in resale application.</p> <p>Call processing degraded for reasons such as trunk group out-of-service:</p> <ul style="list-style-type: none"> <li>• 10% or more lines out-of-service</li> <li>• frequent initializations (seven per day or more)</li> <li>• inability to recover from initialization or SYSLOAD</li> <li>• consistently slow dial tone (eight seconds or more delay)</li> </ul>
E2	Major failure causing potential system degradation or outage	<p>Standby CPU out-of-service.</p> <p>Frequent initializations (one per day or more).</p> <p>Disk drive failure.</p> <p>Two sets of disks inoperative.</p>

**Table 34**  
**Technical services non emergency classifications**

Class	Degree of failure	Symptoms
S1	Failure that affects service	<p>Software or hardware trouble directly and continuously affecting user's service or customer's ability to collect revenue.</p> <p>Problem that will seriously affect service at in-service or cut-over date.</p>
S2	Intermittent failure that affects service	<p>Software or hardware faults that only intermittently affect service.</p> <p>System-related documentation errors that directly result in or lead to impaired service.</p>
NS	Failure that does not affect service	<p>Documentation errors.</p> <p>Software inconsistencies that do not affect service.</p> <p>Hardware diagnostic failures (not defined above) that cannot be corrected by resident skills.</p> <p>Test equipment failures for which a backup or manual alternative can be used.</p> <p>Any questions concerning products.</p>

Except as excluded by the provisions of warranty or other agreements with Nortel, a fee for technical assistance may be charged, at rates established by Nortel. Information on rates and conditions for services are available through Nortel sales representatives.

## Requesting assistance

Collect the information listed in Table 35 before you call for service.

**Table 35**  
**Checklist for service requests**

Name of person requesting service	_____
Company represented	_____
Telephone number	_____
System number/identification	_____
Installed software generic and issue (located on data disk)	_____
Modem telephone number and password (if applicable)	_____
Seriousness of request (see Tables 33 and 34)	_____
Description of assistance required	_____
	_____
	_____



---

# Index

---

## B

backup the database, 39

BKO, 39

## C

call processing, effect of software upgrades on, 18

conversion media

defined, 18

CTS, contacting, 210

## D

data dump, 39

## L

LD 32 program

in 3PE Card replacement, 67

LD 37 program

3PE Card replacement, 66, 67

## P

Peripheral Signaling Cards

in 3PE Card replacement, 67

printouts

site data, 36

## S

single CPU systems

call processing disruptions on, 18

site data printouts

pre-conversion procedure, 36

source software

defined, 19

## T

target software, 19

Technical Assistance Centers, 209

terminal

connection and settings, 32

## U

Unattended backup (BKO command), 39





Nortel Communication Server 1000

# **Communication Server 1000M and Meridian 1**

## **61C to CS 1000M SG CP PIV Upgrade**

**Copyright © 2009 Nortel Networks. All rights reserved.**

### LEGAL NOTICE

While the information in this document is believed to be accurate and reliable, except as otherwise expressly agreed to in writing NORTEL PROVIDES THIS DOCUMENT "AS IS" WITHOUT WARRANTY OR CONDITION OF ANY KIND, EITHER EXPRESS OR IMPLIED. The information and/or products described in this document are subject to change without notice.

Nortel, the Nortel logo, the Globemark, SL-1, Meridian 1, and Succession are trademarks of Nortel Networks. All other trademarks are the property of their respective owners.

To provide feedback or report a problem in this document, go to [www.nortel.com/documentfeedback](http://www.nortel.com/documentfeedback).

Publication number: NN43021-461

Document release: 03.03

Date: June 2009

