



Nortel CallPilot

703t Server Maintenance and Diagnostics

Document status: Standard
Document version: 01.03
Document date: 3 April 2007

Copyright © 2007, Nortel Networks
All Rights Reserved.

Sourced in Canada

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

The process of transmitting data and call messaging between the CallPilot server and the switch or system is proprietary to Nortel Networks. Any other use of the data and the transmission process is a violation of the user license unless specifically authorized in writing by Nortel Networks prior to such use. Violations of the license by alternative usage of any portion of this process or the related hardware constitutes grounds for an immediate termination of the license and Nortel Networks reserves the right to seek all allowable remedies for such breach.

Trademarks

*Nortel, the Nortel logo, the Globemark, and Unified Networks, BNR, CallPilot, DMS, DMS-100, DMS-250, DMS-MTX, DMS-SCP, DPN, Dualmode, Helmsman, IVR, MAP, Meridian, Meridian 1, Meridian Link, Meridian Mail, Norstar, SL-1, SL-100, Communication Server 1000, Supernode, Contact Center, Telesis, and Unity are trademarks of Nortel Networks.

3COM is a trademark of 3Com Corporation.

ADOBE is a trademark of Adobe Systems Incorporated.

ATLAS is a trademark of Quantum Corporation.

BLACKBERRY is a trademark of Research in Motion Limited.

CRYSTAL REPORTS is a trademark of Seagate Software Inc.

EUDORA is a trademark of Qualcomm.

eTrust and InoculateIT are trademarks of Computer Associates Think Inc.

DIRECTX, EXCHANGE.NET, FRONTPAGE, INTERNET EXPLORER, LINKEXCHANGE, MICROSOFT, MICROSOFT EXCHANGE SERVER, MS-DOS, NETMEETING, OUTLOOK, POWERPOINT, VISUAL STUDIO, WINDOWS, WINDOWS MEDIA, and WINDOWS NT are trademarks of Microsoft Corporation.

GROUPWISE and NOVELL are trademarks of Novell Inc.

LOGITECH is a trademark of Logitech, Inc.

MCAFEE and NETSHIELD are trademarks of McAfee Associates, Inc.

MYLEX is a trademark of Mylex Corporation.

NETSCAPE COMMUNICATOR is a trademark of Netscape Communications Corporation.

NOTES is a trademark of Lotus Development Corporation.

NORTON ANTIVIRUS and PCANYWHERE are trademarks of Symantec Corporation.

QUICKTIME is a trademark of Apple Computer, Inc.

RADISYS is a trademark of Radisys Corporation.

SLR4, SLR5, and TANDBERG are trademarks of Tandberg Data ASA.

SYBASE is a trademark of Sybase, Inc.

TEAC is a trademark of TEAC Corporation

US ROBOTICS, the US ROBOTICS logo, and SPORTSTER are trademarks of US Robotics.

WINZIP is a trademark of Nico Mark Computing, Inc.

XEON is a trademark of Intel, Inc.

All other trademarks and registered trademarks are the property of their respective owners.

Information for Japan

Japan Denan statement

The following applies to server models 1005r, 703t, and 1002rp:

 Warning
Please be aware of the following while installing the equipment: • Please use the connecting cables, power cord, and AC adaptors shipped with the equipment or specified by Nortel to be used with the equipment. If you use any other equipment, it may cause failures, malfunctioning or fire. • Power cords shipped with this equipment must not be used with any other equipment. If the above guidelines are not followed, it may lead to death or severe injury.
 警告
本製品を安全にご使用頂くため、以下のことにご注意ください。 ● 接続ケーブル、電源コード、ACアダプタなどの部品は、必ず製品に同梱されております添付品または指定品をご使用ください。添付品・指定品以外の部品をご使用になると故障や動作不良、火災の原因となることがあります。 ● 同梱されております付属の電源コードを他の機器には使用しないでください。上記注意事項を守らないと、死亡や大怪我など人身事故の原因となることがあります。

Japan VCCI statement

The following applies to server models 1005r, 703t, 201i, and 1002rp:

この装置は、情報処理装置等電波障害自主規制協議会 (VCCI) の規定に基づくクラス A 装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を取るよう要求されることがあります。

This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may occur, in which case, the user may be required to take corrective action.

Publication History

April 2007

CallPilot 5.0 Standard 01.03 of the *703t Server Maintenance and Diagnostics* is released for general availability. Added warning about replacement hard drive sizes.

April 2007

CallPilot 5.0 Standard 01.02 of the *703t Server Maintenance and Diagnostics* is released for general availability. The procedure was added for replacing the LSI1600 card with the LSI320-2.

February 2007

CallPilot 5.0 Standard 01.01 of the *703t Server Maintenance and Diagnostics* is released for general availability.

Contents

Chapter 1 How to get help	11
Chapter 2 About this guide	13
Maintenance and diagnostics overview	13
Chapter 3 Troubleshooting your CallPilot system	17
Overview	17
Interpreting front panel LEDs	18
Interpreting rear panel LEDs	22
Interpreting internal LEDs	23
Interpreting POST diagnostics	24
SCSI controller diagnostics	26
RAID controller diagnostics	27
What to do when the server fails to boot into service	27
Chapter 4 Using Windows online diagnostic tools	31
Overview	31
Viewing event logs	32
Using TCP/IP diagnostic tools	35
Using the chkdsk utility	42
Chapter 5 Using serial port diagnostic tools	45
Overview	45
Shutting down services	45
Conducting TSTSERIO tests	47
Conducting TSTSERIO tests with the loopback plug	49
Restarting services	49
Chapter 6 Using CallPilot Manager to monitor hardware	51
Understanding fault management	51
Alarm Monitor	53
Event Browser	55
Channel and Multimedia Monitors	57
The Maintenance page	57
Viewing component states	60
Starting and stopping components	62

Running integrated diagnostics	64
Viewing the last diagnostic results	66
Working with the Multimedia Monitor	67
Working with the Channel Monitor	69

Chapter 7 Using CallPilot system utilities **73**

Overview	73
Diagnostics Tool	74
PEP Maintenance utility	75
Session Trace	75
System Monitor	77

Chapter 8 Replacing basic chassis components **81**

Preparing the server for hardware maintenance	81
Removing the side cover	84
Removing and replacing the upper fan holder foam	86
Replacing the side cover	88
Cooling fans description	89
Replacing a front system fan	92
Replacing a rear system fan	95
Replacing the processor fan	98

Chapter 9 Replacing media drives **101**

SCSI and IDE drive cabling	101
Replacing a faulty hard drive	102
Replacing the tape drive	109
Replacing the CD-ROM drive	113
Replacing the floppy disk drive	116

Chapter 10 RAID operations **121**

RAID overview	121
Verifying the RAID firmware	122
Configuring RAID using LSI Elite 1600 controller and Ctrl+M	124
Replacing the LSI1600 card with LSI320-2	126
Verifying consistency on the drives	128
RAID splitting	129
Task summary for configuring RAID	133
Task summary for RAID splitting	134

Chapter 11 Replacing or adding voice processing boards **137**

DSP numbering and location	137
Replacing MPB96 boards	138

Chapter 12 Working with DIMMs and the CPU **143**

Replacing or adding baseboard DIMMs	143
Replacing the CPU	146

Chapter 13 Working with the CallPilot server BIOS	157
Overview	157
BIOS settings	158
Updating and configuring the BIOS	162
Recovering from corrupted CMOS and BIOS	164

Appendix A 703t description reference	167
Server features	167
Slot assignments	172
IRQ mapping table	173

Index	175
--------------	------------

Chapter 1

How to get help

This section explains how to get help for Nortel products and services.

Getting help from the Nortel Web site

The best way to get technical support for Nortel products is from the Nortel Technical Support Web site:

<http://www.nortel.com/support>

This site provides quick access to software, documentation, bulletins, and tools to address issues with Nortel products. More specifically, the site enables you to:

- download software, documentation, and product bulletins
- search the Technical Support Web site and the Nortel Knowledge Base for answers to technical issues
- sign up for automatic notification of new software and documentation for Nortel equipment
- open and manage technical support cases

Getting help over the phone from a Nortel Solutions Center

If you don't find the information you require on the Nortel Technical Support Web site, and have a Nortel support contract, you can also get help over the phone from a Nortel Solutions Center.

In North America, call 1-800-4NORTEL (1-800-466-7835).

Outside North America, go to the following Web site to obtain the phone number for your region:

<http://www.nortel.com/callus>

Getting help from a specialist by using an Express Routing Code

To access some Nortel Technical Solutions Centers, you can use an Express Routing Code (ERC) to quickly route your call to a specialist in your Nortel product or service. To locate the ERC for your product or service, go to:

<http://www.nortel.com/erc>

Getting help through a Nortel distributor or reseller

If you purchased a service contract for your Nortel product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller.

Chapter 2

About this guide

In this chapter

"Maintenance and diagnostics overview" (page 13)

Maintenance and diagnostics overview

The maintenance and diagnostic activities discussed in this guide are divided into two groups of activities:

- troubleshooting and diagnostics (identifying the cause of and resolving system problems)
- hardware maintenance

This guide is for administrators, technicians, and engineers responsible for maintaining a CallPilot server. This guide assumes that you have basic computing skills, and are familiar with necessary safety procedures. If you are not able to resolve your problem with the resources described in this guide, you can also refer to the following document:

- *Troubleshooting Guide* (NN44200-700)

Note: Nortel continually updates the *Troubleshooting Guide*. You can obtain the latest version from the Partner Information Center (PIC) at <http://www.nortel.com/pic>.

The *Installation and Configuration Task List* (NN44200-306) explains how to restart, shut down, and power up the CallPilot server. When you purchased your CallPilot server, it came preinstalled with the operating system and CallPilot server software. If your CallPilot server no longer functions because of a software problem, you may need to reinstall the CallPilot software or rebuild the system.

Replacement parts

Before replacing any parts on your server, refer to the Nortel product catalog for the part codes.



CAUTION

The use of parts that are not supplied by Nortel can cause serious system problems or void your Nortel warranty.

Preparing for maintenance activities

Before you proceed with hardware maintenance activities, review the *Installation and Configuration Task List* (NN44200-306) and the *703t Server Hardware Installation Guide* (NN44200-304) guide for the following information:


- required tools and equipment
- recommended safety precautions for electrostatic discharge, handling cards, and handling your server
- instructions for shutting down your 703t server or for taking it out of service

Reference documents

For a list of all CallPilot documents, see the following CallPilot Customer Documentation Map.



CallPilot Customer Documentation Map



**available in summer 2007*

Chapter 3

Troubleshooting your CallPilot system

In this chapter

"Overview" (page 17)

"Interpreting front panel LEDs" (page 18)

"Interpreting rear panel LEDs" (page 22)

"Interpreting internal LEDs" (page 23)

"Interpreting POST diagnostics" (page 24)

"SCSI controller diagnostics" (page 26)

"RAID controller diagnostics" (page 27)

"What to do when the server fails to boot into service" (page 27)

Overview

This section describes the startup diagnostics available on the 703t server and the methods for troubleshooting startup problems. the following topics are covered:

- Hardware LED states starting on "Interpreting front panel LEDs" (page 18)
- Power-On Self-Test (POST) diagnostics on "Interpreting POST diagnostics" (page 24)
- SCSI controller diagnostics on "SCSI controller diagnostics" (page 26)
- RAID controller diagnostics "RAID controller diagnostics" (page 27)
- What to do when the server fails to boot into service on "What to do when the server fails to boot into service" (page 27)


Interpreting front panel LEDs

This section describes LED states visible on the 703t server front panel.

LED locations

"LED locations" (page 18) shows where the LEDs are located.

LED locations



The server LEDs, from top to bottom and left to right, indicate the status of the following:

- the ELAN and CLAN network interfaces
- hard drive
- power/sleep
- system

LEDs are also provided on the SCSI tape drive faceplate, floppy disk drive faceplate, and the IDE CD-ROM drive faceplate.

Network LED states

The network LEDs are green and are located as follows:

LED position	Controller name	Controller type	LAN type
Left	NIC1	10/100Base-T	ELAN
Right	NIC2	10/100/1000Base-T	CLAN

IF the network interface LED is	THEN
off	a valid hardware connection with the network has not been established. Ensure that the Ethernet cable is connected to both the Ethernet connector on the server and the respective network hub. If the cable is connected, ensure that the cable is serviceable.
on	a valid hardware connection with the network has been established. Note: Before the 703t server can receive or transmit data, you must configure valid IP settings on the 703t server.
blinking rapidly	activity is occurring on the network. Note: This does not mean that the 703t server is actually transmitting or receiving packets.

Hard drive LED states

The hard drive LED (the first LED in the row of LEDs below the power button on the 703t server front panel) is not used because the 703t server is actually equipped with two hard drives. There are no LEDs on the hard drives.

If hard drive faults occur on the 703t server, you can investigate them by reviewing events in the following:

- operating system Event Viewer (see ["Viewing event logs" \(page 32\)](#))
- CallPilot Event Browser (see ["Event Browser" \(page 55\)](#))

You can also view the status of each hard drive in the MegaRAID Client. For instructions on accessing and using this utility, see [Chapter 10 "RAID operations" \(page 121\)](#)

Power/sleep LED states

The power/sleep LED is the middle LED in the row of LEDs below the power button on the 703t server's front panel (see "Status LEDs" in the diagram on "LED locations" (page 18)). The LED is green.

IF the power/sleep status LED is	AND	THEN
green	steady	the server is powered on.
off	not applicable	the server is powered off.

Note: The CallPilot operating system does not support sleep mode on the server.

System status LED

The system status LED is the right LED in the row of LEDs below the power button on the 703t server's front panel (see "Status LEDs" in the diagram on "LED locations" (page 18)).

Note: If the status LED indicates a problem, you can learn more about the problem by using the server's event log. For more information, see "Viewing event logs" (page 32).

IF the system status LED is	AND	THEN
green	steady	the server is operating normally.
	blinking	the server's processor or memory is disabled.
amber	steady	- a critical temperature or voltage fault has occurred. - the CPU is not installed or is not functioning.
	blinking	- a power fault has occurred. - a fan is faulty. - a non-critical temperature or voltage fault has occurred.
	off	a fatal error occurred during the power-on status test (POST).

Tape drive LED states

The 703t server is equipped with an SLR60 tape drive. Three LEDs are located on the drive's front panel. They are referred to as left, center, and right in the following table:

SLR60 LEDs

Left - Ready Green	Center - Activity Green	Right - Error Amber	Description
On	On	On	LED test (2 seconds at power on) is running.
Blinking	Off	Off	- Power-up self-test is running. - Diagnostic cartridge activity is running.
Off	Off	Off	- Cartridge is not inserted - Tape is not loaded
On	Off	Off	- Cartridge is not inserted - Tape is loaded but is not moving
On	Blinking	Off	- Tape is loaded and moving - Tape is loading or unloading - Cartridge is ejecting
Off	Off	On	- Cleaning is required - Cartridge/tape is not loaded
On	Off	On	- Cleaning is required - Tape is loaded but not moving
On	Blinking	On	- Cleaning is required - Tape is loaded and moving - Tape is loading or unloading - Cartridge is ejecting

Note: If the LED states indicate an error, contact your Nortel technical support representative.

Left - Ready Green	Center - Activity Green	Right - Error Amber	Description
Off	Blinking	On	Cleaning is in progress
Off	Off	Blinking	- Unrecoverable tape drive failure has occurred. - Cartridge has failed - Microcode download failure has occurred

Note: If the LED states indicate an error, contact your Nortel technical support representative.

CD-ROM drive LED states

The CD-ROM drive's status LED is located on the drive's front panel. Refer to the following table when interpreting the CD-ROM drive's status:

IF the CD-ROM drive LED is	THEN
off	the CD-ROM drive is idle.
on	the CD-ROM drive is being accessed.

Interpreting rear panel LEDs

This section describes LED states visible at the back of the 703t server.

MPB96 DS30 connection link LED states

Refer to ["Slot definition and numbering" \(page 172\)](#) for the slot position of the MPB96 boards in your server.

["MPB96 board" \(page 138\)](#) shows the location of three green LEDs on the MPB96 card bracket.

When	THEN
all three are On	the cables are connected properly.
one or more are Off	- there is no connection to the switch. - the connection to the switch is intermittent. - the DS30 clock signal coming from the MGate card (NTRB18CA) is not working correctly.

You should:

When	THEN
	• check each of the three individual branches of the DS30 cable for faults, or replace the cable. • check for a faulty MGate card (NTRB18CA) in the switch.

Blue LED

The blue LED in the back of the 703t system is not used in CallPilot.

It comes on for only a moment during a server reboot.

Interpreting internal LEDs

This section describes LED states visible inside of the 703t server cabinet.

MPB96 LED states

There are three LEDs on the top of the MPB96 board. They are visible even from outside the server cabinet, through the rear grill.

PCI FPGA Done LED (closest to the I/O card bracket)

This LED should go ON at power up and then OFF right away. This LED activity indicates that the board is working properly and was correctly detected by the system.

If the LED stays ON after power up, the card is faulty, and you must replace the board.

DSP FPGA Done LED

This LED comes on at power up and stays ON until the CallPilot drivers are loaded just before the diagnostic screen starts.

If this LED stays ON after the system has booted in the operating system and the CallPilot diagnostic screen has started, either the board is faulty or there is a problem with the CallPilot DSP and Windows Bus drivers.

CTbus FPGA Done LED (furthest from the I/O card bracket)

This LED works in tandem with the "DSP FPGA Done" LED, and should go on and off at the same times.

RAID controller LED states

Refer to "[Slot definition and numbering](#)" (page 172) for the slot position of the RAID boards in your server.

There is one red LED and a row of eight small LEDs at the back of the RAID board.

To check if RAID board is working properly

Step	Action
1	The red LED comes on briefly at power up, then goes off. This indicates that the card was accessed for detection successfully. At the same time, all eight LEDs at the back will light.
2	Four of the eight LEDs will then go off and stay that way.
—End—	

There are four LEDs lit when the RAID card is working properly.

If all eight LEDs stay on after power up and boot, the card was not detected or is faulty.

Interpreting POST diagnostics

The Power-On-Self-Test (POST) is a system diagnostic program (stored in the BIOS) that runs each time the 703t server is started. The function of POST is to test system components and then to display status messages.

POST reports on the system status using POST beep codes. If an error occurs before video initialization, POST emits beep codes that indicate errors in hardware, software, or firmware.

A beep code is a series of separate tones, each equal in length. Record the beep codes that you hear before calling your Nortel customer support representative.

ATTENTION

Some POST beep codes are critical and require you to replace your motherboard. Refer to the tables in this section for more information about beep codes.

Types of beep codes

There are three types of beep codes on the 703t server:

- BIOS recovery beep codes (during a BIOS recovery procedure)
- bootblock error beep codes (for normal operation)

- bootblock error 3-beep codes (for normal operation)

BIOS recovery beep codes

Beeps	Error message	Description
1	Recovery started	Recovery process started.
2	Recovery boot error	Unable to boot from floppy disk drive or CD-ROM drive. Recovery process will retry.
Series of low-pitched single beeps	Recovery failed	Unable to process valid BIOS recovery images. BIOS has already passed control to the operating system and flash utility.
2 long high-pitched beeps	Recovery complete	BIOS recovery succeeded. Ready for power-down or restart.
3	Recovery failed	Recovery failed. Disk is not bootable or the disk is not inserted.

Bootblock error beep codes

Number of beeps	Error message	Error message and conditions
1	Refresh Timer Failure	The memory refresh circuitry on the motherboard is faulty.
2	Parity Error	Parity cannot be reset.
3	Boot Block Failure	See " Bootblock error 3-beep codes " (page 26).
4	System Timer	System timer not operational.
5	Processor Failure	Processor is faulty.
6	Keyboard Gate A20 Failure	Keyboard may be bad.
7	Processor Exception Int error	Processor generated an exception interrupt.
8	Display Memory Read/Write Error	Video adapter is missing or faulty. This is not a fatal error.
9	ROM checksum error	BIOS checksum error has occurred.

Number of beeps	Error message	Error message and conditions
10	Shutdown register error	Shutdown register read/write error has occurred.
11	Invalid BIOS	General BIOS error has occurred.

Bootblock error 3-beep codes

Number of beeps	POST code	Expansion card/controller
3	00h	No memory was found in the system.
3	01h	Memory of mixed types was detected.
3	02h	EDO is not supported.
3	03h	First row memory test has failed.
3	04h	Mismatched DIMMs are in a row.
3	05h	Base memory test failed
3	06h	Decompressing post module failed.
3	07-0Dh	Generic memory error has occurred.
3	0Eh	SMBus protocol error has occurred.
3	0Fh	Generic memory error has occurred.
3	DDh	CPU microcode cannot be found for processor in slot 0.
3	EEh	CPU microcode cannot be found for processor in slot 1.

SCSI controller diagnostics**BIOS initialization**

Most information about SCSI is displayed as part of the BIOS initialization screen.

During BIOS initialization, check to make sure that the tape drive is listed correctly. If the tape drive is not listed correctly:

- Ensure that internal cable connections are made properly.
- Check that tape drive settings are correct.
- Check tape drive termination.

For more information refer to:

- ["SCSI and IDE drive cabling" \(page 101\)](#)
- ["Replacing the tape drive" \(page 109\)](#)

RAID controller diagnostics

Most diagnostic information about RAID is available through beep warnings and status LEDs when the server is rebooting.

For more information refer to:

- "Hard drive LED states" (page 19)
- "RAID controller LED states" (page 23)
- "When the 703t server does not boot and makes audible beeps" (page 29)
- "When the 703t server boots to the operating system and makes audible beeps" (page 30)

What to do when the server fails to boot into service

The following sections suggest tasks you can perform to determine why the 703t server fails the bootup cycle.

To investigate server boot problems

Step	Action
1	Ensure that you accurately record any diagnostic codes and error messages that occur.
2	Try restarting the server by pressing the power button on the server.
3	During the boot sequence, view the diagnostic codes on the monitor for failures. Note: Allow 5 minutes for the boot cycle to complete.
4	If errors indicate a hardware problem with a failure to boot to the operating system or if the server boots to the operating system, but fails to boot into CallPilot, refer to the <i>CallPilot Troubleshooting Guide</i>
5	If you still cannot find the cause of the boot failure after performing the tasks described in the following sections, call your Nortel technical support representative.

—End—

When the 703t server does not boot and there are no audible beeps**To check why server fans are not turning when server does not boot**

Step	Action
1	Ensure that the power cord is properly connected into an electrical outlet.
2	If the problem continues, ensure that there is power to the electrical outlet.

—End—

To check why server does not boot with fans turning

Step	Action
1	Ensure that the monitor is turned on.
2	If the problem continues, ensure that the internal power supply to the boards is connected correctly.

—End—

When the 703t server does not boot and the system board LED is red

If the right-most status LED on the front of the 703t server is red, this is usually due to failure of the Board Management Controller.

The most likely cause is changing boards without completely powering down the 703t server and disconnecting the power cable.

To check why server does not boot and system board LED is red

Step	Action
1	Shut down the 703t server
2	Disconnect the power cable.
3	Wait 1 minute.
4	Reconnect the power cable and attempt to restart the 703t server.
5	If the problem continues, contact your Nortel technical support representative for assistance.

—End—

When the 703t server does not boot and makes audible beeps If beeps are short

If the beeps are short in length, they are from the system board.

Typically, you will not see any video displayed on the monitor, and the right-most status LED on the front of the 703t server will show a blinking or steady amber.

To check why server does not boot and makes beeps

Step	Action
1	Make a note of the number of beeps and any error messages or POST codes.
2	Refer to "Bootblock error beep codes" (page 25) and "Bootblock error 3-beep codes" (page 26) , and use the collected information to identify the cause of the failure.
3	Replace any component that is indicated as faulty.

—End—

If beeps are long

If the beeps are a series of high-pitched, long beeps, they are from the RAID system.

Typically, you will see messages displayed on the monitor indicating that the system is in a critical state.

Step	Action
1	Ensure that internal hard drive cables are properly connected.
2	If the problem continues, RAID BIOS may be corrupted.
3	If the problem continues, the drive is faulty. Replace the hard drive as described in "Replacing a faulty hard drive" (page 102) .

—End—

When the 703t server boots to the operating system and makes audible beeps

If the 703t server boots to the operating system but still makes audible beeps, one of the hard drives is in critical condition.

To check if server has a hard drive in critical condition

Step	Action
1	Rebuild the hard drive as soon as the operating system has finished loading. Refer to "RAID splitting" (page 129).

—End—

When the 703t server boots to the operating system but does not boot to CallPilot

If the 703t server does not boot to CallPilot, it may be due to the failure of a multimedia board.

To check if multimedia board has failed

Step	Action
1	Check the diagnostic screen that is displayed immediately after you reboot the system, and view the event logs. For instructions, see "Viewing event logs" (page 32).
2	If the diagnostic or event log information indicates failure of a multimedia board, replace the card as described in "Replacing MPB96 boards" (page 138).
3	If the diagnostic or event log information does not indicate failure of a multimedia board, a software failure is the likely cause. Refer to <i>the Software Administration and Maintenance Guide</i> (NN44200-600) for instructions on how to reinstall software.

—End—

Chapter 4

Using Windows online diagnostic tools

In this chapter

"Overview" (page 31)

"Viewing event logs" (page 32)

"Using TCP/IP diagnostic tools" (page 35)

"Using the chkdsk utility" (page 42)

Overview

This section describes how to access the runtime online diagnostic tools provided by the Windows server software. Use these tools when a serious problem prevents the use of the CallPilot diagnostic tools that are available in CallPilot Manager.



CAUTION

Do not run any utilities that are not documented in this guide.

Operating system Event Viewer

The operating system Event Viewer provides event logs to help you diagnose and debug system problems.

TCP/IP diagnostics

The following TCP/IP diagnostic tools are described in this chapter:

- ipconfig on "The ipconfig command" (page 36)
- ping on "The ping command" (page 36)
- tracert on "The tracert command" (page 38)
- arp on "The arp command" (page 39)

- nbtstat on "[The nbtstat command](#)" (page 40)
- netstat on "[The netstat command](#)" (page 41)

These utilities help you to verify network connectivity. They help you to thoroughly test the network interface and isolate any configuration problems. Network connectivity is essential to CallPilot operation.

chkdsk utility

The chkdsk utility checks a specified disk on the server and displays a status report. It is an online utility, but it reduces system performance while it is running.

Viewing event logs

When the server startup cycle is complete, and if the CallPilot server has been configured (refer to the *Installation and Configuration Task List* (NN44200-306), messages in dialog boxes on the monitor indicate that CallPilot is ready to accept calls.

If one or more messages appears on the monitor, the message may contain information about an event, or a fault may have occurred. To determine what happened, you can use the following:

- operating system Event Viewer on the 703t server
- CallPilot Event Browser or Alarm Monitor in CallPilot Manager

Note: The Event Browser and Alarm Monitor include online Help for events, which may help you to resolve the problem. If you cannot log on to the CallPilot system using a web browser due to server problems, then use the Event Viewer.

Types of event logs

Three types of event logs are available from the Event Viewer, as follows:

Log type	Description
System	Logs events by Windows components, including RRAS or other Windows services.
Security	Logs security events, such as logons, logoffs and illegal access. This option is available only to users with Administrative access.
Applications	Logs events by application, such as database file errors.


To use the operating system Event Viewer

Step	Action
------	--------



- | | |
|---|---|
| 1 | Click Start → Programs → Administrative Tools → Event Viewer. |
|---|---|

Result: The Event Viewer window appears.

Event viewer window



- | | |
|---|---|
| 2 | To view a log, click the name of the log in the left frame of the window. |
|---|---|

Application Log.**System log.**

Note: The Security log available only to administrators is not shown.

- 3 Look for error codes flagged with either of the following icons that have occurred since the last startup.. that have occurred since the last startup.



Note: Each error is date and time stamped. . . .



Indicates major or critical errors



Indicates minor errors



Indicates information

- 4 To determine the cause of the error, select and then double-click the error.

Result: A description of the error appears in an Event detail dialog box. Use the description to help determine how to resolve errors.

Note: If the error persists or does not suggest a solution, contact your Nortel support representative.

- 5 Click **OK**.

Result: The event log reappears.

- 6 Click **File** → **Exit**.

Result: The Event Viewer closes.

—End—

Using TCP/IP diagnostic tools

This section describes the following TCP/IP diagnostic tools available for the network adapter:

- ipconfig
- ping
- tracert
- arp
- nbtstat
- netstat

These utilities help you to verify network connectivity, test the network interface, and isolate configuration problems.

The **ipconfig** command

The **ipconfig** command displays IP configuration information.

Ipconfig default

If you run the command without flags, it displays the IP address, subnet mask, and default gateway for each adapter bound to TCP/IP.

Ipconfig command syntax

ipconfig [/]

The following flags are available for the **ipconfig** command:

Flag	Description
/?	Displays Help information.
/all	Displays full configuration information.
/release	Releases the IP address for the specified adapter.
/renew	Renews the IP address for the specified adapter.

To run the **ipconfig** command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type ipconfig <i><with appropriate parameters></i> . Example: ipconfig /all
3	Press Enter. Result: The system runs the ipconfig utility.
4	Type Exit to exit the Command Prompt window and return to Windows.
—End—	

The **ping** command

The **ping** command sends an echo request to a specified host. Use this command to verify network connectivity to the remote device.

Ping command syntax

The ping command uses the following syntax:

```
ping [-t] [-a] [-n count] [-l size] [-f] [-i TTL]
      [-v TOS] [-r count] [-s count]
      [[-j host-list] | [-k host-list]]
      [-w timeout] destination-list
```

Ping command parameters

Parameter	Description
-t	Pings the specified host until interrupted.
-a	Resolves addresses to host names.
-n count	Specifies the number of echo requests to send.
-l size	Sends buffer size.
-f	Sets Don't Fragment flag in packet.
-i TTL	Sets Time-To-Live
-v TOS	Sets Type Of Service
-r count	Records route for count hops
-s count	Shows time stamp for count hops
-j host-list	Shows loose source route along host list
-k host-list	Shows strict source route along host list
-w timeout	Sets time-out in milliseconds to wait for each reply

To run the ping command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type ping <destination IP address> (for example, ping 200.286.32.0), or ping <computer name> .
3	Press Enter. Result: The system displays the ping results.
4	Type Exit to exit the Command Prompt window and return to Windows.
—End—	

The tracert command

This utility determines the route taken to a destination.

How tracert works

The tracert utility follows several steps to complete its task:

- Tracert sends Internet Control Message Protocol (ICMP) echo packets with varying Time-To-Live (TTL) values to the destination.
- Each router along the path must decrement the TTL on a packet by at least one before forwarding it, so the TTL is effectively a hop count.
- When the TTL on a packet reaches zero, the router sends back an ICMP Time Exceeded message to the source system.
- Tracert determines the route by sending the first echo packet with a TTL of one, and incrementing the TTL by one on each subsequent transmission until the target responds, or the maximum TTL is reached.
- Tracert then examines the ICMP Time Exceeded messages sent back by intermediate routers.

Tracert syntax

The tracert command uses the following syntax:

```
tracert [-d] [-h maximum_hops] [-j host_list]
        [-w timeout] target_name
```

Tracert parameters

Parameter	Description
-d	Specifies not to resolve addresses to hostnames.
-h maximum_hops	Specifies the maximum number of hops to search for the target.
-j host-list	Specifies a loose source route along the host list.
-w timeout	Waits the number of milliseconds specified by the time-out for each reply.
target_name	Shows the name of the target host.

To run the tracert command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type the following command:

```
tracert [-d] [-h maximum_hops] [-j host_list] [-w
timeout] [target_name]
```

Example: tracert 200.286.0.32

- 3 Press Enter.

Result: The system runs the tracert utility.

- 4 Type **Exit** to exit the Command Prompt window and return to Windows.

—End—

The arp command

The arp command displays and modifies the IP-to-physical address translation tables used by Address Resolution Protocol (arp).

Arp command syntax

The arp command uses the following syntax:

```
arp -s inet_addr eth_addr [if_addr]
```

```
arp -d inet_addr [if_addr]
```

```
arp -a [inet_addr] [-N if_addr]
```

Arp parameters

Parameter	Description
-a	Displays current arp entries by interrogating the current protocol data. If inet_addr is specified, the IP and physical addresses for only the specified computer appear. If more than one network interface uses arp, entries for each arp table appear.
-g	Same as -a.
inet_addr	Specifies an Internet address.
if_addr	Specifies the Internet address of the interface whose address translation table should be modified. If not present, the first applicable interface is used.
eth_addr	Specifies a physical address.
-N if_addr	Displays the arp entries for the network interface specified by if_addr.

Parameter	Description
-d	Deletes the host specified by inet_addr.
-s	Adds the host and associates the Internet address inet_addr with the Physical address eth_addr. The physical address is given as six hexadecimal bytes separated by hyphens. The entry is permanent.

To run the arp command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type arp with the required parameters (for example, arp -g 200.286.0.32).
3	Press Enter. Result: The system runs the arp command. Type Exit to exit the Command Prompt window and return to Windows.
—End—	

The nbtstat command

The nbtstat command displays protocol statistics and current TCP/IP connections using NBT.

Nbtstat command syntax

The nbtstat command uses the following syntax:

```
nbtstat [-a remotename] [-A IP address] [-c] [-n]
        [-R] [-r] [-S] [-s] [interval]
```

Nbstat parameters

Parameter	Description
-a remotename	Lists the remote computer's name table using its name.
-A IP address	Lists the remote computer's name table using its IP address.
-c	Lists the contents of the NetBIOS name cache giving the IP address of each name.

Parameter	Description
-n	Lists local NetBIOS names. Registered indicates that the name is registered by broadcast (Bnode) or WINS (other node types).
-R	Reloads the LMHOSTS file after purging all names from the NetBIOS name cache.
-r	Lists name resolution statistics for Windows networking name resolution. On a Windows computer configured to use WINS, this option returns the number of names resolved and registered through broadcast or through WINS.
-S	Displays both client and server sessions, listing the remote hosts by IP address only.
-s	Displays both client and server sessions, and attempts to convert the remote host IP address to a name using the HOSTS file.
interval	Displays selected statistics, pausing interval seconds between each display. Press Ctrl+C to stop displaying statistics. Without this parameter, nbtstat prints the current configuration information once.

To run the nbtstat command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type nbtstat with the required parameters.
3	Press Enter. Result: The system runs the nbtstat utility. Type Exit to exit the Command Prompt window and return to Windows.
—End—	

The netstat command

The netstat command displays current TCP/IP network connections and protocol statistics.

Netstat command syntax

The netstat command uses the following syntax:

```
netstat [-a] [-e] [-n] [-s] [-p proto] [-r] [interval]
```

Netstat parameters

Parameter	Description
-a	Displays all connections and listening ports.
-e	Displays Ethernet statistics. This can be combined with the -s option.
-n	Displays addresses and port numbers in numerical form.
-s	Displays per-protocol statistics.
-p proto	Shows connections for the protocol specified by proto. Proto can be tcp or udp. If used with the -s option, proto can be tcp, udp, or ip.
-r	Displays the contents of the routing table.
interval	Redisplays selected statistics, pausing between each display. Press Ctrl+C to stop redisplaying.

To run the netstat command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type netstat with the required parameters.
3	Press Enter. Result: The system runs the netstat utility.
4	Type Exit to exit the Command Prompt window and return to Windows.
—End—	

Using the chkdsk utility

The chkdsk utility checks a specified disk on the server and displays a status report. It can be run on drives C, D, E, or F. It is an online utility, but it reduces system performance while it is running.

The chkdsk utility checks for problems at the Windows file system level. Any problems existing at this level can cause problems for CallPilot. Even if there are no problems at the Windows file system level, CallPilot can still be affected by problems at the CallPilot file system level.

Note: A version of this utility, called autocheck, automatically runs during Windows startup. Output from this utility appears on the blue startup screen.

Chkdsk utility syntax

The chkdsk utility uses the following syntax:

```
chkdsk [drive:] [path] filename] [/F] [/V] [/R]
```

Chkdsk parameters

Parameter	Description
drive:	Enter the drive letter of the drive that you want to check.
filename	Enter the names of files to check for fragmentation.
/F	Add this parameter to fix errors on the disk.
/V	Add this parameter to display the full pathname of every file on the disk.
/R	Add this parameter to locate bad sectors and to recover readable information.

To run the chkdsk utility from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type chkdsk <drive letter:> (for example, chkdsk c:).
3	Press Enter. Result: The system runs the chkdsk utility.
4	Type Exit to exit the Command Prompt window and return to Windows.
—End—	

Chapter 5

Using serial port diagnostic tools

In this chapter

"Overview" (page 45)

"Shutting down services" (page 45)

"Conducting TSTSERIO tests" (page 47)

"Conducting TSTSERIO tests with the loopback plug" (page 49)

"Restarting services" (page 49)

Overview

You may want to test the serial ports when remote access does not work.

This chapter describes how to run serial port diagnostics on the CallPilot server using the TSTSERIO command. Direct the TSTSERIO command to serial ports on the server after services on these ports have been shut down manually, as described in this chapter.

Shutting down services

This section describes how to shut down a service using a specific serial port. Use the following procedures before invoking the TSTSERIO local loopback tests.



CAUTION

By stopping the services on COM 1 or COM 2, you lose the support access feature.

**CAUTION**

By stopping the services on COM 2, you stop call processing on CallPilot.

Service to stop for COM 1 testing

-

Services to stop for COM 2 testing

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Stop command

Use the Net Stop command to stop a specified service on a serial port.

Net Stop command syntax

The Net Stop command uses the following syntax:

```
net stop "service_name"
```

ATTENTION

You must restart the services that you shut down through the Net Start command after running the diagnostic. For details, see ["Restarting services" \(page 49\)](#).

To invoke the Net Stop command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type net stop "service_name" , and then press Enter. Note: The quotation marks are required, as in the example above.

Result: The system runs the Net Stop command utility.

- 3 Type **Exit**, and then press Enter to exit the Command Prompt window.

—End—

Conducting TSTSERIO tests

The TSTSERIO command performs local loopback tests of the serial communication ports from the server runtime environment.

Note: Before conducting these tests, shut down the appropriate services. See ["Shutting down services" \(page 45\)](#).



CAUTION

By stopping the services on COM 1 or COM 2, you lose the support access feature.



CAUTION

By stopping the services on COM 2, you stop call processing on CallPilot.

TSTSERIO command syntax

The syntax for the TSTSERIO command is as follows:

TSTSERIO [/?] /P:comport [/S:substname] [/L:loops]

Flag	Requirement	Description
?	n/a	Displays Help.
/P:comport	Required	Specifies the symbolic port name assigned to the port you want to test.
/S:substname	Optional	Specifies a TSTSERIO subtest. See the table below for a description of the available subtests.
/L:loops	Optional	Specifies the number of times (up to a maximum of 65 535) to execute the requested test. The default number of tests is 1. A value of 0 infinitely loops until you enter Ctrl+C.

TSTSERIO internal loopback diagnostic subtests

The following internal loopback subtests are available for the TSTSERIO command. For each of these tests, the communications resource must be available:

Subtest name	Description
idat	Internal data bus loopback
imsr	Internal modem status register
baud	Internal data bus loopback at various baud rates
word	Test 5-, 6-, 7-, and 8-bit data lengths
stop	Test 1, 1.5, and 2 stop bits
pari	Test odd/even parity
fifo	Test that device can operate in fifo mode

To invoke the TSTSERIO /P command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type <code>tstserio</code> with the required parameters, and then press Enter. For example, type <code>TSTSERIO /P com1</code> or <code>TSTSERIO /P com 2</code> , and then press Enter.
3	Type <code>Exit</code> , and then press Enter to exit the Command Prompt window.
—End—	

TSTSERIO external loopback plug subtests

The following external loopback subtests are available for the TSTSERIO command. For each of these tests, an external loopback connector must be used. For more information, see ["Conducting TSTSERIO tests with the loopback plug"](#) (page 49).

Subtest name	Description
edat	External data bus loopback. This test requires an external loopback connector.

Subtest name	Description
emsr	External modem status register. This test requires an external loopback connector.
eint	Test ability of device to generate interrupts. This test requires an external loopback connector.

To invoke the TSTSERIO /S command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type <code>tstserio</code> with the required parameters, and then press Enter. For example, type <code>TSTSERIO /P com1 /S extr</code> , and then press Enter.
3	Type <code>Exit</code> , and then press Enter to exit the Command Prompt window.
—End—	

Conducting TSTSERIO tests with the loopback plug

The TSTSERIO command requires an external loopback connector plug for its edata, emsr, and eint subtests.

9-pin connector plug

The standard serial loopback connector is a female 9-pin D-sub connector. This connector has the following pins wired together:

- CTS (pin 8) wired to (pin 7) RTS
- SIN (pin 2) wired to (pin 3) SOUT
- DTR (pin 4) wired to (pin 6) DSR

Once the plug is installed on the serial port, TSTSERIO can be invoked according to the ["To invoke the TSTSERIO /P command from Windows"](#) (page 48).

Restarting services

This section describes how to restart the services for COM 1 or COM 2 after invoking the TSTSERIO local loopback tests.

Service to restart after COM 1 testing**Services to restart after COM 2 testing**

- CallPilot SLEE Service
- CallPilot MWI Service
- CallPilot Access Protocol Emulator
- CallPilot Blue Call Router
- CallPilot Call Channel Router
- CallPilot Time Service
- Routing and Remote Access

Net Start command

Use the Net Start command to restart a specified service on a serial port.
The syntax for the Net Start command is as follows:

```
net start "[service-name]"
```

To invoke the Net Start command from Windows

Step	Action
1	Click Start → Programs → Accessories → Command Prompt. Result: The Command Prompt window appears.
2	At the Command prompt, type <code>net start "service_name"</code> , and then press Enter. Note: The quotation marks are required, as in the example above.
3	Type <code>Exit</code> , and then press Enter to exit the Command Prompt window.
—End—	

Chapter 6

Using CallPilot Manager to monitor hardware

In this chapter

"Understanding fault management" (page 51)

"Alarm Monitor" (page 53)

"Event Browser" (page 55)

"Channel and Multimedia Monitors" (page 57)

"The Maintenance page" (page 57)

"Viewing component states" (page 60)

"Starting and stopping components" (page 62)

"Running integrated diagnostics" (page 64)

"Viewing the last diagnostic results" (page 66)

"Working with the Multimedia Monitor" (page 67)

"Working with the Channel Monitor" (page 69)

Understanding fault management

Fault management is a term that describes how the CallPilot server detects and notifies you of potential or real hardware problems (faults). The server processes events to detect hardware problems and raises alarms to notify you when these problems occur.

Event processing

An event is any change in system configuration or operational state. An event is also any action taken by the system that requires user notification. Events can be as insignificant as a user logon attempt or as serious as a faulty MPB switching to disabled status.

All events are reported to the fault management server, a subsystem within the CallPilot server. The fault management server enables the server to listen and respond to its clients. The interaction is called event processing and is the means by which the server detects hardware faults.

Alarm notification

Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events.

When an alarm appears in the Alarm Monitor, you must investigate the problem, isolate it, and then fix the cause of the problem. When you fix the problem, ensure that the alarm is cleared from the Alarm Monitor.

Note: You may be required to clear the alarm manually.

Component dependencies

The status of some components is dependent on the operational status of other components. If a component fails or is stopped, the dependent components go out of service.

Note: Based on the CallPilot server type, and the type of switch connected to CallPilot, some of these components may not appear on your system.

Component	Dependent components
Media Bus	All MPBs and all multimedia and call channels.
MPB board	All multimedia and call channels associated with the MPB board.
Time Switch	All multimedia and call channels associated with the same MPB as the time switch.
DS30X	All DS30X channels associated with the DS30X link.

Detecting hardware problems

Typically, you first become aware of a hardware problem when an alarm is raised. All hardware faults produce an alarm (or series of alarms, depending on the problem) in the Alarm Monitor. Other indications of a hardware problem include the following:

- user complaints
- call processing difficulties, such as busy signals, static, dropped calls, connection problems, and cross talk (hearing other conversations)
- system administrator logon difficulties
- alert icons on the Maintenance screen

Alarm Monitor

Use the Alarm Monitor to investigate one or more raised alarms.

About alarms


Alarms are warnings generated by events. Alarms communicate the same information as events. However, alarms are reported in the Alarm Monitor instead of the Event Browser, and are managed differently than events:

- Alarms appear in the Alarm Monitor only for Minor, Major, and Critical events (not Information events). All events can be reported in the Event Browser (depending on filtering criteria defined in the Event Browser).
- The first time an event occurs, it generates an alarm that appears in the Alarm Monitor. If the same event continues to occur, a new alarm is not generated. Instead, the time and date assigned to the original generated alarm is updated.
- Alarms can be cleared from the Alarm Monitor, but the event that generated the alarm is not cleared from the event log or the Event Browser.

Each alarm in the Alarm Monitor has Help text that often provides a solution to the problem. If the solution is not apparent, use the Event Browser or the Maintenance screen to further investigate the problem.

To investigate using the Alarm Monitor

Step	Action
1	Run CallPilot Manager and log in.
2	In CallPilot Manager, click System → Alarm Monitor.
Result: The Alarm Monitor window appears.	

Alarm monitor

- 3 Click the Event Code for the first critical or major alarm.
Result: A description of the event appears in a new web browser window.
- 4 Review the description and recovery action.
- 5 Repeat steps 3 and 4 for a more alarms, if necessary.
- 6 If the solution to the problem is not apparent, obtain the return code of the first event and continue the investigation by using the Event Browser (see "Event Browser" (page 55)).

—End—

Note: For information on how to use the Alarm Monitor, refer to the *Administrator's Guide* (NN44200-601), or the CallPilot Manager online Help.

Event Browser

Use the Event Browser to investigate a series of events that occurred around the time an alarm was raised. The event listing can help you determine the root cause of a problem.

About events


The Event Browser displays events that have been recorded in the server log. Each event identifies the time the event occurred, the object that generated the event, and the cause of the event.

Events are classified as Information, Minor, Major, or Critical. By default, the Event Browser displays only the latest 100 critical events.

Note: Nortel recommends that you change the Event Browser filter criteria to display Minor and Major events as well. Minor and Major events can indicate significant system problems.

To investigate using the Event Browser

Step	Action
1	Run CallPilot Manager and log in.
2	In CallPilot Manager, click System → Event Browser.
Result: The Event Browser window appears	

Event browser

- 3 Click an event that appears to be related to the problem, or an event that occurred near the time the alarm was raised.

Result: A description of the event appears in a new web browser window.

- 4 View the description and recovery action.
- 5 Repeat steps 3 and 4 for more events, if necessary.
- 6 If the solution to the problem is not apparent, contact your Nortel technical support representative.

—End—

Note: For information on how to use the Event Browser, refer to the *Administrator's Guide* (NN44200-601), or the CallPilot Manager online Help.

Channel and Multimedia Monitors

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.

Disabling call channels

If you must take the CallPilot system out of service to perform software or hardware maintenance, Nortel recommends that you disable all call channels first. There are two ways to disable the call channels:

- Courtesy stop the channels (preferred method).

When you courtesy stop call channels, CallPilot waits until the channels are no longer active before disabling them, instead of suddenly terminating active calls.

- Stop the channels.

When you stop channels, you suddenly disable them and terminate all active calls.

The Maintenance page


Use the Maintenance page in CallPilot Manager to do the following:

- Obtain general information about components.
- View component states.
- Start and stop components.
- Run integrated diagnostic tests.
- View the results of the last diagnostic test run against a component.

What the Maintenance page provides

The Maintenance page identifies the server platform and switch connectivity type. It also provides a tree that, when expanded, lists the physical and logical hardware components down the left side of the screen. To list the server hardware components, click the plus sign (+) at the top of the tree. To list the subcomponents for each component, click the plus sign (+) beside the component.

Note: The components that are listed on the Maintenance page are based on the CallPilot server type and the switch that is connected to CallPilot. The examples in this chapter are for illustration purposes and may not appear exactly the same on your system.

Partially expanded tree for the 703t server:

When you click a component, the page refreshes to show the details about that component. ("Partially expanded tree for the 703t server:" (page 58) shows details about a Channel.)

Maintenance page section details

Section	Description
General	This section shows general technical information about the selected component. This typically includes the following details: - the name, class, type, series, or version of a CallPilot server - various capabilities of a component (for example, whether a component is removable)

Note: This section does not appear for all components.

Section	Description
Maintenance	This section shows the state of the selected component. Use this section to start and stop a component before running a diagnostic test. This section appears only for components on which you are allowed to perform maintenance administration. For more information about working with component states, see the following sections: • "Viewing component states" (page 60) • "Starting and stopping components" (page 62)
Diagnostics	Use the Diagnostics section to run one or more diagnostic tests, or to view the results of the last diagnostic tests that were run on the selected component. This section appears only for components on which you are allowed to run diagnostics. For more information about running diagnostics, see the following sections: • "Running integrated diagnostics" (page 64) • "Viewing the last diagnostic results" (page 66)

Maintenance activities for each component

["Maintenance activities" \(page 59\)](#) identifies the maintenance activities you can perform for each component listed in the component tree.

Maintenance activities

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable ?
Media Bus	Yes	No	No	No
MPB board	Yes	No	Yes	Yes
Time Switch	No	No	No	No
Multimedia channels	Yes	Yes	No	No

Note: The MGate card and DS30X cable are replaceable. If you are having problems with the DS30X link, determine if either one or both of those items are causing the problem and need to be replaced.

Component	Start, stop?	Courtesy stop?	Diagnostics available?	Replaceable ?
Call channels	Yes	Yes	No	No
DS30X link	Yes	No	No	No

Note: The MGate card and DS30X cable are replaceable. If you are having problems with the DS30X link, determine if either one or both of those items are causing the problem and need to be replaced.

Viewing component states

View a component state to determine the general condition of the component, including whether the component is disabled or off duty. The component state is shown in the Maintenance section of the Maintenance screen.

Component states

You can determine the state of a component by looking at the State box in the Maintenance section.

State	Description
Active	The component is working and currently involved in processing a call.
Disabled	The diagnostic failed.
Idle	The component is working but not currently involved in processing a call.
InTest	A diagnostic is running on the component.
Loading	The component has been started, which takes it out of the Off Duty state.
	This state occurs quickly and is immediately followed by Idle.
No resources	The hardware required for the component to operate is not installed or is not operating properly.
Not Configured	The component is not configured in CallPilot.
	For example, a multimedia channel is not being used because it was not allocated in the Configuration Wizard.
Off Duty	The component has been stopped.
Remote Off Duty	The component has been taken out of service at the switch.

State	Description
Shutting Down	The component is in the process of stopping. This state occurs quickly and is immediately followed by Off Duty.
Uninitialized	The call processing component has not initialized the resource.

Alert icons

If one of the following icons appears next to a component in the tree, then the component or one of its subcomponents is experiencing a problem:

Icon	Description
	A problem exists with a subcomponent of the selected component. Expand the tree to locate the subcomponent with the problem.
	A problem exists with the selected component.

To view the state of a hardware component

Step	Action
1	Run CallPilot Manager and login.
2	In CallPilot Manager, click Maintenance → Maintenance Admin. Result: The Maintenance screen appears.
3	Click the plus sign (+) beside the CallPilot server to expand the component tree.
4	Continue clicking the plus sign (+) until the component with which you want to work is visible.
5	Click the hardware component with which you want to work. Result: The Maintenance screen refreshes to show details about the component.
6	Scroll down to the Maintenance section.
7	View the state of the selected component in the State box.
—End—	

Starting and stopping components

When you stop a component, you take it out of service and prevent it from operating. You must stop a component before you can replace it (if the component is replaceable) or run a diagnostic test on it.

To bring an out-of-service component back into service, you must start it.

Start and stop components from the Maintenance section on the Maintenance screen.

ATTENTION

Nortel recommends that, if possible, you courtesy stop a component. Courtesy stop is available only at the individual channel level.

To courtesy down CallPilot, use the following:

- Multimedia Monitor - to courtesy stop a range of multimedia channels
- Channel Monitor - to courtesy stop a range of call channels:
 - DS30X channels (also known as DS0 channels)

Stop versus Courtesy stop

The following two methods of taking a component out of service allow you to choose how active calls are affected:

Courtesy stop

A Courtesy stop is the recommended way to take the component out of service only after the component has finished processing an active call. Courtesy stop is preferred over a regular Stop.

- If the component is processing a call, the call is not dropped; the component remains active until the call is finished.
- If the component is not in use, it is taken out of service immediately.

Stop

A Stop takes the component out of service immediately, regardless of whether the component is currently processing calls. All active calls are dropped. Perform a Stop only when severe problems affecting a large number of incoming calls occur or if your organization determines a special need for it.

Components that can be started and stopped

The following components can be started and stopped when connected to a Meridian 1* or CS 1000* switch:

Note: If you want to start or stop more than one or two multimedia or call (DS30X) channels, use the Multimedia Monitor or Channel Monitor. For instructions, see "[Channel and Multimedia Monitors](#)" (page 57).

Component	Effect of stopping
Media Bus	Takes all call processing resources out of service.
MPB board	Takes all call processing resources on the selected board out of service.
Time Switch	You cannot perform maintenance administration on the time switch.
Multimedia Channel	Takes the selected Multimedia Channels out of service.
DS30X link	Takes the selected DS30X link and the channels that belong to that link out of service.
Channels	Takes the selected DS30X channel out of service.

To start or stop a component

Step	Action
1	Run CallPilot Manager and login.
2	In CallPilot Manager, click Maintenance → Maintenance Admin. Result: The Maintenance screen appears.
3	Click the plus sign (+) beside the CallPilot server to expand the component tree.
4	Continue clicking the plus sign (+) until the component with which you want to work is visible.
5	Click the hardware component that you want to start or stop. Result: The Maintenance screen refreshes to show details about the component.
6	Scroll down to the Maintenance section.
7	Click Courtesy Stop, Stop, or Start as required.
—End—	

Button	Description
Start	If the selected component is out of service, click this button to put it into service.
Courtesy Stop	Click this button to take the selected component out of service. CallPilot waits for the call to be completed before disabling the component.

ATTENTION

If you are courtesy stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed.

The system asks you to confirm the Courtesy stop. If you click OK, the component is put out of service after all calls are finished.

Stop	Click this button to take the selected component out of service immediately. All calls that are in progress are disconnected immediately.
------	---

ATTENTION

If you are stopping all components (that is, you are taking the entire system down), ensure that you inform all administrators, desktop messaging users, and web messaging users so that they can log off their sessions before you proceed.

Running integrated diagnostics

Run diagnostic tests from the Diagnostics section on the Maintenance screen in the following circumstances:

- You want to ensure that a component is operating properly after installing or reinstalling it.
- The CallPilot server has trouble processing incoming calls, and you hope that diagnostic results can tell you why.

Problems include static, dropped calls, and cross talk (hearing another conversation).

Before you begin

ATTENTION

Take the component out of service before you run the diagnostic test. See ["Starting and stopping components" \(page 62\)](#).

Diagnostic tests available for each component

The diagnostic tests that are available for each component are listed in the Diagnostic section of the Maintenance screen. To view the list of diagnostic tests for a particular component, click the component in the component tree.

Components that have diagnostic tests available

The following table identifies the components on which you can run diagnostics when connected to a Meridian 1 switch or Communication Server 1000.

Diagnostics tests available for components

Component	Diagnostics available?	Replaceable?
Media Bus	No	No
MPB board	Yes	Yes
Time Switch	No	No
Multimedia Channels	No	Yes (via MPB96 board)
DS30X link	No	No
Channels	No	No

If a diagnostic test fails or cannot be run

If a warning message appears, the diagnostic test cannot be run because a prerequisite condition has not been met. If a diagnostic test fails, a message appears in a new browser window (see the example on page [step 9](#)).

In both cases, check the Alarm Monitor to determine the reason and the appropriate action to take.

If the Alarm Monitor and Event Browser do not provide a solution to a hardware problem, you may need to replace or service a component. If the problem is with a component that is not replaceable because it is not a physical entity (such as the Time Switch), you must either replace its parent component or contact your Nortel technical support representative, depending on the component.

To run a diagnostic test

ATTENTION

Nortel recommends that you courtesy stop rather than stop a component if possible. For instructions, see ["Starting and stopping components" \(page 62\)](#).

Step	Action
1	Run CallPilot Manager and log in.
2	In CallPilot Manager, click Maintenance → Maintenance Admin. Result: The Maintenance screen appears.
3	Click the plus sign (+) beside the CallPilot server to expand the component tree.
4	Continue clicking the plus sign (+) until the component with which you want to work is visible.
5	Click the hardware component for which you want to run diagnostics. Result: The Maintenance screen refreshes to show details about the component.
6	Scroll down to the Maintenance section, and ensure that the component is out of service. Note: For instructions on taking the component out of service, see "To start or stop a component" (page 63) .
7	Scroll down to the Diagnostics section.
8	Check the check box for each diagnostic that you want to run. Note: If you want to run all of the diagnostics, check the Diagnostic Description check box at the top of the list.
9	Click Run. Result: A new web browser window opens to display the progress and results of the diagnostics. The Diagnostic Results box in the Diagnostics section displays diagnostic results when you click Get Last Result.

—End—

Viewing the last diagnostic results

You can review the results of previously run diagnostics by clicking the Get Last Results button for a component.

To view the last diagnostics result

ATTENTION

Nortel recommends that you *courtesy stop* rather than stop a component if possible. For instructions, see ["Starting and stopping components" \(page 62\)](#).

Step	Action
1	Run CallPilot Manager and log in.
2	In CallPilot Manager, click Maintenance → Maintenance Admin. Result: The Maintenance screen appears.
3	Click the plus sign (+) beside the CallPilot server to expand the component tree.
4	Continue clicking the plus sign (+) until the component with which you want to work is visible.
5	Click the hardware component for which you want to run diagnostics. Result: The Maintenance screen refreshes to show details about the component.
6	Scroll down to the Diagnostics section.
7	Check the check box for each diagnostic for which you want to review results.
8	Click Get Last Result. Result: The results appear in the Diagnostic Results box with the following information: • diagnostic title • diagnostic result: pass or fail • the date and time the test was completed

—End—

Working with the Multimedia Monitor

The Multimedia Monitor shows the status of multimedia channels. The multimedia channels are the DSP ports that process the calls. They are the voice, fax, and speech recognition channels.


To view or work with multimedia channel states

Step	Action
------	--------

- | | |
|---|---|
| 1 | Run CallPilot Manager and log in. |
| 2 | In CallPilot Manager, click Maintenance → Multimedia Monitor. |

Result: The Multimedia Monitor screen appears, showing the channels associated with each DSP

Multimedia Monitor.



Note: For an explanation of the channel states, refer to the CallPilot Manager online Help.

- 3 Do one of the following:

IF you want to stop or start	THEN
------------------------------	------

all of the channels associated with a DSP	check the check box to the left of the DSP that you want to stop or start.
---	--

IF you want to stop or start	THEN
	Repeat this step for each DSP.
only one or several channels that are associated with a DSP	check the check box for each channel that you want to stop or start.

- 4 Click Courtesy Stop, Stop, or Start as required.

Result: If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to idle or on-duty status, according to the action you chose.

If the buttons are not available, wait a few seconds for the screen to refresh:

- The Start button is available only when a component is in the Idle state.
- The Courtesy Stop and Stop buttons are available only when a component is in one of the following states: Idle, Active, Remote Alarm, Local Alarm.

—End—


Working with the Channel Monitor

The Channel Monitor shows the status of call channels. The call channels are the connections between the server and the switch that carry the call signals to CallPilot.

To view or work with call channel states

Step	Action
1	Run CallPilot Manager and log in.
2	In CallPilot Manager, click Maintenance → Channel Monitor.
	Result: The Channel Monitor screen appears, showing the channels associated with each link.

Channel Monitor



Note: For an explanation of the channel states, refer to the CallPilot Manager online Help.

3 Do one of the following:

IF you want to stop or start

all of the channels associated with a link

THEN

check the check box to the left of the link that you want to stop or start.

Repeat this step for each link.

only one or several channels that are associated with a link

check the check box for each channel that you want to stop or start.

4 Click Courtesy Stop, Stop, or Start, as required.

Result: If you clicked Courtesy Stop or Stop, you are asked to confirm the Courtesy Stop or Stop. Click OK.

The selected channels change to idle or on-duty status, according to the action you chose.

If the buttons are not available, wait a few seconds for the screen to refresh:

- The Start button is available only when a component is in the idle state.
- The Courtesy Stop and Stop buttons are available only when a component is in one of the following states: Idle, Active, Remote Alarm, Local Alarms.

—End—

Chapter 7

Using CallPilot system utilities

In This chapter

"Overview" (page 73)

"Diagnostics Tool" (page 74)

"PEP Maintenance utility" (page 75)

"Session Trace" (page 75)

"System Monitor" (page 77)

Overview

CallPilot system utilities

Utility	Description
Diagnostics Tool	Allows CallPilot startup diagnostics to be enabled or disabled (turned on or off).
PEP Maintenance	Displays a list of installed PEPs and enables PEP uninstall.
Session Trace	Provides detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI).
System Monitor	Displays the following information: • the status of all CallPilot channels • the status of all CallPilot services. Note that this status is more accurate than the status that Windows provides in the Services control panel.

Utility	Description
	particulars about the CallPilot 5.0 system, such as names, keycodes, serial numbers, IP addresses, and system numbers

Accessing the system utilities

All CallPilot utilities are accessible from the CallPilot server in the Start → Programs → CallPilot → System Utilities menu.

Diagnostics Tool

The Diagnostics Tool allows you to enable or disable CallPilot startup diagnostics. CallPilot startup diagnostics automatically identify hardware problems that may exist when the system and its services are started. Diagnostics are displayed for:

- Media Bus, MPB board, MPC/DSP
(for Meridian 1 and Communication Server 1000)

When you disable startup diagnostics, you can save time during system maintenance operations where restarts or Call Processing services restarts are required.

There are three recommended steps:

Step	Action
1	Use the Diagnostics Tool to turn off CallPilot startup diagnostics.
2	Perform system maintenance.
3	Use the Diagnostics tool to turn on CallPilot startup diagnostics.
—End—	

To access the Diagnostics Tool

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → Diagnostic Tool.

Result: The Diagnostics Tool window appears.

To enable startup diagnostics

From the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Enable.

To disable startup diagnostics

ATTENTION

Nortel recommends that you leave the startup diagnostics turned on. When you disable CallPilot startup diagnostics, you prevent CallPilot from automatically identifying hardware problems that may exist when the system and its services are started.

On the Diagnostics Tool window, select Configuration → Maintenance Startup Diag → Disable.

PEP Maintenance utility

The PEP Maintenance utility displays a list of all installed PEPs on the server and enables you to uninstall PEPs. For information on installing or uninstalling PEPs, refer to the *Installation and Configuration Task List* (NN44200-306).

To access the PEP Maintenance utility

From the Windows desktop, click Start → Programs → CallPilot → System Utilities → PEP Maintenance Utility.

Result: The DMI Viewer window appears.

To view a list of all installed PEPs

Step	Action
1	Click the component for which you want to display the PEP list.
2	Click Show PEPs. Result: A list of all installed PEPs appears in the left pane.
3	If you want to review the readme file associated with a PEP, click the PEP, and then click Read. Result: The readme file opens in Notepad.
—End—	

Session Trace

The Session Trace tool displays detailed information about the activity in a user's mailbox and the state of the message waiting indicator (MWI). The session information includes

- voice messaging
- call answering

- express messaging activity (messages composed and sent, or left in a mailbox)
- the number of messages played or not played at the beginning, middle, and end of a session
- messages and personal distribution lists restored into a mailbox
- the last change to the MWI (turned on or off, or untouched)

This session information allows an administrator or technician to study the state of a user's mailbox and the MWI, and to use that information to follow up on any user complaints. For example, a user may report that the MWI was on, but no voice messages were in the mailbox when the user logged on. The session information can tell the administrator why the MWI was turned on.

To access the session trace tool


From the Windows desktop, click Start → Programs → CallPilot → System Utilities → Session Trace Tool.

Result: The MCE Session Trace window appears.

To find a session

Step	Action
1	From the Session Type drop-down menu, choose the type of session. To display a list of all session types, select All Session Types.
2	Enter as much information in the search criteria boxes to identify the session you want to view. To display a list of all users for the selected Session Type, leave the search criteria boxes blank.
3	Click Search to initiate the search. - If you did not enter any user information, a list of users matching the Session Type appears at the bottom of the window. To select a user from the list, double-click the user name to display session type information. - If you selected All Session Types for a user, the session type information appears to the right of the window.
4	Double-click the session type to display the session information. Result: The Session Type information appears at the bottom of the window. The following example shows Call Answering session type information.

Call Answering session Type



—End—

System Monitor

The System Monitor consists of three tabs, as described in the following table:

Tab	Description
Channel Monitor	Shows the status of all CallPilot services, multimedia channels, and call channels (DS30X channels in Meridian 1 and Communication Server 1000).
System Info	Displays details about the CallPilot 5.0 system, such as features purchased, keycode, serial number, and CallPilot server IP addresses.
Legend/Help	Provides a description of icons and terminology displayed in the System Monitor window.

System Monitor is a non-destructive tool that does not alter the behavior of any CallPilot components.


To access the System Monitor

On the Windows desktop, click Start → Programs → CallPilot → System Utilities → System Monitor.

Result: The CallPilot System Monitor window appears. By default, the Channel Monitor tab appears on top. Click the other tabs to view the information on those tabs.

Channel Monitor tab

Channel Monitor tab.



CallPilot services

The Service Name pane shows the status of services from a CallPilot perspective. The status shown in the Windows Services Control Panel may state that a service is running, but it may not actually be fully running or in service from a CallPilot perspective. Refer to the System Monitor tool Channel Monitor tab for the true status.

The services listed under Service Name should be either running or in full service when CallPilot is functioning optimally. If any CallPilot services are stopped, investigate the cause of this. If you need assistance, call Nortel technical support.

Note: While any stopped services should be investigated, some services are not critical. CallPilot may continue to handle call processing even with some services stopped.

The critical services that are needed for basic CallPilot call answering are listed in the following table. For your reference, the equivalent names as they appear in the Windows Control Panel are also listed.

CallPilot System Monitor	Windows Control Panel equivalent
CTMS Service	CTMS Server
Telephony (TAPI)	Telephony
MCE SLEE	CallPilot SLEE Service
MCE Notification	CallPilot MWI Service
MAS Notification	CallPilot Notification Service
MAS CCR	CallPilot Call Channel Router
MAS BCR	CallPilot Blue Call Router

CallPilot System Monitor	Windows Control Panel equivalent
SQL Anywhere	Adaptive Server Anywhere - %ComputerName%_SQLANY
MAS MltmediaCache	CallPilot Multimedia Cache
MAS MltmediaVol1	CallPilot Multimedia Volume 1
MAS MltmediaVol2 (TRP only)	CallPilot Multimedia Volume 2 (TRP only)
MAS MltmediaVol3 (TRP only)	CallPilot Multimedia Volume 3 (TRP only)
MAS Rsrc. Pckg. 1	CallPilot Resource Package1

DSPs

In the DSP pane, each DSP is represented in a separate row. Each box in the row is one DSP channel or multimedia channel. Click the Legend/Help tab to view descriptions of the multimedia channel icons.

On the 703t server, 12 DSPs are embedded on each MPB96 board.


DS30X links

In the DS30X link pane, each DS30 row represents a separate DS30X link (also referred to as a DS30 link). Each box in the row represents one DS30X channel.

The DS30X links connect the CallPilot server to the MGate card (NTRB18CA) in the Meridian 1 switch or Communication Server 1000 system.

System Info tab

System Info tab.



Note: The screen sample above was acquired from a 1001rp server, but provides the same type of information for any CallPilot server model.


The numbered items provide information about the features purchased. Information about the underlying operating system, including the server IP addresses, is provided in the top right corner.

PEP information and configured Service DNs are listed in the bottom part of the window.

Legend/Help tab

"Legend/Help tab" (page 80) shows the Legend/Help tab. Consult this tab for descriptions of the icons found in the Channel Monitor tab.

Legend/Help tab



Chapter 8

Replacing basic chassis components

In this chapter

"Preparing the server for hardware maintenance" (page 81)

"Removing the side cover" (page 84)

"Removing and replacing the upper fan holder foam" (page 86)

"Replacing the side cover" (page 88)

"Cooling fans description" (page 89)

"Replacing a front system fan" (page 92)

"Replacing a rear system fan" (page 95)

"Replacing the processor fan" (page 98)

Preparing the server for hardware maintenance



DANGER

Before you begin working inside the server, do the following:

1. Power off and disconnect all peripheral devices that are connected to the CallPilot server.
2. Power off the server and disconnect the power cord.

For more information, see ["Preparing the server for hardware maintenance" \(page 81\)](#).

**CAUTION**

- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Place hardware components on an antistatic surface until you are ready to install them.
- Do not touch the components or gold-edge connectors of cards or boards.

**CAUTION**

Place the server on its side to prevent the server from accidentally falling over. This position provides greater stability. If you attempt to work with the server in its standing position, it may tip over when you remove or insert components.

If the server is equipped with chassis feet, do one of the following:


- Remove the feet so that the server lies flat on the working surface. For more information, see ["Remove chassis feet" \(page 84\)](#).
- Place stable material beneath the server to raise the feet away from the working surface. The bottom of the server then lies flat on the working surface.
- Pull the server forward so that the feet hang over the edge of the working surface.

To disconnect the power and peripheral device cables

Before you access the server interior, do the following:


Step	Action
1	Courtesy stop and power off the server. For instructions, see "Starting up and shutting down the CallPilot server" in the <i>Installation and Configuration Task List</i> (NN44200-306).
2	Label and disconnect the power cable and any other peripheral cables that may be in your way. Refer to "Connectors on Server back plane" (page 83) to identify the connectors on the server's back panel.

Connectors on Server back plane



- 3 If desired, continue with "[Remove chassis feet](#)" (page 84).

Remove chassis feet



G101782

- 4 Place the server on it's side.
- 5 Remove the feet as shown in the above diagram.
- 6 Continue with ["Removing the side cover" \(page 84\)](#).

—End—

Removing the side cover

This section describes how to remove the server side cover so that you can work with interior components. The side cover is on the left side of the server when the server front panel is facing you.

To remove the side cover




WARNING

To prevent personal injury, use caution when you handle the sharp edges of the side cover and chassis.

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

"Remove server side panel" (page 85) shows how to remove the side cover. See the following instructions for removal.

Remove server side panel

G101761

Step Action

- 1 Turn the two thumbscrews on the back of the server counter-clockwise to loosen them.

Note: The thumbscrews are not removable.

If a removable screw is present, remove it. This screw secures the cover to the server during shipping.



CAUTION

Use an ESD wrist strap to protect static-sensitive components.


- 2 Place your fingertips in the depression on the side cover, and then, as you apply pressure, pull the cover approximately 2.5 cm (1 in.) away from the front of the server until it stops.
- 3 Use both hands to lift the cover away from the chassis.
- 4 Set the cover aside.

—End—

Removing and replacing the upper fan holder foam

The interior of the server contains two layers of fan holder foam, which secure and stabilize the cooling fans and add-in boards. The fan holder foam also maintains the space that is required between the boards for cooling. You may be required to remove the upper fan holder foam to access and work with some components.

Install fan holder foam



To remove the upper fan holder foam



CAUTION

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Remove the server side cover.
2	Lift the upper fan holder foam out of the server.
—End—	

To replace the upper fan holder foam

Step	Action
1	Ensure that the fan cables are in the slots in the lower fan holder foam.
2	Place the bottom end of the upper fan holder foam beneath the edge of the server chassis.
3	Align the slots on the underside of the foam with the fans and add-in boards. Use your fingers on the underside of the upper fan holder foam to determine correct placement of the fans. The fans must sit straight inside the foam sockets. They must not align with the left side of the foam.
4	Press the foam into place. You may need to wiggle the fans so that the upper fan holder foam sits flush with the bottom fan holder foam.
5	Ensure that the upper fan holder foam engages with the lip on the media drives cage and is securely seated.

—End—

Replacing the side cover

After you complete your work with the interior components of the server, replace the side cover. If you removed them, reinstall the chassis feet on the bottom of the server.

To replace the side cover



CAUTION

Before you replace the side cover, ensure that no tools or loose parts are inside the server chassis.




CAUTION

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Hold the cover flat against the chassis.
2	Slide the cover toward the front of the server until it locks into place.
3	Tighten the two thumbscrews on the back of the server.
4	If you removed the chassis feet, reinstall them.
5	Connect all external peripheral device cables and the power cord to the back panel.
6	Power up the server.
—End—	

Server side cover



G101762

Cooling fans description

For cooling and airflow, the system contains five fans that cool the interior of the server.




WARNING

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

Replaceable fan locations


The server contains five replaceable fans:

- Three fans are located near the front of the server. Two fans draw air through the lower media drive bays and provide cooling to the add-in boards. The third fan provides cooling for the system's processor. See ["Front system fans" \(page 91\)](#).
- Two fans are located at the back of the server. These fans draw air through the upper media drive bays, cool the interior of the server, and assist in evacuating hot air through the back of the server. See ["Rear system fans" \(page 92\)](#).

Front system fans

G101781

Rear system fans



G101763

Fan labels

The following conditions indicate when fans are installed correctly:

- The printed label of the fan faces the back of the server.
- The arrows embossed on the fan casing face as follows:



Replacing a front system fan

Replace a malfunctioning fan with the same type as the one removed. For more information about replacing a fan, contact your Nortel customer service representative.

Note: The fan replacement kit contains four fans: two front fans and two rear fans.

To remove a front system fan


**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Prepare the server for front system fan replacement as follows: a. Shut down the server, and then disconnect the power and peripheral device cables. b. Place the server on its side. c. Remove the side cover. d. Remove the upper fan holder foam. For instructions, see "Preparing the server for hardware maintenance" (page 81) .
2	Label and disconnect any cables that are attached to the voice processing boards.
3	Remove any add-in boards that block your access to the fan connectors on the motherboard. Note: As you remove each board, label it with its slot number so that you can reinstall the board in the same slot.
4	Lift the fan out of its slot in the fan holder foam.
5	Disconnect the fan power cable connector from the server motherboard.

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.

Install front system fan

- 6 Insert the fan into its slot in the bottom fan holder foam.

ATTENTION

To ensure proper cooling operation, ensure that the printed label of the fan is facing the back of the server, and the arrows embossed on the fan casing are facing as follows:



- 7 Connect the fan's power cable as follows:
- Insert the power cable of the fan into its slot on the bottom fan holder foam, and route the cable as shown in the preceding diagram.
 - Connect the power cable of the fan to its connector on the motherboard.

The connector is keyed so that it can be attached only one way.

Note: The fan closest to the top of the server connects to the connector labeled **sysfan5**. The fan closest to the bottom of the server connects to the connector that is labeled **sysfan3**.

- 8 Reinstall the add-in boards.
- 9 Reconnect any cables you disconnected to the add-in boards.
- 10 Ensure that any cables located near the fans are kept well away from the fans.

**CAUTION**

If a cable is caught in a fan, the fan will break.

- 11 Replace the upper fan holder foam.
For instructions, see ["To replace the upper fan holder foam" \(page 88\)](#).
- 12 Replace the side cover of the server.
- 13 Reconnect all peripheral device cables and power cord.
- 14 Power up the server.

—End—

Replacing a rear system fan

Replace a malfunctioning fan with the same type as the one removed.
For more information about replacing a fan, contact your Nortel customer service representative.

Note: The fan replacement kit contains four fans: two front fans and two rear fans.


To remove a rear system fan

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Prepare the server for rear system fan replacement as follows: - Shut down the server, and then disconnect the power and peripheral device cables. - Place the server on its side. - Remove the side cover. For instructions, see "Preparing the server for hardware maintenance" (page 81).
	 WARNING Failure to follow the procedures in "Preparing the server for hardware maintenance" (page 81) can result in electrical shock or equipment damage.
2	Lift the tab on the bracket that holds the fan in place.
3	Angle the fan towards the interior of the server, and then lift it away from its slot.
4	Disconnect the power cable of the fan connector from the server's motherboard.

install rear system fan



G101764

- 5 Place the bottom edge of the fan on the support bracket at the back of the server.

ATTENTION

To ensure proper cooling operation, ensure that the printed label of the fan is facing the back of the server, and the arrows embossed on the fan casing are facing as follows:.



- 6 Lift the brackets tab, align the fan with the server back wall, and then release the tab.
Ensure that the tab engages with the edge of the fan casing.
- 7 Connect the fan power cable to the motherboard.

Note: The fan closest to the top of the server connects to the connector labeled **sysfan1**. The fan closest to the bottom of the server connects to the connector that is labeled **sysfan2**.

- 8 Wrap excess cable length with a twist tie or cable wrap, and ensure that it is placed away from the fans.



CAUTION

If a cable is caught in a fan, the fan will break.

- 9 Replace the server side cover.
- 10 Reconnect all peripheral device cables and power cord.
- 11 Power up the server.

—End—

Replacing the processor fan

Replace a malfunctioning fan with the same type as the one removed. For more information about replacing a fan, contact your Nortel customer service representative.

To remove the processor fan



CAUTION

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
------	--------

- | | |
|---|--|
| 1 | Prepare the server for processor fan replacement as follows: <ol style="list-style-type: none"> a. Shut down the server, and then disconnect the power and peripheral device cables. b. Place the server on its side. c. Remove the side cover. d. Remove the upper fan holder foam. |
|---|--|

For instructions, see ["Preparing the server for hardware maintenance" \(page 81\)](#).


**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.

- 2 Disconnect the fan power cable connector from the server's motherboard.
- 3 Use both hands to spread the fan bracket tabs apart, and then move the fan away from the posts that hold it in place.

Tip: You may need to lift the bottom fan holder foam slightly to create more space.

- 4 Lift the fan up and out of the server.

install processor fan

G101766

- 5 Use both hands to spread the fan bracket tabs apart.

Tip: You may need to lift the bottom fan holder foam slightly to create more space.

- 6 At the same time, slide the fan onto the supporting posts.

ATTENTION

To ensure proper cooling operation, ensure that the fan's printed label is facing the back of the server, and the arrows embossed on the fan casing are facing as follows:



- Ensure that the fan cable is inside the bracket tab. This secures the cable to prevent damage.
 - Ensure that the bracket tabs engage with the edges of the fan casing.
- 7 Connect the fan power cable to the connector labeled **CPUfan1** on the motherboard.
- Secure the power cable by routing it between the heat sink housing and the capacitors.
- 8 Ensure that any cables located near the fan are kept well away from the fan.



CAUTION

If a cable is caught in a fan, the fan will break.

- 9 Reseat the bottom fan holder foam.
- 10 Replace the upper fan holder foam.
- For instructions, see ["To replace the upper fan holder foam"](#) (page 88).
- 11 Replace the server side cover.
- 12 Reconnect all peripheral device cables and power cord.
- 13 Power up the server.

—End—

Chapter 9

Replacing media drives

In this chapter

"SCSI and IDE drive cabling" (page 101)

"Replacing a faulty hard drive" (page 102)

"Replacing the tape drive" (page 109)

"Replacing the CD-ROM drive" (page 113)

"Replacing the floppy disk drive" (page 116)


SCSI and IDE drive cabling

Cabling diagram

"SCSI and IDE drive cabling." (page 102) shows the following:

- cabling for and termination of SCSI devices (hard drives and tape drives)
- cabling for an IDE CD-ROM drive

Use the information in this section to assist you with the procedures for replacing a faulty hard drive, tape drive, or CD-ROM drive

SCSI and IDE drive cabling.**Replacing a faulty hard drive**

If you need to replace a faulty hard drive, then do the following:

Step	Action
1	Review this entire section before proceeding to become familiar with the requirements and process.
2	Prepare the server for hard drive replacement as described in "Preparing the server for hardware maintenance" (page 81) .
3	Remove the faulty drive as described in "To remove a hard drive from the server" (page 105) .

ATTENTION

Due to the confined space for media drive cabling inside the server, hard drive replacement is easiest when the server is laying on its side. Laying the server on its side helps to prevent damage to the server and internal components.

ATTENTION

Replacement drives must be the same size or larger than the drives being replaced.

- 4 Install the new hard drive in the drive carrier as described in [Pull the drive carrier out of the chassis, and then place it cage-side-up on an antistatic surface...](#)
- 5 Install the drive carrier assembly in the server as described in ["To install the hard drive" \(page 107\)](#).

—End—

Hard drive description

The server is equipped with two 36 Gbyte wide SCSI hard drives, each one inch high. The last bay must remain empty to ensure proper system cooling.



CAUTION

The internal SCSI interface in this system supports only single-ended SCSI devices. Use Nortel authorized drives only.

SCSI drive cabling

The hard drive assembly package includes a standard 68-pin, 68 conductor, twisted-pair wide (16-bit) SCSI ribbon cable, with terminator. This cable has three connectors: the first is for the terminator, the second is for the hard drive, and the third is for connection to the RAID card.

Hard drive configuration

Ensure that the hard drives are configured as follows (for instructions, refer to the original equipment manufacturer documentation):

- termination: Set the hard drive on each SCSI bus to provide termination power to the bus.
- active termination (Term Enable): disabled on both drives

ATTENTION

If there is a termination enable jumper on the drive, it must NOT be set.

Termination must be provided by a SCSI terminator attached at the end of the cable.

- parity checking: enabled on both drives

- all other settings: factory default


RAID and SCSI settings

Location of hard drives in internal drive bays (from the top down)	RAID channel	SCSI ID	Hard drive label in the RAID software
Drive bay 4 (empty - used for airflow)	Not applicable	Not applicable	Not applicable
Drive bay 5 (Hard drive 1)	0	0	A0-0
Drive bay 6 (Hard drive 2)	1	0	A0-1
Drive bay 7 (empty)	Not applicable	Not applicable	Not applicable
Drive bay 8 (empty)	Not applicable	Not applicable	Not applicable
Drive bay 9 (bottom slot)	This slot must remain empty to ensure proper system cooling.		

Filler panels and EMI shields

System EMI integrity and cooling are both protected by drives that are installed in the bays or by filler panels and EMI shields that cover the bays. When installing drives, save the panel and shield to reinstall later, in case you remove the drive and do not reinstall one in the same bay.

Hard drive installation overview



To remove a hard drive from the server



CAUTION

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Prepare the server for hard drive replacement as follows: - Shut down the server, and then disconnect the power and peripheral device cables. - Remove the side cover. - Remove the upper fan holder foam.

For instructions, see "Preparing the server for hardware maintenance" (page 81).

**WARNING**

Failure to follow the procedures in "Preparing the server for hardware maintenance" (page 81) can result in electrical shock or equipment damage.

- 2 Open the front panel on the server.
- 3 Remove and save the two screws that secure the drive's carrier to the front of the chassis.
- 4 Pull the drive out slightly—about 1 cm (0.5 in.).
Pulling the drive out creates more space between the front system fans and the drives inside the server so that you can disconnect the cables.
- 5 If required (to provide more space), temporarily remove the front system fans from their slots in the bottom fan holder foam. (Do not disconnect the fans' power cables.)
- 6 Reach your fingers between the fan holder foam inside the server and the hard drives, and carefully disconnect the power and signal cables for both hard drives.
Note: If you are able to disconnect the cables for only the hard drive you want to remove, that is acceptable. You may find it easier, however, to disconnect the cables for both hard drives.
- 7 Pull the drive carrier out of the chassis, and then place it cage-side-up on an antistatic surface..

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

- 8 Remove the new drive from its protective wrapper, and place it on an antistatic surface.
- 9 Record the drive model and serial numbers in your equipment log.

ATTENTION

Replacement drives must be the same size or larger than the drives being replaced.

- 10 Set the hard drive settings as described in ["Hard drive configuration" \(page 103\)](#).
For instructions on changing the hard drive's settings, refer to the drive manufacturer's documentation.
- 11 If you are replacing an existing hard drive, remove the old drive from the drive carrier as follows:
 - a. Remove the four screws that attach the drive to the carrier.
 - b. Lift the carrier off of the hard drive.
 - c. Place the drive in an antistatic protective wrapper.
- 12 Position the new drive component-side down inside the drive carrier, and then attach the four screws that you removed earlier.
Ensure that the connectors on the back of the drive are flush with the rear of the drive carrier.
- 13 Continue with ["To install the hard drive" \(page 107\)](#).

—End—

To install the hard drive

ATTENTION

The last bay must remain empty to ensure proper system cooling.

Step	Action
------	--------

- | | |
|---|---|
| 1 | Slide the hard drive and drive carrier assembly (with the exposed drive facing up) into the server bay. |
|---|---|

ATTENTION

To provide more space inside the server so that you can connect the cables, *do not* push the drive all the way in (that is, until it clicks into place).

- | | |
|---|--|
| 2 | <p><i>If not already done:</i> Temporarily remove the front system fans from their slots in the bottom fan holder foam.</p> <p>Do not disconnect the fans' power cables.</p> |
|---|--|

- 3 Connect the hard drive SCSI cable as follows (the end of the cable with two connectors is the hard drive end):

- a. Ensure that a terminator is connected to the last connector at the hard drive end of the cable.
- b. Connect the second connector on the cable to the hard drive.

Place one hand on the front of the hard drive to hold it in place while you connect the cable with the other hand.

**CAUTION**

To prevent damage to the connector pins, ensure that the cable connector aligns correctly with the hard drive connector before pushing it into place.

- c. Route the cable above the CPU through the vacant space at the top of the server.
- d. Connect the other end of the cable as follows:
 - Connect hard drive 1 to channel 0 on the RAID controller.
 - Connect hard drive 2 to channel 1 on the RAID controller.
- e. For proper cooling and airflow, neatly fold and secure the excess signal cable above the CPU. Use a tie wrap or cable clip to secure the cable.

**CAUTION**

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

If you need more information, see ["SCSI and IDE drive cabling" \(page 101\)](#).

- 4 Connect the hard drive's power cable.
- Note:** The connector is keyed so that you cannot connect it upside down.
- 5 At the front of the server, slide the drive into the bay until it clicks into place.
- 6 Secure the drive carrier to the front of the server with the screws you removed earlier.

Tighten the screws firmly.

- 7 Ensure that all media drive cable connections are secure.

Note: Connectors could be dislodged when you slide the hard drive all the way inside the bay.

**CAUTION**

If the hard drive cable connections are loose, data loss, data corruption, or system malfunction can occur.

- 8 Reinstall the fans (if removed) and upper fan holder foam.
- For instructions on reinstalling the fans, see ["Install front system fan" \(page 94\)](#).
 - For instructions on replacing the upper fan holder foam, see ["To replace the upper fan holder foam" \(page 88\)](#).
- 9 Reinstall the server side cover.
- 10 Reconnect the peripheral device and power cables.
- 11 Power up the server.
- 12 Rebuild the drive in the RAID system pack.

The rebuild copies the data from the operating hard drive to the new hard drive. For instructions, see [Chapter 10 "RAID operations" \(page 121\)](#)

Result: Hard drive replacement is complete.

—End—

Replacing the tape drive

The tape drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.

**CAUTION**

Use only a tape drive that is supplied by Nortel.

Filler panels and EMI shields

System EMI integrity and cooling are both protected by drives installed in the bays or by filler panels and EMI shields covering the bays. When installing drives, save the panel and shield to reinstall later, in case you remove the drive and do not reinstall one in the same bay.

Tape drive configuration

Note: Some settings may already be properly configured. If it is not clear from the drive manufacturer's documentation how to set jumpers, contact your Nortel technical support representative.


Ensure that the hard drives are configured as follows (for instructions, refer to the original equipment manufacturer documentation):

- SCSI ID: 2
- active terminators (Term Enable): disabled

Note: Termination is provided by an Active SCSI terminator that you connect to the end of the SCSI cable (see "[SCSI and IDE drive cabling](#)" (page 101)).

- parity checking: enabled
- termination power (TPWR): enabled
- all other settings: factory default

Tape drive installation overview



G101772

To remove the tape drive

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

Note: The tape drive is installed in the second bay from the top.**Step Action**

- 1 Prepare the server for tape drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see ["Preparing the server for hardware maintenance"](#) (page 81).

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.

- 2 Disconnect the power and signal (SCSI) cables of the faulty drive.
- 3 Open the front panel on the server.
- 4 Remove and save the two screws that secure the tape drive to the front of the chassis.
- 5 Pull the tape drive out of the chassis, and then place it on an antistatic surface.
Note: If you plan to leave the bay empty, install a filler panel and stainless steel EMI shield on the bay.
- 6 Remove the four screws and two slide rails from the tape drive.
- 7 Place the drive in an antistatic protective wrapper.
- 8 Continue with ["To install a replacement tape drive" \(page 112\)](#) below.

—End—

To install a replacement tape drive

Step	Action
1	Remove the new tape drive from its protective wrapper, and place it on an antistatic surface.
2	Record the drive model and serial numbers in your equipment log.
3	Set the settings of the tape drive as described in "Tape drive configuration" (page 110) . For instructions on changing the tape drive's settings, refer to the drive manufacturer's documentation.
4	Attach the slide rails to the replacement tape drive with the screws you removed earlier.
5	Slide the tape drive into the tape drive bay.
6	Secure the tape drive to the front of the server with the screws you removed earlier.

Tighten the screws firmly.

- 7 Refer to the ["Cabling diagram" \(page 101\)](#), and then connect the tape drive's SCSI cable as follows:
 - a. Connect one end of the SCSI cable to **LVD** (the wide SCSI controller of the server) on the server's motherboard.
 - b. If a terminator is not attached to the cable, attach a wide SCSI terminator to the other end of the SCSI cable.
 - c. Connect the second connector on the SCSI cable to the tape drive.
 - d. For proper cooling and air flow, neatly fold and secure the excess signal cable into the last bay (at the bottom of the server) so that the cable does not drape across the baseboard or add-in boards.



CAUTION

Ensure that any cables in the proximity of the fans are kept away from the fans. If a cable is caught in a fan, the fan will break.

- 8 Connect the power cable of the tape drive.
Result: The tape drive is installed.
- 9 Replace the upper fan holder foam.
For instructions on replacing the upper fan holder foam, see ["To replace the upper fan holder foam" \(page 88\)](#).
- 10 Replace the side cover.
- 11 Reconnect the peripheral device and power cables.
- 12 Power up the server.
- 13 Test the tape drive.

—End—

Replacing the CD-ROM drive


The CD-ROM drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.



CAUTION

Use only a CD-ROM drive that is approved by Nortel.

CD-ROM drive installation overview



To remove the CD-ROM drive



CAUTION

Use an ESD wrist strap to protect static-sensitive components.

Note: The CD-ROM drive is installed in the top bay.

Step	Action
1	Prepare the server for CD-ROM drive replacement as follows: - Shut down the server, and then disconnect the power and peripheral device cables. - Remove the side cover. - Remove the upper fan holder foam.

For instructions, see ["Preparing the server for hardware maintenance" \(page 81\)](#).

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.

- 2 Disconnect the faulty drive's power and signal (IDE) cables.
- 3 Open the front panel on the server.
- 4 Remove and save the two screws that secure the CD-ROM drive to the front of the chassis.
- 5 Pull the drive out of the chassis, and then place it on an antistatic surface.

Note: If you plan to leave the bay empty, install a filler panel and stainless steel EMI shield on the bay.

- 6 Remove the four screws and two slide rails from the drive.
- 7 Place the drive in an antistatic protective wrapper.
- 8 Continue with ["To install a replacement CD-ROM drive" \(page 115\)](#).

—End—

To install a replacement CD-ROM drive

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

Step	Action
1	Remove the new CD-ROM drive from its protective wrapper, and place it on an antistatic surface.
2	Record the drive model and serial numbers in your equipment log.
3	Set the new CD-ROM drive to IDE Master by changing the jumper settings at the back of the drive.

Note: Refer to the CD-ROM drive manufacturer's documentation for specific jumper settings.

- 4 Install the slide rails on the new drive.
Ensure that the first set of holes on the bracket are aligned with the screw holes closest to the front of the CD-ROM drive.
- 5 Slide the new CD-ROM drive into the drive bay and secure it to the front of the server with the screws you removed earlier.
- 6 Reconnect the CD-ROM drive's IDE cable to **IDE0** (blue connector) on the motherboard. Ensure that the blue stripe on the cable at the motherboard connector end faces towards the back of the server.

ATTENTION

The server will not start if the cable is connected backwards.

For more information, see the ["Cabling diagram" \(page 101\)](#).

- 7 Reconnect the CD-ROM drive's power cable.
Result: The CD-ROM drive is installed.
- 8 Replace the upper fan holder foam. For instructions on replacing the upper fan holder foam, see ["To replace the upper fan holder foam" \(page 88\)](#).
- 9 Replace the side cover.
- 10 Reconnect the peripheral device and power cables.
- 11 Power up the server.
- 12 Test the CD-ROM drive.

—End—


Replacing the floppy disk drive

The floppy disk drive is preinstalled at the factory. However, if it becomes faulty, follow the procedure in this section to replace it.



CAUTION

Use only a floppy disk drive that is supplied by Nortel.

Floppy disk drive installation overview**To remove the floppy disk drive****ATTENTION**

Nortel recommends that you use a magnetic screwdriver in this procedure. A nonmagnetic screwdriver can result in screws being lost between the chassis and plastic bezel.

**CAUTION**

Keep magnetic screwdrivers away from hard drives, floppy disks, and backup tapes to prevent data loss.

**CAUTION**

Use an ESD wrist strap to protect static-sensitive components.

Step Action

- 1 Prepare the server for floppy disk drive replacement as follows:
 - a. Shut down the server, and then disconnect the power and peripheral device cables.
 - b. Remove the side cover.
 - c. Remove the upper fan holder foam.

For instructions, see ["Preparing the server for hardware maintenance" \(page 81\)](#).

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.


- 2 Disconnect the power and signal cables of the disk drive.
- 3 Open the front panel on the server.
- 4 Remove and save the two screws that secure the floppy disk drive to the front of the chassis.
- 5 Slide the assembly toward the back of the server to disengage it from the tabs that secure the carrier assembly to the server.
- 6 Remove the assembly from the chassis.
- 7 Remove the four screws that hold the bracket to the drive, and set them and the bracket aside.
- 8 Place the drive in an antistatic protective wrapper.
- 9 Continue with ["To install a replacement floppy disk drive" \(page 119\)](#).

—End—

To install a replacement floppy disk drive

Step	Action
1	Remove the new floppy disk drive from its protective wrapper, and place it component-side up on an antistatic surface.
2	Record the drive model and serial numbers in your equipment log.
3	Set any jumpers or switches according to the drive manufacturer's instructions.
4	Place the drive label-side up inside the carrier, and then attach the drive to the carrier with the four screws you removed earlier. See "Attach disk drive to carrier" (page 119).

Attach disk drive to carrier



Ensure that the carrier is aligned with the two screw holes closest to the front of the floppy disk drive. Tighten the screws firmly.

- 5 Install the drive carrier inside the server.

Slide the assembly toward the front of the system, and engage it with the bracket tabs on the side of the drive bay.

Note: The bottom of the drive/bracket assembly must accept the tab that sticks out from the inside of the front panel. Ensure that the front of the drive fits flush in the front opening of the system. (See the ["Floppy disk drive installation overview"](#) (page 117).)

- 6 Secure the assembly to the server's front panel with the screws you removed earlier. Tighten the screws firmly.

- 7 Connect the floppy disk drive's signal cable to the drive.

Note: The connectors are usually keyed to allow you to easily reconnect them to the drive. If they are not keyed, insert both cables so that the red wires are closest to the center of the drive.

**CAUTION**

If the floppy disk drive contains a floppy disk and the signal cable is connected backwards, data loss can occur. The LED at the front of the drive will also remain lit after the server is powered up.

- 8 Connect the power cable of the floppy disk drive to the drive.

Result: The floppy disk drive is installed.

- 9 Replace the upper fan holder foam.

For instructions on replacing the upper fan holder foam, see ["To replace the upper fan holder foam"](#) (page 88).

- 10 Replace the side cover.

- 11 Reconnect the peripheral device and power cables.

- 12 Power up the server.

- 13 Test the floppy disk drive.

—End—

Chapter 10

RAID operations

In this chapter

"RAID overview" (page 121)

"Verifying the RAID firmware" (page 122)

"Configuring RAID using LSI Elite 1600 controller and Ctrl+M" (page 124)

"Verifying consistency on the drives" (page 128)

"RAID splitting" (page 129)

"Task summary for configuring RAID" (page 133)

"Task summary for RAID splitting" (page 134)

RAID overview

Redundant Array of Independent Disks (RAID) is a technology that can combine two or more drives for fault tolerance and continued system performance. The CallPilot RAID controller is a PCI RAID SCSI card that provides high-performance disk mirroring. CallPilot uses RAID Level 1.

With Level 1 mirroring, two equal-capacity disk drives mirror one another. One disk drive serves as the backup copy of the other disk drive. If one disk drive fails, the other continues to run.

RAID configuring and splitting

Working with RAID involves the following:

- Verifying the RAID firmware version
- Upgrading or downgrading the RAID firmware
- Configuring RAID using the LSI Elite 1600 controller and the Ctrl+M menu at server boot-up

- Ensuring that your system is fully working and the RAID hardware is properly configured
- Performing full data backup
- Performing RAID splitting
- Performing a CallPilot software upgrade
- Performing RAID synching if upgrade successful
- Performing RAID synching if upgrade NOT successful

Verifying the RAID firmware

The minimum requirement for RAID firmware:

- firmware: 111U

To verify the RAID firmware version

To determine what the current RAID firmware version is on the RAID LSI Elite 1600 controller, do the following:

Step	Action
1	Turn on the server and press Ctrl+M when prompted during system bootup. Note: The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.
2	Select Objects menu → Adapter → Other Adapter Information. Or a. Launch the MegaRAID client using: Start → Programs → Power Console Plus → Launch Client. b. From the MegaRAID Power Console Plus - Server Selection window, select Access Mode → Full Access to view or change configuration information and click OK. c. From the MegaRAID console, choose Adapter → Properties.
3	Review the information on the screen. Ensure that Power Console Plus is version 5.00i or later. The LSI Elite 1600 controller firmware should be 111U.
4	If the firmware is not correct, perform a firmware update. For instructions, see "To upgrade or downgrade the RAID firmware" (page 123) .

—End—

To upgrade or downgrade the RAID firmware

The firmware of the RAID card is upgraded through a flash process. The flash process is initiated by running the RAID card firmware update utility on the CallPilot CD-ROM.



WARNING

Nortel strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

ATTENTION

Perform this procedure only if the firmware version is not the version identified in this section.

Step	Action
1	Insert the CallPilot tower 703t Image CD-ROM 1 of 3 into the server CD-ROM drive.
2	Restart the server and observe the startup diagnostics.
3	When the processor diagnostics screen appears, press Esc. Result: The following message appears at the bottom of the screen: <code>Entering boot selection menu</code> The system continues with the SCSI and RAID startup diagnostics, and when done, a menu appears.
4	Choose ATAPI CD-ROM, and press Enter. Result: The Startup menu appears.
5	Choose Utilities (for example, BIOS, Firmware, and so on), and then press Enter. Result: A menu appears.
6	Choose LSI Elite 1600 RAID card Firmware update, and press Enter.
7	Press Y for yes and then Enter to confirm that the 471gen.rom file is detected.
8	Respond to the remaining prompts to proceed with the update. Result: The update proceeds. When it is finished, you are informed that the update completed successfully and you are asked to restart the server.
9	Remove the CD-ROM from the CD-ROM drive.

- 10 Press Ctrl+Alt+Delete to restart the server.

—End—

Configuring RAID using LSI Elite 1600 controller and Ctrl+M

The configuration of the RAID card is stored on both the card and on the hard drive, so typically you are not required to reconfigure RAID unless you are making a change to the RAID system (for example, if you replace the hard drives with higher-capacity hard drives).



WARNING

Nortel strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.



CAUTION

This procedure requires that the logical drive be initialized. When you initialize the logical drive, all data on the hard drives is erased.

Do not perform this procedure unless you are replacing the hard drives, or you are rebuilding the CallPilot system (that is, reinstalling the Windows operating system and CallPilot software).

To configure an LSI Elite 1600 RAID system

To configure RAID, do the following:

Step	Action
1	Turn on the server and press Ctrl+M when prompted during system bootup. Note: The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.
2	From the Management menu, select Objects and press Enter.
3	From the Objects menu select Adapter and press Enter.
4	From the Adapter menu select Factory Default.
5	Select Yes to confirm the selection and press Enter.
6	Press Ctrl+Alt+Delete when prompted to restart system.
7	During bootup, press Ctrl+M to re-enter the RAID setup utility.

- 8 From the Management menu select Objects → Adapter, then ensure the Adapter 1 values are set as follows:

Flex RAID Power Fail: **Enabled**

Fast Initialization: **On**

Disk Spin up Timing: **1 Disk every 6 secs**

Cache Flush Timings: **Every 4 seconds**

Rebuild Rate: **30%**

Alarm Control: **Enabled**

Other Adapter Options:

- Emulation: **Mass Storage**
- Auto Rebuild: **Disabled**
- Initiator ID: **7**
- Cluster Mode: **Disabled**
- Multiple PCI Delayed Transactions: **Disabled**
- Force Boot: **Off**
- Coercion Algorithm: **GigaByte Way**
- Cc Restoration: **Enabled**

Note: The Coercion Algorithm must be set properly. Once changed, it cannot be changed again. The only way to reset it is to reconfigure RAID from scratch and load the default configuration, then reboot.

- 9 Select Objects → Channel and press Enter.

- 10 From the Channel menu, ensure the values are set as follows:

Termination State: **Enabled**

SCSI Transfer Rate: **160M**

- 11 Select Configure menu → New Configuration. Click Yes to proceed.

Result: The system should display both SCSI channels, each having one drive. SCSI IDs should be 0 for each channel. All disk drives should be in READY state.

Note: Do not use the Load command on the Configure menu. This command is not for RAID operations.

- 12 Create the first logical drive by selecting Channel-1 ID 0 (A01-01), and pressing the Spacebar. The display will change to ONLIN A01-01. Select Channel-2 ID-0 (A01-02) and again press the Spacebar.

Result: After selection, the drives will blink.

- 13** Press Enter to End the Array.
Result: The blinking stops.
- 14** Press F10 to configure the logical drive.
- 15** Press the space bar to select Configuration Array.
Result: Span-1 appears in the box opened for the A01 logical drive.
- 16** Press F10 to configure the logical drives.
Result: The system prompts you for each of the logical drives to consecutively select:
RAID 1;
Size: accept the size displayed
Accept
SPAN = NO
Change the last value to NOSPAN if required.
- 17** Highlight Accept and press Enter twice to accept these new values.
Result: The system prompts you to save the configuration.
- 18** Highlight YES and press Enter.
- 19** Press ESC twice to exit the submenus.
- 20** In the Management menu, choose the Initialize submenu.
- 21** Press F2 to select the logical drive.
- 22** Press F10 and consecutively select YES to initialize the drive pack.
- 23** When the initialization is complete, press any key to return to the Management menu.
- 24** Press ESC to exit the utility. Save the configuration when prompted.
- 25** Press Ctrl+Alt+Delete as indicated by the menu to reboot.

—End—

Replacing the LSI1600 card with LSI320-2

Use this procedure to replace a failed LSI1600 RAID card.

**WARNING**

Nortel strongly recommends that you not perform low level formatting. Performing low level formatting results in the drives becoming unusable.

ATTENTION

If your replacement RAID card has been previously used and holds an existing configuration, the system will report a mismatch between the controller NVRAM and Drive MetaData. The steps below will correct the mismatch.

To replace the LSI1600 card with the LSI320-2 card.

Step	Action
1	Power up the server and click Ctrl+M to enter the utility.
2	Select Objects → Adapter → Other Adapter to set the following: - Set Force Boot to On. - Set Auto-Rebuild to Disabled. - Select Objects → Channel and ensure channel speed is 160M. ((Default for LSI320 is 320M). - Repeat for all channels.
3	Exit the utility and reboot the server.
4	Set the server to boot from CD.
5	Insert the RAID Update Utility CD and reboot the server. Result: The DOS boot menu appears.
6	Select Update LSI320-2 Firmware. Result: The system will prompt twice to confirm you are upgrading the firmware.
7	Answer Y to both questions. Result: The system upgrades the firmware and asks you to reboot.
8	Allow the system to reboot to Windows 2003.
9	Insert the RAID Update Utility CD and unzip the RAIDUP.EXE file. Result: A directory called RAIDUP is created on C:\ drive
10	Locate SCSI controllers → LSI Adapter in the RAIDUP directory. Double click on it, then select Driver. Result: You are asked to choose the Upgrade Driver.

- 11 Point to the c:\raidup\Win2k3 folder.
- 12 The system asks you to reboot.
Result: The system reboots to Windows 2003.
- 13 Check the driver, firmware and Power Console configuration.
 - a. Open the MegaRAID Power Console from the Start → Programs menu.
 - b. Select Help About from the menu and verify the MegaRAID Power Console version is 5.00i.
 - c. Select Adapter → Properties and verify the firmware version is 1L37 and the board type is LSI320-2.
 - d. Exit the Power Console.
- 14 Right click on C:\WINNT\SYSTEM32\DRIVERS\mraid3xx.sys and select Properties → Version. Verify the Driver version is 6.45.

—End—

Verifying consistency on the drives

This optional consistency check on the logical drive of the RAID system ensures that the data on the drives is identical. If any errors are found, they are corrected automatically. Perform a consistency check *before* you split the RAID system pack. A good data backup on an offline drive is important if you need to revert to the CallPilot system from an unsuccessful upgrade or update. The consistency check can take up to 2 hours to complete.

To perform a consistency check

Step	Action
1	In Windows, click Start → Programs → Power Console Plus → Launch Client. Result: The MegaRAID Power Console Plus- Server Selection window appears.
2	Ensure that Access Mode → Full Access is selected, and click OK. Result: The MegaRAID Power Console Plus window appears displaying the Logical View of the Physical Devices and the Logical Devices. The status bar at the bottom of the window indicates that RAID channels are being scanned. When scanning is done, the screen refreshes and displays the Physical and Logical Devices.

- 3 In the Logical Devices section, right-click the logical drive, and then choose Check Consistency from the pop-up menu.

Result: The Check Consistency status dialog appears.

Note: The check can take up to 2 hours to complete. You are informed when it is finished. If any errors are found, a window with an error message is displayed.

- 4 Select Configuration → Exit to close the MegaRAID console.

Result: An end of session message appears.

- 5 Click OK.

—End—

RAID splitting

Ensure that your system is in full working order and the RAID hardware configuration is set up properly as described on ["Configuring RAID using LSI Elite 1600 controller and Ctrl+M" \(page 124\)](#).

ATTENTION

The most important thing to verify is that the RAID channel 1 is connected to the first hard drive (top as facing the machine) and channel 2 is connected to the second drive (bottom). Do that by either opening the lid and following the cables or by removing one hard drive and observing which drive is marked dead by the system. If the drive matches the graphic location on the Windows MegaRAID console, proceed with the next step.

Full data backup

ATTENTION

As an extra precaution, Nortel recommends that a full system backup be performed PRIOR to performing a RAID-split. For more information on system backups, refer to the CallPilot Manager online Help.

To split the RAID

ATTENTION

Because the 703t has only one physical drive per channel, the RAID splitting can be done using the Windows MegaRAID console without risk of CallPilot database corruption.

Step	Action
------	--------

- | | |
|---|---|
| 1 | To load the MegaRAID console, click Start → Programs → Power Console Plus → Launch Client.

Note: Ensure that Access Mode → Full Access is selected. |
| 2 | Click OK.

Result: Result: the MegaRAID Power Console Plus window appears. |
| 3 | Ensure all drives are in ONLINE state (marked GREEN). |
| 4 | In the Physical Devices section, right-click the Channel-2 hard disk drive. Example: Channel-2 (0) A1-2-Onln. |
| 5 | Select Tools → Fail Drive from the pop-up menu.

Result: A message appears advising that marking the Online drive Failed results in changes. |
| 6 | Ignore the warning and click OK. The drive status will change to FAILED and the color of the icon will change to RED. Example: Channel-2 (0) A1-2-Failed.

Result: The audible alarm should start beeping. |


—End—

ATTENTION

The alarm can be silenced, but under no circumstances should it be disabled. Select Adapter → Alarm Control → Silence Alarm.

At this point, the RAID is split, and the drive marked FAILED is the backup drive and will no longer be written to. A release upgrade or PEP installation can now be completed without impact to the →backup' drive.

MegaRAID Power Console Plus drive status



Perform a CallPilot software upgrade

Let the system boot. The system will still run after Channel 2 of the RAID card was taken out of service and will boot to Windows. Perform the software upgrade.

To synchronize the RAID after a successful upgrade

To restore RAID to full service after completing a successful upgrade or update:

Step	Action
1	WITHOUT shutting down the server, from Windows, click Start → Programs → Power Console Plus → Launch Client. Note: Ensure that Access Mode → Full Access is selected.
2	Click OK. Result: The MegaRAID Power Console Plus window appears.
3	In the Physical Devices section, right-click the Channel 2 hard disk drive that was marked FAILED. Example: Channel-2 (0)A1-2-Failed.
4	From the right mouse pop-up menu, select Rebuild. Result: When Rebuild is done, the drive status changes to ONLINE and the color of the icon should change to green. The alarm should stop beeping unless it was temporarily silenced. Note: The process can take up to 1 hour. DO NOT shut down the machine before the rebuild is complete. If you do reboot or power down during this process, you need to do "To synchronize RAID after an unsuccessful upgrade" (page 132), then start

again. You can monitor the rebuild by opening the Windows MegaRAID console.

—End—

To synchronize RAID after an unsuccessful upgrade

If the upgrade or update has failed, the system needs to be returned to the original configuration.

Step	Action
1	Restart the server and enter the Ctrl+M utility when prompted during system bootup.
2	From the Management menu select Objects and press Enter.
3	Select Objects → Physical Drive and press Enter.
4	Select FAIL Drive for the drive on Channel 1. Result: The drive will show as FAIL.
5	Select the drive on Channel 2 (previously taken offline as the backup drive and marked 'Failed') and make it ONLINE. Ignore the warning message. Result: At this point, the drive on the Channel 2 is ONLINE and the one on Channel 1 is marked FAILED.
6	Exit the utility and press Ctrl+Alt+Delete to reboot the server. Result: The system will boot up to the original configuration before the software upgrade and an audible alarm will indicate the state CRITICAL for the drives. You can silence the alarm but DO NOT disable it.
7	Once the system is fully booted, open the Windows MegaRAID console and rebuild the FAIL drive on Channel 1 using the same process indicated in "To synchronize the RAID after a successful upgrade" (page 131) . Reverting from a failed software upgrade is now complete. The audible alarm, if left on, should automatically stop.

—End—

Task summary for configuring RAID

Note: This summary should be used only after reviewing the more detailed procedures and warnings in this chapter.

What to do	How to do it
Verify the BIOS and firmware revisions	Firmware: 111U Use the Windows MegaRAID console and choose Adapter → Properties. Or turn on the server and press Ctrl+M. Select Objects menu → Adapter → Other Adapter Information.
Upgrade or downgrade firmware and BIOS	Use the CallPilot 5.0 tower 703t Image CD-ROM 1 of 3 and select Utilities, RAID 703t F/W upgrade.
Configure RAID using LSI 1600 controller using the Ctrl+M menu at server boot-up Note: The Ctrl+M utility can take up to 1 minute to launch with 111U firmware. The system may appear frozen. Do not reset.	1. Start the server and press Ctrl+M. Select Objects menu → Adapter → Factory Default, and select Yes to confirm the selection. Press Ctrl+Alt+Delete when prompted to restart system and re-enter Ctrl+M utility. 2. Select Objects → Adapter, then ensure the following values are set as following: - Flex RAID Power Fail: Enabled - Fast Initialization: On - Disk Spin up Timing: 1 disk every 6 secs - Cache Flush Timings: Every 4 seconds - Rebuild Rate: 30% - Alarm Control: Enabled - Other Adapter Settings: • Emulation: Mass Storage • Auto Rebuild: Disabled • Initiator ID: 7 • Cluster Mode: Disabled • Multiple PCI Delayed Transactions: Disabled • Force Boot: Off • Coercion Algorithm: GigaByte Way • Cc Restoration: Enabled 3. Select Objects → Channel, then ensure that the following values are set as follows: Termination State: Enabled SCSI Transfer Rate: 160M

What to do	How to do it
	4. In the Configure menu, select New Configuration. Press Yes to proceed. The system should display both SCSI channels, each having one drive. SCSI ID's should be 0 for each channel. All disk drives should be in READY state. Note: Do not use the Load command on the Configure menu. This command is not for RAID operations. 5. Create the first logical drive by selecting Channel-1 ID 0 (A01-01), and pressing the Spacebar. The display will change to ONLIN A01-01. Select Channel-2 ID-0 (A01-02) and again press the Spacebar. After selection, the drives will blink, press Enter or F10 to create first logical drive. 6. Press the Space bar to Select Configuration Array. <i>Span-1</i> appears in the box opened for the A01 logical drive. 7. Configure the logical drives by pressing F10. The system prompts for each of the logical drives to consecutively select RAID 1; Size: accept the size displayed; Advanced Menu Accept SPAN = NO Change the last value to NOSPAN if required. Accept these new values by pressing Enter. The system will prompt you to save the configuration. Highlight Yes and press Enter. Exit the submenu by pressing Esc. 8. In the main menu enter the Initialize submenu. Select the logical drive by pressing F2. Press F10 and consecutively select YES to initialize the drive pack. When done, press any key to return to the main menu. 9. Exit the utility by pressing Esc. Save the configuration when prompted. Press Ctrl+Alt+Delete as indicated by the menu to reboot.

Task summary for RAID splitting

Note: This summary should be used only after reviewing the more detailed procedures and warnings in this chapter.

What to do	How to do it
Ensure that your system is fully working and the RAID hardware is properly configured.	The most important thing to verify is that the RAID channel 1 is connected to the first hard drive (top as facing the machine) and channel 2 is connected to the second drive (bottom). Open the lid and follow the cables or remove one hard drive and observe which drive is marked dead by the system. If the drive matches the graphic location on the Windows MegaRAID console, proceed with the next step.

What to do	How to do it
Full data backup	Do a full data backup before RAID splitting is performed as an extra precaution.
RAID splitting Note: Because the 703t has only one physical drive per channel, the RAID splitting can be done using the Windows MegaRAID console without risk of CallPilot database corruption.	1. Load the Windows MegaRAID console. Ensure all drives are in ONLINE state (GREEN). 2. Right click the Channel 2 first drive (i.e (0) A1-2-Onln). Select Tools → Fail Drive. A warning message will pop-up. Ignore it and press OK. The drive status will change to FAILED and the color of the icon should change to RED. The alarm should start beeping. Note: The alarm can be silenced, but under no circumstances should it be disabled. Select Adapter → Alarm Control → Silence Alarm Technically the drive that is marked FAILED is now the Backup Drive.
Perform Call Pilot software upgrade	Let the system boot. The system will still run after Channel 2 of the RAID card was taken out of service and will boot to Windows. Perform the software upgrade.
RAID synching for upgrade successful	WITHOUT shutting down the server, in the Physical Devices section of the MegaRAID console, right click the Channel 2 first drive (i.e Channel 2 (0) A1-2-Failed). From the right mouse pop-up menu select Rebuild. When Rebuild is done, the drive status will change to ONLINE and the color of the icon should change to green. The alarm should stop beeping unless it was temporarily silenced. The process can take up to one hour. DO NOT shut down the machine before the rebuild is complete. If you do reboot or power down during this process, you need to do 'RAID synching for upgrade NOT successful', then start again. You can monitor the rebuild by opening the Windows MegaRAID console.
RAID synching for upgrade NOT successful	If the software upgrade has failed, the system needs to be returned to the original configuration. 1. Restart the server and enter the Ctrl+M utility. 2. Select Objects → Physical Drive → FAIL Drive for the drive on Channel 1. The drive will show as FAIL after this step. 3. Select the drive on Channel 2 (previously taken offline or the Backup drive) and make it ONLINE. Ignore the warning message. At this point the drive on the Channel 2 is ONLINE and the one on Channel 1 is marked FAILED. 4. Exit the utility and reboot. The system will boot up to the original configuration before the software upgrade and an audible alarm will indicate the state CRITICAL for the drives. At this time, you can silence the alarm but DO NOT disable it.

What to do	How to do it
	5. Once the system is fully operational, open the Windows MegaRAID console and rebuild the FAIL drive on Channel 1 using the same process indicated in "RAID synching for upgrade successful". Reverting to original from a failed software upgrade is now complete. The audible alarm, if left on, should automatically stop.

Chapter 11

Replacing or adding voice processing boards

In this chapter

"DSP numbering and location" (page 137)

"Replacing MPB96 boards" (page 138)


DSP numbering and location

DSPs are the built-in voice processing components on MPB boards. DSPs are numbered to distinguish them in CallPilot maintenance programs, such as the Maintenance page in CallPilot Manager. Each DSP supports up to eight multimedia channels.

DSP numbering on MPB96 boards

The MPB96 board has 12 embedded DSPs. If an embedded DSP is faulty, you must replace the entire MPB96 board.

MPB96 board



Replacing MPB96 boards

This section describes how to replace an MPB96 board.

You will need to replace an MPB96 board:

- if the board becomes faulty
- when the PCI firmware needs to be updated, and the board must be sent back to the factory



CAUTION


- Wear an antistatic ESD wrist strap when handling cards or boards, or when working inside the server.
- Do not touch the components or gold-edge connectors of cards or boards.
- Place the board on an antistatic surface until you are ready to install it.

Requirements


- MPB96 board (NTRH40AA)
- DS30X cable (NTRH2014)

"DS30X cable for MPB96 board" (page 139) shows the DS30X cable for the MPB96 board.

DS30X cable for MPB96 board



Note: The ferrites on this cable control EMC emission levels. Do not remove them.

MPB96 board installation

G101777b

Note: For Meridian 1 and Communication Server 1000 systems, the MPB96 board is installed in slot 4.

To replace an MPB96 board

Step	Action
1	Prepare the server for MPB96 board replacement as follows: - Shut down the server, shut off the power, and then disconnect the following cables: - power cable - peripheral device cables - DS30X cable(s) (Meridian 1 and Communication Server 1000 only)

- b. Place the server on its side.
- c. Remove the side cover.
- d. Remove the upper fan holder foam.

For instructions, see ["Preparing the server for hardware maintenance" \(page 81\)](#).

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.

- 2 Remove the faulty MPB96 board from its slot, and save the retaining screw.
- 3 Unpack the replacement MPB96 board.
- 4 Hold the MPB96 board by its top edge or upper corners, and then align it with the following:
 - end-plate opening in the chassis Ensure that the tapered foot of the board's retaining bracket fits into the slot in the expansion slot frame.
 - PCI connector
- 5 Press the new MPB96 board firmly into its slot.
- 6 Secure the board using the retaining screw that you removed earlier.
- 7 Replace the upper fan holder foam.

For instructions, see ["To replace the upper fan holder foam" \(page 88\)](#).
- 8 Replace the server cover.
- 9 Reconnect the peripheral device and power cables.
- 10 Reconnect the DS30X cable to the faceplate of the MPB96 board.

Note: Ensure that a single-point ground reference is available for all the power outlets serving the CallPilot server and its peripherals. Before the CallPilot server installation, a qualified electrician must implement the single-point ground reference

requirement between the power outlets of the CallPilot server and the power outlets of the switch.

- 11** Power up the server and log on to Windows.

Note: When the Windows New Hardware Found Wizard pops up, press the next button and select the presented Nortel MPB driver.

- 12** Run the Configuration Wizard to detect the new hardware.

For instructions, refer to the *Installation and Configuration Task List* (NN44200-306).

Result:The MPB96 board replacement is complete.

- 13** Test the multimedia channels to ensure that the new MPB96 board is functioning properly.

Refer to the *Installation and Configuration Task List* (NN44200-306).

—End—

Chapter 12

Working with DIMMs and the CPU

In this chapter

"Replacing or adding baseboard DIMMs" (page 143)

"Replacing the CPU" (page 146)

Replacing or adding baseboard DIMMs


The baseboard provides four slots that support DDR266 SDRAM DIMMs. The server ships with two DIMMs that provide a total of 512 Mbytes of memory. DIMMs must be installed in pairs, and can be expanded to 8 Gbytes of memory.

DIMM sizes and compatibility

Contact your Nortel sales representative or customer support representative for a list of Nortel-supplied DIMMs for the 703t server.

ATTENTION

Use only DIMMs that are supplied by Nortel.

DIMM removal and installation

When installing DIMMs, ensure that the slots are populated in order, starting with the slot closest to the power connector:

- DIMM 1A (This is the slot closest to the power connector.)
- DIMM 1B
- DIMM 2A
- DIMM 2B

To remove baseboard DIMMs

Step	Action
1	Prepare the server for DIMM replacement as follows: a. Shut down the server, and then disconnect the power and peripheral device cables. b. Place the server on its side. c. Remove the side cover.

For instructions, see "Preparing the server for hardware maintenance" (page 81).

**WARNING**

Failure to follow the procedures in "Preparing the server for hardware maintenance" (page 81) can result in electrical shock or equipment damage.

- 2 Gently push the plastic ejector levers of the DIMM socket out and down to eject a DIMM from its socket.

**CAUTION**

Use extreme care when removing a DIMM. Too much pressure can damage the socket slot. Apply only enough pressure on the plastic ejector levers to release the DIMM.

- 3 Hold the DIMM only by its edges; be careful not to touch its components or gold-edge connectors. Carefully lift it away from the socket, and store it in an antistatic package.
- 4 Repeat to remove other DIMMs as necessary.
- 5 If you are replacing a DIMM, continue with "To install baseboard DIMMs" (page 145).

—End—

To install baseboard DIMMs

**CAUTION**

Use only Nortel-supplied DIMMs. A mixture of dissimilar metals (from the use of other DIMMs) can cause later memory failures, resulting in data corruption.

Step	Action
------	--------

- | | |
|---|---|
| 1 | Prepare the server for DIMM installation as described in "Preparing the server for hardware maintenance" (page 81). |
|---|---|

**WARNING**

Failure to follow the procedures in "Preparing the server for hardware maintenance" (page 81) can result in electrical shock or equipment damage.

- 2 Hold the DIMM only by its edges when you remove it from its antistatic package.
- 3 Compare the length of the gold-edge connectors on the DIMM with the socket, and align them accordingly.
- 4 Press the DIMM firmly down until it clicks into place inside the socket.

**CAUTION**

Use extreme care when installing a DIMM. Too much pressure can damage the socket. DIMMs are keyed and can be inserted in only one way.

Result: The plastic ejector levers close automatically indicating correct installation.

—End—

Replacing the CPU

The 703t server motherboard provides two connectors for Xeon processor chips, but only one is populated for CallPilot. For a single-CPU configuration, the CPU must be installed on the CPU1 connector. A processor terminator board is not required.

CPU replacement package contents

The CPU assembly package contains the following:

- 2.0 GHz AT 400 MHz FSB microprocessor with 512 kbytes of L2 cache memory
- Note:** A higher frequency microprocessor may be provided if the above mentioned frequency becomes obsolete.
- heat sink with guides and clips
 - syringe containing heat sink grease
 - heat sink housing
 - fan

**WARNING**

The microprocessor is extremely sensitive to electrostatic discharge (ESD) and requires careful handling to avoid static damage. To prevent ESD, perform the replacement at an ESD workstation or use an ESD wrist strap.

To remove the faulty CPU

Step	Action
1	Prepare the server for CPU replacement as follows: - Shut down the server, and then disconnect the power and peripheral device cables. - Place the server on its side. - Remove the side cover. - Remove the upper fan holder foam. For instructions, see "Preparing the server for hardware maintenance" (page 81).
2	Disconnect the processor fan cable, and then remove the processor fan. For instructions, see "To remove the processor fan" (page 98).
3	Using both hands, remove the heat sink housing, as follows: Grasp the bottom edge of one side of the heat sink housing, and pry the bottom tabs away from the heat sink.

**WARNING**

Failure to follow the procedures in ["Preparing the server for hardware maintenance" \(page 81\)](#) can result in electrical shock or equipment damage.


- 2 Disconnect the processor fan cable, and then remove the processor fan.
For instructions, see ["To remove the processor fan" \(page 98\)](#).
- 3 Using both hands, remove the heat sink housing, as follows:
 - Grasp the bottom edge of one side of the heat sink housing, and pry the bottom tabs away from the heat sink.

**CAUTION**


Ensure that you do not bend the wings of the heat sink while removing the heat sink housing as this will cause damage to the heat sink.

- Repeat step [a](#) for the other side.
- Lift the housing away from the heat sink.

CPU housing



- 4 Remove the clips that secure the heat sink to the motherboard, as shown in "Heat sink attached to motherboard" (page 149).


Heat sink attached to motherboard

G101790

**CAUTION**

Ensure that you do not bend the wings of the heat sink while removing the clips as this will cause damage to the heat sink.

- 5 Remove the heat sink.
- 6 Remove the microprocessor as shown in ["Remove microprocessor from heat sink" \(page 150\)](#).

Remove microprocessor from heat sink

G101791

- a. Lift the lever that secures the microprocessor to the motherboard.
While applying gentle downward pressure, push the lever away from you (towards the top of the server), and then lift it all the way to the left.
- b. Remove the microprocessor, and put it in an antistatic package.

7 Continue with ["To install a new CPU" \(page 150\)](#).

—End—

To install a new CPU**CAUTION**

Wear an antistatic ESD wrist strap during the entire CPU replacement process.

Step	Action
1	Remove the new microprocessor from its antistatic package. CAUTION Do not touch the pins on the microprocessor. The pins are static-sensitive and bend easily.
2	Install the new microprocessor and heat sink as shown in "Install new CPU" (page 152) . See also the description that follows on page 210 .

Install new CPU



- Ensure that the microprocessor lever is open all the way to the left.
- Align the gold triangle on one corner of the microprocessor with the gold triangle on the socket.


Note: See the top left corner of the microprocessor in the photograph in step 6 on 6.

- c. Apply gentle downward pressure to the microprocessor to seat it in its socket.
- d. Lower and secure the lever.

- e. Apply all of the thermal grease in the syringe that was provided in the CPU assembly package to the metal square on the microprocessor.
 - f. Place the heat sink on top of the microprocessor, and then apply light pressure in a circular motion to spread the grease evenly over the entire metal square.
- 3 Install the heat sink clips as shown in "Install heat sink clips" (page 153). See also the description that follows.

**CAUTION**

Ensure that you do not bend the wings of the heat sink while installing the clips as this will cause damage to the heat sink.


Install heat sink clips

G101780

- a. Align the side tabs on the clip over the heat sink guide.

- b. Align the center hole on the clip over the tab on the heat sink guide.
 - c. Slide the clip forward or back until the tab is in the small portion of the hole.
 - d. With both hands, apply even downward pressure on the ends of the clip until it snaps into place over the end tabs on the heat sink guides.
- 4 Use both hands to install the heat sink housing assembly as shown in "Install heat sink housing" (page 154). See also the description that follows on page 214.

Install heat sink housing



- a. Grasp the bottom edge of each side of the heat sink housing.

- b. Spread the sides of the housing slightly, and then lower the housing over the heat sink.
 - c. Release the housing to engage the tabs around the edge of the heat sink's platform.
 - d. Apply pressure to the top of the housing and work with the bottom tabs until the housing snaps into place. When all four tabs are secured, the housing will not move.
- 5** Install the processor fan.
For instructions, see ["install processor fan" \(page 99\)](#).
- 6** Replace the upper fan holder foam.
- 7** Replace the server's side cover.
- 8** Reconnect all peripheral device cables and power cord.
- 9** Restart the server and ensure that CallPilot starts.

—End—

Chapter 13

Working with the CallPilot server BIOS

In this chapter

"Overview" (page 157)

"BIOS settings" (page 158)

"Updating and configuring the BIOS" (page 162)

"Recovering from corrupted CMOS and BIOS" (page 164)

Overview

The BIOS of the server defines the server compatibility with expansion hardware. All systems configured by Nortel are shipped with at least the minimum vintage BIOS. However, new BIOS may be issued to support new hardware standards and options.

BIOS release

The following are tested and supported releases of BIOS and firmware for the server:

- Intel BIOS release: P16 Build 75
- firmware:
 - BMC 1.18
 - FRU/SDR 5.5i

If these releases are not being used on the 703t server, they must be updated.

To determine the BIOS release

Step	Action
1	Start (or restart) the server.
2	Read the BIOS version on the display.

The BIOS version appears after the MAC address information.

—End—

You can also find the BIOS version in the BIOS configuration sections in the server menu. See ["To configure the BIOS" \(page 163\)](#) for instructions.

BIOS settings

This section identifies the 703t server BIOS settings:

- Main (["Main" \(page 158\)](#))
- Advanced (see ["Advanced" \(page 159\)](#))
- Security (see ["Security" \(page 160\)](#))
- Server (see ["Server" \(page 160\)](#))
- Boot (see ["Boot" \(page 161\)](#))

See ["To configure the BIOS" \(page 163\)](#) for instructions on how to verify that the 703t server settings are set to the values given in the following sections.

Main

Main BIOS settings

Options	Settings
System Time	Set for the current time.
System Date	Set for the current date.
Floppy A:	1.44/1.25/1.2 Mbytes, 3.5 inch
Hard Disk Pre-Delay	Disabled
Primary IDE Master	CD-ROM
Primary IDE Slave	None
Secondary IDE Master	None
Secondary IDE Slave	None

Options	Settings
Processor Settings	- Processor POST speed setting: 2 GHz (shown in grey) - Processor Retest: Disabled - Processor Hyperthreading: Enabled - Processor 1 CPU ID: F24 (shown in grey) - Processor 1 CPU L2 Cache size: 512k ECC (shown in grey) - Processor 2 CPU ID: Not installed (shown in grey) - Processor 2 CPU L2 Cache size: (shown in grey)
Language	English (US)

Advanced

Advanced BIOS settings

Options	Settings
PCI Configuration	Use default values. Default values are generated by pressing F9 before you change CMOS values. - USB: Enabled - NIC1: Enabled - NIC2: Enabled - Video: Enabled - SCSI: Enabled - Option ROM: Enabled (where applicable) - PCI slots ROM: Enabled
Integrated Peripheral Configuration	- COM1: 3f8/IRQ4 - COM2: 2f8/IRQ3 - Parallel Port: ECP/378/IRQ7/DMA Channel 3 - Floppy disk controller: Enabled - Legacy USB support: Auto - Front Panel USB: Disabled

Options	Settings
Memory Configuration	- Extended memory test: Disabled - Bank 1: Installed - Bank 2: Not installed (shown in grey) - Memory Retest: Disabled
Advanced Chipset Control	- Wake on Ring: Disabled - Wake on LAN: Disabled - Wake on PME: Disabled - Wake on RTC alarm: Disabled
Boot Time Diag Screen	Enabled
Reset Config Data	No
Num Lock	On
Sleep Button	Disabled

Security

Security BIOS settings

Options	Settings
Use Password Is	Not Installed
Supervisor Password Is	Not Installed
Fixed Disk Boot Sector	None
Power Switch Inhibit	Disabled
NMI Control	Enabled

Server

Server BIOS settings

Options	Settings
System Management	System Info (shown in grey)

Options	Settings
Console Redirection	• BIOS redirection port: Disabled • ACPI redirection: Disabled • Baud Rate: 19.2K • Flow Control: CTS/RTS • Terminal Type: VT100+
Event Log Configuration	• Clear All Events logs: No • Event Logging: Enabled • Critical Event Logging: Enabled
Fault Resilient Booting	• Late POST timeout: Disabled • Fault Resilient Booting: Stay on • Hard Disk OS Boot Timeout: Disabled • PXE OS boot timeout: Disabled
Assert NMI on PERR	Disabled
Assert NMI on SERR	Disabled
FRB-2 Policy	Disable BSP
AC Link	[Last State]
POST Error Pause	Enabled
Boot Monitoring	Disabled
Boot Monitoring Policy	Retry 3 times

Boot

Boot BIOS settings

Options	Settings
BOOT Device Priority	• Removable Devices • Hard Drive • ATAPI CDROM • IBA 4.1.04 Slot 0118 • IBA GE Slot 0120
V1109	Disabled
Hard Disk Drives	Do Not Change
Removable Devices: ATAPI CDROM Drives	Do Not Change

Updating and configuring the BIOS

BIOS update availability

ATTENTION

The BIOS installed on the CallPilot server must be version P07_64 or later.

BIOS updates are provided by Nortel on a floppy disk (NTRH8057).



CAUTION

Do not power off or restart the server before the BIOS update is complete. If you do, the BIOS will become corrupted.

If the server does lose power during BIOS update (for example, because of a power outage or lightning strike) you will need to perform the BIOS recovery procedure on ["To recover from a corrupted BIOS" \(page 165\)](#).

Note: For a complete list of BIOS settings, refer to ["BIOS settings" \(page 158\)](#).

To update the BIOS

Step	Action
1	Insert the BIOS update disk (NTRH8057) into the floppy disk drive of the server.
2	Restart the server. For instructions, refer to the <i>Installation and Configuration Task List</i> (NN44200-306). Result: The server boots from the floppy disk and the BIOS update begins automatically.
3	When prompted, press 1, and then press Enter.
4	When the BIOS update is finished, the server restarts automatically.
5	While the server is restarting, remove the BIOS update disk from the server's floppy disk drive.
6	When the server has rebooted, continue with "To configure the BIOS" (page 163) .

—End—

To configure the BIOS

Note: Only options that need to be changed from their defaults are described below. As you perform this procedure, you should still validate that all BIOS settings conform to the values listed in ["BIOS settings" \(page 158\)](#).

Step	Action
1	During the server startup and while the startup diagnostics still appear on the screen, press F2 to display the Main menu screen.
2	Press BIOS Default (F9) to load the default BIOS settings. Result: You are prompted to confirm the settings.
3	Choose Yes, and then press Enter. Result: The Main menu reappears.
4	Use the right and left arrow keys to choose the Advanced screen. Result: A list of configuration sections appears.
5	Configure the sections as follows: • Boot-up Diag Screen: Enabled • Num Lock: ON • Sleep Button: Disabled
6	Use the right and left arrow keys to choose the Server screen. Result: A list of configuration sections appears.
7	Configure the sections as follows: • Assert NMI on PERR: Disabled • Assert NMI on SERR: Disabled
8	Use the right and left arrow keys to choose the Boot screen. Result: A list of configuration sections appears.
9	Ensure the boot device order is defined as follows: • first: floppy drive • second: hard drive • third: CD-ROM drive

Note 1: The CallPilot operating system requires that the first startup be completed from the CD-ROM drive. To achieve this

during the startup process, press Esc to display the boot menu, and then choose ATAPI CD-ROM to start the server temporarily from the CD-ROM.

Note 2: The hard drive boot option will not appear in the list if the RAID packs are not configured.

- 10 Use the right and left arrow keys to choose the Exit screen.
- 11 Choose the Exit Saving Changes option, and then press Enter.
Result: You are prompted to confirm.
- 12 Choose Yes to save the changes, and then press Enter.
Result: The server restarts.

—End—

Recovering from corrupted CMOS and BIOS

If the system functions abnormally (for example, it does not start up or it freezes during the startup process), the CMOS may be corrupted. To correct this, follow the procedure in ["To recover from a corrupted CMOS" \(page 164\)](#) below.

In situations where a BIOS is corrupt or a BIOS update is not successful, the 703t server can start in recovery mode. To boot in recovery mode, follow the procedure in ["To recover from a corrupted BIOS" \(page 165\)](#).

To recover from a corrupted CMOS

Step	Action
1	Power down the server.
2	Remove the server cover and access the motherboard.
3	Move the CMOS Clear jumper (J1H1) to pins 2 and 3 (by default, the jumper is set to pins 1 and 2). To determine the jumper location, see "Jumper locations and settings" (page 166) .
4	Power up the server. Result: A message appears stating that the CMOS has been cleared (reset to factory defaults).
5	Power down the server.

- 6 Move the CMOS Clear jumper (J1H1) back to pins 1 and 2.
- 7 Replace the server cover.
- 8 Power up the server.
- 9 Perform CMOS setup.
For instructions, see ["To configure the BIOS" \(page 163\)](#).

—End—

To recover from a corrupted BIOS


Notes:

- To start the server into recovery mode, a memory DIMM module must be installed in the first socket, and a floppy disk drive must be installed.
- The CMOS is not cleared when the system BIOS is updated.

Step Action

- 1 Insert the BIOS update disk (NTRH8057) into the floppy disk drive.
- 2 Power down the server.
- 3 Remove the server cover and access the motherboard.
- 4 Move the Boot jumper (J1H1) to pins 10 and 11.
To determine the jumper location, see ["Jumper locations and settings" \(page 166\)](#).
Note: The jumper connects pins 9 and 10 by default for normal BIOS.
- 5 Power up the server.
Result: The server boots from the floppy disk and the BIOS update begins automatically. A single high-pitched beep tone announces the start of the recovery process.
- 6 Wait until the BIOS update is finished.
A successful update ends with two high-pitched beep tones.
A failed update is indicated by a long series of short beep tones. These tones indicate that some of the BIOS files may be corrupted. Three beeps indicates that the BIOS update disk is not inserted in the floppy disk drive or is not bootable.
- 7 When the BIOS update is finished, the server restarts automatically.

- 8 While the server is restarting, remove the BIOS update disk from the server's floppy disk drive.
- 9 While the BIOS boot initialization screen is displayed, power down the server.
- 10 Move the Boot jumper (J1H1) back to pins 9 and 10.
- 11 Power up the server.
- 12 Verify that the BIOS version was updated.

Jumper locations and settings

G101769

—End—

Appendix A

703t description reference

In this appendix

"Server features" (page 167)

"Slot assignments" (page 172)

"IRQ mapping table" (page 173)

Server features


This section provides a general overview of the 703t server.

Server dimensions

Height	chassis only: 420 mm (16.75 in.)
	with chassis feet: 440 mm (17.5 in.)
Width	chassis only: 215 mm (8.6 in.)
	with chassis feet: 320 mm (12.7 in.)
Depth (distance from front to back)	650 mm (26 in.)
Clearance	- front: 250 mm (10 in.) - rear: 125 mm (5 in.) - side: 75 mm (3 in.) Note: Additional side clearance is required for service. - top: 75 mm (3 in.)
Weight of fully loaded system with	approximately 22 kg (46 lb)
- two SCSI hard drives - six populated boards	

- CD-ROM drive
- floppy drive
- tape drive

Front panel features
703t server front panel features



"Front panel features" (page 168) describes the parts identified in "703t server's front panel features" (page 168).


Front panel features

Part	Function
Reset button	Triggers a hardware (cold) reset. Do not use this button to perform a server restart. Restart the server as described in "Restarting the server" in <i>Installation and Configuration Task List</i> (NN44200-306).

Part	Function
Network controller LEDs (green)	Left: 10/100Base-T controller LED (NIC1 10/100 MB: ELAN for Meridian 1/Communication Server 1000 connection) Right: 10/100/1000Base-T controller LED (NIC2 1 GB: CLAN for Customer LAN connection)
Sleep mode button	Not used
Power button	Turns the server's power on or off.
Status LEDs	Indicate when the server is powered up and the disk drives are active. • Left: hard drive activity LED (not used) • Center: power/sleep LED (green) • Right: status LED (bi-color) indicates whether the server is functioning properly, or whether a hardware event has occurred.
USB connector	For future use
Floppy disk eject button	Ejects the floppy disk.
Floppy drive	Drive for 3-1/2 inch diskettes.
IDE CD-ROM drive (5.25 in.)	Enables you to use the CallPilot software and documentation CD-ROMs.
CD drive eject button	Opens the CD-ROM drawer. Push the button again to close the drawer.
Backup tape drive	Allows backup of hard drive data.
Hard drive 1	10,000 rpm hard drive
Hard drive 2	10,000 rpm hard drive
Drive bay	Vacant
Drive bay	Vacant
Drive bay	Vacant
Air flow slot	Must remain empty for proper system cooling.

Rear panel diagram

703t server rear panel features



Note: For more information, see "Slot assignments" (page 172).

703t server rear panel parts

Part	Color
AC power supply connector (450 W non hot-swap power supply)	Not applicable
USB connectors	Not applicable
PS/2 keyboard connector	Purple
PS/2 mouse connector	Green
COM1 serial port connector (9-pin)	Teal
Parallel port connector (25-pin)	Pink
Monitor connector (15-pin)	Blue

Part	Color
10/100/1000Base-T CLAN network connector for Customer LAN connection (NIC2 1 GB)	Not applicable
Note: For more information, refer to the description of LAN connectivity in <i>703t Server Hardware Installation</i> (NN44200-304).	
10/100Base-T ELAN network connector for Meridian 1/Communication Server 1000 connection (NIC1 10/100 MB)	Not applicable
Note: For more information, refer to the description of LAN connectivity in <i>703t Server Hardware Installation</i> (NN44200-304).	
PCI slots (6)	Not applicable
- Four slots are 100 MHz 3.3 V 64-bit PCI slots. - Two slots are 33 MHz 5 V 32-bit PCI slots.	
Note: For more information, see "Slot assignments" (page 172) .	
COM2 serial port connector slot (not installed)	Teal

Environmental specifications

Environmental condition	Specification
Operating temperature	10°C to 35°C (50°F to 95°F)
	Maximum rate of change must not exceed 10°C (50°F) per hour.
Non-operating (storage) temperature	-40°C to 70°C (-40°F to 158°F)
Non-operating humidity	95%, non-condensing at 30°C (86°F)
Altitude	1829 m (6000 ft)
Electrostatic discharge	15 kV or more
Acoustic noise	50 dBA in a typical office ambient temperature (18°C to 25°C [64.4°F to 77°F])

Environmental condition	Specification
Operating shock	No errors with a half sine wave shock of 2G (with 1 millisecond duration)
Handling drop	Operational after a free fall from 450 mm to 600 mm (18 in. to 24 in.) (depending on weight)

Slot assignments

The slot assignment tables show:

- the physical location of boards inside the server, relative to other boards
- the order in which boards are installed (for example, board #1, 2, 3, and so on)
- how the boards are represented in CallPilot Manager applications (that is, on the Maintenance Administration page)
- the maximum capacity for each switch connectivity

Note: Your server may vary depending on what was ordered from Nortel; therefore, your server may not have all of the slots populated.

Slot definition and numbering

In "Slot definition and numbering" (page 172), the term "slot" refers to the available slot openings in the chassis, not the PCI connectors inside the server.

The slots are numbered from the bottom of the server to the top. Slot 1 is the bottom slot in the chassis when the chassis is standing upright.

Slot definition and numbering

Slot number	CallPilot-assigned board label ^a	Meridian 1 or Communication Server 1000
PCI slot 7 (full length)	Not used	Not used
PCI slot 6 (full length)	BRD06	RAID card
PCI slot 5 (full length)	BRD05	Not used
PCI slot 4 (full length)	BRD04	MPB96 board

a. In CallPilot Manager applications, the Callpilot-assigned board label may appear. This label corresponds to the slot number. For example, BRD01 refers to the board in slot 1.

Slot number	CallPilot-assigned board label ^a	Meridian 1 or Communication Server 1000
PCI slot 3 (full length)	BRD03	Not used
PCI slot 2 (full length)	BRD02	Not used
PCI slot 1 (full length)	BRD01	Not used

a. In CallPilot Manager applications, the Callpilot-assigned board label may appear. This label corresponds to the slot number. For example, BRD01 refers to the board in slot 1.

IRQ mapping table

"IRQ mapping" (page 173) lists the assignments for each Interrupt Request (IRQ). You do not need this information for installation, but it may be useful for troubleshooting.

IRQ mapping

Interrupt	I/O APIC level	Slot or device
INTR	INT0	Processor interrupt
IRQ0	INT2	Timer (from PIIX4)
IRQ1	INT1	PS/2 keyboard controller
IRQ2	Not applicable	Internal/reserved
Note: IRQ2 is actually shared with IRQ9 as a cascade interrupt to support IRQs 8–15.		
IRQ3	INT3	Onboard serial port B (COM2)
IRQ4	INT4	Onboard serial port A (COM1)
IRQ5	INT5	Available
IRQ6	INT6	Floppy disk drive controller
IRQ7	INT7	Parallel port 1(LPT1)
IRQ8	INT8	Real Time Clock
IRQ9	INT9	Available
IRQ10	INT10	Available
IRQ11	INT11	Available
IRQ12	INT12	PS/2 mouse
IRQ13	INT13	Internal/reserved

Interrupt	I/O APIC level	Slot or device
IRQ14	INT14	IDE controller
IRQ15	INT15	Available

Index

Symbols/Numerics

703t server
 dimensions
 environmental specifications 171
 front panel, description 168, 169
 hard drive bays 169
 IRQ assignments 173
 LEDs 169, 169
 PCI slots 171
 slot assignments 172, 173
 slot locations 170

A

Alarm Monitor, using 53, 55
 alarms
 about 52, 53
 investigating 53
 alert icons, component states 61
 application event log
 description 32
 arp command 39
 parameters and descriptions 39
 running from Windows 40
 syntax 39

B

beep codes 24
 interpretation 24
 BIOS
 configuring 163, 163
 upgrading
 overview 157
 vintage 157

C

cabling
 RAID system
 with CD-ROM and tape drive 101
 call channels
 disabling 57
 working with 69, 71
 CallPilot
 utilities
 Diagnostics Tool 73
 PEP Maintenance 73, 75
 Session Trace 73, 76
 System Monitor 74
 CallPilot Manager
 Alarm Monitor, using 53, 55
 alarms
 about 52, 53
 investigating 53
 alert icons, component states 61
 Channel Monitor, using 57, 69, 71
 Event Browser, using 55, 57
 events
 about 52, 55
 investigating 55
 fault management
 alarm notification 52
 event processing 52
 Maintenance screen
 General section 58
 Maintenance section 59
 purpose 57
 Multimedia Monitor, using 57, 67, 69
 CallPilot services, Channel Monitor tab 78
 CD-ROM

- cabling 101
- Channel Monitor tab 78
 - CallPilot services 78
 - critical 78
 - DS30X links pane in 79
 - DSP pane in 79
- Channel Monitor, using 57, 69, 71
- channels
 - call, working with 69, 71
 - disabling 57
 - multimedia, working with 68, 69
- chassis
 - accessing 82
- chkdsk
 - Windows 46, 48
- chkdsk utility 42
 - parameters and descriptions 43
 - running from Windows 43
 - syntax 43
- commands
 - Net Start 50
 - Net Stop 46
 - TSTSERIO 47, 48, 48, 49
- commands, TCP/IP
 - arp 39
 - ipconfig 36
 - nbtstat 40
 - netstat 41
 - ping 36
 - tracert 38
- compatibility
 - DIMMs 143
- components
 - CallPilot Manager maintenance
 - activities 59
 - dependencies 52
 - diagnostics that can be run 65
 - diagnostics-eligible 65
 - list 58
 - replacing 13
 - states
 - Alert icons 61
 - description 60, 61
 - viewing 61
- configuring
 - BIOS 163, 163
- cooling fan

- removing 89
- replacing 92, 95, 98

Courtesy stop, description 62

CPU servers

- BIOS settings 163
- configuring the BIOS 163

critical services, CallPilot 78

D

diagnostic tools

- Power-On Self Test (POST) 17
- RAID controller 17
- SCSI controller 17
- TSTSERIO tests 47, 48, 48, 49

diagnostics

- integrated
 - running 64, 66, 66
 - troubleshooting failures 65
 - when to run 64
- last results
 - viewing 67, 67
- POST 24
- serial port
 - overview 45
- startup 17
- TCP/IP 31, 35
 - arp 39
 - ipconfig 36
 - nbtstat 40
 - netstat 41
 - ping 36
 - tracert 38

diagnostics tool

- CallPilot 73

diagrams

- front panel 168
- rear panel 170, 170

dimensions, 703t server

DIMMs

- compatibility 143
- motherboard
 - installing 146
- removing 143
- sizes 143
- sizes and compatibility 143

E

- environmental specifications, 703t
 - server 171
- error messages 24
 - POST 24
- Event Browser, using 55, 57
- event log
 - system 32
- event logs
 - application 32
 - security 32
 - types, description 32
 - viewing 33
- events
 - about 52, 55
 - investigating 55

F

- failure to boot into service
 - boot failure 17
- fan
 - removing 89
 - replacing 92, 95, 98
- fault management
 - alarm notification 52
 - event processing 52
- firmware
 - vintage 157
- Firmware revision
 - verifying 122
- firmware, flashing the 126
- flashing the 123
- front panel, description 168, 169

G

- General section, Maintenance screen 58

H

- hard drive bays 169
- hardware
 - motherboard DIMMs
 - installing 146
 - removing 143
 - peripherals
 - cables 82

- RAID system

- cabling 101

- SCSI bus

- cabling 101

- SCSI drive

- installing 103

- removing 106

- hardware problems, detecting 53

I

- IDE hard drive

- LED 22

- installation

- cooling fan 92, 95, 98

- motherboard DIMMs 146

- SCSI drive 103

- integrated diagnostics

- running 66, 66

- troubleshooting failures 65

- when to run 64

- ipconfig command 36

- flags and descriptions 36

- running from Windows 36

- syntax 36

- ipconfig default 36

- IRQ assignments, 703t server 173

L

- LEDs

- IDE drive 22

- network 19

- network controller 169

- power status 20

- SCSI device 19, 21

- system status 169

- Legend/Help tab 80

- logs

- event, viewing 33

- types, viewing 32

M

- maintenance

- activities by component 59

- preparing for 14

- Maintenance screen, CallPilot Manager

- General section 58
- Maintenance section 59
- purpose 57
- mapping 163
 - PCI IRQs to I/O APIC 163
- motherboard
 - removing DIMMs 143
- multimedia channels, working with 68, 69
- Multimedia Monitor, using 57, 67, 69

N

- nbtstat command 40
 - parameters and descriptions 40
 - running from Windows 41
 - syntax 40
- Net Start command 50
- Net Stop command 46
- netstat command 41
 - parameters and descriptions 42
 - running from Windows 42
 - syntax 42
- network LED 19

P

- parts, obtaining replacement 13
- PCI slots 171
- PEP Maintenance utility 73, 75
- peripherals
 - cables 82
- ping command 36
 - parameters and descriptions 37
 - running from Windows 37
 - syntax 37
- power status LED 20
- Power-On Self Test (POST) 17
 - beep codes 24
 - meaning 24
 - countdown codes 24
 - diagnostics 24
 - error codes 24
 - error messages 24
 - interpreting messages 24
 - message formats 24

Q

- quitting
 - system 45

R

- RAID 121
 - upgrading 123
- RAID configuring summary 133
- RAID controller
 - diagnostics 17
- RAID firmware
 - upgrading 126
- RAID splitting summary 134
- RAID system
 - cabling 101
 - with CD-ROM and tape drive 101
 - configuring 124
- rear panel, description 170, 171
- Redundant Array of Independent Disks (RAID) 121
- removing
 - fan 89
 - motherboard DIMMs 143
 - SCSI drive 106
- replacement parts, obtaining 13
- replacing
 - fan 92, 95, 98
 - motherboard DIMMs 143, 146
 - SCSI drive 103, 106
- restarting system after TSTSERIO tests 49

S

- SCSI bus
 - cabling 101, 101
- SCSI controller
 - diagnostics 17
- SCSI device LED 19, 21
- SCSI drive
 - installing 103
 - removing 106
- SCSI ID 110
- security event log
 - description 32
- serial port
 - diagnostics 45

- server
 - dimensions
 - environmental specifications 171
 - fan
 - removing 89
 - replacing 92, 95, 98
 - front panel, description 168, 169
 - hard drive bays 169
 - IRQ assignments 173
 - LEDs 169, 169
 - mapping 163
 - mapping PCI IRQs to I/O APIC 163
 - PCI slots 171
 - slot assignments 172, 173
 - slot locations 170
 - servicing
 - fan 89, 92, 95, 98
 - Session Trace utility 73, 76
 - settings
 - BIOS 163, 163
 - shutting down
 - system 45
 - sizes
 - DIMMs 143
 - slot assignments 172, 173
 - slot locations 170
 - specifications, environmental 171
 - speed setting for CPU 163
 - startup
 - diagnostics 17
 - Stop, description 62
 - system
 - restarting after TSTSERIO tests 49
 - shutting down 45
 - system event log
 - description 32
 - System Info tab 79
 - System Monitor 74
 - Channel Monitor tab 78
 - Legend/Help tab 80
 - System Info tab 79
 - using 77
 - system utilities
 - System Monitor 77
- ## T
- tape drive
 - cabling 101
 - configuring 110
 - faulty, replacing 111
 - TCP/IP diagnostics 31, 35
 - arp 39
 - ipconfig 36
 - nbtstat 40
 - netstat 41
 - ping 36
 - tracert 38
 - testing
 - POST diagnostics 24
 - tracert command 38
 - parameters and descriptions
 - running from Windows 38
 - syntax 38
 - TSTSERIO command 47
- ## U
- upgrading
 - BIOS
 - overview 157
 - utilities
 - chkdsk 42
 - Diagnostics Tool 73
 - PEP Maintenance 73, 75
 - Session Trace 73, 76
 - System Monitor 74, 77
- ## V
- viewing 33
 - vintage
 - BIOS 157
 - BIOS and SSU 157
- ## W
- Windows
 - chkdsk utility 46, 48
 - viewing 33

Nortel CallPilot

703t Server Maintenance and Diagnostics

Copyright © 2007, Nortel Networks
All Rights Reserved.

Publication: NN44200-702
Document status: Standard
Document version: 01.03
Document date: 3 April 2007

To provide feedback or report a problem in this document, go to www.nortel.com/documentfeedback.

Sourced in Canada

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks.

*Nortel , the Nortel logo, and the Globemark are trademarks of Nortel Networks.

*Microsoft, MS, MS-DOS, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

All other trademarks and registered trademarks are the property of their respective owners.

