




ASUS U57A-BBL4 Optical Drive Replacement

How to replace the CD/DVD reader (optical drive) in the ASUS U57A-BBL4.

Written By: Isabella Bernardi



INTRODUCTION

If your laptop does not read CD's or DVD's properly, there might be a problem with the optical drive. The following guide will help you replace the optical drive.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #00 Screwdriver](#) (1)


Step 1 — Battery



! Make sure the laptop is completely shut down to avoid data complications.

- Hold the left lock switch towards the left to the unlock option.

Step 2




- Toggle the right lock switch to the unlock option.

Step 3




- Gently slide the battery out while still holding the left unlock switch.

Step 4 — Front Panel Assembly




- Remove the two 2 mm Phillips head screws on each side on the bottom using PH00 screw driver.
- Remove the one 2 mm screw underneath the black cover in the middle using the same screw driver.

Step 5




- Remove the RAM by lifting up with your fingers and sliding it out towards you.

Step 6



- Remove the three 2 mm Phillips head screws on the hard drive using PH00 screw driver.
- Remove the remaining seven 1.8 mm Phillips head screws using the same screw driver.

Step 7




- Remove the hard drive by sliding it to the left and lifting up.

Step 8



- Remove the six 2 mm Phillips head screws on the top edge of the laptop using PH00 screw driver.
- Flip the laptop right-side up and open the screen.

Step 9



- Starting in a corner of the keyboard, pry the keyboard from the laptop using a plastic opening tool.
- Remove the ribbon cable on the bottom of the keyboard by lifting up on the tape and pulling up.

ⓘ The front panel is now loose from the laptop.

Step 10 — Optical Drive



- Slide the optical drive out. It should easily come out.

To reassemble your device, follow these instructions in reverse order.