



Acer Chromebook C720-2848 Battery Replacement

This guide will help users replace the battery in their Acer Chromebook C720-2848.

Written By: Robert Escobio




INTRODUCTION

Use this guide to replace the battery in your device.

TOOLS:

- **Phillips #0 Screwdriver** (1)
- **Spudger** (1)

Step 1 — Back Cover



- Use a Phillips head screw driver to remove the 13 screws in these locations.

Step 2



- Use a plastic spudger to pry up the bottom cover and remove it.

⚠ Be sure to pry along other edges if necessary to avoid damaging the back cover.


Step 3 — Battery



- Unscrew the 2 battery screws.

- ★ Make sure you keep these screws separate from the back cover screws; they are different!

Step 4



- Use two fingers to unplug the battery-to-motherboard connection.

Step 5



- Take out battery by lifting it up in the manner pictured.

To reassemble your device, follow these instructions in reverse order.