



Asus ROG G751JL-BB17T29 RAM Access Door Replacement

Prerequisite-only to remove the RAM access door in an Asus ROG G751JL laptop.

Written By: Adam O'Camb



INTRODUCTION

Prerequisite-only guide to remove the RAM door.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [iFixit Opening Picks set of 6](#) (1)
- [Phillips #00 Screwdriver](#) (1)

Step 1 — Remove the RAM access door



- Use an opening tool to pry up the small rubber cover on the upper right corner of the RAM access door.

Step 2



- Remove the 5.3 mm Phillips #00 screw securing the RAM access door.

(i) This screw is held in the hole in the door with a washer and will not come out of the hole, even after you unscrew it.

Step 3



- Insert the point of an opening pick in the seam near the top right corner of the RAM access door and gently pry the door up slightly.
- The door is held in place by small clips around its edges. Pry until you feel the nearest clips release.

Step 4



- Insert the wide edge of an opening pick into a new part of the seam between the door and the computer.
- Pry the door up to release the clips closest to the pick.
- Continue to slide the pick along the seam all the way around the door, prying as you go, until all the clips holding the door down have been released.

Step 5



- Remove the RAM access door.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-12-31 04:13:38 PM (MST).

