



CRACKS IN TALL OBJETS

Written By: abhishek j

Step 1 — CHECK EXTRUCTION TEMPERATURE--1



- Go to main menu and see the nozzle temperature
- go to **control**
- go to **Temperature**

Step 2 — CHECK EXTRUCTION TEMPERATURE--2



- Select the extruder
- Increase the extruder temperature by 5 degree.

Step 3 — CHECK THE FAN



- Check the direction of the flow of the fan air.
- Check the fan is working or not.
- Check the fan speed is good or not.

To reassemble your device, follow these instructions in reverse order.