




Canon PowerShot SD 600 Exterior Frame Replacement

In order to install any interior parts of the camera, it will be necessary to uninstall and re-install the exterior frame. This guide will entail a simple procedure to remove the exterior frame.

Written By: Apurva Patel



This document was generated on 2019-09-23 10:29:14 AM (MST).

INTRODUCTION

In this guide, we will remove the battery, the SD card, the screws on the exterior frame, other exterior components, and finally the exterior frame itself.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Battery/SD Card



- Turn the camera over so that the battery compartment is visible. The compartment should read "Card/Batt. Open".
- Open the compartment.
- Lightly push the compartment lid down and outward. The arrow next to "Card/Batt. Open" indicates the direction you should be pushing.

Step 2



- Once the lid is open, the battery and SD card compartments become visible.
- Notice the red tab on the right side of the battery.
 - Slide this tab off the battery.
 - The battery is now free to slide out of the compartment.

(i) The battery will not pop out of the compartment. The camera needs to be tilted in order to slide the battery out.

Step 3



- To remove the SD card push it down and it will eject out. (SD card not shown)
- ▣ Be sure the new or recharged battery is facing the correct direction. An arrow on the battery indicates which end should be inserted into the compartment first.
- ⓘ If you plan on disassembling the camera further, you should leave the battery and SD card removed. Make sure to close the battery compartment once the battery and the SD card are removed.

Step 4 — Exterior Frame



- There are six 3mm exterior screws that will need to be removed in order to remove the exterior frame.
 - Two screws near the tripod mount on the underside of the camera.
 - Two screws on the camera left hand side (the face with nothing but screws on it).
 - Two screws on the camera right hand side, by the wrist strap attachment.
- Remove the screws using the screwdriver.


(i) It is important to note that the camera has been rotated from the previous orientation in order to show the screws properly.

Step 5



- Remove the wrist strap attachment.
 - Use the spudger to pry it open.
 - Remove the small circular cover underneath the wrist strap attachment.

Step 6



- Carefully pull apart the two parts of the exterior frame.
 - Use the spudger to pry apart the two frame components.
 - Once disconnected, the two parts of the frame can be easily separated by using your fingers.
 - The rear frame should be removed first.
- There should be an O-ring on the front face of the camera. Ensure to keep the O-ring with the front part of the frame.

(i) The orientation for the pictures is changed in order to properly show which piece is being removed.

To reassemble your device, follow these instructions in reverse order.