



Cleaning Function Buttons

This guide will show how to clean the function button to the right of the LCD if they are sticking.

Written By: Tyler Grossheim



INTRODUCTION

Use this guide to clean the function buttons.

TOOLS:

- Cotton Swab (1)

Step 1 — Front and Rear Cover



- Remove wrist strap and battery.


Step 2



- Remove 2 screws from each side of the camera (4 total, 0.102 in).
- Remove 2 screws from the bottom on the camera (0.138 in).

⚠ Do not mix the 4 side screws with the 2 bottoms ones; they are different sizes.

Step 3




- Gently pull off the front cover.
- The plate on the side should come off.
- Gently pull off the back cover.

Step 4



- The cases should now be removed.

Step 5 — Cleaning Function Buttons



- Clean around the function buttons with a cotton swab dipped in isopropyl alcohol.

To reassemble your device, follow these instructions in reverse order.