



Dell Alienware M17x R3 Hard Drive Replacement

Written By: Terrence15



INTRODUCTION

In this guide, we will show you how to remove and replace the Hard Drive.

TOOLS:

- [Phillips #0 Screwdriver \(1\)](#)

Step 1 — Loosen the Captive Screws




⚠ WARNING: Before working inside your computer, read the safety information that shipped with your computer.

⚠ CAUTION: To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface (such as a connector on your computer).

- Loosen the three captive screws that secure the hard-drive assembly to the computer base.

Step 2 — Lifting the Hard-Drive




- Using the pull-tab, lift the hard-drive assembly to disconnect it from the connector on the system board.

Step 3 — Lifting the Hard-Drive Assembly



- Lift the hard-drive assembly out of the computer base.

Step 4 — Remove the Screws



- Remove the four screws that secure the hard drive to the hard-drive bracket.

Step 5 — Lifting the Hard-Drive



- Lift the hard-drive off the hard-drive bracket.

Step 6 — Remove the Interposer




- Remove the interposer from the hard drive.

Step 7 — Connecting the Interposer




- Connect the interposer to the **NEW** hard drive.

Step 8 — Placing the Hard Drive



- Place the hard drive in the hard-drive bracket.

Step 9 — Replace the Screws



- Replace the four screws that secure the hard drive to the hard-drive bracket.

Step 10 — Align the Connector



- Align the connector on the hard drive with the connector on the system board and press the hard drive until it is fully seated.

Step 11 — Tighten the Screws



- Tighten the three captive screws that secure the hard-drive assembly to the computer base.

To reassemble your device, follow these instructions in reverse order.