




# Dell Optiplex GX620 CMOS Battery Replacement

This guide will teach you how to remove the CMOS battery.

Written By: Kristina



## INTRODUCTION

The CMOS battery maintains the time, date, hard disk and other configuration settings in the CMOS memory. When your CMOS battery dies, your system settings will be lost.

### **TOOLS:**

- [Phillips #0 Screwdriver](#) (1)
- [Spudger](#) (1)

### **PARTS:**

- [CR2032 Lithium Battery](#) (1)

## Step 1 — How to unplug and discharge before repair



- Power down your PC and remove the power cord from the back.

## Step 2



- Press and hold the power button for about 10 seconds, then release.
- *This helps drain any remaining power stored in the capacitors, so that you can safely work on the internal components.*


## Step 3 — Dell Optiplex GX620 Side Panel Disassembly



- With the computer standing upright, firmly pull on the tab at the back of the computer.
- When the side panel pops free, gently pull the panel away from the computer.

**i** If you have trouble freeing the side panel from the case, you may need to pull the tab a bit harder.

## Step 4 — Removing the CMOS Battery



- Insert a tool beside the battery and gently pry the battery out.

**!** Using a screwdriver to pry open anything can harm your device. Instead, use a spudger or a plastic opening tool.

To reassemble your device, follow these instructions in reverse order. Make sure you place the battery with the flat (positive) side facing up.

