



Disassembling HP Mini 110-1046NR Memory Card Cover

Prerequisite guide for replacing the memory card or removing the Keyboard Bezel

Written By: Jared Cooper



INTRODUCTION

Prerequisite only

TOOLS:


- [Spudger](#) (1)
- [Phillips #1 Screwdriver](#) (1)

Step 1 — Battery



- Power-off the netbook fully before attempting to remove the battery.
- Flip your netbook upside down, and locate the sliding tabs near the battery.
- Slide both tabs inward so that the battery visibly moves away from the case of the computer.
- Release the tabs and pull the battery out.

Step 2 — Memory Card Cover



- Flip the netbook over so you are looking at the bottom, and locate the two screws that hold the memory card cover.
- Next, take a Phillips PH1 screwdriver and unscrew the two screws.
(i) These screws will not release from the cover once they are unscrewed.
- If necessary, use the flat end of the spudger to assist in prying the cover away from the computer.

To reassemble your device, follow these instructions in reverse order.