




Dremel 8200 Disassembly

Disassembling your Dremel 8200.

Written By: mitchellbarnhart



INTRODUCTION

Disassembling your Dremel 8200.

TOOLS:



- Phillips #0 Screwdriver (1)

Step 1 — Dremel 8200 Disassembly



- Take off the screw cap at the top

Step 2



- Take out the battery

Step 3



- Remove oblong belt clip

Step 4



- Unscrew screws



Step 5



- Take back u clip out carefully


Be very careful to not injure yourself

Step 6





- The casing should just open right up and be easily accessible

Step 7



- You can remove the buttons except for the sliding one that adjusts the speed

Step 8



- You can take the motor out first and it will be a little hard to do so
- Work your way down and take out each successive circuit board
- The last thing to be out should be the sliding speed adjustment and the button for that should fall right out

This document was generated on 2019-09-18 01:22:39 PM (MST).

To reassemble your device, follow these instructions in reverse order.