



Dyson V8 Absolute Bin Replacement

Replacing the bin in the case of cracks or damage.

Written By: Miranda Laberge



INTRODUCTION

This guide will explain the process of removing the bin on the Dyson V8 Absolute. In the case of a broken or cracked bin, it is important to replace the bin for it to properly hold debris.

Step 1 — Bin



- ⓘ Set the device upright on a flat surface and detach the wand.
- Pull the red bin release trigger, on top of the cyclone. This will require some force.

Step 2



- Pull up on the latch until it's fully extend.
- ⓘ The bin will open to dispense debris once the red latch is pulled.

Step 3



- Push the red circular button to release the latch on the cyclone.
- The cyclone should release and be fully detached from the device.

Step 4



- Push on the red release button on the bottom of the bin.
- The bin should slide away from the handle.

To reassemble your device, follow these instructions in reverse order.