



GAPING BETWEEN INFILL AND OUTER WALL

Written By: abhishek j

Step 1 — CHECK THE INFILL



- Go to kisslicer
- go to **style**
- Adjust the **infill density**
- Adjust **Infill extrusion width** and **Infill style**

Step 2 — INCREASE THE THICKNESS OF OUTER WALL



- Open **kisslicer**
- Increase the **skin thickness**
- **skin thickness=Extrusion width *no of loops**

Step 3 — INCREASE THE NOZZLE TEMPERATURE



- Go to **control** in machine menu
- Click **Temperature**
- Go to **nozzle 1** and increase the temperature by **5 degree**

Step 4 — DECREASE THE PRINT SPEED



- Go to **main menu**
- If you Rotate the knob in anti clock wise direction, the speed will be decreasing.
- Decrease the speed by 20%

To reassemble your device, follow these instructions in reverse order.