



Game Boy Color LCD Ribbon Cable Replacement

This guide shows how to disconnect the LCD Ribbon cable so other components may be safely removed.

Written By: Nick Katsantones



This document was generated on 2019-09-23 03:28:18 AM (MST).

INTRODUCTION

Removing the ribbon cable provides unhindered access to the inner workings of the Game Boy Color.

TOOLS:


- [Spudger](#) (1)
- [Tri-point Y0 Screwdriver](#) (1)

Step 1 — Battery



- Locate the battery compartment on the back of the Game Boy Color.
- Push down on the tab and hinge the cover downwards and outwards to remove the battery cover.

Step 2



- Remove the batteries from the battery compartment.

Step 3 — Back Housing




- Using a Y1 screwdriver, remove the six screws on the back of the device as pictured. The bottom two screws are located inside of the battery compartment.

Step 4



- Gently lift and separate the back housing from the rest of the device. Now you've got the back housing out!

Step 5 — LCD Ribbon Cable



- Push up on the tabs on either side of the ribbon with a spudger.

Step 6



- Gently remove the ribbon cable from the port

To reassemble your device, follow these instructions in reverse order.