




# HP 15-AF131DX Optical Drive Replacement

Replacing the optical drive (disk drive) on an HP 15-AF131DX Notebook

Written By: Aaron McCallister



## INTRODUCTION

The Optical Drive allows your notebook to use CD's and DVD's to listen to music and watch movies. Sometimes optical drives can be used to write your own personal data onto CD's. Make sure your notebook is unplugged and turned off.

### TOOLS:


- Phillips #0 Screwdriver (1)
- Paper Clip (1)

## Step 1 — Optical Drive




- Using a small Phillips screwdriver, *remove the Phillips screw* in the middle of the bottom of the computer.
- *Pull the CD/DVD drive outward* to slide it away from the computer.

## Step 2



- To open the drive use an unbent paperclip and *press it into the small hole until the disc tray releases*.
- Pull the disc tray out from the front until it is as far as it will go out of the optical drive.

## Step 3



- To remove excess parts from the optical drive *press down on the plastic tab* behind the tray's bezel.
- Gently pry the **bezel** from the face of the optical drive.
- With a smaller phillips head screwdriver, *remove the screws on the back of the drive* , then remove the small metal bracket.

To reassemble your device, follow these instructions in reverse order.