




# HP 17-bs049dx Fan Replacement

This guide will show you how to replace the fan in the HP 17-bs049dx laptop.

Written By: Juan Seoane-Seri




# INTRODUCTION

Use this guide to replace the fan in your laptop.

## TOOLS:

- **Metal Spudger** (1)
- **Phillips #0 Screwdriver** (1)
- **Phillips #000 Screwdriver** (1)


## Step 1 — Battery



- To remove the battery, simply push the tabs towards each other.

**!** The battery will come out with force, be sure to keep anything fragile away from the laptop during this process.


## Step 2 — Back Panel



- Remove the four screws (13.7mm) with a Phillips #0 screwdriver.
- Be sure to lift all four rubber tabs to access screws (7.51mm) underneath.

**!** Rubber tabs will require force to access screws.

## Step 3



- Use the Philips 0 screwdriver to unscrew the screws (7.51mm) that were underneath the battery.

## Step 4



- Pull outwards on the disk reader to remove from main frame.

**⚠** This removal will require force.

**⚠** All screws must be removed before removing disk reader.

## Step 5



- Lift back panel to access internal components.


 You will need to use force to pry it open.

## Step 6 — Fan



- Unscrew all four screws connecting the heatsink to the motherboard.
- (i)* The screws holding the heat sink will not detach from the heat sink.
-  All four screws must be loosened before removing the heat sink.
- After loosening all screws remove the heat sink and store it in a safe place.

## Step 7



- After removing the heat sink, disconnect the cable connecting the fan to the motherboard.

## Step 8



- Remove the old fan from the device.

To reassemble your device, follow these instructions in reverse order.