



HP 17-bs049dx Motherboard Replacement

How to replace a motherboard in an HP 177-bs049dx device.

Written By: Chanceline Mbiaooh




INTRODUCTION

The motherboard is the link between all the different components in the computer. If you've had your device for a while and it malfunctions, you might assume it's a problem with the motherboard. Before you start opening up the device, check connection and peripherals and listen for beeps.

TOOLS:

- Phillips #0 Screwdriver (1)
- Metal Spudger (1)


Step 1 — Back Panel



- Remove the four screws (13.7mm) with a Phillips #0 screwdriver.
- Be sure to lift all four rubber tabs to access screws (7.51mm) underneath.

⚠️ Rubber tabs will require force to access screws.

Step 2



- Use the Philips 0 screwdriver to unscrew the screws (7.51mm) that were underneath the battery.

Step 3



- Pull outwards on the disk reader to remove from main frame.

⚠ This removal will require force.

⚠ All screws must be removed before removing disk reader.


Step 4



- Lift back panel to access internal components.


⚠ You will need to use force to pry it open.

Step 5 — Hard Drive




- Remove screw (7.51mm) on USB port with "Phillips 0 Screwdriver".
- Lift the USB port over and away from hard drive.

Step 6



- Lift rubber black tabs located on the hard drive upwards.
- Disconnect hard drive from motherboard by pulling towards you.


Step 7 — Motherboard



- Make sure to unplug everything connected to the motherboard.

 Be gentle with this step.

Step 8



- Remove the screws (7.51mm) with a Phillips #0 screwdriver.
- Once all of the screws are removed, remove the motherboard from the device.

To reassemble your device, follow these instructions in reverse order.