



HP Chromebook 11 G4 Keyboard Replacement

This guide will show you how to replace the keyboard on your HP Chromebook 11 G4.

Written By: Jair Herrera



INTRODUCTION

This guide will walk you through the replacement process of a defective or broken keyboard on your HP Chromebook 11 G4. Removing the keyboard is also the basic step to accessing all of the other internal components.

TOOLS:

- Phillips #1 Screwdriver (1)
- Spudger (1)

PARTS:

- HP Chromebook 11 G3/G4 Palmrest Keyboard Assembly (1)

Step 1 — Keyboard



- Position the closed Chromebook with the rubber pads are facing up.

Step 2



- Slide the flat end of the spudger under the rubber pads at the upper right-hand and the upper left-hand corners.
- Pry off the rubber pads to reveal a screw under each pad.

⚠ The rubber pads are attached with a strong adhesive. The force applied may damage the pads.

This document was generated on 2019-09-28 01:53:26 PM (MST).

Step 3



- Remove the eleven 6mm Phillips #1 screws.

Step 4




- Flip over the Chromebook and open it.

Step 5




- Insert the flat end of the spudger between the bottom body of the Chromebook and keyboard body.
 - Slide the spudger along the gap, applying downward pressure to separate the two components.
- (i)* You should hear popping sounds as you slide the spudger along the edge.
- (i)* If the spudger gets stuck while sliding, simply slide the spudger back for a bit, and continue sliding forward.

Step 6



- Lift the bottom of the keyboard assembly to reveal the internal components of the device.

Step 7



- Use the pointed end of the spudger to flip up the black tabs on the two ZIF connectors located on the motherboard.
- Disconnect the ribbon cables from the motherboard by gently sliding them out of their sockets.

Step 8



- Remove the keyboard assembly by lifting it off the laptop base.

To reassemble your device, follow these instructions in reverse order.