




HP Envy m6 1220sb Disassembly

i bought a broken hp envy, i will show you how to open it and how you can replace/fix multiple parts.

Written By: Kevin D



INTRODUCTION

Hello all,

In my opinion it is not the best laptop from HP. actually its a difficult laptop to work on.

a expensive laptop for (inside) parts that could be better parts.. certainly for a hp laptop

i made this guide during night so it is not my best guide that i've written so far.

I hope it helps you fixing your hp envy m6 ..

good luck

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Philips 000 Screwdriver](#) (1)
- [iSesamo Opening Tool](#) (1)
- [Tweezers](#) (1)
- [IC Extractor/Connector Puller](#) (1)
- [Spudger](#) (1)

Step 1 — HP Envy m6 1220sb Disassembly




- first of all we are going to remove the bottom plastic plates and the battery
- I apologize for the bad light (and my Englisch , my native language is dutch), i made this guide during night..
- after removing the battery and plates you will see the HDD, wifi m-sata module and RAM. You will also see the bios battery (next to the HDD).

i like always i advise you to make a map/plan of the laptop. where the screws were attached , where connectors are attached.. etc. I tape my screws to the map i draw. You can also use the magnetic project map here on ifixit.


⚠ Be very carefull removing the HDD connector it is not that strong

Step 2 — removing the HDD




- now remove the hdd by loosen the connector.
- ⚠ Be VERY gently with the connector. Use IC pliers to loose the connector.
- mine was already broken when i bought the laptop.
- after you removed the connector, lift the hdd to one side and pull (gently) it out.
- also remove the connector (flex cable) attached to the mainboard. see green circle in second picture.
- to loosen this connector use a spudger to lift the lid (lid of connector.) up. do it very gently.

Step 3 — remove RAM and Wifi




- now remove the RAM modules
- remove the two antenna's (white and black) en remove the screw of the m-sata module. the module will come towards you when you remove the screw. the antenna's are in the green circle and the screw is in the red circle.

Step 4 — mainboard screws




- remove the 2 screws from the mainboard and the usb module.

Step 5 — removing the screws..




- now we will remove the screws of the case...
- remove the screws in the red circles.
- remove the screw in the blue circle , this is the screw from the dvd bay. You can remove this by using a metal spudger or a isesamo iopener.

Step 6 — remove screws keyboard





- now we remove the screws from the keyboard.

Step 7 — ssd place and DC connector




- in the orange square you'll see the place to put an SSD in. (m-sata)
- in the red circle you'll see the connector of the DC jack.
- if you remove the DC jack do this with an IC pliers.

Step 8 — Removing keyboard



- turn the laptop arround so you can open the lid.
- use a screwdriver or a spudger to push the little black "fingers" from the keyboard away from the case. If you do it right you'll hear clicks.
- afterwards, lift the keyboard up and remove it from the mainboard connector. (lift up the little black lid (gently) en pull out the cable.)

Step 9 — getting closer..



- after removing the keyboard you'll see the metal case with screws and connectors. again : be very gently with removing cables from connectors. especially if its your first repair..
- picture 1 : red circle : connector remove it by gently pulling the little lid up and pull out the cable.
- picture 2 :red circle : screw, remove it. Orange circle : audio connector , remove it with IC pliers. Lime circle : connector , remove like others. Blue circle: connector remove like others.
- picture 3 : Green circle : audio, remove with IC pliers. Orange circle: power FAN connector , remove with IC pliers, Lime circle : power board connector , remove it very gently. Red circle : remove screw
- there was one other screw at the metal case, it's at the right side just above the dvd bay player. I don't have a picture..

Step 10 — opening the laptop



- use a isesamo opener or a spudger to open the case .
- slide your tool against the case , you will hear clicks.
- gently remove the upper plate. afterwards you will see the mainboard.


Step 11 — mainboard/ screen connector



! remove the screen connector. be very very gently.. pull the black flap (in the lime square) towards you .


- red circle : screw from mainboard.

Step 12 — mainboard connector to dvd




- remove the connector. this is the connector from the sata connector dvd player bay.
- It is possible to replace the dvd bay with a HDD bay.

Step 13 — removing the fan



- remove the big screw you see in picture 1
- *(i)* we can remove the fan for taking out the mainboard or to clean the fan, or replace the fan.

Step 14 — removing the mainboard



- we will remove the mainboard in different steps.
- first remove the screw(s) of the mainboard. i had only one screw left , the others were disappeared. the first owner tried to repair the laptop.. but we know now that it has not turned out well..
- now we will remove the usb module .. Remove the screw in the red circle, the audio cable in the orange circle and remove the screw at the green circle. This is the screw from the DC jack metal plate.


Step 15 — removing the mainboard part 2



- lift the mainboard up and remove it from the case. the picture's are not in order so follow my explanation instead and see the picture's just as help.
- after lifting up the mainboard tilt the motherboard so you can remove the DC connector.

⚠ in the second picture you see the DC connector. be very gently if you remove it ! use IC pliers.

Step 16 — thermal paste and cooling parts.



- now the mainboard is free.
- in this case you can remove the CPU cooler. (the copper tubes) In that case remove the screws simultaneous.
- You can add (after cleaning the cpu and the copper with isopropyl alcohol.) some new thermal paste at the cpu and graphic chip.

 If you add some thermal paste for the first time : be carefull ,only put a very smal drop of paste at the cpu and graphic chip.

Step 17 — removing the screen...



- you can remove the screen or better sayed, replace the screen without tear down the laptop. just follow any other guide to replace a screen. normally speaking is it the same way.. thats why i didn't take pictures or guide you throuh this.
- thanks for watching, if you have questions, cantact me and i will try to help you. or examine other guides that i wrote (or other members) to learn about fixing laptops.

To reassemble your device, follow these instructions in reverse order.