



# How to Factory Reset Amazon Fire HD 8

How to reset Amazon Fire HD 8

Written By: John


## Settings

- Internet**  
Wi-Fi, Airplane Mode, Data Usage
- Connected Devices**  
Bluetooth, USB, Printing
- Apps & Notifications**  
Manage, Permissions, Default Apps
- Battery**  
28%
- Alexa**  
Hands-Free Mode, Screen lock access, Wake word, Communic...
- Display**

## INTRODUCTION


Follow this guide to reset your Amazon Fire HD8 to factory settings. **Doing so will erase all user data and user apps.**

## Step 1 — Open Settings




- Open the "Settings" app

## Step 2 — Tap "Device Options"



- Tap "Device Options" in the menu

## Step 3 — Factory Reset



- Tap "Reset to Factory Defaults"
- Follow the on-screen instructions to complete the reset.

**⚠️** Factory Reset will erase all settings and data to their original state.

Follow the on-screen instructions to finish the factory reset.