



Lenovo ThinkPad Yoga 260 Repair RAM Replacement

If you have a faulty RAM or you are upgrading it, this guide will help you replace it.

Written By: Daniel Fernandez



This document was generated on 2020-04-03 06:19:04 PM (MST).

INTRODUCTION

RAM or Random Access Memory, is a type of memory that temporarily stores information. If you have a faulty RAM or you are upgrading it, this guide will help you replace it.

TOOLS:

- [Phillips #1 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



(i) Ensure the device is off and unplugged.

- Remove the stylus from its port and set aside.

Step 2



- Using a Phillips #1 screwdriver, gently unscrew the eight 1.3 mm Phillips #1 screws until you hear an audible click.

(i) The screws will not separate from the bottom cover when loose.

Step 3



ⓘ The bottom cover is attached via several plastic clips located around the edges of the bottom cover.

- Using a plastic opening tool, gently pry the bottom cover from the laptop.
- Work the plastic opening tool around the edges of the bottom cover undoing all of the plastic clips, as shown in the picture.

Step 4



- Place your fingers around the edges of the cover and remove it.

Step 5 — RAM



- Using both thumbs, pinch the RAM's mounting clips outward.
- The RAM module will spring up on its own.

Step 6



- Gently remove it from its mounting.

To reassemble your device, follow these instructions in reverse order.