




Lenovo Thinkpad T450s RAM Replacement

How to replace the RAM on a Lenovo Thinkpad T450s. These instructions also apply to the Thinkpad T460s.

Written By: Hayden Hausman



INTRODUCTION

If you are looking to replace/upgrade the RAM on your device follow this guide for step by step instructions on how to do so.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

Step 1 — Battery



- Turn off device before starting
- *(i)* Flip the laptop upside down so you have access to the battery.

Step 2




- Slide lock button 1 to the unlock position and gently slide away from your body.

Step 3



- Slide lock button 2 to the unlock position and continue gently sliding until the battery is removed.

Step 4 — Lenovo Thinkpad T450s Bottom Panel Removal



- Flip the device over and lay it down with the underside facing upwards.
- Unscrew all 7 screws. Note that they do not come out completely.

Step 5




- Pry the bottom from the computer until it pops out.

Step 6 — RAM




- Pull one side of the prong that is holding the RAM in place

Step 7



- Pull the other side prong until the RAM pops up.

Step 8



- Pull the RAM out of the device

To reassemble your device, follow these instructions in reverse order.