



Lenovo X1 Carbon Laptop Keyboard Replacement

This guide will show how to replace a full keyboard on a Lenove X1 Carbon Series Laptop.

Written By: Christopher Thormodson




INTRODUCTION

This guide outlines how to replace a keyboard on a 2nd generation Lenovo X1 Carbon laptop. These laptops are quite compact, which results in a keyboard replacement being a very involved process. This process includes removing almost every other part of the laptop first.

TOOLS:

- [Spudger \(1\)](#)
- [Arctic Silver Thermal Paste \(1\)](#)
- [Phillips #000 Screwdriver \(1\)](#)
- [Phillips #0 Screwdriver \(1\)](#)

Step 1 — Keyboard



(i) These screws can't be fully removed; they will stay attached to the back cover.


- Loosen the seven screws from the back cover.

Step 2





- Unplug the bundled cable connector attached to the battery by pulling evenly from each side of the plug.
- Remove the four 4mm screws from the corners of the battery.
- Remove the 2.5mm screw from the center of the battery.
- Remove the battery by lifting from the bottom edge and pulling towards the front edge.

Step 3




- Remove the 3mm screw from the solid state drive.
- Pull the solid state drive straight out from its connector to remove it.

Step 4





- Unplug the Local Area Network Card by prying the coaxial connectors straight up from the board.
- Unscrew the 3mm screw from the LAN card.
- Pull the LAN card straight out from its connector to remove it.

Step 5



- Unplug the CPU heatsink fan by flipping up the small locking flap on the ZIF connector and gently removing the cable.

Step 6




- Loosen the upper-left heat pipe screw.
- Loosen the lower-right heat pipe screw.
- Loosen the lower-left heat pipe screw.
- Loosen the upper-right heat pipe screw.
- Lift the CPU cooler straight up to remove it.

Thermal paste will need to be applied during reassembly.


- Apply a small amount of thermal paste across the processor case.

Step 7




- Unscrew the 4mm screw from the audio card.
- Pull the audio card straight back from the side of the laptop and flip it over, exposing the flat topped connector.
- Disconnect the flat topped connector by pulling straight up from its socket.
- Remove the audio card.

Step 8





- Unplug the laptop speakers by pulling evenly on each side of the bundled cable connector.
- Remove the four 4mm screws from the speakers.
- Remove the speaker wires from under the tape loops along the front of the laptop.
- Lift the speakers and speaker wires straight up to remove them.

Step 9




- Disconnect the RJ45 ribbon cable by pulling straight up.
- Remove the 4mm screw from the RJ45 card.
- Move the RJ45 card slightly to the right and pull up to remove it.

Step 10



- Remove the two 2.5mm screws from the guard.
- Pull the guard straight up to remove it.
- Slide the bottom plastic part of the ribbon cable socket forward.
- Disconnect the ribbon cable.
- Lift the fingerprint reader assembly straight up to remove it.



Step 11



! Do not subject the system board to excessive shock or electrostatic discharge of any sort.

- Remove the 4mm screw from the guard in the upper-right corner of the laptop.


Step 12



! Do not subject the system board to excessive shock or electrostatic discharge of any sort.

- Lift the ribbon cable locking mechanism.
- Disconnect the ribbon cables by pulling straight out from the socket.
- Disconnect the ribbon cables by pulling straight up.

Step 13



⚠ Do not subject the system board to excessive shock or electrostatic discharge of any sort.


- Remove the five 3mm screws from the system board.
- Move the system board slightly to the left and pull up to remove it.

Step 14




- Remove the 4mm screw from the guard.
- Pull the guard straight up to remove it.
- Remove the three 4mm screws from the LCD hinges.
- Pull the antenna wires away from the hinges.

Step 15




- Lift the laptop and open the screen 90 degrees.
- Lift the LCD unit straight up to remove it.

Step 16



- Remove the two 1.7mm screws from the bracket.
- Pull the guard straight up to remove it.
- Remove the two 1.7mm screws from the adaptive keys panel.
- Remove the three 2.5mm screws from the adaptive keys panel.
- Lift the adaptive keys panel from the rear of the laptop and pull to remove it.

Step 17



- Lift the ribbon cable locking mechanism.
- Disconnect the ribbon cable.
- Remove the remaining ribbon cables from the back of the keyboard.

Step 18



- Remove the 45 Xmm screws from the back of the keyboard that are visible.
- Remove the tape covering one of the Xmm screws and remove that screw.
- Peel back the large ribbon cable and remove the four Xmm screws underneath it.
- Lift the keyboard straight up to remove it.

To reassemble your device, follow these instructions in reverse order.