




Lenovo Yoga Tab 3 8 Back Cover Replacement

Opening the back of the Lenovo Yoga Tab 3 8

Written By: Nicklaus Krems



 **TOOLS:**

- [Tweezers \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)

Step 1 — Back Cover



- Open the kickstand by pressing the release button in the center.
- Remove the identification sticker with a pair of tweezers to allow access to the two 2mm screws underneath.

Step 2



- Remove the three 2mm screws under the kickstand with a PH00 screwdriver.

(i) The third 2mm screw to the right may have an S sticker covering it which you can scrape off.

Step 3



- Starting along the edge opposite of the hinge, insert a plastic opening tool between the screen and the backing to begin separating the small clips holding the backing on.
- Work along the edge and then up the sides, separating the clips with the plastic opening tool.

i There is adhesive underneath the slot for the SD card so you will need to slowly apply some force to break the adhesive.

! As the back is separated from the device, be careful to not lose the power button. It may come loose and fall out.

To reassemble your device, follow these instructions in reverse order.