



Motorola MC5590 Speaker Replacement

This guide will help the user break down the Motorola MC5590 in order to replace the internal speaker.

Written By: Tyler Jean



INTRODUCTION

The speaker is a vital component of your Motorola MC5590. It signifies a successful scan, and you may feel lost without it. But do not worry, because we can show you how to replace a faulty speaker!

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Phillips #000 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — Battery




- Push in the battery release button.

Step 2



- Pull out battery.

Step 3 — Keyboard



- Remove the two rubber plugs on the top of the device by pushing them up and out of the phone.

Step 4



- Remove the four 1cm Phillips #0 screws from the top and bottom of the phone.

Step 5




- Use a plastic opening tool to remove the keyboard cover by prying up on its perimeter.

Step 6




- Remove the eight 4mm Phillips #00 screws from the keyboard cover.

Step 7




- Remove the keyboard cover.

Step 8



- Use a spudger to flip up the retaining flap on the keyboard ribbon cable [ZIF](#) socket.
- Pull the ribbon cable out of the socket.

Step 9




- Use a spudger to flip up the retaining flap on the display ribbon cable [ZIF](#) socket.
- Remove the keyboard from the device.

Step 10 — Speaker




- Pull the black rubber tabs up gently and remove them.

Step 11





- Using your finger, or spudger, push the motherboard out from the bottom.

Step 12



- Remove the three Phillips #00 screws from the motherboard:
 - Two 3mm screws.
 - One 1mm screw.

Step 13



- Disconnect the speaker from the motherboard.

To reassemble your device, follow these instructions in reverse order.