



Motorola Moto E4 Plus Earpiece Replacement

This guide will provide you with the necessary steps to remove the Earpiece from the Motorola Moto E4 Plus.

Written By: Jack Haseman



INTRODUCTION

For the official, updated iFixit guide, [click here](#). This guide is archived for historical purposes.

This guide is helpful for users who are having difficulty with sound quality, clarity, or volume while taking a phone call.

TOOLS:

- iFixit Opening Picks set of 6 (1)
- Phillips #00 Screwdriver (1)
- ESD Safe Tweezers Blunt Nose (1)
- Spudger (1)
- T4 Torx Screwdriver (1)
- Precision Tweezers Set (1)

PARTS:

- Moto E4 Plus Replacement Battery (2)
- Moto E4 Plus Battery Adhesive Strips (2)
- Motorola HE50 Battery (3)
- Moto E4 Back Camera (2)
- Moto E4 Motherboard (1)
- Moto E4 Earpiece Speaker (1)

Step 1 — Back Plate and Battery



- Insert the spudger into the notch on the corner of the phone and lift up to remove the back case.

Step 2



- Use the [T4 Torx Screwdriver](#) to remove the [17 3.2 mm screws](#) in the back panel covering the battery.

Step 3




- Lift up and remove the back panel.

Step 4




- After removing the back panel, use the spudger to lift and detach the Battery Flux Cable from the Motherboard.

Step 5




- Wedge the spudger between the battery and the phone to lift the battery up and remove the battery. There will be slight resistance to this but the battery will not be damaged by this. It is just the adhesive tape.

Step 6 — Rear Camera




- Use a pair of tweezers to peel up the copper tape that covers the rear camera flex connector.
- Fold the copper tape out of the way.

Step 7



- Use the flat end of a spudger to pry up and disconnect the rear camera flex cable.

Step 8



- Carefully remove the rear camera with a pair of tweezers.

Step 9 — Motherboard



- Use the T4 Torx Screwdriver to remove the 2 3.2 mm screws circled in the image.

Step 10



- Use the Spudger to lift up and detach the Main Flex Cable from the Motherboard.

Step 11



- Use the Spudger to lift up and detach the LCD Screen Flex Cable from the Motherboard.

Step 12



- Use the Plastic Spudger to lift up and detach the Signal Flex Cable from the Motherboard. The Signal


Flex Cable should still be attached to the body of the phone.

Step 13



- Use the Spudger to lift up and remove the Motherboard from the phone.

Step 14 — Earpiece Speaker



- Use the Plastic Spudger to remove the Earpiece Speaker from the phone.

To reassemble your device, follow these instructions in reverse order.