



# Nikon Coolpix S3100 disassembly

This is prerequisite to disassemble the camera.

Written By: Jorge



## INTRODUCTION

Follow these first three steps to accomplish the next guides.

### TOOLS:


- [Phillips #000 Screwdriver \(1\)](#)

## Step 1 — Nikon Coolpix S3100 disassembly



- Remove 8-2.46 mm screws from both sides and bottom of camera using a #000 Phillips screwdriver.
  - Remove 2 screws from left side. (picture 1)
  - Remove 4 screws from bottom. (picture 2)
  - Remove 2 screws from right side. (picture 3)


## Step 2



- Remove black cover pulling up with left thumb. Hold silver cover with right thumb.
- Remove silver cover lifting up with left thumb. Hold the camera with right thumb.

**⚠** Once internal circuit board is exposed, the red and blue wire terminals at top center can provide a nasty shock from the charged flash capacitor (silver can to left of terminals). BE CAREFUL!

## Step 3



- Remove 2-2.10mm screws in the front of the camera using a #000 Phillips screwdriver.
  - Remove the two screws.
- Gently pull up to detach the frame. (picture 2)

To reassemble your device, follow these instructions in reverse order.