



# Playstation Classic Open Button Replacement

This guide will show you how to take apart the Open Button on the PlayStation Classic.

Written By: Maxwell Webb



## INTRODUCTION

This guide will show you how to replace the “Open” button on the PlayStation Classic.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Jimmy](#) (1)
- [Spudger](#) (1)

## Step 1 — Motherboard



- Flip the console so its back is facing up.

## Step 2




- Remove the five 3mm screws using the Phillips #00 screwdriver.
- Make sure to keep your screws together in a secure location to avoid misplacement.

## Step 3



- Remove the back plate from the rest of the console using your hands or the Jimmy tool.

## Step 4




- Unscrew the motherboard's five 3mm screws with the Phillips #00 screwdriver.

**⚠** Be careful not to apply too much force. The motherboard is flimsy and easy to break.


**📌** Keep track of your screws once they are removed.

## Step 5



- Carefully remove the motherboard from the the rest of the console using your hands or the Jimmy tool.

## Step 6



- The motherboard is connected to its metal protective casing with sticky pads. No tools are required to remove it.
- Pull the metal casing off the motherboard.


**⚠** Remember to be gentle when handling the motherboard.

## Step 7 — Open Button



- Remove the motherboard using the previous guide and isolate the top shell of the casing.
- Use the Spudger to apply pressure inwards on the three plastic clips highlighted in the red circles.

## Step 8



- After all three clips are pushed in, apply pressure on the cylindrical piece circled in red.
- Push softly on the button till a small gap is created on the other side.

ⓘ You are not trying to fully remove the Open Button in this step.

## Step 9



- Use the black spudger to softly pry out the open button from the top of the casing.
- Once enough of a gap has been created, use your fingers to grab and slowly remove the open piece.

⚠ An unrestrained string is under the open button and can fall out easily. To avoid losing the spring, complete this step on a flat surface and be gentle while removing the open button.

To reassemble your device, follow these instructions in reverse order.