




Polycom SoundStation Microphone Replacement

This guide will show you how to replace the microphones in your SoundStation if they are not working properly.

Written By: Cali Nowak Credit



This document was generated on 2019-09-20 01:11:31 PM (MST).

INTRODUCTION

Removing the microphones will allow you to replace them or fix up the connections if your phone is not picking up sound.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)

Step 1 — Back Housing




- Flip the device over. Using a Phillips #00 screwdriver, remove the black 10mm screw on each three legs of the phone.
- Using a Phillips #00 screwdriver, remove the two silver 7mm screws as pictured.

Step 2





- Gently lift and separate the back housing from the rest of the device. Now you've got the back housing off!

Step 3 — Microphone



- Gently remove the yellow padding that covers the red and gray microphone wire on each phone leg.

Step 4



- Gently pull up on the black plastic tab connected to the motherboard to disconnect each microphone.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-20 01:11:31 PM (MST).

