



Razer Blade RZ09-0102 Heat Pipe Replacement

This guide will provide steps to remove and replace the heat pipes/heat sink for the Razer blade RZ09-0102 Laptop.

Written By: Kade Gonzalez



INTRODUCTION

The purpose of heat pipes is to draw unwanted heat from the other components of the computer. You may want to remove the heat pipes if the computer is overheating to clean out the heat sinks on the end of the pipes. If the heat pipes are damaged and not working properly they should be replaced. The heat pipes are also required to be removed to work on some other components in this device.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [T5 Torx Screwdriver](#) (1)

Step 1 — Rear Panel



- Using a Torx T5 screwdriver, remove the ten 1/8 inch screws.

Step 2 — Heat Pipes



- Using a Phillips #0 screwdriver, remove the six 8 mm screws holding the cooling rod to the motherboard .

Step 3



- Lift the cooling rod straight up and out of the laptop.

To reassemble your device, follow these instructions in reverse order.