




Razer Blade Stealth (2018) WiFi Card Replacement

This guide outlines how to replace the WiFi card in the Razer Blade Stealth 2018.

Written By: Helene Willits



This document was generated on 2020-01-09 02:23:42 AM (MST).

INTRODUCTION

This guide outlines how to replace the WiFi card if it does not connect to the internet. If the computer does not detect any WiFi connections, the WiFi card may be damaged. Be sure there is a connection available and working before replacing the WiFi card. Some iFixit tools are required for this replacement.

TOOLS:

- [T5 Torx Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)
- [Small Plastic Spudger](#) (1)

Step 1 — Battery



⚠ Ensure the laptop is fully powered off before beginning!

- Use a Torx T5 screwdriver to remove the eight, 3mm screws on the bottom cover of the laptop.
- Whenever removing screws from the device, remember to save and label them.


Step 2



- Remove the bottom cover of the laptop by sliding it away from the hinge.


⚠ Do not force the cover up!

Step 3




- Gently disconnect the battery from the motherboard by lifting up on the connector.

Step 4



- Use a Phillips #00 screwdriver to remove the six, 5mm screws securing the battery.


Step 5



(i) Remove any tape attached to the battery.

- Use the plastic spudger to pry out the battery.


Step 6 — WiFi Card



(i) Remove any tape attached to the WiFi card.


- Use a plastic spudger to disconnect the two coaxial antennae connectors and expose the WiFi card.

Step 7



- Use a Phillips #00 screwdriver to remove the single, 2 mm screw from the WiFi card.

Step 8



- Remove the WiFi card from the motherboard by sliding it out at an angle.

To reassemble your device, follow these instructions in reverse order.