



Sony Walkman NWZ-E353 Navigation Key Replacement

Use this tutorial to replace the 5 way navigation key on the Sony Walkman NWZ-E353


Written By: Dina Rafanomezantsoa



 **TOOLS:**

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

Step 1 — 5-way navigation key



- Before you start, turn off your player.

Step 2



- Unscrew the two Phillips screws on the back of the drive.

Step 3



- Use a plastic opening tool to pry on the edges of the drive.
- Once the cover is detached from the front panel of the player, be careful not to lose the volume key.
- Also be careful not to lose the small room below the Hold switch (see image 2)

Step 4



- Remove the single Phillips screw that holds the front panel and the interior components of the drive.

Step 5



- The interior components of the reader are held by 4 plastic clips.
- Be careful not to break them by removing the display assembly, battery and the motherboard.

Step 6



- Remove the 5-way navigation key.

To reassemble your device, follow the instructions in reverse order.