



Sony Xperia Z5C Teardown

Here is Sony Xperia Z5 Compact teardown. This step-by-step guide will show you how to disassemble Xperia Z5 Compact and show all components inside.

Written By: Witrigs



INTRODUCTION

Here is Sony Xperia Z5 Compact teardown. This step-by-step guide will show you how to disassemble Xperia Z5 Compact and show all components inside.

[video: <https://www.youtube.com/watch?v=cBMxYINFyjo>]

TOOLS:

- Heat Gun (1)
- iFixit Opening Picks set of 6 (1)
- Phillips #1 Screwdriver (1)
- Spudger (1)
- Tweezers (1)
- Suction Handle (1)

Step 1 — Sony Xperia Z5C Teardown




- Power off and remove SIM card tray.

Step 2



- Heat up the back cover to soften the adhesive.
- Place the suction cup to open a gap from top side, then insert guitar picks and slide it to cut the adhesive underneath.
- Remove back cover.

Step 3



- Twist off 10 Phillips screws all.
- Loosen NFC clip and flashlight clip.

Step 4




- Remove the plastic bracket.
- Pry up and remove back frame.

Step 5



- Remove front camera.

Step 6



- Remove earpiece.

Step 7



- Remove rear camera.

Step 8




- Remove loudspeaker.

Step 9




- Release charging port connector.
- Remove plastic protective bar.
- Pry up motherboard assembly from this side. There are three flex connectors connecting the motherboard underneath. So pry up the motherboard assembly gently.
- The motherboard may be attached to the case by a sticky pad near the charging connector. This can be dislodged by very carefully rotating the motherboard side to side, checking that the flex connectors aren't being stretched.

Step 10




- Push audio jack out of the slot, no adhesive underneath.
- Release LCD flex connector and main flex connector.
- Separate motherboard assembly from middle housing.

Step 11




- Remove audio jack flex by flipping up white locking tab.

Step 12




- Remove flashlight flex by flipping up white locking tab.

Step 13



- Remove microphone flex by flipping up white locking tab.

Step 14




- Take away NFC antenna on battery.

Step 15




- Release battery connector and pull off adhesive tapes underneath.
- Pry up and remove battery.

Step 16




- Here is the motherboard only.

Step 17



- Remove charging port flex.

Step 18



- Loosen adhesive underneath vibration motor.
- Loosen side button assembly. There is fingerprint scanner here, be careful.
- Loosen noise canceling microphone.

Step 19



- Loosen all adhesive underneath side button flex assembly.
- Here is side button flex assembly. It's integrated by vibration motor, side button connector, fingerprint scanner connector and noise-canceling mic.

Step 20



- The sticker underneath LCD assembly is a little bit strong, so use heat gun to soften it for a few minutes.
- Remove LCD with digitizer assembly carefully.

Step 21



- Done.