



Weed Whacker Line Replacement

How to replace the line in a self-feeding weed whacker bump head.

Written By: Hannah Akey



INTRODUCTION

This is a general instruction for an audience with limited mechanical skills, to replace the line in a generic bump head weed whacker. Before beginning this guide turn off the machine.

Step 1 — Line



- Remove cutting line guard from weed whacker. This is usually attached by a wing-nut or a bolt and nut, so it can be removed either by hand or with the correct sized wrench.

Step 2



- Flip weed whacker upside down so that bottom of cutting piece is facing up.

Step 3



- There will be a bottom cap of the rotor setup that needs to be removed. In some models this will be held on with a nut and bolt fixture, but in many models there will be a circular cap that can be rotated counter clockwise for removal. Remove this piece in the manner necessary.

Step 4




- Once the bottom piece is removed, there will be another circular piece that may or may not have cutting line coiled around it. Remove this piece from the weed whacker.

Step 5




- There should be slots to coil cutting line around, with a hole in each for line to be anchored. If no line is coiled around the part, insert the end of about three feet of cutting line into each of the holes, and coil the cutting line snugly around the part, making sure that there are no tangles in the line.

Step 6



- If there are plastic tabs on the plastic part to hold the cutting line, insert each line into one of these tabs. Leave approximately a foot of each line hanging out from the coils.

Step 7



- On the weed whacker rotor, there will be eyelets for the cutting line to be fed through. Feed each line through each of these eyelets, being careful not to let the line come uncoiled.

Step 8




- Replace the plastic piece with the cutting lines back onto the rotor, being sure that the coils remain in place, and the lines remain in place through the eyelets.

Step 9



- Replace the cap that was removed at the beginning of the assembly.

Step 10



- Replace the cutting line guard.